# JAPANESE Car & Truck CATALOG

SNT AUTOPART GROUP

www.sntautopart.com

# 1. FOREWORD

**Rubber parts are in our DNA.** It's not marketing speak. SNT produce only the highest quality products. If you need something custom, our engineering and design team can help assist with your unique rubber part requirements with our warranty guarantee. **We are different and we want to show why that's good for you.**

We know that having the right part at the right time is crucial to your operation. Under the SNT brand, we carry more than 30,000 SKUs.

We believe the best method to get our products to the customer is through strategic alliances with our distribution partners. Our commitment to our distributors, and the ultimate user, is to constantly introduce new and innovative products at higher levels of quality with an emphasis on compressed lead times - products that will last longer and reduce overall maintenance costs. All of our employees have a "can do" attitude and take pride in helping customers. **You have a problem? We have a solution.** All we ask is the chance to prove ourselves; you won't be disappointed!

# 2. INTRODUCTION

**SNT AUTOPART GROUP** is a leading manufacturer of replacement parts. For over 30 years experience, SNT supplies the high quality rubber parts successfully. We win worldwide clients' trust based on **premium quality of products, excellent service and competitive price.**

Our top executive has more than 7 years of R&D experience at the top 3 automobile companies in the world, create a perfect knowledge of products. Moreover, SNT products are manufactured according to German standard (DIN) and ISO 9001 quality management system. So we guarantee to

**"SNT products are the same characteristics of original spare parts with competitive price"**

SNT AUTOPART GROUP is comprised of the following companies:

1. SNT AUTOPART ENTERPRISE, LLC. (New York, U.S.A.)
2. SNT AUTOPART INTERTRADE Co., Ltd. (Bangkok, Thailand)
3. SNT MACHINE Ltd., Part. (Bangkok, Thailand)

# 2.1 ISO 9001 CERTIFICATION

globalgroup®
Management System Experts

## Certificate of Registration

*This is to certify that the*

**QUALITY MANAGEMENT SYSTEM**

*of*

**S.N.T. MACHINE LTD., PART.**

**18/3 Soi Bangkradee19 Yeak6, RAMA II Road, Bangkhuntien, Bangkok, 10150, THAILAND**

*for*

**Design and Manufacture of Rubber Parts and Stamping Parts, Oil Seals, Rubber Bushings, Torque Rod Bushings, Engine Mounts for Automotives, Motorcycles and Industrial Machineries.**

*has been assessed and registered against the provisions of*

**ISO 9001:2008**

*International Standard*

*With*

| | | | |
|---|---|---|---|
| Registration Number: | 44Q16937 | Project: | 11-16937-1-Q |
| Certification Date: | 11 December 2015 | Code: | DH 25.13 |
| Recertification Due Date: | 14 September 2018 | Exclusions: | 7.5.4, 7.5.2 |
| Certification Approved By: | | Alan Cherry | |
| | | Chairman | |

Registration is subject to the management system being continually maintained to the above standard under regular surveillance. Should surveillance not take place when required, registration shall be removed.

This certificate is the property of GlobalGROUP of Companies Limited
21 Lansdowne Crescent, Edinburgh, Midlothian, EH12 5EH, Scotland, United Kingdom

UKAS MANAGEMENT SYSTEMS
0039

Please validate the authenticity of the certificate at www.globalgroup.net

30002530

# 3. SNT WARRANTY

SNT, warrants that all products sold shall be free from defects in material and workmanship for period of one year from date of shipment. At our option, any products prove to be defective either in workmanship or material whereby it is not suitable under proper usage and service for the purpose for which designed shall be replaced free of charge including transportation charges, but not the cost of installation, providing that the products are not subject to negligence, accident, or damages beyond our control. We shall not be responsible for consequential damages.

# 4. MEMBERSHIPS

SNT AUTOPART GROUP is long standing members and supporter of the following associations.

1) THE FEDERATION OF THAI INDUSTRIES
2) THE THAI CHAMBER OF COMMERCE
3) THAILAND AUTOMOTIVE INSTITUTE
4) THAI AUTO PARTS MANUFACTURERS ASSOCIATION

THE FEDERATION OF THAI INDUSTRIES

THAILAND AUTOMOTIVE INSTITUTE สถาบันยานยนต์

สมาคมผู้ผลิตชิ้นส่วนยานยนต์ไทย TAPMA Thai Auto - Parts Manufacturers Association

# CONTENT

| | Page |
|---|---|
| 1. Foreword | I-1 |
| 2. Introduction | I-2 |
| 2.1 ISO 9001 Certification | I-3 |
| 3. SNT Warranty | I-4 |
| 4. Memberships | I-4 |
| 5. Seal product list - Interchange for | |
| 5.1 TOYOTA | 4 – 192 |
| 5.2 HONDA | 193 – 238 |
| 5.3 NISSAN | 239 – 365 |
| 5.4 NISSAN DIESEL / UD | 366 – 399 |
| 5.5 MITSUBISHI / FUSO | 400 – 544 |
| 5.6 MAZDA | 545 – 595 |
| 5.7 ISUZU | 596 – 670 |
| 5.8 HINO | 671 – 717 |
| 5.9 SUZUKI | 718 – 741 |

## Content Remarks

All rubber parts in this catalogue are specially manufactured by SNT. The O.E.M. Part No., Interchange Part No., Auto maker name, and all other trademarks mentioned in this document are the property of their respective owners and are used for identification purposes only.

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5371 | 90311-89001 | 89 x 105 x 10 | ALTEZZA 3SGE..SXE10 | 98/10~ | Engine CRANK SHAFT REAR |
| 03901 1037 | 90311-29001 | 30 x 42 x 7 | ALTEZZA SXE10 | 98/10~ | Transmission (M/T) FRONT COVER |
| 03901 7325 | 90311-38032 | 38 x 58 x 11 | ALTEZZA SXE10 | 98/10~ | Transmission (M/T) EXTENSION HOUSING |
| 03901 3109 | 90311-48013 | 48 x 73 x 7 | ALTEZZA GXE10, SXE10 | 98/10~ | Wheel Hub FRONT |
| 03901 3527 | 90913-02115 | | ALTEZZA 3SGE (EX) | 98/10~ | Engine VALVE STEM SEAL |
| 03901 5051 | 90913-02093 | | ALTEZZA 1GFE (IN & EX) | 98/10~ | Engine VALVE STEM SEAL |
| 03901 7403 | 90311-75007 | 75 x 100 x 10 | ALTEZZA 1GFE GXE10 | 98/10~ | Engine CRANK SHAFT REAR |
| 03901 4397 | 90311-42026 | 42 x 60 x 7 | ALTEZZA 3SGE SXE10 | 98/10~ | Engine CRANK SHAFT FRONT |
| 03901 2789 | 90311-45015 | 45 x 62 x 9 | ALTEZZA 1GFE GXE10 | 98/10~ | Engine TIMING GEAR CASE |
| 03901 2909 | 15165-70010 | 18 x 30 x 7 | ALTEZZA 1GFE GXE10, 3SGE SXE10 | 98/10~ | Engine OIL PUMP |
| 03901 2539 | 90311-38032 | 38 x 58 x 11 | ALTEZZA GXE10 | 98/10~ | Transmission (A/T) EXTENSION HOUSING |
| 03901 8247 | 90913-02114 | | ALTEZZA 3SGE (IN) | 98/10~ | Engine VALVE STEM SEAL |
| 03901 2209 | 90311-38029 | 38 x 58 x 11 | ALTEZZA SXE10 | 98/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4731 | 90311-46004 | 46 x 60 x 6.5 | ALTEZZA 3SGE SXE10 | 98/10~ | Engine CAM SHAFT |
| 03901 3211 | 90311-40001 | 40 x 58 x 11 | ALTEZZA SXE10 | 98/10~ | Transmission (A/T) EXTENSION HOUSING |
| 03901 7897 | 90311-38070 | 38 x 74 x 11 x 19 | ALTEZZA GXE10, SXE10 | 98/10~ | Final Drive PINION |
| 03901 4165 | 90311-38071 | 38 x 63 x 10 x 16.5 | ALTEZZA GXE10, SXE10 | 98/10~ | Final Drive DIFF. SIDE |
| 03901 2487 | 04445-53010 | | ALTEZZA GXE10, SXE10 | 98/10~ | Steering (P/S) R&P GASKET KIT |
| 03901 4021 | 90311-19002 | 19 x 32 x 7 x 8 | ALTEZZA GXE10, SXE10 | 98/10~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1685 | 90310-25027 | 25 x 38 x 7 | ALTEZZA GXE10, SXE10 | 98/10~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6929 | 90311-38020 | 38 x 55 x 8.5 | ALTEZZA GXE10 | 98/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 5575 | 90913-02106 | | ARISTO 1UZFE(EX.) UZS143 | 96/8~97 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5055 | 90311-43004 | 43 x 60 x 7 | ARISTO 1UZFE UZS143 | 92/10~97 | Engine OIL PUMP |
| 03901 3117 | 90311-46001 | 46 x 63 x 6.5 | ARISTO 2JZ#...JZS147,16# | 91/10~ | Engine CRANK SHAFT FRONT |
| 03901 3361 | 90311-90006 | 90 x 110 x 9.5 | ARISTO 2JZ#...JZS147,16# | 91/10~ | Engine CRANK SHAF REAR |
| 03901 2737 | 90311-95006 | 95 x 113 x 10 | ARISTO 1UZFE UZS143 | 92/10~97 | Engine CRANK SHAF REAR |
| 03901 7993 | 90913-02062 | | ARISTO 2JZ#...JZS147 | 92/10~97 | Engine VALVE STEM SEAL |
| 03901 6457 | 90913-02113 | | ARISTO 1UZFE(IN.) UZS143 | 96/8~97 | Engine VALVE STEM SEAL |
| 03901 3525 | 90311-38036 | 38 x 50 x 8 | ARISTO 1UZFE UZS143 | 92/10~97 | Engine CAM SHAFT |
| 03901 3179 | 90913-02062 | | ARISTO 2JZ#(EX.) JZS16# | 97/8~ | Engine VALVE STEM SEAL |
| 03901 3897 | 90311-50008 | 50 x 77.5 x 9 x 14 | ARISTO JZS147 | 91/10~97 | Wheel Hub FRONT |
| 03901 8187 | 90913-02079 | | ARISTO 2JZ#(IN.) JZS16# | 97/8~ | Engine VALVE STEM SEAL |
| 03901 6479 | 90311-42024 | 42 x 55 x 10 | ARISTO JZS147, 16#, UZS143 | 91/10~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 1741 | 90311-63001 | 63 x 90 x 7 x 10 | ARISTO JZS147, UZS143 | 91/10~97 | Wheel Hub REAR INNER |
| 03901 6121 | 90311-40020 | 40.5 x 52.5 x 6.5 | ARISTO 2JZ#...JZS147,16# | 91/10~ | Engine CAM SHAFT |
| 03901 3745 | 90311-57001 | 57 x 81 x 8 x 11 | ARISTO JZS147, UZS143 | 91/10~97 | Wheel Hub REAR OUTER |
| 03901 8253 | 90913-02079 | | ARISTO 1UZFE UZS143(IN.&EX.) | 91/10~96/ 8 | Engine VALVE STEM SEAL |
| 03901 3577 | 90311-38029 | 38 x 55 x 7.5 | ARISTO JZS147, 16#, UZS143 | 91/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7257 | 90311-47008 | 47 x 72 x 10 x 11 | ARISTO JZS147, 16#, UZS143 | 91/10~ | Final Drive DIFF. SIDE |
| 03901 6361 | 04445-30150 | | ARISTO JZS147 | 91,10~92/ 10 | Steering (P/S) R&P GASKET KIT |
| 03901 7517 | 90311-50008 | 50 x 77.5 x 9 x 14 | ARISTO JZS16# | 97/8~ | Wheel Hub FRONT |
| 03901 4081 | 04445-30230 | | ARISTO JZS147 | 92/10~97/ | Steering (P/S) R&P GASKET KIT |
| 03901 1509 | 04445-30240 | | ARISTO UZS143 | 92/10~97/ | Steering (P/S) R&P GASKET KIT |
| 03901 7607 | 04445-30252 | | ARISTO JZS16# | 97/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 1499 | 90311-19002 | 19 x 32 x 7 x 8 | ARISTO JZS147, 16#, UZS143 | 91/10~ | Steering (P/S) CONTROL VALE UPPER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4489 | 90311-30016 | 30 x 42 x 7 x 8 | ARISTO JZS147, 16#, UZS143 | 91/10~ | Steering (P/S) CONTROL VALE LOWER |
| 03901 4185 | 90311-44005 | 44 x 74 x 11 x 16 | ARISTO JZS147, 16#, UZS143 | 91/10~ | Final Drive PINION |
| 03901 4173 | 90311-19010 | 19 x 32 x 6 | AVALON MCX10 | 95/3~00/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4983 | 90913-02101 | | AVALON 1MZFE(IN.) | 95/3~00/ | Engine VALVE STEM SEAL |
| 03901 4209 | 90913-02111 | | AVALON 1MZFE(EX.) | 95/3~00/ | Engine VALVE STEM SEAL |
| 03901 2945 | 90311-92008 | 92 x 110 x 9 | AVALON 1MZFE MCX10 | 95/3~00/ | Engine CRANK SHAFT REAR |
| 03901 1767 | 90311-40022 | 40 x 55 x 6 | AVALON 1MZFE MCX10 | 95/3~00/ | Engine OIL PUMP |
| 03901 7691 | 90311-26003 | 26 x 38 x 6.5 | AVALON MCX10 | 95/3~00/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3289 | 04445-07010 | | AVALON MCX10 | 95/3~00/ | Steering (P/S) R&P GASKET KIT |
| 03901 4159 | 90311-38020 | 38 x 55 x 8.5 | AVALON MCX10 | 95/3~00/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4189 | 90311-50011 | 50 x 80 x 16.5 x 23 | AVALON MCX10 | 95/3~00/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 4909 | 90311-40010 | 40 x 56 x 9 x 15.5 | AVALON MCX10 | 95/3~00/ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 6355 | 90311-38034 | 38 x 50 x 10.5 | AVALON 1MZFE MCX10 | 95/3~00/ | Engine CAM SHAFT |
| 03901 4051 | 04445-52010 | | BB NCP35 (4WD) | 00/1~ | Steering (P/S) R&P GASKET KIT |
| 03901 5755 | 90311-34017 | 34 x 63 x 9 x 16 | BB NCP30 | 00/1~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 4591 | 90913-02093 | | BB 1NZFE,2NZFE (IN.& EX.) | 00/1~ | Engine VALVE STEM SEAL |
| 03901 7819 | 90311-75016 | 75 x 107 x 8 | BB 1NZFE,2NZFE NCP3# | 00/1~ | Engine CRANK SHAFT REAR |
| 03901 6135 | 90311-25021 | 25.5 x 37.5 x 6 | BB 1NZFE,2NZFE NCP3# | 00/1~ | Engine OIL PUMP |
| 03901 6199 | 90311-42055 | 42 x 55 x 7 | BB NCP35 (4WD) | 00/1~ | Wheel Hub REAR |
| 03901 3895 | 90311-38020 | 38 x 55 x 8.5 | BB NCP31,35 | 00/1~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2319 | 90311-38075 | 38 x 55 x 7.8 | BB NCP30 | 00/1~ | Mission & Differential (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6973 | 90311-38075 | 38 x 55 x 7.8 | BB NCP30 | 00/1~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 6943 | 90311-34022 | 34 x 56 x 9 x 15 | BB NCP35 (4WD) | 00/1~ | Mission & Differential (A/T) TRANSAXLE (NO.2) |
| 03901 2875 | 90311-34016 | 34 x 54 x 9 x 15.5 | BB NCP30,31 | 00/1~ | Mission & Differential (A/T) TRANSAXLE (NO.2) |
| 03901 4167 | 90311-34022 | 34 x 56 x 9 x 15 | BB NCP31 | 00/1~ | Mission & Differential (A/T) TRANSAXLE (NO.1) |
| 03901 1169 | 04445-52020 | | BB NCP30,31 | 00/1~ | Steering (P/S) R&P GASKET KIT |
| 03901 8205 | 90311-49002 | 50 x 64 x 8 | BB NCP35 (4WD) | 00/1~ | Mission & Differential (A/T) TRANSAXLE (NO.1) |
| 03901 4811 | 90311-42026 | 42 x 60 x 7 | BLIZZARD L,2L#...LD10,2# | 80/3~90/ | Engine TIMING GEAR CASE |
| 03901 2501 | 90311-85001 | 85 x 105 x 13 | BLIZZARD L LD10 | 80/3~84/2 | Engine CRANK SHAFT REAR |
| 03901 1515 | 90311-85004 | 85 x 105 x 10 | BLIZZARD L,2L#...LD10,2# | 84/2~90/ | Engine CRANK SHAFT REAR |
| 03901 1267 | 90913-02036 | | BLIZZARD L LD10 | 80/3~81/7 | Engine VALVE STEM SEAL |
| 03901 7027 | 90913-02060 | | BLIZZARD L,2L#...LD10,2# | 81/7~90/ | Engine VALVE STEM SEAL |
| 03901 5581 | 90311-42003 | 42 x 60 x 7 | BLIZZARD L,2L#...LD10,2# | 80/3~90/ | Engine CAM SHAFT |
| 03901 8055 | 90043-11166-000 | 50 x 62 x 9 | BLIZZARD LD2# | 84/5~90/ | Wheel Hub REAR OUTER |
| 03901 4115 | 90311-52059 | 52 x 65 x 9 | BLIZZARD LD2# | 84/5~90/ | Wheel Hub REAR INNER |
| 03901 1543 | 90043-11131-000 | 45 x 72 x 12 x 18 | BLIZZARD LD10,2# | 80/3~90/ | Final Drive PINION (F&R) |
| 03901 6527 | 90312-32002 | 32 x 40 x 5 | BLIZZARD LD2# | 84/5~90/ | Steering (P/S) GEAR HOUSING |
| 03901 7445 | 90043-11080-000 | 55 x 78 x 12 | BLIZZARD LD10,2# | 80/3~90/ | Wheel Hub FRONT |
| 03901 2317 | 90043-11081-000 | 32 x 48 x 8 | BLIZZARD LD10 | 80/3~84/ | Wheel Hub REAR INNER |
| 03901 7121 | 90043-11082-000 | 50 x 72 x 9 | BLIZZARD LD10 | 80/3~84/ | Wheel Hub REAR OUTER |
| 03901 6803 | 90043-11141-000 | 30 x 45 x 8 | BLIZZARD LD10,2# | 80/3~90/ | Transmission FRONT COVER |
| 03901 3359 | 04445-60020 | | BLIZZARD LD2# | 84/5~90/ | Steering (P/S) GEAR GASKET KIT |
| 03901 4525 | 90043-11086-000 | 32 x 52 x 8 | BLIZZARD LD10 | 80/3~84/ | Final Drive FRONT DIFF. SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4135 | 90043-11117-000 | 19 x 32 x 8 | BLIZZARD LD10,2# | 80/3~90/ | Steering (M/S) WORM GEAR |
| 03901 3087 | 90043-11168-000 | 34 x 44 x 8 | BLIZZARD LD2# | 84/5~90/ | Steering (M/S) SEKTOR SHAFT |
| 03901 7177 | 90913-02079 | | BREVIS 1JZFSE, 2JZFSE (IN.) | 01/5~ | Engine VALVE STEM SEAL |
| 03901 4279 | 90311-38029 | 38 x 55 x 7.5 | BREVIS JCG1# | 01/5~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2885 | 90913-02062 | | BREVIS 1JZFSE, 2JZFSE(EX.) | 01/5~ | Engine VALVE STEM SEAL |
| 03901 2689 | 90311-90006 | 90 x 110 x 9.5 | BREVIS 1JZFSE, 2JZFSE JCG1# | 01/5~ | Engine CRANK SHAFT REAR |
| 03901 7837 | 90311-46001 | 46 x 63 x 6.5 | BREVIS 1JZFSE, 2JZFSE JCG1# | 01/5~ | Engine CRANK SHAFT FRONT |
| 03901 8227 | 90311-34027 | 34 x 56 x 6 | BREVIS 1JZFSE, 2JZFSE JCG1# | 01/5~ | Engine CAM SHAFT |
| 03901 2641 | 04445-51011 | | BREVIS JCG1# | 01/5~ | Steering (P/S) RACK&PINION KIT |
| 03901 7031 | 90311-43001 | 43 x 70 x 9 x 15.5 | BREVIS JCG11 | 01/5~ | Final Drive DIFF. SIDE |
| 03901 6159 | 90311-38071 | 38 x 63 x 10 x 16.5 | BREVIS JCG10,15 | 01/5~ | Final Drive DIFF. SIDE |
| 03901 8229 | 90311-38070 | 38 x 74 x 11 x 19 | BREVIS JCG1# | 01/5~ | Final Drive PINION |
| 03901 2533 | 90311-40001 | 40 x 58 x 11 | BREVIS JCG1# | 01/5~ | Transmission (A/T) REAR EXTENTION |
| 03901 1749 | 90311-48013 | 48 x 73 x 7 | BREVIS JCG10,11 | 01/5~ | Wheel Hub FRONT |
| 03901 4333 | 15165-70010 | 18 x 30 x 7 | CALDINA 3SFE,4SFE ST19#,21# | 92/11~ | Engine OIL PUMP |
| 03901 3039 | 90311-38044 | 38 x 50 x 6 | CALDINA 2C#,3C#...CT19#,216 | 92/11~ | Engine CAM SHAFT |
| 03901 3509 | 90311-38036 | 38 x 50 x 8 | CALDINA 3SFE,4SFE ST19# | 92/11~97/8 | Engine CAM SHAFT |
| 03901 7111 | 90311-38067 | 38 x 50 x 8 | CALDINA 3SFE ST198,21# | 97/8~ | Engine CAM SHAFT |
| 03901 2597 | 90311-35041 | 35 x 60 x 11 | CALDINA 3SGE ST215 | 97/8~ | Engine CAM SHAFT (NO.1) |
| 03901 2575 | 90311-46004 | 46 x 60 x 6.5 | CALDINA 3SGE ST215 | 97/8~ | Engine CAM SHAFT (NO.2) |
| 03901 4987 | 90029-21022 | 22 x 34 x 6.5 | CALDINA 2C CT19# | 92/11~93/8 | Engine OIL PUMP |
| 03901 7157 | 90311-32020 | 32 x 46 x 6 | CALDINA 7AFE AT191,211 | 96/1~ | Engine OIL PUMP |
| 03901 7497 | 90310-25004 | 25 x 38 x 7 x 8 | CALDINA AT211,CT216,ST21#...TOYODAKOKI G/B | 97/8~ | Steering (P/S) CONTROL VALVE LOWER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6213 | 90029-21020 | 20 x 32 x 5 | CALDINA 5EFE ET196 | 92/11~ | Engine OIL PUMP |
| 03901 2921 | 90311-35013 | 35 x 49 x 6 | CALDINA 3SGTE ST215 | 97/8~ | Engine CAM SHAFT |
| 03901 6651 | 90311-35013 | 35 x 49 x 6 | CALDINA 3SGE ST195 | 95/2~97/8 | Engine CAM SHAFT |
| 03901 5509 | 90311-35013 | 35 x 49 x 6 | CALDINA 5EFE ET196 | 92/11~ | Engine CAM SHAFT |
| 03901 6925 | 90311-35013 | 35 x 49 x 6 | CALDINA 7AFE AT191,211 | 96/1~ | Engine CAM SHAFT |
| 03901 1619 | 90310-25004 | 25 x 38 x 7 x 8 | CALDINA AT191,CT19#,ST19#...TOYODAKOKI G/B | 92/11~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6847 | 90310-28003 | 28 x 41 x 6.5 | CALDINA AT191,ET196,ST191 TOYOTA G/B | 92/11~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6103 | 15165-70010 | 18 x 30 x 7 | CALDINA 3SG#...ST195,215 | 95/2~ | Engine OIL PUMP |
| 03901 3945 | 90311-89001 | 89 x 105 x 10 | CALDINA 3SG#...ST195,215 | 95/2~ | Engine CRANK SHAFT REAR |
| 03901 4413 | 04445-20210 | | CALDINA ET196 | 96/1~ | Steering (P/S) R&P GASKET KIT |
| 03901 7783 | 90311-19002 | 19 x 32 x 7 x 8 | CALDINA AT191,211,CT19#,216,ST19#,21# | 92/11~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7805 | 90310-28003 | 28 x 41 x 6.5 | CALDINA AT211,ST210 TOYOTA G/B | 97/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2261 | 90913-02062 | | CALDINA 5EFE (IN. & EX.) | 92/11~ | Engine VALVE STEM SEAL |
| 03901 6971 | 04445-20240 | | CALDINA CT196,197 | 96/1~ | Steering (P/S) R&P GASKET KIT |
| 03901 6347 | 90311-44003 | 44 x 80 x 9 x 15.5 | CALDINA ST195,198 4FC | 92/11~ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 3791 | 90913-02117 | | CALDINA 2C#,3C# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 7943 | 90913-02110 | | CALDINA 2C# | 96/1~97/4 | Engine VALVE STEM SEAL |
| 03901 1699 | 90913-02056 | | CALDINA 2C | 95/11~96/1 | Engine VALVE STEM SEAL |
| 03901 5191 | 90913-02094 | | CALDINA 2C | 92/11~95/11 | Engine VALVE STEM SEAL |
| 03901 5327 | 90913-02079 | | CALDINA 3SFE,4SFE (IN.) | 92/11~ | Engine VALVE STEM SEAL |
| 03901 8181 | 90913-02079 | | CALDINA 7AFE (IN.) | 96/1~ | Engine VALVE STEM SEAL |
| 03901 7861 | 90311-90008 | 90 x 110 x 9.5 x 11.5 | CALDINA 2C#,3C#...CT19#,216 | 96/1~ | Engine CRANK SHAFT REAR |
| 03901 7667 | 90913-02062 | | CALDINA 7AFE (EX.) | 96/1~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1113 | 90311-35013 | 35 x 49 x 6 | CALDINA 5EFE ET196 | 92/11~96/4 | Engine CRANK SHAFT FRONT |
| 03901 2757 | 90311-85007 | 85 x 105 x 10 | CALDINA 3SFE,4SFE ST19#,21# | 92/11~ | Engine CRANK SHAFT REAR |
| 03901 2077 | 90311-90005 | 90 x 110 x 8.5 x 10 | CALDINA 2C CT19# | 92/11~96/1 | Engine CRANK SHAFT REAR |
| 03901 5401 | 90311-70007 | 70 x 92 x 8.5 | CALDINA 7AFE AT191,211 | 96/1~ | Engine CRANK SHAFT REAR |
| 03901 6469 | 90311-80012 | 80 x 100 x 8.5 | CALDINA 5EFE ET196 | 92/11~ | Engine CRANK SHAFT REAR |
| 03901 7933 | 90311-42035 | 42 x 60 x 7 | CALDINA 3SGE ST19#,21# | 96/9~ | Engine CRANK SHAFT FRONT |
| 03901 7297 | 90311-42026 | 42 x 60 x 7 | CALDINA 3SGE ST195,215 | 96/9~ | Engine CRANK SHAFT FRONT |
| 03901 1467 | 90311-42026 | 42 x 60 x 7 | CALDINA 3S#,4SFE ST19# | 92/11~96/9 | Engine CRANK SHAFT FRONT |
| 03901 7895 | 90311-42026 | 42 x 60 x 7 | CALDINA 2C3,3C#...CT19#,216 | 92/11~ | Engine CRANK SHAFT FRONT |
| 03901 7967 | 90311-35040 | 35 x 49 x 6 | CALDINA 5EFE ET196 | 96/4~ | Engine CRANK SHAFT FRONT |
| 03901 5403 | 90913-02062 | | CALDINA 3SFE,4SFE (EX.) | 92/11~ | Engine VALVE STEM SEAL |
| 03901 5417 | 90311-56015 | 56 x 75 x 7 x 12 | CALDINA CT216,ST215 (4WD) | 97/8~ | Wheel Hub REAR INNER |
| 03901 8003 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA CT197 5F | 00/2~ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 4099 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA CT190,196,197,ST190 5F | 92/11~00/2 | Mission & Differential (M/T) DIFF. SIDE |
| 03901 7109 | 90311-49002 | 50 x 64 x 8 | CALDINA ST215 5F (E,G) | 97/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 3983 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA CT197 5F | 00/2~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1237 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA CT190,196,197,ST190 5F | 92/11~00/2 | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 8127 | 90311-34016 | 34 x 54 x 9 x 15.5 | CALDINA AT191,211,ET196 5F | 92/11~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 7533 | 90311-50010 | 50 x 80 x 16.5 x 23 | CALDINA ST215 5F GTT | 97/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1733 | 90311-44003 | 44 x 80 x 9 x 15.5 | CALDINA CT198,199,ST195 5F | 92/11~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4253 | 90311-30006 | 30 x 42 x 7 | CALDINA CT19#,ST190,195,215 5F | 92/11~ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2685 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA ST215 5F (E,G) | 97/8~ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 7361 | 90311-52005 | 52 x 75 x 7.5 x 12 | CALDINA ST195 (4WD) | 92/11~97/8 | Wheel Hub REAR OUTER |
| 03901 2345 | 90311-34017 | 34 x 63 x 9 x 16 | CALDINA AT191,211,ET196 5F | 92/11~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1657 | 90311-56007 | 56 x 75 x 6.5 x 11 | CALDINA ST195 (4WD) | 92/11~97/8 | Wheel Hub REAR INNER |
| 03901 1769 | 90311-52059 | 52 x 65 x 9 | CALDINA CT198,199,ST198 | 92/11~ | Wheel Hub REAR |
| 03901 3573 | 90311-48001 | 48 x 62 x 9 | CALDINA CT196,197,ET196 | 92/11~ | Wheel Hub REAR |
| 03901 2403 | 04422-20080 | Kit | CALDINA AT191,CT190,ST19#...ABS | 92/11~97/8 | Wheel Hub FRONT |
| 03901 2647 | 04422-20080 | Kit | CALDINA CT19#,ET196 ABS | 85/5~99/8 | Wheel Hub FRONT |
| 03901 6637 | 04422-20080 | Kit | CALDINA AT211,CT216,ST21# | 97/8~ | Wheel Hub FRONT |
| 03901 7639 | 04422-21010 | Kit | CALDINA ST215 GTT | 97/8~ | Wheel Hub FRONT |
| 03901 1359 | 04445-20200 | | CALDINA CT196 | 92/11~96/1 | Steering (P/S) R&P GASKET KIT |
| 03901 4127 | 90311-38020 | 38 x 55 x 8.5 | CALDINA AT191,CT190,196,197,ET196,ST19# | 92/11~99/3 | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 3569 | 90311-52005 | 52 x 75 x 7.5 x 12 | CALDINA CT216,ST215 (4WD) | 97/8~ | Wheel Hub REAR OUTER |
| 03901 2739 | 90311-34012 | 34 x 54 x 9 x 15.5 | CALDINA ET196 3FC | 92/11~98/3 | Mission & Differential (A/T) DIFF.SIDE |
| 03901 1825 | 90311-25011 | 25 x 37 x 8 | CALDINA AT191,211,ET196 5F | 92/11~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 2297 | 90311-38064 | 38 x 55 x 8.7 | CALDINA ET196 | 99/3~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 6965 | 90311-34012 | 34 x 54 x 9 x 15.5 | CALDINA ET196 3FC | 92/11~83/3 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5453 | 04445-20161 | | CALDINA AT191,CT190,198,199,ST19#...TOYODAKOKI | 92/11~ | Steering (P/S) R&P GASKET KIT |
| 03901 6671 | 04445-20161 | | CALDINA AT211,CT216,ST215 TOYODAKOKI G/B | 97/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 7425 | 04445-20170 | | CALDINA ET196 | 92/11~96/1 | Steering (P/S) R&P GASKET KIT |
| 03901 4999 | 90311-38020 | 38 x 55 x 8.5 | CALDINA AT211,CT216,ST21# | 97/8~ | Mission & Differential (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3967 | 90311-38020 | 38 x 55 x 8.5 | CALDINA CT197,ST198 | 99/3~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 5393 | 04422-12060 | Kit | CALDINA CT19#,ET196,ST19#...WITH OUT ABS | 92/11~ | Wheel Hub FRONT |
| 03901 7771 | 90311-34022 | 34 x 56 x 9 x 15 | CALDINA ET196 3FC | 98/3~ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 5631 | 04445-20170 | | CALDINA AT191,ST191 TOYOTA G/B | 96/4~97/8 | Steering (P/S) R&P GASKET KIT |
| 03901 5313 | 90311-34012 | 34 x 54 x 915.5 | CALDINA AT191,211 4FC | 96/1~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4745 | 90311-34016 | 34 x 54 x 9 x 15.5 | CALDINA ET196 3FC | 83/3~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2809 | 90311-34013 | 34 x 63 x 9 x 15 | CALDINA AT191,211 4FC | 96/1~97/8 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3295 | 90311-35020 | 35 x 63 x 9 x 15.5 | CALDINA CT190,196,197,ST190,191 4FC | 92/11~99/8 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1965 | 90311-50011 | 50 x 80 x 16.5 x 23 | CALDINA ST215 4FC GTT | 97/11~ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 1421 | 90311-35020 | 35 x 63 x 9 x 15.5 | CALDINA CT216,ST21#...4FC (E,G,GT) | 97/8~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2269 | 90311-62004 | 62 x 74 x 8.5 | CALDINA ST215 4FC GTT | 97/11~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1117 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA CT190,196,197,ST190,191 4FC | 92/11~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4605 | 90311-35033 | 35 x 55 x 9 x 15.5 | CALDINA ST210 | 97/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1563 | 90311-49002 | 50 x 64 x 8 | CALDINA CT216,ST215 4FC (E,G,GT) | 97/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3323 | 04445-20170 | | CALDINA AT211,ST210 TOYOTA G/B | 97/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 4841 | 90311-35020 | 35 x 63 x 9 x 15.5 | CALDINA CT197 4FC | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2255 | 90043-11292-000 | 73.5 x 89 x 8.5 | CAMI K3V#...J102,122 | 00/5~ | Engine CRANK SHAFT REAR |
| 03901 1001 | 90043-11310-000 | 34 x 55 x 12 x 18 | CAMI J10#...EFI | 99/5~ | Final Drive PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2197 | 90048-12021-000 | | CAMI K3V# | 00/5~ | Engine VALVE STEM SEAL |
| 03901 5137 | 90048-12011-000 | | CAMI HCEJ | 99/5~ | Engine VALVE STEM SEAL |
| 03901 3047 | 90311-35040 | 35 x 49 x 6 | CAMI K3V#...J102,122 | 00/5~ | Engine TIMING GEAR COVER |
| 03901 4895 | 90043-11345-000 | 32 x 48 x 5 | CAMI HCEJ J100 | 99/5~ | Engine CRANK SHAFT FRONT |
| 03901 2651 | 90043-11342-000 | 40 x 65 x 11.5 x 18 | CAMI J102 TURBO,J122 | 00/5~ | Final Drive PINION |
| 03901 7319 | 90043-11285-000 | 36 x 52 x 8 | CAMI J122 5F | 99/5~ | Transmission EXTENTION |
| 03901 3553 | 90043-10035-000 | 25 x 35 x 6 | CAMI J10#,122 5F | 99/5~ | Transmission FRONT |
| 03901 5859 | 90043-11291-000 | 40 x 56 x 8 | CAMI J10#,122 | 99/5~ | Wheel Hub REAR |
| 03901 5067 | 90311-80003 | 80 x 100 x 8.5 | CAMI HCEJ J100 | 99/5~ | Engine CRANK SHAFT REAR |
| 03901 1723 | 90043-11229-000 | 38 x 50 x 8 | CAMI HCEJ J100 | 99/5~ | Engine CAM SHAFT |
| 03901 2749 | 90913-02101 | | CAMRY GRACIA 2MZFE (IN.) | 96/12~ | Engine VALVE STEM SEAL |
| 03901 3311 | 15165-70010 | 18 x 30 x 7 | CAMRY GRACIA 5SFE SXV2# | 96/12~ | Engine OIL PUMP |
| 03901 3515 | 90311-42035 | 42 x 60 x 7 | CAMRY GRACIA 5SFE SXV2# | 96/12~ | Engine CRANK SHAFT FRONT |
| 03901 6687 | 90311-92008 | 92 x 110 x 9 | CAMRY GRACIA 2MZFE MCV2# | 96/12~ | Engine CRANK SHAFT REAR |
| 03901 3293 | 90311-85007 | 85 x 105 x 10 | CAMRY GRACIA 5SFE SXV2# | 96/12~ | Engine CRANK SHAFT REAR |
| 03901 1819 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY GRACIA SXV20 | 96/12~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 4829 | 90913-02079 | | CAMRY GRACIA 5SFE (IN.) | 96/12~ | Engine VALVE STEM SEAL |
| 03901 4869 | 90913-02062 | | CAMRY GRACIA 5SFE (EX.) | 96/12~ | Engine VALVE STEM SEAL |
| 03901 3263 | 90913-02111 | | CAMRY GRACIA 2MZFE (EX.) | 96/12~ | Engine VALVE STEM SEAL |
| 03901 5849 | 90311-40022 | 40 x 55 x 6 | CAMRY GRACIA 2MZFE MCV2# | 96/12~ | Engine OIL PUMP |
| 03901 7365 | 90311-52005 | 52 x 75 x 7.5 x 12 | CAMRY GRACIA MCV25,SXV25 (4WD) | 97/6~ | Wheel Hub REAR OUTER |
| 03901 6913 | 04445-32051 | | CAMRY GRACIA MCV21,SXV20 WAGON | 96/12~ | Steering (P/S) R&P GASKET KIT |
| 03901 1249 | 90311-38036 | 38 x 50 x 8 | CAMRY GRACIA 5SFE SXV2# | 96/12~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6373 | 90311-54005 | 55 x 70 x 10 | CAMRY GRACIA MCV25,SXV25 (4WD) | 97/6~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 5425 | 90311-40010 | 40 x 56 x 9 x 15.5 | CAMRY GRACIA MCV21 | 96/12~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 7393 | 90311-56015 | 56 x 75 x 7 x 12 | CAMRY GRACIA MCV25,SXV25 (4WD) | 97/6~ | Wheel Hub REAR INNER |
| 03901 5765 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY GRACIA SXV20 | 96/12~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 6107 | 90311-50011 | 50 x 80 x 16.5 x 23 | CAMRY GRACIA MCV2# | 96/12~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3059 | 90311-38020 | 38 x 55 x 8.5 | CAMRY GRACIA MCV2#,SXV2# | 96/12~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2341 | 90311-38034 | 38 x 50 x 10.5 | CAMRY GRACIA 2MZFE MCV2# | 96/12~ | Engine CAM SHAFT |
| 03901 3773 | 04445-33070 | | CAMRY GRACIA MCV21,SXV20 SEDAN | 96/12~ | Steering (P/S) R&P GASKET KIT |
| 03901 2195 | 04445-33080 | | CAMRY GRACIA MCV25,SXV25 | 97/6~ | Steering (P/S) R&P GASKET KIT |
| 03901 5597 | 90311-26003 | 26 x 38 x 6.5 | CAMRY GRACIA MCV2#,SXV2# | 96/12~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1363 | 90311-19010 | 19 x 32 x 6 | CAMRY GRACIA MCV21,SXV20 | 96/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4545 | 90311-50022 | 42 x 62 x 8.5 x 15.4 | CAMRY GRACIA SXV25 | 97/6~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 6447 | 90311-38025 | 38 x 50 x 6 | CAMRY, VISTA 1CT,2CT CV10,20,30 | 85/1~94/ | Engine CAM SHAFT |
| 03901 6091 | 90311-42003 | 42 x 60 x 7 | CAMRY, VISTA 1S#,2S#,3S#,4S$...SV1#,2# | 82/3~90/ | Engine CRANK SHAFT FRONT |
| 03901 4935 | 90311-38059 | 38 x 50 x 8 | CAMRY, VISTA 1ZZFE ZZV50 | 98/6~ | Engine TIMING GEAR COVER |
| 03901 1565 | 90311-40022 | 40 x 55 x 6 | CAMRY, VISTA 1VZFE,4VZFE VZV20,3# | 87/4~94/ | Engine OIL PUMP |
| 03901 3951 | 90029-21022 | 22 x 34 x 6.5 | CAMRY, VISTA 2CT,3CT CV20,30,4# | 89/5~98/ | Engine OIL PUMP |
| 03901 2879 | 90029-21020 | 20325 x x | CAMRY, VISTA 1CT,2CT CV1#,20 | 85/5~89/5 | Engine OIL PUMP |
| 03901 4031 | 15165-64010 | 20 x 32 x 7 | CAMRY, VISTA 1CT CV10 | 82/3~85/5 | Engine OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7061 | 15165-70010 | 18 x 30 x 7 | CAMRY, VISTA 1S#,2S#,3S#,4S#...SV1#,2#,3#,4#,5# | 82/3~ | Engine OIL PUMP |
| 03901 2099 | 90311-38067 | 38 x 50 x 8 | CAMRY, VISTA 3SF#...SV5# | 98/6~ | Engine CAM SHAFT |
| 03901 1575 | 90311-38044 | 38 x 50 x 6 | CAMRY, VISTA 3CT CV4# | 94/6~98/ | Engine CAM SHAFT |
| 03901 7371 | 90311-38036 | 38 x 50 x 8 | CAMRY, VISTA 1CT CV10 | 82/3~85/1 | Engine CAM SHAFT |
| 03901 7219 | 90311-42026 | 42 x 60 x 7 | CAMRY, VISTA 3S#,4S#...SV3#,4# | 90/7~98/ | Engine CRANK SHAFT FRONT |
| 03901 5463 | 90311-90005 | 90 x 110 x 8.5 x 10 | CAMRY, VISTA 2CT,3CT CV30,4# | 90/7~98/ | Engine CRANK SHAFT REAR |
| 03901 2947 | 90310-25032 | 25 x 35 x 6 | CAMRY, VISTA SV5#,ZZV50 | 98/6~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6767 | 90311-38067 | 38 x 50 x 8 | CAMRY, VISTA 3SFE,4SFE 4# | 97/8~98/ | Engine CAM SHAFT |
| 03901 4633 | 90311-38036 | 38 x 50 x 8 | CAMRY, VISTA 3SFE,4SFE SV2#,3#,4# | 86/8~97/8 | Engine CAM SHAFT |
| 03901 1945 | 90311-38036 | 38 x 50 x 8 | CAMRY, VISTA 1S#,2S#...SV1#,20 | 82/3~88/ | Engine CAM SHAFT |
| 03901 4689 | 90311-38034 | 38 x 50 x 10.5 | CAMRY, VISTA 1VZFE,4VZFE VZ20,3# | 87/4~94/ | Engine CAM SHAFT |
| 03901 2029 | 90913-02062 | | CAMRY, VISTA 3S#,4S# (EX.) | 88/8~98/ | Engine VALVE STEM SEAL |
| 03901 1991 | 90913-02095 | | CAMRY, VISTA 4VZFE(IN.) | 91/5~98/ | Engine VALVE STEM SEAL |
| 03901 7475 | 90913-02062 | | CAMRY, VISTA 4VZFE(EX.) | 91/5~98/ | Engine VALVE STEM SEAL |
| 03901 4495 | 90913-02062 | | CAMRY, VISTA 1VZFE(IN. & EX.) | 88/8~92/ | Engine VALVE STEM SEAL |
| 03901 2441 | 90913-02110 | | CAMRY, VISTA 1CT,2CT,3CT,(IN. & EX.) | 82/3~98/ | Engine VALVE STEM SEAL |
| 03901 1207 | 90913-02111 | | CAMRY, VISTA 3SFSE(EX.) SV50,1ZZFE(EX.) | 98/6~ | Engine VALVE STEM SEAL |
| 03901 6117 | 90913-02101 | | CAMRY, VISTA 3SFSE(IN.) SV50,1ZZFE(IN.) | 98/6~ | Engine VALVE STEM SEAL |
| 03901 5161 | 90913-02079 | | CAMRY, VISTA 3SFE(IN.) SV55 | 98/6~ | Engine VALVE STEM SEAL |
| 03901 3607 | 90913-02079 | | CAMRY, VISTA 3S#,4S#(IN.) | 90/7~98/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3947 | 90311-85007 | 85 x 105 x 10 | CAMRY, VISTA 3SF#,4SFE SV3#,4#,5# | 90/10~ | Engine CRANK SHAFT REAR |
| 03901 3685 | 90913-02062 | | CAMRY, VISTA 3SFE(EX.) SV55 | 98/6~ | Engine VALVE STEM SEAL |
| 03901 5221 | 90311-42035 | 42 x 60 x 7 | CAMRY, VISTA 3SF#...SV5# | 98/6~ | Engine CRANK SHAFT FRONT |
| 03901 1357 | 90913-02056 | | CAMRY, VISTA 1S#,2S# (IN. & EX.) | 82/3~88/ | Engine VALVE STEM SEAL |
| 03901 4683 | 90311-76001 | 76 x 94 x 8.5 | CAMRY, VISTA 1ZZFE ZZV50 | 98/6~ | Engine CRANK SHAFT REAR |
| 03901 6663 | 90311-89001 | 89 x 105 x 10 | CAMRY, VISTA 3SGE SV21,32,33 | 89/7~92/ | Engine CRANK SHAFT REAR |
| 03901 7581 | 90311-92005 | 92 x 110 x 10 | CAMRY, VISTA 1VZFE,4VZFE VZV20,3# | 87/4~94/ | Engine CRANK SHAFT REAR |
| 03901 5733 | 90311-90003 | 90 x 110 x 8.5 x 10 | CAMRY, VISTA 1CT,2CT CV10,20 | 82/3~90/ | Engine CRANK SHAFT REAR |
| 03901 3097 | 90311-85004 | 85 x 105 x 10 | CAMRY, VISTA 1S#,2S#,3SFE,4SFE SV1#,2#,3# | 82/3~90/10 | Engine CRANK SHAFT REAR |
| 03901 3135 | 90311-42026 | 42 x 60 x 7 | CAMRY, VISTA 2CT,3CT CV30,4# | 90/7~98/ | Engine CRANK SHAFT FRONT |
| 03901 5937 | 90311-42015 | 42 x 60 x 6 | CAMRY, VISTA 1CT,2CT CV1#,20 | 85/5~90/ | Engine CRANK SHAFT FRONT |
| 03901 2397 | 90311-42003 | 42 x 60 x 7 | CAMRY, VISTA 1CT CV10 | 82/3~85/5 | Engine CRANK SHAFT FRONT |
| 03901 7263 | 90913-02062 | | CAMRY, VISTA 3S#,4S#(IN.) | 88/8~90/7 | Engine VALVE STEM SEAL |
| 03901 6407 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,40 | 82/3~98/ | Mission & Differential (M/T) DIFF.SIDE |
| 03901 5249 | 90311-40010 | 40 x 56 x 9 x 15.5 | CAMRY, VISTA VZV3# | 90/7~94/ | Mission & Differential (A/T) DIFFERENTIAL |
| 03901 2837 | 90311-49002 | 50 x 64 x 8 | CAMRY, VISTA SV55 | 98/6~ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 8099 | 90311-50011 | 50 x 80 x 16.5 x 23 | CAMRY, VISTA VZV3# | 90/7~94/ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 1691 | 90311-44003 | 44 x 80 x 9 x 15.5 | CAMRY, VISTA SV25,35,43,CV43 (4WD) | 87/10~98 | Mission & Differential (A/T) DIFF.SIDE |
| 03901 3307 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY, VISTA SV50,ZZV50 | 98/6~ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 5619 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,40,VZV20 2WD | 82/3~98/ | Mission & Differential (A/T) DIFF.SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4041 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY, VISTA SV5#,ZZV50 | 98/6~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1479 | 90311-40004 | 40 x 56 x 9 x 15.5 | CAMRY, VISTA VZV20,30,31 | 87/4~94/ | Mission & Differential (M/T) TRANSAXLE CASE COVER |
| 03901 6921 | 90311-50010 | 50 x 80 x 16.5 x 23 | CAMRY, VISTA VZV20,30,31 | 87/4~94/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 5103 | 90311-50010 | 50 x 80 x 16.5 x 23 | CAMRY, VISTA SV25 ABS | 87/10~90/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 6139 | 90311-38020 | 38 x 55 x 8.5 | CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4#,VZV20,3# | 82/3~98/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 7293 | 90311-44003 | 44 x 80 x 9 x 15.5 | CAMRY, VISTA SV25 WITHOUT ABS | 87/10~90/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 7381 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,40,VZV20 2WD | 82/3~98/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 6855 | 90311-35033 | 35 x 55 x 9 x 15.5 | CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,40 | 82/3~98/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2509 | 90311-30006 | 30 x 42 x 7 | CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,40,VZV20 | 82/3~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1481 | 90311-52005 | 52 x 75 x 7.5 x 12 | CAMRY, VISTA SV25,35,43,CV43 (4WD) | 87/10~98 | Wheel Hub REAR OUTER |
| 03901 6513 | 90311-56007 | 56 x 75 x 6.5 x 11 | CAMRY, VISTA SV25,35,43,CV43 (4WD) | 87/10~98 | Wheel Hub REAR INNER |
| 03901 7969 | 90311-42018 | 42 x 55 x 6 | CAMRY, VISTA SV33,VZV33 | 92/6~94 | Wheel Hub REAR |
| 03901 2123 | 90311-42018 | 42 x 55 x 6 | CAMRY, VISTA SV3#,CV30,VZV3# | 90/7~92/6 | Wheel Hub REAR |
| 03901 6991 | 90311-42018 | 42 x 55 x 6 | CAMRY, VISTA SV1#,20,21,22,CV10,20,VZV20 | 82/3~90 | Wheel Hub REAR |
| 03901 7451 | 04422-32010 | Kit | CAMRY, VISTA SV1#,2#,CV10,20,VZV20 | 82/3~90 | Wheel Hub FRONT |
| 03901 6235 | 90310-30013 | 30 x 41 x 6.5 | CAMRY, VISTA SV32,VZV30,32 ZX,VX,PRO | 90/7~94/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 8065 | 90311-35013 | 35 x 49 x 6 | CAMRY, VISTA 3SGE SV21,32,33 | 86/8~94/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5343 | 90311-44003 | 44 x 80 x 9 x 15.5 | CAMRY, VISTA SV35,43 | 90/7~98/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 2481 | 90310-28003 | 28 x 41 x 6.5 | CAMRY, VISTA SV1#,CV11 | 85/8~86/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4997 | 90310-30013 | 30 x 41 x 6.5 | CAMRY, VISTA SV21 ZX,GT,VX,VZV20 | 86/8~90/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5945 | 90310-28003 | 28 x 41 x 6.5 | CAMRY, VISTA CV30,4#,VZV31,33 | 90/7~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5941 | 90310-28003 | 28 x 41 x 6.5 | CAMRY, VISTA SV2#,CV20 XT,ZT,ZE,GT,VL,VE,VR | 86/8~90/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5127 | 90311-38020 | 38 x 55 x 8.5 | CAMRY, VISTA SV5#,ZZV50 | 98/6~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 6979 | 90310-28003 | 28 x 41 x 6.5 | CAMRY, VISTA SV11,12,CV10 | 82/8~85/8 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4835 | 90310-31001 | 31 x 44 x 6.5 | CAMRY, VISTA SV10 | 82/7~85/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7345 | 90311-20008 | 20 x 34 x 7 | CAMRY, VISTA SV5#,ZZV50 | 98/6~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7739 | 90311-19002 | 19 x 32 x 7 x 8 | CAMRY, VISTA SV1#,2#,3#,4#,CV1#,20,30,4#,VZV3# | 82/3~98/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2999 | 04445-32081 | | CAMRY, VISTA SV5#,ZZV50 | 98/6~ | Steering (P/S) R&P GASKET KIT |
| 03901 6289 | 04445-32070 | | CAMRY, VISTA SV42 | 94/6~98/ | Steering (P/S) R&P GASKET KIT |
| 03901 5035 | 04445-32070 | | CAMRY, VISTA SV33,VZV31,33 | 90/7~94/ | Steering (P/S) R&P GASKET KIT |
| 03901 1297 | 04445-32061/60 | | CAMRY, VISTA SV32,VZV30,32 ZX,VX,PRO | 90/7~94/ | Steering (P/S) R&P GASKET KIT |
| 03901 6935 | 04445-32051 | | CAMRY, VISTA CV4#,SV40,41,43 | 94/6~98/ | Steering (P/S) R&P GASKET KIT |
| 03901 2407 | 04445-32041 | | CAMRY, VISTA SV21 ZX,GT,VX,VZV20 | 86/8~90/ | Steering (P/S) R&P GASKET KIT |
| 03901 7813 | 90311-15001 | 15 x 25 x 7 | CAMRY, VISTA SV10,20 LT,VC | 82/3~98/ | Steering (M/S) RACK HOUSING |
| 03901 5045 | 04445-32011/10 | | CAMRY, VISTA SV10 | 82/8~85/8 | Steering (P/S) R&P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7191 | 04445-32051 | | CAMRY, VISTA SV30,32(LUM,GT,VE,ETO), 35,CV30 | 90/7~94/ | Steering (P/S) R&P GASKET KIT |
| 03901 6449 | 04445-32030 | | CAMRY, VISTA SV2#,CV20 XT,ZT,ZE,GT,VL,VE,VR | 86/8~90/ | Steering (P/S) R&P GASKET KIT |
| 03901 6563 | 04445-32020 | | CAMRY, VISTA SV1#,CV11 | 85/8~86 | Steering (P/S) R&P GASKET KIT |
| 03901 3567 | 04445-32020 | | CAMRY, VISTA SV11,12,CV10 | 82/8~85/8 | Steering (P/S) R&P GASKET KIT |
| 03901 5983 | 90310-28003 | 28 x 41 x 6.5 | CAMRY, VISTA SV30,329LUM,GT,VE,ETO) ,33,35,4# | 90/7~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1097 | 04422-20080 | Kit | CARINA (FWD) SEDAN AT19#,ST19#,CT19#...WITH ABS | 92/8~96/ | Wheel Hub FRONT |
| 03901 1525 | 90310-23005 | 23 x 34 x 6.5 | CARINA (FWD) SEDAN AT15#,ST150,CT150 TOYOTA G/B | 84/5~88/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3937 | 90311-19002 | 19 x 32 x 7 x 8 | CARINA (FWD) SEDAN ST17#,19#,215 | 87/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7975 | 90311-19002 | 19 x 32 x 7 x 8 | CARINA (FWD) SEDAN AT17#,19#,21#,CT17#,19#,2 1# | 87/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2925 | 90311-19002 | 19 x 32 x 7 x 8 | CARINA (FWD) SEDAN AT15#,160,ST150,162,CT15 0 TOYODAKOKI | 84/5~88/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6983 | 04422-20010 | Kit | CARINA (FWD) SEDAN AT15#,160,ST150,162,CT15 0 | 84/5~89/ | Wheel Hub FRONT |
| 03901 5649 | 04422-20010 | Kit | CARINA (FWD) SEDAN AT17#,ST17#,CT17#,ET17# | 88/5~92/ | Wheel Hub FRONT |
| 03901 3759 | 90311-42018 | 42 x 55 x 6 | CARINA (FWD) SEDAN AT15#,160,ST150,16#,CT15 0 | 84/5~89/ | Wheel Hub REAR |
| 03901 4153 | 04422-12060 | Kit | CARINA (FWD) SEDAN AT19#,ST19#,CT19#...WITH OUT ABS | 92/8~96/ | Wheel Hub FRONT |
| 03901 2243 | 90311-48001 | 48 x 62 x 9 | CARINA (FWD) SEDAN CT176,ET176 | 88/5~92/ | Wheel Hub REAR |
| 03901 1379 | 04422-20080 | Kit | CARINA (FWD) SEDAN AT21#,ST215,CT21# | 96/8~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7809 | 90310-25004 | 25 x 38 x 7 x 8 | CARINA (FWD) SEDAN AT15#,160,ST150,162,CT150 TOYODAKOKI | 84/5~88/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7551 | 90311-52005 | 52 x 75 x 7.5 x 12 | CARINA (FWD) SEDAN AT175,ST195,CT195 (4WD) | 88/8~96 | Wheel Hub REAR OUTER |
| 03901 1477 | 90310-28003 | 28 x 41 x 6.5 | CARINA (FWD) SEDAN AT211(TOYOTA G/B0,212 | 96/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4979 | 90311-56015 | 56 x 75 x 7 x 12 | CARINA (FWD) SEDAN CT215,216,ST215 (4WD) | 97/7~ | Wheel Hub REAR INNER |
| 03901 6287 | 90311-56007 | 56 x 75 x 6.5 x 11 | CARINA (FWD) SEDAN CT215,ST215 (4WD) | 96/8~97/7 | Wheel Hub REAR INNER |
| 03901 3919 | 90311-56007 | 56 x 75 x 6.5 x 11 | CARINA (FWD) SEDAN AT175,ST195,CT195 (4WD) | 88/8~96 | Wheel Hub REAR INNER |
| 03901 6277 | 90311-42018 | 42 x 55 x 6 | CARINA (FWD) SEDAN AT170.171,CT170.ST170 | 88/5~92/ | Wheel Hub REAR |
| 03901 6977 | 90311-52005 | 52 x 75 x 7.5 x 12 | CARINA (FWD) SEDAN CT215,216,ST215 (4WD) | 96/8~ | Wheel Hub REAR OUTER |
| 03901 1475 | 90311-35003 | 35 x 49 x 6 | CARINA (FWD) SEDAN 3E ET176 | 88/5~92/ | Engine CAM SHAFT |
| 03901 5627 | 90311-32020 | 32 x 46 x 6 | CARINA (FWD) SEDAN 3A#,4A#,5A#,7A#...AT15#,160,17#,19#,21# | 84/5~ | Engine OIL PUMP |
| 03901 1847 | 90311-38044 | 38 x 50 x | CARINA (FWD) SEDAN 2C,3CTE CT21# | 96/8~ | Engine CAM SHAFT |
| 03901 3799 | 90311-38044 | 38 x 50 x | CARINA (FWD) SEDAN 2C CT170,19# | 90/10~96/ | Engine CAM SHAFT |
| 03901 7237 | 90311-38025 | 38 x 50 x 6 | CARINA (FWD) SEDAN 2C CT150,170 | 85/1~90/10 | Engine CAM SHAFT |
| 03901 6553 | 90311-38067 | 38 x 50 x 8 | CARINA (FWD) SEDAN 3SFE ST215 | 97/8~ | Engine CAM SHAFT |
| 03901 5517 | 90311-38036 | 38 x 50 x 8 | CARINA (FWD) SEDAN 2C CT150 | 84/5~85/1 | Engine CAM SHAFT |
| 03901 6525 | 90311-38036 | 38 x 50 x 8 | CARINA (FWD) SEDAN 1S#,3SFE,4S#...ST150,170,19#,215 | 84/5~97/7 | Engine CAM SHAFT |
| 03901 2027 | 90310-25004 | 25 x 38 x 7 x 8 | CARINA (FWD) SEDAN AT210,211(TOYODAKOKI G/B),CT21#,ST215 | 96/8~ | Steering (P/S) CONTROL VALVE LOWER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5893 | 90311-35003 | 35 x 49 x 6 | CARINA (FWD) SEDAN 3SGLU ST162 | 85/8~88/ | Engine CAM SHAFT |
| 03901 7851 | 90310-25004 | 25 x 38 x 7 x 8 | CARINA (FWD) SEDAN AT17#,ST17#,CT17#,ET176 | 87/12~92/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6313 | 90311-35003 | 35 x 49 x 6 | CARINA (FWD) SEDAN 4AGE(NO.1) AT210 | 96/8~ | Engine CAM SHAFT |
| 03901 6689 | 90311-35003 | 35 x 49 x 6 | CARINA (FWD) SEDAN 5AFE,7AFE AT211,212 | 96/8~ | Engine CAM SHAFT |
| 03901 5821 | 90311-35003 | 35 x 49 x 6 | CARINA (FWD) SEDAN 4A#,5A#,7A#...AT15#,17#,19# | 84/5~96/ | Engine CAM SHAFT |
| 03901 2417 | 90311-30006 | 30 x 42 x 7 | CARINA (FWD) SEDAN ST150,162,170,19#,CT150,17#,19#,AT175 | 84/5~96/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 3385 | 90310-28003 | 28 x 41 x 6.5 | CARINA (FWD) SEDAN AT193,ST190 | 92/8~96/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 8193 | 15165-70010 | 18 x 30 x 7 | CARINA (FWD) SEDAN 1S#,3S#,4S#...ST150,162,170,19#,215 | 84/5~ | Engine OIL PUMP |
| 03901 1445 | 90310-25004 | 25 x 38 x 7 x 8 | CARINA (FWD) SEDAN CT19#,ST195 | 92/8~96/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3923 | 90311-40015 | 40 x 54.5 x 7 | CARINA (FWD) SEDAN 4AGE(NO.) AT210 | 96/8~ | Engine CAM SHAFT |
| 03901 7637 | 04445-20080 | | CARINA (FWD) SEDAN AT175,ST171 | 87/12~92/ | Steering (P/S) R&P GASKET KIT |
| 03901 4469 | 90311-34012 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN AT159 3FC | 84/5~88/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 6485 | 90311-34012 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN ET176 | 87/12~92/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3921 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN ST162 | 85/8~88/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 2353 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN ST17# | 87/12~92/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 4995 | 90311-44003 | 44 x 80 x 9 x 15.5 | CARINA (FWD) SEDAN ST195,215 | 92/8~98/8 | Mission & Differential (A/T) DIFF. SIDE |
| 03901 1211 | 90311-38020 | 38 x 55 x 8.5 | CARINA (FWD) SEDAN AT15#,160,17#,19#,21#,CT150,17#,19#,21# | 84/5~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 6773 | 90311-38020 | 38 x 55 x 8.5 | CARINA (FWD) SEDAN ST150,162,17#,19#,215 | 84/5~ | Mission & Differential (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6521 | 90311-15001 | 15 x 25 x 7 | CARINA (FWD) SEDAN AT150,170,CT176,ET176 | 84/5~92/ | Steering (M/S) RACK HOUSING |
| 03901 6441 | 04445-12020 | | CARINA (FWD) SEDAN AT15#,ST150,CT150 TOYOTA G/B | 84/5~88/ | Steering (P/S) R&P GASKET KIT |
| 03901 7203 | 90311-25011 | 25 x 37 x 8 | CARINA (FWD) SEDAN AT15#,160,170,171,19#,ET176 | 84/5~96/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 5949 | 04445-20070 | | CARINA (FWD) SEDAN AT170,CT17#,ST170,ET176 | 87/12~92/ | Steering (P/S) R&P GASKET KIT |
| 03901 7613 | 90311-34016 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN AT21# | 99/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3277 | 04445-20140 | | CARINA (FWD) SEDAN CT190 SG | 92/8~96/ | Steering (P/S) R&P GASKET KIT |
| 03901 2561 | 04445-20160/1 | | CARINA (FWD) SEDAN CT190 SE,CT195,ST195 | 92/8~96/ | Steering (P/S) R&P GASKET KIT |
| 03901 2175 | 04445-20160/1 | | CARINA (FWD) SEDAN AT210,211(TOYODAKOKI G/B),CT21#,ST215 | 96/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 7847 | 04445-20170 | | CARINA (FWD) SEDAN AT19#,ST190 | 92/8~96/ | Steering (P/S) R&P GASKET KIT |
| 03901 3635 | 04445-20170 | | CARINA (FWD) SEDAN AT211(TOYOTA G/B) | 98/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 7721 | 04445-20210 | | CARINA (FWD) SEDAN AT211(TOYOTA G/B) | 96/8~98/8 | Steering (P/S) R&P GASKET KIT |
| 03901 3903 | 04445-20210 | | CARINA (FWD) SEDAN AT212 | 96/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 4275 | 04445-20240 | | CARINA (FWD) SEDAN CT210,211 | 96/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 4823 | 04445-20250 | | CARINA (FWD) SEDAN AT210 | 96/8~ | Steering (P/S) R&P GASKET KIT |
| 03901 8171 | 04445-20030/1 | | CARINA (FWD) SEDAN AT15#,160,ST,150,162,CT150 TOYODAKOKI | 84/5~88/ | Steering (P/S) R&P GASKET KIT |
| 03901 5443 | 90311-34012 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN AT150 3FC | 84/5~88/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 7977 | 90029-21022 | 22 x 34 x 6.5 | CARINA (FWD) SEDAN 2C CT17#,19# | 89/5~96/ | Engine OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7255 | 90311-30006 | 30 x 42 x 7 | CARINA (FWD) SEDAN CT210,211,215,ST215 | 96/8~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 6931 | 90311-34016 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN AT15#,160,170,171,19#,ET176 | 84/5~96/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 5675 | 90311-34016 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN AT21# | 96/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 5495 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN ST150,162,170,190,CT150,17#,190 | 84/5~96/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 7941 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN CT210,211 | 96/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1701 | 90311-49002 | 50 x 64 x 8 | CARINA (FWD) SEDAN ST215 | 96/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4271 | 90311-34017 | 34 x 63 x 9 x 16 | CARINA (FWD) SEDAN AT15#,160,170,171,19#,ET176 | 84/5~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1333 | 90311-34017 | 34 x 63 x 9 x 16 | CARINA (FWD) SEDAN AT21# | 96/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1261 | 90311-49002 | 50 x 64 x 8 | CARINA (FWD) SEDAN CT216,ST215 | 98/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 6177 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN CT210,211,ST215 | 96/8~ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 1491 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN ST150,190,CT150,17#,190,210,211 | 84/5~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4923 | 90311-34012 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN ET176 | 87/12~92 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1031 | 90311-34013 | 34 x 63 x 9 x 15 | CARINA (FWD) SEDAN AT150 4FC | 84/5~88/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1891 | 90311-34013 | 34 x 63 x 9 x 15 | CARINA (FWD) SEDAN AT151,160,170,171,19#,21# | 84/5~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 4795 | 90311-35020 | 35 x 63 x 9 x 15.5 | CARINA (FWD) SEDAN ST150,190,215 | 84/5~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 8177 | 90311-35020 | 35 x 63 x 9 x 15.5 | CARINA (FWD) SEDAN CT150,17#,190,213 | 84/5~ | Mission & Differential (A/T) TRANSAXLE CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7513 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN ST162 | 85/8~88/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5145 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA (FWD) SEDAN ST17# | 87/12~92/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5749 | 90311-44003 | 44 x 80 x 9 x 15.5 | CARINA (FWD) SEDAN AT175 (4WD0 | 88/8~92/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5171 | 90311-34012 | 34 x 54 x 9 x 15.5 | CARINA (FWD) SEDAN AT15#,(4FC),160,170,19#,21# | 84/5~99/8 | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 6421 | 90311-25011 | 25 x 37 x 8 | CARINA (FWD) SEDAN AT21# | 96/8~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 2483 | 90311-44003 | 44 x 80 x 9 x 15.5 | CARINA (FWD) SEDAN AT175,CT195,215,ST195,215 (4WD) | 88/8~98/8 | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 8211 | 90913-02062 | | CARINA (FWD) SEDAN 4AGE(EX.) AT171 | 89/3~92/8 | Engine VALVE STEM SEAL |
| 03901 1111 | 90311-85007 | 85 x 105 x 10 | CARINA (FWD) SEDAN 3S#,4S#...ST170,19#,215 | 90/10~ | Engine CRANK SHAFT REAR |
| 03901 3273 | 90311-80003 | 80 x 100 x 8.5 | CARINA (FWD) SEDAN 3E ET176 | 88/5~91/8 | Engine CRANK SHAFT REAR |
| 03901 3255 | 90311-80012 | 80 x 100 x 8.5 | CARINA (FWD) SEDAN 3E ET176 | 91/8~92/ | Engine CRANK SHAFT REAR |
| 03901 3905 | 90311-90003 | 90 x 110 x 8.5 x 10 | CARINA (FWD) SEDAN 2C CT150,170 | 84/5~90/2 | Engine CRANK SHAFT REAR |
| 03901 6529 | 90311-90005 | 90 x 110 x 8.5 x 10 | CARINA (FWD) SEDAN 2C CT170,19#,21# | 90/2~96/12 | Engine CRANK SHAFT REAR |
| 03901 3549 | 90311-90008 | 90 x 110 x 9.8 x 11.5 | CARINA (FWD) SEDAN 2C,3C CT21# | 96/12~ | Engine CRANK SHAFT REAR |
| 03901 3343 | 90913-02038 | | CARINA (FWD) SEDAN 3ALU,4AELU AT15# | 84/5~88/4 | Engine VALVE STEM SEAL |
| 03901 7271 | 90913-02062 | | CARINA (FWD) SEDAN 4AFE,5A#(IN. &EX.) AT17# | 88/5~90/10 | Engine VALVE STEM SEAL |
| 03901 4327 | 90311-85004 | 85 x 105 x 10 | CARINA (FWD) SEDAN 1S#,3S#,4S#...ST150,162,170 | 84/5~90/10 | Engine CRANK SHAFT REAR |
| 03901 5831 | 90913-02062 | | CARINA (FWD) SEDAN 4AGE AT171 | 88/5~89/3 | Engine VALVE STEM SEAL |
| 03901 4787 | 90913-02062 | | CARINA (FWD) SEDAN 4F#,5AFE,7AFE(EX.) AT17#,19#,21# | 90/10~ | Engine VALVE STEM SEAL |
| 03901 3529 | 90913-02079 | | CARINA (FWD) SEDAN 4AGE(IN.) AT171 | 89/3~92/8 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3619 | 90913-02093 | | CARINA (FWD) SEDAN 4AGE(IN. & EX.) AT210 | 96/8~ | Engine VALVE STEM SEAL |
| 03901 1355 | 90913-02056 | | CARINA (FWD) SEDAN 1SILU ST150 | 84/5~87/9 | Engine VALVE STEM SEAL |
| 03901 5537 | 90913-02094 | | CARINA (FWD) SEDAN 1SILU ST150 | 87/9~88/ | Engine VALVE STEM SEAL |
| 03901 5091 | 90913-02062 | | CARINA (FWD) SEDAN 3SGELU(IN. & EX.) ST162 | 85/8~88/ | Engine VALVE STEM SEAL |
| 03901 6049 | 90913-02062 | | CARINA (FWD) SEDAN ASF(IN. & EX.) ST170 | 88/5~90/3 | Engine VALVE STEM SEAL |
| 03901 1595 | 15165-64010 | 20 x 32 x 7 | CARINA (FWD) SEDAN 2CL CT150 | 84/5~85/5 | Engine OIL PUMP |
| 03901 2207 | 90029-21020 | 20 x 32 x 5 | CARINA (FWD) SEDAN 2C CT150,17# | 85/5~89/5 | Engine OIL PUMP |
| 03901 2109 | 90913-02079 | | CARINA (FWD) SEDAN 4F#,5AFE,7AFE(IN.) AT17#,19#,21# | 90/10~ | Engine VALVE STEM SEAL |
| 03901 4035 | 90913-02094 | | CARINA (FWD) SEDAN 2C CT17#,19# | 90/11~96/ | Engine VALVE STEM SEAL |
| 03901 6639 | 90029-21020 | 20 x 32 x 5 | CARINA (FWD) SEDAN 3E ET176 | 88/5~92/ | Engine OIL PUMP |
| 03901 4297 | 90913-02062 | | CARINA (FWD) SEDAN 4AGELU AT160 | 85/8~88/4 | Engine VALVE STEM SEAL |
| 03901 3753 | 90311-70007 | 70 x 92 x 8.5 | CARINA (FWD) SEDAN 4A#,5A#,7A#...AT17#,19#,21# | 91/6~ | Engine CRANK SHAFT REAR |
| 03901 5933 | 90311-42026 | 42 x 60 x 7 | CARINA (FWD) SEDAN 3S#,4S#...ST170,19#,215 | 89/9~96/9 | Engine CRANK SHAFT FRONT |
| 03901 5195 | 90311-42035 | 42 x 60 x 7 | CARINA (FWD) SEDAN 3SFE ST215 | 96/9~ | Engine CRANK SHAFT FRONT |
| 03901 6077 | 90311-42003 | 42 x 60 x 7 | CARINA (FWD) SEDAN 2C CT150 | 84/5~85/1 | Engine CRANK SHAFT FRONT |
| 03901 6291 | 90913-02117 | | CARINA (FWD) SEDAN 2C,3C CT21# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 4673 | 90311-42003 | 42 x 60 x 7 | CARINA (FWD) SEDAN 1S#,3S#,4S#...ST150,162,170 | 84/5~89/9 | Engine CRANK SHAFT FRONT |
| 03901 3795 | 90913-02110 | | CARINA (FWD) SEDAN 2C CT21# | 96/8~97/4 | Engine VALVE STEM SEAL |
| 03901 5927 | 90913-02079 | | CARINA (FWD) SEDAN 3SFE,4SF#(IN.) ST170,19#,215 | 90/3~ | Engine VALVE STEM SEAL |
| 03901 8059 | 90913-02062 | | CARINA (FWD) SEDAN 3SFE,4SF#(EX.) ST170,19#,215 | 90/3~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2699 | 90311-70004 | 70 x 92 x 8.5 | CARINA (FWD) SEDAN 3A#,4A#,5A#...AT15#,17# | 84/5~91/6 | Engine CRANK SHAFT REAR |
| 03901 7605 | 90311-19007 | 19 x 38 x 7 | CARINA (FWD) SEDAN AT15#,ST150,CT150 TOYOTA G/B | 84/5~88/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1463 | 90913-02110 | | CARINA (FWD) SEDAN 2C CT150,17# | 84/5~90/11 | Engine VALVE STEM SEAL |
| 03901 3831 | 90311-42015 | 42 x 60 x 6 | CARINA (FWD) SEDAN 2C CT150,170 | 85/1~90/5 | Engine CRANK SHAFT FRONT |
| 03901 7253 | 90311-42026 | 42 x 60 x 7 | CARINA (FWD) SEDAN 2C,3C CT170,19#,21# | 90/5~ | Engine CRANK SHAFT FRONT |
| 03901 1613 | 90311-45002 | 45 x 68 x 12 | CARINA (RWD) 18RGEU RA63 | 81/9~82/ | Engine TIMING GEAR COVER |
| 03901 2543 | 90311-32020 | 32 x 46 x 6 | CARINA (RWD) 3AU,4AGEU AA6# | 81/9~88/ | Engine OIL PUMP |
| 03901 4145 | 15165-70010 | 18 x 30 x 7 | CARINA (RWD) 1SU SA60 | 81/9~88/ | Engine OIL PUMP |
| 03901 5929 | 90029-21020 | 20 x 32 x 5 | CARINA (RWD) 1C CA67 | 85/5~88/ | Engine OIL PUMP |
| 03901 3401 | 15165-64010 | 20 x 32 x 7 | CARINA (RWD) 1C CA60,67 | 82/2~85/5 | Engine OIL PUMP |
| 03901 2005 | 90311-38022 | 38.5 x 58 x 8.5 | CARINA (RWD) 12TJ TA67V | 82/3~88/ | Engine TIMING GEAR COVER |
| 03901 7659 | 90311-38036 | 38 x 50 x 8 | CARINA (RWD) 1SU SA60 | 81/9~88/ | Engine CAM SHAFT |
| 03901 1151 | 90311-42003 | 42 x 60 x 7 | CARINA (RWD) 1SU SA60 | 81/9~88/ | Engine CRANK SHAFT FRONT |
| 03901 4429 | 90311-38036 | 38 x 50 x 8 | CARINA (RWD) 1C CA60,67 | 82/2~85/1 | Engine CAM SHAFT |
| 03901 1311 | 90311-38025 | 38 x 50 x 6 | CARINA (RWD) 1C CA67 | 85/1~88/ | Engine CAM SHAFT |
| 03901 3167 | 90311-35013 | 35 x 49 x 6 | CARINA (RWD) 3AU,4AGEU AA60,63 | 81/9~87/ | Engine CAM SHAFT |
| 03901 1371 | 90311-42003 | 42 x 60 x 7 | CARINA (RWD) 1C CA60,67 | 82/2~85/5 | Engine CRANK SHAFT FRONT |
| 03901 6073 | 90311-42015 | 42 x 60 x 6 | CARINA (RWD) 1C CA67 | 85/5~88/ | Engine CRANK SHAFT FRONT |
| 03901 2957 | 90311-75114 | 75 x 100 x 13 | CARINA (RWD) 3T,12T TA63,67V | 81/9~85/ | Engine CRANK SHAFT REAR |
| 03901 5865 | 90311-80001 | 80 x 100 x 12 | CARINA (RWD) 18RGEU RA63 | 81/9~82/ | Engine CRANK SHAFT REAR |
| 03901 3779 | 90311-70004 | 70 x 92 x 8.5 | CARINA (RWD) 3AU,4AGEU AA6# | 81/9~88/ | Engine CRANK SHAFT REAR |
| 03901 2781 | 90311-70004 | 70 x 92 x 8.5 | CARINA (RWD) 5KJ KA67 | 83/8~88/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7921 | 90311-85004 | 85 x 105 x 10 | CARINA (RWD) 1SU SA60 | 81/9~88/ | Engine CRANK SHAFT REAR |
| 03901 1671 | 90311-38013 | 38.5 x 58 x 11 | CARINA (RWD) 12TJ TA67V | 81/9~82/3 | Engine TIMING GEAR COVER |
| 03901 3473 | 90311-48001 | 48 x 62 x 9 | CARINA (RWD) AA63,TA61,63,RA63 | 81/9~85/ | Wheel Hub FRONT |
| 03901 1589 | 90913-02058 | | CARINA (RWD) 3T,13T EX. | 81/9~83/ | Engine VALVE STEM SEAL |
| 03901 7503 | 90913-02024 | | CARINA (RWD) 3T,12T IN. | 81/9~83/ | Engine VALVE STEM SEAL |
| 03901 4501 | 90311-90003 | 90 x 110 x 8.5 x 10 | CARINA (RWD) 1C CA6# | 82/2~88/ | Engine CRANK SHAFT REAR |
| 03901 5639 | 90913-02056 | | CARINA (RWD) 1SU | 81/9~88/ | Engine VALVE STEM SEAL |
| 03901 6895 | 90311-38020 | 38 x 55 x 8.5 | CARINA (RWD) AA60,TA63,67,SA60,KA67, CA60 | 81/9~88/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4071 | 90913-02056 | | CARINA (RWD) 5KJ | 81/11~88/ | Engine VALVE STEM SEAL |
| 03901 7419 | 90913-02110 | | CARINA (RWD) 1C | 82/2~88/ | Engine VALVE STEM SEAL |
| 03901 3051 | 90913-02038 | | CARINA (RWD) 3AU | 81/9~88/ | Engine VALVE STEM SEAL |
| 03901 6621 | 90311-41123 | 41 x 53 x 7 | CARINA (RWD) AA60,TA67,SA60,KA67,CA 6# | 81/9~88/ | Wheel Hub FRONT |
| 03901 2425 | 90311-52059 | 52 x 65 x 9 | CARINA (RWD) AA60,TA67,SA60,KA67,CA 6# | 81/9~88/ | Wheel Hub REAR |
| 03901 7741 | 90311-48122 | 48 x 62 x 7 | CARINA (RWD) TA61,63,RA63 | 81/9~83/5 | Wheel Hub REAR OUTER |
| 03901 5209 | 90311-48001 | 48 x 62 x 9 | CARINA (RWD) AA63,TA63 | 83/5~85/ | Wheel Hub REAR OUTER |
| 03901 3519 | 90311-25003 | 25 x 38 x 7 | CARINA (RWD) AA6#,TA6#,SA60,KA67 | 81/9~88/ | Transmission (M/T) FRONT COVER |
| 03901 2719 | 90311-30115 | 30 x 45 x 8 | CARINA (RWD) RA63,CA6#,TA63(GTT) | 81/9~88/ | Transmission (M/T) FRONT COVER |
| 03901 4735 | 90311-38009 | 38 x 58 x 8 | CARINA (RWD) AA63,TA61,63,RA63 | 81/9~85/ | Wheel Hub REAR INNER |
| 03901 5287 | 90311-38043 | 38 x 58 x 11 | CARINA (RWD) RA63,CA6#,TA63(GTT) | 81/9~88/ | Transmission (M/T) REAR |
| 03901 4063 | 90311-38013 | 38.5 x 58 x 11 | CARINA (RWD) 3TGTEU TA63 | 82/10~85/ | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3571 | 04332-30020 | Kit | CARINA (RWD) AA60,TA63,67,SA60,KA67, CA60 | 81/9~88/ | Transmission (A/T) EXTENTION HOUSING |
| 03901 1415 | 90311-11128 | 11 x 22 x 7 | CARINA (RWD) AA60,TA63,67,SA60,KA67, CA60 | 81/9~88/ | Transmission (A/T) LEVER SHAFT |
| 03901 7359 | 90311-38015 | 38 x 65 x 12 x 19 | CARINA (RWD) AA60,TA67,SA60,KA67,CA 6# | 81/9~88/ | Final Drive PINION |
| 03901 1085 | 90311-38133 | 38 x 74 x 11 | CARINA (RWD) TA63,RA63 GT,GTT | 81/9~85/ | Final Drive PINION |
| 03901 6263 | 90311-38019 | 38 x 65 x 10 x 17 | CARINA (RWD) AA63,TA61,63 ST,SE,GT | 81/9~88/ | Final Drive PINION |
| 03901 4531 | 90311-38011 | 38 x 65 x 10 x 17 | CARINA (RWD) AA63,TA61,63,RA63 | 81/9~85/ | Final Drive DIFF. SIDE |
| 03901 4585 | 90310-28027 | 28 x 40 x 8 | CARINA (RWD) TA67,KA67,CA67 | 81/9~88/ | Steering (M/S) SECTOR SHAFT |
| 03901 4803 | 90311-19001 | 19 x 32 x 8 | CARINA (RWD) TA67,KA67,CA67 | 81/9~88/ | Steering (M/S) WORM GEAR |
| 03901 7455 | 90311-15001 | 15 x 25 x 7 | CARINA (RWD) AA6#,TA61,63,SA60,CA60, RA63 | 81/9~88/ | Steering (M/S) RACK HOUSING |
| 03901 1621 | 90311-19002 | 19 x 32 x 7 x 8 | CARINA (RWD) AA6#,TA63,SA60,CA60,RA 63 | 81/9~88/ | Steering (P/S) ADJUSTER PLUG |
| 03901 7489 | 90311-32074 | 32 x 52 x 11 | CARINA (RWD) AA6#,TA6#,SA60,KA67 | 81/9~88/ | Transmission (M/T) REAR |
| 03901 4873 | 9031135033 | 35 x 55 x 9 x 15.5 | CARINA ED ST16#,18# | 87/8~93/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2379 | 15165-70010 | 18 x 30 x 7 | CARINA ED 1S#,3S#,4S# | 87/8~98/ | Engine OIL PUMP |
| 03901 7041 | 04422-20010 | Kit | CARINA ED ST200,201,202,203 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 6835 | 04422-20010 | Kit | CARINA ED ST18#...WITHOUT ABS | 89/9~93/ | Wheel Hub FRONT (RH) |
| 03901 4323 | 04422-20010 | Kit | CARINA ED ST16# | 87/8~89/ | Wheel Hub FRONT (RH) |
| 03901 4511 | 04445-20103 | | CARINA ED ST181,183,201,203 | 89/9~98/ | Steering (P/S) R&P GASKET KIT |
| 03901 1679 | 04445-20040 | | CARINA ED ST180 | 89/9~91/8 | Steering (P/S) R&P GASKET KIT |
| 03901 7075 | 04445-20060 | | CARINA ED ST16# | 87/8~89/ | Steering (P/S) R&P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2525 | 04445-20110 | | CARINA ED ST182 | 89/9~93/ | Steering (P/S) R&P GASKET KIT |
| 03901 4419 | 9031135033 | 35 x 55 x 9 x 15.5 | CARINA ED ST16#,18# | 87/8~93/ | Mission & Differential (M/T) DIFF.SIDE |
| 03901 2731 | 90311-19002 | 19 x 32 x 7 x 8 | CARINA ED ST16#,18#,20# | 87/8~98/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4477 | 90310-28003 | 28 x 41 x 6.5 | CARINA ED ST16#,181,183,201,203 | 87/8~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1715 | 90310-31001 | 31 x 44 x 6.5 | CARINA ED ST180,182,200,202,205 | 89/9~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3873 | 04422-20080 | Kit | CARINA ED ST18#...ABS | 89/9~93/ | Wheel Hub FRONT (RH) |
| 03901 6387 | 90311-35013 | 35 x 49 x 6 | CARINA ED 3SGE# | 87/8~98/ | Engine CAM SHAFT |
| 03901 8097 | 04445-20120 | | CARINA ED ST180 | 91/8~93/ | Steering (P/S) R&P GASKET KIT |
| 03901 8239 | 90311-42003 | 42 x 60 x 7 | CARINA ED 1S#,3S#,4S# | 87/8~89/ | Engine CRANK SHAFT FRONT |
| 03901 1089 | 90311-42026 | 42 x 60 x 7 | CARINA ED 3S#,4S# | 89/9~98/ | Engine CRANK SHAFT FRONT |
| 03901 5917 | 90311-85004 | 85 x 105 x 10 | CARINA ED 1S#,3S#,4SFE | 87/8~90/10 | Engine CRANK SHAFT REAR |
| 03901 3767 | 90311-85004 | 85 x 105 x 10 | CARINA ED 3SGE#...ST162 | 87/8~89/ | Engine CRANK SHAFT REAR |
| 03901 5743 | 90311-85007 | 85 x 105 x 10 | CARINA ED 3SFE,4SFE | 90/10~98/ | Engine CRANK SHAFT REAR |
| 03901 7831 | 90311-89002 | 89 x 105 x 10 | CARINA ED 3SGE | 89/9~98/ | Engine CRANK SHAFT REAR |
| 03901 4813 | 90913-02056 | | CARINA ED 1S# | 87/8~88/ | Engine VALVE STEM SEAL |
| 03901 4097 | 90913-02062 | | CARINA ED 3S#,4S# | 87/8~90/3 | Engine VALVE STEM SEAL |
| 03901 4685 | 90913-02062 | | CARINA ED 3S#,4S#(IN.) | 90/3~98/ | Engine VALVE STEM SEAL |
| 03901 4045 | 90913-02079 | | CARINA ED 3S#,4S#(EX.) | 90/3~93/ | Engine VALVE STEM SEAL |
| 03901 6275 | 90913-02079 | | CARINA ED 3SFE,4SFE(EX.) | 93/9~98/ | Engine VALVE STEM SEAL |
| 03901 5797 | 90913-02104 | | CARINA ED 3SGE | 93/9~98/ | Engine VALVE STEM SEAL |
| 03901 2103 | 90311-38036 | 38 x 50 x 8 | CARINA ED 1S#,3SFE,4SFE | 87/8~98/ | Engine CAM SHAFT |
| 03901 6947 | 90311-44003 | 44 x 80 x 9 x 15.5 | CARINA ED ST205 (4WD) | 94/5~98/ | Mission & Differential (M/T) TRANSMISSION CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4089 | 90311-38020 | 38 x 55 x 8.5 | CARINA ED ST16#,18#,20# | 87/8~98/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 3377 | 90311-44003 | 44 x 80 x 9 x 15.5 | CARINA ED ST205 (4WD) | 94/5~98/ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 7375 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA ED ST20#...F,X,SLIM,GLIM | 93/9~98/ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 1483 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA ED ST16#,18# | 87/8~93/ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 5877 | 04445-20180 | | CARINA ED ST200,202,205 | 93/9~98/ | Steering (P/S) R&P GASKET KIT |
| 03901 6209 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA ED ST16#,18# | 87/8~93/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5423 | 04422-20080 | Kit | CARINA ED ST200,201,202,203 ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 5169 | 90311-50010 | 50 x 80 x 16.5 x 23 | CARINA ED ST202 GLIM | 93/9~98/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 3601 | 90311-40004 | 40 x 56 x 9 x 15.5 | CARINA ED ST202 GLIM | 93/9~98/ | Mission & Differential (M/T) TRANSAXLE CASE COVER |
| 03901 6257 | 9031135033 | 35 x 55 x 9 x 15.5 | CARINA ED ST20#...F,X,SLIM,GLIM | 93/9~98/ | Mission & Differential (M/T) DIFF.SIDE |
| 03901 4695 | 9031135033 | 35 x 55 x 9 x 15.5 | CARINA ED ST20#...F,X,SLIM,GLIM | 93/9~98/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4877 | 90311-30006 | 30 x 42 x 7 | CARINA ED ST16#,18#,20# | 87/8~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1527 | 90311-52005 | 52 x 75 x 7.5 x 12 | CARINA ED ST205 (4WD) | 94/5~98/ | Wheel Hub REAR OUTER |
| 03901 5695 | 04422-20010 | Kit | CARINA ED ST16# | 87/8~89/ | Wheel Hub FRONT (LH) |
| 03901 6061 | 90311-35033 | 35 x 55 x 9 x 15.5 | CARINA ED ST20#...F,X,SLIM,GLIM | 93/9~98/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1951 | 90311-56015 | 56 x 75 x 7 x 12 | CARINA ED ST205 (4WD) | 94/5~98/ | Wheel Hub REAR INNER |
| 03901 4781 | 04422-20090 | Kit | CARINA ED ST202 GLIM ABS,ST205 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 7601 | 04422-20100 | Kit | CARINA ED ST202 GLIM ABS & SSS,ST205 ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 5285 | 04422-20010 | Kit | CARINA ED ST180,182 WITHOUT ABS | 89/9~93/ | Wheel Hub FRONT (LH) |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8183 | 04422-20010 | Kit | CARINA ED ST200,202 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 1361 | 04422-20080 | Kit | CARINA ED ST180,182 ABS | 89/9~93/ | Wheel Hub FRONT (LH) |
| 03901 3599 | 04422-20080 | Kit | CARINA ED ST181,183 | 89/9~93/ | Wheel Hub FRONT (LH) |
| 03901 3839 | 04422-20080 | Kit | CARINA ED ST200,202 ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 1971 | 04422-20080 | Kit | CARINA ED ST201,203 | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 5019 | 04422-20090 | Kit | CARINA ED ST202 GLIM SSS,ST205 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 4055 | 04422-20100 | Kit | CARINA ED ST202 GLIM ABS & SSS,ST205 ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 3107 | 90311-42018 | 42 x 55 x 6 | CARINA ED ST16#,18# | 87/8~93/ | Wheel Hub REAR |
| 03901 3893 | 04422-20080 | Kit | CELICA (FWD) ST18#...ABS | 89/9~93/ | Wheel Hub FRONT |
| 03901 5151 | 04422-12121 | Kit | CELICA (FWD) ST202 SS2,3 ABS &SUPER STRUT SUS. | 93/9~99/ | Wheel Hub FRONT |
| 03901 2045 | 90311-56015 | 56 x 75 x 7 x 12 | CELICA (FWD) ST185,205 (4WD) | 91/4~99/ | Wheel Hub REAR INNER |
| 03901 6005 | 90311-56007 | 56 x 75 x 6.5 x 11 | CELICA (FWD) ST165,185 (4WD) | 86/10~91/4 | Wheel Hub REAR INNER |
| 03901 8045 | 90311-42018 | 42 x 55 x 6 | CELICA (FWD) ST182,183 | 85/9~93/ | Wheel Hub REAR |
| 03901 6781 | 90311-42018 | 42 x 55 x 6 | CELICA (FWD) ST160,162,163,AT160 | 85/8~89/ | Wheel Hub REAR |
| 03901 3575 | 04422-12121 | Kit | CELICA (FWD) ST205 (4WD) | 94/2~99/ | Wheel Hub FRONT |
| 03901 1949 | 90311-52005 | 52 x 75 x 7.5 x 12 | CELICA (FWD) ST165,185,205 (4WD) | 86/10~99/ | Wheel Hub REAR OUTER |
| 03901 2171 | 04422-12111 | Kit | CELICA (FWD) ST202 SS2,3 SUPER STRUT SUS. | 93/9~96/ | Wheel Hub FRONT |
| 03901 3145 | 04422-20080 | Kit | CELICA (FWD) ST203 | 93/9~97/ | Wheel Hub FRONT |
| 03901 4373 | 90311-85004 | 85 x 105 x 10 | CELICA (FWD) 1S#,3SF#,4SF#...ST16#,18# | 85/8~90/10 | Engine CRANK SHAFT REAR |
| 03901 1401 | 90311-25011 | 25 x 37 x 8 | CELICA (FWD) AT160 | 85/8~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 7547 | 04422-20010 | Kit | CELICA (FWD) ST18#...WITHOUT ABS | 89/9~93/ | Wheel Hub FRONT |
| 03901 5979 | 04422-20010 | Kit | CELICA (FWD) ST202 CV | 96/6~97/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4241 | 04422-20080 | Kit | CELICA (FWD) ST202 CV,SS1,SS2 ABS | 93/9~99/ | Wheel Hub FRONT |
| 03901 2271 | 04422-20010 | Kit | CELICA (FWD) ST202 CV,SS1,SS2 | 93/9~96/6 | Wheel Hub FRONT |
| 03901 1461 | 90311-35013 | 35 x 49 x 6 | CELICA (FWD) 3SGTE ST205 | 97/12~99/ | Engine CAM SHAFT |
| 03901 5887 | 04422-20010 | Kit | CELICA (FWD) ST16#,AT160 | 85/~89/ | Wheel Hub FRONT |
| 03901 3399 | 90311-42026 | 42 x 60 x 7 | CELICA (FWD) 3SG#...ST202,205 | 96/9~99/ | Engine CRANK SHAFT FRONT |
| 03901 3743 | 90311-42026 | 42 x 60 x 7 | CELICA (FWD) 3S#...ST18#,20# | 89/9~96/9 | Engine CRANK SHAFT FRONT |
| 03901 6327 | 90311-42003 | 42 x 60 x 7 | CELICA (FWD) 1S#,3S#,4SF#...ST16# | 85/8~89/ | Engine CRANK SHAFT FRONT |
| 03901 5897 | 90311-38059 | 38 x 50 x 8 | CELICA (FWD) 1ZZFE,2ZZGE ZZT23# | 99/8~ | Engine TIMING GEAR COVER |
| 03901 5879 | 90311-32020 | 32 x 46 x 6 | CELICA (FWD) 4A#...AT160 | 85/8~87/ | Engine OIL PUMP |
| 03901 2073 | 90311-38036 | 38 x 50 x 8 | CELICA (FWD) 3SGTE ST202,203 | 93/9~97/8 | Engine CAM SHAFT |
| 03901 3555 | 90311-38036 | 38 x 50 x 8 | CELICA (FWD) 1S#,3SF#,4SF#...ST16#,18# | 85/8~93/ | Engine CAM SHAFT |
| 03901 5555 | 90311-42035 | 42 x 60 x 7 | CELICA (FWD) 3SFE ST202,203 | 96/9~99/ | Engine CRANK SHAFT FRONT |
| 03901 4507 | 90311-35041 | 35 x 60 x 11 | CELICA (FWD) 3SGTE ST202 | 97/12~99/ | Engine CAM SHAFT (NO.1) |
| 03901 1471 | 90311-85007 | 85 x 105 x 10 | CELICA (FWD) 3SF#...ST18#,20# | 90/10~99/ | Engine CRANK SHAFT REAR |
| 03901 2245 | 90311-35013 | 35 x 49 x 6 | CELICA (FWD) 3SG#...ST202,205 | 93/9~97/12 | Engine CAM SHAFT |
| 03901 7915 | 90311-35013 | 35 x 49 x 6 | CELICA (FWD) 3SG#...ST16#,18# | 85/8~93/ | Engine CAM SHAFT |
| 03901 5801 | 90311-35013 | 35 x 49 x 6 | CELICA (FWD) 4A#...AT160 | 85/8~87/ | Engine CAM SHAFT |
| 03901 3363 | 90310-25032 | 25 x 35 x 6 | CELICA (FWD) ZZT23# | 99/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2609 | 90310-31001 | 31 x 44 x 6.5 | CELICA (FWD) ST182,185,202,205 | 89/9~99/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6205 | 90310-31001 | 31 x 44 x 6.5 | CELICA (FWD) ST162,163 | 89/3~89/ | Steering (P/S) CONTROL VALVE LOWER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8037 | 90310-31001 | 31 x 44 x 6.5 | CELICA (FWD) ST162(GT) | 87/8~89/3 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7435 | 90310-31001 | 31 x 44 x 6.5 | CELICA (FWD) AT160,ST162 | 86/2~87/8 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6517 | 90311-46004 | 46 x 60 x 6.5 | CELICA (FWD) 3SGTE ST202 | 97/12~99/ | Engine CAM SHAFT (NO.2) |
| 03901 6701 | 90913-02079 | | CELICA (FWD) 3SFE (IN.) | 93/8~99/ | Engine VALVE STEM SEAL |
| 03901 1243 | 90913-02111 | | CELICA (FWD) 1ZZFE (EX.) | 99/8~ | Engine VALVE STEM SEAL |
| 03901 3077 | 90913-02101 | | CELICA (FWD) 1ZZFE (IN.) | 99/8~ | Engine VALVE STEM SEAL |
| 03901 6993 | 90913-02115 | | CELICA (FWD) 2ZZGE (EX.) | 99/8~ | Engine VALVE STEM SEAL |
| 03901 2259 | 90913-02115 | | CELICA (FWD) 3SGE (EX.) | 97/12~99/ | Engine VALVE STEM SEAL |
| 03901 2613 | 90913-02104 | | CELICA (FWD) 3SGTE (EX.) | 97/12~99/ | Engine VALVE STEM SEAL |
| 03901 4753 | 90913-02104 | | CELICA (FWD) 3SG# (EX.) | 93/8~97/12 | Engine VALVE STEM SEAL |
| 03901 4849 | 90913-02114 | | CELICA (FWD) 2ZZGE (IN.) | 99/8~ | Engine VALVE STEM SEAL |
| 03901 4863 | 90913-02114 | | CELICA (FWD) 3SGE (IN.) | 97/12~99/ | Engine VALVE STEM SEAL |
| 03901 4377 | 90311-70004 | 70 x 92 x 8.5 | CELICA (FWD) 4A#...AT160 | 85/8~87/ | Engine CRANK SHAFT REAR |
| 03901 2607 | 90913-02079 | | CELICA (FWD) 3SG# (IN.) | 93/8~97/12 | Engine VALVE STEM SEAL |
| 03901 6003 | 90311-38067 | 38 x 50 x 8 | CELICA (FWD) 3SGTE ST202,203 | 97/12~99/ | Engine CAM SHAFT |
| 03901 3439 | 90913-02062 | | CELICA (FWD) 3SFE (EX.) | 93/8~99/ | Engine VALVE STEM SEAL |
| 03901 4061 | 90913-02062 | | CELICA (FWD) 3S#,4S# (EX.) | 90/3~93/8 | Engine VALVE STEM SEAL |
| 03901 4537 | 90913-02062 | | CELICA (FWD) 3S#,4S# (IN. & EX.) | 85/8~90/3 | Engine VALVE STEM SEAL |
| 03901 2591 | 90913-02056 | | CELICA (FWD) | 85/8~88/ | Engine VALVE STEM SEAL |
| 03901 4563 | 90913-02062 | | CELICA (FWD) 4A# | 85/8~87/ | Engine VALVE STEM SEAL |
| 03901 6997 | 90311-76001 | 76 x 94 x 8.5 | CELICA (FWD) 1ZZFE ZZT230 | 99/8~ | Engine CRANK SHAFT REAR |
| 03901 7185 | 90311-89001 | 89 x 105 x 10 | CELICA (FWD) 3SG#...ST18#,20# | 89/9~99/ | Engine CRANK SHAFT REAR |
| 03901 3765 | 90311-85007 | 85 x 105 x 10 | CELICA (FWD) 2ZZGE ZZT231 | 99/8~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3249 | 90310-28003 | 28 x 41 x 6.5 | CELICA (FWD) ST160,165 | 89/3 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2287 | 90913-02079 | | CELICA (FWD) 3SGTE (IN.) | 97/12~99/ | Engine VALVE STEM SEAL |
| 03901 2203 | 90311-50010 | 50 x 80 x 16.5 x 23 | CELICA (FWD) ST205 (4WD) | 95/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1617 | 90310-31001 | 31 x 44 x 6.5 | CELICA (FWD) AT160,ST16# | 85/8~86/2 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3357 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ST16#,18#,20#...2WD | 85/8~99/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3437 | 90311-35046 | 35 x 57 x 9 x 15.5 | CELICA (FWD) ZZT230 | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 5373 | 90311-35020 | 35 x 63 x 9 x 15.5 | CELICA (FWD) ST202 CV,SS2,SS3 | 97/12~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2329 | 90311-35020 | 35 x 63 x 9 x 15.5 | CELICA (FWD) ST182,183 | 89/9~93/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 6715 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ZZT230 | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1241 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ST202 SS1 | 97/12~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2687 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ST202,203 | 93/9~97/12 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1309 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ZZT231 | 99/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 7587 | 90311-40004 | 40 x 56 x 9 x 15.5 | CELICA (FWD) ST202 SS2 | 93/9~95/8 | Mission & Differential (M/T) TRANSAXLE CASE COVER |
| 03901 7285 | 90311-38020 | 38 x 55 x 8.5 | CELICA (FWD) ST16#,18#,20# | 85/8~99/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 6379 | 90311-50010 | 50 x 80 x 16.5 x 23 | CELICA (FWD) ST202,205 GT4,SS2 | 93/9~95/8 | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 5993 | 90311-50010 | 50 x 80 x 16.5 x 23 | CELICA (FWD) ST165,185 (4WD) | 85/8~93/ | Mission & Differential (M/T) TRANSMISSION CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2989 | 90311-35044 | 35 x 63 x 10 x 22 | CELICA (FWD) ZZT23# | 99/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 6817 | 90311-34017 | 34 x 63 x 9 x 16 | CELICA (FWD) AT160 | 85/8~87/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 7049 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ST16#,18#,20#...2WD | 85/8~99/ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 3463 | 90311-35043 | 35 x 54 x 9 x 21.5 | CELICA (FWD) ZZT23# | 99/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 5307 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ST16#,18#,20#...2WD | 85/8~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 5233 | 90311-34016 | 34 x 54 x 9 x 15.5 | CELICA (FWD) AT160 | 85/8~87/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 3589 | 90311-30006 | 30 x 42 x 7 | CELICA (FWD) ST16#,18#,20# | 85/8~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1739 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ST16#...2WD | 85/8~89/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 8049 | 04445-20110 | | CELICA (FWD) ST182 | 91/8~93/ | Steering (P/S) R &P GASKET KIT |
| 03901 2179 | 90311-25011 | 25 x 37 x 8 | CELICA (FWD) ZZT23# | 99/8~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 4187 | 90310-28003 | 28 x 41 x 6.5 | CELICA (FWD) ST160,162(ZR,CV),163,165 | 87/8~89/3 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4643 | 90310-28003 | 28 x 41 x 6.5 | CELICA (FWD) ST160,165 | 86/2~87/8 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7395 | 90311-20008 | 20 x 34 x 7 | CELICA (FWD) ZZT23# | 99/8~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1125 | 90311-19002 | 19 x 32 x 7 x 8 | CELICA (FWD) AT160,ST16# | 85/8~99/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1189 | 04445-20261 | | CELICA (FWD) ZZT23# | 99/8~ | Steering (P/S) R &P GASKET KIT |
| 03901 4739 | 04445-20180 | | CELICA (FWD) ST203,205 | 93/9~99/ | Steering (P/S) R &P GASKET KIT |
| 03901 5153 | 04445-20230 | | CELICA (FWD) ST203 | 96/2~97/ | Steering (P/S) R &P GASKET KIT |
| 03901 8013 | 90311-35033 | 35 x 55 x 9 x 15.5 | CELICA (FWD) ZZT231 | 99/8~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 4519 | 04445-20130 | | CELICA (FWD) ST185 | 91/8~93/ | Steering (P/S) R &P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2377 | 90310-28003 | 28 x 41 x 6.5 | CELICA (FWD) ST183,203 | 89/9~97/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1129 | 04445-20110 | | CELICA (FWD) ST162,185 | 89/9~91/8 | Steering (P/S) R &P GASKET KIT |
| 03901 6731 | 04445-32030 | | CELICA (FWD) ST165 | 86/10~89/ | Steering (P/S) R &P GASKET KIT |
| 03901 4283 | 04445-20060 | | CELICA (FWD) ST160,162(ZR,CV),163 | 87/8~89/ | Steering (P/S) R &P GASKET KIT |
| 03901 3867 | 04445-20060 | | CELICA (FWD) ST160 | 86/2~87/8 | Steering (P/S) R &P GASKET KIT |
| 03901 4855 | 04445-20040 | | CELICA (FWD) ST162,163 | 89/3~89/ | Steering (P/S) R &P GASKET KIT |
| 03901 4077 | 04445-20040 | | CELICA (FWD) ST162(GT) | 87/8~89/3 | Steering (P/S) R &P GASKET KIT |
| 03901 2131 | 04445-20040 | | CELICA (FWD) AT160,ST162 | 86/2~87/8 | Steering (P/S) R &P GASKET KIT |
| 03901 1881 | 04445-20040 | | CELICA (FWD) AT160,ST16# | 85/8~86/2 | Steering (P/S) R &P GASKET KIT |
| 03901 5021 | 90311-38064 | 38 x 55 x 8.7 | CELICA (FWD) ST23# | 99/8~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4819 | 04445-20103 | | CELICA (FWD) ST183,203 | 89/9~96/2 | Steering (P/S) R &P GASKET KIT |
| 03901 4741 | 15165-70010 | 18 x 30 x 7 | CELICA (FWD) 1S#,3S#,4SF#...ST16#,18#,20# | 85/8~99/ | Engine OIL PUMP |
| 03901 1409 | 90311-32074 | 32 x 52 x 11 | CELICA (RWD) AA63,TA61,SA60 ALL,TA63 SV,ST,SX | 81/7~85/ | Transmission (M/T) REAR EXTENTION |
| 03901 4487 | 90311-19002 | 19 x 32 x 7 x 8 | CELICA (RWD) AA63,TA63,RA63,GA61,MA6#,SA60 | 81/7~85/ | Steering (P/S) ADJUSTER PLUG |
| 03901 4621 | 90311-15001 | 15 x 25 x 7 | CELICA (RWD) AA63,TA61,63,64,SA60,RA63,GA61 | 81/7~85/ | Steering (M/S) RACK HOUSING |
| 03901 2865 | 90311-38018 | 38 x 50 x 8 | CELICA (RWD) GA61 L,S,G | 85/9~85/ | Final Drive DUFF. SIDE |
| 03901 1599 | 90311-38011 | 38 x 63 x 10 x 17 | CELICA (RWD) GA61(GT),MA61(GT),MA63 | 85/9~85/ | Final Drive DUFF. SIDE |
| 03901 1135 | 90311-38011 | 38 x 63 x 10 x 17 | CELICA (RWD) AA63,TA61,63,RA63,GA61, MA6# | 81/7~85/9 | Final Drive DUFF. SIDE |
| 03901 4417 | 90311-38133 | 38 x 74 x 11 | CELICA (RWD) TA64,MA63 ALL | 81/7~85/ | Final Drive PINION |
| 03901 6093 | 90311-38015 | 38 x 65 x 12 x 19 | CELICA (RWD) SA60 | 81/8~85/ | Final Drive PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3151 | 90311-38015 | 38 x 65 x 12 x 19 | CELICA (RWD) TA6#,SA60,GA61 | 81/7~81/8 | Final Drive PINION |
| 03901 2819 | 90311-38020 | 38 x 55 x 8.5 | CELICA (RWD) TA64,SA60,GA61,MA6# | 81/7~85/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1043 | 90311-11128 | 11 x 22 x 7 | CELICA (RWD) TA64,SA60,GA61,MA6# | 81/7~85/ | Transmission (A/T) LEVER SHAFT |
| 03901 5079 | 90311-38013 | 38.5 x 58 x 11 | CELICA (RWD) 2TGEU,3T#,4TGTEU TA6# | 81/7~85/ | Engine TIMING GEAR COVER |
| 03901 5303 | 90311-38043 | 38 x 58 x 11 | CELICA (RWD) TA63(GTT),64,RA63,GA61, MA61 | 81/7~85/ | Transmission (M/T) REAR EXTENTION |
| 03901 3207 | 90311-38019 | 38 x 65 x 10 x 17 | CELICA (RWD) TA63,GA61 ST,SX,L,S,G, TA61 ALL | 81/8~85/ | Final Drive PINION |
| 03901 7065 | 90311-30115 | 30 x 45 x 8 | CELICA (RWD) TA63(GTT),64,RA63,GA61, MA61 | 81/7~85/ | Transmission (M/T) FRONT COVER |
| 03901 1791 | 90311-25003 | 25 x 38 x 7 | CELICA (RWD) AA63,TA61,SA60 ALL,TA63 SV,ST,SX | 81/7~85/ | Transmission (M/T) FRONT COVER |
| 03901 7331 | 90311-48001 | 48 x 62 x 9 | CELICA (RWD) AA63,TA61,63,RA63,GA61, MA6# | 83/5~85/ | Wheel Hub REAR OUTER |
| 03901 1987 | 90311-48122 | 48 x 62 x 7 | CELICA (RWD) TA61,63,RA63,GA61,MA6# | 81/7~83/5 | Wheel Hub REAR OUTER |
| 03901 2059 | 90311-38009 | 38 x 58 x 8 | CELICA (RWD) AA63,TA61,63,RA63,GA61, MA6# | 81/7~85/ | Wheel Hub REAR INNER |
| 03901 8119 | 90311-52059 | 52 x 65 x 9 | CELICA (RWD) TA64,SA60 | 81/7~85/ | Wheel Hub REAR |
| 03901 3695 | 90311-48122 | 48 x 62 x 7 | CELICA (RWD) AA63,TA6#,RA63,GA61,M A6# | 81/7~85/ | Wheel Hub FRONT |
| 03901 8169 | 90311-41123 | 41 x 53 x 7 | CELICA (RWD) SA60 | 81/7~85/ | Wheel Hub FRONT |
| 03901 6539 | 90311-45003 | 45 x 62 x 8 | CELICA (RWD) 1G#...GA61 | 81/7~85/ | Engine TIMING GEAR CASE |
| 03901 5769 | 04332-30020 | Kit | CELICA (RWD) TA64,SA60,GA61,MA6# | 81/7~85/ | Transmission (A/T) EXTENTION HOUSING |
| 03901 3003 | 90311-42003 | 42 x 60 x 7 | CELICA (RWD) 1SU SA60 | 81/7~85/ | Engine CRANK SHAFT FRONT |
| 03901 1887 | 90311-42003 | 42 x 60 x 7 | CELICA (RWD) 5MGEU MA61 | 81/7~85/ | Engine TIMING GEAR CASE |
| 03901 3409 | 90311-38013 | 38.5 x 58 x 11 | CELICA (RWD) 5MGEU MA61 | 81/7~85/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6751 | 90311-35013 | 35 x 49 x 6 | CELICA (RWD) 1GGEU GA61 | 81/7~85/ | Engine CAM SHAFT |
| 03901 6493 | 90311-35013 | 35 x 49 x 6 | CELICA (RWD) 4AGEU AA63 | 83/8~85/ | Engine CAM SHAFT |
| 03901 5133 | 90311-38036 | 38 x 50 x 8 | CELICA (RWD) 1SU SA60, 1GEU GA61 | 81/7~85/ | Engine CAM SHAFT |
| 03901 6271 | 90311-38133 | 38 x 74 x 11 | CELICA (RWD) AA63,TA63,RA63,GA61,MA61 GT,GTT | 81/7~85/ | Final Drive PINION |
| 03901 5295 | 90311-32020 | 32 x 46 x 6 | CELICA (RWD) 4AGEU AA63 | 83/8~85/ | Engine OIL PUMP |
| 03901 5385 | 90311-45002 | 45 x 68 x 12 | CELICA (RWD) 18RGEU RA63,MTEU MA63 | 81/7~85/ | Engine TIMING GEAR COVER |
| 03901 3543 | 90311-75114 | 75 x 100 x 13 | CELICA (RWD) 2TGEU,3T#,4TGTEU TA6#,1G#...GA61 | 81/7~85/ | Engine CRANK SHAFT REAR |
| 03901 7753 | 90311-80001 | 80 x 100 x 12 | CELICA (RWD) 18RGEU RA63,MTEU,5MGEU MA6# | 81/7~85/ | Engine CRANK SHAFT REAR |
| 03901 6125 | 90311-85004 | 85 x 105 x 10 | CELICA (RWD) 1SU SA60 | 81/7~85/ | Engine CRANK SHAFT REAR |
| 03901 7357 | 90311-70004 | 70 x 92 x 8.5 | CELICA (RWD) 4AGEU AA63 | 83/8~85/ | Engine CRANK SHAFT REAR |
| 03901 1403 | 90913-02024 | | CELICA (RWD) 3TEU(IN.) TA63 | 81/7~83/8 | Engine VALVE STEM SEAL |
| 03901 7123 | 90913-02038 | | CELICA (RWD) 1GEU GA61 | 81/7~85/ | Engine VALVE STEM SEAL |
| 03901 2997 | 15165-70010 | 18 x 30 x 7 | CELICA (RWD) 1SU SA60, 1G#...GA61 | 81/7~85/ | Engine OIL PUMP |
| 03901 5785 | 90913-02058 | | CELICA (RWD) 3TEU(EX.) TA63 | 81/7~83/8 | Engine VALVE STEM SEAL |
| 03901 4261 | 90913-02056 | | CELICA (RWD) 1SU SA60 | 81/7~85/ | Engine VALVE STEM SEAL |
| 03901 4195 | 90913-02062 | | CELICA (RWD) 1GGEU GA61 | 82/8~85/ | Engine VALVE STEM SEAL |
| 03901 4845 | 90311-48004 | 48 x 70 x 12 | CELICA (RWD) 5MGEU MA61 | 81/7~85/ | Engine TIMING GEAR COVER |
| 03901 1271 | 90913-02110 | | CELICA (RWD) 5MGEU MA61 | 81/7~85/ | Engine VALVE STEM SEAL |
| 03901 6851 | 90913-02015 | | CELICA (RWD) MTEU(EX.) MA63 | 82/2~85/ | Engine VALVE STEM SEAL |
| 03901 2889 | 90913-02022 | | CELICA (RWD) MTEU(IN.) MA63 | 82/2~85/ | Engine VALVE STEM SEAL |
| 03901 7505 | 90913-02060 | | CELICA (RWD) 3TGEU,4TGEU TA63,64 | 82/10~85/ | Engine VALVE STEM SEAL |
| 03901 2765 | 90072-72006 | | CELICA (RWD) 2TGEU TA61, 18RGEU RA63 | 81/7~83/8 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7351 | 90913-02062 | | CELICA (RWD) 4AGEU AA63 | 83/8~85/ | Engine VALVE STEM SEAL |
| 03901 2827 | 04445-50012 | | CELSIOR / LEXUS LS400 UCF1# | 89/11~92/8 | Steering (P/S) R &P GASKET KIT |
| 03901 5489 | 04445-50013 | | CELSIOR / LEXUS LS401 UCF1# | 92/8~94/ | Steering (P/S) R &P GASKET KIT |
| 03901 7117 | 90311-42024 | 42 x 55 x 10 | CELSIOR / LEXUS LS402 UCF1#,2# | 89/11~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 1973 | 90311-47008 | 47 x 72 x 10 x 11 | CELSIOR / LEXUS LS403 UCF2#,3# | 97/7~ | Final Drive DIFF. SIDE |
| 03901 4217 | 90311-47003 | 47 x 84 x 11 x 17.5 | CELSIOR / LEXUS LS404 UCF1#,2# | 89/11~97/7 | Final Drive DIFF. SIDE |
| 03901 1245 | 90311-44005 | 44 x 74 x 11 x 16 | CELSIOR / LEXUS LS405 UCF1#,2#,3# | 89/11~ | Final Drive PINION |
| 03901 1943 | 90311-38029 | 38 x 55 x 7.5 | CELSIOR / LEXUS LS406 UCF1#,2# | 89/11~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7163 | 90311-57001 | 57 x 81 x 8 x 11 | CELSIOR / LEXUS LS407 UCF2# | 94/10~00/ | Wheel Hub REAR OUTER |
| 03901 3423 | 90311-57001 | 57 x 81 x 8 x 11 | CELSIOR / LEXUS LS408 UCF1# | 89/11~94/ | Wheel Hub REAR OUTER |
| 03901 4029 | 90311-63001 | 63 x 90 x 7 x 10 | CELSIOR / LEXUS LS409 UCF2# | 94/10~00/ | Wheel Hub REAR INNER |
| 03901 7883 | 90311-63001 | 63 x 90 x 7 x 10 | CELSIOR / LEXUS LS410 UCF1# | 89/11~94/ | Wheel Hub REAR INNER |
| 03901 2541 | 90311-50008 | 50 x 77.5 x 9 x 14 | CELSIOR / LEXUS LS411 UCF1# | 89/11~94/ | Wheel Hub FRONT |
| 03901 5269 | 90913-02112 | | CELSIOR / LEXUS LS412 1UZFE,3UZFE (EX.) | 97/7~ | Engine VALVE STEM SEAL |
| 03901 6655 | 04445-50020 | | CELSIOR / LEXUS LS413 UCF2# | 94/10~97/7 | Steering (P/S) R &P GASKET KIT |
| 03901 3609 | 90311-50008 | 50 x 77.5 x 9 x 14 | CELSIOR / LEXUS LS414 UCF2# | 94/10~00/ | Wheel Hub FRONT |
| 03901 2479 | 90913-02062 | | CELSIOR / LEXUS LS415 1UZFE (IN. &EX.) | 89/11~94/ | Engine VALVE STEM SEAL |
| 03901 4587 | 90913-02106 | | CELSIOR / LEXUS LS416 1UZFE (IN. &EX.) | 94/10~97/7 | Engine VALVE STEM SEAL |
| 03901 6495 | 04445-50030 | | CELSIOR / LEXUS LS417 UCF2# | 97/7~00/ | Steering (P/S) R &P GASKET KIT |
| 03901 3459 | 90913-02113 | | CELSIOR / LEXUS LS418 1UZFE,3UZFE (IN.) | 97/7~ | Engine VALVE STEM SEAL |
| 03901 8083 | 90311-95012 | 95 x 113 x 8.5 | CELSIOR / LEXUS LS419 3UZFE UCF3# | 00/8~ | Engine CRANK SHAFT REAR |
| 03901 3445 | 90311-95012 | 95 x 113 x 8.5 | CELSIOR / LEXUS LS420 1UZFE UCF1#,2# | 89/11~00/ | Engine CRANK SHAFT REAR |
| 03901 2465 | 90311-43006 | 43 x 60 x 7 | CELSIOR / LEXUS LS421 3UZFE UCF3# | 00/8~ | Engine OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6609 | 90311-43006 | 43 x 60 x 7 | CELSIOR / LEXUS LS422 1UZFE UCF2# | 97/12~00/ | Engine OIL PUMP |
| 03901 6825 | 90311-19002 | 19 x 32 x 7 x 8 | CELSIOR / LEXUS LS423 UCF1#,2#,3# | 89/11~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5187 | 90311-71001 | 71.5 x 85 x 10 | CELSIOR / LEXUS LS424 3UZFE UCF3# | 00/8~ | Engine CAM SHAFT |
| 03901 4779 | 90311-71001 | 71.5 x 85 x 10 | CELSIOR / LEXUS LS425 1UZFE UCF2# | 97/7~00/ | Engine CAM SHAFT |
| 03901 3545 | 90311-38036 | 38 x 50 x 8 | CELSIOR / LEXUS LS426 1UZFE UCF1#,2# | 89/11~97/ 7 | Engine CAM SHAFT |
| 03901 5231 | 90310-30013 | 30 x 41 x 6.5 | CELSIOR / LEXUS LS427 UCF1#,2#,3# | 89/11~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4679 | 90311-43004 | 43 x 60 x 7 | CELSIOR / LEXUS LS428 1UZFE UCF1#,2# | 89/11~97/ 12 | Engine OIL PUMP |
| 03901 2263 | 04445-50040 | | CELSIOR / LEXUS LS429 UCF3# | 00/8~ | Steering (P/S) R &P GASKET KIT |
| 03901 1743 | 9828-01228 | 100 x 135 x 15 | COASTER J05C RX4JFAT# | 96/6~ | Engine CRANK SHAFT REAR |
| 03901 3035 | 90311-95008 | 95 x 115 x 9.5 x 12 | COASTER 1HZ,1HD#...HZB4#,5#,HDB 5# | 93/1~ | Engine CRANK SHAFT REAR |
| 03901 7307 | 90311-95008 | 95 x 115 x 9.5 x 12 | COASTER 1HZ,1HDT HZB3#,HDB20,3# | 90/1~93/ | Engine CRANK SHAFT REAR |
| 03901 5613 | 90311-95008 | 95 x 115 x 9.5 x 12 | COASTER 15B#,1BZFPE,3B BB4#,5#,BZB40,50 | 93/1~ | Engine CRANK SHAFT REAR |
| 03901 6279 | 90311-95008 | 95 x 115 x 9.5 x 12 | COASTER 3B,14B BB2#,31 | 88/8~93/ | Engine CRANK SHAFT REAR |
| 03901 7981 | 90311-95001 | 95 x 115 x 12 | COASTER 2H,12HT HB3# | 82/5~90/1 | Engine CRANK SHAFT REAR |
| 03901 4357 | 90311-80001 | 80 x 100 x 12 | COASTER 2OR,22R RB1#,2# | 77/8~83/6 | Engine CRANK SHAFT REAR |
| 03901 3309 | 90311-95001 | 95 x 115 x 12 | COASTER 2B,3B BB1#,2#,3# | 77/8~88/8 | Engine CRANK SHAFT REAR |
| 03901 3119 | 90311-80010 | 80 x 100 x 10 x 11.5 | COASTER 22R RB2# | 83/6~93/ | Engine CRANK SHAFT REAR |
| 03901 7333 | 90913-02024 | | COASTER 20R,22R RB1#,2# | 77/8~82/1 2 | Engine VALVE STEM SEAL |
| 03901 7301 | 90913-02094 | | COASTER 1HZ,1HDT HZB3#,HDB20,3# | 90/11~93/ | Engine VALVE STEM SEAL |
| 03901 6087 | 04445-36120 | | COASTER BB5# | 95/12~99/ 7 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2069 | 90913-02110 | | COASTER 22R RB2# | 82/12~93/ | Engine VALVE STEM SEAL |
| 03901 1785 | 90913-02028 | | COASTER 2B BB1# | 77/8~80/8 | Engine VALVE STEM SEAL |
| 03901 7067 | 90913-02051 | | COASTER 2B,3B BB1#,2#,3# | 80/8~88/8 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8261 | 90913-02076 | | COASTER 3B,14B BB2#,31,4# | 88/8~99/7 | Engine VALVE STEM SEAL |
| 03901 1861 | 90913-02108 | | COASTER 15BF BB5# | 95/12~99/3 | Engine VALVE STEM SEAL |
| 03901 5123 | 90913-02096 | | COASTER 15B#,1BZFPE BB58,BZB40,50 | 99/3~ | Engine VALVE STEM SEAL |
| 03901 3085 | 90913-02110 | | COASTER 1HZ,1HDT HZB3#,HDB20,3# | 90/1~90/11 | Engine VALVE STEM SEAL |
| 03901 7267 | 90913-02094 | | COASTER 1HZ,1HDT HZB4#,5#,HDB5# | 93/1~97/7 | Engine VALVE STEM SEAL |
| 03901 3055 | 90913-02096 | | COASTER 1HD#...HDB5# | 95/5~ | Engine VALVE STEM SEAL |
| 03901 5559 | 90913-02056 | | COASTER 1HZ HZB4#,5# | 97/7~ | Engine VALVE STEM SEAL |
| 03901 2055 | 90311-32020 | 32 x 46 x 6 | COASTER 1HZ,1HD#...HZB4#,5#,HDB5# | 93/1~ | Engine CAM SHAFT |
| 03901 2365 | 90913-02050 | | COASTER 2H,12HT HB3# | 82/5~90/1 | Engine VALVE STEM SEAL |
| 03901 6665 | 90310-38033 | 38 x 44 x 18 | COASTER RB2#,BB2#,3#,HB3#,HDB20,3#,HZB3# | 82/5~93/ | Wheel Hub REAR OUTER |
| 03901 3475 | 90311-45007 | 45 x 62 x 8 | COASTER HDB5#...6F | 75/5~99/7 | Transmission REAR OUTPUT |
| 03901 1669 | 90311-48011 | 48 x 62 x 9 | COASTER HDB5#...TDFI 6F | 99/7~ | Transmission REAR OUTPUT |
| 03901 3721 | 90311-48011 | 48 x 62 x 9 | COASTER BB4#,BZB40,50,HDB5#,HZB4#,5#...5F | 93/1~ | Transmission REAR OUTPUT |
| 03901 6175 | 90311-48011 | 48 x 62 x 9 | COASTER RB2#,BB2#,3#,HB3#,HDB3#,HZB3# | 85/10~93/ | Transmission REAR OUTPUT |
| 03901 5567 | 90311-45001 | 45 x 62 x 9 | COASTER RB1#,2#,BB1#,2#,3#,HB3# | 77/8~85/10 | Transmission REAR OUTPUT |
| 03901 5075 | 9828-43102 | 43 x 63 x 9 | COASTER RX4JFAT# | 96/6~ | Transmission FRONT COVER |
| 03901 1157 | 90311-32020 | 32 x 46 x 6 | COASTER 1HZ,1HDZ HZB3#,HDB20,3# | 90/1~93/ | Engine CAM SHAFT |
| 03901 5885 | 90311-32012 | 32 x 53 x 7 | COASTER BB4# | 93/1~99/7 | Transmission FRONT COVER |
| 03901 5889 | 90029-21010 | 24 x 36 x 7 x 7.5 | COASTER BB4#,5#,HDB5#,HZB4#,5# | 93/1~99/7 | Steering (P/S) STEERING WORM |
| 03901 4453 | 90311-28004 | 28.6 x 43.6.5 x | COASTER HB3# | 82/5~85/10 | Transmission FRONT COVER |
| 03901 7675 | 90311-32106 | 32 x 48 x 8 | COASTER RB1#,2#,BB1#,2#,3# | 77/8~85/10 | Transmission FRONT COVER |
| 03901 1159 | 9828-55110 | 55 x 72 x 9 x 15 | COASTER RX4JFAT#...AGF | 96/6~ | Transmission REAR OUTPUT |
| 03901 3987 | 90310-38033 | 38 x 44 x 18 | COASTER BB4#,5#,BZB40,50,HDB5#, | 93/1~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | | HZB4#,5# | | |
| 03901 5493 | 90311-35023 | 35 x 48 x 6.5 | COASTER BXB40,50,HDB5#,HZB4#,5# | 93/1~ | Transmission FRONT COVER |
| 03901 4649 | 90311-35038 | 35 x 44 x 7 | COASTER RB1#,BB1# | 77/8~82/ | Wheel Hub REAR OUTER |
| 03901 6007 | 9828-01206 | 107 x 123 x 11 | COASTER RX4JFAT# | 96/6~ | Wheel Hub REAR INNER |
| 03901 7047 | 90311-78001 | 78 x 115 x 10 x 19 | COASTER BB58,BZB40,50,HDB5#,HZB4#,5# | 99/7~ | Wheel Hub REAR INNER |
| 03901 2467 | 90311-75003 | 75 x 108 x 10 x 20 | COASTER BB4#,5#,BZB40,50,HDB5#,HZB4#,5# | 93/1~99/7 | Wheel Hub REAR INNER |
| 03901 3735 | 90311-75003 | 75 x 108 x 10 x 20 | COASTER RB2#,BB2#,3#,HB3#,HDB20,3#,HZB3# | 84/8~93/ | Wheel Hub REAR INNER |
| 03901 7021 | 42404-36010 | 75 x 108 x 20 | COASTER RB1#,2#,BB1#,2#,3#,HB3# | 77/8~84/8 | Wheel Hub REAR INNER |
| 03901 7615 | 9828-85106 | 84 x 100 x 10 | COASTER RX4JFAT# | 96/6~ | Wheel Hub FRONT |
| 03901 4783 | 90311-68002 | 68 x 92 x 9.7 | COASTER BZB40,50,HDB5#,HZB4#,5# | 99/7~ | Wheel Hub FRONT |
| 03901 4001 | 90311-68001 | 68 x 90 x 10 | COASTER BB4#,HDB5#,HZB4#,5# | 93/1~99/7 | Wheel Hub FRONT |
| 03901 2115 | 90311-68001 | 68 x 90 x 10 | COASTER RB2#,BB2#,3#,HB3#,HDB20,3#,HZB3# | 82/5~93/ | Wheel Hub FRONT |
| 03901 2981 | 90311-68001 | 68 x 90 x 10 | COASTER RB1#,BB1# | 77/8~82/ | Wheel Hub FRONT |
| 03901 5483 | 9828-48112 | 48 x 109 x 13 | COASTER RX4JFAT# | 96/6~ | Wheel Hub REAR OUTER |
| 03901 7597 | 90311-65003 | 65 x 79 x 7 | COASTER 1HDFTE HDB5# | 99/7~ | Engine TIMING GEAR COVER (NO.1) |
| 03901 3907 | 9828-79103 | 79 x 114 x 17 | COASTER J05C RX4JFAT# | 96/6~ | Engine TIMING GEAR COVER |
| 03901 7173 | 90311-58007 | 58.5 x 75 x 9 x 14.5 | COASTER 1HDFTE HDB5# | 99/7~ | Engine TIMING GEAR COVER (NO.2) |
| 03901 4389 | 90311-58007 | 58.5 x 75 x 9 x 14.5 | COASTER 1HZ,1HDEFT,1HDT HZB4#,5#,HDB5# | 93/1~ | Engine TIMING GEAR COVER (NO.2) |
| 03901 1917 | 90311-32012 | 32 x 53 x 7 | COASTER RB2#,BB2#,3#,HB3#,HDB3#,HZB3# | 85/10~93/ | Transmission FRONT COVER |
| 03901 8029 | S1371-91360 | | COASTER J05C RX4JFAT# | 96/6~ | Engine VALVE STEM SEAL |
| 03901 3631 | 9828-60119 | 60 x 75 x 9 x 15 | COASTER RX4JFAT#...KGB,KGC,KGD,KGE | 96/6~ | Transmission REAR OUTPUT |
| 03901 1277 | 90311-58006 | 58 x 72 x 7 | COASTER 1HZ,1HDEFT,1HDT HZB4#,5#,HDB5# | 93/1~ | Engine TIMING GEAR COVER (NO.1) |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1913 | 90311-58006 | 58 x 72 x 7 | COASTER 1HZ,1HDZ HZB3#,HDB20,3# | 90/1~93/ | Engine TIMING GEAR COVER (NO.1) |
| 03901 3877 | 90311-50013 | 50 x 72 x 9 x 14 | COASTER 15B#,1BZFPE,3B BB4#,5#,BZB40,50 | 93/1~ | Engine TIMING GEAR COVER |
| 03901 4639 | 90311-50013 | 50 x 72 x 9 x 14 | COASTER 3B,14B BB2#,31 | 88/8~93/ | Engine TIMING GEAR COVER |
| 03901 2449 | 90311-50006 | 50 x 72 x 12 | COASTER 2H,12HT HB3# | 82/5~90/1 | Engine TIMING GEAR COVER |
| 03901 5601 | 90311-50006 | 50 x 72 x 12 | COASTER 2B,3B BB1#,2#,3# | 77/8~88/8 | Engine TIMING GEAR COVER |
| 03901 5219 | 90311-45002 | 45 x 68 x 12 | COASTER 1OR,22R RB1#,2# | 77/8~93/ | Engine TIMING GEAR COVER |
| 03901 1487 | 90311-48019 | 48 x 82 x 10.2 x 17.8 | COASTER BB4#,58,BZB40,50,HDB5#, HZB4#,5# | 99/5~ | Final Drive PINION |
| 03901 8125 | 90311-58007 | 58.5 x 75 x 9 x 14.5 | COASTER 1HZ,1HDZ HZB3#,HDB20,3# | 90/1~93/ | Engine TIMING GEAR COVER (NO.2) |
| 03901 3319 | 90311-48135 | 48 x 82 x 12 | COASTER RB1#,BB1# | 77/8~82/ | Final Drive PINION |
| 03901 3597 | 90311-48135 | 48 x 82 x 12 | COASTER BB4#,5#,HDB5#,HZB4#,5# | 93/1~99/5 | Final Drive PINION |
| 03901 2839 | 9828-58109 | 58 x 102 x 8 x 22 | COASTER RX4JFAT# | 96/6~ | Final Drive PINION |
| 03901 1995 | 90311-36104 | 36 x 50 x 7 | COASTER RB1#,2#,BB1#,2#,3# | 77/8~90/1 | Steering (M/S) SECTOR SHAFT |
| 03901 3329 | 90311-22103 | 22 x 36 x 8 | COASTER RB1#,2#,BB1#,2#,3# | 77/8~90/1 | Steering (M/S) WORM GEAR |
| 03901 4497 | 04445-36040 | | COASTER RB2#,BB2#,3#,HB3#,HDB2 0,3#,HZB3# | 85/10~93/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1997 | 04445-36100 | | COASTER BB4#,HDB5#,HZB4#,5# | 93/1~99/7 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7803 | 04445-37040 | | COASTER BB58,BZB40,50,HDB5#,HZ B4#,5# | 99/7~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 4437 | 90029-21010 | 24 x 36 x 7 x 7.5 | COASTER RB2#,BB2#,3#,HB3#,HDB2 0,3#,HZB3# | 82/5~93/ | Steering (P/S) STEERING WORM |
| 03901 3491 | 90311-48135 | 48 x 82 x 12 | COASTER RB2#,BB2#,3#,HB3#,HDB2 0,3#,HZB3# | 82/5~93/ | Final Drive PINION |
| 03901 1269 | 90913-02062 | | COMFORT 1GGPE (EX.) | 95/12~01/ 12 | Engine VALVE STEM SEAL |
| 03901 4565 | 90311-80009 | 80 x 100 x 10 | COMFORT 3YPE YXS1# | 95/12~ | Engine CRANK SHAFT REAR |
| 03901 5991 | 90311-45015 | 45 x 62 x 9 | COMFORT 1GGPE GXS12 | 01/8~ | Engine TIMING GEAR CASE |
| 03901 2695 | 90311-45010 | 45 x 62 x 8.5 | COMFORT 1GGPE GXS10 | 95/12~ | Engine TIMING GEAR CASE |
| 03901 7315 | 90311-42026 | 42 x 60 x 7 | COMFORT 4SFE SXS11 | 96/4~96/9 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1391 | 90311-42035 | 42 x 60 x 7 | COMFORT 3SFE,4SFE SXS1# | 96/9~ | Engine CRANK SHAFT FRONT |
| 03901 8237 | 90311-85007 | 85 x 105 x 10 | COMFORT 2LTE LXS11 | 95/12~99/ | Engine CRANK SHAFT REAR |
| 03901 2253 | 90311-85007 | 85 x 105 x 10 | COMFORT 3SFE,4SFE SXS1# | 95/12~ | Engine CRANK SHAFT REAR |
| 03901 4573 | 90311-75007 | 75 x 100 x 10 | COMFORT 1G#...GXS1# | 95/12~ | Engine CRANK SHAFT REAR |
| 03901 5989 | 90913-02110 | | COMFORT 2LTE | 95/12~97/ 5 | Engine VALVE STEM SEAL |
| 03901 7611 | 90913-02117 | | COMFORT 2LTE | 97/5~99/ | Engine VALVE STEM SEAL |
| 03901 6487 | 90913-02094 | | COMFORT 3YPE | 95/12~ | Engine VALVE STEM SEAL |
| 03901 6339 | 90913-02079 | | COMFORT 3SFE,4SFE (IN.) | 96/4~ | Engine VALVE STEM SEAL |
| 03901 6219 | 90913-02062 | | COMFORT 3SFE,4SFE (EX.) | 96/4~ | Engine VALVE STEM SEAL |
| 03901 7291 | 90913-02123 | | COMFORT 1GGPE (IN.) | 01/12~ | Engine VALVE STEM SEAL |
| 03901 7995 | 90311-42026 | 42 x 60 x 7 | COMFORT 2LTE LXS11 | 95/12~99/ | Engine TIMING GEAR CASE |
| 03901 6531 | 90913-02122 | | COMFORT 1GGPE (EX.) | 01/10~ | Engine VALVE STEM SEAL |
| 03901 4831 | 04332-30030 | Kit | COMFORT GXS1#,LXS11,SXS1#,YXS1 # | 95/12~ | Transmission (A/T) REAR EXTENTON |
| 03901 4843 | 90913-02106 | | COMFORT 1GGPE (IN.) | 95/12~01/ 12 | Engine VALVE STEM SEAL |
| 03901 2511 | 90311-30014 | 30 x 45 x 8 | COMFORT LXS11,SXS1#,YXS1# | 95/12~ | Transmission (M/T) FRONT COVER |
| 03901 7845 | 04445-43010 | | COMFORT GXS1#,LXS11,SXS1#,YXS1 # | 95/12~ | Steering (P/S) R & P GASKET KIT |
| 03901 7811 | 90311-52059 | 52 x 65 x 9 | COMFORT GXS1#,LXS11,SXS1#,YXS1 # | 95/12~ | Wheel Hub REAR |
| 03901 6809 | 15165-70040 | 18 x 30 x 7 | COMFORT 1GGPE GXS10 | 95/12~01/ 2 | Engine OIL PUMP |
| 03901 2615 | 90311-38032 | 38 x 58 x 11 | COMFORT LXS11,SXS1#,YXS1# | 95/12~ | Transmission (M/T) REAR EXTENTION |
| 03901 6873 | 90311-38020 | 38 x 55 x 8.5 | COMFORT GXS10,LXS11,SXS11,YXS1 # | 95/12~96/ 10 | Transmission (A/T) FRONT OIL PUMP |
| 03901 6349 | 90311-38020 | 38 x 55 x 8.5 | COMFORT SXS11 | 96/10~00/ 5 | Transmission (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2241 | 90311-38058 | 38 x 55 x 8.5 | COMFORT GXS10,LXS11,YXS1# | 96/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7631 | 90311-38064 | 38 x 55 x 8.7 | COMFORT GXS12,SXS1# | 00/5~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1975 | 90311-38067 | 38 x 50 x 8 | COMFORT 3SFE,4SFE SXS1# | 97/8~ | Engine CAM SHAFT |
| 03901 6423 | 15165-70010 | 18 x 30 x 7 | COMFORT 4SFE SXS11 | 96/4~01/8 | Engine OIL PUMP |
| 03901 3623 | 90311-48013 | 48 x 73 x 7 | COMFORT GXS1#,LXS11,SXS1#,YXS1# | 95/12~ | Wheel Hub FRONT |
| 03901 8249 | 90311-38047 | 38 x 74 x 11 x 18 | COMFORT GXS1#,LXS11,SXS1#,YXS1# | 95/12~ | Final Drive PINION |
| 03901 5647 | 90311-35040 | 35 x 49 x 6 | COMFORT 1GGPE GXS10 | 95/12~ | Engine CAM SHAFT |
| 03901 1425 | 90311-38036 | 38 x 50 x 8 | COMFORT 4SFE SXS11 | 96/4~97/8 | Engine CAM SHAFT |
| 03901 1561 | 90311-32020 | 32 x 46 x 6 | COMFORT 2LTE LXS11 | 95/12~99/ | Engine CAM SHAFT |
| 03901 4797 | 90310-25027 | 25 x 38 x 7 | COMFORT GXS1#,LXS11,SXS1#,YXS1# | 95/12~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4623 | 90311-19002 | 19 x 32 x 7 x 8 | COMFORT GXS1#,LXS11,SXS1#,YXS1# | 95/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2367 | 90311-34016 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE8#,9#,EE80,9# | 83/5~92/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4025 | 90311-25011 | 25 x 37 x 8 | COROLLA (FWD) AE8#,9#,EE80,9# | 83/5~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 2093 | 90311-52059 | 52 x 65 x 9 | COROLLA (FWD) AE109,CE105,109 (4WD) | 91/9~ | Wheel Hub REAR |
| 03901 4067 | 90311-56007 | 56 x 75 x 6.5 x 11 | COROLLA (FWD) AE104,114,CE104,114 (4WD) | 91/9~ | Wheel Hub REAR INNER |
| 03901 1579 | 90311-48001 | 48 x 62 x 9 | COROLLA (FWD) EE102,103,104,106,107,108 | 91/9~ | Wheel Hub REAR |
| 03901 2411 | 90311-48001 | 48 x 62 x 9 | COROLLA (FWD) CE102,106,107,108 | 91/9~ | Wheel Hub REAR |
| 03901 7947 | 90311-52010 | 52 x 65 x 7.5 x 12 | COROLLA (FWD) AE104,114,CE104,114 (4WD) | 91/9~ | Wheel Hub REAR OUTER |
| 03901 1583 | 90311-42055 | 42 x 55 x 7 | COROLLA (FWD) AE95,CE95 (4WD) | 87/10~91/ | Wheel Hub REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5311 | 90311-25011 | 25 x 37 x 8 | COROLLA (FWD) AE10#,11#,EE10#,111 2WD | 91/6~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 6613 | 90311-25011 | 25 x 37 x 8 | COROLLA (FWD) NZE12#,ZZE12# | 00/8~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 7781 | 90311-30006 | 30 x 42 x 7 | COROLLA (FWD) AE104,109,114 (4WD) | 91/6~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 4491 | 90311-34016 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE10#,11#,EE10#,111 2WD | 91/6~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 5491 | 90311-48001 | 48 x 62 x 9 | COROLLA (FWD) CE96,97,EE96,97,98 | 87/8~91/ | Wheel Hub REAR |
| 03901 3709 | 90311-35033 | 35 x 55 x 9 x 15.5 | COROLLA (FWD) CE80,9#,10#,11#...2WD | 83/5~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4425 | 90311-34016 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) NZE12# | 00/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 3261 | 90311-30006 | 30 x 42 x 7 | COROLLA (FWD) CE80,9#,10#,11#,12# | 83/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1863 | 90311-40025 | 40 x 64 x 8 x 14.5 | COROLLA (FWD) CE121 | 00/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1539 | 04422-12020 | Kit | COROLLA (FWD) AE9#,CE9#,EE9#...WITHOUT ABS | 87/5~91/ | Wheel Hub FRONT |
| 03901 6755 | 04422-12020 | Kit | COROLLA (FWD) AE10#,CE10#,EE10#...WITHOUT ABS | 91/6~95/5 | Wheel Hub FRONT |
| 03901 2389 | 04422-12091 | Kit | COROLLA (FWD) AE10#,CE10#,EE10#...WITHOUT ABS | 95/5~ | Wheel Hub FRONT |
| 03901 3739 | 04422-12091 | Kit | COROLLA (FWD) AE11#,CE11#,EE111 WITHOUT ABS | 95/5~ | Wheel Hub FRONT |
| 03901 6537 | 04422-12030 | Kit | COROLLA (FWD) AE9#...WITH ABS | 89/5~92/ | Wheel Hub FRONT |
| 03901 8145 | 04422-12030 | Kit | COROLLA (FWD) AE10#,CE100,104,EE101 WITH ABS | 91/6~ | Wheel Hub FRONT |
| 03901 2489 | 04422-20080 | Kit | COROLLA (FWD) AE101GT,GTZ ABS,SSS | 92/4~95/ | Wheel Hub FRONT |
| 03901 6133 | 04422-12030 | Kit | COROLLA (FWD) AE11#,CE11#,EE111 WITH ABS | 95/5~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5167 | 90311-41004 | 41 x 55 x 7 x 12 | COROLLA (FWD) AE91 (ABS),AE92 | 87/5~91/ | Wheel Hub REAR |
| 03901 2349 | 04422-12111 | Kit | COROLLA (FWD) AE111BZV,BZG (SSS) | 95/5~ | Wheel Hub FRONT |
| 03901 5445 | 04422-12121 | Kit | COROLLA (FWD) AE111BZG (ABS & SSS),AE111BZV (ABS) | 95/5~ | Wheel Hub FRONT |
| 03901 7101 | 90311-41003 | 41 x 55 x 6 | COROLLA (FWD) AE80,81,CE80,EE80 | 83/5~87/ | Wheel Hub REAR |
| 03901 4993 | 90311-41003 | 41 x 55 x 6 | COROLLA (FWD) AE82 (EXC. GT,FXT) | 83/5~87/ | Wheel Hub REAR |
| 03901 2247 | 90311-41003 | 41 x 55 x 6 | COROLLA (FWD) AE91 WITHOUT ABS,CE90,EE9# | 87/5~91/ | Wheel Hub REAR |
| 03901 5107 | 90311-41004 | 41 x 55 x 7 x 12 | COROLLA (FWD) AE82 (GT,FXT) | 84/10~87/ | Wheel Hub REAR |
| 03901 7081 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) EE80,90,96,98,10#,111 3FC | 83/5~98/3 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3737 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) EE80,90,96,98,10#,111 3FC | 83/5~98/2 | Mission & Differential (A/T) DIFFERENTIAL SIDE |
| 03901 2843 | 90311-35033 | 35 x 55 x 9 x 15.5 | COROLLA (FWD) CE80,9#,10#,11#...2WD | 83/5~ | Mission & Differential (M/T) DUFFERENTIAL SIDE |
| 03901 4095 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE81,82,91,92,100,101,111 4FC | 83/5~98/2 | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3083 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE101.111 4FC | 98/2~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 7057 | 90311-34016 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE100,110 4FC | 98/2~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 6251 | 90311-35033 | 35 x 55 x 9 x 15.5 | COROLLA (FWD) CE80,9#,10#,11#...2WD 4FC | 84/1~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3523 | 90311-35033 | 35 x 55 x 9 x 15.5 | COROLLA (FWD) ZZE123 4FC | 00/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1077 | 90311-35046 | 35 x 57 x 9 x 15.5 | COROLLA (FWD) CE121,ZZE122,124 | 00/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 4251 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE80,81,91,100 3FC | 83/5~98/2 | Mission & Differential (A/T) DIFFERENTIAL SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1503 | 90311-49002 | 50 x 64 x 8 | COROLLA (FWD) ZZE124 | 00/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.1) |
| 03901 7953 | 90311-34022 | 34 x 56 x 9 x 15 | COROLLA (FWD) EE10#,111 3FC | 98/2~ | Mission & Differential (A/T) DIFFERENTIAL SIDE |
| 03901 5305 | 90311-35033 | 35 x 55 x 9 x 15.5 | COROLLA (FWD) ZZE123 4FC | 00/8~ | Mission & Differential (A/T) DIFFERENTIAL SIDE |
| 03901 7373 | 90311-38020 | 38 x 55 x 8.5 | COROLLA (FWD) AE8#,9#,10#,11#,CE8#,9#,10#,110 | 83/5~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 6953 | 90311-38020 | 38 x 55 x 8.5 | COROLLA (FWD) EE80,9#,10#,111 | 83/5~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4125 | 90311-15001 | 15 x 25 x 7 | COROLLA (FWD) AE8#,9#,CE8#,9#,EE80,9# | 83/5~89/5 | Steering (M/S) RACK HOUSING |
| 03901 4415 | 9031--15002 | 15 x 25 x 7 | COROLLA (FWD) AE9#,100,110,CE9#,10#,110, EE9#,10#,111 | 89/5 | Steering (M/S) RACK HOUSING |
| 03901 5683 | 04445-12020 | | COROLLA (FWD) EE80,CE80,AE8#...TOYOTA GEAR BOX | 83/5~87/ | Steering (P/S) R & P GASKET KIT |
| 03901 5315 | 90311-38075 | 38 x 55 x 7.8 | COROLLA (FWD) NZE120 4FC | 00/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4017 | 90311-19007 | 19 x 38 x 7 | COROLLA (FWD) EE111,CE11#,AE11#(TOYOTA G/B) | 95/5~00/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3455 | 90311-34017 | 34 x 63 x 9 x 16 | COROLLA (FWD) AE8#,9#,EE80,9# | 83/5~92/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 6151 | 90311-34017 | 34 x 63 x 9 x 16 | COROLLA (FWD) AE10#,11#,EE10#,111 2WD | 91/6~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4147 | 90311-34017 | 34 x 63 x 9 x 16 | COROLLA (FWD) NZE120,121 | 00/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 7241 | 90311-44003 | 44 x 80 x 9 x 15.5 | COROLLA (FWD) AE10#,114,CE10#,11#...4WD | 91/9~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4523 | 90311-35044 | 35 x 63 x 10 x 22 | COROLLA (FWD) ZZE122,123 | 00/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 6559 | 90311-50024 | 50 x 80 x 11 x 17.5 | COROLLA (FWD) CE121 | 00/8~ | Mission & Differential (M/T) TRANSMISSION CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5643 | 90311-49002 | 50 x 64 x 8 | COROLLA (FWD) NZE124 | 00/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 6069 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) AE80,91,100 3FC | 83/5~98/3 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 4375 | 90311-35051 | 35 x 54 x 9 x 21.5 | COROLLA (FWD) ZZE122,123 | 00/8~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 3989 | 90311-34016 | 34 x 54 x 9 x 15.5 | COROLLA (FWD) EE10#,111 3FC | 98/3~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5907 | 90311-34013 | 34 x 63 x 9 x 15 | COROLLA (FWD) AE81,91,92,100,101,111 4FC | 83/5~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3417 | 90311-44003 | 44 x 80 x 9 x 15.5 | COROLLA (FWD) AE104,109,114 (4WD) 4FC | 91/9~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1255 | 90311-35020 | 35 x 63 x 9 x 15.5 | COROLLA (FWD) CE80,9#,10#,11#...2WD 4FC | 84/1~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 6879 | 90311-34017 | 34 x 63 x 9 x 16 | COROLLA (FWD) NZE120 4FC | 00/8~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1821 | 90311-34022 | 34 x 56 x 9 x 15 | COROLLA (FWD) NZE121,124 4FC | 00/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.1) |
| 03901 6849 | 90311-35033 | 35 x 55 x 9 x 15.5 | COROLLA (FWD) CE121,ZZE122 4FC | 00/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.1) |
| 03901 3833 | 04422-20010 | Kit | COROLLA (FWD) AE8#,CE80,EE80 | 83/5~87 | Wheel Hub FRONT |
| 03901 2239 | 90311-70007 | 70 x 92 x 8.5 | COROLLA (FWD) 4A,4A AE9#,10#,11# | 91/6~ | Engine CRANK SHAFT REAR |
| 03901 5881 | 90311-38059 | 38 x 50 x 8 | COROLLA (FWD) 1ZZ,2ZZ ZZE12# | 00/8~ | Engine TIMING GEAR COVER |
| 03901 2393 | 90311-75016 | 75 x 107 x 8 | COROLLA (FWD) 1NZ,2NZ NZE12# | 00/8~ | Engine CRANK SHAFT REAR |
| 03901 4059 | 90311-90005 | 90 x 110 x 8.5 x 10 | COROLLA (FWD) 1C,2C,3C CE9#,10#,11#,121 | 90/2~ | Engine CRANK SHAFT REAR |
| 03901 1007 | 90311-90003 | 90 x 110 x 8.5 x 10 | COROLLA (FWD) 1C,2C CE80,9# | 83/5~90/2 | Engine CRANK SHAFT REAR |
| 03901 2413 | 90311-80012 | 80 x 100 x 8.5 | COROLLA (FWD) 3E,5E EE98,103,104,107,108 | 91/8 | Engine CRANK SHAFT REAR |
| 03901 4981 | 90311-80003 | 80 x 100-8.5 x | COROLLA (FWD) 3E EE98 | 87/8~91/8 | Engine CRANK SHAFT REAR |
| 03901 5953 | 90311-85007 | 85 x 105 x 10 | COROLLA (FWD) 2ZZ ZZE123 | 00/8~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7339 | 90311-75004 | 75 x 100 x 8.5 | COROLLA (FWD) 2E EE80,9# | 85/5~90/10 | Engine CRANK SHAFT REAR |
| 03901 3253 | 90913-02038 | | COROLLA (FWD) 2A-LU,3A-LU,4A-LU | 83/5~87/4 | Engine VALVE STEM SEAL |
| 03901 4769 | 90311-70004 | 70 x 92 x 8.5 | COROLLA (FWD) 2A,3A,4A,5A AE8#,9# | 83/5~91/6 | Engine CRANK SHAFT REAR |
| 03901 6807 | 90311-35040 | 35 x 49 x 6 | COROLLA (FWD) 4E,5E EE10#,111 | 96/4~ | Engine CRANK SHAFT FRONT |
| 03901 4917 | 90311-42026 | 42 x 60 x 7 | COROLLA (FWD) 1C,2C,3C CE9#,10#,11#,121 | 90/10~ | Engine CRANK SHAFT FRONT |
| 03901 1033 | 90311-42015 | 42 x 60 x 6 | COROLLA (FWD) 1C,2C CE9# | 85/5~90/10 | Engine CRANK SHAFT FRONT |
| 03901 6841 | 90311-42003 | 42 x 60 x 7 | COROLLA (FWD) 1C CE80,9# | 83/5~85/5 | Engine CRANK SHAFT FRONT |
| 03901 6887 | 90311-19007 | 19 x 38 x 7 | COROLLA (FWD) EE80,CE80,AE8# (TOYOTA G/B) | 83/5~87/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3383 | 90311-75009 | 75 x 100 x 8.5 | COROLLA (FWD) 2E,4E EE9#,101,102,106,111 | 90/10~ | Engine CRANK SHAFT REAR |
| 03901 5469 | 90913-02110 | | COROLLA (FWD) 2C | 95/11~97/4 | Engine VALVE STEM SEAL |
| 03901 4249 | 04445-12030 | | COROLLA (FWD) AE81,82 KOYO GEAR BOX | 83/5~87/ | Steering (P/S) R & P GASKET KIT |
| 03901 2459 | 90913-02115 | | COROLLA (FWD) 2ZZGE (IN.) | 00/8~ | Engine VALVE STEM SEAL |
| 03901 7945 | 90913-02114 | | COROLLA (FWD) 2ZZGE (EX.) | 00/8~ | Engine VALVE STEM SEAL |
| 03901 7085 | 90913-02101 | | COROLLA (FWD) 1ZZFE (IN.) | 00/8~ | Engine VALVE STEM SEAL |
| 03901 3581 | 90913-02111 | | COROLLA (FWD) 1ZZFE (EX.) | 00/8~ | Engine VALVE STEM SEAL |
| 03901 5163 | 90913-02093 | | COROLLA (FWD) 1NZFE,2NZFE (IN. & EX.) | 00/8~ | Engine VALVE STEM SEAL |
| 03901 7273 | 90311-76001 | 76 x 94 x 8.5 | COROLLA (FWD) 1ZZ ZZE122,124 | 00/8~ | Engine CRANK SHAFT REAR |
| 03901 4703 | 90913-02117 | | COROLLA (FWD) 2C,3C | 97/4~ | Engine VALVE STEM SEAL |
| 03901 8267 | 90311-25021 | 25.5 x 37.5 x 6 | COROLLA (FWD) 1NZ,2NZ NZE12# | 00/8~ | Engine OIL PUMP |
| 03901 4569 | 90913-02094 | | COROLLA (FWD) 1C,2C | 90/1~95/11 | Engine VALVE STEM SEAL |
| 03901 7161 | 90913-02110 | | COROLLA (FWD) 1C,2C | 83/5~90/1 | Engine VALVE STEM SEAL |
| 03901 7709 | 90913-02062 | | COROLLA (FWD) 2E,3E,4E,5E | 83/5~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7563 | 90913-02079 | | COROLLA (FWD) 4AFE,5AFE IN. | 90/10~ | Engine VALVE STEM SEAL |
| 03901 7311 | 90913-02062 | | COROLLA (FWD) 4AFE,5AFE EX. | 90/10~ | Engine VALVE STEM SEAL |
| 03901 7509 | 90913-02062 | | COROLLA (FWD) 4AFE,5AFE IN. & EX. | 87/5~90/10 | Engine VALVE STEM SEAL |
| 03901 2453 | 90913-02093 | | COROLLA (FWD) 4AGE (IN. & EX.) | 91/6~00/ | Engine VALVE STEM SEAL |
| 03901 5515 | 04445-12170 | | COROLLA (FWD) CE121,NZE124,ZZE12# | 00/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 6799 | 90311-35013 | 35 x 49 x 6 | COROLLA (FWD) 2E,3E4E EE9#,10# | 87/5~96/4 | Engine CRANK SHAFT FRONT |
| 03901 1061 | 90310-23005 | 23 x 34 x 6.5 | COROLLA (FWD) EE10#,CE10#,AE10#(TOYOTA G/B) | 91/6~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5479 | 90310-23005 | 23 x 34 x 6.5 | COROLLA (FWD) EE80,CE80,AE8# (TOYOTA G/B) | 83/5~87/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2727 | 90311-19010 | 19 x 32 x 6 | COROLLA (FWD) EE111,CE11#,AE11#(KOYO G/B) | 95/5~00/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5547 | 90311-19010 | 19 x 32 x 6 | COROLLA (FWD) EE10#,CE10#,AE10#(KOYO G/B) | 91/6~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1373 | 90311-19010 | 19 x 32 x 6 | COROLLA (FWD) EE9#,CE9#,AE9#(KOYO G/B) | 87/5~91/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6545 | 90310-23004 | 23 x 35 x 6.5 | COROLLA (FWD) AE8#(KOYO G/B) | 83/5~87/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3975 | 90311-19007 | 19 x 38 x 7 | COROLLA (FWD) EE10#,CE10#,AE10#(TOYOTA G/B) | 91/6~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5585 | 90311-26003 | 26 x 38 x 6.5 | COROLLA (FWD) EE9#,CE9#,AE9#(KOYO G/B) | 87/5~91/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2555 | 04445-12160 | | COROLLA (FWD) AE11#...KOYO GEAR BOX | 95/5~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 7221 | 04445-12160 | | COROLLA (FWD) AE10#...KOYO GEAR BOX | 95/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 2161 | 04445-12150 | | COROLLA (FWD) AE11#...TOYOTA GEAR BOX,CE 11#,EE11# | 95/5~00/ | Steering (P/S) R & P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5519 | 04445-12150 | | COROLLA (FWD) AE10#...TOYOTA GEAR BOX,CE10#,EE10# | 95/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 1837 | 04445-12110 | | COROLLA (FWD) AE10#...TOYOTA GEAR BOX,CE10#,EE10# | 91/6~95/5 | Steering (P/S) R & P GASKET KIT |
| 03901 3091 | 04445-12100 | | COROLLA (FWD) AE10#...KOYO GEAR BOX | 91/6~95/5 | Steering (P/S) R & P GASKET KIT |
| 03901 2523 | 90311-19010 | 19 x 32 x 6 | COROLLA (FWD) AE8#(KOYO G/B) | 83/5~87/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1301 | 90311-38025 | 38 x 50 x 6 | COROLLA (FWD) 1C,2C CE80,9# | 85/1~90/10 | Engine CAM SHAFT |
| 03901 8163 | 90029-21022 | 22 x 34 x 6.5 | COROLLA (FWD) 2C,3C CE9#,10#,11# | 89/5~ | Engine OIL PUMP |
| 03901 4481 | 90029-21020 | 20 x 32 x 5 | COROLLA (FWD) 1C,2C CE80,9# | 85/5~89/5 | Engine OIL PUMP |
| 03901 1099 | 15165-64010 | 20 x 32 x 7 | COROLLA (FWD) 1C CE80 | 83/5~85/5 | Engine OIL PUMP |
| 03901 3347 | 90029-21020 | 20 x 32 x 5 | COROLLA (FWD) 2E,3E,4E,5E EE9#,10#,111 | 87/5~ | Engine OIL PUMP |
| 03901 6247 | 90029-21020 | 20 x 32 x 5 | COROLLA (FWD) 2E EE80 | 86/4~87/ | Engine OIL PUMP |
| 03901 2611 | 90029-21005 | 18 x 30 x 5 | COROLLA (FWD) 2E EE80 | 85/5~86/4 | Engine OIL PUMP |
| 03901 2771 | 90310-23005 | 23 x 34 x 6.5 | COROLLA (FWD) EE111,CE11#,AE11#(TOYOTA G/B) | 95/5~00/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5451 | 90311-38044 | 38 x 50 x 6 | COROLLA (FWD) 1C,2C CE9#,10#,11#,121 | 90/1 | Engine CAM SHAFT |
| 03901 2755 | 04445-12051 | | COROLLA (FWD) EE9#,CE9#,AE9#...KOYO GEAR BOX | 87/5~91/ | Steering (P/S) R & P GASKET KIT |
| 03901 6363 | 90311-38036 | 38 x 50 x 8 | COROLLA (FWD) 1C CE80 | 83/5~85/1 | Engine CAM SHAFT |
| 03901 6653 | 90311-40015 | 40 x 54.5 x 7 | COROLLA (FWD) 4AGE AE101,111(INTAKE) | 91/6~00/ | Engine CAM SHAFT |
| 03901 3497 | 90311-35013 | 35 x 49 x 6 | COROLLA (FWD) 2E,3E,4E,5E EE8#,9#,10#11# | 83/5~ | Engine CAM SHAFT |
| 03901 1697 | 90311-35013 | 35 x 49 x 6 | COROLLA (FWD) 4AGE AE101,111(EXHAUST) | 91/6~00/ | Engine CAM SHAFT |
| 03901 2681 | 90311-35013 | 35 x 49 x 6 | COROLLA (FWD) 2A,3A,4A,5A AE8#,9#,10#,11# | 83/5~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4409 | 90311-26003 | 26 x 38 x 6.5 | COROLLA (FWD) AE11#(KOYO G/B) | 95/5~00/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5193 | 90311-26003 | 26 x 38 x 6.5 | COROLLA (FWD) AE10#(KOYO G/B) | 91/6~95/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4865 | 90311-32020 | 32 x 46 x 6 | COROLLA (FWD) 4A,5A AE9#,10#,11# | 87/5~ | Engine OIL PUMP |
| 03901 1143 | 90310-34003 | 34 x 46 x 8 | COROLLA (RWD) TE71 | 81/8~87/ | Steering (M/S) SECTOR SHAFT |
| 03901 3103 | 90311-42083 | 42 x 65 x 12 | COROLLA (RWD) KE7# | 79/3~81/8 | Transmission (A/T) FRONT OIL PUMP |
| 03901 1177 | 90311-17092 | 17.4 x 30 x 7 | COROLLA (RWD) KE72,74,TE7# | 81/8~87/ | Steering (M/S) WORM GEAR |
| 03901 6919 | 90310-28027 | 28 x 40 x 8 | COROLLA (RWD) KE72,74,TE74,CE7# | 81/8~87/ | Steering (M/S) SECTOR SHAFT |
| 03901 1045 | 90310-28027 | 28 x 40 x 8 | COROLLA (RWD) KE71,AE70,TE7# | 79/3~81/8 | Steering (M/S) SECTOR SHAFT |
| 03901 1511 | 90311-38015 | 38 x 65 x 12 x 19 | COROLLA (RWD) AE70.8#,TE7#,CE7# | 79/3~87/ | Final Drive PINION |
| 03901 3579 | 90311-38015 | 38 x 65 x 12 x 19 | COROLLA (RWD) KE7# (EXC.KE70) | 79/3~87/ | Final Drive PINION |
| 03901 7621 | 90311-35131 | 35 x 55 x 11 | COROLLA (RWD) KE70 | 79/3~83/ | Final Drive PINION |
| 03901 2409 | 90311-11128 | 11 x 22 x 7 | COROLLA (RWD) AE70.8#,TE7#,CE7# | 79/8~87/ | Transmission (A/T) LEVER SHAFT |
| 03901 3657 | 90311-11128 | 11 x 22 x 7 | COROLLA (RWD) KE7# | 81/8~87/ | Transmission (A/T) LEVER SHAFT |
| 03901 3461 | 04332-30020 | Kit | COROLLA (RWD) AE70.8#,TE7#,CE7# | 79/8~87/ | Transmission (A/T) EXTENTION HOUSING |
| 03901 4681 | 04332-30020 | Kit | COROLLA (RWD) KE7# | 81/8~87/ | Transmission (A/T) EXTENTION HOUSING |
| 03901 2217 | 90311-32074 | 32 x 52 x 11 | COROLLA (RWD) KE7# | 79/3~81/8 | Transmission (A/T) EXTENTION HOUSING |
| 03901 1175 | 90311-19001 | 19 x 32 x 8 | COROLLA (RWD) CE7# | 82/2~87/ | Steering (M/S) WORM GEAR |
| 03901 2181 | 90311-38020 | 38 x 55 x 8.5 | COROLLA (RWD) KE7# | 81/8~87/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6109 | 90311-17092 | 17.4 x 30 x 7 | COROLLA (RWD) KE71,AE70,TE7# | 79/3~81/8 | Steering (M/S) WORM GEAR |
| 03901 6015 | 90311-38043 | 38 x 58 x 11 | COROLLA (RWD) CE7# | 82/2~87/ | Transmission (M/T) REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7095 | 90311-32074 | 32 x 52 x 11 | COROLLA (RWD) KE7#,AE70,8#,TE7# | 79/3~87/ | Transmission (M/T) REAR |
| 03901 7275 | 90311-30115 | 30 x 45 x 8 | COROLLA (RWD) CE7# | 82/2~87/ | Transmission (M/T) FRONT COVER |
| 03901 4553 | 90311-25003 | 25 x 38 x 7 | COROLLA (RWD) KE7#,AE70,8#,TE7# | 79/3~87/ | Transmission (M/T) FRONT COVER |
| 03901 5217 | 90311-52059 | 52 x 65 x 9 | COROLLA (RWD) AE86 | 83/5~87/ | Wheel Hub REAR |
| 03901 4411 | 90311-52059 | 52 x 65 x 9 | COROLLA (RWD) TE70,71 | 79/3~83/ | Wheel Hub REAR |
| 03901 2337 | 90311-42055 | 42 x 55 x 7 | COROLLA (RWD) AE85 | 83/5~87/ | Wheel Hub REAR |
| 03901 1855 | 90311-42055 | 42 x 55 x 7 | COROLLA (RWD) KE7#,AE70,TE73,74,CE7# | 79/3~87/ | Wheel Hub REAR |
| 03901 1809 | 90311-41123 | 41 x 53 x 7 | COROLLA (RWD) AE85,86 | 83/5~87/ | Wheel Hub FRONT |
| 03901 6941 | 90311-41123 | 41 x 53 x 7 | COROLLA (RWD) KE7#,AE70,TE7#,CE7# | 79/3~87/ | Wheel Hub FRONT |
| 03901 7979 | 90913-02110 | | COROLLA (RWD) 1C | 82/2~87/ | Engine VALVE STEM SEAL |
| 03901 6775 | 90311-38020 | 38 x 55 x 8.5 | COROLLA (RWD) AE70.8#,TE7#,CE7# | 79/8~87/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4447 | 90311-42003 | 42 x 60 x 7 | COROLLA (RWD) 1C CE7# | 82/2~85/5 | Engine CRANK SHAFT FRONT |
| 03901 3807 | 90913-02056 | | COROLLA (RWD) 4A | 83/5~87/ | Engine VALVE STEM SEAL |
| 03901 3997 | 90913-02038 | | COROLLA (RWD) 3A | 79/3~87/ | Engine VALVE STEM SEAL |
| 03901 5561 | 90913-02058 | | COROLLA (RWD) 12T,13T (EX.) | 81/1~83/ | Engine VALVE STEM SEAL |
| 03901 4191 | 90913-02024 | | COROLLA (RWD) 12T,13T (IN.) | 81/1~83/ | Engine VALVE STEM SEAL |
| 03901 5259 | 90913-02024 | | COROLLA (RWD) 2T,12T,13T (IN. & EX.) | 79/8~81/1 | Engine VALVE STEM SEAL |
| 03901 5727 | 90913-02056 | | COROLLA (RWD) 4K,5K | 81/1~87/ | Engine VALVE STEM SEAL |
| 03901 5737 | 90913-02024 | | COROLLA (RWD) 4K | 79/8~81/1 | Engine VALVE STEM SEAL |
| 03901 3025 | 90311-90003 | 90 x 110 x 8.5 x 10 | COROLLA (RWD) 1C CE7# | 82/2~87/ | Engine CRANK SHAFT REAR |
| 03901 2149 | 90311-75114 | 75 x 100 x 13 | COROLLA (RWD) 2T,12T,13T TE7# | 79/8~83/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7775 | 90311-70004 | 70 x 92 x 8.5 | COROLLA (RWD) 3A,4A AE70,85,86 | 79/3~87/ | Engine CRANK SHAFT REAR |
| 03901 7561 | 90311-42015 | 42 x 60 x 6 | COROLLA (RWD) 1C CE7# | 85/5~87/ | Engine CRANK SHAFT FRONT |
| 03901 7961 | 90311-15001 | 15 x 25 x 7 | COROLLA (RWD) KE70 | 79/3~81/8 | Steering (M/S) RACK HOUSING |
| 03901 2913 | 90029-21020 | 20 x 32 x 5 | COROLLA (RWD) 1C CE7# | 85/5~87/ | Engine OIL PUMP |
| 03901 3675 | 90311-19002 | 19 x 32 x 7 x 8 | COROLLA (RWD) AE70.85,86,TE70 | 81/8~87/ | Steering (P/S) ADJUSTER PLUG |
| 03901 5431 | 90311-15001 | 15 x 25 x 7 | COROLLA (RWD) KE70,73,AE70,85,86 | 81/8~87/ | Steering (M/S) RACK HOUSING |
| 03901 4043 | 04445-12010 | | COROLLA (RWD) AE70 | 81/8~83/ | Steering (P/S) R & P GASKET KIT |
| 03901 6743 | 90311-70004 | 70 x 92 x 8.5 | COROLLA (RWD) 4K,5K KE7# | 79/8~87/ | Engine CRANK SHAFT REAR |
| 03901 2967 | 04445-12010 | | COROLLA (RWD) AE85,86 | 83/5~85/ | Steering (P/S) R & P GASKET KIT |
| 03901 6231 | 15165-64010 | 20 x 32 x 7 | COROLLA (RWD) 1C CE7# | 82/2~85/5 | Engine OIL PUMP |
| 03901 2125 | 90311-38013 | 38.5 x 58 x 11 | COROLLA (RWD) 4K KE7# | 79/8~82/4 | Engine TIMING GEAR COVER |
| 03901 6995 | 90311-38022 | 38.5 x 58 x 8.5 | COROLLA (RWD) 4K,5K KE7# | 82/5~87/ | Engine TIMING GEAR COVER |
| 03901 1507 | 90311-38013 | 38.5 x 58 x 11 | COROLLA (RWD) 2T,12T,13T TE7# | 79/8~83/ | Engine TIMING GEAR COVER |
| 03901 7835 | 90311-35013 | 35 x 49 x 6 | COROLLA (RWD) 3A,4A AE70,85,86 | 79/3~87/ | Engine CAM SHAFT |
| 03901 7935 | 90311-38036 | 38 x 50 x 8 | COROLLA (RWD) 1C CE7# | 82/2~85/1 | Engine CAM SHAFT |
| 03901 2531 | 90311-38025 | 38 x 50 x 6 | COROLLA (RWD) 1C CE7# | 85/1~87/ | Engine CAM SHAFT |
| 03901 4403 | 90311-32020 | 32 x 46 x 6 | COROLLA (RWD) 3A,4A AE70,85,86 | 79/3~87/ | Engine OIL PUMP |
| 03901 7767 | 04422-12030 | Kit | COROLLA SPACIO AE11# | 97/1~ | Wheel Hub FRONT |
| 03901 6505 | 90311-34013 | 34 x 63 x 9 x 15 | COROLLA SPACIO AE111 | 97/1~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1643 | 90311-52010 | 52 x 65 x 7.5 x 12 | COROLLA SPACIO AE115 (4WD) | 97/7~ | Wheel Hub REAR OUTER |
| 03901 6111 | 90311-44003 | 44 x 80 x 9 x 15.5 | COROLLA SPACIO AE115 (4WD) | 97/1~ | Mission & Differential (M/T) TRANSAXLE CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8035 | 90311-34012 | 34 x 54 x 9 x 15.5 | COROLLA SPACIO AE111 | 97/1~ | Mission & Differential (M/T) TRANSAXLE HOUSING |
| 03901 5475 | 90311-38020 | 38 x 55 x 8.5 | COROLLA SPACIO AE11# | 97/1~ | Mission & Differential (M/T) FRONT OIL PUMP |
| 03901 1419 | 04445-12150 | | COROLLA SPACIO AE11# | 97/1~ | Steering (P/S) R & P GASKET KIT |
| 03901 1101 | 90310-23005 | 23 x 34 x 6.5 | COROLLA SPACIO AE11# | 97/1~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3611 | 90311-35013 | 35 x 49 x 6 | COROLLA SPACIO 4AFE,7AFE AE11# | 97/1~ | Engine CAM SHAFT |
| 03901 4837 | 90311-32020 | 32 x 46 x 6 | COROLLA SPACIO 4AFE,7AFE AE11# | 97/1~ | Engine OIL PUMP |
| 03901 1849 | 90311-70007 | 70 x 92 x 8.5 | COROLLA SPACIO 4AFE,7AFE AE11# | 97/1~ | Engine CRANK SHAFT REAR |
| 03901 7997 | 90913-02062 | | COROLLA SPACIO 4AFE,7AFE | 97/1~ | Engine VALVE STEM SEAL |
| 03901 5257 | 90913-02079 | | COROLLA SPACIO 4AFE,7AFE | 97/1~ | Engine VALVE STEM SEAL |
| 03901 5673 | 90311-19007 | 19 x 38 x 7 | COROLLA SPACIO AE11# | 97/1~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2221 | 90311-56007 | 56-75 x 6.5 x 11 | COROLLA SPACIO AE115 (4WD) | 97/7~ | Wheel Hub REAR INNER |
| 03901 2553 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203 | 87/8~98/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1181 | 90311-42018 | 42 x 55 x 6 | CORONA (COUPE / EXIV) ST16#,18# | 87/8~93/ | Wheel Hub REAR |
| 03901 3451 | 90311-56015 | 56 x 75 x 7 x 12 | CORONA (COUPE / EXIV) ST205 (4WD) | 94/5~98/ | Wheel Hub REAR INNER |
| 03901 5473 | 90311-52005 | 52 x 75 x 7.5 x 12 | CORONA (COUPE / EXIV) ST205 (4WD) | 94/5~98/ | Wheel Hub REAR OUTER |
| 03901 2703 | 90311-30006 | 30 x 42 x 7 | CORONA (COUPE / EXIV) ST16#,18#,20# | 87/8~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1593 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203 | 87/8~98/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 7045 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203 | 87/8~98/ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 7409 | 90311-50010 | 50 x 80 x 16.5 x 23 | CORONA (COUPE / EXIV) ST205 (4WD) | 94/5~98/ | Mission & Differential (M/T) TRANSMISSION CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5595 | 04422-20100 | Kit | CORONA (COUPE / EXIV) ST202 TRG ABS & SSS,ST205 ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 1459 | 90311-40004 | 40 x 56 x 9 x 15.5 | CORONA (COUPE / EXIV) ST202 TRG | 93/9~98/ | Mission & Differential (M/T) TRANSAXLE CASE COVER |
| 03901 8121 | 04422-20080 | Kit | CORONA (COUPE / EXIV) ST180,182 ABS | 89/9~93/ | Wheel Hub FRONT (LH) |
| 03901 1963 | 90311-44003 | 44 x 80 x 9 x 15.5 | CORONA (COUPE / EXIV) ST205 (4WD) | 94/5~98/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 8061 | 90311-44003 | 44 x 80 x 9 x 15.5 | CORONA (COUPE / EXIV) ST202 TRG | 93/9~98/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1205 | 04422-20090 | Kit | CORONA (COUPE / EXIV) ST202 TRG SSS,ST205 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 5853 | 04422-20080 | Kit | CORONA (COUPE / EXIV) ST201,203 | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 4661 | 04422-20080 | Kit | CORONA (COUPE / EXIV) ST181,183 | 89/9~93/ | Wheel Hub FRONT (LH) |
| 03901 2067 | 90311-38020 | 38 x 55 x 8.5 | CORONA (COUPE / EXIV) ST16#,18#,20# | 87/8~98/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2701 | 04422-20010 | Kit | CORONA (COUPE / EXIV) ST200,202 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 5527 | 04422-20010 | Kit | CORONA (COUPE / EXIV) ST180,182 WITHOUT ABS | 89/9~93/ | Wheel Hub FRONT (LH) |
| 03901 3379 | 04422-20010 | Kit | CORONA (COUPE / EXIV) ST16# | 87/8~89/ | Wheel Hub FRONT (LH) |
| 03901 3531 | 04422-20100 | Kit | CORONA (COUPE / EXIV) ST202 TRG ABS & SSS,ST205 ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 7999 | 04422-20090 | Kit | CORONA (COUPE / EXIV) ST202 TRG SSS,ST205 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 6583 | 04422-20080 | Kit | CORONA (COUPE / EXIV) ST200,201,202,203 ABS | 93/9~98/ | Wheel Hub FRONT (RH) |
| 03901 2001 | 04422-20080 | Kit | CORONA (COUPE / EXIV) ST18#... ABS | 89/9~93/ | Wheel Hub FRONT (RH) |
| 03901 7367 | 04422-20010 | Kit | CORONA (COUPE / EXIV) ST200,201,202,203 WITHOUT ABS | 93/9~98/ | Wheel Hub FRONT (RH) |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2211 | 04422-20010 | Kit | CORONA (COUPE / EXIV) ST18#...WITHOUT ABS | 89/9~93/ | Wheel Hub FRONT (RH) |
| 03901 2235 | 04422-20010 | Kit | CORONA (COUPE / EXIV) ST16# | 87/8~89/ | Wheel Hub FRONT (RH) |
| 03901 7353 | 04422-20080 | Kit | CORONA (COUPE / EXIV) ST200,202 ABS | 93/9~98/ | Wheel Hub FRONT (LH) |
| 03901 1227 | 15165-70010 | 18 x 30 x 7 | CORONA (COUPE / EXIV) 1S#,3S#,4S#...ST16#,18#,20# | 87/8~98/ | Engine OIL PUMP |
| 03901 7153 | 90913-02062 | | CORONA (COUPE / EXIV) 3S#,4S# (EX.) ST18#,20# | 90/3~98/ | Engine VALVE STEM SEAL |
| 03901 1807 | 90913-02062 | | CORONA (COUPE / EXIV) 3S#,4S#...ST162,163,18# | 87/8~90/3 | Engine VALVE STEM SEAL |
| 03901 3861 | 90913-02094 | | CORONA (COUPE / EXIV) 1SILU ST160 | 87/8~88/5 | Engine VALVE STEM SEAL |
| 03901 7289 | 90311-89001 | 89 x 105 x 10 | CORONA (COUPE / EXIV) 3SGE ST18#,20# | 89/9~98/ | Engine CRANK SHAFT REAR |
| 03901 4947 | 90311-85007 | 85 x 105 x 10 | CORONA (COUPE / EXIV) 3SFE,4SFE ST18#,20# | 90/10~98/ | Engine CRANK SHAFT REAR |
| 03901 7131 | 90311-85004 | 85 x 105 x 10 | CORONA (COUPE / EXIV) 3SFE,4S#...ST18# | 89/9~90/10 | Engine CRANK SHAFT REAR |
| 03901 6509 | 90311-85004 | 85 x 105 x 10 | CORONA (COUPE / EXIV) 1S#,3S#,4S#...ST16# | 87/8~89/ | Engine CRANK SHAFT REAR |
| 03901 1517 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203 | 87/8~98/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3559 | 90311-42003 | 42 x 60 x 7 | CORONA (COUPE / EXIV) 1S#,3S#,4S#...ST16# | 87/8~89/ | Engine CRANK SHAFT FRONT |
| 03901 5773 | 04445-20040 | | CORONA (COUPE / EXIV) ST162 GT | 87/8~89/3 | Steering (P/S) R & P GASKET KIT |
| 03901 4833 | 90311-35013 | 35 x 49 x 6 | CORONA (COUPE / EXIV) 3SGE ST162,18#,20# | 87/8~98/ | Engine CAM SHAFT |
| 03901 2335 | 90311-38036 | 38 x 50 x 8 | CORONA (COUPE / EXIV) 1S#,3SFE,4S#...ST16#,18#,20# | 87/8~98/ | Engine CAM SHAFT |
| 03901 8007 | 90310-31001 | 31 x 44 x 6.5 | CORONA (COUPE / EXIV) ST162,163,180,182,200,202,205 | 89/3~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1347 | 04445-20060 | | CORONA (COUPE / EXIV) ST16#,,,EX,VX,GX | 87/8~89/3 | Steering (P/S) R & P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4221 | 90311-42026 | 42 x 60 x 7 | CORONA (COUPE / EXIV) 3S#,4S#...ST18#,20# | 89/9~98/ | Engine CRANK SHAFT FRONT |
| 03901 4421 | 04445-20040 | | CORONA (COUPE / EXIV) ST180 | 89/9~91/ | Steering (P/S) R & P GASKET KIT |
| 03901 4701 | 90310-31001 | 31 x 44 x 6.5 | CORONA (COUPE / EXIV) ST162 GT | 87/8~89/3 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7229 | 04445-20210 | | CORONA (COUPE / EXIV) ST180 | 91/8~93 | Steering (P/S) R & P GASKET KIT |
| 03901 6155 | 04445-20110 | | CORONA (COUPE / EXIV) ST182 | 89/9~93/ | Steering (P/S) R & P GASKET KIT |
| 03901 2873 | 90913-02079 | | CORONA (COUPE / EXIV) 3S#,4S# (IN.) ST18#,20# | 90/3~98/ | Engine VALVE STEM SEAL |
| 03901 7507 | 04445-20103 | | CORONA (COUPE / EXIV) ST201,203 | 93/9~98/ | Steering (P/S) R & P GASKET KIT |
| 03901 1667 | 04445-20180 | | CORONA (COUPE / EXIV) ST200,202,205 | 93/9~98/ | Steering (P/S) R & P GASKET KIT |
| 03901 1689 | 90311-19002 | 19 x 32 x 7 x 8 | CORONA (COUPE / EXIV) ST16#,18#,20# | 87/8~96/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5397 | 90310-28003 | 28 x 41 x 6.5 | CORONA (COUPE / EXIV) ST16#...EX,VX,GX | 87/8~89/3 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7401 | 90310-28003 | 28 x 41 x 6.5 | CORONA (COUPE / EXIV) ST181,183,201,203 | 89/9~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7035 | 04445-20103 | | CORONA (COUPE / EXIV) ST181,183 | 89/9~93/ | Steering (P/S) R & P GASKET KIT |
| 03901 6611 | 04445-20040 | | CORONA (COUPE / EXIV) ST162,163 | 89/3~89/ | Steering (P/S) R & P GASKET KIT |
| 03901 5155 | 90311-38020 | 38 x 55 x 8.5 | CORONA (RWD) KT147,TT14#,AT140,ST140 | 82/1~87/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4859 | 90913-02058 | | CORONA (RWD) 3TEU (EX.) TT142 | 82/1~83/ | Engine VALVE STEM SEAL |
| 03901 1823 | 90913-02060 | | CORONA (RWD) STGTEU TT142 | 82/10~85/ | Engine VALVE STEM SEAL |
| 03901 7855 | 90913-02056 | | CORONA (RWD) 1SU ST140 | 82/1~87/ | Engine VALVE STEM SEAL |
| 03901 7029 | 90913-02056 | | CORONA (RWD) 5KJ KT147 | 83/10~87/ | Engine VALVE STEM SEAL |
| 03901 2589 | 90913-02038 | | CORONA (RWD) 3AU AT140 | 82/1~87/ | Engine VALVE STEM SEAL |
| 03901 1549 | 90913-02062 | | CORONA (RWD) 4AGEU AT141 | 83/10~85/ | Engine VALVE STEM SEAL |
| 03901 5759 | 90913-02110 | | CORONA (RWD) 1C,2C CT14# | 82/1~91/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6619 | 90913-02024 | | CORONA (RWD) 3TEU (IN.) TT142 | 82/1~83/ | Engine VALVE STEM SEAL |
| 03901 6071 | 90913-02094 | | CORONA (RWD) 2YPU YT140 | 82/9~ | Engine VALVE STEM SEAL |
| 03901 7235 | 90311-42026 | 42 x 60 x 7 | CORONA (RWD) 2YPU YT140 | 86/5~ | Engine TIMING GEAR COVER |
| 03901 3183 | 90311-42026 | 42 x 60 x 7 | CORONA (RWD) 2C CT141 | 90/10~91/ | Engine CRANK SHAFT FRONT |
| 03901 3603 | 90311-34001 | 34 x 44 x 8 | CORONA (RWD) YT140 | 86/12~ | Steering (M/S) SECTOR SHAFT |
| 03901 6063 | 90311-19001 | 19 x 32 x 8 | CORONA (RWD) KT147,TT147,CT140(STD),141,147 | 82/1~91/ | Steering (M/S) WORM GEAR |
| 03901 6451 | 90311-19001 | 19 x 32 x 8 | CORONA (RWD) YT140 | 82/9~ | Steering (M/S) WORM GEAR |
| 03901 4263 | 90311-15001 | 15 x 25 x 7 | CORONA (RWD) TT142,AT14#,ST140,CT140(GX) | 82/1~87/ | Steering (M/S) RACK HOUSING |
| 03901 2075 | 90311-19002 | 19 x 32 x 7 x 8 | CORONA (RWD) TT142,AT14#,ST140,CT140,RT141 | 82/1~87/ | Steering (P/S) ADJUSTER PLUG |
| 03901 6791 | 90311-19002 | 19 x 32 x 7 x 8 | CORONA (RWD) YT140 | 82/9~ | Steering (P/S) ADJUSTER PLUG |
| 03901 1087 | 90312-30001 | 30 x 38 x 5 | CORONA (RWD) YT140 | 82/9~ | Steering (P/S) GEAR HOUSING |
| 03901 2119 | 90310-25004 | 25 x 38 x 7 x 8 | CORONA (RWD) AT140,ST140 GX | 86/2~87/ | Steering (P/S) BEARING GUIDE NUT |
| 03901 2897 | 90311-38013 | 38.5 x 58 x 11 | CORONA (RWD) 3T#...TT142 | 82/1~85/ | Engine TIMING GEAR COVER |
| 03901 1413 | 90311-38022 | 38.5 x 58 x 8.5 | CORONA (RWD) 5KJ KT147 | 83/10~87/ | Engine TIMING GEAR COVER |
| 03901 2779 | 90310-28027 | 28 x 40 x 8 | CORONA (RWD) KT147,CT147 | 86/12~87/12 | Steering (M/S) SECTOR SHAFT |
| 03901 3111 | 90311-42003 | 42 x 60 x 7 | CORONA (RWD) 2YPU YT140 | 82/9~86/5 | Engine TIMING GEAR COVER |
| 03901 3939 | 90310-28027 | 28 x 40 x 8 | CORONA (RWD) KT147,TT147,CT147,YT140 | 82/1~86/12 | Steering (M/S) SECTOR SHAFT |
| 03901 1705 | 90311-35013 | 35 x 49 x 6 | CORONA (RWD) 3AU,4AGEU AT14# | 82/1~87/ | Engine CAM SHAFT |
| 03901 4401 | 90311-38036 | 38 x 50 x 8 | CORONA (RWD) 1SU ST140 | 82/1~87/ | Engine CAM SHAFT |
| 03901 5625 | 90311-38036 | 38 x 50 x 8 | CORONA (RWD) 1C CT14# | 82/1~85/1 | Engine CAM SHAFT |
| 03901 3749 | 90311-38025 | 38 x 50 x 6 | CORONA (RWD) 1C,2C CT14# | 85/1~91/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3499 | 90311-32020 | 32 x 46 x 6 | CORONA (RWD) 3AU,4AGEU AT14# | 82/1~87/ | Engine OIL PUMP |
| 03901 5609 | 15165-70010 | 18 x 30 x 7 | CORONA (RWD) 1SU ST140 | 82/1~87/ | Engine OIL PUMP |
| 03901 4601 | 15165-64010 | 20 x 32 x 7 | CORONA (RWD) 1C CT14# | 82/1~85/5 | Engine OIL PUMP |
| 03901 1901 | 90029-21020 | 20 x 32 x 5 | CORONA (RWD) 1C,2C CT14# | 85/5~89/5 | Engine OIL PUMP |
| 03901 6915 | 90029-21022 | 22 x 34 x 6.5 | CORONA (RWD) 2C CT141 | 89/5~91/ | Engine OIL PUMP |
| 03901 1041 | 90311-42003 | 42 x 60 x 7 | CORONA (RWD) 1SU ST140 | 82/1~87/ | Engine CRANK SHAFT FRONT |
| 03901 6351 | 90311-42003 | 42 x 60 x 7 | CORONA (RWD) 1C CT14# | 82/1~85/5 | Engine CRANK SHAFT FRONT |
| 03901 8245 | 90311-42015 | 42 x 60 x 6 | CORONA (RWD) 1C,2C CT14# | 85/5~90/10 | Engine CRANK SHAFT FRONT |
| 03901 2887 | 90311-45002 | 45 x 68 x 12 | CORONA (RWD) 18RGEU RT141 | 82/1~82/10 | Engine TIMING GEAR COVER |
| 03901 6723 | 90311-30115 | 30 x 45 x 8 | CORONA (RWD) YT140 | 82/9~91/10 | Transmission (M/T) FRONT COVER |
| 03901 7295 | 04332-30020 | Kit | CORONA (RWD) KT147,TT14#,AT140,ST140, YT140 | 82/1~87/ | Transmission (A/T) REAR EXTENTION |
| 03901 2439 | 90072-72006 | | CORONA (RWD) 18RGEU RT141 | 82/1~82/10 | Engine VALVE STEM SEAL |
| 03901 2375 | 90311-48122 | 48 x 62 x 7 | CORONA (RWD) TT142,RT141,YT140 | 82/1~83/5 | Wheel Hub FRONT |
| 03901 5745 | 90311-48122 | 48 x 62 x 7 | CORONA (RWD) CT140 STD | 82/1~83/5 | Wheel Hub FRONT |
| 03901 6435 | 90311-48001 | 48 x 62 x 9 | CORONA (RWD) TT142,AT141,CT141 | 83/5~91/ | Wheel Hub FRONT |
| 03901 6343 | 90311-48001 | 48 x 62 x 9 | CORONA (RWD) YT140 | 83/5~ | Wheel Hub FRONT |
| 03901 5487 | 90311-48001 | 48 x 62 x 9 | CORONA (RWD) CT140 STD | 83/5~86/ | Wheel Hub FRONT |
| 03901 6533 | 90311-41123 | 41 x 53 x 7 | CORONA (RWD) KT147,TT147,AT140,ST140, CT147 | 82/1~87/ | Wheel Hub FRONT |
| 03901 2165 | 90311-41123 | 41 x 53 x 7 | CORONA (RWD) CT140 GX,EXS | 82/1~83/ | Wheel Hub FRONT |
| 03901 7751 | 90311-52059 | 52 x 65 x 9 | CORONA (RWD) KT147,TT147,AT140,ST140, CT14# | 82/1~91/ | Wheel Hub REAR |
| 03901 4007 | 90311-38009 | 38 x 58 x 8 | CORONA (RWD) TT142,AT141,RT141 | 82/1~85/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5943 | 90311-34001 | 34 x 44 x 8 | CORONA (RWD) CT140(STD),CT141 | 82/1~91/ | Steering (M/S) SECTOR SHAFT |
| 03901 6223 | 90311-30115 | 30 x 45 x 8 | CORONA (RWD) TT142(GTT),RT141,CT14# | 82/1~91/ | Transmission (M/T) FRONT COVER |
| 03901 3707 | 90311-48122 | 48 x 62 x 7 | CORONA (RWD) TT142,AT141,RT141 | 82/1~85/ | Wheel Hub REAR OUTER |
| 03901 3019 | 90311-30014 | 30 x 45 x 8 | CORONA (RWD) YT140 | 91/10~ | Transmission (M/T) FRONT COVER |
| 03901 6321 | 90311-32074 | 32 x 52 x 11 | CORONA (RWD) KT147,TT142(SX),147,AT14 #,ST140 | 82/1~87/ | Transmission (M/T) REAR |
| 03901 4915 | 90311-38043 | 38 x 58 x 11 | CORONA (RWD) TT142(GTT),RT141,CT14#, YT140 | 82/1~97/ | Transmission (M/T) REAR |
| 03901 7129 | 90311-38043 | 38 x 58 x 11 | CORONA (RWD) YT140 | 82/9~91/1 0 | Transmission (M/T) REAR |
| 03901 5689 | 90311-38032 | 38 x 58 x 11 | CORONA (RWD) YT140 | 91/10~ | Transmission (M/T) REAR |
| 03901 3677 | 90311-38020 | 38 x 55 x 8.5 | CORONA (RWD) YT140 | 82/9~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2747 | 90311-38015 | 38 x 65 x 12 x 19 | CORONA (RWD) AT140,ST140,CT140,141 | 82/1`91/ | Final Drive PINION |
| 03901 6933 | 90311-38133 | 38 x 74 x 11 | CORONA (RWD) KT147,TT147,CT147 | 82/1~87/ | Final Drive PINION |
| 03901 5583 | 90311-38133 | 38 x 74 x 11 | CORONA (RWD) YT140 | 82/9~ | Final Drive PINION |
| 03901 7841 | 90311-38133 | 38 x 74 x 11 | CORONA (RWD) TT142,RT141 GTT | 82/1~85/8 | Final Drive PINION |
| 03901 1093 | 90311-38019 | 38 x 65 x 10 x 17 | CORONA (RWD) TT142,AT141 SX | 82/1~85/8 | Final Drive PINION |
| 03901 6445 | 90311-38011 | 38 x 63 x 10 x 17 | CORONA (RWD) TT142,AT141,RT141 | 82/1~85/8 | Final Drive DIFF. SIDE |
| 03901 6375 | 90311-25003 | 25 x 38 x 7 | CORONA (RWD) KT147,TT142(SX),147,AT14 #,ST140 | 82/1~87/ | Transmission (M/T) FRONT COVER |
| 03901 4657 | 90311-75114 | 75 x 100 x 13 | CORONA (RWD) 3T#...TT142 | 82/1~85/ | Engine CRANK SHAFT FRONT |
| 03901 7791 | 90311-52059 | 52 x 65 x 9 | CORONA (RWD) YT140 | 82/9~ | Wheel Hub REAR |
| 03901 6729 | 90311-90005 | 90 x 110 x 8.5 x 10 | CORONA (RWD) 2C CT141 | 90/2~91/1 1 | Engine CRANK SHAFT FRONT |
| 03901 3617 | 90311-90003 | 90 x 110 x 8.5 x 10 | CORONA (RWD) 1C,2C CT14# | 82/1~90/2 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6021 | 90311-85004 | 85 x 105 x 10 | CORONA (RWD) 1SU ST140 | 82/1~87/ | Engine CRANK SHAFT FRONT |
| 03901 5667 | 90311-70004 | 70 x 92 x 8.5 | CORONA (RWD) 5KJ,3AU,4AGEU KT147.AT14# | 82/1~87/ | Engine CRANK SHAFT FRONT |
| 03901 6497 | 90311-80012 | 80 x 100 x 8.5 | CORONA (RWD) 2YPU YT140 | 86/5~ | Engine CRANK SHAFT FRONT |
| 03901 1523 | 90311-80003 | 80 x 100 x 8.5 | CORONA (RWD) 2YPU YT140 | 82/9~86/5 | Engine CRANK SHAFT FRONT |
| 03901 6471 | 90311-80001 | 80 x 100 x 12 | CORONA (RWD) 18RGEU RT141 | 82/1~82/10 | Engine CRANK SHAFT FRONT |
| 03901 4885 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ST16#,17#,210 | 85/8~ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 2825 | 90311-34012 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ET176 | 87/12~92/ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 7755 | 90311-34012 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT150..3FC | 84/5~88/ | Mission & Differential (A/T) DIFF.SIDE |
| 03901 3303 | 90311-49002 | 50 x 64 x 8 | CORONA (SEDAN / 5 DOOR) CT216,ST215 | 97/12~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3413 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ST150,190,CT150,17#,190,210,211 | 83/1~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 6473 | 90311-34012 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT150(4FC),170,190,21# | 83/10~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 7773 | 90311-44003 | 44 x 80 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT175 | 88/8~92/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2713 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ST16#,17# | 85/8~92/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3313 | 90311-35020 | 35 x 63 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) CT150,17#,190,21# | 83/10~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1955 | 90311-44003 | 44 x 80 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ST195,215 | 92/2~97/12 | Mission & Differential (A/T) DIFF.SIDE |
| 03901 5723 | 90311-34013 | 34 x 63 x 9 x 15 | CORONA (SEDAN / 5 DOOR) AT170,190,21# | 87/12~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5659 | 90913-02117 | | CORONA (SEDAN / 5 DOOR) 2CT,3CTE CT21# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 7477 | 90311-34013 | 34 x 63 x 9 x 15 | CORONA (SEDAN / 5 DOOR) AT150 4FC | 83/10~87/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2289 | 90311-35020 | 35 x 63 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ST150,190,21# | 83/1~ | Mission & Differential (A/T) TRANSAXLE CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5969 | 90311-38020 | 38 x 55 x 8.5 | CORONA (SEDAN / 5 DOOR) AT150,170,190,21#,CT150,17#,190,21# | 83/10~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4789 | 90311-38020 | 38 x 55 x 8.5 | CORONA (SEDAN / 5 DOOR) ST150,16#,17#,19#,215 | 83/1~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 8123 | 90311-15001 | 15 x 25 x 7 | CORONA (SEDAN / 5 DOOR) AT150,170,CT176,ET176 | 83/10~92/ | Steering (M/S) RACK HOUSING |
| 03901 1907 | 90311-34012 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ET176 | 87/12~92/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 7017 | 04445-20030 | | CORONA (SEDAN / 5 DOOR) AT15#,160,ST150,162,CT150 TOYODAKOKI | 83/1~87/ | Steering (P/S) R & P GASKET KIT |
| 03901 5729 | 90311-49002 | 50 x 64 x 8 | CORONA (SEDAN / 5 DOOR) ST215 | 97/12~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 6481 | 90913-02110 | | CORONA (SEDAN / 5 DOOR) 2C CT21# | 96/1~97/4 | Engine VALVE STEM SEAL |
| 03901 6059 | 90913-02094 | | CORONA (SEDAN / 5 DOOR) 2C CT17#,19# | 90/11~96/ | Engine VALVE STEM SEAL |
| 03901 3747 | 90913-02110 | | CORONA (SEDAN / 5 DOOR) 2C CT150,17# | 87/12~90/11 | Engine VALVE STEM SEAL |
| 03901 6981 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 3E ET176 | 87/12~92/ | Engine VALVE STEM SEAL |
| 03901 7499 | 90913-02079 | | CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE (IN.) AT17#,19#,21# | 90/10~ | Engine VALVE STEM SEAL |
| 03901 1399 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE (EX.) AT17#,19#,21# | 90/10~ | Engine VALVE STEM SEAL |
| 03901 7429 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 4A#,5A#...AT17# | 87/12~90/10 | Engine VALVE STEM SEAL |
| 03901 2753 | 04445-12020 | | CORONA (SEDAN / 5 DOOR) AT150,ST150,CT150 TOYOTA G/B | 83/1~87/ | Steering (P/S) R & P GASKET KIT |
| 03901 2011 | 90311-52005 | 52 x 75 x 7.5 x 12 | CORONA (SEDAN / 5 DOOR) AT175,CT195,ST195 (4WD) | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 5615 | 04445-20070 | | CORONA (SEDAN / 5 DOOR) CT17#,ET176,ST170 | 87/12~92/ | Steering (P/S) R & P GASKET KIT |
| 03901 6759 | 04422-20010 | Kit | CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150 | 83/1~87/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6039 | 04422-20010 | Kit | CORONA (SEDAN / 5 DOOR) AT17#,ST17#,CT17#,ET176 | 87/12~92/ | Wheel Hub FRONT |
| 03901 5341 | 04422-20080 | Kit | CORONA (SEDAN / 5 DOOR) AT170,ST170,171 ABS | 90/5~92/ | Wheel Hub FRONT |
| 03901 1353 | 04422-20080 | Kit | CORONA (SEDAN / 5 DOOR) AT190,CT19#,ST19#...ABS | 92/2~95/ | Wheel Hub FRONT |
| 03901 3095 | 04422-20080 | Kit | CORONA (SEDAN / 5 DOOR) AT21#,CT21#,ST21# | 96/1~ | Wheel Hub FRONT |
| 03901 2983 | 04422-12060 | Kit | CORONA (SEDAN / 5 DOOR) AT190,CT19#,ST19#...WITH OUT ABS | 92/2~95/ | Wheel Hub FRONT |
| 03901 3299 | 90311-42018 | 42 x 55 x 6 | CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150 | 83/1~87/ | Wheel Hub REAR |
| 03901 6377 | 90311-42018 | 42 x 55 x 6 | CORONA (SEDAN / 5 DOOR) AT170,ST17#,CT170 | 87/12~92/ | Wheel Hub REAR |
| 03901 8079 | 90311-48001 | 48 x 62 x 9 | CORONA (SEDAN / 5 DOOR) CT176,ET176 | 87/12~92/ | Wheel Hub REAR |
| 03901 6115 | 90311-56007 | 56 x 75 x 6.5 x 11 | CORONA (SEDAN / 5 DOOR) AT175,CT195,ST195 (4WD) | 88/8~95/ | Wheel Hub REAR INNER |
| 03901 3217 | 90311-34017 | 34 x 63 x 9 x 16 | CORONA (SEDAN / 5 DOOR) AT21# | 96/1~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 6635 | 90311-56015 | 56 x 75 x 7 x 12 | CORONA (SEDAN / 5 DOOR) CT215,216,ST215 (4WD) | 97/7~ | Wheel Hub REAR INNER |
| 03901 4645 | 90311-34012 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT150 3FC | 83/10~87/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3971 | 90311-25011 | 25 x 37 x 8 | CORONA (SEDAN / 5 DOOR) AT150,170,190,ET176 | 83/10~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1495 | 90311-30006 | 30 x 42 x 7 | CORONA (SEDAN / 5 DOOR) AT175,ST150,16#,17#,190,CT150,17#,190 | 83/1~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 6737 | 90311-30006 | 30 x 42 x 7 | CORONA (SEDAN / 5 DOOR) CT210,211,215,ST215 | 96/1~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 7033 | 90311-34016 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT150,170,190,ET176 | 83/10~95/ | Mission & Differential (M/T) TRANSAXLE CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5275 | 90311-34016 | 34 x 54 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT21# | 96/1~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2009 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) ST150,16#,17#,190,CT150,17#,190 | 83/1~95/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 7305 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) CT210,211 | 96/1~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1707 | 90311-25011 | 25 x 37 x 8 | CORONA (SEDAN / 5 DOOR) AT21# | 96/1~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 4171 | 90311-34017 | 34 x 63 x 9 x 16 | CORONA (SEDAN / 5 DOOR) AT150,170,190,ET176 | 83/10~95/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4329 | 90913-02038 | | CORONA (SEDAN / 5 DOOR) 3ALU | 83/10~87/ | Engine VALVE STEM SEAL |
| 03901 6319 | 90311-44003 | 44 x 80 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) AT175,CT195,215,ST195,215 (4WD) | 88/8~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4635 | 90311-35033 | 35 x 55 x 9 x 15.5 | CORONA (SEDAN / 5 DOOR) CT210,211,ST215 | 96/1~ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 6381 | 90311-56007 | 56 x 75 x 6.5 x 11 | CORONA (SEDAN / 5 DOOR) CT215,ST215 (4WD) | 96/1~97/ | Wheel Hub REAR INNER |
| 03901 5529 | 90311-38025 | 38 x 50 x 6 | CORONA (SEDAN / 5 DOOR) 2C CT150,17# | 85/1~90/10 | Engine CAM SHAFT |
| 03901 1431 | 90310-25004 | 25 x 38 x 7 x 8 | CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150 TOYODAKOKI G/B | 83/1~87/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2815 | 90310-25004 | 25 x 38 x 7 x 8 | CORONA (SEDAN / 5 DOOR) AT17#,ST17#,CT17#,ET176 | 87/12~92/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6237 | 90310-25004 | 25 x 38 x 7 x 8 | CORONA (SEDAN / 5 DOOR) CT19#,ST195 | 92/2~95/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5763 | 90310-25004 | 25 x 38 x 7 x 8 | CORONA (SEDAN / 5 DOOR) AT211,CT21#,ST21#...TOYODAKOKI G/B | 96/1~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1345 | 90310-28003 | 28 x 41 x 6.5 | CORONA (SEDAN / 5 DOOR) AT19#,ST190 | 92/8~96/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6595 | 90311-38036 | 38 x 50 x 8 | CORONA (SEDAN / 5 DOOR) 1S#,3SFE,4S#...ST150,160,17#,19#,21# | 83/1~97/8 | Engine CAM SHAFT |
| 03901 7355 | 90311-38036 | 38 x 50 x 8 | CORONA (SEDAN / 5 DOOR) 2C CT150 | 83/1~85/1 | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4729 | 90311-19002 | 19 x 32 x 7 x 8 | CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150 TOYODAKOKI G/B | 83/1~87/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2537 | 90311-38044 | 38 x 50 x 6 | CORONA (SEDAN / 5 DOOR) 2C CT17#,19# | 90/10~96/ | Engine CAM SHAFT |
| 03901 4687 | 90311-38044 | 38 x 50 x 6 | CORONA (SEDAN / 5 DOOR) 2CT,3CTE CT21# | 96/1~ | Engine CAM SHAFT |
| 03901 4723 | 90311-35013 | 35 x 49 x 6 | CORONA (SEDAN / 5 DOOR) 3A#,4A#,5A#...AT150,17#,190 | 83/10~96/ | Engine CAM SHAFT |
| 03901 3321 | 90311-35013 | 35 x 49 x 6 | CORONA (SEDAN / 5 DOOR) 4AFE,7AFE AT21# | 96/1~ | Engine CAM SHAFT |
| 03901 6239 | 90311-35013 | 35 x 49 x 6 | CORONA (SEDAN / 5 DOOR) 3E ET176 | 87/12~92/ | Engine CAM SHAFT |
| 03901 5065 | 90311-35013 | 35 x 49 x 6 | CORONA (SEDAN / 5 DOOR) 3SGE ST162,171 | 85/8~92/ | Engine CAM SHAFT |
| 03901 5501 | 90310-28003 | 28 x 41 x 6.5 | CORONA (SEDAN / 5 DOOR) AT21#,ST210 TOYOTA G/B | 96/1~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5439 | 04445-20161 | | CORONA (SEDAN / 5 DOOR) CT216,ST215 | 96/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 2301 | 04445-20070 | | CORONA (SEDAN / 5 DOOR) AT170 | 87/12~92/ | Steering (P/S) R & P GASKET KIT |
| 03901 5005 | 04445-20070 | | CORONA (SEDAN / 5 DOOR) AT175 | 89/11~92/ | Steering (P/S) R & P GASKET KIT |
| 03901 3901 | 90311-52005 | 52 x 75 x 7.5 x 12 | CORONA (SEDAN / 5 DOOR) CT215,216,ST215 (4WD) | 96/1~ | Wheel Hub REAR OUTER |
| 03901 8259 | 90913-02111 | | CORONA (SEDAN / 5 DOOR) 3SFSE (EX.) ST210 | 96/12~ | Engine VALVE STEM SEAL |
| 03901 1171 | 04445-20080 | | CORONA (SEDAN / 5 DOOR) AT175 | 87/12~89/11 | Steering (P/S) R & P GASKET KIT |
| 03901 5809 | 04445-20080 | | CORONA (SEDAN / 5 DOOR) ST171 | 87/12~92/ | Steering (P/S) R & P GASKET KIT |
| 03901 2273 | 90310-23005 | 23 x 34 x 6.5 | CORONA (SEDAN / 5 DOOR) AT150,ST150,CT150 TOYOTA G/B | 83/1~87/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7891 | 04445-20161 | | CORONA (SEDAN / 5 DOOR) AT211,ST210 TOYODAKOKI G/B | 96/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 1191 | 90311-19002 | 19 x 32 x 7 x 8 | CORONA (SEDAN / 5 DOOR) AT17#,19#,21#,CT17#,19#,21# | 87/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7417 | 04445-20210 | | CORONA (SEDAN / 5 DOOR) AT210 | 96/1~97/12 | Steering (P/S) R & P GASKET KIT |
| 03901 8153 | 04445-20170 | | CORONA (SEDAN / 5 DOOR) AT210 | 97/12 | Steering (P/S) R & P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8091 | 04445-20170 | | CORONA (SEDAN / 5 DOOR) AT211,ST210 TOYOTA G/B | 96/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 1921 | 04445-20240 | | CORONA (SEDAN / 5 DOOR) CT210,211 | 96/1~ | Steering (P/S) R & P GASKET KIT |
| 03901 3953 | 90311-19007 | 19 x 38 x 7 | CORONA (SEDAN / 5 DOOR) AT150,ST150,CT150 TOYOTA G/B | 83/1~87/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5061 | 90311-19002 | 19 x 32 x 7 x 8 | CORONA (SEDAN / 5 DOOR) ST17#,19#,215 | 87/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2717 | 04445-20161 | | CORONA (SEDAN / 5 DOOR) AT211,CT215,ST21# | 96/1~96/4 | Steering (P/S) R & P GASKET KIT |
| 03901 1957 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17# | 87/12~90/3 | Engine VALVE STEM SEAL |
| 03901 3869 | 90311-70004 | 70 x 92 x 8.5 | CORONA (SEDAN / 5 DOOR) 3A#,4A#,5A#...AT150,160,17# | 83/10~91/6 | Engine CRANK SHAFT REAR |
| 03901 3271 | 90311-70007 | 70 x 92 x 8.5 | CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE AT17#,19#,21# | 91/6~ | Engine CRANK SHAFT REAR |
| 03901 3655 | 90311-85004 | 85 x 105 x 10 | CORONA (SEDAN / 5 DOOR) 1S#,3S#,4S#...ST150,16#,17# | 83/1~90/10 | Engine CRANK SHAFT REAR |
| 03901 7287 | 90311-90003 | 90 x 110 x 8.5 x 10 | CORONA (SEDAN / 5 DOOR) 2C CT150,17# | 83/10~92/ | Engine CRANK SHAFT REAR |
| 03901 2281 | 90311-90008 | 90 x 110 x 9.5 x 11.5 | CORONA (SEDAN / 5 DOOR) 2CT,3CTE CT21# | 96/1~ | Engine CRANK SHAFT REAR |
| 03901 1695 | 90311-80003 | 80 x 100 x 8.5 | CORONA (SEDAN / 5 DOOR) 3E ET176 | 87/12~92/ | Engine CRANK SHAFT REAR |
| 03901 5421 | 90311-35013 | 35 x 49 x 6 | CORONA (SEDAN / 5 DOOR) 3E ET176 | 87/12~90/ | Engine CRANK SHAFT FRONT |
| 03901 1335 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 3SGELU ST162 | 85/8~87/ | Engine VALVE STEM SEAL |
| 03901 1843 | 90311-85007 | 85 x 105 x 10 | CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#,19#,21# | 90/10~ | Engine CRANK SHAFT REAR |
| 03901 3931 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 3S#,4S#(EX.) ST17#,19# | 90/3~96/ | Engine VALVE STEM SEAL |
| 03901 6045 | 90311-38067 | 38 x 50 x 8 | CORONA (SEDAN / 5 DOOR) 3SFE ST21# | 97/8~ | Engine CAM SHAFT |
| 03901 7633 | 90913-02062 | | CORONA (SEDAN / 5 DOOR) 3SFE (EX.) ST21# | 96/1~ | Engine VALVE STEM SEAL |
| 03901 4211 | 90913-02079 | | CORONA (SEDAN / 5 DOOR) 3S#,4S# (IN.) ST17#,19# | 90/3~96/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5215 | 90913-02079 | | CORONA (SEDAN / 5 DOOR) 3SFE (IN.) ST21# | 96/1~ | Engine VALVE STEM SEAL |
| 03901 7707 | 90913-02101 | | CORONA (SEDAN / 5 DOOR) 3SFSE (IN.) ST210 | 96/12~ | Engine VALVE STEM SEAL |
| 03901 8031 | 90913-02056 | | CORONA (SEDAN / 5 DOOR) 1S#...ST150,160 | 83/1~87/ | Engine VALVE STEM SEAL |
| 03901 1831 | 15165-70010 | 18 x 30 x 7 | CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#,19#,21# | 87/12~ | Engine OIL PUMP |
| 03901 6587 | 90311-38067 | 38 x 50 x 8 | CORONA (SEDAN / 5 DOOR) 3SFSE ST210 | 96/12~ | Engine CAM SHAFT |
| 03901 3471 | 90311-32020 | 32 x 46 x 6 | CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE AT17#,19#,21# | 87/12~ | Engine OIL PUMP |
| 03901 6863 | 90029-21020 | 20 x 32 x 5 | CORONA (SEDAN / 5 DOOR) 2C CT17# | 87/12~89/5 | Engine OIL PUMP |
| 03901 1485 | 90029-21022 | 22 x 34 x 6.5 | CORONA (SEDAN / 5 DOOR) 2C CT17#,19# | 89/5~96/ | Engine OIL PUMP |
| 03901 5751 | 90311-90005 | 90 x 110 x 8.5 x 10 | CORONA (SEDAN / 5 DOOR) 2C CT19# | 92/2~96/ | Engine CRANK SHAFT REAR |
| 03901 3075 | 90029-21020 | 20 x 32 x 5 | CORONA (SEDAN / 5 DOOR) 3E ET176 | 87/12~92/ | Engine OIL PUMP |
| 03901 6285 | 90311-42035 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 3SFGE ST210 | 97/8~ | Engine CRANK SHAFT FRONT |
| 03901 1731 | 90311-42003 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 2C CT150 | 83/1~85/5 | Engine CRANK SHAFT FRONT |
| 03901 6711 | 90311-42015 | 42 x 60 x 6 | CORONA (SEDAN / 5 DOOR) 2C CT150,17# | 85/5~90/8 | Engine CRANK SHAFT FRONT |
| 03901 4711 | 90311-42026 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 2C#,3CTE CT17#,19#,21# | 90/8~ | Engine CRANK SHAFT FRONT |
| 03901 1553 | 90311-42035 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 3SFE ST21# | 96/9~ | Engine CRANK SHAFT FRONT |
| 03901 3963 | 90311-42003 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 1S#,3S#,4S#...ST150,16#,17# | 83/1~89/10 | Engine CRANK SHAFT FRONT |
| 03901 8095 | 90311-42026 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#,19# | 89/10~96/ | Engine CRANK SHAFT FRONT |
| 03901 3965 | 90311-42026 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 3SFE ST21# | 96/1~96/9 | Engine CRANK SHAFT FRONT |
| 03901 6169 | 90311-42026 | 42 x 60 x 7 | CORONA (SEDAN / 5 DOOR) 3SFGE ST210 | 96/12~97/8 | Engine CRANK SHAFT FRONT |
| 03901 6797 | 90310-25004 | 25 x 38 x 7 x 8 | CRESSIDA / MARK II GX7#...EXCEPT GX71,TWT | 84/8~88/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3809 | 04445-22270 | | CRESSIDA / MARK II GX105 | 98/8~00/ | Steering (P/S) R & P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6897 | 90311-30016 | 30 x 42 x 7 x 8 | CRESSIDA / MARK II JZX10# | 96/9~00/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6581 | 04445-22280 | | CRESSIDA / MARK II GX110,JZX110 | 00/10~ | Steering (P/S) R & P GASKET KIT |
| 03901 4289 | 04445-22290 | | CRESSIDA / MARK II GX115,JZX115 | 00/10~ | Steering (P/S) R & P GASKET KIT |
| 03901 4515 | 90311-19002 | 19 x 32 x 7 x 8 | CRESSIDA / MARK II SX70,YX7#,GX7#,MX71,LX 7# | 84/8~88/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3595 | 90311-19002 | 19 x 32 x 7 x 8 | CRESSIDA / MARK II GX81,LX80,MX83,SX80,YX 80,JZX81 | 88/8~95/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7261 | 90311-19002 | 19 x 32 x 7 x 8 | CRESSIDA / MARK II GX90,JZX9#,LX90,SX90 | 92/10~96/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4197 | 90311-19002 | 19 x 32 x 7 x 8 | CRESSIDA / MARK II GX10#,JZX10#,LX100 | 96/9~00/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5847 | 90310-25027 | 25 x 38 x 7 | CRESSIDA / MARK II GX10#,LX100 | 96/9~00/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5959 | 90311-30016 | 30 x 42 x 7 x 8 | CRESSIDA / MARK II JZX9# | 92/10~96/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 8135 | 04445-22260 | | CRESSIDA / MARK II JZX105 | 96/9~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 2303 | 90310-25004 | 25 x 38 x 7 x 8 | CRESSIDA / MARK II SX80,YX80,GX81 (EXC. TWC,TWT),LX80 | 88/8~95/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6273 | 90310-25004 | 25 x 38 x 7 x 8 | CRESSIDA / MARK II GX90,LX90,SX90 | 92/10~96/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7317 | 90311-30016 | 30 x 42 x 7 x 8 | CRESSIDA / MARK II GX81 (TWC,TWT),MX83,JZX81 | 88/8~93/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5025 | 90311-19001 | 19 x 32 x 8 | CRESSIDA / MARK II TX6#,RX6#,GX60,MX60,LX 6# | 80/9~84/ | Steering (M/S) WORM GEAR |
| 03901 7093 | 90311-30016 | 30 x 42 x 7 x 8 | CRESSIDA / MARK II GX71 TWT | 86/8~88/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1251 | 90311-38025 | 38 x 50 x 6 | CRESSIDA / MARK II 1GEU GX7# | 87/1~88/ | Engine CAM SHAFT |
| 03901 5245 | 90311-38036 | 38 x 50 x 8 | CRESSIDA / MARK II 1GEU GX6#,7# | 80/9~87/1 | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6365 | 90310-25004 | 25 x 38 x 7 x 8 | CRESSIDA / MARK II SX70,YX7#,MX71,LX7# | 84/8~88/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3121 | 04445-22081 | | CRESSIDA / MARK II GX71 TWC | 87/1~88/ | Steering (P/S) R & P GASKET KIT |
| 03901 5535 | 90311-43001 | 43 x 70 x 9 x 15.5 | CRESSIDA / MARK II GX81,JZX81,MX83,,,TWC | 88/8~93/ | Final Drive DIFF. SIDE |
| 03901 3483 | 90311-43001 | 43 x 70 x 9 x 15.5 | CRESSIDA / MARK II JZX90 (TOUV),JZX91 | 92/10~96/ | Final Drive DIFF. SIDE |
| 03901 2805 | 90311-75007 | 75 x 100 x 10 | CRESSIDA / MARK II 1G#...GX70,81,90,10#,11# | 89/8~ | Engine CRANK SHAFT REAR |
| 03901 4975 | 90311-35013 | 35 x 49 x 6 | CRESSIDA / MARK II 1GG#...GX61,71,81 | 88/8~95/ | Engine CAM SHAFT |
| 03901 6801 | 90311-43001 | 43 x 70 x 9 x 15.5 | CRESSIDA / MARK II JZX110 GDGT,GDV,IRV | 00/10~ | Final Drive DIFF. SIDE |
| 03901 1257 | 90311-35018 | 35 x 63 x 10 x 16.5 | CRESSIDA / MARK II GX71 (EFI) | 85/10~88/ | Final Drive DIFF. SIDE |
| 03901 6951 | 90310-28027 | 28 x 40 x 8 | CRESSIDA / MARK II TX6#,RX6#,GX60,MX60,LX 6# | 80/9~84/ | Steering (M/S) SECTOR SHAFT |
| 03901 1051 | 90311-15001 | 15 x 25 x 7 | CRESSIDA / MARK II LX7#,SX70,YX7# | 84/8~88/ | Steering (M/S) RACK HOUSING |
| 03901 3763 | 04445-22062 | | CRESSIDA / MARK II SX70,YX7#,MX71,LX7# | 87/1~90/ | Steering (P/S) R & P GASKET KIT |
| 03901 5375 | 04445-22062 | | CRESSIDA / MARK II GX7#...EXCEPT GX71 TWC,TWT | 87/1~88/ | Steering (P/S) R & P GASKET KIT |
| 03901 7527 | 04445-22250 | | CRESSIDA / MARK II GX100,LX100 | 96/9~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 1751 | 04445-22091/2 | | CRESSIDA / MARK II GX71 TWT | 87/1~88/ | Steering (P/S) R & P GASKET KIT |
| 03901 4123 | 04445-22100/1 | | CRESSIDA / MARK II SX80,YX80,GX81 (EXC. TWC,TWT),LX80 | 88/8~95/ | Steering (P/S) R & P GASKET KIT |
| 03901 5499 | 04445-22110 | | CRESSIDA / MARK II GX81 (TWC,TWT),MX83 | 88/8~90/8 | Steering (P/S) R & P GASKET KIT |
| 03901 4589 | 04445-22130 | | CRESSIDA / MARK II GX81 (TWC,TWT),MX83,JZX81 | 90/8~92/ | Steering (P/S) R & P GASKET KIT |
| 03901 7541 | 04445-22160 | | CRESSIDA / MARK II JZX90,91 | 92/10~96/ | Steering (P/S) R & P GASKET KIT |
| 03901 6763 | 04445-22170 | | CRESSIDA / MARK II GX90,LX90,SX90 | 92/10~96/ | Steering (P/S) R & P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4961 | 04445-22190 | | CRESSIDA / MARK II JZX93 | 93/10~96/ | Steering (P/S) R & P GASKET KIT |
| 03901 3251 | 04445-22240 | | CRESSIDA / MARK II JZX100,101 | 96/9~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 7379 | 90311-43001 | 43 x 70 x 9 x 15.5 | CRESSIDA / MARK II JZX100 5F,5FC,4FC-TOUV,JZX101 | 96/9~00/ | Final Drive DIFF. SIDE |
| 03901 7663 | 90311-80009 | 80 x 100 x 10 | CRESSIDA / MARK II 2Y#,3Y#...YX7#,80 | 90/5~97/ | Engine CRANK SHAFT REAR |
| 03901 7091 | 90311-75114 | 75 x 100 x 13 | CRESSIDA / MARK II 1G#...GX6#,7# | 80/9~86/5 | Engine CRANK SHAFT REAR |
| 03901 7269 | 90311-42026 | 42 x 60 x 7 | CRESSIDA / MARK II 2L LX7#,8#,9# | 91/2~96/ | Engine TIMING GEAR CASE |
| 03901 3021 | 90311-42003 | 42 x 60 x 7 | CRESSIDA / MARK II 1SU,4S#...SX70,80 | 84/8~89/9 | Engine CRANK SHAFT FRONT |
| 03901 7187 | 90311-42026 | 42 x 60 x 7 | CRESSIDA / MARK II 4S#...SX80,90 | 89/9~96/ | Engine CRANK SHAFT FRONT |
| 03901 5271 | 90311-46001 | 46 x 63 x 6.5 | CRESSIDA / MARK II 1JZ#,2JZGE JZX81,9#,10#,11# | 90/8~ | Engine CRANK SHAFT FRONT |
| 03901 6633 | 90311-80001 | 80 x 100 x 12 | CRESSIDA / MARK II 21R RX6# | 80/9~84/ | Engine CRANK SHAFT REAR |
| 03901 2801 | 90311-80001 | 80 x 100 x 12 | CRESSIDA / MARK II M,5M,7M MX6#,71,83 | 80/9~93/ | Engine CRANK SHAFT REAR |
| 03901 5621 | 90311-75114 | 75 x 100 x 13 | CRESSIDA / MARK II 13T TX6# | 80/9~84/ | Engine CRANK SHAFT REAR |
| 03901 4989 | 90311-42003 | 42 x 60 x 7 | CRESSIDA / MARK II 7MGE MX83 | 89/8~93/ | Engine TIMING GEAR CASE |
| 03901 4109 | 90311-80003 | 80 x 100 x 8.5 | CRESSIDA / MARK II 2Y#,3Y#...YX7#,80 | 84/11~90/4 | Engine CRANK SHAFT REAR |
| 03901 6961 | 90311-45015 | 45 x 62 x 9 | CRESSIDA / MARK II 1GFE GX10#,11# | 98/8~ | Engine TIMING GEAR CASE |
| 03901 7281 | 90311-85004 | 85 x 105 x 10 | CRESSIDA / MARK II L,2L LX6#,7#,8# | 80/9~91/2 | Engine CRANK SHAFT REAR |
| 03901 6323 | 90072-72006 | | CRESSIDA / MARK II 18RGEU RX63 | 80/9~82/8 | Engine VALVE STEM SEAL |
| 03901 7119 | 90311-85004 | 85 x 105 x 10 | CRESSIDA / MARK II 1S#,4S#...SX60,70 | 80/9~91/2 | Engine CRANK SHAFT REAR |
| 03901 6241 | 90311-85007 | 85 x 105 x 10 | CRESSIDA / MARK II 2L LX7#,8#,9#,100 | 91/2~99/ | Engine CRANK SHAFT REAR |
| 03901 3015 | 90311-85007 | 85 x 105 x 10 | CRESSIDA / MARK II 4S#...SX80,90 | 91/2~96/ | Engine CRANK SHAFT REAR |
| 03901 3803 | 90311-90006 | 90 x 110 x 9.5 | CRESSIDA / MARK II 1JZ#,2JZGE JZX81,9#,10#,11# | 90/8~ | Engine CRANK SHAFT REAR |
| 03901 4861 | 90311-38071 | 38 x 63 x 10 x 16.5 | CRESSIDA / MARK II GX11#,JZX11#...GD,GDG,GDG,IR,IRS | 00/10~ | Final Drive DIFF. SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6269 | 90913-02094 | | CRESSIDA / MARK II 1SU SX70 | 87/9~88/8 | Engine VALVE STEM SEAL |
| 03901 7051 | 90311-75004 | 75 x 100 x 8.5 | CRESSIDA / MARK II 1G#...GX7#,81 | 86/5~89/8 | Engine CRANK SHAFT REAR |
| 03901 1385 | 15165-70010 | 18 x 30 x 7 | CRESSIDA / MARK II 1GEU,1GGEU,1GG(Z)E GX7#,81 | 88/8~93/ | Engine OIL PUMP |
| 03901 8085 | 90311-38036 | 38 x 50 x 8 | CRESSIDA / MARK II 1SU SX60,70 | 80/9~88/ | Engine CAM SHAFT |
| 03901 6501 | 90311-38036 | 38 x 50 x 8 | CRESSIDA / MARK II 4S#...SX80,90 | 88/8~96/ | Engine CAM SHAFT |
| 03901 2053 | 90311-42003 | 42 x 60 x 7 | CRESSIDA / MARK II 2L#...LX7# | 84/8~88/ | Engine CAM SHAFT |
| 03901 2823 | 90311-32020 | 32 x 46 x 6 | CRESSIDA / MARK II 2L#...LX76,80,90,100 | 88/8~99/ | Engine CAM SHAFT |
| 03901 3241 | 90311-38025 | 38 x 50 x 6 | CRESSIDA / MARK II 1JZGTE JZX90 | 92/10~96/ | Engine CAM SHAFT |
| 03901 2835 | 90311-40020 | 40.5 x 52.5 x 6.5 | CRESSIDA / MARK II 1JZGTE,2JZGE JZX9#,100,115 | 92/10~ | Engine CAM SHAFT |
| 03901 4493 | 90311-40020 | 40.5 x 52.5 x 6.5 | CRESSIDA / MARK II 1JZGTE JZX100,110 | 96/9~ | Engine CAM SHAFT (NO.1) |
| 03901 1153 | 90311-38056 | 38 x 52.5 x 6 | CRESSIDA / MARK II 1JZGTE JZX100,110 | 96/9~ | Engine CAM SHAFT (NO.2) |
| 03901 5633 | 90311-42003 | 42 x 60 x 7 | CRESSIDA / MARK II L,2L LX6#,7#,8# | 80/9~91/2 | Engine TIMING GEAR CASE |
| 03901 6335 | 90029-21005 | 18 x 30 x 5 | CRESSIDA / MARK II 1GFE GX70,81,90,100 | 88/8~98/ | Engine OIL PUMP |
| 03901 6265 | 90311-35013 | 35 x 49 x 6 | CRESSIDA / MARK II 1GFE GX70,81,90,100 | 88/8~98/8 | Engine CAM SHAFT |
| 03901 4871 | 15165-70010 | 18 x 30 x 7 | CRESSIDA / MARK II 1SU,4S#...SX70,80,90 | 84/8~96/ | Engine OIL PUMP |
| 03901 5967 | 90311-45002 | 45 x 68 x 12 | CRESSIDA / MARK II 21R RX6# | 80/9~84/ | Engine TIMING GEAR COVER |
| 03901 4939 | 90311-45002 | 45 x 68 x 12 | CRESSIDA / MARK II M,5M MX6#,71 | 80/9~85/ | Engine TIMING GEAR COVER |
| 03901 6161 | 90311-52003 | 52 x 70 x 8.5 | CRESSIDA / MARK II 7MGE MX83 | 89/8~93/ | Engine TIMING GEAR COVER |
| 03901 2503 | 90311-38022 | 38.5 x 58 x 8.5 | CRESSIDA / MARK II 13T TX6# | 80/9~84/ | Engine TIMING GEAR COVER |
| 03901 2927 | 90311-42003 | 42 x 60 x 7 | CRESSIDA / MARK II 2Y YX7# | 84/11~86/ 5 | Engine TIMING GEAR COVER |
| 03901 1239 | 90311-42026 | 42 x 60 x 7 | CRESSIDA / MARK II 2Y,3Y YX7#,80 | 86/5~97/ | Engine TIMING GEAR COVER |
| 03901 4875 | 90311-45003 | 45 x 62 x 8 | CRESSIDA / MARK II 1G#...GX6#,7#,81,90,100 | 80/9~98/8 | Engine TIMING GEAR CASE |
| 03901 6157 | 90311-34027 | 34 x 56 x 6 | CRESSIDA / MARK II 1JZGTE JZX110 | 00/10~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6383 | 90311-52059 | 52 x 65 x 9 | CRESSIDA / MARK II SX70,YX7#,GX70,LX7# | 84/8~88/ | Wheel Hub REAR |
| 03901 6149 | 90913-02024 | | CRESSIDA / MARK II 13T TX6# | 80/9~81/1 | Engine VALVE STEM SEAL |
| 03901 3769 | 90311-48001 | 48 x 62 x 9 | CRESSIDA / MARK II SX60,TX6#,RX6#,GX6#,MX6#,LX6# | 80/9~84/ | Wheel Hub FRONT |
| 03901 1521 | 90311-48001 | 48 x 62 x 9 | CRESSIDA / MARK II SX70,YX7#,GX7#,MX71,LX7# | 84/8~88/ | Wheel Hub FRONT |
| 03901 1889 | 90311-48001 | 48 x 62 x 9 | CRESSIDA / MARK II GX70,LX76,YX76,78 (WAGON, VAN) | 88/10~97/ | Wheel Hub FRONT |
| 03901 3679 | 90311-48013 | 48 x 73 x 7 | CRESSIDA / MARK II SX80,YX80,GX81,MX83,JZX81,LX80 | 88/8~95/ | Wheel Hub FRONT |
| 03901 3591 | 90311-48013 | 48 x 73 x 7 | CRESSIDA / MARK II SX90,GX90,JZX9#,LX90 | 92/10~96/ | Wheel Hub FRONT |
| 03901 3563 | 90311-48013 | 48 x 73 x 7 | CRESSIDA / MARK II GX100,JZX100,101,LX100 | 96/9~00/ | Wheel Hub FRONT |
| 03901 4737 | 90311-48001 | 48 x 62 x 9 | CRESSIDA / MARK II GX71,MX71 | 84/8~88/ | Wheel Hub REAR OUTER |
| 03901 6681 | 90311-52059 | 52 x 65 x 9 | CRESSIDA / MARK II SX60,TX6#,RX60,GX60,MX60,LX60,67 | 80/9~84/ | Wheel Hub REAR |
| 03901 2551 | 90913-02022 | | CRESSIDA / MARK II M#,5M# (IN.) MX6#,71 | 80/9~85/10 | Engine VALVE STEM SEAL |
| 03901 1567 | 90311-52059 | 52 x 65 x 9 | CRESSIDA / MARK II GX70,LX76,YX76,78 (WAGON, VAN) | 88/10~97/ | Wheel Hub REAR |
| 03901 5857 | 90311-52059 | 52 x 65 x 9 | CRESSIDA / MARK II SX80,LX80,YX80 | 88/8~95/ | Wheel Hub REAR |
| 03901 4219 | 90311-38009 | 38 x 58 x 8 | CRESSIDA / MARK II RX63,GX61,MX61,63,LX65 | 80/9~84/ | Wheel Hub REAR INNER |
| 03901 5357 | 90311-38009 | 38 x 58 x 8 | CRESSIDA / MARK II GX71,MX71 | 84/8~88/ | Wheel Hub REAR INNER |
| 03901 5015 | 90311-63001 | 63 x 90 x 7 x 10 | CRESSIDA / MARK II GX81,MX83,JZX81 | 88/8~93/ | Wheel Hub REAR INNER |
| 03901 2057 | 90311-63001 | 63 x 90 x 7 x 10 | CRESSIDA / MARK II SX90,GX90,JZX9#,LX90 | 92/10~96/ | Wheel Hub REAR INNER |
| 03901 4655 | 90311-63001 | 63 x 90 x 7 x 10 | CRESSIDA / MARK II GX10#,JZX10#,LX100 | 96/9~00/ | Wheel Hub REAR INNER |
| 03901 1015 | 90913-02062 | | CRESSIDA / MARK II 7MGE MX83 | 89/8~93/2 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7179 | 90311-48013 | 48 x 73 x 7 | CRESSIDA / MARK II GX110,JZX110 | 00/10~ | Wheel Hub FRONT |
| 03901 2919 | 90913-02117 | | CRESSIDA / MARK II 2LTE LX100 | 97/5~99/ | Engine VALVE STEM SEAL |
| 03901 6463 | 90913-02024 | | CRESSIDA / MARK II 21R RX60 | 80/9~82/8 | Engine VALVE STEM SEAL |
| 03901 7063 | 90913-02038 | | CRESSIDA / MARK II 1GEU GX6#,7# | 80/9~88/8 | Engine VALVE STEM SEAL |
| 03901 6523 | 90913-02062 | | CRESSIDA / MARK II 1GG#...GX61,71,81 | 82/8~93/ | Engine VALVE STEM SEAL |
| 03901 6603 | 90913-02062 | | CRESSIDA / MARK II 1GFE GX70,81,90,100 | 88/10~98/ 8 | Engine VALVE STEM SEAL |
| 03901 1713 | 90913-02093 | | CRESSIDA / MARK II 1GFE (IN. &E EX.) GX10#,11# | 98/8~ | Engine VALVE STEM SEAL |
| 03901 5931 | 90913-02094 | | CRESSIDA / MARK II 2Y#,3Y#...YX60,7#,80 | 83/2~97/ | Engine VALVE STEM SEAL |
| 03901 6033 | 90913-02036 | | CRESSIDA / MARK II L LX6# | 80/9~81/7 | Engine VALVE STEM SEAL |
| 03901 3781 | 90913-02060 | | CRESSIDA / MARK II L,2L LX6#,7# | 81/7~88/8 | Engine VALVE STEM SEAL |
| 03901 1411 | 90913-02024 | | CRESSIDA / MARK II 13T# (IN.) TX6# | 81/1~84/7 | Engine VALVE STEM SEAL |
| 03901 4715 | 90913-02110 | | CRESSIDA / MARK II 2LTE LX100 | 96/9~97/5 | Engine VALVE STEM SEAL |
| 03901 5861 | 90913-02058 | | CRESSIDA / MARK II 13T# (EX.) TX6# | 81/1~84/7 | Engine VALVE STEM SEAL |
| 03901 1557 | 90913-02079 | | CRESSIDA / MARK II 1JZ#,2JZGE (IN.) JZX81,9#,10#,11# | 90/8~ | Engine VALVE STEM SEAL |
| 03901 1305 | 90913-02062 | | CRESSIDA / MARK II 1JZ#,2JZGE (EX.) JZX81,9#,10#,11# | 90/8~ | Engine VALVE STEM SEAL |
| 03901 1435 | 90913-02079 | | CRESSIDA / MARK II 4S# (IN.) SX80,90 | 90/3~96/ | Engine VALVE STEM SEAL |
| 03901 2743 | 90913-02062 | | CRESSIDA / MARK II 4S# (EX.) SX80,90 | 90/3~96/ | Engine VALVE STEM SEAL |
| 03901 6227 | 90913-02062 | | CRESSIDA / MARK II 4S# (IN. & EX.) SX80 | 88/8~90/3 | Engine VALVE STEM SEAL |
| 03901 4293 | 90913-02056 | | CRESSIDA / MARK II 1SU SX60,70 | 82/8~87/9 | Engine VALVE STEM SEAL |
| 03901 8019 | 90913-02015 | | CRESSIDA / MARK II M#,5M# (EX.) MX6#,71 | 80/9~85/1 0 | Engine VALVE STEM SEAL |
| 03901 4299 | 90311-57001 | 57 x 81 x 8 x 11 | CRESSIDA / MARK II GX81,MX83,JZX81 | 88/8~93/ | Wheel Hub REAR OUTER |
| 03901 5545 | 90913-02110 | | CRESSIDA / MARK II 2L#...LX7#,80,90 | 88/8~96/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5641 | 90311-38019 | 38 x 65 x 10 x 17 | CRESSIDA / MARK II GX61 (ATM-EFI),GX71 (EFI) | 82/8~88/ | Final Drive PINION |
| 03901 2961 | 90311-48122 | 48 x 62 x 7 | CRESSIDA / MARK II RX63,GX61,MX61,63,LX65 | 80/9~84/ | Wheel Hub REAR OUTER |
| 03901 4405 | 90311-38133 | 38 x 74 x 11 | CRESSIDA / MARK II SX60,TX6#,RX6#,MX6#,LX6# | 80/9~84/ | Final Drive PINION |
| 03901 1577 | 90311-38133 | 38 x 74 x 11 | CRESSIDA / MARK II GX6#...EXCEPT ATM-EFI | 80/9~84/ | Final Drive PINION |
| 03901 3705 | 90311-38133 | 38 x 74 x 11 | CRESSIDA / MARK II SX70,YX7#,GX7# (EXCEPT EFI), MX71,LX7# | 84/8~97/ | Final Drive PINION |
| 03901 6561 | 90311-38133 | 38 x 74 x 11 | CRESSIDA / MARK II SX80,YX80,GX81,MX83,JZX81,LX80 | 88/8~95/ | Final Drive PINION |
| 03901 7461 | 90311-38133 | 38 x 74 x 11 | CRESSIDA / MARK II SX90,GX90,JZX9#,LX90 | 92/10~96/ | Final Drive PINION |
| 03901 3485 | 90311-38133 | 38 x 74 x 11 | CRESSIDA / MARK II GX100,JZX10#,LX100 | 96/9~98/8 | Final Drive PINION |
| 03901 8203 | 90311-40001 | 40 x 58 x 11 | CRESSIDA / MARK II GX81,MX83,JZX81,9#...A340E,341E | 88/8~96/ | Transmission (A/T) EXTENTION HOUSING |
| 03901 2891 | 90311-38070 | 38 x 74 x 11 x 19 | CRESSIDA / MARK II GX11#,JZX11# | 00/10~ | Final Drive PINION |
| 03901 4319 | 90311-38032 | 38 x 58 x 11 | CRESSIDA / MARK II GX100,110,LX100 | 96/9~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 5289 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II RX63,GX61,MX61,63 | 80/9~84/ | Final Drive DIFF. SIDE |
| 03901 4549 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II GX71,MX71 | 84/8~85/10 | Final Drive DIFF. SIDE |
| 03901 1813 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II GX71 (EXCEPT EFI,TWC) | 85/10~88/ | Final Drive DIFF. SIDE |
| 03901 5301 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II GX81 (ATM-HTWC,MTM-LG,GD) | 88/8~85/ | Final Drive DIFF. SIDE |
| 03901 3969 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II GX90,JZX90 (EXCEPT TOUV),93,LX90,SX90 | 92/10~96/ | Final Drive DIFF. SIDE |
| 03901 8075 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II GX100,JZX105,LX100 | 96/9~98/8 | Final Drive DIFF. SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4485 | 90311-38011 | 38 x 63 x 10 x 17 | CRESSIDA / MARK II JZX100 EXCEPT 5F,5FC,4FC-TOUV | 96/9~98/8 | Final Drive DIFF. SIDE |
| 03901 7369 | 90311-38071 | 38 x 63 x 10 x 16.5 | CRESSIDA / MARK II GX100,JZX105,LX100 | 98/8~00/ | Final Drive DIFF. SIDE |
| 03901 6987 | 90311-38070 | 38 x 74 x 11 x 19 | CRESSIDA / MARK II GX100,JZX10#,LX100 | 98/8~00/ | Final Drive PINION |
| 03901 3187 | 90311-38032 | 38 x 58 x 11 | CRESSIDA / MARK II GX70,LX76,80,YX76,78,80, SX80,GX81 | 91/10~97/ | Transmission (M/T) REAR EXTENTION |
| 03901 4641 | 90311-57001 | 57 x 81 x 8 x 11 | CRESSIDA / MARK II SX90,GX90,JZX9#,LX90 | 92/10~96/ | Wheel Hub REAR OUTER |
| 03901 2251 | 90311-57001 | 57 x 81 x 8 x 11 | CRESSIDA / MARK II GX10#,JZX10#,LX100 | 96/9~00/ | Wheel Hub REAR OUTER |
| 03901 3441 | 90311-30115 | 30 x 45 x 8 | CRESSIDA / MARK II SX60,TX6#,RX6#,GX6#,MX 6#,LX6# | 80/9~84/ | Transmission (M/T) FRONT COVER |
| 03901 3279 | 90311-30115 | 30 x 45 x 8 | CRESSIDA / MARK II SX70,80,YX7#,80,GX7#,81, LX7#,80 | 84/8~91/1 0 | Transmission (M/T) FRONT COVER |
| 03901 7737 | 90311-30014 | 30 x 45 x 8 | CRESSIDA / MARK II GX70,LX76,80,YX76,78,80, SX80,GX81 | 91/10~97/ | Transmission (M/T) FRONT COVER |
| 03901 7973 | 90311-30014 | 30 x 45 x 8 | CRESSIDA / MARK II SX90,GX90,100,LX90 | 92/10~00/ | Transmission (M/T) FRONT COVER |
| 03901 1381 | 90311-32012 | 32 x 53 x 7 | CRESSIDA / MARK II JZX90,100,110 | 92/10~ | Transmission (M/T) FRONT COVER |
| 03901 3443 | 90311-40001 | 40 x 58 x 11 | CRESSIDA / MARK II JZX100,101,110 | 96/9~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 3957 | 90311-38043 | 38 x 58 x 11 | CRESSIDA / MARK II SX70,80,YX7#,80,GX7#,81, LX7#,80 | 84/8~91/1 0 | Transmission (M/T) REAR EXTENTION |
| 03901 6413 | 90311-38071 | 38 x 63 x 10 x 16.5 | CRESSIDA / MARK II JZX100 EXCEPT 5F,5FC,4FC-TOUV | 98/8~00/ | Final Drive DIFF. SIDE |
| 03901 7909 | 90311-38032 | 38 x 58 x 11 | CRESSIDA / MARK II SX90,GX90,100,LX90 | 92/10~00/ | Transmission (M/T) REAR EXTENTION |
| 03901 5795 | 90311-40001 | 40 x 58 x 11 | CRESSIDA / MARK II JZX90,100,110 | 92/10~ | Transmission (M/T) REAR EXTENTION |
| 03901 1287 | 90311-38020 | 38 x 55 x 8.5 | CRESSIDA / MARK II SX,YX,GX,MX,LX A41,42D,43D | 84/8~96/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 8047 | 90311-38020 | 38 x 55 x 8.5 | CRESSIDA / MARK II GX100,LX100 | 96/9~98/8 | Transmission (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1449 | 90311-38020 | 38 x 55 x 8.5 | CRESSIDA / MARK II LX100 | 98/8~99/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4965 | 90311-38029 | 38 x 55 x 7.5 | CRESSIDA / MARK II GX81,MX83,JZX81,9#...A340E,341E | 88/8~96/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2905 | 90311-38029 | 38 x 55 x 7.5 | CRESSIDA / MARK II GX105,115,JZX10#,11# | 96/9~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 3913 | 90311-38064 | 38 x 55 x 8.7 | CRESSIDA / MARK II GX100,110 | 98/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7901 | 04332-30020 | Kit | CRESSIDA / MARK II SX,YX,GX,MX,LX A41,42D,43D | 84/8~96/ | Transmission (A/T) EXTENTION HOUSING |
| 03901 5719 | 90311-38043 | 38 x 58 x 11 | CRESSIDA / MARK II SX60,TX6#,RX6#,GX6#,MX6#,LX6# | 80/9~84/ | Transmission (M/T) REAR EXTENTION |
| 03901 1729 | 90311-56015 | 56 x 75 x 7 x 12 | CRESSIDA / MARK II WAGON MCV25,SXV25 | 97/6~ | Wheel Hub REAR INNER |
| 03901 8233 | 90311-38034 | 38 x 50 x 10.5 | CRESSIDA / MARK II WAGON 1MZFE,2MZFE MCV2# | 97/4~ | Engine CAM SHAFT |
| 03901 2773 | 90311-52005 | 52 x 75 x 7.5 x 12 | CRESSIDA / MARK II WAGON MCV25,SXV25 | 97/6~ | Wheel Hub REAR OUTER |
| 03901 5387 | 90311-54005 | 55 x 70 x 10 | CRESSIDA / MARK II WAGON MCV25,SXV25 | 97/6~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 6785 | 90311-35033 | 35 x 55 x 9 x 15.5 | CRESSIDA / MARK II WAGON SXV20 | 97/4~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1659 | 90311-35033 | 35 x 55 x 9 x 15.5 | CRESSIDA / MARK II WAGON SXV20 | 97/4~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3849 | 90311-50011 | 50 x 80 x 16.5 x 23 | CRESSIDA / MARK II WAGON MCV2# | 97/4~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 4793 | 90311-50022 | 42 x 62 x 8.5 x 15.4 | CRESSIDA / MARK II WAGON SXV25 | 97/6~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 1225 | 90311-38020 | 38 x 55 x 8.5 | CRESSIDA / MARK II WAGON MCV2#,SXV2# | 97/4~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 3101 | 04445-32051 | | CRESSIDA / MARK II WAGON MCV20,21,SXV20 | 97/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 1683 | 04445-33080 | | CRESSIDA / MARK II WAGON MCV25,SXV25 | 97/6~ | Steering (P/S) R & P GASKET KIT |
| 03901 2573 | 90311-40010 | 40 x 56 x 9 x 15.5 | CRESSIDA / MARK II WAGON MCV20,21 | 97/4~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1393 | 90311-26003 | 26 x 38 x 6.5 | CRESSIDA / MARK II WAGON MCV2#,SXV2# | 97/4~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5309 | 90311-38036 | 38 x 50 x 8 | CRESSIDA / MARK II WAGON 5SFE SXV2# | 97/4~ | Engine CAM SHAFT |
| 03901 1217 | 90311-40022 | 40 x 55 x 6 | CRESSIDA / MARK II WAGON 1MZFE,2MZFE MCV2# | 97/4~ | Engine OIL PUMP |
| 03901 2047 | 15165-70010 | 18 x 30 x 7 | CRESSIDA / MARK II WAGON 5SFE SXV2# | 97/4~ | Engine OIL PUMP |
| 03901 1865 | 90311-42035 | 42 x 60 x 7 | CRESSIDA / MARK II WAGON 5SFE SXV2# | 97/4~ | Engine CRANK SHAFT FRONT |
| 03901 2421 | 90311-92008 | 92 x 110 x 9 | CRESSIDA / MARK II WAGON 1MZFE,2MZFE MCV2# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 3731 | 90311-85007 | 85 x 105 x 10 | CRESSIDA / MARK II WAGON 5SFE SXV2# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 1451 | 90913-02079 | | CRESSIDA / MARK II WAGON 5SFE (IN.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 5715 | 90913-02062 | | CRESSIDA / MARK II WAGON 5SFE (EX.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6385 | 90913-02101 | | CRESSIDA / MARK II WAGON 1MZFE,2MZFE (IN.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 7283 | 90913-02111 | | CRESSIDA / MARK II WAGON 1MZFE,2MZFE (EX.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6727 | 90311-19010 | 19 x 32 x 6 | CRESSIDA / MARK II WAGON MCV2#,SXV2# | 97/4~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4751 | 90311-43003 | 43 x 65 x 8 | CROWN GS141,JZS141,143,145,LS141 | 91/10~95/ | Wheel Hub REAR INNER |
| 03901 7671 | 90311-35013 | 35 x 49 x 6 | CROWN 1GFE GS13#,151,171 | 88/9~ | Engine CAM SHAFT |
| 03901 1285 | 04445-30120 | | CROWN GS141,JZS141,LS141 (SALEX) | 91/10~95/ | Steering (P/S) GEAR GASKET KIT |
| 03901 5121 | 90311-30016 | 30 x 42 x 7 x 8 | CROWN JZS153,155,157,UZS155 C,ROY#,SALEX | 95/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5033 | 90311-30016 | 30 x 42 x 7 x 8 | CROWN UZS173 | 99/9~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1439 | 90310-25004 | 25 x 38 x 7 x 8 | CROWN GS151,JZS151,LS151 | 95/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6171 | 90310-25004 | 25 x 38 x 7 x 8 | CROWN GS272,JZS171,173,175,179 | 99/9~ | Steering (P/S) CONTROL VALVE LOWER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4499 | 90311-42003 | 42 x 60 x 7 | CROWN L,2L#...LS11#,12#,13# | 79/9~89/8 | Engine CAM SHAFT |
| 03901 3069 | 90311-32020 | 32 x 46 x 6 | CROWN 2L#...LS13#,141,151 | 89/8~ | Engine CAM SHAFT |
| 03901 5699 | 90311-38013 | 38.5 x 58 x 11 | CROWN 5M#,6M#...MS112.123.125 | 83/8~87/ | Engine CAM SHAFT |
| 03901 8201 | 90311-35013 | 35 x 49 x 6 | CROWN 7M#...MS13# | 87/9~91/ | Engine CAM SHAFT |
| 03901 6101 | 90311-38036 | 38 x 50 x 8 | CROWN 1GE#...GS120,126 | 83/8~87/1 | Engine CAM SHAFT |
| 03901 5321 | 90310-30013 | 30 x 41 x 6.5 | CROWN JZS177,UZS171,175 | 99/9~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1199 | 90311-35013 | 35 x 49 x 6 | CROWN 1GGE,1GGZE GS121,13# | 83/8~91/ | Engine CAM SHAFT |
| 03901 5049 | 90310-30013 | 30 x 41 x 6.5 | CROWN JZS155,UZS151,157 (MAJESTA) | 95/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2451 | 90311-35040 | 35 x 49 x 6 | CROWN 1GGPE GS130,151 | 89/8~ | Engine CAM SHAFT |
| 03901 7431 | 90311-40020 | 40.5 x 52.5 x 6.5 | CROWN 1JZGE,2JZGE JZS13#,14#,15# | 90/8~ | Engine CAM SHAFT |
| 03901 4949 | 90311-40020 | 40.5 x 52.5 x 6.5 | CROWN 1JZGE,2JZGE JZS171,173,179 | 99/9~ | Engine CAM SHAFT |
| 03901 7207 | 90311-40020 | 40.5 x 52.5 x 6.5 | CROWN 1JZGFE JZS171 | 99/9~ | Engine CAM SHAFT (NO.1) |
| 03901 6599 | 90311-38056 | 38 x 52.5 x 6 | CROWN 1JZGFE JZS171 | 99/9~ | Engine CAM SHAFT (NO.2) |
| 03901 3331 | 90311-34027 | 34 x 56 x 6 | CROWN 2JZFSE JZS175,177 | 99/9~ | Engine CAM SHAFT |
| 03901 5007 | 90311-38036 | 38 x 50 x 8 | CROWN 1UZFE UZS131,14#,15# | 89/8~97/7 | Engine CAM SHAFT |
| 03901 7887 | 90311-71001 | 71.5 x 85 x 10 | CROWN 1UZFE UZS15#,17# | 97/7 | Engine CAM SHAFT |
| 03901 6267 | 90311-45002 | 45 x 68 x 12 | CROWN 5RU RU110 | 79/9~83/ | Engine TIMING GEAR COVER |
| 03901 7573 | 90311-45002 | 45 x 68 x 12 | CROWN M#,5MEU MS11#,120,130 | 79/9~89/ | Engine TIMING GEAR COVER |
| 03901 2035 | 90311-38025 | 38 x 50 x 6 | CROWN 1GE#...GS120,126,13# | 87/1~89/ | Engine CAM SHAFT |
| 03901 6137 | 04445-51010 | | CROWN GS171,JZS171 HTWC,TWC | 99/9~ | Steering (P/S) R & P GASKET KIT |
| 03901 6331 | 04445-30130 | | CROWN GS130/6,LS130/6,YS130 STD,DX,SDX | 91/10~95/ | Steering (P/S) GEAR GASKET KIT |
| 03901 4033 | 04445-30130 | | CROWN GS13#,JZS130,LS130 | 95/12~99/ | Steering (P/S) GEAR GASKET KIT |
| 03901 4579 | 04445-30130 | | CROWN LS141 (SSL) | 91/10~95/ | Steering (P/S) GEAR GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7135 | 04445-30140 | | CROWN JZS147,149,UZS141,147 | 91/10~95/ | Steering (P/S) R & P GASKET KIT |
| 03901 4023 | 04445-30170 | | CROWN UZS143,145,155 | 92/10~ | Steering (P/S) R & P GASKET KIT |
| 03901 3225 | 04445-30180 | | CROWN JZS155,UZS151,157 (MAJESTA) | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 6195 | 04445-30190 | | CROWN JZS155 ROY# | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 8077 | 04445-30200 | | CROWN GS151,JZS151,LS151 | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 3053 | 04445-30220 | | CROWN JZS153,157 | 95/12~ | Steering (P/S) R & P GASKET KIT |
| 03901 7399 | 04445-30260 | | CROWN JZS171,175 D4,TWT | 99/9~ | Steering (P/S) R & P GASKET KIT |
| 03901 5553 | 90311-30016 | 30 x 42 x 7 x 8 | CROWN UZS143M145 | 92/10~95/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3649 | 04445-30290 | | CROWN UZS173 | 99/9~ | Steering (P/S) R & P GASKET KIT |
| 03901 8241 | 90311-42003 | 42 x 60 x 7 | CROWN 3Y#...YS120 | 83/8~87/ | Engine TIMING GEAR COVER |
| 03901 4181 | 90311-19002 | 19 x 32 x 7 x 8 | CROWN YS120,GS12#,MS12#,LS12# | 83/8~87/ | Steering (P/S) ADJUSTER PLUG |
| 03901 4451 | 90312-32002 | 32 x 40 x 5 | CROWN RS110,GS11#,MS11#,LS11# | 79/9~83/ | Steering (P/S) GEAR HOUSING |
| 03901 3237 | 90312-32002 | 32 x 40 x 5 | CROWN YS120,GS12#,MS12#,LS12# | 83/8~87/ | Steering (P/S) GEAR HOUSING |
| 03901 3941 | 90312-32002 | 32 x 40 x 5 | CROWN YS130,GS13#,MS13#,UZS131,LS13# | 87/9~91/10 | Steering (P/S) GEAR HOUSING |
| 03901 7857 | 90312-32002 | 32 x 40 x 5 | CROWN YS130,GS13#,JZS13#,LS13# | 91/10~99/ | Steering (P/S) GEAR HOUSING |
| 03901 3195 | 90312-32002 | 32 x 40 x 5 | CROWN JZS141,143,145,LS141 | 91/10~95/ | Steering (P/S) GEAR HOUSING |
| 03901 1977 | 90311-19002 | 19 x 32 x 7 x 8 | CROWN UZS14#,JZS147,149 | 91/10~95/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6589 | 90311-19002 | 19 x 32 x 7 x 8 | CROWN GS15#,JZS15#,UZS15#,LS151 | 95/8~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7777 | 90311-19002 | 19 x 32 x 7 x 8 | CROWN GS171,JZS17#,UZS17# | 99/9~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1783 | 90310-30013 | 30 x 41 x 6.5 | CROWN JZS147,149,UZS141,147 | 91/10~95/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6719 | 04445-30280 | | CROWN JZS173,179 | 99/9~ | Steering (P/S) R & P GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3407 | 90913-02110 | | CROWN 2L# | 89/8~97/5 | Engine VALVE STEM SEAL |
| 03901 2347 | 90311-95012 | 95 x 113 x 8.5 | CROWN 1UZFE UZS131,14#,15#,17# | 89/8~ | Engine CRANK SHAFT REAR |
| 03901 6489 | 90913-02042 | | CROWN 5RU RU110 | 79/9~83/ | Engine VALVE STEM SEAL |
| 03901 1829 | 90913-02015 | | CROWN M#,5MEU (EX.) | 79/9~89/ | Engine VALVE STEM SEAL |
| 03901 3173 | 90913-02022 | | CROWN M#,5MEU (IN.) | 79/9~89/ | Engine VALVE STEM SEAL |
| 03901 1717 | 90913-02110 | | CROWN 5MGEU,6MGEU | 81/8~87/ | Engine VALVE STEM SEAL |
| 03901 5705 | 90913-02062 | | CROWN 7MGE | 87/9~91/ | Engine VALVE STEM SEAL |
| 03901 3669 | 90913-02038 | | CROWN 1G#,1GE | 81/8~89/ | Engine VALVE STEM SEAL |
| 03901 8213 | 90913-02062 | | CROWN 1GG#,1GFE | 83/8~98/8 | Engine VALVE STEM SEAL |
| 03901 4957 | 90913-02093 | | CROWN 1GFE (IN. & EX.) | 98/8~ | Engine VALVE STEM SEAL |
| 03901 6757 | 90913-02094 | | CROWN 3Y# | 83/8~95/ | Engine VALVE STEM SEAL |
| 03901 7697 | 90311-48004 | 48 x 70 x 12 | CROWN 5MGEU MS112,123 | 81/8~84/8 | Engine TIMING GEAR COVER |
| 03901 2595 | 90913-02060 | | CROWN L,2L# | 81/7~89/8 | Engine VALVE STEM SEAL |
| 03901 1873 | 90311-80003 | 80 x 100 x 8.5 | CROWN 3Y#...YS120 | 83/8~87/ | Engine CRANK SHAFT REAR |
| 03901 4597 | 90913-02117 | | CROWN 2L# | 97/5~ | Engine VALVE STEM SEAL |
| 03901 2959 | 90913-02079 | | CROWN 1JZGE,2JZGE (IN. & EX.) | 90/8~91/10 | Engine VALVE STEM SEAL |
| 03901 1817 | 90913-02079 | | CROWN 1JZGE,2JZGE (IN.) | 91/10~ | Engine VALVE STEM SEAL |
| 03901 8089 | 90913-02062 | | CROWN 1JZGE,2JZGE (EX.) | 91/10~ | Engine VALVE STEM SEAL |
| 03901 5905 | 90913-02079 | | CROWN 1UZFE (IN. & EX.) | 90/8~96/8 | Engine VALVE STEM SEAL |
| 03901 3751 | 90913-02079 | | CROWN 1UZFE (IN.) | 96/8~97/7 | Engine VALVE STEM SEAL |
| 03901 2529 | 90913-02113 | | CROWN 1UZFE (IN.) | 97/7~ | Engine VALVE STEM SEAL |
| 03901 3243 | 90913-02106 | | CROWN 1UZFE (EX.) | 96/8~97/7 | Engine VALVE STEM SEAL |
| 03901 7239 | 90913-02112 | | CROWN 1UZFE (EX.) | 97/7~ | Engine VALVE STEM SEAL |
| 03901 2871 | 90311-43003 | 43 x 65 x 8 | CROWN MS135,137,UZS131 | 87/9~91/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6299 | 90913-02036 | | CROWN L | 79/9~81/7 | Engine VALVE STEM SEAL |
| 03901 6733 | 90311-43004 | 43 x 60 x 7 | CROWN 1UZFE UZS131,14#,15# | 89/8~97/12 | Engine OIL PUMP |
| 03901 2911 | 04445-30300 | | CROWN JZS177,UZS171,175 | 99/9~ | Steering (P/S) R & P GASKET KIT |
| 03901 5891 | 90311-42026 | 42 x 60 x 7 | CROWN 3Y#...YS120 | 87/9~95/ | Engine TIMING GEAR COVER |
| 03901 7743 | 90311-42003 | 42 x 60 x 7 | CROWN 7MGE MS135,137 | 87/9~91/ | Engine TIMING GEAR CASE |
| 03901 4505 | 90311-42003 | 42 x 60 x 7 | CROWN L,2L#...LS11#,12#,13# | 79/9~91/2 | Engine TIMING GEAR CASE |
| 03901 4807 | 90311-42026 | 42 x 60 x 7 | CROWN 2L#...LS13#,141,151 | 91/2~ | Engine TIMING GEAR CASE |
| 03901 2371 | 90311-45003 | 45 x 62 x 8 | CROWN 1G#,1GG#...GS11#,12#,13#, 141,151 | 81/8~98/8 | Engine TIMING GEAR CASE |
| 03901 2527 | 90311-45015 | 45 x 62 x 9 | CROWN 1GFE GS151,171 | 98/8~ | Engine TIMING GEAR CASE |
| 03901 2723 | 90311-45010 | 45 x 62 x 8.5 | CROWN 1GGPE GS130,151 | 89/8~ | Engine TIMING GEAR CASE |
| 03901 3239 | 15165-70010 | 18 x 30 x 7 | CROWN 1GE,1GG#...GS13# | 87/9~91/10 | Engine OIL PUMP |
| 03901 1639 | 90029-21005 | 18 x 30 x 5 | CROWN 1GFE GS13#,141,151 | 88/9~98/8 | Engine OIL PUMP |
| 03901 7175 | 90311-90006 | 90 x 110 x 9.5 | CROWN 1JZ#,2JZ#...JZS13#,14#,15#, 17# | 90/8~ | Engine CRANK SHAFT REAR |
| 03901 4727 | 15165-70040 | 18 x 30 x 7 | CROWN 1GGPE GS130,151 | 89/8~ | Engine OIL PUMP |
| 03901 2159 | 90311-80012 | 80 x 100 x 8.5 | CROWN 3Y#...YS130 | 87/9~95/ | Engine CRANK SHAFT REAR |
| 03901 1395 | 90311-43006 | 43 x 60 x 7 | CROWN 1UZFE UZS15#,17# | 97/12~ | Engine OIL PUMP |
| 03901 4757 | 90311-46001 | 46 x 63 x 6.5 | CROWN 1JZGE,2JZGE JZS13#,14#,15#,17# | 90/8~ | Engine CRANK SHAFT FRONT |
| 03901 2285 | 90311-80001 | 80 x 100 x 12 | CROWN 5RU RU110 | 79/9~83/ | Engine CRANK SHAFT REAR |
| 03901 4183 | 90311-80001 | 80 x 100 x 12 | CROWN M#,5M#,6M#,7M#...MS11#, 12#,13# | 79/9~91/ | Engine CRANK SHAFT REAR |
| 03901 6261 | 90311-85001 | 85 x 105 x 13 | CROWN L,2L#...LS11#,12# | 79/9~84/2 | Engine CRANK SHAFT REAR |
| 03901 5159 | 90311-85004 | 85 x 105 x 10 | CROWN 2L#...LS12#,13# | 84/2~91/2 | Engine CRANK SHAFT REAR |
| 03901 3013 | 90311-85007 | 85 x 105 x 10 | CROWN 2L#...LS13#,141,151 | 91/2 | Engine CRANK SHAFT REAR |
| 03901 7937 | 90311-75114 | 75 x 100 x 13 | CROWN 1G#...GS11#,12# | 81/8~86/5 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5029 | 90311-75004 | 75 x 100 x 8.5 | CROWN 1G#...GS12#,13# | 86/5~89/8 | Engine CRANK SHAFT REAR |
| 03901 1417 | 90311-75007 | 75 x 100 x 10 | CROWN 1G#...GS13#,141,151 | 89/8 | Engine CRANK SHAFT REAR |
| 03901 7197 | 90311-52003 | 52 x 70 x 8.5 | CROWN 6MGEU,7MGE MS125,135,137 | 84/8~91/ | Engine TIMING GEAR COVER |
| 03901 1049 | 15165-70010 | 18 x 30 x 7 | CROWN 1GFE GS151,171 | 98/8~ | Engine OIL PUMP |
| 03901 1133 | 04445-30120 | | CROWN GS130/1,JZS130/1,LS130/1 ROY,SALEX | 91/10~95/ | Steering (P/S) GEAR GASKET KIT |
| 03901 4717 | 90311-38058 | 38 x 55 x 8.5 | CROWN GS151 LPGTE | 96/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4663 | 90311-30115 | 30 x 45 x 8 | CROWN RS110,MS110,117 3H,4H | 80/10~83/ | Transmission (M/T) FRONT COVER |
| 03901 5367 | 90311-30115 | 30 x 45 x 8 | CROWN RS110,MS11#...4F,5F,GS11# ,LS11# | 79/9~83/ | Transmission (M/T) FRONT COVER |
| 03901 3771 | 90311-30115 | 30 x 45 x 8 | CROWN YS120,GS12#,MS120,LS12# | 83/8~87/ | Transmission (M/T) FRONT COVER |
| 03901 5365 | 90311-30115 | 30 x 45 x 8 | CROWN YS130,GS13#,MS13#,LS13# | 87/9~91/1 0 | Transmission (M/T) FRONT COVER |
| 03901 8067 | 90311-30014 | 30 x 45 x 8 | CROWN YS130,GS13#,LS13# | 91/10~99/ | Transmission (M/T) FRONT COVER |
| 03901 1675 | 90311-30014 | 30 x 45 x 8 | CROWN GS151 | 95/12~ | Transmission (M/T) FRONT COVER |
| 03901 5741 | 04332-30010 | Kit | CROWN MS11#...4F,5F,LS11# | 79/9~81/1 | Transmission (M/T) REAR EAXTENTION |
| 03901 6617 | 90311-38140 | 38 x 58 x 11 | CROWN RS110,MS110,117 3H,4H | 79/9~80/1 0 | Transmission (M/T) REAR EAXTENTION |
| 03901 5543 | 90311-38043 | 38 x 58 x 11 | CROWN RS110,MS110,117 3H,4H | 80/10~81/ 8 | Transmission (M/T) REAR EAXTENTION |
| 03901 4107 | 90311-57001 | 57 x 81 x 8 x 11 | CROWN GS151,JZS15#,LS151,UZS15 # | 95/8~ | Wheel Hub REAR OUTER |
| 03901 7501 | 90311-38043 | 38 x 58 x 11 | CROWN RS110,GS11#,MS110,117,LS 11# | 81/8~83/ | Transmission (M/T) REAR EAXTENTION |
| 03901 1967 | 90311-57001 | 57 x 81 x 8 x 11 | CROWN JZS147,149,UZS14# | 91/10~95/ | Wheel Hub REAR OUTER |
| 03901 6243 | 90311-38043 | 38 x 58 x 11 | CROWN YS130,GS13#,LS13#...5F | 87/9~91/1 0 | Transmission (M/T) REAR EAXTENTION |
| 03901 3067 | 90311-38043 | 38 x 58 x 11 | CROWN YS130,GS13#,MS130,LS13# ...4H | 87/9~88/8 | Transmission (M/T) REAR EAXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6597 | 90311-38032 | 38 x 58 x 11 | CROWN YS130,GS13#,MS130,LS13# ...4H | 88/8~91/10 | Transmission (M/T) REAR EAXTENTION |
| 03901 6677 | 90311-38032 | 38 x 58 x 11 | CROWN YS130,GS13#,LS136 | 91/10~99/ | Transmission (M/T) REAR EAXTENTION |
| 03901 3741 | 90311-38032 | 38 x 58 x 11 | CROWN GS151 | 95/12~ | Transmission (M/T) REAR EAXTENTION |
| 03901 3133 | 90311-38020 | 38 x 55 x 8.5 | CROWN YS130,MS130,LS13#,GS130 ,131 (EXC. SPC) | 87/9~91/10 | Transmission (A/T) FRONT OIL PUMP |
| 03901 6329 | 90311-38020 | 38 x 55 x 8.5 | CROWN GS13#,LS136,YS130 | 91/10~99/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6131 | 90311-38020 | 38 x 55 x 8.5 | CROWN GS141,151 | 93/8~96/10 | Transmission (A/T) FRONT OIL PUMP |
| 03901 7493 | 90311-38020 | 38 x 55 x 8.5 | CROWN GS151 HTWC | 96/10~98/8 | Transmission (A/T) FRONT OIL PUMP |
| 03901 4243 | 90311-38064 | 38 x 55 x 8.7 | CROWN GS151 HTWC | 98/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4291 | 90311-38064 | 38 x 55 x 8.7 | CROWN GS171 | 99/9~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4761 | 90311-19002 | 19 x 32 x 7 x 8 | CROWN RS110,GS11#,MS11#,LS11# | 79/9~83/ | Steering (P/S) ADJUSTER PLUG |
| 03901 3541 | 90311-58118 | 58 x 72 x 9 | CROWN GS11#,MS11#,LS11#...WAGON,VAN | 79/9~83/ | Wheel Hub REAR |
| 03901 8087 | 90311-48001 | 48 x 62 x 9 | CROWN YS120,GS12#,MS12#,LS12# | 83/8~87/ | Wheel Hub FRONT |
| 03901 5419 | 90311-48001 | 48 x 62 x 9 | CROWN MS13#,UZS13# | 87/9~91/ | Wheel Hub FRONT |
| 03901 6403 | 90311-48001 | 48 x 62 x 9 | CROWN YS130,GS13#,JZS13#,LS13# | 87/9~99/ | Wheel Hub FRONT |
| 03901 2007 | 90311-48001 | 48 x 62 x 9 | CROWN GS141,JZS141,143,145,LS141 | 91/10~95/ | Wheel Hub FRONT |
| 03901 5407 | 90311-48013 | 48 x 73 x 7 | CROWN GS151,JZS151,155 (EXC. MAJESTA),LS151 | 95/8~ | Wheel Hub FRONT |
| 03901 1279 | 90311-48013 | 48 x 73 x 7 | CROWN GS171,JZS171,175 | 99/9~ | Wheel Hub FRONT |
| 03901 1833 | 90311-50008 | 50 x 77.5 x 9 x 14 | CROWN JZS147,149,UZS141,147 | 91/10~95/ | Wheel Hub FRONT |
| 03901 4345 | 90311-50008 | 50 x 77.5 x 9 x 14 | CROWN JZS155,UZS151,157 (MAJESTA) | 95/8~99/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7089 | 90311-50008 | 50 x 77.5 x 9 x 14 | CROWN JZS177,UZS171,175 | 99/9~ | Wheel Hub FRONT |
| 03901 2853 | 90311-52059 | 52 x 65 x 9 | CROWN RS110,GS110,MS11#,LS11#. ..SEDAN,H/T | 79/9~83/ | Wheel Hub REAR |
| 03901 7397 | 90311-32106 | 32 x 48 x 8 | CROWN RS110,MS110,117 3H,4H | 79/9~80/10 | Transmission (M/T) FRONT COVER |
| 03901 1867 | 90311-52059 | 52 x 65 x 9 | CROWN YS130,GS130,MS130,LS130 SEDAN,H/T | 87/9~95/ | Wheel Hub REAR |
| 03901 2627 | 90311-38043 | 38 x 58 x 11 | CROWN YS120,GS12#,MS120,LS12# | 83/8~87/ | Transmission (M/T) REAR EAXTENTION |
| 03901 7669 | 90311-58118 | 58 x 72 x 9 | CROWN GS12#,LS12#...WAGON,VAN | 83/8~87/ | Wheel Hub REAR |
| 03901 7949 | 90311-58118 | 58 x 72 x 9 | CROWN GS13#,JZS130,LS13#...WAGON,VAN | 87/9~99/ | Wheel Hub REAR |
| 03901 2951 | 90311-38009 | 38 x 58 x 8 | CROWN GS121,MS123,125 | 83/8~87/ | Wheel Hub REAR INNER |
| 03901 3845 | 90311-43003 | 43 x 65 x 8 | CROWN GS131,JZS131,133,135,LS131 | 87/9~95/ | Wheel Hub REAR INNER |
| 03901 6573 | 90311-48122 | 48 x 62 x 7 | CROWN RS110,GS11#,MS11#,LS11# | 79/9~83/ | Wheel Hub FRONT |
| 03901 6255 | 90311-63001 | 63 x 90 x 7 x 10 | CROWN JZS147,149,UZS14# | 91/10~95/ | Wheel Hub REAR INNER |
| 03901 4479 | 90311-63001 | 63 x 90 x 7 x 10 | CROWN GS151,JZS15#,LS151,UZS15# | 95/8~ | Wheel Hub REAR INNER |
| 03901 1387 | 90311-48001 | 48 x 62 x 9 | CROWN GS121,MS123,125 | 83/8~87/ | Wheel Hub REAR OUTER |
| 03901 2455 | 90311-48001 | 48 x 62 x 9 | CROWN MS135,137,UZS131 | 87/9~91/ | Wheel Hub REAR OUTER |
| 03901 7717 | 90311-48001 | 48 x 62 x 9 | CROWN GS131,JZS131,133,135,LS131 | 87/9~95/ | Wheel Hub REAR OUTER |
| 03901 3017 | 90311-48001 | 48 x 62 x 9 | CROWN GS141,JZS141,143,145,LS141 | 91/10~95/ | Wheel Hub REAR OUTER |
| 03901 5427 | 90311-52059 | 52 x 65 x 9 | CROWN YS120,GS120,MS120,LS120 SEDAN,H/T | 83/8~87/ | Wheel Hub REAR |
| 03901 4229 | 90311-38043 | 38 x 58 x 11 | CROWN MS11#...4F,5F,LS11# | 81/8~ | Transmission (M/T) REAR EAXTENTION |
| 03901 7087 | 90311-44005 | 44 x 74 x 11 x 16 | CROWN JZS155,UZS15# (MAJESTA) | 95/8~ | Final Drive PINION |
| 03901 7625 | 90311-44005 | 44 x 74 x 11 x 16 | CROWN JZS177,UZS17# | 99/9~ | Final Drive PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1641 | 90311-38011 | 38 x 63 x 10 x 17 | CROWN GS121,MS123,125 | 83/8~87/ | Final Drive DIFF.SIDE |
| 03901 1535 | 90311-38011 | 38 x 63 x 10 x 17 | CROWN GS131 (EXC. SPC),LS131 | 87/9~91/10 | Final Drive DIFF.SIDE |
| 03901 5273 | 90311-38011 | 38 x 63 x 10 x 17 | CROWN GS131,141,LS131,141 | 91/10~95/ | Final Drive DIFF.SIDE |
| 03901 4473 | 90311-38011 | 38 x 63 x 10 x 17 | CROWN GS151,JZS151,153,LS151 | 95/8~98/8 | Final Drive DIFF.SIDE |
| 03901 4617 | 90311-38071 | 38 x 63 x 10 x 16.5 | CROWN GS151,JZS151,153,LS151 | 98/8~ | Final Drive DIFF.SIDE |
| 03901 1893 | 90311-38071 | 38 x 63 x 10 x 16.5 | CROWN GS171,JZS171,173,179 4FC HTWC,TWC | 99/9~ | Final Drive DIFF.SIDE |
| 03901 4891 | 90311-43001 | 43 x 70 x 9 x 15.5 | CROWN GS131 (SPC),MS135,137,JZS131,UZS131 | 87/9~91/ | Final Drive DIFF.SIDE |
| 03901 3287 | 90311-43001 | 43 x 70 x 9 x 15.5 | CROWN JZS131,133,135,141,143,145 | 91/10~95/ | Final Drive DIFF.SIDE |
| 03901 3783 | 90311-44005 | 44 x 74 x 11 x 16 | CROWN JZS147,149,UZS14# | 91/10~95/ | Final Drive PINION |
| 03901 3345 | 90311-43001 | 43 x 70 x 9 x 15.5 | CROWN JZS171 (ATH,ATGV),175 | 99/9~ | Final Drive DIFF.SIDE |
| 03901 4561 | 90311-43001 | 43 x 70 x 9 x 15.5 | CROWN JZS155 ROY,ROYG,ROYT | 95/8~ | Final Drive DIFF.SIDE |
| 03901 4257 | 90311-47008 | 47 x 72 x 10 x 11 | CROWN JZS155,UZS15# (MAJESTA) | 95/8~ | Final Drive DIFF.SIDE |
| 03901 6181 | 90311-47008 | 47 x 72 x 10 x 11 | CROWN JZS177,UZS17# | 99/9~ | Final Drive DIFF.SIDE |
| 03901 5637 | 90311-19001 | 19 x 32 x 8 | CROWN RS#,YS#,GS#,MS#,LS# | 79/9~93/ | Steering (M/S) WORM GEAR |
| 03901 5097 | 90310-34006 | 34 x 48 x 8 | CROWN RS#,YS#,GS#,MS#,LS# | 79/9~93/ | Steering (M/S) SECTOR SHAFT |
| 03901 5223 | 04445-30070 | | CROWN RS110,GS11#,MS11#,LS11# | 79/9~83/ | Steering (P/S) GEAR GASKET KIT |
| 03901 6541 | 04445-30080 | | CROWN YS120,GS12#,MS12#,LS12# | 83/8~87/ | Steering (P/S) GEAR GASKET KIT |
| 03901 6593 | 04445-30101 | | CROWN YS130,GS13#,MS13# (EXC. 135,137),LS13# | 87/9~91/ | Steering (P/S) GEAR GASKET KIT |
| 03901 6141 | 04445-30091 | | CROWN MS137 | 87/9~89/8 | Steering (P/S) GEAR GASKET KIT |
| 03901 2735 | 04445-30091 | | CROWN MS135,137,UZS131 | 89/8~91/ | Steering (P/S) GEAR GASKET KIT |
| 03901 5175 | 04445-30110 | | CROWN JZS133,135,143,145 | 91/10~95/ | Steering (P/S) GEAR GASKET KIT |
| 03901 2783 | 90311-38029 | 38 x 55 x 7.5 | CROWN GS130,131 (SPC) | 87/9~91/10 | Transmission (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5139 | 04332-30030 | Kit | CROWN GS141,151 | 93/8~97/7 | Transmission (A/T) REAR EXTENTION |
| 03901 5073 | 90311-47008 | 47 x 72 x 10 x 11 | CROWN JZS147,149,UZS14# | 91/10~95/ | Final Drive DIFF.SIDE |
| 03901 4927 | 90311-38070 | 38 x 74 x 11 x 19 | CROWN GS171,JZS171,173,175,179 | 99/9~ | Final Drive PINION |
| 03901 5143 | 90311-38029 | 38 x 55 x 7.5 | CROWN JZS13#,MS135,137,UZS131 | 87/9~91/10 | Transmission (A/T) FRONT OIL PUMP |
| 03901 6233 | 90311-38029 | 38 x 55 x 7.5 | CROWN JZS130,131,133,135,LS130,131 | 91/10~99/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 5455 | 90311-38029 | 38 x 55 x 7.5 | CROWN JZS14#,LS141,UZS14# | 91/10~95/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7641 | 90311-38029 | 38 x 55 x 7.5 | CROWN JZS15#,LS151,UZS15# | 95/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7655 | 90311-38029 | 38 x 55 x 7.5 | CROWN JZS17#,UZS17# | 99/9~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 3991 | 04332-30030 | Kit | CROWN GS13#,LS136,YS130 | 91/10~99/ | Transmission (A/T) REAR EXTENTION |
| 03901 3653 | 90311-38032 | 38 x 58 x 11 | CROWN GS151,171 | 97/7~ | Transmission (A/T) REAR EXTENTION |
| 03901 1727 | 90311-40001 | 40 x 58 x 11 | CROWN JZS13#,MS135,137,UZS131 | 87/9~91/10 | Transmission (A/T) REAR EXTENTION |
| 03901 1541 | 90311-40001 | 40 x 58 x 11 | CROWN JZS130,131,133,135,LS130,131 | 91/10~ | Transmission (A/T) REAR EXTENTION |
| 03901 6667 | 90311-40001 | 40 x 58 x 11 | CROWN JZS141,143,145LS141 | 91/10~95/ | Transmission (A/T) REAR EXTENTION |
| 03901 3189 | 90311-38133 | 38 x 74 x 11 | CROWN GS141,JZS141,143,145,LS141 | 91/10~95/ | Final Drive PINION |
| 03901 5413 | 90311-38070 | 38 x 74 x 11 x 19 | CROWN GS151,JZS15# (EXC. MAJESTA),LS151 | 98/8~ | Final Drive PINION |
| 03901 7531 | 04332-30030 | Kit | CROWN YS130,GS13# (EXC. SPC),MS130,LS13# | 87/9~91/10 | Transmission (A/T) REAR EXTENTION |
| 03901 5157 | 90311-38133 | 38 x 74 x 11 | CROWN GS151,JZS15# (EXC. MAJESTA),LS151 | 95/8~98/8 | Final Drive PINION |
| 03901 2741 | 90311-40001 | 40 x 58 x 11 | CROWN JZS151,155 (EXC. MAJESTA),LS151 | 95/8~ | Transmission (A/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7459 | 90311-38133 | 38 x 74 x 11 | CROWN YS130,GS13#,MS13#,JZS130,LS13# | 87/9~99/ | Final Drive PINION |
| 03901 3647 | 90311-38133 | 38 x 74 x 11 | CROWN YS120,GS12#,MS12#,LS12# | 83/8~87/ | Final Drive PINION |
| 03901 4255 | 90311-38133 | 38 x 74 x 11 | CROWN RS110,GS11#,MS11#,LS11# | 79/9~83/ | Final Drive PINION |
| 03901 1473 | 90311-42024 | 42 x 55 x 10 | CROWN JZS155,UZS151,157 (MAJESTA) | 95/8~99/ | Transmission (A/T) REAR EXTENTION |
| 03901 2973 | 90311-42024 | 42 x 55 x 10 | CROWN JZS147,149,UZS141,147 | 91/10~95/ | Transmission (A/T) REAR EXTENTION |
| 03901 5031 | 90311-40001 | 40 x 58 x 11 | CROWN JZS171,175 | 99/9~ | Transmission (A/T) REAR EXTENTION |
| 03901 4755 | 90311-42024 | 42 x 55 x 10 | CROWN JZS177,UZS171,175 | 99/9~ | Transmission (A/T) REAR EXTENTION |
| 03901 8015 | 90311-85007 | 85 x 105 x 10 | CURREN 3SFE,4SFE ST20# | 94/2~98/ | Engine CRANK SHAFT REAR |
| 03901 7479 | 90311-19002 | 19 x 32 x 7 x 8 | CURREN ST20# | 94/2~98/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 8017 | 90310-28003 | 28 x 41 x 6.5 | CURREN ST207 | 94/2~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3283 | 90310-31001 | 31 x 44 x 6.5 | CURREN ST206,208 | 94/2~98/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3733 | 90311-35013 | 35 x 49 x 6 | CURREN 3SGE ST206 | 94/2~98/ | Engine CAM SHAFT |
| 03901 4867 | 90311-38036 | 38 x 50 x 8 | CURREN 3SFE,4SFE ST20# | 94/2~98/ | Engine CAM SHAFT |
| 03901 3911 | 90311-42026 | 42 x 60 x 7 | CURREN 3S#,4SFE ST20# | 94/2~96/9 | Engine CRANK SHAFT FRONT |
| 03901 3875 | 9031-89002 | 89 x 105 x 10 | CURREN 3SGE ST206 | 94/2~98/ | Engine CRANK SHAFT REAR |
| 03901 2953 | 90311-42035 | 42 x 60 x 7 | CURREN 3SFE,4SFE ST20# | 96/9~98/ | Engine CRANK SHAFT FRONT |
| 03901 3613 | 90913-02062 | | CURREN 3SFE,4SFE(EX.) | 94/2~98/ | Engine VALVE STEM SEAL |
| 03901 5961 | 90913-02104 | | CURREN 3SGE(EX.) | 94/2~98/ | Engine VALVE STEM SEAL |
| 03901 5449 | 04422-20010 | Kit | CURREN ST20#...WITHOUT ABS | 94/2~96/6 | Wheel Hub FRONT |
| 03901 6605 | 04445-20230 | | CURREN ST207 | 94/2~98/ | Steering (P/S) R & P GASKET KIT |
| 03901 7469 | 90311-42026 | 42 x 60 x 7 | CURREN 3SGE ST206 | 96/9~98/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5779 | 04445-20103 | | CURREN ST207 | 94/2~96/2 | Steering (P/S) R & P GASKET KIT |
| 03901 3157 | 04445-20180 | | CURREN ST206,208 | 94/2~98/ | Steering (P/S) R & P GASKET KIT |
| 03901 4581 | 90311-38020 | 38 x 55 x 8.5 | CURREN ST20# | 94/2~98/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 5955 | 90311-35033 | 35 x 55 x 9 x 15.5 | CURREN ST20# | 94/2~98/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 7539 | 90311-35033 | 35 x 55 x 9 x 15.5 | CURREN ST20# | 94/2~98/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 6253 | 90311-50010 | 50 x 80 x 16.5 x 23 | CURREN ST206 ZS | 94/2~95/9 | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 6859 | 90311-40004 | 40 x 56 x 9 x 15.5 | CURREN ST206 ZS | 94/2~95/9 | Mission & Differential (M/T) TRANSAXLE CASECOVER |
| 03901 5429 | 90311-35033 | 35 x 55 x 9 x 15.5 | CURREN ST20# | 94/2~98/ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 7567 | 90311-35033 | 35 x 55 x 9 x 15.5 | CURREN ST20# | 94/2~98/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 7905 | 90311-30006 | 30 x 42 x 7 | CURREN ST20# | 94/2~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 7427 | 04422-12121 | Kit | CURREN ST206 ZS ABS & SUPER STRUT SUS | 94/2~98/ | Wheel Hub FRONT |
| 03901 1559 | 04422-20080 | Kit | CURREN ST20#...WITH ABS | 94/2~98/ | Wheel Hub FRONT |
| 03901 5105 | 90913-02079 | | CURREN 3S#,4SFE(IN.) | 94/2~98/ | Engine VALVE STEM SEAL |
| 03901 2635 | 04422-12111 | Kit | CURREN ST206 ZS SUPER STRUT SUS. | 94/2~96/6 | Wheel Hub FRONT |
| 03901 1185 | 90311-56016 | 56 x 73 x 7.5 x 15 | CYNOS EL44,52,54 WITHOUT ABS | 91/1~96/ | Wheel Hub FRONT INNER |
| 03901 2063 | 04445-10030 | | CYNOS EL44 ALPHA | 91/1~95/ | Steering (P/S) R & P GASKET KIT |
| 03901 7679 | 90311-75009 | 75 x 100 x 8.5 | CYNOS 4E EL52 | 95/8~99/ | Engine CRANK SHAFT REAR |
| 03901 6955 | 90311-80012 | 80 x 100 x 8.5 | CYNOS ,5E EL44,54 | 91/8~99/ | Engine CRANK SHAFT REAR |
| 03901 4539 | 90311-35040 | 35 x 49 x 6 | CYNOS 4E,5E EL44,52,54 | 96/4~99/ | Engine CRANK SHAFT FRONT |
| 03901 7829 | 90311-54003 | 54 x 66 x 7.5 x 10 | CYNOS EL44,52,54 | 91/1~99/ | Wheel Hub FRONT OUTER |
| 03901 5113 | 90029-21020 | 20 x 32 x 5 | CYNOS 4E,5E EL44,52,54 | 91/1~99/ | Engine OIL PUMP |
| 03901 8033 | 90311-35013 | 35 x 49 x 6 | CYNOS 4E,5E EL44,52,54 | 91/1~99/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3643 | 90311-26003 | 26 x 38 x 6.5 | CYNOS EL44,52,54 | 91/1~99/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6503 | 90311-19010 | 19 x 32 x 6 | CYNOS EL44,52,54 | 91/1~99/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5947 | 04445-16110 | | CYNOS EL52,54 | 95/12~99/ | Steering (P/S) R & P GASKET KIT |
| 03901 1603 | 90913-02062 | | CYNOS 4E,5E (IN. & EX.) | 91/1~99/ | Engine VALVE STEM SEAL |
| 03901 6325 | 04445-10040 | | CYNOS EL44 BETA | 91/1~95/ | Steering (P/S) R & P GASKET KIT |
| 03901 2023 | 90311-80003 | 80 x 100 x 8.5 | CYNOS 5E EL44 | 91/1~91/8 | Engine CRANK SHAFT REAR |
| 03901 1187 | 90311-38020 | 38 x 55 x 8.5 | CYNOS EL44,52,54 | 91/1~99/ | Mission & Differential (A/T) FRONT PUMP |
| 03901 7925 | 90311-34012 | 34 x 54 x 9 x 15.5 | CYNOS EL44,52,54 | 91/1~99/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 6647 | 90311-34012 | 34 x 54 x 9 x 15.5 | CYNOS EL52 | 95/8~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 6341 | 90311-34013 | 34 x 63 x 9 x 15 | CYNOS EL44,54 | 91/1~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3973 | 90311-50015 | 50 x 68 x 9 x 14.5 | CYNOS EL44,52,54 WITH LSD | 91/1~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2633 | 90311-34016 | 34 x 54 x 9 x 15.5 | CYNOS EL44,52,54 | 91/1~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 6837 | 90311-34017 | 34 x 63 x 9 x 16 | CYNOS EL44,52,54 | 91/1~99/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 5415 | 90311-25011 | 25 x 37 x 8 | CYNOS EL44,52,54 | 91/1~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1903 | 90311-38037 | 38 x 52 x 7 | CYNOS EL44,52,54 | 91/1~99/ | Wheel Hub REAR |
| 03901 1405 | 90311-56017 | 56 x 73 x 88.5 x 21.5 | CYNOS EL44,52,54 WITH ABS | 91/1~99/ | Wheel Hub FRONT INNER |
| 03901 1493 | 04445-16090 | | CYNOS EL52,54 | 95/8~95/12 | Steering (P/S) R & P GASKET KIT |
| 03901 6875 | 90311-35013 | 35 x 49 x 6 | CYNOS 4E,5E EL44,52,54 | 91/1~96/4 | Engine CRANK SHAFT FRONT |
| 03901 6989 | 90048-12021-000 | | DUET EJ#,K3VE M100,101,110,111 | 98/9~ | Engine VALVE STEM SEAL |
| 03901 2225 | 90043-11316-000 | 45 x 70 x 12 x 18.5 | DUET M10#,11# | 98/9~ | Mission & Differential (A/T) TRANSAXLE CASE (LH) |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5593 | 90043-11317-000 | 45 x 62 x 11 x 18 | DUET M10# | 98/9~ | Mission & Differential (A/T) TRANSAXLE CASE (RH) |
| 03901 4449 | 90043-11337-000 | 38 x 52 x 6.2 | DUET EJ#...M100,110 | 98/9~ | Engine CAM SHAFT |
| 03901 6549 | 90043-11284-000 | 32 x 46 x 6 | DUET EJ#...M100,110 | 98/9~ | Engine CRANK SHAFT FRONT |
| 03901 6911 | 90311-35040 | 35 x 49 x 6 | DUET K3VE M101,111 | 00/5~ | Engine TIMING GEAR COVER |
| 03901 8109 | 90043-11283-000 | 58 x 74 x 10 | DUET EJ#...M100,110 | 98/9~00/6 | Engine CRANK SHAFT REAR |
| 03901 1795 | 90043-11292-000 | 73.5 x 89 x 8.5 | DUET K3VE M101,111 | 00/5~ | Engine CRANK SHAFT REAR |
| 03901 7731 | 90043-11317-000 | 45 x 62 x 11 x 18 | DUET M10# | 98/9~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4543 | 90043-11312-000 | 35 x 54 x 10.5 | DUET M11# (4WD) | 98/9~ | Wheel Hub REAR |
| 03901 3419 | 90043-10035-000 | 25 x 35 x 6 | DUET M10#,11# | 98/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 1265 | 90043-11316-000 | 45 x 70 x 12 x 18.5 | DUET M10#,11# | 98/9~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 5805 | 90043-11323-000 | 58 x 74 x 10 | DUET EJ#...M100,110 | 00/6~ | Engine CRANK SHAFT REAR |
| 03901 3317 | 9828-79102 | 79 x 114 x 17 | DYNA 350 J05C FB4J# | 95/5~99/ | Engine TIMING GEAR COVER |
| 03901 6147 | S1371-91470 | | DYNA 351 F05C | 98/2~99/ | Engine VALVE STEM SEAL |
| 03901 7251 | S1371-91360 | | DYNA 352 F05C | 95/5~98/1 | Engine VALVE STEM SEAL |
| 03901 3521 | 90913-02096 | | DYNA 353 15B | 99/3~99/5 | Engine VALVE STEM SEAL |
| 03901 2491 | 90913-02108 | | DYNA 354 15B | 95/5~99/3 | Engine VALVE STEM SEAL |
| 03901 4265 | 90311-95008 | 95 x 115 x 9.5 x 12 | DYNA 355 15B FB5#,FB4JEAT(DF3,EF3,UF3,VF3,XB,XB3) | 95/5~99/ | Engine CRANK SHAFT REAR |
| 03901 1765 | 90311-50013 | 50 x 72 x 9 x 14 | DYNA 356 15B FB5#,FB4JEAT(DF3,EF3,UF3,VF3,XB,XB3) | 95/5~99/ | Engine TIMING GEAR COVER |
| 03901 2043 | 9828-58113 | 58 x 102 x 7.8 x 21.8 | DYNA 357 FB4J#,FB5B# | 98/8~99/ | Final Drive REAR DIFF. PINION |
| 03901 3219 | 9828-58109 | 58 x 102 x 8 x 22 | DYNA 358 FB4J#,FB5B# | 95/5~98/7 | Final Drive REAR DIFF. PINION |
| 03901 5141 | 90311-48011 | 48 x 62 x 9 | DYNA 359 FB4J#,FB5BC#,FB5BEAT#, FB5BGAT# | 95/5~99/ | Transmission REAR OUTPUT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3371 | 90311-35023 | 35 x 48 x 6.5 | DYNA 360 FB4J#,FB5BC#,FB5BEAT#, FB5BGAT# | 95/5~99/ | Transmission FRONT COVER |
| 03901 5623 | 9828-57103 | 57 x 124 x 13 | DYNA 361 FB4JC#,FB4JEAT(AB,AB3, AC4,AE4,BB,BB3,DF3,EF3, FB3, | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 1533 | 9828-48112 | 48 x 109 x 13 | DYNA 362 FB4JEAT,GAT(AA,AA3,BA ,BA3,RA,RA3,SA,SA3),FB5 BC#, | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 3671 | 9828-01203 | 127 x 147 x 11 | DYNA 363 FB4JC#,FB4JEAT(AB,AB3, AC4,AE4,BB,BB3,DF3,EF3, FB3, | 95/5~99/ | Wheel Hub REAR INNER |
| 03901 1119 | 9828-01137 | 101 x 114 x 10 | DYNA 364 FB4JEAT(DF3,EF3,UF3,VF3 ),FB4JGAK# | 95/5~99/ | Wheel Hub FRONT |
| 03901 8221 | 9828-85106 | 84 x 100 x 10 | DYNA 365 FB5B# | 95/5~99/ | Wheel Hub FRONT |
| 03901 3275 | 9828-85106 | 84 x 100 x 10 | DYNA 366 FB4J#...EXC. FB4JEAT(DF3,EF3,UF3,VF3 ),FB4JGAK | 95/5~99/ | Wheel Hub FRONT |
| 03901 7863 | 9828-01206 | 107 x 123 x 11 | DYNA 367 FB4JEAT,GAT(AA,AA3,BA ,BA3,RA,RA3,SA,SA3),FB5 BC#, | 95/5~99/ | Wheel Hub REAR INNER |
| 03901 5521 | 9828-01228 | 100 x 135 x 15 | DYNA 368 J05C FB4J# | 95/5~99/ | Engine CRANK SHAFT REAR |
| 03901 7125 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU6#,7#,8#...EXCEPT DM1,DM4,275T,3T,TD,DTP | 84/9~87/8 | Wheel Hub REAR OUTER |
| 03901 7151 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU100.105,107,112,12#,13#, 14#...(TR,V) (175T,20T) | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 2385 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE WU85 T3 20T(10.5INCH DIFF) | 89/10~95/ | Wheel Hub REAR OUTER |
| 03901 4175 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU88 (T2,T3,T4,DM2,DM5) (20T,175T) | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 1073 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU87 VAN,20T | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 8093 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU67 TRUCK, BU72 FULL JUST LOW | 88/8~95/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3547 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU66 EXCEPT D/CAB,STANDARD DMP | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 7553 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU60,61,70,80,81,83,84 | 87/8~95/ | Wheel Hub REAR OUTER |
| 03901 7411 | 90311-19001 | 19 x 32 x 8 | DYNA, TOYO ACE BU6#,7#,8# | 84/9~95/ | Steering (M/S) WORM GEAR |
| 03901 3165 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE YU6#,70,80 | 84/9~95/ | Wheel Hub REAR OUTER |
| 03901 6823 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU20,HU30 | 77/8~84/ | Wheel Hub REAR OUTER |
| 03901 2861 | 9828-01203 | 127 x 147 x 11 | DYNA, TOYO ACE BU410,420,430,XZU400,401,41#,42#,430 295T~40T | 99/5~ | Wheel Hub REAR INNER |
| 03901 6017 | 9828-01203 | 127 x 147 x 11 | DYNA, TOYO ACE XZU330,340,350 35T,40T | 99/6~ | Wheel Hub REAR INNER |
| 03901 4709 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU62,82,85,93 20T DSL,BU64 T3 | 87/8~88/8 | Wheel Hub REAR OUTER |
| 03901 1013 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU202,212,222,RZU140 (TR,V) (175T,20T) | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 6713 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU172,182 T4 | 95/5~ | Wheel Hub REAR OUTER |
| 03901 3775 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU30#,346,RZU300,340,XZU302,307,322,337,351,352 | 99/5~ | Wheel Hub REAR OUTER |
| 03901 2343 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU100,102,112,162,XZU130 DM3,DM6,DM7,DM8,TW1 | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 3711 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU68,73,74,78,85,94,WU85,93 | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 4743 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU67 DMP,BU72 DM3,DM4,T3 | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 7023 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU66 D/CAB,STANDARD DMP | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 1055 | 90311-88102 | 88 x 115 x 13 | DYNA, TOYO ACE BU90,91,95,96,WU75,90,95 | 84/9~95/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2017 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU66,87 275T,3T | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 5909 | 90311-75008 | 75 x 95 x 9.5 x 14 | DYNA, TOYO ACE XZU362,37#,382 (4WD) | 99/5~ | Wheel Hub FRONT |
| 03901 5283 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU62,82,85,93,98 275T,3T,BU64 DMP | 87/8~88/8 | Wheel Hub REAR OUTER |
| 03901 4459 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU62,64,82,85 DM1,DM4,275T,3T,TD,DTP | 84/9~87/8 | Wheel Hub REAR OUTER |
| 03901 8057 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE XZU402,411 T2,XZU412 SCB (T2,T5) | 99/5~ | Wheel Hub REAR OUTER |
| 03901 2691 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE XZU306 T4,XZU347 T2 | 99/5~ | Wheel Hub REAR OUTER |
| 03901 2495 | 90310-38033 | 38 x 44 x 18 | DYNA, TOYO ACE BU102,162,RZU100 (DM1,DM5,T2,T3,TW1,TW4 ) 20T | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 5087 | 9828-01137 | 101 x 114 x 10 | DYNA, TOYO ACE BU90,91,95,96,WU75,90,95 | 84/9~95/ | Wheel Hub FRONT |
| 03901 7725 | 04445-36110 | | DYNA, TOYO ACE BU102 T4 30T | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 4955 | 04445-36110 | | DYNA, TOYO ACE BU142 T3 20T | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 4465 | 04445-36110 | | DYNA, TOYO ACE RZU100 DM6 | 95/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7463 | 04445-36110 | | DYNA, TOYO ACE BU60 T3 WT,BU87 TW1,T3 | 94/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3993 | 04445-36110 | | DYNA, TOYO ACE BU66 (DM1,DM2,DM3,TW1,T3) WT | 94/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1289 | 04445-36110 | | DYNA, TOYO ACE BU68,78,88,9# | 94/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7871 | 90311-68001 | 68 x 90 x 10 | DYNA, TOYO ACE BU6#,70,78,8#,93,94,98,YU6 #,70,80,WU85,93 | 84/9~95/ | Wheel Hub FRONT |
| 03901 4015 | 90311-68001 | 68 x 90 x 10 | DYNA, TOYO ACE BU10#,112,12#,13#,14#,202, 212,222,XZU130,140 | 95/5~99/ | Wheel Hub FRONT |
| 03901 4433 | 90311-68001 | 68 x 90 x 10 | DYNA, TOYO ACE RZU100,140 | 95/5~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1059 | 90311-68002 | 68 x 92 x 9.7 | DYNA, TOYO ACE BU30#,346,RZU300,340,XZU30#,31#,32#,33#,34#,35# | 99/5~03/3 | Wheel Hub FRONT |
| 03901 2813 | 90311-68002 | 68 x 92 x 9.7 | DYNA, TOYO ACE BU400,410,420,XZU402,411,412,421 20T | 99/5~ | Wheel Hub FRONT |
| 03901 7931 | 90311-68002 | 68 x 92 x 9.7 | DYNA, TOYO ACE BU301,RZU300,340,XZU300,301,302,31#,32#,330,331 | 03/3~ | Wheel Hub FRONT |
| 03901 1081 | 42404-36010 | 75 x 108 x 20 | DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU20,HU30 | 77/8~84/ | Wheel Hub REAR INNER |
| 03901 4629 | 9828-01137 | 101 x 114 x 10 | DYNA, TOYO ACE BU40,41,5#,HU26,40,50,WU26,40,50 | 82/4~84/ | Wheel Hub FRONT |
| 03901 4149 | 90311-88102 | 88 x 115 x 13 | DYNA, TOYO ACE BU40,41,5#,HU26,40,50,WU26,40,50 | 82/4~84/ | Wheel Hub REAR INNER |
| 03901 2585 | 9828-01137 | 101 x 114 x 10 | DYNA, TOYO ACE BU410,420,430,XZU400,401,41#,42#,430 195T~40T | 95/5~ | Wheel Hub FRONT |
| 03901 5645 | 90311-75008 | 75 x 95 x 9.5 x 14 | DYNA, TOYO ACE BU72,73,74 (4WD) | 89/10~95/ | Wheel Hub FRONT |
| 03901 1529 | 90311-75008 | 75 x 95 x 9.5 x 14 | DYNA, TOYO ACE BU162,172,182 (4WD) | 95/5~99/ | Wheel Hub FRONT |
| 03901 8165 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE BU6#,7#,8#,9# | 84/9~85/8 | Transmission REAR EXTENTION |
| 03901 4161 | 90311-37001 | 37 x 58 x 11 | DYNA, TOYO ACE BU72,73,74,162,172,182,XZU362,37#,382 | 89/10~ | Wheel Hub FRONT AXLE HOUSING |
| 03901 3493 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU102,132,142,212,RZU100,XZU140 275T,30T | 95/5~ | Wheel Hub REAR OUTER |
| 03901 1571 | 90311-75003 | 75 x 108 x 10 x 20 | DYNA, TOYO ACE BU6#,7#,8#,93,94,98,YU6#,70,80,WU85,93 | 84/9~95/ | Wheel Hub REAR INNER |
| 03901 2721 | 90311-75003 | 75 x 108 x 10 x 20 | DYNA, TOYO ACE BU10#,112,12#,13#,14#,162,172,182,202,212,222 | 95/5~99/ | Wheel Hub REAR INNER |
| 03901 3141 | 90311-75003 | 75 x 108 x 10 x 20 | DYNA, TOYO ACE XZU130,140 | 95/5~99/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4775 | 90311-75003 | 75 x 108 x 10 x 20 | DYNA, TOYO ACE RZU100,140 | 95/5~ | Wheel Hub REAR INNER |
| 03901 1069 | 90311-78001 | 78 x 115 x 10 x 19 | DYNA, TOYO ACE BU30#,346,RZU300,340 | 99/5~ | Wheel Hub REAR INNER |
| 03901 3817 | 90311-78001 | 78 x 115 x 10 x 19 | DYNA, TOYO ACE XZU30#,31#,32#,33#,34#,35#,362,37#,382 175T~30T | 95/5~ | Wheel Hub REAR INNER |
| 03901 5011 | 90311-78001 | 78 x 115 x 10 x 19 | DYNA, TOYO ACE BU400,410,420,XZU402,411,412,421 20T | 95/5~ | Wheel Hub REAR INNER |
| 03901 6695 | 90311-68003 | 68 x 92 x 10 x 13.5 | DYNA, TOYO ACE BU306,346,XZU306,307,337,346,347 | 03/3~ | Wheel Hub FRONT |
| 03901 6145 | 90311-28004 | 28.6 x 43 x 6.5 | DYNA, TOYO ACE BU62,85,9#...TD,IV4 | 84/9~85/8 | Transmission FRONT COVER |
| 03901 6025 | 04445-36110 | | DYNA, TOYO ACE BU212,222,XZU140 | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7939 | 90311-35023 | 35 x 48 x 6.5 | DYNA, TOYO ACE BU132,XZU130,140 (DM2,T3,TL4) 5F | 99/5~99/ | Transmission FRONT COVER |
| 03901 3495 | 90311-35023 | 35 x 48 x 6.5 | DYNA, TOYO ACE BU102,212,222 20T (LPG,TD) 5F | 99/5~99/ | Transmission FRONT COVER |
| 03901 5117 | 90311-35023 | 35 x 48 x 6.5 | DYNA, TOYO ACE BU102,112,142 275T,30T | 99/5~99/ | Transmission FRONT COVER |
| 03901 2903 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE XZU301,341,342,346,347,362,372,382 DM3,DM5,DM6,DM7 | 99/5~ | Wheel Hub REAR OUTER |
| 03901 1281 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU301,346,XZU306,31#,320,321,330,371 (DM5,DM6,DM7, | 99/5~ | Wheel Hub REAR OUTER |
| 03901 6283 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU400,410,420,XZU402,411,412,421 (T4,T5) 20T | 99/5~ | Wheel Hub REAR OUTER |
| 03901 6477 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE XZU382 | 99/5~ | Wheel Hub REAR OUTER |
| 03901 8257 | 90310-41001 | 41 x 47 x 17 | DYNA, TOYO ACE BU40,41,5#,HU26,40,50,WU26,40,50 | 82/4~84/ | Wheel Hub REAR OUTER |
| 03901 5149 | 90310-41001 | 41 x 47 x 17 | DYNA, TOYO ACE BU90,91,95,96,WU75,90,95 | 84/9~95/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6397 | 9828-57103 | 57 x 124 x 13 | DYNA, TOYO ACE XZU330,340,350 35T,40T | 99/6~ | Wheel Hub REAR OUTER |
| 03901 4203 | 9828-57103 | 57 x 124 x 13 | DYNA, TOYO ACE BU410,420,430,XZU400,401 ,41#,42#,430 295T~40T | 99/5~ | Wheel Hub REAR OUTER |
| 03901 5247 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU6#,70,8#,9#...(CBU,IV3) | 85/9~88/8 | Transmission REAR EXTENTION |
| 03901 5441 | 90311-28004 | 28.6 x 43 x 6.5 | DYNA, TOYO ACE RU2#,HU26,30,40,50,WU26, 40,50 H50 | 77/8~84/ | Transmission FRONT COVER |
| 03901 1327 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU6#...EXC. BU66 TW1 | 88/8~95/ | Transmission REAR EXTENTION |
| 03901 2021 | 90311-28004 | 28.6 x 43 x 6.5 | DYNA, TOYO ACE BU62 IV4 | 85/8~87/8 | Transmission FRONT COVER |
| 03901 6623 | 90311-28004 | 28.6 x 43 x 6.5 | DYNA, TOYO ACE BU62,66 TW1 | 87/8~95/ | Transmission FRONT COVER |
| 03901 1709 | 90311-28004 | 28.6 x 43 x 6.5 | DYNA, TOYO ACE WU75,90,95 | 84/9~95/ | Transmission FRONT COVER |
| 03901 5477 | 90311-32106 | 32 x 48 x 8 | DYNA, TOYO ACE BU20,22,30,33,35,RU2#,3#,J U20 M50,M51 | 77/8~84/ | Transmission FRONT COVER |
| 03901 3125 | 90311-32106 | 32 x 48 x 8 | DYNA, TOYO ACE YU60,70,80 | 84/9~85/8 | Transmission FRONT COVER |
| 03901 3139 | 90311-32106 | 32 x 48 x 8 | DYNA, TOYO ACE BU6#,70,8#...DSL (CBU,IV3) | 84/9~85/8 | Transmission FRONT COVER |
| 03901 1631 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE YU6#,70,80 | 85/8~95/ | Transmission FRONT COVER |
| 03901 2777 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE BU6#,70,8#,9#...(CBU,IV3) | 85/8~88/8 | Transmission FRONT COVER |
| 03901 7043 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE BU6#...EXC. BU66 TW1 | 88/8~95/ | Transmission FRONT COVER |
| 03901 6829 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE BU7#,8#,9# | 88/8~95/ | Transmission FRONT COVER |
| 03901 3757 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE WU85,93 | 88/8~95/ | Transmission FRONT COVER |
| 03901 7521 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE BU10#,112,12#.13#,14#,162, 202,212,222,RZU140 (175T | 95/5~ | Transmission FRONT COVER |
| 03901 5109 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE BU172,182,RZU100 | 95/5~ | Transmission FRONT COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2643 | 90311-28004 | 28.6 x 43 x 6.5 | DYNA, TOYO ACE BU2#,30,31,32,34,35,36,37 H50,H51 | 77/8~84/ | Transmission FRONT COVER |
| 03901 3645 | 90311-35023 | 35 x 48 x 6.5 | DYNA, TOYO ACE XZU30#,31#,32#,33#,34#,35 #,362,37#,382 | 99/5~ | Transmission FRONT COVER |
| 03901 4353 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE RZU100 DM6 | 95/5~ | Wheel Hub REAR OUTER |
| 03901 5721 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU212,222 TD | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 1179 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU212 (T3,T4,TW1,TW4) DSL ABS | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 4133 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU172,182 T3,TW1 | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 5577 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE RZU300,XZU300,331,340 30T | 99/5~ | Wheel Hub REAR OUTER |
| 03901 4163 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE XZU302 (T4,T5) (295T,30T) | 99/5~ | Wheel Hub REAR OUTER |
| 03901 2769 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE XZU302,322 DM3,DM6,DM7,DM8,T3 | 99/5~ | Wheel Hub REAR OUTER |
| 03901 7247 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE BU62,66 TW1 | 87/8~95/ | Transmission REAR EXTENTION |
| 03901 3185 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE BU62 IV4 | 85/8~87/8 | Transmission REAR EXTENTION |
| 03901 5935 | 90311-32012 | 32 x 53 x 7 | DYNA, TOYO ACE BU30#,346,RZU300,340 | 99/5~ | Transmission FRONT COVER |
| 03901 1339 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE YU60,70,80 | 84/9~85/8 | Transmission REAR EXTENTION |
| 03901 3389 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE HU26,30,40,50,WU26,40,50 | 77/8~84/ | Transmission REAR EXTENTION |
| 03901 7149 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE YU6#,70,80 | 85/8~95/ | Transmission REAR EXTENTION |
| 03901 4091 | 90311-35023 | 35 x 48 x 6.5 | DYNA, TOYO ACE BU400,410,420,430,XZU382 ,40#,41#,42#,430 | 99/5~ | Transmission FRONT COVER |
| 03901 6905 | 90310-40001 | 40 x 46 x 18 | DYNA, TOYO ACE BU142,147 T3 20T ABS | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 1009 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE WU75,90,95 | 84/9~95/ | Transmission REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5181 | 90311-48018 | 48 x 62 x 9 | DYNA, TOYO ACE BU162,172,182,XZU362,37#,382 | 96/5~ | Transfer CASE |
| 03901 2475 | 90311-48003 | 48 x 62 x 8 | DYNA, TOYO ACE BU162,172,182 | 95/5~96/5 | Transfer CASE |
| 03901 3981 | 90311-48003 | 48 x 62 x 8 | DYNA, TOYO ACE XZU362,37#,382 (4WD) | 99/7~ | Transmission REAR EXTENTION |
| 03901 7559 | 90311-48003 | 48 x 62 x 8 | DYNA, TOYO ACE BU162,172,182 (4WD) | 95/5~99/ | Transmission REAR EXTENTION |
| 03901 5793 | 90311-48003 | 48 x 62 x 8 | DYNA, TOYO ACE BU72,73,74 | 89/10~95/ | Transmission REAR EXTENTION |
| 03901 8207 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU400,410,420,430,XZU40#,41#,42#,430 | 99/5~ | Transmission REAR EXTENTION |
| 03901 4313 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE XZU30#,31#,32#,33#,34#,35# | 99/5~ | Transmission REAR EXTENTION |
| 03901 4093 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU30#,346,RZU300,400 | 99/5~ | Transmission REAR EXTENTION |
| 03901 6051 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE RZU100,140,XZU130,140 | 95/5~ | Transmission REAR EXTENTION |
| 03901 4087 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU10#,112,12#,14#,202,212,222 5F | 95/5~99/ | Transmission REAR EXTENTION |
| 03901 1601 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU70,8#,9# | 88/8~95/ | Transmission REAR EXTENTION |
| 03901 4231 | 90311-35023 | 35 x 48 x 6.5 | DYNA, TOYO ACE BU212,222 6F | 99/5~99/ | Transmission FRONT COVER |
| 03901 1745 | 90311-45001 | 45 x 62 x 9 | DYNA, TOYO ACE BU2#,3#,4#,RU2#,3#,JU20 | 77/8~84/ | Transmission REAR EXTENTION |
| 03901 6405 | 90913-02028 | | DYNA, TOYO ACE 2J,H(IN.) JU20,HU30 | 77/8~78/12 | Engine VALVE STEM SEAL |
| 03901 5063 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU72 DM3,DM4,T3,BU87,88 275T,3T | 88/8~89/8 | Final Drive REAR DIFF. PINION |
| 03901 5363 | 90033-11033 | 64 x 114 x 9 x 24.8 | DYNA, TOYO ACE XZU400,410,420,430 40T | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 6909 | 90311-18010 | 18 x 30 x 8 | DYNA, TOYO ACE BU20,30,RU20,30,JU20 ST,T2,TW2 | 77/8~82/4 | Steering (M/S) WORM GEAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3667 | 90311-22103 | 22 x 36 x 8 | DYNA, TOYO ACE BU20,25,30,RU20,30,HU30 EXCEPT ST,T2 | 77/8~79/4 | Steering (M/S) WORM GEAR |
| 03901 4027 | 90311-22103 | 22 x 36 x 8 | DYNA, TOYO ACE BU20 BTP,CTP,DTP,RU20 BTP | 79/4~82/4 | Steering (M/S) WORM GEAR |
| 03901 3391 | 90311-22103 | 22 x 36 x 8 | DYNA, TOYO ACE BU2#,3#,RU2#,3#,JU20 EXCEPT ST,T2 | 79/4~82/4 | Steering (M/S) WORM GEAR |
| 03901 2985 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE XZU410,420 4FC | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 4513 | 90913-02096 | | DYNA, TOYO ACE 15BFTE BU400,410,420,430 | 99/8~ | Engine VALVE STEM SEAL |
| 03901 4953 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE BU420,430 T4,T5 | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 1197 | 90913-02044 | | DYNA, TOYO ACE 2J,H(EX.) JU20,HU30 | 77/8~78/12 | Engine VALVE STEM SEAL |
| 03901 6917 | 90913-02044 | | DYNA, TOYO ACE 2H(IN. & EX.) HU26,40,50 | 78/12~83/ | Engine VALVE STEM SEAL |
| 03901 1663 | 90913-02016 | | DYNA, TOYO ACE 1W WU75,85,9# | 83/4~95/ | Engine VALVE STEM SEAL |
| 03901 2423 | 90038-12003 | | DYNA, TOYO ACE JO5C XZU130,140 | 95/10~98/2 | Engine VALVE STEM SEAL |
| 03901 8225 | 90038-12004 | | DYNA, TOYO ACE JO5C XZU130,140 | 98/2~99/ | Engine VALVE STEM SEAL |
| 03901 2485 | 90038-12004 | | DYNA, TOYO ACE J05C,S05#...XZU30#,31#,32#,33#,341,342,346,347,35# | 99/5~ | Engine VALVE STEM SEAL |
| 03901 5379 | 90311-68001 | 68 x 90 x 10 | DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU20,HU30 | 77/8~84/ | Wheel Hub FRONT |
| 03901 6417 | 90311-22103 | 22 x 36 x 8 | DYNA, TOYO ACE BU36,37,45,46 | 82/4~84/ | Steering (M/S) WORM GEAR |
| 03901 6725 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU212 T3,T4,TW1,TW4,BU222 TD | 95/5~99/ | Final Drive REAR DIFF. PINION |
| 03901 6367 | 90311-19001 | 19 x 32 x 8 | DYNA, TOYO ACE BU2#,30,32,33,34,RU22,32 | 82/4~84/ | Steering (M/S) WORM GEAR |
| 03901 5027 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU88 T4,BU88 20T TD | 89/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 7911 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU66,87,88 275T | 89/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 4817 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU66,87,88 T3 30T | 89/8~95/ | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8147 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU102,132,142,212,RZU100, XZU140 275T,30T | 95/5~ | Final Drive REAR DIFF. PINION |
| 03901 4551 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU100,102,112,162,XZU130 DM3,DM6,DM7,DM8,TW1 | 95/5~99/ | Final Drive REAR DIFF. PINION |
| 03901 7181 | 90033-11033 | 64 x 114 x 9 x 24.8 | DYNA, TOYO ACE BU420,430 T3 | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 4205 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU172,182 T3,TW1 | 95/5~99/ | Final Drive REAR DIFF. PINION |
| 03901 4759 | 90311-19001 | 19 x 32 x 8 | DYNA, TOYO ACE YU6#,70,80 | 84/9~95/ | Steering (M/S) WORM GEAR |
| 03901 8011 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE RZU300,XZU300,331,340 30T,35T,40T | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 2231 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE XZU301,341,342,346,347,36 2,372,382 DM3,DM5,DM6,DM7 | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 5331 | 04445-36110 | | DYNA, TOYO ACE BU87 V | 94/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2395 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE BU301,346,XZU306,31#,320 ,321,330,350,371 (DM5,DM6, | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 7919 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE XZU302 (T4,T5) (295T,30T) | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 5803 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE XZU302,322 DM3,DM6,DM7,DM8,T3 | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 2883 | 90311-58010 | 58 x 102 x 11 x 19.5 | DYNA, TOYO ACE BU400,410,XZU382,40#,41# ,42#,430 (T3,T4,T5) (20T, | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 3007 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU142,147 T3 20T | 95/5~99/ | Final Drive REAR DIFF. PINION |
| 03901 5939 | 04445-36070 | | DYNA, TOYO ACE BU67 DMP | 88/8~94/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5041 | 04445-36060 | | DYNA, TOYO ACE BU60,66 T2,T4,TW4,BU66 ST | 90/1~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2901 | 04445-36060 | | DYNA, TOYO ACE BU60,T3 ST | 90/1~95/ | Steering (P/S) P/S GEAR GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2845 | 04445-36060 | | DYNA, TOYO ACE YU60 TW1,TW2,T2,T3 | 93/5~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6843 | 04445-36060 | | DYNA, TOYO ACE YU60 DYN T1 CBU | 93/5~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6281 | 04445-36060 | | DYNA, TOYO ACE BU100,102 T3 ST | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2233 | 04445-36060 | | DYNA, TOYO ACE BU112,12#,132,RZU140 (TR,V) 20T | 95/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5825 | 90311-22103 | 22 x 36 x 8 | DYNA, TOYO ACE BU77,85,93,98 | 84/9~87/ | Steering (M/S) WORM GEAR |
| 03901 2355 | 04445-36060 | | DYNA, TOYO ACE BU100,102,140,142 (DM5,T1,T2,T4,TW2,TW4) (175T,20T | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1851 | 04445-36060 | | DYNA, TOYO ACE BU87 T2,T4,B67 TR | 90/1~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6053 | 04445-36070 | | DYNA, TOYO ACE WU75,85,9#,YU61 | 88/8~94/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1993 | 04445-36070 | | DYNA, TOYO ACE BU87 V | 88/8~94/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 4065 | 04445-36070 | | DYNA, TOYO ACE BU68,78,85,88,9# | 88/8~94/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5293 | 04445-36070 | | DYNA, TOYO ACE BU66 (DM1,DM2,DM3,TW1,T3) WT | 88/8~94/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1983 | 04445-36070 | | DYNA, TOYO ACE BU60 T3 WT,BU87 TW1,T3 | 88/8~94/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6893 | 04445-36110 | | DYNA, TOYO ACE BU67 DMP | 94/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6075 | 04445-36110 | | DYNA, TOYO ACE WU75,85,9# | 94/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3073 | 04445-36060 | | DYNA, TOYO ACE RZU100 (DM5,T2,T3,T4,TW1,TW4) 20T | 95/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7593 | 90311-38033 | 38 x 52 x 9 | DYNA, TOYO ACE BU85,88 (T2,T3) 5F 20T DSL | 87/8~95/ | Steering (M/S) SECTOR SHAFT |
| 03901 7923 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU68,73,74,78,85,90,91,94,95,96 | 88/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 7259 | 90311-18010 | 18 x 30 x 8 | DYNA, TOYO ACE BU85 (T2,T3) 5F 20T DSL | 87/8~95/ | Steering (M/S) WORM GEAR |
| 03901 5771 | 90311-32014 | 32 x 44 x 9 | DYNA, TOYO ACE BU20,30,RU20,30,JU20 ST.T2.TW2 | 77/8~82/4 | Steering (M/S) SECTOR SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6187 | 90311-36104 | 36 x 50 x 7 | DYNA, TOYO ACE BU20,25,30,RU20,30,HU30 EXCEPT ST,T2 | 77/8~79/4 | Steering (M/S) SECTOR SHAFT |
| 03901 5359 | 90311-36104 | 36 x 50 x 7 | DYNA, TOYO ACE BU20 BTP,CTP,DTP,RU20 BTP | 79/4~82/4 | Steering (M/S) SECTOR SHAFT |
| 03901 5339 | 90311-36104 | 36 x 50 x 7 | DYNA, TOYO ACE BU2#,3#,RU2#,3#,JU20 EXCEPT ST,T2 | 79/4~82/4 | Steering (M/S) SECTOR SHAFT |
| 03901 6211 | 90311-36104 | 36 x 50 x 7 | DYNA, TOYO ACE BU2#,3#,45,46,RU22,32 | 82/4~84/ | Steering (M/S) SECTOR SHAFT |
| 03901 1629 | 04445-36060 | | DYNA, TOYO ACE BU66 DM5,BU60 T1,TW1,TW2 | 90/1~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7787 | 90311-36104 | 36 x 50 x 7 | DYNA, TOYO ACE BU6#,7#,8# | 84/9~95/ | Steering (M/S) SECTOR SHAFT |
| 03901 4897 | 04445-36060 | | DYNA, TOYO ACE BU61,70,83,84 | 90/1~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2373 | 04445-36060 | | DYNA, TOYO ACE BU61,67,83,84 TR | 88/8~90/1 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7727 | 04445-36060 | | DYNA, TOYO ACE YU60,70 T1,T2,T3,TW2,SRF | 88/8~90/1 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7013 | 04445-36060 | | DYNA, TOYO ACE BU60,87 T1,T2,T4,TW2,TW4 | 88/8~90/1 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1655 | 04445-36060 | | DYNA, TOYO ACE BU66 T2,T4,DMS | 88/8~90/1 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3089 | 04445-36060 | | DYNA, TOYO ACE BU60,66,70 (T3,SRF) (03S,06S) ST | 88/8~90/1 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3397 | 04445-36060 | | DYNA, TOYO ACE YU60,70 | 90/1~93/5 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2693 | 90311-50014 | 50 x 70 x 10 x 16 | DYNA, TOYO ACE BU162,172,182,XZU362,37#,382 | 95/5~ | Transfer FRONT OUTPUT |
| 03901 7341 | 90311-36104 | 36 x 50 x 7 | DYNA, TOYO ACE YU6#,70,80 | 84/9~95/ | Steering (M/S) SECTOR SHAFT |
| 03901 4037 | 90311-95001 | 95 x 115 x 12 | DYNA, TOYO ACE 2J,H,2H JU20,HU26,30,40,50 | 77/8~83/ | Engine CRANK SHAFT REAR |
| 03901 7875 | 9828-79103 | 79 x 114 x 17 | DYNA, TOYO ACE JO5C XZU130,140 | 95/10~99/ | Engine TIMING GEAR COVER |
| 03901 1121 | 9828-79103 | 79 x 114 x 17 | DYNA, TOYO ACE JO5C,SO5#...XZU30#,31#,32#,33#,341,342,346,347,35# | 99/5~ | Engine TIMING GEAR COVER |
| 03901 8129 | 90311-48020 | 48 x 68 x 7 | DYNA, TOYO ACE 3RZ RZU100,140 | 95/5~ | Engine TIMING GEAR CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2567 | 90311-80001 | 80 x 100 x 12 | DYNA, TOYO ACE 5R RU2#,3# | 77/8~84/ | Engine CRANK SHAFT REAR |
| 03901 6095 | 90311-80003 | 80 x 100 x 8.5 | DYNA, TOYO ACE 3Y YU6#,70,8# | 84/9~90/4 | Engine CRANK SHAFT REAR |
| 03901 2785 | 90311-80009 | 80 x 100 x 10 | DYNA, TOYO ACE 3Y YU6#,70 | 90/4~95/ | Engine CRANK SHAFT REAR |
| 03901 3355 | 90311-95008 | 95 x 115 x 9.5 x 12 | DYNA, TOYO ACE 15B#...XZU301,302,341 | 00/5~ | Engine CRANK SHAFT REAR |
| 03901 6453 | 90311-88005 | 88 x 106 x 8.5 | DYNA, TOYO ACE 3RZ RZU300,340 | 99/5~ | Engine CRANK SHAFT REAR |
| 03901 5255 | 90311-50013 | 50 x 72 x 9 x 14 | DYNA, TOYO ACE 15BFTE BU400,410,420,430 | 99/5~ | Engine TIMING GEAR COVER |
| 03901 4267 | 90311-95001 | 95 x 115 x 12 | DYNA, TOYO ACE B,2B,3B BU2#,3#,4#,5# | 77/8~84/ | Engine CRANK SHAFT REAR |
| 03901 2667 | 90311-95001 | 95 x 115 x 12 | DYNA, TOYO ACE B,3B,11B,13B#,14B#...BU6#,7#,8#,9# | 84/9~90/1 | Engine CRANK SHAFT REAR |
| 03901 1677 | 90311-95008 | 95 x 115 x 9.5 x 12 | DYNA, TOYO ACE B,3B,11B,14B#...BU6#,7#,8#,9# | 90/1~95/ | Engine CRANK SHAFT REAR |
| 03901 5541 | 90311-95008 | 95 x 115 x 9.5 x 12 | DYNA, TOYO ACE 15B,3B BU10#,112,12#,13#,14#,162,172,182,202,212, | 95/5~99/ | Engine CRANK SHAFT REAR |
| 03901 2229 | 90311-95008 | 95 x 115 x 9.5 x 12 | DYNA, TOYO ACE 4B BU30#,346 | 99/5~ | Engine CRANK SHAFT REAR |
| 03901 4053 | 90311-95008 | 95 x 115 x 9.5 x 12 | DYNA, TOYO ACE 15BFTE BU400,410,420,430 | 99/5~ | Engine CRANK SHAFT REAR |
| 03901 2949 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU67 DMP,BU66 TW1,DM1,275T,3T | 88/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 1349 | 90311-88005 | 88 x 106 x 8.5 | DYNA, TOYO ACE 3RZ RZU100,140 | 95/5~ | Engine CRANK SHAFT REAR |
| 03901 7685 | 90311-42026 | 42 x 60 x 7 | DYNA, TOYO ACE 3Y YU6#,70 | 87/8~95/ | Engine TIMING GEAR COVER |
| 03901 3561 | 04445-36110 | | DYNA, TOYO ACE BU112,202,XZU130 DM7,DM8,T4 | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2955 | 04445-36110 | | DYNA, TOYO ACE BU100,102,132,140 (DM2,DM3,DM6,T3,T5,TW1) WT | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2907 | 04445-36090 | | DYNA, TOYO ACE BU72,73,74 | 89/10~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3081 | 04445-36090 | | DYNA, TOYO ACE BU162,172,182 | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2881 | 04445-37040 | | DYNA, TOYO ACE BU301,RZU300,340,XZU300,301,302,31#,32#,330,331, | 99/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7491 | 04445-37040 | | DYNA, TOYO ACE BU400,410,420,430,XZU382,40#,41#,42#,430 | 99/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6245 | 04445-37030 | | DYNA, TOYO ACE BU306,346,XZU306,307,337,346,347 | 99/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 3403 | 9828-58104 | 58 x 75 x 9 x 14.5 | DYNA, TOYO ACE 1W WU75,85,9# | 83/4~95/ | Engine TIMING GEAR COVER |
| 03901 7749 | 90311-42003 | 42 x 60 x 7 | DYNA, TOYO ACE 3Y YU6#,70,8# | 84/9~87/8 | Engine TIMING GEAR COVER |
| 03901 2655 | 90311-50013 | 50 x 72 x 9 x 14 | DYNA, TOYO ACE 15B#...XZU301,302,341 | 00/5~ | Engine TIMING GEAR COVER |
| 03901 3023 | 90311-50006 | 50 x 72 x 12 | DYNA, TOYO ACE 2J,H,2H JU20,HU26,30,40,50 | 77/8~83/ | Engine TIMING GEAR COVER |
| 03901 5815 | 90311-50006 | 50 x 72 x 12 | DYNA, TOYO ACE B,2B,3B BU2#,3#,4#,5# | 77/8~84/ | Engine TIMING GEAR COVER |
| 03901 1437 | 90311-50006 | 50 x 72 x 12 | DYNA, TOYO ACE B,11B,13B BU6#,7#,8#,9# | 84/9~88/8 | Engine TIMING GEAR COVER |
| 03901 6353 | 90311-50013 | 50 x 72 x 9 x 14 | DYNA, TOYO ACE B,3B,11B,13BT,14B#...BU6#,7#,8#,9# | 88/8~95/ | Engine TIMING GEAR COVER |
| 03901 8137 | 90311-50013 | 50 x 72 x 9 x 14 | DYNA, TOYO ACE 15B,3B BU10#,112,12#,13#,14#,162,172,182,202,212, | 95/5~99/ | Engine TIMING GEAR COVER |
| 03901 4075 | 90311-50013 | 50 x 72 x 9 x 14 | DYNA, TOYO ACE 4B BU30#,346 | 99/5~ | Engine TIMING GEAR COVER |
| 03901 5725 | 9828-00109 | 100 x 120 x 13 x 18 | DYNA, TOYO ACE 1W WU75,85,9# | 83/4~95/ | Engine CRANK SHAFT REAR |
| 03901 3955 | 90311-45002 | 45 x 68 x 12 | DYNA, TOYO ACE 5R RU2#,3# | 77/8~84/ | Engine TIMING GEAR COVER |
| 03901 1911 | 90311-48019 | 48 x 82 x 10.2 x 17.8 | DYNA, TOYO ACE BU30#,346,RZU300,340,XZU302,307,322,337,351,352 | 99/5~ | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1797 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU62,82,85,93 20T DSL,BU64 T3 | 87/8~88/8 | Final Drive REAR DIFF. PINION |
| 03901 4547 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU73 TW1,BU74,84 20T | 88/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 2935 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU67 TR, BU87 VAN | 88/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 7569 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU66 (DM2,DM3,DM5,TW4,T2,T3,T4) (175T,20T) | 88/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 2081 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU88 (TW1,T2,T3) 20T DSL | 88/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 4443 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU100,105,107,112,12#,13#, 14#.202,212,222,RZU140.. | 95/5~ | Final Drive REAR DIFF. PINION |
| 03901 5369 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU6#,7#,8#...EXCEPT DM1,DM4,275T,3T,TD,DTP | 84/9~87/8 | Final Drive REAR DIFF. PINION |
| 03901 5895 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU172,182 T4 | 95/5~99/ | Final Drive REAR DIFF. PINION |
| 03901 8155 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE YU6#,70,80 | 84/9~95/ | Final Drive REAR DIFF. PINION |
| 03901 2933 | 90311-48019 | 48 x 82 x 10.2 x 17.8 | DYNA, TOYO ACE XZU306 T4,XZU347 T2 | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 4991 | 90311-48019 | 48 x 82 x 10.2 x 17.8 | DYNA, TOYO ACE XZU402,411 T2,XZU412 SCB (T2,T5) | 99/5~ | Final Drive REAR DIFF. PINION |
| 03901 4929 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU40,41,5#HU26,40,50,WU 26,40,50 | 82/4~84/ | Final Drive REAR DIFF. PINION |
| 03901 5281 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE WU75,85,9# | 84/9~95/ | Final Drive REAR DIFF. PINION |
| 03901 7449 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU62,64,82,85,9#...DM1,DM4,275T,3T,TD,DTP | 87/8~88/8 | Final Drive REAR DIFF. PINION |
| 03901 1065 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU62,82,85,92,98 (275T,3T) DSL | 87/8~88/8 | Final Drive REAR DIFF. PINION |
| 03901 6515 | 90311-58002 | 58 x 102 x 12 | DYNA, TOYO ACE BU64 DMP,BU85,90,95 TD | 87/8~88/8 | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7011 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU102,162,RZU100 (DM2,DM5,T2,T3,T4,TW1,TW4) 20T | 95/5~ | Final Drive REAR DIFF. PINION |
| 03901 1665 | 90913-02076 | | DYNA, TOYO ACE B,3B,11B,13B,14B BU6#,7#,8#,9# | 88/8~95/ | Engine VALVE STEM SEAL |
| 03901 4287 | 9828-01228 | 100 x 135 x 17 | DYNA, TOYO ACE JO5C XZU130,140 | 95/10~ | Engine CRANK SHAFT REAR |
| 03901 2237 | 9828-01228 | 100 x 135 x 17 | DYNA, TOYO ACE J05C,S05#...XZU30#,31#,32#,33#,341,342,346,347,35# | 99/5~ | Engine CRANK SHAFT REAR |
| 03901 2223 | 90913-02042 | | DYNA, TOYO ACE 5R RU2#,3# | 78/5~84/ | Engine VALVE STEM SEAL |
| 03901 5101 | 90913-02094 | | DYNA, TOYO ACE 3Y#...YU6#,70,80 | 84/9~95/ | Engine VALVE STEM SEAL |
| 03901 2521 | 90913-02079 | | DYNA, TOYO ACE 3RZ(IN.) RZU100,140,300,340 | 95/5~ | Engine VALVE STEM SEAL |
| 03901 3479 | 90913-02062 | | DYNA, TOYO ACE 3RZ(EX.) RZU100,140,300,340 | 95/5~ | Engine VALVE STEM SEAL |
| 03901 7007 | 90913-02028 | | DYNA, TOYO ACE B,2B BU2#,3# | 77/8~80/8 | Engine VALVE STEM SEAL |
| 03901 3045 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU60,61,70,80,81,83,84 | 87/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 6891 | 90913-02051 | | DYNA, TOYO ACE B,11B,13B BU6#,7#,8#,9# | 84/9~88/8 | Engine VALVE STEM SEAL |
| 03901 4615 | 04445-36110 | | DYNA, TOYO ACE BU142,RZU100 30T | 95/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7189 | 90913-02076 | | DYNA, TOYO ACE 3B BU100,105,120,140,145 | 95/5~99/ | Engine VALVE STEM SEAL |
| 03901 6557 | 90913-02076 | | DYNA, TOYO ACE 4B BU30#,346 | 99/5~ | Engine VALVE STEM SEAL |
| 03901 3823 | 90913-02108 | | DYNA, TOYO ACE 15B BU102,107,112,122,13#,142,147,162,172,182,202, | 95/5~99/ | Engine VALVE STEM SEAL |
| 03901 3327 | 90913-02096 | | DYNA, TOYO ACE 15B#...XZU301,302,341 | 99/5~ | Engine VALVE STEM SEAL |
| 03901 3365 | 90311-48011 | 48 x 62 x 9 | DYNA, TOYO ACE BU162,172,182,XZU362,37#,382 | 95/5~ | Transfer REAR OUTPUT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3785 | 90311-48135 | 48 x 82 x 12 | DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU20,HU30 | 77/8~84/ | Final Drive REAR DIFF. PINION |
| 03901 7313 | 90913-02051 | | DYNA, TOYO ACE B,3B BU2#,3# | 80/8~84/ | Engine VALVE STEM SEAL |
| 03901 6221 | 04332-30030 | Kit | ESTIMA CXR1#,TCR1# (EFI) | 90/5~00/ | Transmission (A/T) REAR EXTENTION |
| 03901 5791 | 90311-38029 | 38 x 55 x 7.5 | ESTIMA TCR1#,2# (SPC) | 94/8~00/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6857 | 04445-28030 | | ESTIMA CXR1#,2#,TCR1#,2# (EFI) | 90/5~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 5919 | 90311-38011 | 38 x 63 x 10 x 17 | ESTIMA CXR11,21,TCR11,21 | 90/5~00/ | Final Drive DIFF. SIDE |
| 03901 6459 | 90311-38047 | 38 x 74 x 11 x 18 | ESTIMA CXR10,20,TCR10,20 | 95/12~00/ | Final Drive PINION |
| 03901 2745 | 90311-38133 | 38 x 74 x 11 | ESTIMA CXR10,20,TCR10,20 | 92/1~95/12 | Final Drive PINION |
| 03901 3395 | 90311-38133 | 38 x 74 x 11 | ESTIMA CXR11,21,TCR11,21 | 90/5~00/ | Final Drive PINION |
| 03901 6543 | 90311-50026 | 50 x 68 x 9 x 15.5 | ESTIMA ACR30 | 00/2~ | Differential DIFF. SIDE |
| 03901 1879 | 90311-50011 | 50 x 80 x 16.5 x 23 | ESTIMA ACR40,MCR30,40 | 99/12~ | Differential DIFF. SIDE |
| 03901 4213 | 90311-40026 | 40 x 64 x 9 x 15.5 | ESTIMA ACR30 | 00/2~ | Differential TRANSAXLE HOUSING |
| 03901 6089 | 90311-55003 | 55 x 74 x 10 | ESTIMA ACR40,MCR40 | 99/12~ | Differential TRANSAXLE HOUSING |
| 03901 5317 | 04445-28060 | | ESTIMA TCR1#,2# (SPC) | 94/8~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 6163 | 90311-38064 | 38 x 55 x 8.7 | ESTIMA ACR30,40,MCR30,40 | 99/12~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7991 | 90311-35002 | 35 x 40 x 49 x 11 | ESTIMA CXR10,20,TCR10,20 | 92/1~00/ | Wheel Hub REAR OUTER |
| 03901 3943 | 90311-38020 | 38 x 55 x 8.5 | ESTIMA CXR1#,2#,TCR1#,2# (EFI) | 90/5~00/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1315 | 90311-38032 | 38 x 58 x 11 | ESTIMA CXR1#,TCR10 | 92/1~00/ | Transmission (M/T) REAR EXTENTION |
| 03901 3467 | 90311-30014 | 30 x 45 x 8 | ESTIMA CXR1#,2#,TCR1#,2# | 92/1~00/ | Transmission (M/T) FRONT COVER |
| 03901 5197 | 90311-59002 | 59 x 78 x 7 | ESTIMA CXR11,21,TCR11,21 | 90/5~00/ | Wheel Hub REAR OUTER |
| 03901 8223 | 90913-02111 | | ESTIMA 2AZFE,1MZFE (EX.) | 99/12~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5997 | 90311-63001 | 63 x 90 x 7 x 10 | ESTIMA CXR11,21,TCR11,21 | 90/5~00/ | Wheel Hub REAR INNER |
| 03901 6461 | 90311-40010 | 40 x 56 x 9 x 15.5 | ESTIMA MCR30 | 99/12~ | Differential TRANSAXLE HOUSING |
| 03901 5329 | 90311-56014 | 56 x 78 x 7.5 x 13 | ESTIMA CXR2#,TCR2# (4WD) | 90/5~00/ | Wheel Hub FRONT DRIVE SHAFT |
| 03901 1147 | 90311-61001 | 61 x 76 x 7 x 10 | ESTIMA CXR1#,2#,TCR1#,2# | 90/5~00/ | Wheel Hub FRONT |
| 03901 7585 | 90311-40001 | 40 x 58 x 11 | ESTIMA TCR1# (SPC) | 94/8~00/ | Transmission (A/T) REAR EXTENTION |
| 03901 3857 | 90913-02094 | | ESTIMA 3CT# | 92/1~95/11 | Engine VALVE STEM SEAL |
| 03901 4671 | 90311-52059 | 52 x 65 x 9 | ESTIMA CXR10,20,TCR10,20 | 92/1~00/ | Wheel Hub REAR INNER |
| 03901 3959 | 04445-28090 | | ESTIMA ACR30,40,MCR30,40 | 99/12~ | Steering (P/S) R & P GASKET KIT |
| 03901 4557 | 90913-02101 | | ESTIMA 2AZFE,1MZFE (IN.) | 99/12~ | Engine VALVE STEM SEAL |
| 03901 7519 | 90913-02110 | | ESTIMA 3CT# | 95/11~97/4 | Engine VALVE STEM SEAL |
| 03901 7825 | 90913-02079 | | ESTIMA 2TZFE (IN.) | 92/6~00/ | Engine VALVE STEM SEAL |
| 03901 3979 | 90913-02062 | | ESTIMA 2TZFE (IN.) | 90/5~92/6 | Engine VALVE STEM SEAL |
| 03901 5901 | 90913-02062 | | ESTIMA 2TZFE (EX.) | 90/5~00/ | Engine VALVE STEM SEAL |
| 03901 5023 | 90311-89003 | 89 x 105 x 10 | ESTIMA 2AZFE ACR30,40 | 00/2~ | Engine CRANK SHAFT REAR |
| 03901 3065 | 90311-92008 | 92 x 110 x 9 | ESTIMA 1MZFE MCR30,40 | 99/12~ | Engine CRANK SHAFT REAR |
| 03901 8111 | 90311-88005 | 88 x 106 x 8.5 | ESTIMA 2TZFE TCR1#,2# | 90/5~00/ | Engine CRANK SHAFT REAR |
| 03901 6189 | 90311-90008 | 90 x 110 x 9.5 x 11.5 | ESTIMA 3CT#...CXR1#,2# | 93/8~00/ | Engine CRANK SHAFT REAR |
| 03901 2943 | 90310-25027 | 25 x 38 x 7 | ESTIMA ACR30,40,MCR30,40 | 99/12~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2019 | 90311-90005 | 90 x 110 x 8.5 x 10 | ESTIMA 3CT#...CXR1#,2# | 92/1~93/8 | Engine CRANK SHAFT REAR |
| 03901 3663 | 90311-42026 | 42 x 60 x 7 | ESTIMA 3CT#...CXR1#,2# | 92/1~00/ | Engine CRANK SHAFT FRONT |
| 03901 3113 | 90311-40022 | 40 x 55 x 6 | ESTIMA 1MZFE MCR30,40 | 99/12~ | Engine OIL PUMP |
| 03901 2151 | 90311-38059 | 38 x 50 x 8 | ESTIMA 2AZFE ACR30,40 | 00/2~ | Engine TIMING GEAR CASE |
| 03901 2849 | 90311-48020 | 48 x 68 x 7 | ESTIMA 2TZFE TCR1#,2# | 90/5~00/ | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7821 | 90311-38034 | 38 x 50 x 10.5 | ESTIMA 1MZFE MCR30,40 | 99/12~ | Engine CAM SHAFT |
| 03901 7677 | 90311-38044 | 38 x 50 x 6 | ESTIMA 3CT#...CXR1#,2# | 92/1~00/ | Engine CAM SHAFT |
| 03901 4899 | 90913-02117 | | ESTIMA 3CT# | 94/4~ | Engine VALVE STEM SEAL |
| 03901 4369 | 90311-19002 | 19 x 32 x 7 x 8 | ESTIMA ACR30,40,MCR30,40 | 99/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7817 | 90310-25004 | 25 x 38 x 7 x 8 | ESTIMA CXR1#,2#,TCR1#,2# | 90/5~00/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7039 | 90311-19002 | 19 x 32 x 7 x 8 | ESTIMA CXR1#,2#,TCR1#,2# | 90/5~00/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7723 | 90311-38020 | 38 x 55 x 8.5 | FUN CARGO NCP21,25 | 99/8~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 5465 | 04445-52020 | | FUN CARGO NCP20,21 | 99/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 4887 | 04445-52010 | | FUN CARGO NCP25 (4WD) | 99/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 6191 | 90311-25021 | 25.5 x 37.5 x 6 | FUN CARGO 1NZFE,2NZFE NCP2# | 99/8~ | Engine OIL PUMP |
| 03901 4517 | 90913-02093 | | FUN CARGO 1NZFE,2NZFE (IN. & EX.) | 99/8~ | Engine VALVE STEM SEAL |
| 03901 2293 | 90311-34016 | 34 x 54 x 9 x 15.5 | FUN CARGO NCP20,21 | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 6889 | 90311-75016 | 75 x 107 x 8 | FUN CARGO 1NZFE,2NZFE NCP2# | 99/8~ | Engine CRANK SHAFT REAR |
| 03901 4933 | 90311-38075 | 38 x 55 x 7.8 | FUN CARGO NCP20 | 99/8~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2917 | 90311-49002 | 50 x 64 x 8 | FUN CARGO NCP25 (4WD) | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 2363 | 90311-42055 | 42 x 55 x 7 | FUN CARGO NCP25 (4WD) | 99/8~ | Wheel Hub REAR |
| 03901 7525 | 90311-34022 | 34 x 56 x 9 x 15 | FUN CARGO NCP21,25 | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.1) |
| 03901 6429 | 90311-34017 | 34 x 63 x 9 x 16 | FUN CARGO NCP20 | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4771 | 90311-38075 | 38 x 55 x 7.8 | FUN CARGO NCP20 | 99/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1545 | 04332-30030 | Kit | GRANVIA, GRAND HIACE RCH11 | 95/8~98/ | Transmission (A/T) REAR EXTENTION |
| 03901 4763 | 90311-92006 | 92 x 110 x 9.5 | GRANVIA, GRAND HIACE 5VZFE VZH1#,2# | 97/8~ | Engine CRANK SHAFT REAR |
| 03901 8023 | 90311-50136 | 50 x 68 x 9 | GRANVIA, GRAND HIACE KCH10,12,RCH11,VCH10,22 | 95/8~ | Wheel Hub FRONT |
| 03901 1407 | 90311-66001 | 66 x 85 x 8 x 10 | GRANVIA, GRAND HIACE KCH16,VCH16,28 (4WD) | 95/10~ | Wheel Hub FRONT |
| 03901 8081 | 90311-38020 | 38 x 55 x 8.5 | GRANVIA, GRAND HIACE RCH11 | 95/8~98/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6707 | 90311-38029 | 38 x 55 x 7.5 | GRANVIA, GRAND HIACE KCH1#,VCH1#,2# | 95/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4235 | 90311-38051 | 38 x 50 x 10 | GRANVIA, GRAND HIACE 5VZFE VZH1#,2# | 97/8~ | Engine CAM SHAFT |
| 03901 4073 | 90913-02062 | | GRANVIA, GRAND HIACE 5VZFE (EX.) | 97/8~ | Engine VALVE STEM SEAL |
| 03901 1107 | 90913-02095 | | GRANVIA, GRAND HIACE 5VZFE (IN.) | 97/8~ | Engine VALVE STEM SEAL |
| 03901 5503 | 90913-02062 | | GRANVIA, GRAND HIACE 3RZFE (EX.) | 95/8~98/4 | Engine VALVE STEM SEAL |
| 03901 5351 | 90913-02079 | | GRANVIA, GRAND HIACE 3RZFE (IN.) | 95/8~98/4 | Engine VALVE STEM SEAL |
| 03901 3129 | 90913-02117 | | GRANVIA, GRAND HIACE 1KZTE | 97/8~ | Engine VALVE STEM SEAL |
| 03901 3855 | 90913-02110 | | GRANVIA, GRAND HIACE 1KZTE | 95/8~97/8 | Engine VALVE STEM SEAL |
| 03901 3689 | 90311-95008 | 95 x 115 x 9.5 x 12 | GRANVIA, GRAND HIACE 1KZTE KCH1# | 95/8~ | Engine CRANK SHAFT REAR |
| 03901 5731 | 90311-40022 | 40 x 55 x 6 | GRANVIA, GRAND HIACE 5VZFE VZH1#,2# | 97/8~ | Engine OIL PUMP |
| 03901 2991 | 90311-40001 | 40 x 58 x 11 | GRANVIA, GRAND HIACE KCH10,12,VCH10,22 | 95/8~ | Transmission (A/T) REAR EXTENTION |
| 03901 6185 | 90311-32020 | 32 x 46 x 6 | GRANVIA, GRAND HIACE 1KZTE KCH1# | 95/8~ | Engine CAM SHAFT |
| 03901 5817 | 90311-58006 | 58 x 72 x 7 | GRANVIA, GRAND HIACE 1KZTE KCH1# | 95/8~ | Engine TIMING GEAR COVER |
| 03901 2291 | 90311-50017 | 50 x 68 x 9 x 14.5 | GRANVIA, GRAND HIACE 1KZTE KCH1# | 95/8~ | Engine TIMING GEAR CASE |
| 03901 5165 | 90311-48020 | 48 x 68 x 7 | GRANVIA, GRAND HIACE 3RZFE RCH11 | 95/8~98/ | Engine TIMING GEAR CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2581 | 90310-25004 | 25 x 38 x 7 x 8 | GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2# | 95/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5411 | 90311-19002 | 19 x 32 x 7 x 8 | GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2# | 95/8~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3583 | 04445-26050 | | GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2# | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 5747 | 90311-38133 | 38 x 74 x 11 | GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2# | 95/8~ | Final Drive REAR DIFF. PINION |
| 03901 4431 | 90311-88005 | 88 x 106 x 8.5 | GRANVIA, GRAND HIACE 3RZFE RCH11 | 95/8~98/ | Engine CRANK SHAFT REAR |
| 03901 4881 | 90311-40010 | 40 x 56 x 9 x 15.5 | HARRIER MCU10,SXU10 (2WD) | 97/12~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3199 | 15165-70010 | 18 x 30 x 7 | HARRIER 5SFE SXU1# | 97/12~ | Engine OIL PUMP |
| 03901 2863 | 90311-62004 | 62 x 74 x 8.5 | HARRIER MCU15,SXU15 (4WD) | 97/12~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 8069 | 90311-38020 | 38 x 55 x 8.5 | HARRIER MCU1#,SXU1# | 97/12~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2307 | 04445-33070 | | HARRIER MCU1#,SXU1# | 97/12~ | Steering (P/S) R & P GASKET KIT |
| 03901 3245 | 90311-19010 | 19 x 32 x 6 | HARRIER MCU1#,SXU1# | 97/12~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6333 | 90311-26003 | 26 x 38 x 6.5 | HARRIER MCU1#,SXU1# | 97/12~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1501 | 90311-38034 | 38 x 50 x 10.5 | HARRIER 1MZFE MCU1# | 97/12~ | Engine CAM SHAFT |
| 03901 3393 | 90311-52005 | 52 x 75 x 7.5 x 12 | HARRIER MCU15,SXU15 (4WD) | 97/12~ | Wheel Hub REAR OUTER |
| 03901 5225 | 90311-40022 | 40 x 55 x 6 | HARRIER 1MZFE MCU1# | 97/12~ | Engine OIL PUMP |
| 03901 7025 | 90311-56015 | 56 x 75 x 7 x 12 | HARRIER MCU15,SXU15 (4WD) | 97/12~ | Wheel Hub REAR INNER |
| 03901 3825 | 90311-42035 | 42 x 60 x 7 | HARRIER 5SFE SXU1# | 97/12~ | Engine CRANK SHAFT FRONT |
| 03901 4665 | 90311-92008 | 92 x 110 x 9 | HARRIER 1MZFE MCU1# | 97/12~ | Engine CRANK SHAFT REAR |
| 03901 7199 | 90311-85007 | 85 x 105 x 10 | HARRIER 5SFE SXU1# | 97/12~ | Engine CRANK SHAFT REAR |
| 03901 1017 | 90913-02101 | | HARRIER 1MZFE (IN.) | 97/12~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7745 | 90913-02111 | | HARRIER 1MZFE (EX.) | 97/12~ | Engine VALVE STEM SEAL |
| 03901 4269 | 90913-02079 | | HARRIER 5SFE (IN.) | 97/12~ | Engine VALVE STEM SEAL |
| 03901 6567 | 90311-50011 | 50 x 80 x 16.5 x 23 | HARRIER MCU1#,SXU1# | 97/12~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3863 | 90311-38067 | 38 x 50 x 8 | HARRIER 5SFE SXU1# | 97/12~ | Engine CAM SHAFT |
| 03901 7793 | 90913-02062 | | HARRIER 5SFE (EX.) | 97/12~ | Engine VALVE STEM SEAL |
| 03901 1615 | 90311-38133 | 38 x 74 x 11 | HIACE (TRUCK) LY101,111,151,161,YY101 | 95/5~95/11 | Final Drive REAR DIFF. PINION |
| 03901 7785 | 90311-32106 | 32 x 48 x 8 | HIACE (TRUCK) RH24,YH80 | 82/11~87/ | Transmission (M/T) FRONT COVER |
| 03901 7415 | 90311-32012 | 32 x 53 x 7 | HIACE (TRUCK) LH85,95 | 87/10~95/ | Transmission (M/T) FRONT COVER |
| 03901 5921 | 90311-32012 | 32 x 53 x 7 | HIACE (TRUCK) LY151,161 | 95/5~99/ | Transmission (M/T) FRONT COVER |
| 03901 3427 | 90311-38043 | 38 x 58 x 11 | HIACE (TRUCK) LH24,RH24 | 82/11~85/ | Transmission (M/T) REAR EXTENTION |
| 03901 4119 | 90311-38043 | 38 x 58 x 11 | HIACE (TRUCK) LH80,YH80,81 | 85/8~88/8 | Transmission (M/T) REAR EXTENTION |
| 03901 7729 | 90311-38032 | 38 x 58 x 11 | HIACE (TRUCK) LH80,90,YH81 | 88/8~95/ | Transmission (M/T) REAR EXTENTION |
| 03901 2309 | 90311-38032 | 38 x 58 x 11 | HIACE (TRUCK) LY101,111,YY101 | 95/5~99/ | Transmission (M/T) REAR EXTENTION |
| 03901 4669 | 90311-38020 | 38 x 55 x 8.5 | HIACE (TRUCK) LH80,90,LY101,111 | 85/8~99/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1935 | 04332-30030 | Kit | HIACE (TRUCK) LH80,90,LY101,111 | 85/8~99/ | Transmission (A/T) REAR EXTENTION |
| 03901 2387 | 90311-38133 | 38 x 74 x 11 | HIACE (TRUCK) LH8#,9#,YH8# | 85/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 7917 | 90311-38133 | 38 x 74 x 11 | HIACE (TRUCK) LY101,111,YY101 | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 8173 | 90311-38133 | 38 x 74 x 11 | HIACE (TRUCK) LY151,161 SUPER SINGLE JUST LOW | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 7629 | 90311-38047 | 38 x 74 x 11 x 18 | HIACE (TRUCK) LY151,161 W/CAB,SINGLE JUST LOW | 95/11~96/1 | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1321 | 90311-38047 | 38 x 74 x 11 x 18 | HIACE (TRUCK) LY101,111,151,161,YY101 | 96/1~99/ | Final Drive REAR DIFF. PINION |
| 03901 6827 | 90311-50136 | 50 x 68 x 9 | HIACE (TRUCK) LY101,111,YY101 | 95/5~99/ | Wheel Hub FRONT |
| 03901 2665 | 90311-30014 | 30 x 45 x 8 | HIACE (TRUCK) LY101.111.YY101 | 95/5~99/ | Transmission (M/T) FRONT COVER |
| 03901 4011 | 90311-38133 | 38 x 74 x 11 | HIACE (TRUCK) LH24,RH24 | 82/11~85/ | Final Drive REAR DIFF. PINION |
| 03901 5093 | 90311-62001 | 62 x 85 x 10 | HIACE (TRUCK) LH8#,9#,YH81 DOUBLE TIRE | 85/8~95/ | Wheel Hub REAR INNER |
| 03901 3001 | 90311-50136 | 50 x 68 x 9 | HIACE (TRUCK) LH80,90,YH81 | 85/8~95/ | Wheel Hub FRONT |
| 03901 2433 | 90311-42026 | 42 x 60 x 7 | HIACE (TRUCK) 2Y,3Y YH8#,YY101 | 87/8~99/ | Engine TIMING GEAR COVER |
| 03901 6645 | 90311-66001 | 68 x 85 x 8 x 10 | HIACE (TRUCK) LH85,95 | 87/10~95/ | Wheel Hub FRONT |
| 03901 5829 | 90311-18010 | 18 x 30 x 8 | HIACE (TRUCK) LH24,80,90,RH24,YH8# | 82/11~95/ | Steering (M/S) WORM GEAR |
| 03901 7249 | 90310-50001 | 50 x 70 x 9 | HIACE (TRUCK) LH24,RH24 SINGLE TIRE | 82/11~85/ | Wheel Hub REAR INNER |
| 03901 4619 | 90310-50001 | 50 x 70 x 9 | HIACE (TRUCK) LH8#,9#,YH81 SINGLE TIRE | 85/8~95/ | Wheel Hub REAR INNER |
| 03901 3995 | 90311-66001 | 68 x 85 x 8 x 10 | HIACE (TRUCK) LY151,161 | 95/5~99/ | Wheel Hub FRONT |
| 03901 1215 | 90311-62001 | 62 x 85 x 10 | HIACE (TRUCK) LH24,RH24 DOUBLE TIRE | 82/11~85/ | Wheel Hub REAR INNER |
| 03901 5835 | 90311-30014 | 30 x 45 x 8 | HIACE (TRUCK) LH80,90,YH81 | 90/7~95/ | Transmission (M/T) FRONT COVER |
| 03901 2545 | 90313-48001 | 48 x 62 x 9 x 24 | HIACE (TRUCK) LH24,RH24 SINGLE TIRE | 82/11~85/ | Wheel Hub REAR OUTER |
| 03901 2471 | 90313-48001 | 48 x 62 x 9 x 24 | HIACE (TRUCK) LH8#,9#,YH81 SINGLE TIRE | 85/8~95/ | Wheel Hub REAR OUTER |
| 03901 1827 | 90313-48001 | 48 x 62 x 9 x 24 | HIACE (TRUCK) LY101,111,151,161,YY101 | 95/5~99/ | Wheel Hub REAR OUTER |
| 03901 2833 | 90310-35001 | 35 x 41 x 5.5 x 9 | HIACE (TRUCK) LH24,RH24 DOUBLE TIRE | 82/11~85/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3851 | 90310-35001 | 35 x 41 x 5.5 x 9 | HIACE (TRUCK) LH8#,9#,YH81 DOUBLE TIRE | 85/8~95/ | Wheel Hub REAR OUTER |
| 03901 3915 | 90311-30115 | 30 x 45 x 8 | HIACE (TRUCK) LH24 | 82/11~85/ | Transmission (M/T) FRONT COVER |
| 03901 3339 | 90311-30115 | 30 x 45 x 8 | HIACE (TRUCK) LH80,YH81 | 85/8~90/7 | Transmission (M/T) FRONT COVER |
| 03901 2381 | 90310-50001 | 50 x 70 x 9 | HIACE (TRUCK) LY101,111,151,161,YY101 | 95/5~99/ | Wheel Hub REAR INNER |
| 03901 5111 | 90311-85007 | 85 x 105 x 10 | HIACE (TRUCK) 3L LY101,111,151,161 | 95/5~99/ | Engine CRANK SHAFT REAR |
| 03901 7413 | 90311-42003 | 42 x 60 x 7 | HIACE (TRUCK) 2L LH8# | 85/8~88/8 | Engine CAM SHAFT |
| 03901 5037 | 90311-42003 | 42 x 60 x 7 | HIACE (TRUCK) 2L LH85 | 88/8~89/10 | Engine CAM SHAFT |
| 03901 4363 | 90311-32020 | 32 x 46 x 6 | HIACE (TRUCK) 2L LH80 | 88/8~89/10 | Engine CAM SHAFT |
| 03901 7971 | 90311-32020 | 32 x 46 x 6 | HIACE (TRUCK) 2L LH8#,9# | 89/10~95/ | Engine CAM SHAFT |
| 03901 6949 | 90311-32020 | 32 x 46 x 6 | HIACE (TRUCK) 3L LY101,111,151,161 | 95/5~99/ | Engine CAM SHAFT |
| 03901 5851 | 90311-85001 | 85 x 105 x 13 | HIACE (TRUCK) L LH24 | 82/11~84/2 | Engine CRANK SHAFT REAR |
| 03901 3259 | 90311-38013 | 38.5 x 58 x 11 | HIACE (TRUCK) 12R RH24 | 82/11~85/ | Engine TIMING GEAR COVER |
| 03901 4937 | 90311-85007 | 85 x 105 x 10 | HIACE (TRUCK) 2L LH8#,9# | 91/2~95/ | Engine CRANK SHAFT REAR |
| 03901 7133 | 90311-42026 | 42 x 60 x 7 | HIACE (TRUCK) 2L LH8#,9# | 91/2~95/ | Engine TIMING GEAR CASE |
| 03901 5279 | 90311-80003 | 80 x 100 x 8.5 | HIACE (TRUCK) 2Y YH8# | 85/8~90/4 | Engine CRANK SHAFT REAR |
| 03901 7233 | 90311-80009 | 80 x 100 x 10 | HIACE (TRUCK) 2Y,3Y YH8#,YY101 | 90/4~99/ | Engine CRANK SHAFT REAR |
| 03901 1115 | 90913-02060 | | HIACE (TRUCK) L,2L LH24,8# | 82/11~88/8 | Engine VALVE STEM SEAL |
| 03901 7877 | 90913-02060 | | HIACE (TRUCK) 2L LH85 | 88/8~89/10 | Engine VALVE STEM SEAL |
| 03901 3457 | 90913-02110 | | HIACE (TRUCK) 2L LH80 | 88/8~89/10 | Engine VALVE STEM SEAL |
| 03901 5433 | 90913-02110 | | HIACE (TRUCK) 3L LY101,111,151,161 | 95/5~99/ | Engine VALVE STEM SEAL |
| 03901 7927 | 90913-02094 | | HIACE (TRUCK) 2Y,3Y YH8#,YY101 | 85/8~99/ | Engine VALVE STEM SEAL |
| 03901 1443 | 90311-85004 | 85 x 105 x 10 | HIACE (TRUCK) L,2L LH24,8# | 84/2~91/2 | Engine CRANK SHAFT REAR |
| 03901 7495 | 90312-32001 | 32 x 42 x 5 | HIACE (TRUCK) LY101,111,YY101 | 95/5~99/ | Steering (P/S) GEAR HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5973 | 04445-25030 | | HIACE (TRUCK) LH80,YH8# | 85/8~89/2 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5703 | 04445-26030 | | HIACE (TRUCK) LH80,90,YH81 | 89/2~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7591 | 04445-25060 | | HIACE (TRUCK) LY101,111,YY101 | 95/5~99/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5471 | 04445-27010 | | HIACE (TRUCK) LH85 | 87/10~88/8 | Steering (P/S) R & P GASKET KIT |
| 03901 7735 | 04445-27011 | | HIACE (TRUCK) LH85 | 88/8~89/10 | Steering (P/S) R & P GASKET KIT |
| 03901 7589 | 04445-27013 | | HIACE (TRUCK) LH85,95 | 89/10~95/ | Steering (P/S) R & P GASKET KIT |
| 03901 4911 | 04445-27013 | | HIACE (TRUCK) LY151,161 | 95/5~99/ | Steering (P/S) R & P GASKET KIT |
| 03901 6969 | 90311-42003 | 42 x 60 x 7 | HIACE (TRUCK) L LH24 | 82/11~85/ | Engine CAM SHAFT |
| 03901 1275 | 90312-32001 | 32 x 42 x 5 | HIACE (TRUCK) LH80,90,YH8# | 85/8~95/ | Steering (P/S) GEAR HOUSING |
| 03901 7823 | 90311-42026 | 42 x 60 x 7 | HIACE (TRUCK) 3L LY101,111,151,161 | 95/5~99/ | Engine TIMING GEAR CASE |
| 03901 8039 | 90311-19002 | 19 x 32 x 7 x 8 | HIACE (TRUCK) LH85,95,LY151,161 | 87/10~99/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5239 | 90310-25004 | 25 x 38 x 7 x 8 | HIACE (TRUCK) LH85,95,LY151,161 | 87/10~99/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7009 | 90311-50136 | 50 x 68 x 9 | HIACE (TRUCK) LH24,RH24 | 82/11~85/ | Wheel Hub FRONT |
| 03901 5243 | 90311-42003 | 42 x 60 x 7 | HIACE (TRUCK) 2Y YH8# | 85/8~87/8 | Engine TIMING GEAR COVER |
| 03901 5497 | 90913-02110 | | HIACE (TRUCK) 2L LH8#,9# | 89/10~95/ | Engine VALVE STEM SEAL |
| 03901 6833 | 90311-42003 | 42 x 60 x 7 | HIACE (TRUCK) L,2L LH24,8# | 82/11~91/2 | Engine TIMING GEAR CASE |
| 03901 3353 | 90311-32014 | 32 x 44 x 9 | HIACE (TRUCK) LH24,80,90,RH24,YH8# | 82/11~95/ | Steering (M/S) SECTOR SHAFT |
| 03901 1079 | 90311-19002 | 19 x 32 x 7 x 8 | HIACE (TRUCK) LH80,90,YH8# | 85/8~95/ | Steering (P/S) ADJUSTER PLUG |
| 03901 5069 | 90913-02033 | | HIACE (TRUCK) 12R RH24 | 82/11~85/ | Engine VALVE STEM SEAL |
| 03901 7799 | 90311-38032 | 38 x 58 x 11 | HIACE (VAN, WAGON) LH102,103,113,123,162,172, 182,184 | 89/8~ | Transmission (A/T) REAR EXTENTION |
| 03901 2821 | 90311-38032 | 38 x 58 x 11 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7# | 88/8~89/ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6805 | 90311-38032 | 38 x 58 x 11 | HIACE (VAN, WAGON) LH10#,11#,12#,140,16#,17#, 18#...EXCEPT TD,TDE | 89/8~ | Transmission (M/T) REAR EXTENTION |
| 03901 1585 | 90311-40001 | 40 x 58 x 11 | HIACE (VAN, WAGON) LH100,120,KZH10#,11#,12#. ..TD,TDE | 89/8~ | Transmission (M/T) REAR EXTENTION |
| 03901 2775 | 90311-38020 | 38 x 55 x 8.5 | HIACE (VAN, WAGON) YH51,61,LH50,51,61 | 83/12~89/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 3727 | 90311-38020 | 38 x 55 x 8.5 | HIACE (VAN, WAGON) LH1##...EXCEPT 100,120 | 89/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7383 | 90311-38020 | 38 x 55 x 8.5 | HIACE (VAN, WAGON) RZH10#,11#,12#,133 | 89/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7801 | 90311-38029 | 38 x 55 x 7.5 | HIACE (VAN, WAGON) LH100,120,KZH10#,11#,120, 13# | 90/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1871 | 90311-18010 | 18 x 30 x 8 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7# | 82/12~89/ | Steering (M/S) WORM GEAR |
| 03901 1253 | 90311-38032 | 38 x 58 x 11 | HIACE (VAN, WAGON) LH100 | 89/8~90/1 0 | Transmission (A/T) REAR EXTENTION |
| 03901 6081 | 90311-32012 | 32 x 53 x 7 | HIACE (VAN, WAGON) YH57,LH56,66 | 86/8~89/ | Transmission (M/T) FRONT COVER |
| 03901 6661 | 90311-40001 | 40 x 58 x 11 | HIACE (VAN, WAGON) LH100,120,KZH100,110,120, 132 | 90/10~ | Transmission (A/T) REAR EXTENTION |
| 03901 5971 | 90311-38133 | 38 x 74 x 11 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7# | 82/12~89/ | Final Drive REAR DIFF. PINION |
| 03901 3447 | 90311-38133 | 38 x 74 x 11 | HIACE (VAN, WAGON) LH10#,11#,12#,140,RZH10#, 11#,12#,133 | 89/8~95/1 1 | Final Drive REAR DIFF. PINION |
| 03901 3821 | 90311-38133 | 38 x 74 x 11 | HIACE (VAN, WAGON) KZH10#,11#,12#,13# | 93/8~95/1 1 | Final Drive REAR DIFF. PINION |
| 03901 3615 | 90311-38133 | 38 x 74 x 11 | HIACE (VAN, WAGON) LH10#,11#,12#,RZH102,112, 124 | 95/11~96/ 1 | Final Drive REAR DIFF. PINION |
| 03901 6371 | 90311-38047 | 38 x 74 x 11 x 18 | HIACE (VAN, WAGON) KZH106,116 5F,KZH100,110,12#,132 | 95/11~96/ 1 | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2857 | 90311-38047 | 38 x 74 x 11 x 18 | HIACE (VAN, WAGON) RZH10#,11#,12#,133,KZH10 #,11#,12#,13# | 96/1~ | Final Drive REAR DIFF. PINION |
| 03901 1801 | 90311-38032 | 38 x 58 x 11 | HIACE (VAN, WAGON) YH51,61,LH51,61 | 87/8~ | Transmission (A/T) REAR EXTENTION |
| 03901 3281 | 90310-50001 | 50 x 70 x 9 | HIACE (VAN, WAGON) LH1##,KZH1##,RZH1## | 89/8~ | Wheel Hub REAR INNER |
| 03901 3205 | 90311-42026 | 42 x 60 x 7 | HIACE (VAN, WAGON) 2L,3L,5L LH10#,11#,16#,17#,18# | 91/8~ | Engine TIMING GEAR CASE |
| 03901 1057 | 90311-50136 | 50 x 68 x 9 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD | 82/12~89/ | Wheel Hub FRONT |
| 03901 6425 | 90311-50136 | 50 x 68 x 9 | HIACE (VAN, WAGON) RZH10#,11#,12#,133 2WD | 89/8~ | Wheel Hub FRONT |
| 03901 5873 | 90311-50136 | 50 x 68 x 9 | HIACE (VAN, WAGON) LH10#,11#,12#,140,162,172, 18#...2WD | 89/8~ | Wheel Hub FRONT |
| 03901 6067 | 90311-50136 | 50 x 68 x 9 | HIACE (VAN, WAGON) KZH100,110,120,132 2WD | 93/8~ | Wheel Hub FRONT |
| 03901 1941 | 90311-66001 | 66 x 85 x 8 x 10 | HIACE (VAN, WAGON) YH57,LH56,66 4WD | 86/8~89/ | Wheel Hub FRONT |
| 03901 7211 | 90311-66001 | 66 x 85 x 8 x 10 | HIACE (VAN, WAGON) LH107,109,117,119,129,168, 178,186,188 4WD | 89/8~ | Wheel Hub FRONT |
| 03901 4719 | 90311-38043 | 38 x 58 x 11 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7# | 82/12~88/ 8 | Transmission (M/T) REAR EXTENTION |
| 03901 4475 | 90310-50001 | 50 x 70 x 9 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...SI NGLE TIRE | 82/12~89/ | Wheel Hub REAR INNER |
| 03901 4575 | 90311-32012 | 32 x 53 x 7 | HIACE (VAN, WAGON) LH100,120,KZH10#,11#,12#. ..TD,TDE | 89/8~99/ | Transmission (M/T) FRONT COVER |
| 03901 5131 | 90311-62001 | 62 x 85 x 10 | HIACE (VAN, WAGON) YH61,LH6#...DOUBLE TIRE | 82/12~89/ | Wheel Hub REAR INNER |
| 03901 6293 | 90313-48001 | 48 x 62 x 9 x 24 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...SI NGLE TIRE | 82/12~89/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6389 | 90313-48001 | 48 x 62 x 9 x 24 | HIACE (VAN, WAGON) LH1##,KZH1##,RZH1## | 89/8~ | Wheel Hub REAR OUTER |
| 03901 5869 | 90310-35001 | 35 x 41 x 5.5 x 9 | HIACE (VAN, WAGON) YH61,LH6#...DOUBLE TIRE | 82/12~89/ | Wheel Hub REAR OUTER |
| 03901 1761 | 90311-30115 | 30 x 45 x 8 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD | 82/12~89/ | Transmission (M/T) FRONT COVER |
| 03901 2327 | 90311-30014 | 30 x 45 x 8 | HIACE (VAN, WAGON) LH10#,11#,12#,140,16#,17#, 18#...EXCEPT TD,TDE | 89/8~ | Transmission (M/T) FRONT COVER |
| 03901 5125 | 90311-30014 | 30 x 45 x 8 | HIACE (VAN, WAGON) RZH10#,11#,12# | 89/8~ | Transmission (M/T) FRONT COVER |
| 03901 8197 | 90311-38047 | 38 x 74 x 11 x 18 | HIACE (VAN, WAGON) LH10#,11#,12#,16#,17#,18# | 96/1~ | Final Drive REAR DIFF. PINION |
| 03901 4445 | 90311-66001 | 66 x 85 x 8 x 10 | HIACE (VAN, WAGON) KZH106,116,12#,138 4WD | 93/8~ | Wheel Hub FRONT |
| 03901 6741 | 90311-85007 | 85 x 105 x 10 | HIACE (VAN, WAGON) 2L,3L,5L LH10#,11#,12#,140,16#,17#, 18# | 91/2~ | Engine CRANK SHAFT REAR |
| 03901 5383 | 90311-36004 | 36 x 46 x 9 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7# | 82/12~89/ | Steering (M/S) SECTOR SHAFT |
| 03901 6923 | 90913-02110 | | HIACE (VAN, WAGON) 1RZ#,2RZE RZH10#,11#,12#,133 | 89/8~ | Engine VALVE STEM SEAL |
| 03901 2549 | 90311-38133 | 38 x 74 x 11 | HIACE (VAN, WAGON) KZH106,116,138,RZH101,11 1,133 4FC | 95/11~96/ 1 | Final Drive REAR DIFF. PINION |
| 03901 7465 | 90913-02110 | | HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13# | 93/8~97/1 0 | Engine VALVE STEM SEAL |
| 03901 5349 | 90913-02117 | | HIACE (VAN, WAGON) 3L,5L LH10#,11#,12#,16#,17#,18# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 7703 | 90913-02110 | | HIACE (VAN, WAGON) 2L,3L LH10#,11#,12#,140 | 89/8~97/4 | Engine VALVE STEM SEAL |
| 03901 3411 | 90913-02060 | | HIACE (VAN, WAGON) L,2L LH5#,6#,7# | 82/12~89/ 8 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7529 | 90913-02094 | | HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71 | 82/12~89/ | Engine VALVE STEM SEAL |
| 03901 3033 | 90311-58006 | 58 x 72 x 7 | HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13# | 93/8~ | Engine TIMING GEAR COVER |
| 03901 4395 | 90311-88005 | 88 x 106 x 8.5 | HIACE (VAN, WAGON) 1RZ#,2RZE RZH10#,11#12#,133 | 89/8~ | Engine CRANK SHAFT REAR |
| 03901 3265 | 90311-42003 | 42 x 60 x 7 | HIACE (VAN, WAGON) L,2L,3L LH5#,6#,7#,10#,11#,12#,140 | 82/12~91/ 8 | Engine TIMING GEAR CASE |
| 03901 2841 | 90311-85004 | 85 x 105 x 10 | HIACE (VAN, WAGON) L,2L,3L LH5#,6#,7#,10#,11#,12#,140 | 84/2~91/2 | Engine CRANK SHAFT REAR |
| 03901 5665 | 90311-85001 | 85 x 105 x 13 | HIACE (VAN, WAGON) L,2L LH5#,6#,7# | 82/12~84/ 2 | Engine CRANK SHAFT REAR |
| 03901 4137 | 90311-80003 | 80 x 100 x 8.5 | HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71 | 82/12~89/ | Engine CRANK SHAFT REAR |
| 03901 7827 | 90311-32020 | 32 x 46 x 6 | HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13# | 93/8~ | Engine CAM SHAFT |
| 03901 2513 | 90311-32020 | 32 x 46 x 6 | HIACE (VAN, WAGON) 2L,3L,5L LH10#,11#,140,16#,17#,18# | 89/8~ | Engine CAM SHAFT |
| 03901 5655 | 90311-42003 | 42 x 60 x 7 | HIACE (VAN, WAGON) L,2L LH5#,6#,7# | 82/12~89/ | Engine CAM SHAFT |
| 03901 3789 | 90311-50017 | 50 x 68 x 9 x 14.5 | HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13# | 93/8~ | Engine TIMING GEAR CASE |
| 03901 6631 | 90311-48020 | 48 x 68 x 7 | HIACE (VAN, WAGON) 1RZ#,2RZE RZH10#,11#,12#,133 | 89/8~ | Engine TIMING GEAR CASE |
| 03901 2969 | 90311-95008 | 95 x 115 x 9.5 x 12 | HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13# | 93/8~ | Engine CRANK SHAFT REAR |
| 03901 4193 | 04445-26060 | | HIACE (VAN, WAGON) RZH102,112,12# | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 4207 | 90311-15001 | 15 x 25 x 7 | HIACE (VAN, WAGON) LH10#,11#,RZH10#,11# | 89/8~93/ | Steering (M/S) RACK HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7115 | 04445-27013 | | HIACE (VAN, WAGON) LH11#,KZH1##,RZH1##...EXC. PROGRESSIVE P/S | 89/8~95/8 | Steering (P/S) R & P GASKET KIT |
| 03901 1039 | 04445-26020 | | HIACE (VAN, WAGON) LH100,107,RZH10#...PROGRESSIVE P/S | 89/8~93/8 | Steering (P/S) R & P GASKET KIT |
| 03901 5995 | 90913-02117 | | HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13# | 97/10~ | Engine VALVE STEM SEAL |
| 03901 7687 | 04445-26060 | | HIACE (VAN, WAGON) LH103,113,123,125,162,172, 182,184 | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 5767 | 90311-42026 | 42 x 60 x 7 | HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71 | 87/8~89/ | Engine TIMING GEAR COVER |
| 03901 5735 | 04445-26070 | | HIACE (VAN, WAGON) LH109,119,129,168,178,186, 188 | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 7335 | 04445-26070 | | HIACE (VAN, WAGON) RZH101,111,133,KZH10#,11#,12#,13# | 95/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 5531 | 90311-30016 | 30 x 42 x 7 x 8 | HIACE (VAN, WAGON) LH100,KZH10#,RZH100,101 SCL | 92/4~94/8 | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3503 | 90312-32002 | 32 x 40 x 5 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2WD | 82/12~89/ | Steering (P/S) GEAR HOUSING |
| 03901 7651 | 90311-19002 | 19 x 32 x 7 x 8 | HIACE (VAN, WAGON) YH57,LH56,66 (4WD) | 86/8~89/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6871 | 90311-19002 | 19 x 32 x 7 x 8 | HIACE (VAN, WAGON) LH1##,KZH1##,RZH1## | 89/8~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3213 | 90310-25004 | 25 x 38 x 7 x 8 | HIACE (VAN, WAGON) YH57,LH56,66 (4WD) | 86/8~89/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7485 | 90310-25004 | 25 x 38 x 7 x 8 | HIACE (VAN, WAGON) LH1##,KZH1##,RZH1##...EXC. PROGRESSIVE P/S | 89/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1607 | 90311-30016 | 30 x 42 x 7 x 8 | HIACE (VAN, WAGON) LH100,107,RZH10#...PROGRESSIVE P/S | 89/8~94/8 | Steering (P/S) CONTROL VALVE LOWER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4503 | 90311-19002 | 19 x 32 x 7 x 8 | HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD | 82/12~89/ | Steering (P/S) ADJUSTER PLUG |
| 03901 1753 | 04445-28051 | | HIACE (VAN, WAGON) KZH10#,RZH101 SUPER CUSTOM LIMITED | 93/8~94/8 | Steering (P/S) R & P GASKET KIT |
| 03901 6437 | 90311-42003 | 42 x 60 x 7 | HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71 | 82/12~87/ 8 | Engine TIMING GEAR COVER |
| 03901 8103 | 90311-32020 | 32 x 46 x 6 | HIACE REGIUS 5L LXH4# | 97/6~ | Engine CAM SHAFT |
| 03901 4799 | 90311-48020 | 48 x 68 x 7 | HIACE REGIUS 1RZE,3RZFE RCH4# | 97/4~ | Engine TIMING GEAR CASE |
| 03901 8041 | 90311-32020 | 32 x 46 x 6 | HIACE REGIUS 1KZTE KCH4# | 97/4~ | Engine CAM SHAFT |
| 03901 4767 | 90311-42026 | 42 x 60 x 7 | HIACE REGIUS 5L LXH4# | 97/6~ | Engine TIMING GEAR CASE |
| 03901 4387 | 90311-58006 | 58 x 72 x 7 | HIACE REGIUS 1KZTE KCH4# | 97/4~ | Engine TIMING GEAR COVER |
| 03901 1537 | 90311-95008 | 95 x 115 x 9.5 x 12 | HIACE REGIUS 1KZTE KCH4# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 3301 | 90913-02079 | | HIACE REGIUS 3RZFE(IN.) RCH41,47 | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6043 | 90311-85007 | 85 x 105 x 10 | HIACE REGIUS 5L LXH4# | 97/6~ | Engine CRANK SHAFT REAR |
| 03901 6427 | 90913-02110 | | HIACE REGIUS 1KZTE KCH4# | 97/4~97/1 0 | Engine VALVE STEM SEAL |
| 03901 6601 | 90913-02110 | | HIACE REGIUS 1RZE RCH42 | 97/6~ | Engine VALVE STEM SEAL |
| 03901 2331 | 90311-88005 | 88 x 106 x 8.5 | HIACE REGIUS 1RZE,3RZFE RCH4# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 7907 | 90913-02117 | | HIACE REGIUS 5L LXH4# | 97/6~ | Engine VALVE STEM SEAL |
| 03901 3723 | 90913-02062 | | HIACE REGIUS 3RZFE(EX.) RCH41,47 | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6659 | 90913-02117 | | HIACE REGIUS 1KZTE KCH4# | 97/10~ | Engine VALVE STEM SEAL |
| 03901 3469 | 90311-50136 | 50 x 68 x 9 | HIACE REGIUS KCH40,LXH43,RCH41,42 | 97/4~ | Wheel Hub FRONT |
| 03901 1165 | 90311-38029 | 38 x 55 x 7.5 | HIACE REGIUS KCH4# | 97/4~99/7 | Transmission (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3537 | 90311-50017 | 50 x 68 x 9 x 14.5 | HIACE REGIUS 1KZTE KCH4# | 97/4~ | Engine TIMING GEAR CASE |
| 03901 1803 | 90311-38029 | 38 x 55 x 7.5 | HIACE REGIUS KCH4#,RCH41,47 | 99/7~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7681 | 90311-38064 | 38 x 55 x 8.7 | HIACE REGIUS LXH4#,RCH42 | 00/5~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 3633 | 90311-38020 | 38 x 55 x 8.5 | HIACE REGIUS LXH4#,RCH42 | 99/7~00/5 | Transmission (A/T) FRONT OIL PUMP |
| 03901 1295 | 90311-38020 | 38 x 55 x 8.5 | HIACE REGIUS LXH4#,RCH41,47 | 97/4~99/7 | Transmission (A/T) FRONT OIL PUMP |
| 03901 2577 | 90311-38032 | 38 x 58 x 11 | HIACE REGIUS LXH4#,RCH42 | 97/6~ | Transmission (M/T) REAR EXTENTION |
| 03901 7423 | 04332-30030 | Kit | HIACE REGIUS LXH43,RCH41 | 97/4~99/7 | Transmission (A/T) REAR EXTENTION |
| 03901 4285 | 90311-66001 | 66 x 85 x 8 x 10 | HIACE REGIUS KCH46,LXH49,RCH47 (4WD) | 97/4~ | Wheel Hub FRONT |
| 03901 5903 | 90310-25004 | 25 x 38 x 7 x 8 | HIACE REGIUS KCH4#,LXH4#,RCH4# | 97/4~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7653 | 90311-19002 | 19 x 32 x 7 x 8 | HIACE REGIUS KCH4#,LXH4#,RCH4# | 97/4~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2645 | 04445-26050 | | HIACE REGIUS KCH4#,LXH4#,RCH4# | 97/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 7757 | 90311-38133 | 38 x 74 x 11 | HIACE REGIUS KCH4#,LXH4#,RCH4# | 97/4~ | Final Drive REAR DIFF. PINION |
| 03901 1653 | 90311-40001 | 40 x 58 x 11 | HIACE REGIUS KCH40,RCH41 | 99/7~ | Transmission (A/T) REAR EXTENTION |
| 03901 7343 | 90311-40001 | 40 x 58 x 11 | HIACE REGIUS KCH40 | 97/4~99/7 | Transmission (A/T) REAR EXTENTION |
| 03901 5999 | 90311-38032 | 38 x 58 x 11 | HIACE REGIUS LXH43,RCH42 | 99/7~ | Transmission (A/T) REAR EXTENTION |
| 03901 3193 | 90311-30014 | 30 x 45 x 8 | HIACE REGIUS LXH4#,RCH42 | 97/6~ | Transmission (M/T) FRONT COVER |
| 03901 3651 | 90311-45002 | 45 x 68 x 12 | HILUX 18RJ RN36,39 | 79/10~83/ | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2565 | 90311-32015 | 32 x 42 x 5 | HILUX YN60,65,YN100,105,LN60,65,100,106 | 88/1~97/ | Steering (P/S) GEAR HOUSING |
| 03901 8161 | 90311-32016 | 32 x 40 x 5 | HILUX YN8#,LN8# | 90/8~97/ | Steering (P/S) GEAR HOUSING |
| 03901 3815 | 90311-32016 | 32 x 40 x 5 | HILUX RZN147,152,LN147 | 97/8~ | Steering (P/S) GEAR HOUSING |
| 03901 7869 | 90311-36005 | 36 x 44 x 5 | HILUX LN107,108,109,112,13#,KZN130,YN107,130,VZN130 | 89/4~97/ | Steering (P/S) GEAR HOUSING |
| 03901 1637 | 90311-36005 | 36 x 44 x 5 | HILUX LN16#,173,RZN16#,174 | 97/8~ | Steering (P/S) GEAR HOUSING |
| 03901 4151 | 90311-19002 | 19 x 32 x 7 x 8 | HILUX KZN185,RZN183,VZN18# | 95/11~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7055 | 90311-38013 | 38.5 x 58 x 11 | HILUX 12RJ RN30,33,35,4# | 78/8~88/ | Engine TIMING GEAR COVER |
| 03901 6975 | 04445-35110 | | HILUX LN13#,VZN130,YN130 | 89/4~91/8 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3369 | 90311-42003 | 42 x 60 x 7 | HILUX 2Y#,3Y#...YN5#,6# | 83/11~87/6 | Engine TIMING GEAR COVER |
| 03901 7575 | 90311-42026 | 42 x 60 x 7 | HILUX 2Y#,3Y#...YN5#,6#,8#,10#,130 | 87/6~97/ | Engine TIMING GEAR COVER |
| 03901 6967 | 90311-58006 | 58 x 72 x 7 | HILUX 1KZTE KZN130,185 | 93/8~ | Engine TIMING GEAR COVER |
| 03901 5915 | 90311-42003 | 42 x 60 x 7 | HILUX L,2L,3L LN3#,4#,5#,6#,8#,10#,13# | 79/12~91/2 | Engine TIMING GEAR CASE |
| 03901 7963 | 90311-42026 | 42 x 60 x 7 | HILUX 2L,3L LN8#,10#,11#,13# | 91/2~97/ | Engine TIMING GEAR CASE |
| 03901 6433 | 90310-25004 | 25 x 38 x 7 x 8 | HILUX KZN185,RZN183,VZN18# | 95/11~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1071 | 90311-32014 | 32 x 44 x 9 | HILUX YN8#,LN8# | 91/8~94/ | Steering (M/S) SECTOR SHAFT |
| 03901 2661 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX LN8#,10#,112,YN8#,107 | 95/11~97/ | Final Drive REAR DIFF. PINION |
| 03901 7543 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX LN147,16#,17#,RZN147,152,16#,174 | 97/8~ | Final Drive REAR DIFF. PINION |
| 03901 7665 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX KZN185,RZN18#,VZN18# | 95/11~ | Final Drive REAR DIFF. PINION |
| 03901 5819 | 90311-19001 | 19 x 32 x 8 | HILUX RN30,33,35,4#,YN5#,8#,LN30,4#,5#,8# | 78/8~94/ | Steering (M/S) WORM GEAR |
| 03901 1441 | 90311-18010 | 18 x 30 x 8 | HILUX RN36,39,YN6#,LN36,46,6# | 79/10~89/ | Steering (M/S) WORM GEAR |
| 03901 3433 | 90311-18010 | 18 x 30 x 8 | HILUX LN106 | 88/9~94/ | Steering (M/S) WORM GEAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7473 | 90310-28027 | 28 x 40 x 8 | HILUX RN30,33,35,4#,YN5#,8#,LN 30,4#,5#,8# | 78/8~91/8 | Steering (M/S) SECTOR SHAFT |
| 03901 4471 | 04445-35180 | | HILUX LN16#,17#,RZN163,174 | 97/8~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6565 | 90311-32014 | 32 x 44 x 9 | HILUX LN106 | 88/9~94/ | Steering (M/S) SECTOR SHAFT |
| 03901 6099 | 04445-35160 | | HILUX KZN185,RZN18#,VZN183 | 95/11~ | Steering (P/S) R & P GASKET KIT |
| 03901 3665 | 90311-36004 | 36 x 46 x 9 | HILUX YN61,LN61 | 85/8~88/ | Steering (M/S) SECTOR SHAFT |
| 03901 4631 | 04445-35090 | | HILUX YN8#,LN83 | 90/8`91/8 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 4555 | 04445-35120 | | HILUX YN8#,LN8# | 91/8~97/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2867 | 04445-35120 | | HILUX RZN147,152,LN147 | 97/8~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7759 | 04445-35100 | | HILUX YN100,105,LN100,106 | 88/9~97/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 1019 | 90311-42003 | 42 x 60 x 7 | HILUX L,2L LN3#,4#,5#,6# | 79/12~89/ | Engine CAM SHAFT |
| 03901 2763 | 04445-35130 | | HILUX LN107,108,109,112,13#,KZN 130,YN107,VZN130 | 91/8~97/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6907 | 90311-32014 | 32 x 44 x 9 | HILUX RN36,39,YN60,65,LN36,46, 60,65 | 79/10~89/ | Steering (M/S) SECTOR SHAFT |
| 03901 4593 | 90913-02110 | | HILUX 5VZFE(IN.) VZN18# | 95/11~ | Engine VALVE STEM SEAL |
| 03901 7217 | 90913-02094 | | HILUX 2Y#,3Y#...YN8#,10#,130 | 88/9~97/ | Engine VALVE STEM SEAL |
| 03901 6839 | 90913-02036 | | HILUX L LN30,40 | 79/12~81/ 7 | Engine VALVE STEM SEAL |
| 03901 5789 | 90913-02060 | | HILUX L,2L LN3#,4# | 81/7~88/9 | Engine VALVE STEM SEAL |
| 03901 2391 | 90913-02110 | | HILUX 2L,3L LN8#,10#,11#,13# | 88/9~97/5 | Engine VALVE STEM SEAL |
| 03901 3057 | 90913-02117 | | HILUX 2L,3L,5L LN8#,10#,11#,13#,147,16#,1 7# | 97/5~ | Engine VALVE STEM SEAL |
| 03901 1573 | 90913-02110 | | HILUX 1KZTE KZN130,185 | 93/8~97/1 0 | Engine VALVE STEM SEAL |
| 03901 3169 | 90311-50017 | 50 x 68 x 9 x 14.5 | HILUX 1KZTE KZN130,185 | 93/8~ | Engine TIMING GEAR CASE |
| 03901 5701 | 90913-02110 | | HILUX 3VZE VZN130 | 90/8~95/ | Engine VALVE STEM SEAL |
| 03901 6037 | 90311-88005 | 88 x 106 x 8.5 | HILUX 1RZFE,3ZFE RZN147,152,16#,174,18# | 95/11~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6119 | 90913-02062 | | HILUX 5VZFE(EX.) VZN18# | 95/11~ | Engine VALVE STEM SEAL |
| 03901 3079 | 90913-02110 | | HILUX 3RZFE(IN.) RZN169,174,18# | 95/11~ | Engine VALVE STEM SEAL |
| 03901 6311 | 90913-02062 | | HILUX 3RZFE(EX.) RZN169,174,18# | 95/11~ | Engine VALVE STEM SEAL |
| 03901 5611 | 90913-02117 | | HILUX 1RZE RZN147,167 | 97/8~ | Engine VALVE STEM SEAL |
| 03901 7537 | 90913-02110 | | HILUX 1RZE RZN152 | 99/8~ | Engine VALVE STEM SEAL |
| 03901 6519 | 90311-38140 | 38 x 58 x 11 | HILUX RN36,39,YN6#,LN36,46,6# | 79/10~88/ | Transfer FRONT OUTPUT |
| 03901 7583 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX LN8#,100,106,107,109,13#,YN8#,10#,130 | 88/9~96/1 | Final Drive REAR DIFF. PINION |
| 03901 4177 | 90913-02117 | | HILUX 1KZTE KZN185 | 97/10~ | Engine VALVE STEM SEAL |
| 03901 6899 | 90311-80009 | 80 x 100 x 10 | HILUX 2Y#,3Y#...YN8#,10#,130 | 90/4~97/ | Engine CRANK SHAFT REAR |
| 03901 7143 | 90311-48020 | 48 x 68 x 7 | HILUX 1RZFE,3RZFE RZN147,152,16#,174,18# | 95/11~ | Engine TIMING GEAR CASE |
| 03901 1933 | 90311-32020 | 32 x 46 x 6 | HILUX 2L,3L LN8#,10#,11#,13# | 88/9~97/ | Engine CAM SHAFT |
| 03901 4509 | 90311-32020 | 32 x 46 x 6 | HILUX 2LTE,5L LN147,16#,17# | 97/8~ | Engine CAM SHAFT |
| 03901 7265 | 90311-32020 | 32 x 46 x 6 | HILUX 1KZTE KZN130,185 | 93/8~ | Engine CAM SHAFT |
| 03901 6315 | 90311-42027 | 742 x 55 x 8 | HILUX 3VZE VZN130 | 90/8`95/ | Engine CAM SHAFT |
| 03901 3605 | 90311-38051 | 38 x 50 x 10 | HILUX 5VZFE VZN18# | 95/11~ | Engine CAM SHAFT |
| 03901 8151 | 90311-40022 | 40 x 55 x 6 | HILUX 3VZE,5VZFE VZN130,18# | 90/8~ | Engine OIL PUMP |
| 03901 5753 | 90913-02016 | | HILUX 18RJ RN36,39 | 79/10~83/ | Engine VALVE STEM SEAL |
| 03901 8053 | 90311-80003 | 80 x 100 x 8.5 | HILUX 2Y#,3Y#...YN5#,6#,8#,10#,130 | 83/11~90/4 | Engine CRANK SHAFT REAR |
| 03901 7171 | 90913-02033 | | HILUX 12RJ RN30,33,35,$ | 78/8`88/ | Engine VALVE STEM SEAL |
| 03901 7467 | 90311-85001 | 85 x 105 x 13 | HILUX L,2L LN3#,4#,5#,6# | 79/12~84/2 | Engine CRANK SHAFT REAR |
| 03901 8263 | 90311-85004 | 85 x 105 x 10 | HILUX L,2L,3L LN4#,5#,6#,8#,10#,13# | 84/2~91/2 | Engine CRANK SHAFT REAR |
| 03901 1025 | 90311-85007 | 85 x 105 x 10 | HILUX 2L,3L LN8#,10#,11#,13# | 91/2~97/ | Engine CRANK SHAFT REAR |
| 03901 3285 | 90311-85007 | 85 x 105 x 10 | HILUX 2LTE,5L LN147,16#,17# | 97/8~ | Engine CRANK SHAFT REAR |
| 03901 5399 | 90311-95008 | 95 x 115 x 9.5 x 12 | HILUX 1KZTE KZN130,185 | 93/8~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4691 | 90311--92006 | 92 x 110 x 9.5 | HILUX 3VZE,5VZFE VZN130,18# | 90/8~ | Engine CRANK SHAFT REAR |
| 03901 7323 | 90311-42026 | 42 x 60 x 7 | HILUX 2LTE,5L LN147,16#,17# | 97/8~ | Engine TIMING GEAR CASE |
| 03901 3513 | 90311-80001 | 80 x 100 x 12 | HILUX 18RJ RN36,39 | 79/10~83/ | Engine CRANK SHAFT REAR |
| 03901 3477 | 90311-30014 | 30 x 45 x 8 | HILUX YN8#,10#,130,LN8#,10#,131 | 88/9~97/ | Transmission (M/T) FRONT COVER |
| 03901 5617 | 90311-38020 | 38 x 55 x 8.5 | HILUX LN56,85,YN86,RZN147,152 | 83/11~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 5923 | 90313-48001 | 48 x 62 x 9 x 24 | HILUX LN147,16#,17#,RZN147,167 | 97/8~98/5 | Wheel Hub REAR OUTER |
| 03901 3641 | 90313-48001 | 48 x 62 x 9 x 24 | HILUX LN147,RZN147,152 | 98/5~ | Wheel Hub REAR OUTER |
| 03901 1925 | 90313-54001 | 54 x 64 x 9 x 24 | HILUX LN16#,17#,RZN16#,174 | 98/5~ | Wheel Hub REAR OUTER |
| 03901 2183 | 90311-32106 | 32 x 48 x 8 | HILUX RN3#,4# | 78/8~85/ | Transmission (M/T) FRONT COVER |
| 03901 2193 | 90311-32106 | 32 x 48 x 8 | HILUX YN5#...4H | 83/11~85/ | Transmission (M/T) FRONT COVER |
| 03901 4399 | 90313-48001 | 48 x 62 x 9 x 24 | HILUX LN30,4#,5#,6#,8#,10# | 78/8~97/ | Wheel Hub REAR OUTER |
| 03901 1649 | 90311-30115 | 30 x 45 x 8 | HILUX YN5#,6#,LN5#,6#...5H,5F | 83/11~89/ | Transmission (M/T) FRONT COVER |
| 03901 5481 | 90313-48001 | 48 x 62 x 9 x 24 | HILUX RN#,YN#,KZN#,VZN# | 78/8~97/ | Wheel Hub REAR OUTER |
| 03901 6123 | 90311-30014 | 30 x 45 x 8 | HILUX RZN147,167,LN147,167,172 | 97/8~ | Transmission (M/T) FRONT COVER |
| 03901 3257 | 90311-30014 | 30 x 45 x 8 | HILUX RZN185 | 95/11~ | Transmission (M/T) FRONT COVER |
| 03901 1231 | 90311-32012 | 32 x 53 x 7 | HILUX LN130,KZN130,VZN130 | 89/4~95/ | Transmission (M/T) FRONT COVER |
| 03901 1383 | 90311-32012 | 32 x 53 x 7 | HILUX KZN185 | 95/11~ | Transmission (M/T) FRONT COVER |
| 03901 5685 | 90311-38043 | 38 x 58 x 11 | HILUX RN3#,4#,YN5#,LN30,4#,5# | 78/8~88/ | Transmission (M/T) REAR EXTENTION |
| 03901 2113 | 90311-38032 | 38 x 58 x 11 | HILUX YN8#,LN8# | 88/9~97/ | Transmission (M/T) REAR EXTENTION |
| 03901 7983 | 90311-38032 | 38 x 58 x 11 | HILUX LN147,RZN147 | 97/8~ | Transmission (M/T) REAR EXTENTION |
| 03901 4311 | 90311-30115 | 30 x 45 x 8 | HILUX LN3#,4# | 79/12~88/ | Transmission (M/T) FRONT COVER |
| 03901 1799 | 90311-66001 | 66 x 85 x 8 x 10 | HILUX YN107,LN107,108,109,112 (4WD) | 91/8~97/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8209 | 90311-50136 | 50 x 68 x 9 | HILUX RN3#,4#,LN30,4#...2WD | 78/8~88/ | Wheel Hub FRONT |
| 03901 3801 | 90311-50136 | 50 x 68 x 9 | HILUX YN5#,LN5# | 83/11~88/ | Wheel Hub FRONT |
| 03901 4611 | 90311-50136 | 50 x 68 x 9 | HILUX YN8#,LN8# | 88/9~97/ | Wheel Hub FRONT |
| 03901 4435 | 90311-50136 | 50 x 68 x 9 | HILUX RZN147,152,LN147 | 97/8~ | Wheel Hub FRONT |
| 03901 6945 | 90311-62001 | 62 x 85 x 10 | HILUX RN36,39,LN36,46 (4WD) | 79/10~83/ | Wheel Hub FRONT |
| 03901 3625 | 90311-62001 | 62 x 85 x 10 | HILUX YN60,65,LN60,65 (4WD) | 83/11~88/ | Wheel Hub FRONT |
| 03901 4277 | 90313-48001 | 48 x 62 x 9 x 24 | HILUX KZN185,RZN18#,VZN18# | 95/11~ | Wheel Hub REAR OUTER |
| 03901 7137 | 90311-66001 | 66 x 85 x 8 x 10 | HILUX YN61,LN61 (4WD) | 85/8~89/ | Wheel Hub FRONT |
| 03901 6041 | 90311-33085 | 33 x 44 x 8 | HILUX RN36,39,YN36,46,60,65 (4WD) | 79/10~88/ | Wheel Hub FRONT DRIVE SHAFT |
| 03901 1469 | 90311-66001 | 66 x 85 x 8 x 10 | HILUX YN130,VZN130,LN13#,KZN 130 (4WD) | 89/4~95/ | Wheel Hub FRONT |
| 03901 6013 | 90311-66001 | 66 x 85 x 8 x 10 | HILUX RZN16#,174,LN16#,17# (4WD) | 97/8~ | Wheel Hub FRONT |
| 03901 6577 | 90311-41008 | 41 x 59 x 10 x 15 | HILUX LN106,109,112,13#,KZN130, YN130,VZN130 | 89/4~97/ | Transfer FRONT OUTPUT |
| 03901 4343 | 90312-95001 | 90 x 108 x 10 x 12 | HILUX KZN185,RZN18#,VZN18# | 95/11~ | Wheel Hub FRONT OUTER |
| 03901 5691 | 90311-38133 | 38 x 74 x 11 | HILUX KZN130,LN108,112,130,VZ N130 | 90/8~95/1 1 | Final Drive REAR DIFF. PINION |
| 03901 7987 | 90311-33085 | 33 x 44 x 8 | HILUX YN100,105,LN100,106 (4WD) | 88/9~97/ | Wheel Hub FRONT DRIVE SHAFT |
| 03901 8195 | 90310-50001 | 50 x 70 x 9 | HILUX RN#,YN#,RZN#,LN#,KZN#, VZN# | 78/8~ | Wheel Hub REAR INNER |
| 03901 1953 | 90311-62001 | 62 x 85 x 10 | HILUX YN100,105,LN100,106 (4WD) | 88/9~97/ | Wheel Hub FRONT |
| 03901 5783 | 90311-40021 | 40 x 58 x 7.8 | HILUX KZN185,RZN185,VZN185 | 95/11~ | Transfer TRANSFER COVER |
| 03901 1597 | 90311-41007 | 41 x 61 x 8 x 13 | HILUX LN107,YN107 SSR | 91/8~97/ | Transfer REAR OUTPUT |
| 03901 2675 | 90311-41007 | 41 x 61 x 8 x 13 | HILUX LN16#,17#,RZN16#,174 | 97/8~ | Transfer REAR OUTPUT |
| 03901 6035 | 90311-41007 | 41 x 61 x 8 x 13 | HILUX KZN185,RZN185,VZN185 | 95/11~ | Transfer REAR OUTPUT |
| 03901 2415 | 90311-40007 | 40.5 x 58 x 8 | HILUX LN108,109,112,13#,KZN130, YN130,VZN130 | 89/4~95/6 | Transfer TRANSFER COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4625 | 90311-40007 | 40.5 x 58 x 8 | HILUX LN107,YN107 SSR | 91/8~95/6 | Transfer TRANSFER COVER |
| 03901 8175 | 90311-40021 | 40 x 58 x 7.8 | HILUX LN108,109,112,13#,KZN130, YN130,VZN130 | 95/6~97/ | Transfer TRANSFER COVER |
| 03901 5787 | 90311-41007 | 41 x 61 x 8 x 13 | HILUX LN108,109,112,13#,KZN130, YN130,VZN130 | 89/4~97/ | Transfer REAR OUTPUT |
| 03901 7705 | 90311-40021 | 40 x 58 x 7.8 | HILUX LN16#,173,RZN16#,174 | 97/8~ | Transfer TRANSFER COVER |
| 03901 1427 | 90311-38134 | 38 x 74 x 11 | HILUX RN36,39,YN6#,LN36,46,6# | 79/10~89/ | Final Drive FRONT DIFF. PINION |
| 03901 5409 | 90311-38134 | 38 x 74 x 11 | HILUX LN107,108,109,112,13#,KZN 130,YN107,130,VZN130 | 89/4~96/1 | Final Drive FRONT DIFF. PINION |
| 03901 2795 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX LN10#,112,YN107 | 96/1~97/ | Final Drive FRONT DIFF. PINION |
| 03901 4321 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX LN16#,17#,RZN16#,174 | 97/8~ | Final Drive FRONT DIFF. PINION |
| 03901 4379 | 90311-38049 | 38 x 74 x 11 x 17.5 | HILUX KZN185,RZN185,VZN185 | 95/11~ | Final Drive FRONT DIFF. PINION |
| 03901 3267 | 90311-38133 | 38 x 74 x 11 | HILUX RN3#,4#,YN5#,6#,LN3#,4#, 5#,6# | 78/8~88/ | Final Drive REAR DIFF. PINION |
| 03901 4941 | 90311-38029 | 38 x 55 x 7.5 | HILUX YN61,130,LN108,112,130,V ZN130,KZN130 | 86/8~97/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2205 | 90316-69001 | 69 x 86 x 7 x 15 | HILUX KZN185,RZN185,VZN185 | 95/11~ | Wheel Hub FRONT INNER |
| 03901 2279 | 90311-40021 | 40 x 58 x 7.8 | HILUX LN107,YN107 SSR | 95/6~97/ | Transfer TRANSFER COVER |
| 03901 2507 | 90311-32009 | 32 x 52 x 8 | HILUX RN36,39,YN6#,LN36,46,6# | 79/10~88/ | Transfer INPUT |
| 03901 2829 | 90311-38029 | 38 x 55 x 7.5 | HILUX LN165,170,RZN169,174 | 97/8~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1919 | 90311-38047 | 38 x 74 x 11 x 18 | HILUX LN100,106,YN100,105 | 88/9~96/1 | Final Drive FRONT DIFF. PINION |
| 03901 2111 | 90311-38140 | 38 x 58 x 11 | HILUX YN10#,LN100,106,107 | 88/9~97/ | Transfer REAR OUTPUT |
| 03901 3557 | 04332-30020 | Kit | HILUX LN56 | 83/11~88/ | Transmission (A/T) REAR EXTENTION |
| 03901 4747 | 90311-40001 | 40 x 58 x 11 | HILUX RZN180,VZN180 | 98/7~ | Transmission (A/T) REAR EXTENTION |
| 03901 4931 | 90311-38029 | 38 x 55 x 7.5 | HILUX KZN185,RZN18#,VZN18# | 95/11~ | Transmission (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3681 | 90311-32009 | 32 x 52 x 8 | HILUX YN10#,LN100,106,107 | 88/9~97/ | Transfer INPUT |
| 03901 1447 | 90311-40007 | 40.5 x 58 x 8 | HILUX LN108,109,112,13#,KZN130, YN130,VZN130 | 89/4~97/ | Transfer INPUT |
| 03901 1203 | 90311-41008 | 41 x 59 x 10 x 15 | HILUX LN16#,17#,RZN16#,174 | 97/8~ | Transfer FRONT OUTPUT |
| 03901 4227 | 90311-40007 | 40.5 x 58 x 8 | HILUX LN16#,17#,RZN16#,174 | 97/8~ | Transfer INPUT |
| 03901 6055 | 90311-40007 | 40.5 x 58 x 8 | HILUX KZN185,RZN185,VZN185 | 95/11~ | Transfer INPUT |
| 03901 5977 | 90311-38140 | 38 x 58 x 11 | HILUX YN10#,LN100,106,107 | 88/9~97/ | Transfer FRONT OUTPUT |
| 03901 2729 | 90311-41008 | 41 x 59 x 10 x 15 | HILUX LN107,YN107 SSR | 91/8~97/ | Transfer FRONT OUTPUT |
| 03901 7733 | 90311-40007 | 40.5 x 58 x 8 | HILUX LN107,YN107 SSR | 91/8~97/ | Transfer INPUT |
| 03901 6011 | 90311-38140 | 38 x 58 x 11 | HILUX RN36,39,YN6#,LN36,46,6# | 79/10~88/ | Transfer REAR OUTPUT |
| 03901 7893 | 04332-30030 | Kit | HILUX YN86,LN85,RZN147,152 | 88/9~ | Transmission (A/T) REAR EXTENTION |
| 03901 4529 | 90311-41008 | 41 x 59 x 10 x 15 | HILUX KZN185,RZN185,VZN185 | 95/11~ | Transfer FRONT OUTPUT |
| 03901 2405 | 90311-35033 | 35 x 55 x 9 x 15.5 | IPSUM / GAIA CXM10,SXM10 | 96/5~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 5235 | 90311-85007 | 85 x 105 x 10 | IPSUM / GAIA 3SFE SXM1# | 96/5~ | Engine CRANK SHAFT REAR |
| 03901 7227 | 90913-02117 | | IPSUM / GAIA 3CTE | 97/9~ | Engine VALVE STEM SEAL |
| 03901 7483 | 90913-02062 | | IPSUM / GAIA 3SFE(EX.) | 96/5~ | Engine VALVE STEM SEAL |
| 03901 5589 | 90311-35020 | 35 x 63 x 9 x 15.5 | IPSUM / GAIA CXM10,SXM1# | 96/5~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1693 | 90311-90008 | 90 x 110 x 9.5 x 11.5 | IPSUM / GAIA 3CTE CXM10 | 97/9~ | Engine CRANK SHAFT REAR |
| 03901 5003 | 90311-42026 | 42 x 60 x 7 | IPSUM / GAIA 3CTE CXM10 | 97/9~ | Engine CRANK SHAFT FRONT |
| 03901 4951 | 90311-42035 | 42 x 60 x 7 | IPSUM / GAIA 3SFE SXM1# | 96/9~ | Engine CRANK SHAFT FRONT |
| 03901 4973 | 90311-42026 | 42 x 60 x 7 | IPSUM / GAIA 3SFE SXM1# | 96/5~96/9 | Engine CRANK SHAFT FRONT |
| 03901 5587 | 15165-70010 | 18 x 30 x 7 | IPSUM / GAIA 3SFE SXM1# | 96/5~ | Engine OIL PUMP |
| 03901 3985 | 90311-38067 | 38 x 50 x 8 | IPSUM / GAIA 3SFE SXM1# | 97/8~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5333 | 90311-38036 | 38 x 50 x 8 | IPSUM / GAIA 3SFE SXM1# | 96/5~97/8 | Engine CAM SHAFT |
| 03901 3429 | 04445-20161 | | IPSUM / GAIA SXM15 | 98/4~ | Steering (P/S) R & PGASKET KIT |
| 03901 8217 | 90913-02079 | | IPSUM / GAIA 3SFE(IN.) | 96/5~ | Engine VALVE STEM SEAL |
| 03901 7209 | 90311-38044 | 38 x 50 x 6 | IPSUM / GAIA 3CTE CXM10 | 97/9~ | Engine CAM SHAFT |
| 03901 6097 | 90311-49002 | 50 x 64 x 8 | IPSUM / GAIA SXM15 | 98/4~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1777 | 04445-20210 | | IPSUM / GAIA CXM10,SXM10 | 96/5~ | Steering (P/S) R & PGASKET KIT |
| 03901 2141 | 04445-20161 | | IPSUM / GAIA SXM10 FRIEND MATIC | 97/8~ | Steering (P/S) R & PGASKET KIT |
| 03901 2579 | 90311-19002 | 19 x 32 x 7 x 8 | IPSUM / GAIA CXM10,SXM1# | 96/5~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2135 | 90310-25004 | 25 x 38 x 7 x 8 | IPSUM / GAIA SXM15 | 96/5~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6065 | 90310-25004 | 25 x 38 x 7 x 8 | IPSUM / GAIA SXM10 FRIEND MATIC | 97/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5523 | 90310-28003 | 28 x 41 x 6.5 | IPSUM / GAIA CXM10,SXM10 | 96/5~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3929 | 90311-38020 | 38 x 55 x 8.5 | IPSUM / GAIA CXM10,SXM1# | 96/5~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4359 | 90913-02101 | | KLUGER-V 1MZFE,2AZFE (IN.) | 00/11~ | Engine VALVE STEM SEAL |
| 03901 5677 | 90311-89003 | 89 x 105 x 10 | KLUGER-V 2AZFE ACU2# | 00/11~ | Engine CRANK SHAFT REAR |
| 03901 3291 | 90311-52005 | 52 x 75 x 7.5 x 12 | KLUGER-V ACU25,MCU25 (4WD) | 00/11~ | Wheel Hub REAR OUTER |
| 03901 2663 | 04445-48010 | | KLUGER-V ACU2#,MCU2# | 00/11~ | Steering (P/S) R & P GASKET KIT |
| 03901 6685 | 90311-92008 | 92 x 110 x 9 | KLUGER-V 1MZFE MCU2# | 00/11~ | Engine CRANK SHAFT REAR |
| 03901 7843 | 90311-38059 | 38 x 50 x 8 | KLUGER-V 2AZFE ACU2# | 00/11~ | Engine TIMING GEAR CASE |
| 03901 2083 | 90311-40022 | 40 x 55 x 6 | KLUGER-V 1MZFE MCU2# | 00/11~ | Engine OIL PUMP |
| 03901 1519 | 90311-38034 | 38 x 50 x 10.5 | KLUGER-V 1MZFE MCU2# | 00/11~ | Engine CAM SHAFT |
| 03901 1149 | 90311-38064 | 38 x 8.7 x | KLUGER-V ACU2#,MCU2# | 00/11~ | Mission & Differential (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7387 | 90311-50026 | 50 x 68 x 9 x 15.5 | KLUGER-V ACU20 | 00/11~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 2427 | 90311-50011 | 50 x 80 x 16.5 x 23 | KLUGER-V ACU25,MCU2# | 00/11~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 2653 | 90311-62004 | 62 x 74 x 8.5 | KLUGER-V ACU25,MCU25 (4WD) | 00/11~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3453 | 90311-40010 | 40 x 56 x 9 x 15.5 | KLUGER-V MCU20 | 00/11~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 8157 | 90311-56015 | 56 x 75 x 7 x 12 | KLUGER-V ACU25,MCU25 (4WD) | 00/11~ | Wheel Hub REAR INNER |
| 03901 6203 | 90913-02111 | | KLUGER-V 1MZFE,2AZFE ( | 00/11~ | Engine VALVE STEM SEAL |
| 03901 5361 | 90311-40026 | 40 x 64 x 9 x 15.5 | KLUGER-V ACU20 | 00/11~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1775 | 04445-35160 | | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 1771 | 04445-60030 | | LAND CRUISER BJ61,HJ6#,FJ62 | 84/11~87/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 3269 | 90311-18010 | 18 x 30 x 8 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# | 84/11~90/ | Steering (M/S) WORM GEAR |
| 03901 3203 | 90311-18010 | 18 x 30 x 8 | LAND CRUISER FJ75,HZJ75 | 90/6~99/ | Steering (M/S) WORM GEAR |
| 03901 1173 | 90311-19001 | 19 x 32 x 8 | LAND CRUISER FJ6#,BJ6# | 80/8~84/11 | Steering (M/S) WORM GEAR |
| 03901 5325 | 90311-32014 | 32 x 44 x 9 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~84/ | Steering (M/S) SECTOR SHAFT |
| 03901 7453 | 90311-36104 | 36 x 50 x 7 | LAND CRUISER FJ6#,BJ6# | 80/8~84/11 | Steering (M/S) SECTOR SHAFT |
| 03901 7079 | 90311-36004 | 36 x 46 x 9 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# | 84/11~90/ | Steering (M/S) SECTOR SHAFT |
| 03901 4825 | 90311-36005 | 36 x 44 x 5 | LAND CRUISER HZJ7#,KZJ7#,LJ7#,PZJ7# | 90/1~ | Steering (P/S) GEAR HOUSING |
| 03901 5053 | 04445-60020 | | LAND CRUISER BJ6#,HJ60,FJ6# | 80/8~84/11 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 7277 | 90311-38066 | 38 x 74 x 11 x 48 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 2631 | 04445-60030 | | LAND CRUISER LJ71,BJ7# | 84/11~90/ | Steering (P/S) P/S GEAR GASKET KIT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2101 | 04445-60040 | | LAND CRUISER HZJ7#,LJ7#,PZJ7# | 90/1~92/8 | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6207 | 04445-60070 | | LAND CRUISER HZJ7#,LJ7#,PZJ7#,KZJ7# | 92/8~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5345 | 04445-60050 | | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 4157 | 04445-60080 | | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Steering (P/S) R & P GASKET KIT |
| 03901 1005 | 90311-19002 | 19 x 32 x 7 x 8 | LAND CRUISER FJ4#,6#,BJ4#,6#,7#,HJ6#,LJ7# | 80/8~90/ | Steering (P/S) ADJUSTER PLUG |
| 03901 2031 | 90311-50014 | 50 x 70 x 10 x 16 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Transfer FRONT OUTPUT |
| 03901 6305 | 90311-36004 | 36 x 46 x 9 | LAND CRUISER FJ75,HZJ75 | 90/6~99/ | Steering (M/S) SECTOR SHAFT |
| 03901 1959 | 90311-38133 | 38 x 74 x 11 | LAND CRUISER KZJ7#,LJ7# | 90/4~95/11 | Final Drive REAR DIFF. PINION |
| 03901 7329 | 90311-95008 | 95 x 115 x 9.5 x 12 | LAND CRUISER 1PZ PZJ7# | 90/1~94/ | Engine CRANK SHAFT REAR |
| 03901 4005 | 90311-35004 | 35 x 55 x 11 | LAND CRUISER FJ4#,5#,BJ4#,6#,7#HJ6# | 69/3~90/ | P.T.O. BEARING RETAINER |
| 03901 4259 | 90311-35004 | 35 x 55 x 11 | LAND CRUISER HZJ70,PZJ70 | 90/1~99/ | P.T.O. BEARING RETAINER |
| 03901 4705 | 90311-38134 | 38 x 74 x 11 | LAND CRUISER FJ4#,5#,BJ4#,6#,7#HJ6#,LJ7# | 69/3~90/ | Final Drive FRONT DIFF. PINION |
| 03901 4627 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#,PZJ7# | 90/1~ | Final Drive FRONT DIFF. PINION |
| 03901 6467 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Final Drive FRONT DIFF. PINION |
| 03901 3827 | 90311-38049 | 38 x 74 x 11 x 17.5 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Final Drive FRONT DIFF. PINION |
| 03901 2369 | 90311-18010 | 18 x 30 x 8 | LAND CRUISER FJ4#,5#,BJ4# | 72/4~84/ | Steering (M/S) WORM GEAR |
| 03901 1219 | 90311-38133 | 38 x 74 x 11 | LAND CRUISER FJ4#,5#,BJ4#,6#,7#HJ6#,LJ7# | 69/3~90/ | Final Drive REAR DIFF. PINION |
| 03901 1369 | 90311-18021 | 18 x 32 x 7 | LAND CRUISER FJ55 | 69/3~72/4 | Steering (M/S) WORM GEAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1029 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER KZJ7#,LJ7#...WITH DIFF. LOCK | 90/4~95/12 | Final Drive REAR DIFF. PINION |
| 03901 4103 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER KZJ7# | 95/11~96/ | Final Drive REAR DIFF. PINION |
| 03901 3755 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER FJ75,HZJ7#,PZJ7# | 90/1~98/1 | Final Drive REAR DIFF. PINION |
| 03901 1127 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Final Drive REAR DIFF. PINION |
| 03901 7673 | 90311-38047 | 38 x 74 x 11 x 18 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Final Drive REAR DIFF. PINION |
| 03901 3551 | 90311-38066 | 38 x 74 x 11 x 48 | LAND CRUISER HZJ7# | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 2625 | 90311-36005 | 36 x 44 x 5 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Steering (P/S) GEAR HOUSING |
| 03901 4971 | 90311-38066 | 38 x 74 x 11 x 48 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Final Drive FRONT DIFF. PINION |
| 03901 7881 | 90311-43006 | 43 x 60 x 7 | LAND CRUISER 2UZFE UZJ100 | 98/1~ | Engine OIL PUMP |
| 03901 5811 | 90311-48020 | 48 x 68 x 7 | LAND CRUISER 3RZFE RZJ9# | 97/4~ | Engine TIMING GEAR CASE |
| 03901 6735 | 90312-32001 | 32 x 42 x 5 | LAND CRUISER FJ4#,BJ4# | 81/10~84/ | Steering (P/S) GEAR HOUSING |
| 03901 1979 | 90311-32020 | 32 x 46 x 6 | LAND CRUISER 2L LJ7# | 90/4~93/ | Engine CAM SHAFT |
| 03901 1609 | 90311-32020 | 32 x 46 x 6 | LAND CRUISER 1K#...KZJ7#,9#,KDJ9# | 93/5~ | Engine CAM SHAFT |
| 03901 7167 | 90311-32020 | 32 x 46 x 6 | LAND CRUISER 1H#...HZJ7#,81,HDJ81,101 | 90/1~ | Engine CAM SHAFT |
| 03901 2709 | 90311-38051 | 38 x 50 x 10 | LAND CRUISER 5VZFE VZJ9# | 96/4~ | Engine CAM SHAFT |
| 03901 4721 | 90312-32002 | 32 x 40 x 5 | LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7# | 80/8~90/ | Steering (P/S) GEAR HOUSING |
| 03901 1931 | 90311-40022 | 40 x 55 x 6 | LAND CRUISER 5VZFE VZJ9# | 96/4~ | Engine OIL PUMP |
| 03901 1899 | 90311-58007 | 58.5 x 75 x 9 x 14.5 | LAND CRUISER 1PZ PZJ7# | 90/1~94/ | Engine TIMING GEAR COVER (NO.2) |
| 03901 3147 | 90311-99065 | 100 x 120 x 11 | LAND CRUISER F,2F,3F FJ4#,5#,6# | 69/3~85/6 | Engine CRANK SHAFT REAR |
| 03901 1605 | 90311-99005 | 105 x 120 x 11 | LAND CRUISER 3F FJ6#,75,80 | 85/6~92/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6699 | 90311-99009 | 99 x 119 x 9.5 | LAND CRUISER 1FZFE FZJ80 | 92/8~98/ | Engine CRANK SHAFT REAR |
| 03901 5267 | 90311-95001 | 95 x 115 x 12 | LAND CRUISER B,2B,3B,13B BJ4#,6#,7# | 74/2~88/8 | Engine CRANK SHAFT REAR |
| 03901 4367 | 90311-95001 | 95 x 115 x 12 | LAND CRUISER 2H,12H HJ6# | 82/10~90/ | Engine CRANK SHAFT REAR |
| 03901 5505 | 90311-95008 | 95 x 115 x 9.5 x 12 | LAND CRUISER 3B,13B BJ7# | 88/8~90/ | Engine CRANK SHAFT REAR |
| 03901 4613 | 90311-95008 | 95 x 115 x 9.5 x 12 | LAND CRUISER 1H#...HZJ7#,81,HDJ81,101 | 90/1~ | Engine CRANK SHAFT REAR |
| 03901 7405 | 90311-38065 | 38 x 85 x 10 | LAND CRUISER 2UZFE UZJ100 | 98/1~ | Engine CAM SHAFT |
| 03901 6643 | 90311-50013 | 50 x 72 x 9 x 14 | LAND CRUISER 3B,13B BJ7# | 88/8~90/ | Engine TIMING GEAR COVER |
| 03901 4785 | 90311-19002 | 19 x 32 x 7 x 8 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1291 | 90311-19002 | 19 x 32 x 7 x 8 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1755 | 90310-25004 | 25 x 38 x 7 x 8 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 7873 | 90310-25004 | 25 x 38 x 7 x 8 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3761 | 90311-45002 | 45 x 68 x 12 | LAND CRUISER F,2F FJ4#,5#,6# | 69/3~84/10 | Engine TIMING GEAR COVER |
| 03901 3777 | 90311-45008 | 45 x 68 x 8.5 | LAND CRUISER 2F,3F FJ6#,75,80 | 84/10~92/ | Engine TIMING GEAR COVER |
| 03901 5389 | 90311-52013 | 52 x 70 x 8.5 | LAND CRUISER 1FZFE FZJ80 | 92/8~98/ | Engine TIMING GEAR COVER |
| 03901 5043 | 90311-50017 | 50 x 68 x 9 x 14.5 | LAND CRUISER 1K#...KZJ7#,9#,KDJ9# | 93/5~ | Engine TIMING GEAR CASE |
| 03901 5173 | 90311-50006 | 50 x 72 x 12 | LAND CRUISER 2H,12H HJ6# | 82/10~90/ | Engine TIMING GEAR COVER |
| 03901 6507 | 90311-42003 | 42 x 60 x 7 | LAND CRUISER 2L LJ7# | 85/10~93/ | Engine TIMING GEAR CASE |
| 03901 1123 | 90311-58006 | 58 x 72 x 7 | LAND CRUISER 1HZ,1HD#...HZJ7#,81,HDJ81 | 90/1~ | Engine TIMING GEAR COVER (NO.1) |
| 03901 2559 | 90311-58006 | 58 x 72 x 7 | LAND CRUISER 1PZ PZJ7# | 90/1~94/ | Engine TIMING GEAR COVER (NO.1) |
| 03901 2169 | 90311-65003 | 65 x 79 x 7 | LAND CRUISER 1HDFTE HDJ101 | 98/1~ | Engine TIMING GEAR COVER (NO.1) |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7595 | 90311-58006 | 58 x 72 x 7 | LAND CRUISER 1KZTE KZJ7#,9# | 93/5~00/ | Engine TIMING GEAR COVER |
| 03901 3539 | 90311-65003 | 65 x 79 x 7 | LAND CRUISER 1KDFTV KDJ9# | 00/8~ | Engine TIMING GEAR COVER |
| 03901 2167 | 90311-58007 | 58.5 x 75 x 9 x 14.5 | LAND CRUISER 1HZ,1HD#...HZJ7#,81,HDJ81,101 | 90/1~ | Engine TIMING GEAR COVER (NO.2) |
| 03901 2061 | 90311-50014 | 50 x 70 x 10 x 16 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Transfer FRONT OUTPUT |
| 03901 4467 | 90311-50006 | 50 x 72 x 12 | LAND CRUISER B,2B,3B,13B BJ4#,6#,7# | 74/2~88/8 | Engine TIMING GEAR COVER |
| 03901 5435 | 90313-62001 | 62 x 81 x 7.5 x 17.5 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Wheel Hub REAR OUTER |
| 03901 5651 | 90310-35001 | 35 x 41 x 5.5 x 9 | LAND CRUISER FZ56,BJ4#...FULL FLOATING AXLE | 79/9~84/ | Wheel Hub REAR OUTER |
| 03901 5001 | 90310-35001 | 35 x 41 x 5.5 x 9 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# FULL FLOATING AXLE | 80/8~90/ | Wheel Hub REAR OUTER |
| 03901 2143 | 90310-35001 | 35 x 41 x 5.5 x 9 | LAND CRUISER FJ75,HZJ7#,PZJ7#...FULL FLOATING AXLE | 90/1~97/12 | Wheel Hub REAR OUTER |
| 03901 2517 | 90310-35001 | 35 x 41 x 5.5 x 9 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 FULL FLOATING AXLE | 90/1~98/ | Wheel Hub REAR OUTER |
| 03901 6761 | 90310-36003 | 36 x 41 x 5.5 x 9 | LAND CRUISER HZJ7# | 97/12~ | Wheel Hub REAR OUTER |
| 03901 3209 | 90313-48001 | 48 x 62 x 9 x 24 | LAND CRUISER LJ7# | 85/10~90/4 | Wheel Hub REAR OUTER |
| 03901 4083 | 90310-50001 | 50 x 70 x 9 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Wheel Hub REAR INNER |
| 03901 8251 | 90313-48004 | 48 x 75 x 83.7 x 18 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Wheel Hub REAR OUTER |
| 03901 2657 | 90311-47001 | 47.5 x 70.6 x 9 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# SEMI FLOATING AXLE | 80/8~90/ | Wheel Hub REAR OUTER |
| 03901 8179 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER FJ56,BJ4#...FULL FLOATING AXLE | 79/9~84/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7147 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# FULL FLOATING AXLE | 80/8~90/ | Wheel Hub REAR INNER |
| 03901 3917 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER FJ75,HZJ7#,PZJ7#...DRUM BRAKE | 90/1~ | Wheel Hub REAR INNER |
| 03901 6415 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER HZJ81,FZJ80 DRUM BRAKE | 90/1~98/ | Wheel Hub REAR INNER |
| 03901 3505 | 90311-62002 | 62 x 85 x 8 x 17 | LAND CRUISER HZJ7#...DISC BRAKE | 90/1~ | Wheel Hub REAR INNER |
| 03901 1137 | 90311-62002 | 62 x 85 x 8 x 17 | LAND CRUISER FJ80,FZJ80,HZJ81 DISC BRAKE | 90/1~98/ | Wheel Hub REAR INNER |
| 03901 1905 | 90311-41008 | 41 x 59 x 10 x 15 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Transfer FRONT OUTPUT |
| 03901 7885 | 90313-48004 | 48 x 75 x 83.7 x 18 | LAND CRUISER KZJ7#,LJ7# | 90/4~96/ | Wheel Hub REAR OUTER |
| 03901 2937 | 90311-33085 | 33 x 44 x 8 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~84/ | Wheel Hub FRONT DRIVE SHAFT |
| 03901 4117 | 90312-55010 | 55 x 82 x 10 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~75/9 | Wheel Hub FRONT INNER |
| 03901 5147 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER FJ4#,5#,BJ4# | 75/9~84/ | Wheel Hub FRONT INNER |
| 03901 1981 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER FJ6#,BJ6#,HJ6# | 80/8~90/ | Wheel Hub FRONT INNER |
| 03901 6853 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER BJ7#,LJ7#,FJ75,HZJ7#,KZJ7#,PZJ7# | 84/11~ | Wheel Hub FRONT INNER |
| 03901 2599 | 90311-62001 | 62 x 85 x 10 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Wheel Hub FRONT INNER |
| 03901 6047 | 90316-69001 | 69 x 86 x 7 x 15 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Wheel Hub FRONT INNER |
| 03901 3687 | 90311-70011 | 70 x 94 x 8 x 10.5 | LAND CRUISER HD101,UZJ100 | 98/1~ | Wheel Hub FRONT INNER |
| 03901 5653 | 90311-47001 | 47.5 x 70.6 x 9 | LAND CRUISER FZJ80,HZJ81 SEMI FLOATING AXLE | 90/1~98/ | Wheel Hub REAR OUTER |
| 03901 7689 | 90312-95001 | 90 x 108 x 10 x 12 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Wheel Hub FRONT OUTER |
| 03901 2603 | 90311-47001 | 47.5 x 70.6 x 9 | LAND CRUISER HZJ7#,PZJ7#...SEMI FLOATING AXLE | 90/1~99/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5551 | 90311-33085 | 33 x 44 x 8 | LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7# | 80/8~90/1 | Wheel Hub FRONT DRIVE SHAFT |
| 03901 5883 | 90310-35005 | 35 x 50 x 9.5 | LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#,PZJ7# | 90/1~ | Wheel Hub FRONT DRIVE SHAFT |
| 03901 4057 | 90310-35005 | 35 x 50 x 9.5 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Wheel Hub FRONT DRIVE SHAFT |
| 03901 7443 | 90311-47029 | 47.6 x 70.6 x 13.5 | LAND CRUISER FJ4#,5# | 69/3~73/8 | Wheel Hub REAR OUTER |
| 03901 2797 | 90311-47001 | 47.5 x 70.6 x 9 | LAND CRUISER FJ4#,5#,BJ4# | 73/8~74/11 | Wheel Hub REAR OUTER |
| 03901 6985 | 90311-47001 | 47.5 x 70.6 x 9 | LAND CRUISER FJ4#,5#,BJ4#...SEMI FLOATING AXLE | 74/11~84/ | Wheel Hub REAR OUTER |
| 03901 2705 | 90310-58002 | 58 x 70 x 7 | LAND CRUISER KZJ7#,LJ7# | 90/1~96/ | Wheel Hub REAR INNER |
| 03901 4361 | 90311-62003 | 62 x 74 x 8 | LAND CRUISER HZJ7#,PZJ7#,KZJ7#,LZJ7#... POWER LOCKING HUB | 90/1~99/ | Wheel Hub FRONT OUTER |
| 03901 2851 | 90311-48010 | 48 x 62 x 8 x 13 | LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#.PZJ7# | 90/1~ | Transfer REAR OUTPUT |
| 03901 7865 | 90316-48003 | 48 x 72 x 11 | LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#,PZJ7# | 90/1~ | Transfer INPUT |
| 03901 7765 | 90311-48003 | 48 x 62 x 8 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~96/5 | Transfer INPUT |
| 03901 3683 | 90311-48018 | 48 x 62 x 9 | LAND CRUISER FZJ80,HDJ81,HZJ81 | 96/5~98/ | Transfer INPUT |
| 03901 6657 | 90311-48018 | 48 x 62 x 9 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Transfer INPUT |
| 03901 4883 | 90311-40021 | 40 x 58 x 7.8 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Transfer INPUT |
| 03901 8219 | 90311-45001 | 45 x 62 x 9 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~80/7 | Transfer REAR OUTPUT |
| 03901 6717 | 90310-50001 | 50 x 70 x 9 | LAND CRUISER LJ7# | 85/10~90/4 | Wheel Hub REAR INNER |
| 03901 6249 | 90311-48010 | 48 x 62 x 8 x 13 | LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7# | 84/11~90/ | Transfer REAR OUTPUT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2799 | 90311-48002 | 48 x 74 x 10 | LAND CRUISER FJ4#,5#,BJ4#,6# | 80/8~82/10 | Transfer INPUT |
| 03901 3425 | 90311-58008 | 50 x 70 x 16 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Transfer REAR OUTPUT |
| 03901 7903 | 90311-58008 | 50 x 70 x 16 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Transfer REAR OUTPUT |
| 03901 8063 | 90311-40007 | 40.5 x 58 x 8 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Transfer REAR OUTPUT |
| 03901 1161 | 90311-45001 | 45 x 62 x 9 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~80/7 | Transfer FRONT OUTPUT |
| 03901 4559 | 90311-48002 | 48 x 74 x 10 | LAND CRUISER FJ4#,5#,BJ4#,6#,HJ6# | 80/8~84/11 | Transfer FRONT OUTPUT |
| 03901 2807 | 90311-48009 | 48 x 74 x 10 x 15 | LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7# | 84/11~90/ | Transfer FRONT OUTPUT |
| 03901 7113 | 90311-48009 | 48 x 74 x 10 x 15 | LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#.PZJ7# | 90/1~ | Transfer FRONT OUTPUT |
| 03901 4901 | 90311-48003 | 48 x 62 x 8 | LAND CRUISER FJ4#,5#,BJ4#,6#,HJ6# | 80/8~84/11 | Transfer REAR OUTPUT |
| 03901 3337 | 90311-35023 | 35 x 48 x 6.5 | LAND CRUISER HDJ101 | 98/1~ | Transmission (M/T) FRONT COVER |
| 03901 7059 | 90310-58002 | 58 x 70 x 7 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Wheel Hub REAR INNER |
| 03901 5807 | 90311-28004 | 28.6 x 43 x 6.5 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~84/ | Transmission (M/T) FRONT COVER |
| 03901 1195 | 90311-28004 | 28.6 x 43 x 6.5 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# | 80/8~85/10 | Transmission (M/T) FRONT COVER |
| 03901 3489 | 90311-32013 | 32 x 48 x 7 | LAND CRUISER FJ6#,BJ6#,7#,HJ6# | 85/10~90/ | Transmission (M/T) FRONT COVER |
| 03901 2893 | 90311-32013 | 32 x 48 x 7 | LAND CRUISER FJ75,HZJ7# | 90/1~99/8 | Transmission (M/T) FRONT COVER |
| 03901 2995 | 90311-32012 | 32 x 53 x 7 | LAND CRUISER LJ7#,KZJ7#,PZJ7# | 85/10~99/ | Transmission (M/T) FRONT COVER |
| 03901 1047 | 90311-32012 | 32 x 53 x 7 | LAND CRUISER HZJ71,74,76,79 | 99/8~ | Transmission (M/T) FRONT COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2087 | 90316-48003 | 48 x 72 x 11 | LAND CRUISER FJ62,HJ6#,BJ7#,LJ7# | 88/1~90/ | Transfer INPUT |
| 03901 1423 | 90311-35023 | 35 x 48 x 6.5 | LAND CRUISER FZJ80,HZJ81,HDJ81 | 90/1~98/ | Transmission (M/T) FRONT COVER |
| 03901 1299 | 90311-48012 | 48 x 72 x 8.5 | LAND CRUISER FJ4#,5#,BJ4#,6#,7#,HJ6#,LJ7# | 82/10~88/1 | Transfer INPUT |
| 03901 2767 | 90311-38029 | 38 x 55 x 7.5 | LAND CRUISER KZJ7#,LJ7# | 90/4~96/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2071 | 90311-38029 | 38 x 55 x 7.5 | LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9# | 96/4~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4085 | 90311-42010 | 42 x 60 x 8.5 | LAND CRUISER HZJ7# | 90/1~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 5707 | 90311-42010 | 42 x 60 x 8.5 | LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 | 90/1~98/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6153 | 90311-42010 | 42 x 60 x 8.5 | LAND CRUISER HDJ101,UZJ100 | 98/1~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 3629 | 90311-42014 | 42 x 60 x 9 | LAND CRUISER FJ4#,5#,BJ4# | 69/3~80/7 | Transfer INPUT |
| 03901 1927 | 90311-32020 | 32 x 46 x 6 | LAND CRUISER 1PZ PZJ7# | 90/1~94/ | Engine CAM SHAFT |
| 03901 2963 | 90311-32012 | 32 x 53 x 7 | LAND CRUISER KDJ9#,KZJ9#,VZJ90 | 96/4~ | Transmission (M/T) FRONT COVER |
| 03901 6795 | 90913-02096 | | LAND CRUISER 1HDFTE HDJ81,101 | 95/1~ | Engine VALVE STEM SEAL |
| 03901 2569 | 90913-02110 | | LAND CRUISER 2L LJ7# | 90/4~93/ | Engine VALVE STEM SEAL |
| 03901 3881 | 90913-02110 | | LAND CRUISER 1KZTE KZJ7#,9# | 93/5~97/10 | Engine VALVE STEM SEAL |
| 03901 7457 | 90913-02117 | | LAND CRUISER 1KZTE KZJ9# | 97/10~00/ | Engine VALVE STEM SEAL |
| 03901 5875 | 90913-02121 | | LAND CRUISER 1KDFTV KDJ9# | 00/8~ | Engine VALVE STEM SEAL |
| 03901 5277 | 90913-02094 | | LAND CRUISER 1PZ PZJ7# | 90/1~94/ | Engine VALVE STEM SEAL |
| 03901 1787 | 90913-02094 | | LAND CRUISER 1HZ HZJ7#,81 | 90/1~97/7 | Engine VALVE STEM SEAL |
| 03901 6777 | 90913-02060 | | LAND CRUISER 2L LJ7# | 85/10~90/3 | Engine VALVE STEM SEAL |
| 03901 4049 | 90913-02094 | | LAND CRUISER 1HDT HDJ81 | 90/1~95/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4305 | 90913-02095 | | LAND CRUISER 5VZFE (IN.) VZJ9# | 96/4~ | Engine VALVE STEM SEAL |
| 03901 3885 | 90913-02079 | | LAND CRUISER 3RZFE (IN.) RZJ9# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 2725 | 90913-02062 | | LAND CRUISER 3RZFE (EX.) RZJ9# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 3841 | 90913-02062 | | LAND CRUISER 5VZFE (EX.) VZJ9# | 96/4~ | Engine VALVE STEM SEAL |
| 03901 6307 | 90913-02112 | | LAND CRUISER 2UZFE (EX.) UZJ100 | 98/1~ | Engine VALVE STEM SEAL |
| 03901 2587 | 90311-42003 | 42 x 60 x 7 | LAND CRUISER 2L LJ7# | 85/10~90/ 4 | Engine CAM SHAFT |
| 03901 2519 | 90311-95008 | 95 x 115 x 9.5 x 12 | LAND CRUISER 1K#...KZJ7#,9#,KDJ9# | 93/5~ | Engine CRANK SHAFT REAR |
| 03901 3719 | 90913-02094 | | LAND CRUISER 1HZ HZJ7#,81 | 97/7~ | Engine VALVE STEM SEAL |
| 03901 4827 | 90311-92006 | 92 x 110 x 9.5 | LAND CRUISER 5VZFE VZJ9# | 96/4~ | Engine CRANK SHAFT REAR |
| 03901 7201 | 90311-85007 | 85 x 105 x 10 | LAND CRUISER 2L LJ7# | 91/2~93/ | Engine CRANK SHAFT REAR |
| 03901 4765 | 90913-02113 | | LAND CRUISER 2UZFE (IN.) UZJ100 | 98/1~ | Engine VALVE STEM SEAL |
| 03901 3155 | 90913-02050 | | LAND CRUISER 2H,12H HJ6# | 82/10~90/ | Engine VALVE STEM SEAL |
| 03901 3715 | 90311-85004 | 85 x 105 x 10 | LAND CRUISER 2L LJ7# | 85/10~91/ 2 | Engine CRANK SHAFT REAR |
| 03901 6391 | 90311-88005 | 88 x 106 x 8.5 | LAND CRUISER 3RZFE RZJ9# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 7545 | 90311-95012 | 95 x 113 x 8.5 | LAND CRUISER 2UZFE UZJ100 | 98/1~ | Engine CRANK SHAFT REAR |
| 03901 5957 | 90913-02017 | | LAND CRUISER F,2F FJ4#,5# | 69/3~76/8 | Engine VALVE STEM SEAL |
| 03901 6771 | 90913-02033 | | LAND CRUISER 2F FJ5# | 76/8~80/7 | Engine VALVE STEM SEAL |
| 03901 1229 | 90913-02096 | | LAND CRUISER 1FZFE (IN.) FZJ80 | 92/8~98/ | Engine VALVE STEM SEAL |
| 03901 1365 | 90913-02105 | | LAND CRUISER 1FZFE (EX.) FZJ80 | 92/8~98/ | Engine VALVE STEM SEAL |
| 03901 2583 | 90913-02044 | | LAND CRUISER B (EX.) BJ4# | 74/2~76/1 | Engine VALVE STEM SEAL |
| 03901 3043 | 90913-02076 | | LAND CRUISER 3B,13B BJ7# | 88/8~90/ | Engine VALVE STEM SEAL |
| 03901 8107 | 90913-02028 | | LAND CRUISER B (IN.) BJ4# | 74/2~76/1 | Engine VALVE STEM SEAL |
| 03901 7437 | 90913-02028 | | LAND CRUISER B (IN. & EX.) BJ4# | 76/1~80/7 | Engine VALVE STEM SEAL |
| 03901 5871 | 90913-02042 | | LAND CRUISER 2F,3F FJ6#,75,80 | 80/8~92/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2177 | 90913-02051 | | LAND CRUISER 2B,3B,13B BJ4#,6#,7# | 80/7~88/8 | Engine VALVE STEM SEAL |
| 03901 6815 | 90311-38032 | 38 x 58 x 11 | LITE ACE KM51,YM55,CM5#...5H,5F | 88/8~96/ | Transmission (M/T) REAR EXTENTION |
| 03901 2187 | 90311-42003 | 42 x 60 x 7 | LITE ACE 1YU,2Y#...YM2#,3#,40,55,60 | 82/10~87/6 | Engine TIMING GEAR COVER |
| 03901 2751 | 90311-38032 | 38 x 58 x 11 | LITE ACE KM3#,YM3#,CM3#...5H,5F | 88/8~92/ | Transmission (M/T) REAR EXTENTION |
| 03901 1083 | 90311-19001 | 19 x 32 x 8 | LITE ACE KM2#,TM20,YM2#,CM2# | 79/10~85/ | Steering (M/S) WORM GEAR |
| 03901 1929 | 90311-38043 | 38 x 58 x 11 | LITE ACE KM5#,YM55 4H | 88/8~89/10 | Transmission (M/T) REAR EXTENTION |
| 03901 3005 | 90311-38043 | 38 x 58 x 11 | LITE ACE KM3#,YM30,CM3#...5H,5F | 85/9~88/8 | Transmission (M/T) REAR EXTENTION |
| 03901 8143 | 90311-38032 | 38 x 58 x 11 | LITE ACE KM5#,YM55 4H | 89/10~90/ | Transmission (M/T) REAR EXTENTION |
| 03901 4301 | 90311-38043 | 38 x 58 x 11 | LITE ACE KM30,35,36 4H | 85/9~90/8 | Transmission (M/T) REAR EXTENTION |
| 03901 3889 | 90311-38043 | 38 x 58 x 11 | LITE ACE KM2#,TM20,YM2#,CM2# | 79/10~85/ | Transmission (M/T) REAR EXTENTION |
| 03901 5089 | 90311-38043 | 38 x 58 x 11 | LITE ACE KM55,YM55,CM50,55 | 86/10~88/8 | Transmission (M/T) REAR EXTENTION |
| 03901 5485 | 90311-38032 | 38 x 58 x 11 | LITE ACE KM7#,CM7# | 99/6~ | Transmission (M/T) REAR EXTENTION |
| 03901 4637 | 90311-38020 | 38 x 55 x 8.5 | LITE ACE KM3#,51,7#,YM3#,40,55,CM3#,40,5#,7#,85 | 85/9~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6225 | 04332-30020 | Kit | LITE ACE KM3#,51,YM3#,55,CM3#,51,55 | 85/9~87/11 | Transmission (A/T) REAR EXTENTON |
| 03901 1429 | 04332-30030 | Kit | LITE ACE KM3#,51,YM3#,55,CM3#,51,55 | 87/11~99/ | Transmission (A/T) REAR EXTENTON |
| 03901 6309 | 90311-38133 | 38 x 74 x 11 | LITE ACE KM2#,3#,TM20,YM2#,3#,40,CM2#,3#,4# | 79/10~92/ | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2137 | 90311-38133 | 38 x 74 x 11 | LITE ACE KM5#,YM55,6#,CM5#,6# | 86/10~95/ 12 | Final Drive REAR DIFF. PINION |
| 03901 3333 | 90311-38133 | 38 x 74 x 11 | LITE ACE KM7#,CM7# | 99/6~ | Final Drive REAR DIFF. PINION |
| 03901 4893 | 90311-38047 | 38 x 74 x 11 x 18 | LITE ACE CM52,6#,YM6# | 95/12~99/ | Final Drive REAR DIFF. PINION |
| 03901 2877 | 90311-38047 | 38 x 74 x 11 x 18 | LITE ACE KM8#,CM8# | 99/6~ | Final Drive REAR DIFF. PINION |
| 03901 1351 | 90311-30014 | 30 x 45 x 8 | LITE ACE KM73,8#,CM7#,8# | 99/6~ | Transmission (M/T) FRONT COVER |
| 03901 2619 | 90311-48001 | 48 x 62 x 9 | LITE ACE KM7#,CM7# | 99/6~ | Wheel Hub FRONT |
| 03901 1627 | 90311-38133 | 38 x 74 x 11 | LITE ACE KM51,YM55,CM51,55 | 95/12~99/ | Final Drive REAR DIFF. PINION |
| 03901 4307 | 90311-62001 | 62 x 85 x 10 | LITE ACE CM52,61 | 91/10~99/ | Wheel Hub REAR |
| 03901 7647 | 90311-48122 | 48 x 62 x 7 | LITE ACE KM2#,TM2#,YM2#,CM2# | 79/10~83/ 5 | Wheel Hub FRONT |
| 03901 7713 | 90311-48001 | 48 x 62 x 9 | LITE ACE KM21,YM2#,CM2# | 83/5~85/ | Wheel Hub FRONT |
| 03901 7815 | 90311-48001 | 48 x 62 x 9 | LITE ACE KM3#,YM3#,CM3# | 85/9~92/ | Wheel Hub FRONT |
| 03901 7571 | 90311-48001 | 48 x 62 x 9 | LITE ACE KM5#,YM55,CM50,51,55 | 86/10~99/ | Wheel Hub FRONT |
| 03901 4155 | 90311-66002 | 66 x 80 x 9 | LITE ACE YM40,CM4# (4WD) | 85/10~92/ | Wheel Hub FRONT |
| 03901 8101 | 90311-61001 | 61 x 76 x 7 x 10 | LITE ACE KM8#,CM8# (4WD) | 99/6~ | Wheel Hub FRONT OUTER |
| 03901 6963 | 90311-56014 | 56 x 78 x 7.5 x 13 | LITE ACE KM8#,CM8# (4WD) | 99/6~ | Wheel Hub FRONT INNER |
| 03901 5335 | 90311-52059 | 52 x 65 x 9 | LITE ACE KM2#,TM20,YM20,21,CM2 0 SINGLE TIRE | 79/10~85/ | Wheel Hub REAR |
| 03901 2715 | 90311-52059 | 52 x 65 x 9 | LITE ACE KM3#,YM3#,40,CM3#,4# | 85/9~92/ | Wheel Hub REAR |
| 03901 3049 | 90311-66002 | 66 x 80 x 9 | LITE ACE YM6#,CM52,6# (4WD) | 86/10~99/ | Wheel Hub FRONT |
| 03901 7481 | 90311-52059 | 52 x 65 x 9 | LITE ACE KM7#,8#,CM7#,8# | 99/6~ | Wheel Hub REAR |
| 03901 5761 | 90311-30014 | 30 x 45 x 8 | LITE ACE KM51,YM55,6#,CM5#,63 | 90/7~99/ | Transmission (M/T) FRONT COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5777 | 90311-58001 | 58 x 78 x 8 | LITE ACE KM2#,YM20,25,CM2#...DOUBLE TIRE | 79/10~85/ | Wheel Hub REAR INNER |
| 03901 3565 | 90310-29001 | 29 x 38 x 7 x 12 | LITE ACE KM2#,YM20,25,CM2#...DOUBLE TIRE | 79/10~85/ | Wheel Hub REAR OUTER |
| 03901 4773 | 90311-32106 | 32 x 48 x 8 | LITE ACE KM2#,TM20,YM25 4H,4F | 79/10~85/ | Transmission (M/T) FRONT COVER |
| 03901 3093 | 90311-32106 | 32 x 48 x 8 | LITE ACE KM30,35,36 4H | 85/9~90/8 | Transmission (M/T) FRONT COVER |
| 03901 4341 | 90311-32106 | 32 x 48 x 8 | LITE ACE KM5#,YM55 4H | 86/10~90/8 | Transmission (M/T) FRONT COVER |
| 03901 4603 | 90311-30115 | 30 x 45 x 8 | LITE ACE TM20,YM20,21,CM2#...5H,5F | 81/1~85/ | Transmission (M/T) FRONT COVER |
| 03901 4921 | 90311-30115 | 30 x 45 x 8 | LITE ACE KM30,36 5F,CM3#,4#,KM31,YM30,40 | 85/9~90/7 | Transmission (M/T) FRONT COVER |
| 03901 5539 | 90311-30115 | 30 x 45 x 8 | LITE ACE KM51,CM5#,6#...5F,5H,YM60 | 86/10~90/7 | Transmission (M/T) FRONT COVER |
| 03901 8113 | 90311-30014 | 30 x 45 x 8 | LITE ACE KM3#,YM3#,40,CM33,4#...5H,5F | 90/7~92/ | Transmission (M/T) FRONT COVER |
| 03901 6821 | 90311-52059 | 52 x 65 x 9 | LITE ACE KM5#,YM55,6#,CM50,51,55,60,65 | 86/10~99/ | Wheel Hub REAR |
| 03901 1319 | 90913-02056 | | LITE ACE 4KJ,5K#...KM2#,3#,5# | 81/2~95/8 | Engine VALVE STEM SEAL |
| 03901 6585 | 90311-42015 | 42 x 60 x 6 | LITE ACE 1C,2C#...CM3#,4#,5#,6# | 85/5~90/10 | Engine CRANK SHAFT FRONT |
| 03901 2711 | 90311-42026 | 42 x 60 x 7 | LITE ACE 2C#,3CE CM5#,6#,7#,8# | 90/10~ | Engine CRANK SHAFT FRONT |
| 03901 7645 | 90311-70004 | 70 x 92 x 8.5 | LITE ACE 4KJ,5K#...KM2#,3#,5# | 79/10~97/5 | Engine CRANK SHAFT REAR |
| 03901 1853 | 90311-70007 | 70 x 92 x 8.5 | LITE ACE 5K,7KE KM51,7#,8# | 97/5~ | Engine CRANK SHAFT REAR |
| 03901 7005 | 90311-75114 | 75 x 100 x 13 | LITE ACE 13TU TM20 | 79/10~82/ | Engine CRANK SHAFT REAR |
| 03901 2429 | 90311-80003 | 80 x 100 x 8.5 | LITE ACE 1YU,2Y#...YM2#,3#,40,55,60 | 82/10~90/4 | Engine CRANK SHAFT REAR |
| 03901 6745 | 90311-80009 | 80 x 100 x 10 | LITE ACE 2Y#,3YU YM3#,40,55,6# | 90/4~99/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5253 | 90311-90003 | 90 x 110 x 8.5 x 10 | LITE ACE 1C,2C#...CM2#,3#,4#,5#,6# | 82/10~90/2 | Engine CRANK SHAFT REAR |
| 03901 1687 | 90311-42003 | 42 x 60 x 7 | LITE ACE 1C CM2# | 82/10~85/5 | Engine CRANK SHAFT FRONT |
| 03901 4455 | 90311-90008 | 90 x 110 x 9.5 x 11.5 | LITE ACE 2C#,3CE CM5#,6#,7#,8# | 90/11~ | Engine CRANK SHAFT REAR |
| 03901 7635 | 90913-02024 | | LITE ACE 4KJ | 79/10~81/2 | Engine VALVE STEM SEAL |
| 03901 4483 | 90913-02024 | | LITE ACE 13TU(IN. & EX.) | 79/10~81/1 | Engine VALVE STEM SEAL |
| 03901 1209 | 90913-02024 | | LITE ACE 13TU(IN.) | 81/1~82/ | Engine VALVE STEM SEAL |
| 03901 3977 | 90913-02058 | | LITE ACE 13TU(EX.) | 81/1~82/ | Engine VALVE STEM SEAL |
| 03901 2601 | 90913-02094 | | LITE ACE 1Y,2Y,3Y YM2#,30,40,55,6# | 82/10~99/ | Engine VALVE STEM SEAL |
| 03901 4339 | 90913-02110 | | LITE ACE 1C,2C#...CM2#,3#,4#,5#,6# | 82/10~97/4 | Engine VALVE STEM SEAL |
| 03901 2215 | 90913-02117 | | LITE ACE 2C,3CE CM53,6#,7#,8# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6193 | 90311-38086 | 38 x 58 x 7.5 | LITE ACE 5K KM51 | 97/5~99/ | Engine TIMING GEAR COVER |
| 03901 7599 | 90310-28027 | 28 x 40 x 8 | LITE ACE KM2#,TM20,YM2#,CM2# | 79/10~85/ | Steering (M/S) SECTOR SHAFT |
| 03901 2499 | 90311-90005 | 90 x 110 x 8.5 x 10 | LITE ACE 2C#...CM5#,6# | 90/2~90/11 | Engine CRANK SHAFT REAR |
| 03901 3639 | 90311-19002 | 19 x 32 x 7 x 8 | LITE ACE CM7#,8#,KM7#,8# | 99/6~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4335 | 90913-02094 | | LITE ACE 5K,7KE KM51,7#,8# | 95/8~ | Engine VALVE STEM SEAL |
| 03901 2085 | 90029-21022 | 22 x 34 x 6.5 | LITE ACE 2C#...CM5#,6# | 89/5~93/8 | Engine OIL PUMP |
| 03901 1747 | 04445-27020 | | LITE ACE CM50,51,55,60,65,KM51,YM55,6# | 88/7~99/ | Steering (P/S) R & P GASKET KIT |
| 03901 5823 | 04445-27060 | | LITE ACE CM7#,8#,KM7#,8# | 99/6~ | Steering (P/S) R & P GASKET KIT |
| 03901 4371 | 90311-19002 | 19 x 32 x 7 x 8 | LITE ACE YM2#,CM2# | 82/10~85/ | Steering (P/S) ADJUSTER PLUG |
| 03901 7523 | 90311-19002 | 19 x 32 x 7 x 8 | LITE ACE CM3#,4#,5#,6#,KM3#,51,YM30,40,55,6# | 85/9~99/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5047 | 90311-15001 | 15 x 25 x 7 | LITE ACE KM3#,5#,CM3#,5#,YM55 | 85/9~99/ | Steering (M/S) RACK HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1737 | 90310-25004 | 25 x 38 x 7 x 8 | LITE ACE CM3#,4#,5#,6#,KM3#,51,YM30,40,55,6# | 85/9~99/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6113 | 90310-25004 | 25 x 38 x 7 x 8 | LITE ACE CM7#,8#,KM7#,8# | 99/6~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6575 | 90311-38013 | 38.5 x 58 x 11 | LITE ACE 13TU TM20 | 79/10~82/ | Engine TIMING GEAR COVER |
| 03901 2277 | 90311-38044 | 38 x 50 x 6 | LITE ACE 3CE CE7#,8# | 99/6~ | Engine CAM SHAFT |
| 03901 3909 | 90029-21020 | 20 x 32 x 5 | LITE ACE 1C,2C#...CM2#,3#,4#,5#,6# | 85/5~89/5 | Engine OIL PUMP |
| 03901 3305 | 90312-30001 | 30 x 38 x 5 | LITE ACE YM2#,CM2# | 82/10~85/ | Steering (P/S) GEAR HOUSING |
| 03901 5863 | 15165-64010 | 20 x 32 x 7 | LITE ACE 1C CM2# | 82/10~85/5 | Engine OIL PUMP |
| 03901 7073 | 90311-38013 | 38.5 x 58 x 11 | LITE ACE 4KJ KM2# | 79/10~82/5 | Engine TIMING GEAR COVER |
| 03901 7627 | 90311-38044 | 38 x 50 x 6 | LITE ACE 2C#...CM5#,6# | 90/10~99/ | Engine CAM SHAFT |
| 03901 6683 | 90311-38025 | 38 x 50 x 6 | LITE ACE 1C,2C#...CM2#,3#,4#,5#,6# | 85/1~90/10 | Engine CAM SHAFT |
| 03901 6901 | 90311-38036 | 38 x 50 x 8 | LITE ACE 1C CM2# | 82/10~85/1 | Engine CAM SHAFT |
| 03901 4427 | 90311-42026 | 42 x 60 x 7 | LITE ACE 2Y#,3YU YM3#,40,55,6# | 87/6~99/ | Engine TIMING GEAR COVER |
| 03901 6499 | 90311-38086 | 38 x 58 x 7.5 | LITE ACE 7KE KM7#,8# | 99/6~ | Engine TIMING GEAR COVER |
| 03901 2153 | 90311-38022 | 38.5 x 58 x 8.5 | LITE ACE 4KJ,5K#...KM2#,3#,5# | 82/5~97/5 | Engine TIMING GEAR COVER |
| 03901 3235 | 90311-35033 | 35 x 55 x 9 x 15.5 | MARK II QUALIS (WAGON) SXV20 | 97/4~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 6831 | 90311-38034 | 38 x 50 x 10.5 | MARK II QUALIS (WAGON) 1MZFE,2MZFE NCV2# | 97/4~ | Engine CAM SHAFT |
| 03901 4919 | 90311-26003 | 26 x 38 x 6.5 | MARK II QUALIS (WAGON) MCV2#,SXV2# | 97/4~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6753 | 90311-56015 | 56 x 75 x 7 x 12 | MARK II QUALIS (WAGON) MCV25,SXV25 | 97/6~ | Wheel Hub REAR INNER |
| 03901 7693 | 90311-52005 | 52 x 75 x 7.5 x 12 | MARK II QUALIS (WAGON) MCV25,SXV25 | 97/6~ | Wheel Hub REAR OUTER |
| 03901 1719 | 04445-33080 | | MARK II QUALIS (WAGON) MCV25,SXV25 | 97/6~ | Steering (P/S) R & P GASKET KIT |
| 03901 8139 | 90311-40010 | 40 x 56 x 9 x 15.5 | MARK II QUALIS (WAGON) MCV20,21 | 97/4~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8189 | 90311-38020 | 38 x 55 x 8.5 | MARK II QUALIS (WAGON) MCV2#,SXV2# | 97/4~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 3181 | 90311-35033 | 35 x 55 x 9 x 15.5 | MARK II QUALIS (WAGON) SXV20 | 97/4~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 7205 | 90311-50011 | 50 x 80 x 16.5 x 23 | MARK II QUALIS (WAGON) MCV2# | 97/4~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 7127 | 90311-50022 | 42 x 62 x 8.5 x 15.4 | MARK II QUALIS (WAGON) SXV25 | 97/6~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 1999 | 90913-02062 | | MARK II QUALIS (WAGON) 5SFE (EX.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6143 | 04445-32051 | | MARK II QUALIS (WAGON) MCV20,21,SXV20 | 97/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 7795 | 90311-54005 | 55 x 70 x 10 | MARK II QUALIS (WAGON) MCV25,SXV25 | 97/6~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 3717 | 90311-38036 | 38 x 50 x 8 | MARK II QUALIS (WAGON) 5SFE SXV2# | 97/4~ | Engine CAM SHAFT |
| 03901 6475 | 90311-40022 | 40 x 55 x 6 | MARK II QUALIS (WAGON) 1MZFE,2MZFE NCV2# | 97/4~ | Engine OIL PUMP |
| 03901 1105 | 15165-70010 | 18 x 30 x 7 | MARK II QUALIS (WAGON) 5SFE SXV2# | 97/4~ | Engine OIL PUMP |
| 03901 8043 | 90311-42035 | 42 x 60 x 7 | MARK II QUALIS (WAGON) 5SFE SXV2# | 97/4~ | Engine CRANK SHAFT FRONT |
| 03901 6345 | 90311-92008 | 92 x 110 x 9 | MARK II QUALIS (WAGON) 1MZFE,2MZFE NCV2# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 3387 | 90913-02079 | | MARK II QUALIS (WAGON) 5SFE (IN.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 6779 | 90913-02101 | | MARK II QUALIS (WAGON) 1MZFE,2MZFE (IN.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 4129 | 90913-02111 | | MARK II QUALIS (WAGON) 1MZFE,2MZFE (EX.) | 97/4~ | Engine VALVE STEM SEAL |
| 03901 5237 | 90311-19010 | 19 x 32 x 6 | MARK II QUALIS (WAGON) MCV2#,SXV2# | 97/4~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6869 | 90311-85007 | 85 x 105 x 10 | MARK II QUALIS (WAGON) 5SFE SXV2# | 97/4~ | Engine CRANK SHAFT REAR |
| 03901 1223 | 90311-40004 | 40 x 56 x 9 x 15.5 | MR2 SW20 GT | 89/12~99/ | Mission & Differential (M/T) MISSION CASE COVER |
| 03901 6401 | 90311-50010 | 50 x 80 x 16.5 x 23 | MR3 SW20 GT | 89/12~99/ | Mission & Differential (M/T) TRANSMISSION CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1377 | 90311-50010 | 50 x 80 x 16.5 x 23 | MR4 AW1#... SUPER CHARGER | 86/8~89/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 2107 | 90311-89002 | 89 x 105 x 10 | MR5 3S#...SW20 | 93/11~99/ | Engine CRANK SHAFT REAR |
| 03901 2915 | 90311-34017 | 34 x 63 x 9 x 16 | MR6 AW1#...EXCEPT SUPER CHARGER | 84/6~89/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 3793 | 90311-30006 | 30 x 42 x 7 | MR7 SW20 | 89/7~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 2761 | 90913-02079 | | MR8 3S# (IN.) | 90/6~99/ | Engine VALVE STEM SEAL |
| 03901 4281 | 90913-02104 | | MR9 3S# (EX.) | 93/11~99/ | Engine VALVE STEM SEAL |
| 03901 6721 | 90913-02062 | | MR10 3S# (EX.) | 90/6~93/11 | Engine VALVE STEM SEAL |
| 03901 2325 | 90913-02062 | | MR11 3S# (IN. & EX.) | 89/12~90/6 | Engine VALVE STEM SEAL |
| 03901 5461 | 90913-02062 | | MR12 4A#...AW11 | 84/6~89/ | Engine VALVE STEM SEAL |
| 03901 3593 | 90913-02038 | | MR13 3ALU AW10 | 84/6~89/ | Engine VALVE STEM SEAL |
| 03901 6215 | 90311-89001 | 89 x 105 x 10 | MR14 3SGE SW20 | 90/12~93/11 | Engine CRANK SHAFT REAR |
| 03901 5291 | 90311-89002 | 89 x 105 x 10 | MR15 3SGTE SW20 | 90/12~93/11 | Engine CRANK SHAFT REAR |
| 03901 5951 | 90311-34016 | 34 x 54 x 9 x 15.5 | MR16 AW1#...EXCEPT SUPER CHARGER | 84/6~89/ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 5657 | 90311-89001 | 89 x 105 x 10 | MR17 3S#...SW20 | 89/12~90/12 | Engine CRANK SHAFT REAR |
| 03901 3421 | 90311-70004 | 70 x 92 x 8.5 | MR18 3A#,4A#...AW1# | 84/6~89/ | Engine CRANK SHAFT REAR |
| 03901 7001 | 90311-42026 | 42 x 60 x 7 | MR19 3S#...SW20 | 89/12~99/ | Engine CRANK SHAFT FRONT |
| 03901 5437 | 90311-35013 | 35 x 49 x 6 | MR20 3A#,4A#...AW1# | 84/6~89/ | Engine CAM SHAFT |
| 03901 6673 | 90311-35020 | 35 x 63 x 9 x 15.5 | MR21 SW20 | 89/12~99/ | Mission & Differential (A/T) TRANSMISSION CASE |
| 03901 1845 | 90311-35033 | 35 x 55 x 9 x 15.5 | MR22 SW20 G | 89/12~99/ | Mission & Differential (M/T) DIFF. SIDE |
| 03901 3373 | 90311-35033 | 35 x 55 x 9 x 15.5 | MR23 SW20 | 89/12~99/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3701 | 90311-35013 | 35 x 49 x 6 | MR24 3S#...SW20 | 89/12~99/ | Engine CAM SHAFT |
| 03901 5839 | 90311-30006 | 30 x 42 x 7 | MR25 AW1#... SUPER CHARGER | 86/8~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 7223 | 90311-41004 | 41 x 55 x 7 x 12 | MR26 AW1# | 84/6~89/ | Wheel Hub FRONT |
| 03901 4905 | 90311-42018 | 42 x 55 x 6 | MR27 SW20 | 89/12~99/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7535 | 90311-25011 | 25 x 37 x 8 | MR28 AW1#...EXCEPT SUPER CHARGER | 84/6~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 5201 | 04422-32010 | Kit | MR29 AW1# | 86/8~89/ | Wheel Hub REAR |
| 03901 1341 | 04422-17010 | Kit | MR30 AW1# | 84/6~86/8 | Wheel Hub REAR |
| 03901 7225 | 90311-35051 | 35 x 54 x 9 x 21.5 | MR-S ZZW30 | 99/10~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 2185 | 90311-35044 | 35 x 63 x 10 x 22 | MR-S ZZW30 | 99/10~ | Mission & Differential (A/T) MISSION CASE |
| 03901 2939 | 90311-25011 | 25 x 37 x 8 | MR-S ZZW30 | 99/10~ | Mission & Differential (A/T) INPUT SHAFT |
| 03901 6625 | 04445-17020 | | MR-S ZZW30 | 99/10~ | Steering (P/S) R & P GASKET KIT |
| 03901 1213 | 90311-19010 | 19 x 32 x 6 | MR-S ZZW30 | 99/10~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3191 | 90311-26003 | 26 x 38 x 6.5 | MR-S ZZW30 | 99/10~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2399 | 90311-38067 | 38 x 50 x 8 | MR-S 1ZZFE ZZW30 | 99/10~ | Engine TIMING GEAR COVER |
| 03901 5987 | 90311-76001 | 76 x 94 x 8.5 | MR-S 1ZZFE ZZW30 | 99/10~ | Engine CRANK SHAFT REAR |
| 03901 7327 | 90913-02101 | | MR-S 1ZZFE (IN.) | 99/10~ | Engine VALVE STEM SEAL |
| 03901 2283 | 90913-02111 | | MR-S 1ZZFE (EX.) | 99/10~ | Engine VALVE STEM SEAL |
| 03901 7779 | 90311-38067 | 38 x 50 x 8 | NADIA 3SF#...SXN1# | 98/7~ | Engine CAM SHAFT |
| 03901 1923 | 90311-19002 | 19 x 32 x 7 x 8 | NADIA SXN1# | 98/7~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7243 | 90310-25004 | 25 x 38 x 7 x 8 | NADIA SXN15 | 98/7~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1673 | 90310-25004 | 25 x 38 x 7 x 8 | NADIA SXN10 FRIEND MATIC | 98/7~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1757 | 90310-28003 | 28 x 41 x 6.5 | NADIA SXN10 | 98/7~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1313 | 15165-70010 | 18 x 30 x 7 | NADIA 3SF#...SXN1# | 98/7~ | Engine OIL PUMP |
| 03901 7391 | 90311-42035 | 42 x 60 x 7 | NADIA 3SF#...SXN1# | 98/7~ | Engine CRANK SHAFT FRONT |
| 03901 2155 | 90311-85007 | 85 x 105 x 10 | NADIA 3SF#...SXN1# | 98/7~ | Engine CRANK SHAFT REAR |
| 03901 6591 | 90913-02079 | | NADIA 3SF# (IN.) | 98/7~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4365 | 04445-20161 | | NADIA SXN15 | 98/7~ | Steering (P/S) R & P GASKET KIT |
| 03901 6551 | 04445-20210 | | NADIA SXN10 | 98/7~ | Steering (P/S) R & P GASKET KIT |
| 03901 1909 | 90913-02062 | | NADIA 3SF# (EX.) | 98/7~ | Engine VALVE STEM SEAL |
| 03901 1877 | 90311-38020 | 38 x 55 x 8.5 | NADIA SXN1# | 98/7~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4239 | 90311-49002 | 50 x 64 x 8 | NADIA SXN15 | 98/7~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 5629 | 90311-35033 | 35 x 55 x 9 x 15.5 | NADIA SXN10 | 98/7~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 8235 | 90311-35033 | 35 x 55 x 9 x 15.5 | NADIA SXN1#...WITHOUT EFI | 98/7~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 5837 | 90311-35020 | 35 x 63 x 9 x 15.5 | NADIA SXN1#...EFI | 98/7~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5757 | 04445-20161 | | NADIA SXN10 FRIEND MATIC | 98/7~ | Steering (P/S) R & P GASKET KIT |
| 03901 7617 | 90311-35033 | 35 x 55 x 9 x 15.5 | OPA ACT10 | 00/8~ | Mission & Differential (A/T) CVT NO.1 |
| 03901 6317 | 90310-25032 | 25 x 35 x 6 | OPA ACT10,ZCT1# | 00/4~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3233 | 04445-32081 | | OPA ACT10,ZCT1# | 00/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 2219 | 90311-38059 | 38 x 50 x 8 | OPA 1AZFSE ACT10 | 00/8~ | Engine TIMING GEAR CASE |
| 03901 5057 | 90311-38059 | 38 x 50 x 8 | OPA 1ZZFE ZCT1# | 00/4~ | Engine TIMING GEAR COVER |
| 03901 4013 | 90311-76001 | 76 x 94 x 8.5 | OPA 1ZZFE ZCT1# | 00/4~ | Engine CRANK SHAFT REAR |
| 03901 8167 | 90311-89003 | 89 x 105-10 x | OPA 1AZFSE ACT10 | 00/8~ | Engine CRANK SHAFT REAR |
| 03901 3415 | 90913-02101 | | OPA 1ZZFE,1AZFSE IN. | 00/4~ | Engine VALVE STEM SEAL |
| 03901 7019 | 90311-20008 | 20 x 34 x 7 | OPA ACT10,ZCT1# | 00/4~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 5099 | 90311-35046 | 35 x 57 x 9 x 15.5 | OPA ACT10 | 00/8~ | Mission & Differential (A/T) CVT NO.2 |
| 03901 1109 | 90311-35046 | 35 x 57 x 9 x 15.5 | OPA ZCT1# | 00/4~ | Mission & Differential (A/T) TRANSAXLE CASE NO.2 |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2515 | 90311-49002 | 50 x 64 x 8 | OPA ZCT15 | 00/4~ | Mission & Differential (A/T) TRANSAXLE CASE NO.1 |
| 03901 3315 | 90311-35033 | 35 x 55 x 9 x 15.5 | OPA ZCT10 | 00/4~ | Mission & Differential (A/T) TRANSAXLE CASE NO.1 |
| 03901 6079 | 90913-02111 | | OPA 1ZZFE,1AZFSE EX. | 00/4~ | Engine VALVE STEM SEAL |
| 03901 7619 | 90311-38064 | 38 x 55 x 8.7 | OPA ZCT1# | 00/4~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 5713 | 90311-35046 | 35 x 57 x 9 x 15.5 | PRIUS NHW11 | 00/5~ | Transaxle Assy TRANSAXLE (L) |
| 03901 3999 | 90311-24024 | 25 x 39.5 x 8 | PRIUS NHW11 | 00/5~ | Transaxle Assy Input Shaft |
| 03901 4347 | 90311-25022 | 25 x 39.5 x 8.2 | PRIUS NHW10 | 97/12~00/5 | Transaxle Assy Input Shaft |
| 03901 3587 | 90913-02093 | | PRIUS 1NZFXE( IN. & EX. ) | 97/12~ | Engine VALVE STEM SEAL |
| 03901 2361 | 90311-75016 | 75 x 107 x 8 | PRIUS 1NZFXE NHW11 | 00/5~ | Engine CRANK SHAFT REAR |
| 03901 4141 | 90311-25021 | 25.5 x 37.5 x 6 | PRIUS 1NZFXE NHW10,11 | 97/12~ | Engine OIL PUMP |
| 03901 7169 | 90311-35033 | 35 x 55 x 9 x 15.5 | PRIUS NHW11 | 00/5~ | Transaxle Assy TRANSAXLE ◆ |
| 03901 5297 | 90311-35033 | 35 x 55 x 9 x 15.5 | PRIUS NHW10 | 97/12~00/5 | Transaxle Assy TRANSAXLE (R & L) |
| 03901 7959 | 90311-75013 | 75 x 114 x 8 | PRIUS 1NZFXE NHW10 | 97/12~00/5 | Engine CRANK SHAFT REAR |
| 03901 4199 | 90311-19002 | 19 x 32 x 7 x 8 | PROGRES JCG1# | 98/5~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7183 | 04445-51010 | | PROGRES JCG1# | 98/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 6127 | 90311-40020 | 40.5 x 52.5 x 6.5 | PROGRES 1JZGE,2JZGE JCG1# | 98/5~ | Engine CAM SHAFT |
| 03901 3797 | 90913-02062 | | PROGRES 1JZGE,2JZGE(EX.) | 98/5~ | Engine VALVE STEM SEAL |
| 03901 1433 | 90913-02079 | | PROGRES 1JZGE,2JZGE(IN.) | 98/5~ | Engine VALVE STEM SEAL |
| 03901 3725 | 90311-90006 | 90 x 110 x 9.5 | PROGRES 1JZGE,2JZGE JCG1# | 98/5~ | Engine CRANK SHAFT REAR |
| 03901 1647 | 90310-25027 | 25 x 38 x 7 | PROGRES JCG1# | 98/5~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5459 | 90311-43001 | 43 x 70 x 9 x 15.5 | PROGRES JCG11 | 98/5~ | Final Drive DIFF. SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5319 | 90311-38011 | 38 x 63 x 10 x 17 | PROGRES JCG10 | 98/5~ | Final Drive DIFF. SIDE |
| 03901 1397 | 90311-38133 | 38 x 74 x 11 | PROGRES JCG1# | 98/5~ | Final Drive PINION |
| 03901 6883 | 90311-40001 | 40 x 58 x 11 | PROGRES JCG1# | 98/5~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 6001 | 90311-38029 | 38 x 55 x 7.5 | PROGRES JCG1# | 98/5~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 4223 | 90311-48013 | 48 x 73 x 7 | PROGRES JCG1# | 98/5~ | Wheel Hub FRONT |
| 03901 8215 | 90311-46001 | 46 x 63 x 6.5 | PROGRES 1JZGE,2JZGE JCG1# | 98/5~ | Engine CRANK SHAFT FRONT |
| 03901 5211 | 90311-50011 | 50 x 80 x 16.5 x 23 | PRONARD MCX20 | 00/2~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 2803 | 90311-19010 | 19 x 32 x 6 | PRONARD MCX20 | 00/2~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 6679 | 90311-40010 | 40 x 56 x 9 x 15.5 | PRONARD MCX20 | 00/2~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 8009 | 90311-38020 | 38 x 55 x 8.5 | PRONARD MCX20 | 00/2~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 3227 | 90311-38034 | 38 x 50 x 10.5 | PRONARD 1MZFE MCX20 | 00/2~ | Engine CAM SHAFT |
| 03901 3171 | 90311-40022 | 40 x 55 x 6 | PRONARD 1MZFE MCX20 | 00/2~ | Engine OIL PUMP |
| 03901 7279 | 90311-92008 | 92 x 110 x 9 | PRONARD 1MZFE MCX20 | 00/2~ | Engine CRANK SHAFT REAR |
| 03901 3431 | 90913-02101 | | PRONARD 1MZFE(IN.) | 00/2~ | Engine VALVE STEM SEAL |
| 03901 2437 | 90913-02111 | | PRONARD 1MZFE(EX.) | 00/2~ | Engine VALVE STEM SEAL |
| 03901 2621 | 90311-26003 | 26 x 38 x 6.5 | PRONARD MCX20 | 00/2~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 4777 | 90311-80012 | 80 x 100 x 8.5 | RAUM 5E EXZ1# | 97/5~ | Engine CRANK SHAFT REAR |
| 03901 3027 | 90913-02062 | | RAUM 5E (IN. & EX.) | 97/5~ | Engine VALVE STEM SEAL |
| 03901 2977 | 90311-34016 | 34 x 54 x 9 x 15.5 | RAUM EXZ10 | 97/5~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 2683 | 90311-54004 | 54 x 68 x 8.5 | RAUM EXZ15 (4WD) | 97/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 5669 | 90311-38020 | 38 x 55 x 8.5 | RAUM EXZ1# | 97/5~ | Mission & Differential (A/T) FRONT OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2091 | 04445-16110 | | RAUM EXZ1# | 97/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 1455 | 90311-19010 | 19 x 32 x 6 | RAUM EXZ1# | 97/5~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1053 | 90311-26003 | 26 x 38 x 6.5 | RAUM EXZ1# | 97/5~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 3847 | 90311-35013 | 35 x 49 x 6 | RAUM 5E EXZ1# | 97/5~ | Engine CAM SHAFT |
| 03901 7245 | 90311-42055 | 42 x 55 x 7 | RAUM EXZ15 (4WD) | 97/8~ | Wheel Hub REAR |
| 03901 7471 | 90311-35040 | 35 x 49 x 6 | RAUM 5E EXZ1# | 97/5~ | Engine CRANK SHAFT FRONT |
| 03901 4393 | 90311-56017 | 56 x 73 x 88.5 x 21.5 | RAUM EXZ1# | 97/5~ | Wheel Hub FRONT INNER |
| 03901 3859 | 90311-54003 | 54 x 66 x 7.5 x 10 | RAUM EXZ1# | 97/5~ | Wheel Hub FRONT OUTER |
| 03901 2855 | 90311-38037 | 38 x 52 x 7 | RAUM EXZ10 | 97/5~ | Wheel Hub REAR |
| 03901 2117 | 90311-34013 | 34 x 63 x 9 x 15 | RAUM EXZ1# | 97/5~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 7577 | 90029-21020 | 20 x 32 x 5 | RAUM 5E EXZ1# | 97/5~ | Engine OIL PUMP |
| 03901 4913 | 04422-20080 | Kit | RAV4 SXA1#...ABS | 94/4~96/8 | Wheel Hub FRONT |
| 03901 8149 | 90311-76001 | 76 x 94 x 8.5 | RAV5 1ZZFE ZCA2# | 00/5~ | Engine CRANK SHAFT REAR |
| 03901 3367 | 90311-35041 | 35 x 60 x 11 | RAV6 3SGE SXA10,11 | 98/8~00/ | Engine CAM SHAFT (NO.1) |
| 03901 5571 | 90311-46004 | 46 x 60 x 6.5 | RAV7 3SGE SXA10,11 | 98/8~00/ | Engine CAM SHAFT (NO.2) |
| 03901 2637 | 90311-38067 | 38 x 50 x 8 | RAV8 3SGE SXA1# | 97/8~ | Engine CAM SHAFT |
| 03901 3533 | 90311-38059 | 38 x 50 x 8 | RAV9 1AZESE ACA2# | 00/5~ | Engine TIMING GEAR CASE |
| 03901 5985 | 90311-38059 | 38 x 50 x 8 | RAV10 1ZZFE ZCA2# | 00/5~ | Engine TIMING GEAR COVER |
| 03901 5263 | 90311-42026 | 42 x 60 x 7 | RAV11 3S#...SXA1# | 94/4~96/9 | Engine CRANK SHAFT FRONT |
| 03901 7071 | 90311-42026 | 42 x 60 x 7 | RAV12 3SGE SXA10,11 | 96/9~00/ | Engine CRANK SHAFT FRONT |
| 03901 1937 | 90311-42035 | 42 x 60 x 7 | RAV13 3SFE SXA1# | 96/9~00/ | Engine CRANK SHAFT FRONT |
| 03901 1139 | 90311-85007 | 85 x 105 x 10 | RAV14 3SFE SXA1# | 94/4~00/ | Engine CRANK SHAFT REAR |
| 03901 2831 | 90311-35013 | 35 x 49 x 6 | RAV15 3SGE SXA1# | 96/8~98/8 | Engine CAM SHAFT |
| 03901 1329 | 90311-89003 | 89 x 105 x 10 | RAV16 1AZESE ACA2# | 00/5~ | Engine CRANK SHAFT REAR |
| 03901 6259 | 90311-38036 | 38 x 50 x 8 | RAV17 3SGE SXA1# | 94/4~97/8 | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3349 | 90913-02079 | | RAV18 3S#(IN.) | 94/4~98/8 | Engine VALVE STEM SEAL |
| 03901 8131 | 90913-02079 | | RAV19 3SFE (IN.) | 98/8~00/ | Engine VALVE STEM SEAL |
| 03901 4461 | 90913-02062 | | RAV20 3SFE (EX.) | 94/4~00/ | Engine VALVE STEM SEAL |
| 03901 8243 | 90913-02101 | | RAV21 1AZ,1ZZ (IN.) | 00/5~ | Engine VALVE STEM SEAL |
| 03901 6703 | 90913-02111 | | RAV22 1AZ,1ZZ (EX.) | 00/5~ | Engine VALVE STEM SEAL |
| 03901 4959 | 90913-02104 | | RAV23 3SGE (EX.) | 96/8~98/8 | Engine VALVE STEM SEAL |
| 03901 3935 | 90913-02115 | | RAV24 3SGE (EX.) | 98/8~00/ | Engine VALVE STEM SEAL |
| 03901 2049 | 90913-02114 | | RAV25 3SGE (IN.) | 98/8~00/ | Engine VALVE STEM SEAL |
| 03901 7441 | 90311-30006 | 30 x 42 x 7 | RAV26 SXA1# | 94/4~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 2435 | 90311-89001 | 89 x 105 x 10 | RAV27 3SGE SXA1# | 96/8~00/ | Engine CRANK SHAFT REAR |
| 03901 6491 | 90311-35020 | 35 x 63 x 9 x 15.5 | RAV28 SXA15,16 | 97/9~00/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2339 | 04422-12060 | Kit | RAV29 SXA1#...WITHOUT ABS | 94/4~96/8 | Wheel Hub FRONT |
| 03901 6845 | 04422-20080 | Kit | RAV30 SXA1#...EXCEPT G TYPE | 96/8~00/ | Wheel Hub FRONT |
| 03901 2065 | 90311-30006 | 30 x 42 x 7 | RAV31 ACA2# | 00/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 4079 | 90311-44003 | 44 x 80 x 9 x 15.5 | RAV32 SXA10,11 | 94/4~00/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1023 | 90311-50010 | 50 x 80 x 16.5 x 23 | RAV33 SXA15,16 | 97/9~99/11 | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 7649 | 90311-50011 | 50 x 80 x 16.5 x 23 | RAV34 SXA15,16 | 99/11~00/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4101 | 90311-50011 | 50 x 80 x 16.5 x 23 | RAV35 ACA2# | 00/5~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 1193 | 15165-70010 | 18 x 30 x 7 | RAV36 3SGE,3SFE SXA1# | 96/8~00/ | Engine OIL PUMP |
| 03901 1303 | 90311-62005 | 62 x 74 x 7.5 | RAV37 ACA2# | 00/5~ | Mission & Differential (M/T) TRANSAXLE CASE COVER |
| 03901 1337 | 90310-23005 | 23 x 34 x 6.5 | RAV38 SXA1#,ACA2#,ZCA2# | 94/4~ | Steering (P/S) CONTROL VALVE LOWER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3853 | 90311-35033 | 35 x 55 x 9 x 15.5 | RAV39 ZCA2# | 00/5~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.1) |
| 03901 6641 | 90311-35046 | 35 x 57 x 9 x 15.5 | RAV40 ZCA2# | 00/5~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 8133 | 04445-42020 | | RAV41 SXA1# | 95/1~00/ | Steering (P/S) R & P GASKET KIT |
| 03901 5377 | 90311-40004 | 40 x 56 x 9 x 15.5 | RAV42 SXA15,16 | 92/9~00/ | Mission & Differential (M/T) TRANSAXLE CASE COVER |
| 03901 5207 | 04445-42030 | | RAV43 ACA2#,ZCA2# | 00/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 2869 | 90311-35033 | 35 x 55 x 9 x 15.5 | RAV44 SXA15,16 | 97/9~00/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4667 | 04445-42010 | | RAV45 SXA10 | 94/4~95/1 | Steering (P/S) R & P GASKET KIT |
| 03901 5525 | 90311-38064 | 38 x 55 x 8.7 | RAV46 ACA2#,ZCA2# | 00/5~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4725 | 90311-38020 | 38 x 55 x 8.5 | RAV47 SXA1# | 94/4~00/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4857 | 90311-50011 | 50 x 80 x 16.5 x 23 | RAV48 ACA2# | 00/5~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 4839 | 90311-44003 | 44 x 80 x 9 x 15.5 | RAV49 SXA10,11 | 94/4~00/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 2473 | 90311-62004 | 62 x 74 x 8.5 | RAV50 ACA2# | 00/5~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4131 | 90311-19007 | 19 x 38 x 7 | RAV51 SXA1#,ACA2#,ZCA2# | 94/4~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7215 | 15165-70010 | 18 x 30 x 7 | SCEPTER 5SFE SXV1# | 92/11~96/ | Engine OIL PUMP |
| 03901 4651 | 90311-38034 | 38 x 50 x 10.5 | SCEPTER 3VZFE VCV1# | 92/7~96/ | Engine CAM SHAFT |
| 03901 2173 | 90913-02062 | | SCEPTER 3VZFE(EX.) | 92/7~96/ | Engine VALVE STEM SEAL |
| 03901 2383 | 90913-02095 | | SCEPTER 3VZFE(IN.) | 92/7~96/ | Engine VALVE STEM SEAL |
| 03901 7103 | 90913-02062 | | SCEPTER 5SFE(EX.) | 92/11~96/ | Engine VALVE STEM SEAL |
| 03901 6627 | 90913-02079 | | SCEPTER 5SFE(IN.) | 92/11~96/ | Engine VALVE STEM SEAL |
| 03901 7797 | 90311-92005 | 92 x 110 x 10 | SCEPTER 3VZFE VCV1# | 92/7~96/ | Engine CRANK SHAFT REAR |
| 03901 4749 | 90311-85007 | 85 x 105 x 10 | SCEPTER 5SFE SXV1# | 92/11~96/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3131 | 90311-42026 | 42 x 60 x 7 | SCEPTER 5SFE SXV1# | 92/11~96/ | Engine CRANK SHAFT FRONT |
| 03901 1389 | 90311-50010 | 50 x 80 x 16.5 x 23 | SCEPTER VCV1# | 92/7~96/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 3037 | 90311-40022 | 40 x 55 x 6 | SCEPTER 3VZFE VCV1# | 92/7~96/ | Engine OIL PUMP |
| 03901 1505 | 90311-38036 | 38 x 50 x 8 | SCEPTER 5SFE SXV1# | 92/11~96/ | Engine CAM SHAFT |
| 03901 1489 | 90311-26003 | 26 x 38 x 6.5 | SCEPTER SXV1#,VCV1# | 92/7~96/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2571 | 90311-19010 | 19 x 32 x 6 | SCEPTER SXV1#,VCV1# | 92/7~96/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7849 | 90311-38020 | 38 x 55 x 8.5 | SCEPTER SXV1#,VCV1# | 92/7~96/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 7913 | 90311-40010 | 40 x 56 x 9 x 15.5 | SCEPTER VCV1# | 92/7~96/ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 4571 | 90311-35033 | 35 x 55 x 9 x 15.5 | SCEPTER SXV1# | 92/11~96/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 8073 | 90311-35033 | 35 x 55 x 9 x 15.5 | SCEPTER SXV1# | 92/11~96/ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 7623 | 90311-26003 | 26 x 38 x 6.5 | SERA EXY10 | 90/3~95/ | Steering (P/S) CONTROL VALVE |
| 03901 7439 | 90311-35013 | 35 x 49 x 6 | SERA 5E EXY10 | 90/3~95/ | Engine CAM SHAFT |
| 03901 5975 | 90029-21020 | 20 x 32 x 5 | SERA 5E EXY10 | 90/3~95/ | Engine OIL PUMP |
| 03901 6295 | 90311-35013 | 35 x 49 x 6 | SERA 5E EXY10 | 90/3~95/ | Engine CRANK SHAFT FRONT |
| 03901 3071 | 90311-80003 | 80 x 100 x 8.5 | SERA 5E EXY10 | 90/3~91/8 | Engine CRANK SHAFT REAR |
| 03901 6229 | 90311-80012 | 80 x 100 x 8.5 | SERA 5E EXY10 | 91/8~95/ | Engine CRANK SHAFT REAR |
| 03901 1551 | 04445-10030 | | SERA EXY10 | 90/3~95/ | Steering (P/S) R & P GASKET KIT |
| 03901 2257 | 90913-02062 | | SERA 5E (EX.) | 90/3~95/ | Engine VALVE STEM SEAL |
| 03901 5095 | 90913-02062 | | SERA 5E (IN.) | 90/3~95/ | Engine VALVE STEM SEAL |
| 03901 7069 | 90311-38037 | 38 x 52 x 7 | SERA EXY10 | 90/3~95/ | Wheel Hub REAR |
| 03901 1703 | 90311-38020 | 38 x 55 x 8.5 | SERA EXY10 | 90/3~95/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2357 | 04422-10030 | Kit | SERA EXY10 WITHOUT ABS | 90/3~95/ | Wheel Hub FRONT |
| 03901 4317 | 04422-10040 | Kit | SERA EXY10 WITH ABS | 90/3~95/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6431 | 90311-25011 | 25 x 37 x 8 | SERA EXY10 | 90/3~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 4295 | 90311-34017 | 34 x 63 x 9 x 16 | SERA EXY10 | 90/3~95/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 3231 | 90311-34016 | 34 x 54 x 9 x 15.5 | SERA EXY10 | 90/3~95/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1465 | 90311-50015 | 50 x 68 x 9 x 14.5 | SERA EXY10 WITH LSD | 92/12~95/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1233 | 90311-34013 | 34 x 63 x 9 x 15 | SERA EXY10 | 90/3~95/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 7377 | 90311-34012 | 34 x 54 x 9 x 15.5 | SERA EXY10 | 90/3~95/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 4577 | 04445-30251 | | SOARER UZZ40 | 01/4~ | Steering (P/S) R & P GASKET KIT |
| 03901 7555 | 90311-40020 | 40.5 x 52.5 x 6.5 | SOARER 2JZGE JZZ31 | 94/1~01/ | Engine CAM SHAFT |
| 03901 7407 | 90311-43004 | 43 x 60 x 7 | SOARER 1UZFE UZZ3# | 91/5~01/ | Engine OIL PUMP |
| 03901 3115 | 90311-71001 | 71.5 x 85 x 10 | SOARER 3UZFE UZZ40 | 01/4~ | Engine CAM SHAFT |
| 03901 6393 | 90311-38036 | 38 x 50 x 8 | SOARER 1UZFE UZZ3# | 91/5~01/ | Engine CAM SHAFT |
| 03901 5965 | 90311-43006 | 43 x 60 x 7 | SOARER 3UZFE UZZ40 | 01/4~ | Engine OIL PUMP |
| 03901 3535 | 90311-38056 | 38 x 52.5 x 6 | SOARER 1JZGTE JZZ30 | 96/8~01/ | Engine CAM SHAFT (NO.2) |
| 03901 6669 | 90311-40020 | 40.5 x 52.5 x 6.5 | SOARER 1JZGTE JZZ30 | 96/8~01/ | Engine CAM SHAFT (NO.1) |
| 03901 7657 | 90311-38025 | 38 x 50 x 6 | SOARER 1JZGTE JZZ30 | 91/5~96/8 | Engine CAM SHAFT |
| 03901 6789 | 90311-46001 | 46 x 63 x 6.5 | SOARER 1JZGTE,2JZGE JZZ3# | 91/5~01/ | Engine CRANK SHAFT FRONT |
| 03901 4325 | 90311-19002 | 19 x 32 x 7 x 8 | SOARER JZZ3#,UZZ3# | 91/5~01/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1103 | 90913-02079 | | SOARER 1UZFE (IN.) | 96/8~01/ | Engine VALVE STEM SEAL |
| 03901 2295 | 04445-24051 | | SOARER JZZ3#,UZZ3# | 91/5~01/ | Steering (P/S) R & P GASKET KIT |
| 03901 1095 | 90310-30013 | 30 x 41 x 6.5 | SOARER JZZ3#,UZZ3# | 91/5~01/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1711 | 90311-95012 | 95 x 113 x 8.5 | SOARER 1UZFE UZZ3# | 91/5~01/ | Engine CRANK SHAFT REAR |
| 03901 7303 | 90311-95012 | 95 x 113 x 8.5 | SOARER 3UZFE UZZ40 | 01/4~ | Engine CRANK SHAFT REAR |
| 03901 4385 | 90311-90006 | 90 x 110 x 9.5 | SOARER 1JZGTE,2JZGE JZZ3# | 91/5~01/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5261 | 90913-02062 | | SOARER 1JZGTE,2JZGE (EX.) | 95/1~ | Engine VALVE STEM SEAL |
| 03901 1897 | 90913-02079 | | SOARER 1UZFE (IN. & EX.) | 94/8~96/8 | Engine VALVE STEM SEAL |
| 03901 6649 | 90913-02106 | | SOARER 1UZFE (EX.) | 96/8~01/ | Engine VALVE STEM SEAL |
| 03901 3713 | 90913-02113 | | SOARER 3UZFE (IN.) | 01/4~ | Engine VALVE STEM SEAL |
| 03901 1623 | 90913-02112 | | SOARER 3UZFE (EX.) | 01/4~ | Engine VALVE STEM SEAL |
| 03901 2787 | 90913-02079 | | SOARER 1JZGTE (IN.) | 91/5~01/ | Engine VALVE STEM SEAL |
| 03901 2249 | 90913-02106 | | SOARER 2JZGE (IN.) | 94/1~95/1 | Engine VALVE STEM SEAL |
| 03901 6303 | 90913-02079 | | SOARER 2JZGE (IN.) | 95/1~01/ | Engine VALVE STEM SEAL |
| 03901 1811 | 90311-47008 | 47 x 72 x 10 x 11 | SOARER JZZ3#,UZZ3#,40 | 91/5~ | Final Drive DIFF. SIDE |
| 03901 2227 | 90311-50008 | 50 x 77.5 x 9 x 14 | SOARER UZZ40 | 01/4~ | Wheel Hub FRONT |
| 03901 3673 | 90913-02062 | | SOARER 1UZFE (IN. & EX.) | 91/5~94/8 | Engine VALVE STEM SEAL |
| 03901 3029 | 90311-48001 | 48 x 62 x 9 | SOARER GZ10,MZ1# | 81/2~85/ | Wheel Hub REAR OUTER |
| 03901 3949 | 90311-63001 | 63 x 90 x 7 x 10 | SOARER GZ20,MZ2#,JZZ3#,UZZ3#,40 | 86/1~ | Wheel Hub REAR INNER |
| 03901 1793 | 90311-43001 | 43 x 70 x 9 x 15.5 | SOARER GX20 GT (ATM) | 89/1~91/ | Final Drive DIFF. SIDE |
| 03901 2419 | 90311-48001 | 48 x 62 x 9 | SOARER GZ10,MZ1# | 81/2~85/ | Wheel Hub FRONT |
| 03901 1885 | 90311-50008 | 50 x 77.5 x 9 x 14 | SOARER GZ20,MZ2# | 86/1~91/ | Wheel Hub FRONT |
| 03901 3137 | 90311-50008 | 50 x 77.5 x 9 x 14 | SOARER JZZ3#,UZZ3# | 91/5~01/ | Wheel Hub FRONT |
| 03901 5009 | 90311-38009 | 38 x 58 x 8 | SOARER GZ10,MZ1# | 81/2~85/ | Wheel Hub REAR INNER |
| 03901 7099 | 90311-57001 | 57 x 81 x 8 x 11 | SOARER GZ20,MZ2#,JZZ3#,UZZ3#,40 | 86/1~ | Wheel Hub REAR OUTER |
| 03901 5511 | 90311-30115 | 30 x 45 x 8 | SOARER GZ10,20,MZ1# | 81/2~91/ | Transmission (M/T) FRONT COVER |
| 03901 5507 | 90311-32012 | 32 x 53 x 7 | SOARER MZ2#,JZZ3# | 86/1~01/ | Transmission (M/T) FRONT COVER |
| 03901 5017 | 90311-38043 | 38 x 58 x 11 | SOARER GZ10,20,MZ1# | 81/2~91/ | Transmission (M/T) REAR EXTENTION |
| 03901 6217 | 90311-40001 | 40 x 58 x 11 | SOARER MZ2#,JZZ3# | 91/5~01/ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1247 | 90311-38029 | 38 x 55 x 7.5 | SOARER GZ20,MZ2#,JZZ3#,UZZ3#,40 | 86/1~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7139 | 90311-40001 | 40 x 58 x 11 | SOARER JZZ3# | 91/5~01/ | Transmission (A/T) REAR EXTENTION |
| 03901 1839 | 90311-38011 | 38 x 63 x 10 x 17 | SOARER GZ20 VZ,VX,GT | 86/1~89/1 | Final Drive DIFF. SIDE |
| 03901 6861 | 90311-38015 | 38 x 65 x 12 x 19 | SOARER GZ10 | 81/2~81/8 | Final Drive PINION |
| 03901 6009 | 90311-38019 | 38 x 65 x 10 x 17 | SOARER GZ10 V1,V2,VR,VX | 81/8~85/ | Final Drive PINION |
| 03901 1167 | 90311-38133 | 38 x 74 x 11 | SOARER GZ10 GT | 83/2~85/ | Final Drive PINION |
| 03901 4457 | 90311-38133 | 38 x 74 x 11 | SOARER GZ20,MX1#,2# | 81/2~91/ | Final Drive PINION |
| 03901 6787 | 90311-44005 | 44 x 74 x 11 x 16 | SOARER JZZ30,UZZ3#,40 | 91/5~ | Final Drive PINION |
| 03901 6693 | 90311-38011 | 38 x 63 x 10 x 17 | SOARER GZ10,MZ10,11,12 ATM | 81/2~85/9 | Final Drive DIFF. SIDE |
| 03901 6511 | 90311-43001 | 43 x 70 x 9 x 15.5 | SOARER MZ2#,GZ20 GTT,GTL | 86/1~91/ | Final Drive DIFF. SIDE |
| 03901 5381 | 90311-38011 | 38 x 63 x 10 x 17 | SOARER GZ10 GT, MZ1#...ATM | 85/9~85/12 | Final Drive DIFF. SIDE |
| 03901 7193 | 90311-35018 | 35 x 63 x 10 x 16.5 | SOARER GZ10 V2,VR,VX | 85/9~85/12 | Final Drive DIFF. SIDE |
| 03901 1721 | 90311-43001 | 43 x 70 x 9 x 15.5 | SOARER MZ12 MTM | 85/1~85/12 | Final Drive DIFF. SIDE |
| 03901 7321 | 90311-38011 | 38 x 63 x 10 x 17 | SOARER GZ20 VX,GT(MTM) | 89/1~91/ | Final Drive DIFF. SIDE |
| 03901 7195 | 90311-42024 | 42 x 55 x 10 | SOARER UZZ3#,UZZ40 | 91/5~ | Transmission (A/T) REAR EXTENTION |
| 03901 2213 | 90311-38025 | 38 x 50 x 6 | STARLET (FWD) 1N NP7#,80,90 | 86/12~92/8 | Engine CAM SHAFT |
| 03901 8141 | 90311-35013 | 35 x 49 x 6 | STARLET (FWD) 2E#,4E#...EP7#,8#,9# | 84/10~99/ | Engine CAM SHAFT |
| 03901 1155 | 90311-26003 | 26 x 38 x 6.5 | STARLET (FWD) EP8#,9#,NP80,90 | 89/12~99/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1681 | 90311-19010 | 19 x 32 x 6 | STARLET (FWD) EP8#,9#,NP80,90 | 89/12~99/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3405 | 90029-21005 | 18 x 30 x 5 | STARLET (FWD) 2E#...EP7# | 84/10~86/4 | Engine OIL PUMP |
| 03901 4463 | 04445-10030 | | STARLET (FWD) EP8#,NP80 | 89/12~96/ | Steering (P/S) R & P GASKET KIT |
| 03901 3837 | 90311-15002 | 15 x 25 x 7 | STARLET (FWD) EP82,91,NP80,90 | 89/12~99/ | Steering (M/S) RACK HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2033 | 04445-16110 | | STARLET (FWD) EP9#,NP90 | 96/1~99/ | Steering (P/S) R & P GASKET KIT |
| 03901 7715 | 90029-21020 | 20 x 32 x 5 | STARLET (FWD) 2E#,4E#...EP7#,8#,9# | 86/4~99/ | Engine OIL PUMP |
| 03901 4391 | 90311-35013 | 35 x 49 x 6 | STARLET (FWD) 2E#,4E#...EP7#,8#,9# | 84/10~96/ 4 | Engine CRANK SHAFT FRONT |
| 03901 2623 | 90311-35013 | 35 x 49 x 6 | STARLET (FWD) 1N NP7#,80 | 86/12~92/ 8 | Engine CRANK SHAFT FRONT |
| 03901 7511 | 90913-02062 | | STARLET (FWD) 2E#,4E# | 84/10~99/ | Engine VALVE STEM SEAL |
| 03901 5845 | 90311-75009 | 75 x 100 x 8.5 | STARLET (FWD) 4E#...EP9# | 96/1~99/ | Engine CRANK SHAFT REAR |
| 03901 3883 | 90311-80003 | 80 x 100 x 8.5 | STARLET (FWD) 1N NP7# | 86/12~89/ | Engine CRANK SHAFT REAR |
| 03901 3843 | 90311-80009 | 80 x 100 x 10 | STARLET (FWD) 1N NP80,90 | 89/12~99/ | Engine CRANK SHAFT REAR |
| 03901 4247 | 90311-15001 | 15 x 25 x 7 | STARLET (FWD) EP7#,NP7# | 84/10~89/ | Steering (M/S) RACK HOUSING |
| 03901 6999 | 04422-10040 | Kit | STARLET (FWD) EP9#,NP90 WITH ABS | 96/1~99/ | Wheel Hub FRONT |
| 03901 7761 | 90311-35031 | 35 x 49 x 6 | STARLET (FWD) 1N NP80,90 | 92/8~99/ | Engine CRANK SHAFT FRONT |
| 03901 7899 | 90311-34017 | 34 x 63 x 9 x 16 | STARLET (FWD) EP7#,8#,9#,NP7#,80,90 | 84/10~99/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4349 | 90913-02062 | | STARLET (FWD) 1N | 86/12~99/ | Engine VALVE STEM SEAL |
| 03901 2037 | 90311-75004 | 75 x 100 x 8.5 | STARLET (FWD) 2E#,4E#...EP7#,8# | 84/10~95/ | Engine CRANK SHAFT REAR |
| 03901 3105 | 04422-10020 | Kit | STARLET (FWD) EP7#,NP7# | 84/10~89/ | Wheel Hub FRONT |
| 03901 8001 | 04422-10030 | Kit | STARLET (FWD) EP8#,NP80 WITHOUT ABS | 89/12~95/ | Wheel Hub FRONT |
| 03901 3891 | 04422-10030 | Kit | STARLET (FWD) EP9#,NP90 WITHOUT ABS | 96/1~99/ | Wheel Hub FRONT |
| 03901 6547 | 04422-10040 | Kit | STARLET (FWD) EP8#,NP80 WITH ABS | 89/12~95/ | Wheel Hub FRONT |
| 03901 1325 | 90311-36001 | 36 x 50 x 7 | STARLET (FWD) EP7#,NP7# | 84/10~89/ | Wheel Hub REAR |
| 03901 6793 | 90311-38037 | 38 x 52 x 7 | STARLET (FWD) EP82,91,NP80,90 | 89/12~99/ | Wheel Hub REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2733 | 90311-25011 | 25 x 37 x 8 | STARLET (FWD) EP7#,8#,9#,NP7#,80,90 | 84/10~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 5573 | 90311-34012 | 34 x 54 x 9 x 15.5 | STARLET (FWD) EP7#,82,91 3FC | 84/10~99/ | Mission & Differential (A/T) DIFFERENTIAL SIDE |
| 03901 4805 | 90311-34016 | 34 x 54 x 9 x 15.5 | STARLET (FWD) EP7#,82,91 (EXC. GRZV),NP7#,80,90 | 84/10~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4903 | 90311-54004 | 54 x 68 x 8.5 | STARLET (FWD) EP85,95 (4WD) | 90/8~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2401 | 90311-50015 | 50 x 68 x 9 x 14.5 | STARLET (FWD) EP91 (GRZV) | 96/1~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 6023 | 90311-34012 | 34 x 54 x 9 x 15.5 | STARLET (FWD) EP7#,82,91 3FC | 84/10~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 4847 | 90311-34013 | 34 x 63 x 9 x 15 | STARLET (FWD) EP7#,8#,9#,NP7#,80,90 4FC | 84/10~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 1497 | 90311-34012 | 34 x 54 x 9 x 15.5 | STARLET (FWD) EP7#,82,91,NP70,80,90 4FC | 84/10~99/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1841 | 90311-54004 | 54 x 68 x 8.5 | STARLET (FWD) EP85,95 (4WD) | 90/8~99/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 7661 | 90311-42055 | 42 x 55 x 7 | STARLET (FWD) EP85,95 (4WD) | 90/8~99/ | Wheel Hub REAR |
| 03901 6027 | 90311-35040 | 35 x 49 x 6 | STARLET (FWD) 4E#...EP9# | 96/4~99/ | Engine CRANK SHAFT FRONT |
| 03901 1547 | 90913-02056 | | STARLET (RWD) 3K#,4K# | 81/2~84/ | Engine VALVE STEM SEAL |
| 03901 1235 | 90311-40108 | 40 x 52 x 7 | STARLET (RWD) KP4#,51,6# | 73/4~84/ | Wheel Hub FRONT |
| 03901 7807 | 90311-42055 | 42 x 55 x 7 | STARLET (RWD) KP4#,51,6# | 73/4~84/ | Wheel Hub REAR |
| 03901 6197 | 90311-25003 | 25 x 38 x 7 | STARLET (RWD) KP4#,51,6# | 73/4~84/ | Transmission FRONT COVER |
| 03901 7989 | 90311-32074 | 32 x 52 x 11 | STARLET (RWD) KP4#,51,6# | 73/4~84/ | Transmission REAR |
| 03901 2321 | 90311-35131 | 35 x 55 x 11 | STARLET (RWD) KP4#,51,6# | 73/4~84/ | Final Drive PINION |
| 03901 1075 | 90310-28038 | 28 x 37 x 7 | STARLET (RWD) KP4#,51 | 73/4~78/1 | Steering SECTOR SHAFT |
| 03901 5533 | 90310-30035 | 30 x 40 x 7 | STARLET (RWD) KP4#,51 | 73/4~78/1 | Steering WORM GEAR |
| 03901 5177 | 90311-15001 | 15 x 25 x 7 | STARLET (RWD) KP6# | 78/2~84/ | Steering RACK HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5781 | 90311-38013 | 38.5 x 58 x 11 | STARLET (RWD) 2K,3K#,4K#...KP4#,51,6# | 73/4~82/5 | Engine TIMING GEAR COVER |
| 03901 5135 | 90311-38022 | 38.5 x 58 x 8.5 | STARLET (RWD) 4K#...KP61 | 82/5~84/ | Engine TIMING GEAR COVER |
| 03901 2673 | 90311-70003 | 70 x 92 x 12 | STARLET (RWD) 2K,3K#,4K#...KP4#,51,6# | 73/4~82/5 | Engine CRANK SHAFT REAR |
| 03901 5563 | 90913-02024 | | STARLET (RWD) 2K,3K#,4K# | 74/10~81/2 | Engine VALVE STEM SEAL |
| 03901 4019 | 90311-70004 | 70 x 92 x 8.5 | STARLET (RWD) 4K#...KP61 | 82/5~84/ | Engine CRANK SHAFT REAR |
| 03901 2505 | 90080-31031 | 35 x 52 x 7 | SUPRA JZA80 6F | 93/5~ | Transmission (M/T) FRONT COVER (NO.2) |
| 03901 5799 | 90311-42003 | 42 x 60 x 7 | SUPRA 7MGTEU MA70 | 86/2~90/ | Engine TIMING GEAR CASE |
| 03901 7037 | 90311-45003 | 45 x 62 x 8 | SUPRA 1G#...GA70 | 86/2~93/ | Engine TIMING GEAR CASE |
| 03901 2443 | 90311-52003 | 52 x 70 x 8.5 | SUPRA 7MGTEU MA70 | 86/2~90/ | Engine TIMING GEAR COVER |
| 03901 2313 | 90311-46001 | 46 x 63 x 6.5 | SUPRA 1JZGTE JZA70 | 90/8~93/ | Engine CRANK SHAFT FRONT |
| 03901 6167 | 90311-46001 | 46 x 63 x 6.5 | SUPRA 2JZ#...JZA80 | 93/5~ | Engine CRANK SHAFT FRONT |
| 03901 2139 | 90311-75004 | 75 x 100 x 8.5 | SUPRA 1G#...GA70 | 86/2~89/10 | Engine CRANK SHAFT REAR |
| 03901 1003 | 90311-75007 | 75 x 100 x 10 | SUPRA 1G#...GA70 | 89/10~93/ | Engine CRANK SHAFT REAR |
| 03901 4315 | 90311-80001 | 80 x 100 x 12 | SUPRA 7MGTEU MA70 | 86/2~90/ | Engine CRANK SHAFT REAR |
| 03901 8115 | 90311-90006 | 90 x 110 x 9.5 | SUPRA 1JZGTE JZA70 | 90/8~93/ | Engine CRANK SHAFT REAR |
| 03901 5323 | 90311-90006 | 90 x 110 x 9.5 | SUPRA 2JZ#...JZA80 | 93/5~ | Engine CRANK SHAFT REAR |
| 03901 6019 | 90913-02062 | | SUPRA 1G# (IN. & EX.) | 86/2~93/ | Engine VALVE STEM SEAL |
| 03901 5265 | 90913-02062 | | SUPRA 7MGTEU (IN. & EX.) | 86/2~90/ | Engine VALVE STEM SEAL |
| 03901 6813 | 90029-21020 | 20 x 32 x 5 | SUPRA 1GGEU GA70 | 86/2~92/ | Engine OIL PUMP |
| 03901 4595 | 90913-02079 | | SUPRA 1JZGTE,2JZ# (IN.) | 90/8~ | Engine VALVE STEM SEAL |
| 03901 5391 | 90311-50008 | 50 x 77.5 x 9 x 14 | SUPRA JZA80 | 93/5~ | Wheel Hub FRONT |
| 03901 2493 | 90311-38032 | 38 x 58 x 11 | SUPRA JZA80 5F | 93/5~ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4963 | 90311-40001 | 40 x 58 x 11 | SUPRA MA70,JZA70 | 86/2~93/ | Transmission (M/T) REAR EXTENTION |
| 03901 8199 | 90311-38043 | 38 x 58 x 11 | SUPRA GA70 | 86/2~93/ | Transmission (M/T) REAR EXTENTION |
| 03901 3375 | 90311-50008 | 50 x 77.5 x 9 x 14 | SUPRA GA70 | 86/2~93/ | Wheel Hub FRONT |
| 03901 2305 | 90311-50008 | 50 x 77.5 x 9 x 14 | SUPRA MA70 | 86/2~90/ | Wheel Hub FRONT |
| 03901 4527 | 90311-50008 | 50 x 77.5 x 9 x 14 | SUPRA JZA70 | 90/8~93/ | Wheel Hub FRONT |
| 03901 2697 | 90080-31029 | 52 x 68 x 8 | SUPRA JZA80 6F | 93/5~ | Transmission (M/T) REAR EXTENTION |
| 03901 4809 | 90311-63001 | 63 x 90 x 7 x 10 | SUPRA GA70,MA70,JZA70,80 | 86/2~ | Wheel Hub REAR INNER |
| 03901 2041 | 90311-30115 | 30 x 45 x 8 | SUPRA GA70 | 86/2~93/ | Transmission (M/T) FRONT COVER |
| 03901 5115 | 90311-32012 | 32 x 53 x 7 | SUPRA MA70,JZA70 | 86/2~93/ | Transmission (M/T) FRONT COVER |
| 03901 6359 | 90311-30014 | 30 x 45 x 8 | SUPRA JZA80 5F | 93/5~ | Transmission (M/T) FRONT COVER |
| 03901 1915 | 90069-08001 | 52.3 x 73 x 4.5 x 5.5 | SUPRA JZA80 6F | 93/5~ | Transmission (M/T) FRONT COVER (NO.1) |
| 03901 3925 | 90913-02062 | | SUPRA 1JZGTE,2JZ# (EX.) | 90/8~ | Engine VALVE STEM SEAL |
| 03901 1457 | 90311-57001 | 57 x 81 x 8 x 11 | SUPRA GA70,MA70,JZA70,80 | 86/2~ | Wheel Hub REAR OUTER |
| 03901 7579 | 90311-38029 | 38 x 55 x 7.5 | SUPRA GA70,MA70,JZA70,80 | 86/2~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7447 | 90311-47008 | 47 x 72 x 10 x 11 | SUPRA JZA80 | 96/5~ | Final Drive DIFF. SIDE |
| 03901 4121 | 90311-47008 | 47 x 72 x 10 x 11 | SUPRA JZA80 4FC,5F | 93/5~96/5 | Final Drive DIFF. SIDE |
| 03901 3627 | 90311-43001 | 43 x 70 x 9 x 15.5 | SUPRA GA70,MA70,JZA70 GT,GTT,GTL,GTTR/L | 86/2~93/ | Final Drive DIFF. SIDE |
| 03901 6419 | 90311-38011 | 38 x 63 x 10 x 17 | SUPRA GA70 G | 86/2~90/ | Final Drive DIFF. SIDE |
| 03901 7107 | 90311-50018 | 50 x 87 x 11 x 18 | SUPRA JZA80 6F | 93/5~96/5 | Final Drive PINION |
| 03901 3819 | 90311-44005 | 44 x 74 x 11 x 16 | SUPRA JZA80 | 96/5~ | Final Drive PINION |
| 03901 4943 | 90311-44005 | 44 x 74 x 11 x 16 | SUPRA JZA80 4FC,5F | 93/5~96/5 | Final Drive PINION |
| 03901 3063 | 90311-38133 | 38 x 74 x 11 | SUPRA GA70,MA70,JZA70 | 86/2~ | Final Drive PINION |
| 03901 4047 | 90311-42024 | 42 x 55 x 10 | SUPRA JZA80 2JZGTE | 93/5~ | Transmission (A/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7889 | 90311-40001 | 40 x 58 x 11 | SUPRA JZA80 2JZGE | 93/5~ | Transmission (A/T) REAR EXTENTION |
| 03901 2189 | 90311-40001 | 40 x 58 x 11 | SUPRA GA70,MA70,JZA70 GT,GTT,GTL,GTTR | 86/2~93/ | Transmission (A/T) REAR EXTENTION |
| 03901 4945 | 90311-38032 | 38 x 58 x 11 | SUPRA GA70 G | 88/8~90/ | Transmission (A/T) REAR EXTENTION |
| 03901 1835 | 90029-21005 | 18 x 30 x 5 | SUPRA 1GFE GA70 | 88/8~90/ | Engine OIL PUMP |
| 03901 2199 | 90311-35013 | 35 x 49 x 6 | SUPRA 1GF#,1GG#...GA70 | 86/2~93/ | Engine CAM SHAFT |
| 03901 1263 | 04445-14030 | | SUPRA GA70 GTT | 88/8~93/ | Steering (P/S) R & P GASKET KIT |
| 03901 6057 | 04445-20040 | | SUPRA GA70 G,GT | 88/8~93/ | Steering (P/S) R & P GASKET KIT |
| 03901 4143 | 04445-14040 | | SUPRA JZA80 | 93/5~ | Steering (P/S) R & P GASKET KIT |
| 03901 7763 | 90311-45013 | 45 x 98 x 10.5 x 15.5 | SUPRA JZA80 6F | 93/5~96/5 | Final Drive DIFF. SIDE |
| 03901 4801 | 90311-19002 | 19 x 32 x 7 x 8 | SUPRA GA70,MA70,JZA70,80 | 88/8~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7433 | 90311-38036 | 38 x 50 x 8 | SUPRA 1GEU GA70 | 86/2~87/1 | Engine CAM SHAFT |
| 03901 7957 | 04445-14020 | | SUPRA MA70,JZA70 | 88/8~93/ | Steering (P/S) R & P GASKET KIT |
| 03901 6675 | 90311-35013 | 35 x 49 x 6 | SUPRA 7MGTEU MA70 | 86/2~90/ | Engine CAM SHAFT |
| 03901 1875 | 90311-38025 | 38 x 50 x 6 | SUPRA 1GEU GA70 | 97/1~90/ | Engine CAM SHAFT |
| 03901 5827 | 90311-38025 | 38 x 50 x 6 | SUPRA 1JZGTE JZA70 | 90/8~93/ | Engine CAM SHAFT |
| 03901 2971 | 90311-40020 | 40.5 x 52.5 x 6.5 | SUPRA 2JZ#...JZA80 | 93/5~ | Engine CAM SHAFT |
| 03901 6877 | 15165-70010 | 18 x 30 x 7 | SUPRA 1GEU,1GGEU GA70 | 86/2~93/ | Engine OIL PUMP |
| 03901 6105 | 90310-30013 | 30 x 41 x 6.5 | SUPRA GA70,MA70,JZA70,80 | 88/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5071 | 90311-35013 | 35 x 49 x 6 | TERCEL, CORSA 2E,3E,4E,5E EL3#,4#,5# | 86/5~99/ | Engine CAM SHAFT |
| 03901 6749 | 90913-02062 | | TERCEL, CORSA 1N | 86/5~99/ | Engine VALVE STEM SEAL |
| 03901 5447 | 90311-35040 | 35 x 49 x 6 | TERCEL, CORSA 4E,5E EL5# | 96/4~99/ | Engine CRANK SHAFT FRONT |
| 03901 3435 | 90311-70004 | 70 x 92 x 8.5 | TERCEL, CORSA 1A,2A,3A AL1#,2# | 78/8~90/ | Engine CRANK SHAFT REAR |
| 03901 3481 | 90913-02038 | | TERCEL, CORSA 1A,2A,3A | 78/8~90/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4351 | 90311-80009 | 80 x 100 x 10 | TERCEL, CORSA 1N NL30,40,50 | 86/5~99/ | Engine CRANK SHAFT REAR |
| 03901 6179 | 90311-80012 | 80 x 100 x 8.5 | TERCEL, CORSA 5E EL43,45,53,55 | 90/9~99/ | Engine CRANK SHAFT REAR |
| 03901 3865 | 90311-80003 | 80 x 100 x 8.5 | TERCEL, CORSA 3E EL31 | 86/5~90/ | Engine CRANK SHAFT REAR |
| 03901 2089 | 90311-35013 | 35 x 49 x 6 | TERCEL, CORSA 1A,2A,3A AL1#,2# | 78/8~90/ | Engine CAM SHAFT |
| 03901 3325 | 90311-75004 | 75 x 100 x 8.5 | TERCEL, CORSA 2E EL30 | 86/5~90/ | Engine CRANK SHAFT REAR |
| 03901 7309 | 90913-02062 | | TERCEL, CORSA 2E,3E,4E,5E | 86/5~99/ | Engine VALVE STEM SEAL |
| 03901 5299 | 90311-35040 | 35 x 49 x 6 | TERCEL, CORSA 1N NL40,50 | 92/8~99/ | Engine CRANK SHAFT FRONT |
| 03901 5059 | 90311-35013 | 35 x 49 x 6 | TERCEL, CORSA 1N NL30,40 | 86/5~92/8 | Engine CRANK SHAFT FRONT |
| 03901 1869 | 90311-35013 | 35 x 49 x 6 | TERCEL, CORSA 2E,3E,4E,5E EL3#,4#,5# | 86/5~96/4 | Engine CRANK SHAFT FRONT |
| 03901 5395 | 90029-21020 | 20 x 32 x 5 | TERCEL, CORSA 2E,3E,4E,5E EL3#,4#,5# | 86/5~99/ | Engine OIL PUMP |
| 03901 2127 | 90311-32020 | 32 x 46 x 6 | TERCEL, CORSA 3A AL2# | 82/5~90/ | Engine OIL PUMP |
| 03901 4113 | 90311-38025 | 38 x 50 x 6 | TERCEL, CORSA 1N NL30,40,50 | 86/5~99/ | Engine CAM SHAFT |
| 03901 3465 | 90311-75009 | 75 x 100 x 8.5 | TERCEL, CORSA 4E EL41,51 | 90/9~99/ | Engine CRANK SHAFT REAR |
| 03901 4977 | 04445-16040/43 | | TERCEL, CORSA, COROLLA II EL31GP | 86/5~90/ | Steering (P/S) R & P GASKET KIT |
| 03901 2265 | 90311-19009 | 19 x 37 x 6.5 x 9 | TERCEL, CORSA, COROLLA II EL3#,NL30 | 86/5~90/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 1591 | 90311-26003 | 26 x 38 x 6.5 | TERCEL, CORSA, COROLLA II EL4#,5#,NL40,50 | 90/9~99/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 5679 | 90310-23004 | 23 x 35 x 6.5 | TERCEL, CORSA, COROLLA II AL2#,EL3#NL30 | 82/5~90/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 1183 | 90311-19010 | 19 x 32 x 6 | TERCEL, CORSA, COROLLA II EL4#,5#,NL40,50 | 90/9~99/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 3221 | 90311-25011 | 25 x 37 x 8 | TERCEL, CORSA, COROLLA II EL3#,4#,5#,NL30,40,50 | 86/5~99/ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3699 | 90311-56017 | 56 x 73 x 88.5 x 21.5 | TERCEL, CORSA, COROLLA II EL4#,NL40 WITH ABS | 90/9~94/ | Wheel Hub FRONT INNER |
| 03901 5579 | 90311-19010 | 19 x 32 x 6 | TERCEL, CORSA, COROLLA II AL2# | 82/5~90/ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 4699 | 90311-56016 | 56 x 73 x 7.5 x 15 | TERCEL, CORSA, COROLLA II EL5#,NL50 WITHOUT ABS | 94/9~99/ | Wheel Hub FRONT INNER |
| 03901 2677 | 04445-10040 | | TERCEL, CORSA, COROLLA II EL43 SZ,VITZ,VZ | 90/9~94/ | Steering (P/S) R & P GASKET KIT |
| 03901 1221 | 90311-54004 | 54 x 68 x 8.5 | TERCEL, CORSA, COROLLA II EL45,55 (4WD) | 90/9~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 5077 | 90311-34016 | 34 x 54 x 9 x 15.5 | TERCEL, CORSA, COROLLA II EL3#,4# (EXC.45),5# (EXC.55),NL30,40,50 | 86/5~99/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2191 | 90311-32006 | 32 x 48 x 9 x 15.5 | TERCEL, CORSA, COROLLA II AL1#,2# | 78/8~90/ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4355 | 90311-34012 | 34 x 54 x 9 x 15.5 | TERCEL, CORSA, COROLLA II EL41,51 3FC | 90/9~98/3 | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5205 | 90311-32006 | 32 x 48 x 9 x 15.5 | TERCEL, CORSA, COROLLA II AL1#,2# | 78/8~90/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 7867 | 90311-34016 | 34 x 54 x 9 x 15.5 | TERCEL, CORSA, COROLLA II EL51 3FC | 98/3~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 2557 | 90311-26001 | 26 x 48 x 7 | TERCEL, CORSA, COROLLA II AL1#,2# | 78/8~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 5241 | 90311-42055 | 42 x 55 x 7 | TERCEL, CORSA, COROLLA II AL25,EL45,55 (4WD) | 82/8~99/ | Wheel Hub REAR |
| 03901 4733 | 90311-38037 | 38 x 52 x 7 | TERCEL, CORSA, COROLLA II EL4# (EXC.45),5# (EXC.55),NL40,50 | 90/9~99/ | Wheel Hub REAR |
| 03901 4541 | 90311-36001 | 36 x 50 x 7 | TERCEL, CORSA, COROLLA II EL3#,NL30 | 86/5~90/ | Wheel Hub REAR |
| 03901 7929 | 90311-36001 | 36 x 50 x 7 | TERCEL, CORSA, COROLLA II AL1#,2# (EXC.25) | 78/8~90/ | Wheel Hub REAR |
| 03901 5347 | 90311-54003 | 54 x 66 x 7.5 x 10 | TERCEL, CORSA, COROLLA II EL3#,4#,5#,NL30,40,50 | 86/5~99/ | Wheel Hub FRONT OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3247 | 90311-56017 | 56 x 73 x 88.5 x 21.5 | TERCEL, CORSA, COROLLA II EL5#,NL50 WITH ABS | 94/9~99/ | Wheel Hub FRONT INNER |
| 03901 6465 | 90311-34017 | 34 x 63 x 9 x 16 | TERCEL, CORSA, COROLLA II EL3#,4#,5#,NL30,40,50 | 86/5~99/ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 3511 | 90311-15001 | 15 x 25 x 7 | TERCEL, CORSA, COROLLA II AL1#,2# | 78/8~90/ | Steering (M/S) RACK HOUSING |
| 03901 1773 | 04445-16110 | | TERCEL, CORSA, COROLLA II EL5#,NL50 | 95/12~99/ | Steering (P/S) R & P GASKET KIT |
| 03901 1141 | 04445-16090 | | TERCEL, CORSA, COROLLA II EL5#,NL50 | 94/9~95/12 | Steering (P/S) R & P GASKET KIT |
| 03901 6885 | 04445-10030 | | TERCEL, CORSA, COROLLA II EL4# (EXC.43SZ,VTIZ,VZ),NL40 | 90/9~94/ | Steering (P/S) R & P GASKET KIT |
| 03901 5085 | 04445-16030/33 | | TERCEL, CORSA, COROLLA II EL3# (EXC.31GP),NL30 | 86/5~90/ | Steering (P/S) R & P GASKET KIT |
| 03901 6709 | 04422-16010 | Kit | TERCEL, CORSA, COROLLA II AL1# | 78/8~82/ | Wheel Hub FRONT |
| 03901 6173 | 04422-16020 | Kit | TERCEL, CORSA, COROLLA II AL2# | 82/5~90/ | Wheel Hub FRONT |
| 03901 2649 | 90311-56006 | 56 x 73 x 77.7 x 14 | TERCEL, CORSA, COROLLA II EL3#,NL30 | 86/5~90/ | Wheel Hub FRONT INNER |
| 03901 6769 | 90311-56016 | 56 x 73 x 7.5 x 15 | TERCEL, CORSA, COROLLA II EL4#,NL40 WITHOUT ABS | 90/9~94/ | Wheel Hub FRONT INNER |
| 03901 1763 | 90311-15001 | 15 x 25 x 7 | TERCEL, CORSA, COROLLA II EL3#,NL30 | 86/5~90/ | Steering (M/S) RACK HOUSING |
| 03901 2039 | 90311-38020 | 38 x 55 x 8.5 | TERCEL, CORSA, COROLLA II EL4#,5#,NL40,50 | 90/9~99/ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 7347 | 90311-34022 | 34 x 56 x 9 x 15 | TERCEL, CORSA, COROLLA II EL51 3FC | 98/3~99/ | Mission & Differential (A/T) DIFFERENTIAL SIDE |
| 03901 1859 | 90311-34012 | 34 x 54 x 9 x 15.5 | TERCEL, CORSA, COROLLA II EL41,51 3FC | 90/9~98/3 | Mission & Differential (A/T) DIFFERENTIAL SIDE |
| 03901 8025 | 90311-54004 | 54 x 68 x 8.5 | TERCEL, CORSA, COROLLA II EL45,55 (4WD) | 90/9~99/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 1635 | 90311-34016 | 34 x 54 x 9 x 15.5 | TERCEL, CORSA, COROLLA II EL53,NL50 4FC | 98/2~99/ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3871 | 90311-34012 | 34 x 54 x 9 x 15.5 | TERCEL, CORSA, COROLLA II EL43,53,NL40,50 4FC | 90/9~98/2 | Mission & Differential (A/T) TRANSAXLE HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3501 | 90311-34013 | 34 x 63 x 9 x 15 | TERCEL, CORSA, COROLLA II EL43,45,53,55,NL40,50 4FC | 90/9~99/ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3811 | 04445-16020 | | TERCEL, CORSA, COROLLA II AL2# | 83/6~86/ | Steering (P/S) R & P GASKET KIT |
| 03901 1781 | 90311-38044 | 38 x 50 x 6 | TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5# | 90/10~ | Engine CAM SHAFT |
| 03901 5843 | 90311-38022 | 38.5 x 58 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) 5K KR41 | 96/11~97/5 | Engine TIMING GEAR COVER |
| 03901 2201 | 90311-38086 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) 7K KR42 | 96/11~97/5 | Engine TIMING GEAR COVER |
| 03901 7603 | 90311-38086 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) 5K,7K KR4# | 97/5~ | Engine TIMING GEAR COVER |
| 03901 4653 | 90311-42003 | 42 x 60 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) 1YJ,2YU,3YEU YR2#,3# | 82/11~87/6 | Engine TIMING GEAR COVER |
| 03901 3449 | 90311-42026 | 42 x 60 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) 1YJ,2Y#,3YEU YR2#,3# | 87/6~96/ | Engine TIMING GEAR COVER |
| 03901 2923 | 90311-38036 | 38 x 50 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50 | 96/10~97/8 | Engine CAM SHAFT |
| 03901 2669 | 90311-38025 | 38 x 50 x 6 | TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C#...CR2#,3# | 85/1~90/10 | Engine CAM SHAFT |
| 03901 7053 | 90311-38022 | 38.5 x 58 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) 4KJ,5KJ KR12,2# | 82/5~96/ | Engine TIMING GEAR COVER |
| 03901 8071 | 90029-21020 | 20 x 32 x 5 | TOWN ACE, LITE ACE (VAN, WAGON) 2C#...CR2#,3# | 88/8~89/5 | Engine OIL PUMP |
| 03901 1969 | 90311-38067 | 38 x 50 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50 | 97/8~ | Engine CAM SHAFT |
| 03901 4851 | 90311-38036 | 38 x 50 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C CR2# | 82/11~85/1 | Engine CAM SHAFT |
| 03901 5775 | 90311-38013 | 38.5 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) 3KJ,4KJ KR1# | 78/8~82/5 | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1283 | 90311-38013 | 38.5 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) 12RJ RR1#,2# | 78/8~82/ | Engine TIMING GEAR COVER |
| 03901 1027 | 90311-38013 | 38.5 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) 2TJ,12T,13TU TR1# | 76/10~82/ | Engine TIMING GEAR COVER |
| 03901 6357 | 90311-30016 | 30 x 42 x 7 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR21,22,30,31,YR21,30 FXV LIMITED | 92/1~94/ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 8185 | 90310-25004 | 25 x 38 x 7 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,4#,5#,KR2#,4#,YR2#,30,SR30, | 85/8~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 6555 | 90311-19002 | 19 x 32 x 7 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,4#,5#,KR2#,4#,YR2#,30,SR30, | 85/8~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7015 | 90312-30001 | 30 x 38 x 5 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,YR2# | 82/11~85/8 | Steering (P/S) GEAR HOUSING |
| 03901 7145 | 90311-19002 | 19 x 32 x 7 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,YR2# | 82/11~85/8 | Steering (P/S) ADJUSTER PLUG |
| 03901 2105 | 04445-28070 | | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50 | 96/10~ | Steering (P/S) R & P GASKET KIT |
| 03901 3175 | 04445-28041 | | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR27,YR2#,3# | 92/1~96/ | Steering (P/S) R & P GASKET KIT |
| 03901 7859 | 90029-21022 | 22 x 34 x 6.5 | TOWN ACE, LITE ACE (VAN, WAGON) 2C#...CR2#,3# | 89/5~93/8 | Engine OIL PUMP |
| 03901 4599 | 90913-02110 | | TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5# | 95/11~97/4 | Engine VALVE STEM SEAL |
| 03901 6369 | 04445-28051 | | TOWN ACE, LITE ACE (VAN, WAGON) CR1,22,30,31,YR21,30 FXV LIMITED | 92/1~94/ | Steering (P/S) R & P GASKET KIT |
| 03901 1735 | 90311-85007 | 85 x 105 x 10 | TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50 | 96/10~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 3887 | 90913-02117 | | TOWN ACE, LITE ACE (VAN, WAGON) 2C,3C#...CR4#,5# | 97/4~ | Engine VALVE STEM SEAL |
| 03901 7695 | 90311-70004 | 70 x 92 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) 3KJ,4KJ,5KJ KR1#,2# | 76/10~96/ | Engine CRANK SHAFT REAR |
| 03901 8021 | 90913-02094 | | TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3# | 90/11~95/ 11 | Engine VALVE STEM SEAL |
| 03901 3041 | 90311-15001 | 15 x 25 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR2#,YR2# | 85/8~96/ | Steering (M/S) RACK HOUSING |
| 03901 1661 | 90913-02094 | | TOWN ACE, LITE ACE (VAN, WAGON) 1Y,2Y,3Y YR2#,3# | 82/11~96/ | Engine VALVE STEM SEAL |
| 03901 6615 | 90913-02058 | | TOWN ACE, LITE ACE (VAN, WAGON) 2T,13T(EX.) TR1# | 81/1~82/ | Engine VALVE STEM SEAL |
| 03901 1569 | 90913-02024 | | TOWN ACE, LITE ACE (VAN, WAGON) 2T,13T(IN.) TR1# | 81/1~82/ | Engine VALVE STEM SEAL |
| 03901 4273 | 90913-02024 | | TOWN ACE, LITE ACE (VAN, WAGON) 2T,12T,13T TR1# | 76/10~81/ 1 | Engine VALVE STEM SEAL |
| 03901 4381 | 90913-02033 | | TOWN ACE, LITE ACE (VAN, WAGON) 12RJ RR1#,2# | 78/8~82/ | Engine VALVE STEM SEAL |
| 03901 4791 | 90913-02094 | | TOWN ACE, LITE ACE (VAN, WAGON) 5K#,7K KR2#,4# | 95/8~ | Engine VALVE STEM SEAL |
| 03901 6607 | 90913-02110 | | TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C CR2#,3# | 82/11~90/ 11 | Engine VALVE STEM SEAL |
| 03901 2457 | 90913-02024 | | TOWN ACE, LITE ACE (VAN, WAGON) 3KJ,4KJ KR1# | 76/10~81/ 2 | Engine VALVE STEM SEAL |
| 03901 4707 | 15165-70010 | 18 x 30 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50 | 96/10~ | Engine OIL PUMP |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7421 | 90311-90008 | 90 x 110 x 9.5 x 11.5 | TOWN ACE, LITE ACE (VAN, WAGON) 2C,3C#...CR4#,5# | 96/12~ | Engine CRANK SHAFT REAR |
| 03901 5405 | 90311-90005 | 90 x 110 x 8.5 x 10 | TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5# | 90/2~96/12 | Engine CRANK SHAFT REAR |
| 03901 7719 | 90311-90003 | 90 x 110 x 8.5 x 10 | TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C#...CR2#,3# | 82/11~90/2 | Engine CRANK SHAFT REAR |
| 03901 7955 | 90311-80009 | 80 x 100 x 10 | TOWN ACE, LITE ACE (VAN, WAGON) 2Y#,3YEU YR2#,3# | 90/4~96/ | Engine CRANK SHAFT REAR |
| 03901 2431 | 90311-80003 | 80 x 100 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) 1YJ,2Y#,3YEU YR2#,3# | 82/11~90/4 | Engine CRANK SHAFT REAR |
| 03901 4201 | 90311-70007 | 70 x 92 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) 5K,7K KR4# | 96/11~ | Engine CRANK SHAFT REAR |
| 03901 2847 | 90311-42035 | 42 x 60 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) 2SFE SR40,50 | 96/10~ | Engine CRANK SHAFT FRONT |
| 03901 1895 | 90311-42026 | 42 x 60 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5# | 90/10~ | Engine CRANK SHAFT FRONT |
| 03901 3637 | 90311-42015 | 42 x 60 x 6 | TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C#...CR2#,3# | 85/5~90/10 | Engine CRANK SHAFT FRONT |
| 03901 5189 | 90311-42003 | 42 x 60 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C CR2# | 82/11~85/5 | Engine CRANK SHAFT FRONT |
| 03901 5599 | 90913-02056 | | TOWN ACE, LITE ACE (VAN, WAGON) 4KJ,5KJ KR12,2# | 92/1~95/8 | Engine VALVE STEM SEAL |
| 03901 3031 | 90310-50001 | 50 x 70 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) RR10,20 | 78/8~79/11 | Wheel Hub REAR INNER |
| 03901 3659 | 90311-38043 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) KR12,TR1#,RR11,21 | 79/10~82/ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4139 | 04332-30010 | Kit | TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR10,20 | 76/10~79/ 10 | Transmission (M/T) REAR EXTENTION |
| 03901 6867 | 90311-30014 | 30 x 45 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40 | 96/10~ | Transmission (M/T) FRONT COVER |
| 03901 1331 | 90311-30014 | 30 x 45 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR27,YR2#,3# | 90/7~96/ | Transmission (M/T) FRONT COVER |
| 03901 2965 | 90311-30115 | 30 x 45 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,YR2#,3#...5F,5H | 82/11~90/ 7 | Transmission (M/T) FRONT COVER |
| 03901 7747 | 90311-30115 | 30 x 45 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) TR1#...5F | 81/1~82/ | Transmission (M/T) FRONT COVER |
| 03901 4693 | 90311-32106 | 32 x 48 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) KR26,YR2#...4H | 82/11~90/ 8 | Transmission (M/T) FRONT COVER |
| 03901 7839 | 90311-32106 | 32 x 48 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR1#,2#...4H | 76/10~82/ | Transmission (M/T) FRONT COVER |
| 03901 4225 | 90313-48001 | 48 x 62 x 9 x 24 | TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 EXCEPT JUST LOW | 79/11~82/ | Wheel Hub REAR OUTER |
| 03901 1555 | 90312-35002 | 35 x 49 x 5.5 x 11.5 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50 ABS | 96/10~ | Wheel Hub REAR INNER |
| 03901 6337 | 90311-38043 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) KR26,CR2#,YR2# | 82/11~88/ 8 | Transmission (M/T) REAR EXTENTION |
| 03901 3351 | 90310-50001 | 50 x 70 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 EXCEPT JUST LOW | 79/11~82/ | Wheel Hub REAR INNER |
| 03901 7853 | 90310-29001 | 29 x 38 x 7 x 12 | TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 JUST LOW | 79/11~82/ | Wheel Hub REAR OUTER |
| 03901 5513 | 90311-52059 | 52 x 65 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50 | 96/10~ | Wheel Hub REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1947 | 90311-52059 | 52 x 65 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR2#,YR2#,3# | 82/11~96/ | Wheel Hub REAR |
| 03901 3961 | 90311-52059 | 52 x 65 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1# | 76/10~82/ | Wheel Hub REAR |
| 03901 2811 | 90311-56014 | 56 x 78 x 7.5 x 13 | TOWN ACE, LITE ACE (VAN, WAGON) CR5#,SR50 (4WD) | 96/10~ | Wheel Hub FRONT |
| 03901 8265 | 90311-61001 | 61 x 76 x 7 x 10 | TOWN ACE, LITE ACE (VAN, WAGON) CR5#,SR50 (4WD) | 96/10~ | Wheel Hub FRONT OUTER |
| 03901 2899 | 90311-66002 | 66 x 80 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) CR3#,YR3# (4WD) | 85/10~96/ | Wheel Hub FRONT |
| 03901 4009 | 90311-48001 | 48 x 62 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,KR4#,SR40 | 96/10~ | Wheel Hub FRONT |
| 03901 4169 | 90311-48122 | 48 x 62 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR1#,2# | 76/10~82/ | Wheel Hub FRONT |
| 03901 2133 | 90311-48001 | 48 x 62 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR2#,YR2# | 82/11~96/ | Wheel Hub FRONT |
| 03901 3161 | 90311-75114 | 75 x 100 x 13 | TOWN ACE, LITE ACE (VAN, WAGON) 2TJ,12T,13TU TR1# | 76/10~82/ 10 | Engine CRANK SHAFT REAR |
| 03901 4179 | 90311-19008 | 19 x 38 x 7 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR26,YR2# | 82/11~85/ 8 | Steering (M/S) SECTOR SHAFT |
| 03901 7159 | 90311-58001 | 58 x 78 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 JUST LOW | 79/11~82/ | Wheel Hub REAR INNER |
| 03901 4647 | 90311-38133 | 38 x 74 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) CR27,KR27,YR25 | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 2299 | 90311-18010 | 18 x 30 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) RR1#,2# | 78/8~82/ | Steering (M/S) WORM GEAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 2129 | 90311-34001 | 34 x 44 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR26,YR2# | 82/11~85/ 8 | Steering (M/S) WORM GEAR |
| 03901 7879 | 90313-48001 | 48 x 62 x 9 x 24 | TOWN ACE, LITE ACE (VAN, WAGON) RR10,20 | 78/8~79/1 1 | Wheel Hub REAR OUTER |
| 03901 2461 | 90311-38043 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) KR26,YR25 4H | 88/8~90/8 | Transmission (M/T) REAR EXTENTION |
| 03901 4233 | 90311-38047 | 38 x 74 x 11 x 18 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50 | 96/10~ | Final Drive REAR DIFF. PINION |
| 03901 5739 | 90311-38047 | 38 x 74 x 11 x 18 | TOWN ACE, LITE ACE (VAN, WAGON) YR21 MTM E ABS | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 3621 | 90311-38047 | 38 x 74 x 11 x 18 | TOWN ACE, LITE ACE (VAN, WAGON) CR3#,YR30 | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 6395 | 90311-38047 | 38 x 74 x 11 x 18 | TOWN ACE, LITE ACE (VAN, WAGON) CR22,YR21 ATM ABS | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 2147 | 90311-38047 | 38 x 74 x 11 x 18 | TOWN ACE, LITE ACE (VAN, WAGON) CR22,29 MTM | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 1581 | 90311-38133 | 38 x 74 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) CR22,29,YR21 ATM | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 2095 | 90311-19001 | 19 x 32 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) KR12,TR1# | 81/1~82/ | Steering (M/S) WORM GEAR |
| 03901 2497 | 90311-38133 | 38 x 74 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR2#,YR2#,3# | 82/11~95/ 12 | Final Drive REAR DIFF. PINION |
| 03901 5661 | 90311-38133 | 38 x 74 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR1#,2# | 76/10~82/ | Final Drive REAR DIFF. PINION |
| 03901 4535 | 90311-38020 | 38 x 55 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50 | 96/10~98/ 12 | Transmission (A/T) FRONT OIL PUMP |
| 03901 5603 | 90311-38032 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR27,YR2#...5F,5H | 88/8~96/ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8027 | 90311-38032 | 38 x 58 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,KR4#,SR40 | 96/10~ | Transmission (M/T) REAR EXTENTION |
| 03901 6811 | 90311-38020 | 38 x 55 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR27,YR2#,3# | 82/11~96/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7701 | 90311-38133 | 38 x 74 x 11 | TOWN ACE, LITE ACE (VAN, WAGON) YR21 MTM (D,E) | 95/12~96/ | Final Drive REAR DIFF. PINION |
| 03901 4069 | 90311-32014 | 32 x 44 x 9 | TOWN ACE, LITE ACE (VAN, WAGON) RR1#,2# | 78/8~82/ | Steering (M/S) SECTOR SHAFT |
| 03901 7683 | 90311-38020 | 38 x 55 x 8.5 | TOWN ACE, LITE ACE (VAN, WAGON) CR42,52,KR42 | 98/12~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7077 | 90311-38064 | 38 x 55 x 8.7 | TOWN ACE, LITE ACE (VAN, WAGON) CR40,50,SR40,50 | 98/12~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 7337 | 04332-30020 | Kit | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,YR2# | 82/11~88/ 8 | Transmission (A/T) REAR EXTENTION |
| 03901 4821 | 04332-30030 | Kit | TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR27,YR2# | 88/8~96/ | Transmission (A/T) REAR EXTENTION |
| 03901 2605 | 90310-28027 | 28 x 40 x 8 | TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1# | 76/10~82/ | Steering (M/S) SECTOR SHAFT |
| 03901 7165 | 04332-30030 | Kit | TOWN ACE, LITE ACE (VAN, WAGON) CR4#,KR4#,SR40 | 96/10~ | Transmission (A/T) REAR EXTENTION |
| 03901 3585 | 90311-48135 | 48 x 82 x 12 | TOYO ACE, DYNA LY211,212,YY211 FULL JUST LOW (T4) | 95/5~ | Final Drive REAR DIFF. PINION |
| 03901 4303 | 90311-48135 | 48 x 82 x 12 | TOYO ACE, DYNA LY220,230,240,280,290,RZY 220,230 T4,TW4,VAN | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 3381 | 90311-18010 | 18 x 30 x 8 | TOYO ACE, DYNA LY5#,6#,YY5#,61 | 85/8~95/ | Steering (M/S) WORM GEAR |
| 03901 5899 | 90311-38066 | 38 x 74 x 11 x 48 | TOYO ACE, DYNA LY12#,13#,20#,21#,YY121,1 31,201,211 ST | 98/1~ | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4815 | 90311-38066 | 38 x 74 x 11 x 48 | TOYO ACE, DYNA LY230,RZY230 TW1 | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 2121 | 90311-38066 | 38 x 74 x 11 x 48 | TOYO ACE, DYNA LY230,280,RZY230 (125T,15T) ST | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 2311 | 90311-18010 | 18 x 30 x 8 | TOYO ACE, DYNA LY2#,3#,RY2#,3# | 79/3~85/ | Steering (M/S) WORM GEAR |
| 03901 2157 | 90311-18010 | 18 x 30 x 8 | TOYO ACE, DYNA BY3#...TRUCK | 79/3~85/ | Steering (M/S) WORM GEAR |
| 03901 2563 | 90311-38066 | 38 x 74 x 11 x 48 | TOYO ACE, DYNA LY16#...TW2.LY16#...ST 15T | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 5841 | 90311-19001 | 19 x 32 x 8 | TOYO ACE, DYNA BY31 DUMP | 83/8~85/ | Steering (M/S) WORM GEAR |
| 03901 6569 | 90311-32014 | 32 x 44 x 9 | TOYO ACE, DYNA LY2#,3#,RY2#,3# | 79/3~85/ | Steering (M/S) SECTOR SHAFT |
| 03901 4967 | 90311-32014 | 32 x 44 x 9 | TOYO ACE, DYNA BY3#...TRUCK | 79/3~85/ | Steering (M/S) SECTOR SHAFT |
| 03901 3297 | 90311-32014 | 32 x 44 x 9 | TOYO ACE, DYNA LY5#,6#,YY5#,6# | 85/8~95/ | Steering (M/S) SECTOR SHAFT |
| 03901 3703 | 90311-36104 | 36 x 50 x 7 | TOYO ACE, DYNA BY31 DUMP | 83/8~85/ | Steering (M/S) SECTOR SHAFT |
| 03901 5557 | 04445-25030 | | TOYO ACE, DYNA LY21,31 | 83/8~85/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 6031 | 04445-25040 | | TOYO ACE, DYNA LY5#,6#,YY5#,61 | 85/8~95/ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 2979 | 04445-25060 | | TOYO ACE, DYNA LY10#,11#,20#,21#,YY101,201,211 | 95/5~ | Steering (P/S) P/S GEAR GASKET KIT |
| 03901 5591 | 04445-27013 | | TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,131 | 96/10~ | Steering (P/S) R & P GASKET KIT |
| 03901 5081 | 90311-19002 | 19 x 32 x 7 x 8 | TOYO ACE, DYNA LY21,31,5#,6#,YY5#,61 | 83/8~95/ | Steering (P/S) ADJUSTER PLUG |
| 03901 1513 | 90311-48135 | 48 x 82 x 12 | TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4) | 85/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 3341 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA LY5#,6#,YY5#,6#...EXCEPT FULL JUST LOW | 85/8~95/ | Final Drive REAR DIFF. PINION |
| 03901 5083 | 90312-32001 | 32 x 42 x 5 | TOYO ACE, DYNA LY21,31,5#,6#,YY5#,61 | 83/8~95/ | Steering (P/S) GEAR HOUSING |
| 03901 6399 | 90312-32001 | 32 x 42 x 5 | TOYO ACE, DYNA LY10#,11#,20#,21#,YY101,201,211 | 95/5~ | Steering (P/S) GEAR HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 8231 | 04445-25080 | | TOYO ACE, DYNA LY220,230,240,270,280,290, RZY220,230 | 01/7~ | Steering (P/S) R & P GASKET KIT |
| 03901 2013 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY201,211 (T2,TW2) WT | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 2975 | 90311-46005 | 46 x 63 x 7.8 | TOYO ACE, DYNA LY230 TB | 01/7~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 7083 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA LY2#,3#,RY2#,3# | 79/3~85/ | Final Drive REAR DIFF. PINION |
| 03901 2015 | 90311-80009 | 80 x 100 x 10 | TOYO ACE, DYNA 3Y#...YY101,121,131,161,201,211 | 95/5~ | Engine CRANK SHAFT REAR |
| 03901 5635 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA LY201,YY201 T1,T2,TW2 | 95/5~95/11 | Final Drive REAR DIFF. PINION |
| 03901 2593 | 90311-19002 | 19 x 32 x 7 x 8 | TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,131 | 96/10~ | Steering (M/S) CONTROL VALVE UPPER |
| 03901 3177 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA LY201 T2 ST | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 3879 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA LY211 T2 ATM | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 6747 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA YY201 T1,T2,TW2 | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 6301 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA YY211 (T2,TW2) WT | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 4697 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY51,61,YY61 ST,YY52 15T ST | 89/11~95/ | Steering (P/S) REAR DIFF. PINION |
| 03901 2535 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY201,YY201 ST 15T | 95/5~96/3 | Final Drive REAR DIFF. PINION |
| 03901 6903 | 90311-38133 | 38 x 74 x 11 | TOYO ACE, DYNA LY211,YY211 (T2,TW2) WT | 95/5~95/11 | Final Drive REAR DIFF. PINION |
| 03901 5693 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY201 T1,TW2 | 95/11~96/1 | Final Drive REAR DIFF. PINION |
| 03901 6579 | 90311-48135 | 48 x 82 x 12 | TOYO ACE, DYNA JY30,BY3# | 79/3~85/ | Final Drive REAR DIFF. PINION |
| 03901 6939 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY201,YY201 T1,T2,TW2 | 96/1~96/3 | Final Drive REAR DIFF. PINION |
| 03901 5213 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY211,YY211 (T2,TW2) WT | 96/1~96/3 | Final Drive REAR DIFF. PINION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7389 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY101,111,121,131,151,161, 201,211 T1,T2,T3,TW1,TW2 | 96/3~98/1 | Final Drive REAR DIFF. PINION |
| 03901 1259 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA YY101,121,131,201,211 T1,T2,T3,TW1,TW2 | 96/3~98/1 | Final Drive REAR DIFF. PINION |
| 03901 7965 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY10#,11#,15#,YY101 | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 6443 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY16#...(T2,T3,TW1) TS | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 1779 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY12#,13#,162,20#,21#...(T2 ,TW2) WT | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 1961 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA YY121,131,201,211 (T2,TW2) WT | 98/1~ | Final Drive REAR DIFF. PINION |
| 03901 2267 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY230 TB 125T ST | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 2793 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY220,270,RZY220 T2,T3,TW1 | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 6927 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY230,RZY230 (T2,TW2) TB WT | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 1021 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY230,280,RZY230 (T2,T3,TW3) TS | 01/7~ | Final Drive REAR DIFF. PINION |
| 03901 2463 | 90311-38047 | 38 x 74 x 11 x 18 | TOYO ACE, DYNA LY211,YY211 ST | 95/5~96/3 | Final Drive REAR DIFF. PINION |
| 03901 6535 | 90913-02036 | | TOYO ACE, DYNA L LY20,30 | 79/3~81/7 | Engine VALVE STEM SEAL |
| 03901 3661 | 90311-80003 | 80 x 100 x 8.5 | TOYO ACE, DYNA 1Y,2Y,3Y#...YY5#,61 | 85/8~90/4 | Engine CRANK SHAFT REAR |
| 03901 5199 | 90311-85007 | 85 x 105 x 10 | TOYO ACE, DYNA 2L,3L LY5#,6# | 91/2~95/ | Engine CRANK SHAFT REAR |
| 03901 6957 | 90311-85007 | 85 x 105 x 10 | TOYO ACE, DYNA 3L,5L LY10#,11#,12#,13#,15#,16#, 20#,21# | 95/5~ | Engine CRANK SHAFT REAR |
| 03901 7385 | 90311-85007 | 85 x 105 x 10 | TOYO ACE, DYNA 5L LY220,230,240,270,280,290 | 01/7~ | Engine CRANK SHAFT REAR |
| 03901 3829 | 90311-88005 | 88 x 106 x 8.5 | TOYO ACE, DYNA 1RZE RZY220,230 | 01/7~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4889 | 90311-88005 | 88 x 106 x 8.5 | TOYO ACE, DYNA 3RZFPE LY230,280 | 01/7~ | Engine CRANK SHAFT REAR |
| 03901 3163 | 90913-02033 | | TOYO ACE, DYNA 12R RY2# | 79/3~85/ | Engine VALVE STEM SEAL |
| 03901 2079 | 90913-02042 | | TOYO ACE, DYNA 5R RY3# | 79/3~85/ | Engine VALVE STEM SEAL |
| 03901 3933 | 90913-02094 | | TOYO ACE, DYNA 1Y,2Y,3Y#...YY5#,61 | 85/8~95/ | Engine VALVE STEM SEAL |
| 03901 2941 | 90913-02094 | | TOYO ACE, DYNA 3Y#...YY101,121,131,161,201,211 | 95/5~ | Engine VALVE STEM SEAL |
| 03901 7299 | 90311-85004 | 85 x 105 x 10 | TOYO ACE, DYNA L,2L LY2#,31 | 84/2~85/ | Engine CRANK SHAFT REAR |
| 03901 5981 | 90913-02051 | | TOYO ACE, DYNA B BY3# | 80/9~85/ | Engine VALVE STEM SEAL |
| 03901 6959 | 90311-85001 | 85 x 105 x 13 | TOYO ACE, DYNA L,2L LY2#,3# | 79/3~84/2 | Engine CRANK SHAFT REAR |
| 03901 8159 | 90913-02060 | | TOYO ACE, DYNA L,2L LY2#,3#,50,60 | 81/7~88/8 | Engine VALVE STEM SEAL |
| 03901 1011 | 90913-02110 | | TOYO ACE, DYNA 2L,3L LY5#,6# | 88/8~95/ | Engine VALVE STEM SEAL |
| 03901 7549 | 90913-02110 | | TOYO ACE, DYNA 3L LY201,211 | 95/5~96/1 | Engine VALVE STEM SEAL |
| 03901 7985 | 90913-02110 | | TOYO ACE, DYNA 3L LY101,111,121,131,151,161, 201,211 | 96/1~97/5 | Engine VALVE STEM SEAL |
| 03901 7565 | 90913-02117 | | TOYO ACE, DYNA 3L,5L LY10#,11#,12#,15#,16#,20#, 21# | 97/5~ | Engine VALVE STEM SEAL |
| 03901 3223 | 90913-02117 | | TOYO ACE, DYNA 5L LY220,230,240,270,280,290 | 01/7~ | Engine VALVE STEM SEAL |
| 03901 4879 | 90913-02110 | | TOYO ACE, DYNA 1RZE RZY220,230 | 01/7~ | Engine VALVE STEM SEAL |
| 03901 4105 | 90913-02079 | | TOYO ACE, DYNA 3RZFPE (IN.) LY230,280 | 01/7~ | Engine VALVE STEM SEAL |
| 03901 3517 | 90913-02062 | | TOYO ACE, DYNA 3RZFPE (EX.) LY230,280 | 01/7~ | Engine VALVE STEM SEAL |
| 03901 7833 | 90311-46005 | 46 x 63 x 7.8 | TOYO ACE, DYNA LY132,212 | 99/5~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 8191 | 90310-58002 | 58 x 70 x 7 | TOYO ACE, DYNA LY230,280,RZY230 (12T,15T) ST | 01/7~ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 7789 | 90913-02044 | | TOYO ACE, DYNA 2J JY30 | 79/3~83/ | Engine VALVE STEM SEAL |
| 03901 2759 | 90311-48020 | 48 x 68 x 7 | TOYO ACE, DYNA 1RZE RZY220,230 | 01/7~ | Engine TIMING GEAR CASE |
| 03901 1063 | 90311-38013 | 38.5 x 58 x 11 | TOYO ACE, DYNA 12R RY2# | 79/3~85/ | Engine TIMING GEAR COVER |
| 03901 1131 | 90311-45002 | 45 x 68 x 12 | TOYO ACE, DYNA 5R RY3# | 79/3~85/ | Engine TIMING GEAR COVER |
| 03901 6297 | 90311-42003 | 42 x 60 x 7 | TOYO ACE, DYNA 1Y,3Y#...YY5#,61 | 85/8~87/8 | Engine TIMING GEAR COVER |
| 03901 5467 | 90311-42026 | 42 x 60 x 7 | TOYO ACE, DYNA 2Y,3Y#...YY5#,61 | 87/8~95/ | Engine TIMING GEAR COVER |
| 03901 4441 | 90311-42026 | 42 x 60 x 7 | TOYO ACE, DYNA 3Y#...YY101,121,131,161,201,211 | 95/5~ | Engine TIMING GEAR COVER |
| 03901 2163 | 90311-50006 | 50 x 72 x 12 | TOYO ACE, DYNA 2J JY30 | 79/3~83/ | Engine TIMING GEAR COVER |
| 03901 7097 | 90311-50006 | 50 x 72 x 12 | TOYO ACE, DYNA B BY3# | 79/3~85/ | Engine TIMING GEAR COVER |
| 03901 5183 | 90311-42003 | 42 x 60 x 7 | TOYO ACE, DYNA L,2L LY2#,3# | 79/3~85/ | Engine TIMING GEAR CASE |
| 03901 4111 | 90311-42003 | 42 x 60 x 7 | TOYO ACE, DYNA 2L,3L LY5#,6# | 85/8~91/2 | Engine TIMING GEAR CASE |
| 03901 1317 | 90311-42026 | 42 x 60 x 7 | TOYO ACE, DYNA 2L,3L LY5#,6# | 91/2~95/ | Engine TIMING GEAR CASE |
| 03901 1645 | 90311-85004 | 85 x 105 x 10 | TOYO ACE, DYNA 2L,3L LY5#,6# | 85/8~91/2 | Engine CRANK SHAFT REAR |
| 03901 3127 | 90311-42026 | 42 x 60 x 7 | TOYO ACE, DYNA 5L LY220,230,240,270,280,290 | 01/7~ | Engine TIMING GEAR CASE |
| 03901 2445 | 90310-25004 | 25 x 38 x 7 x 8 | TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,131 | 96/10~ | Steering (P/S) CONTROL VALVE LOWER |
| 03901 2333 | 90311-48020 | 48 x 68 x 7 | TOYO ACE, DYNA 3RZFPE LY230,280 | 01/7~ | Engine TIMING GEAR CASE |
| 03901 6571 | 90311-42003 | 42 x 60 x 7 | TOYO ACE, DYNA L,2L LY2#,3# | 79/3~85/ | Engine CAM SHAFT |
| 03901 2895 | 90311-42003 | 42 x 60 x 7 | TOYO ACE, DYNA 2L LY50,60 | 85/8~88/8 | Engine CAM SHAFT |
| 03901 5227 | 90311-32020 | 32 x 46 x 6 | TOYO ACE, DYNA 2L,3L LY5#,6# | 88/8~95/ | Engine CAM SHAFT |
| 03901 5251 | 90311-32020 | 32 x 46 x 6 | TOYO ACE, DYNA 3L,5L LY10#,11#,12#,13#,15#,16#,20#,21# | 95/5~ | Engine CAM SHAFT |
| 03901 5185 | 90311-32020 | 32 x 46 x 6 | TOYO ACE, DYNA 5L LY220,230,240,270,280,290 | 01/7~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6483 | 11551-31010 | | TOYO ACE, DYNA 12R RY2# | 79/3~85/ | Engine CRANK SHAFT REAR |
| 03901 7003 | 90311-80001 | 80 x 100 x 12 | TOYO ACE, DYNA 5R RY3# | 79/3~85/ | Engine CRANK SHAFT REAR |
| 03901 4675 | 90311-80009 | 80 x 100 x 10 | TOYO ACE, DYNA 2Y,3Y#...YY5#,61 | 90/4~95/ | Engine CRANK SHAFT REAR |
| 03901 4907 | 90311-95001 | 95 x 115 x 12 | TOYO ACE, DYNA 2J JY30 | 79/3~83/ | Engine CRANK SHAFT REAR |
| 03901 5565 | 90311-95001 | 95 x 115 x 12 | TOYO ACE, DYNA B BY3# | 79/3~85/ | Engine CRANK SHAFT REAR |
| 03901 7951 | 90311-42026 | 42 x 60 x 7 | TOYO ACE, DYNA 3L,5L LY10#,11#,12#,13#,15#,16#, 20#,21# | 95/5~ | Engine TIMING GEAR CASE |
| 03901 5671 | 90310-35001 | 35 x 41 x 5.5 x 9 | TOYO ACE, DYNA LY5#,6#,YY5#,61 WT EXC. FULL JUST LOW | 85/8~95/ | Wheel Hub REAR OUTER |
| 03901 2817 | 90313-48001 | 48 x 62 x 9 x 24 | TOYO ACE, DYNA LY50,YY50 125T (T1,T3) | 85/8~87/8 | Wheel Hub REAR OUTER |
| 03901 3787 | 90311-62001 | 62 x 85 x 10 | TOYO ACE, DYNA LY220,230,RZY220,230 (T2,TW2) WT | 01/7~ | Wheel Hub REAR INNER |
| 03901 3009 | 42404-36010 | 75 x 108 x 20 | TOYO ACE, DYNA JY30,BY3# | 79/3~85/ | Wheel Hub REAR INNER |
| 03901 7557 | 90311-75003 | 75 x 108 x 10 x 20 | TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4) | 85/8~95/ | Wheel Hub REAR INNER |
| 03901 2477 | 90311-75003 | 75 x 108 x 10 x 20 | TOYO ACE, DYNA LY21#,YY211 FULL JUST LOW (T4) | 95/5~ | Wheel Hub REAR INNER |
| 03901 1091 | 90311-75003 | 75 x 108 x 10 x 20 | TOYO ACE, DYNA LY220,230,240,280,290,RZY 220,230 T4,TW4,VAN | 01/7~ | Wheel Hub REAR INNER |
| 03901 2315 | 90310-58002 | 58 x 70 x 7 | TOYO ACE, DYNA LY230,RZY230 TW1 | 01/7~ | Wheel Hub REAR INNER |
| 03901 2993 | 90313-48001 | 48 x 62 x 9 x 24 | TOYO ACE, DYNA LY50,YY51 (T1,T2,T3) TS ST | 87/8~88/8 | Wheel Hub REAR OUTER |
| 03901 3149 | 90313-48001 | 48 x 62 x 9 x 24 | TOYO ACE, DYNA LY50,YY5#...(T1,T2,T3,TW) TS ST | 88/8~95/ | Wheel Hub REAR OUTER |
| 03901 1163 | 90313-48001 | 48 x 62 x 9 x 24 | TOYO ACE, DYNA LY10#,11#,15#,201,YY101,2 01 ST (125T,1T) | 95/5~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4567 | 90311-62001 | 62 x 85 x 10 | TOYO ACE, DYNA LY12#,13#,162,YY121,131 (T2,TW2) WT | 96/10~ | Wheel Hub REAR INNER |
| 03901 6937 | 90310-35001 | 35 x 41 x 5.5 x 9 | TOYO ACE, DYNA LY2#,3#,RY2#,3#...DOUBL E TIRE | 79/3~85/ | Wheel Hub REAR OUTER |
| 03901 3697 | 90311-62001 | 62 x 85 x 10 | TOYO ACE, DYNA LY5#,6#,YY5#,61 WT EXC.FULL JUST LOW | 85/8~95/ | Wheel Hub REAR INNER |
| 03901 5569 | 90310-35001 | 35 x 41 x 5.5 x 9 | TOYO ACE, DYNA LY121,131,201,211,YY121,1 31,201,211 (T2,TW2) WT | 95/5~97/1 2 | Wheel Hub REAR OUTER |
| 03901 8105 | 90310-36003 | 36 x 41 x 5.5 x 9 | TOYO ACE, DYNA LY123,13#,162,YY121,131 (T2,TW2) WT | 97/12~ | Wheel Hub REAR OUTER |
| 03901 5549 | 90310-36003 | 36 x 41 x 5.5 x 9 | TOYO ACE, DYNA LY20#,21#,YY201,211 (T2,TW2) WT | 97/12~ | Wheel Hub REAR OUTER |
| 03901 7643 | 90310-36003 | 36 x 41 x 5.5 x 9 | TOYO ACE, DYNA LY220,230,RZY220,230 (T2,TW2) WT | 01/7~ | Wheel Hub REAR OUTER |
| 03901 1725 | 90310-38033 | 38 x 44 x 18 | TOYO ACE, DYNA JY30,BY3# | 79/3~85/ | Wheel Hub REAR OUTER |
| 03901 4713 | 90310-38033 | 38 x 44 x 18 | TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4) | 85/8~95/ | Wheel Hub REAR OUTER |
| 03901 7769 | 90310-38033 | 38 x 44 x 18 | TOYO ACE, DYNA LY21#,YY211 FULL JUST LOW (T4) | 95/5~ | Wheel Hub REAR OUTER |
| 03901 5867 | 90310-38033 | 38 x 44 x 18 | TOYO ACE, DYNA LY220,230,240,280,290,RZY 220,230 T4,TW4,VAN | 01/7~ | Wheel Hub REAR OUTER |
| 03901 2929 | 90313-54001 | 54 x 64 x 9 x 24 | TOYO ACE, DYNA LY220,270,RZY220 ST | 01/7~ | Wheel Hub REAR OUTER |
| 03901 2359 | 90313-54001 | 54 x 64 x 9 x 24 | TOYO ACE, DYNA LY230,280,RZY230 9T2,T3,TW3) (125T,1T) | 01/7~ | Wheel Hub REAR OUTER |
| 03901 6697 | 90313-62001 | 62 x 81 x 7.5 x 17.5 | TOYO ACE, DYNA LY230,RZY230 TW1 | 01/7~ | Wheel Hub REAR OUTER |
| 03901 1453 | 90313-48001 | 48 x 62 x 9 x 24 | TOYO ACE, DYNA LY16#...(T2,T3,TW1) TS | 95/5~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5119 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY50,YY51 TW,LY50 T3..TB | 87/8~88/8 | Wheel Hub REAR |
| 03901 4407 | 90311-50003 | 50 x 73 x 9 | TOYO ACE, DYNA LY2#,3#,RY2#,3# | 79/3~85/ | Wheel Hub FRONT |
| 03901 1651 | 90311-50003 | 50 x 73 x 9 | TOYO ACE, DYNA LY5#,6#,YY5#,61 EXC. FULL JUST LOW | 85/8~95/ | Wheel Hub FRONT |
| 03901 4003 | 90311-50003 | 50 x 73 x 9 | TOYO ACE, DYNA LY20#,21#,YY201,211 EXC. FULL JUST LOW | 95/5~ | Wheel Hub FRONT |
| 03901 1625 | 90311-68001 | 68 x 90 x 10 | TOYO ACE, DYNA JY30,BY3# | 79/3~85/ | Wheel Hub FRONT |
| 03901 2987 | 90311-68001 | 68 x 90 x 10 | TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4) | 85/5~95/ | Wheel Hub FRONT |
| 03901 5129 | 90311-68001 | 68 x 90 x 10 | TOYO ACE, DYNA LY21#,YY211 FULL JUST LOW (T4) | 95/5~ | Wheel Hub FRONT |
| 03901 1067 | 90311-50136 | 50 x 68 x 9 | TOYO ACE, DYNA LY10#,11#,YY101 | 96/10~ | Wheel Hub FRONT |
| 03901 4337 | 90311-66001 | 66 x 85 x 8 x 10 | TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,131 | 96/10~ | Wheel Hub FRONT |
| 03901 3805 | 90311-66001 | 66 x 85 x 8 x 10 | TOYO ACE, DYNA LY220,230,240,270,280,290, RZY220,230 | 01/7~ | Wheel Hub FRONT |
| 03901 3335 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY2#,3#,RY2#,3#...SINGLE TIRE | 79/3~85/ | Wheel Hub REAR |
| 03901 6783 | 90311-62001 | 62 x 85 x 10 | TOYO ACE, DYNA LY20#,21#,YY201,211 (T2,TW2) WT | 95/5~ | Wheel Hub REAR INNER |
| 03901 2791 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY60,YY52,61 (T2,T3,TW) ST | 87/8~88/8 | Wheel Hub REAR |
| 03901 7141 | 90311-28004 | 28.6 x 43 x 6.5 | TOYO ACE, DYNA BY31 DUMP | 83/5~85/ | Transmission (M/T) FRONT COVER |
| 03901 2025 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY51,61,YY61 ST,YY52 15T ST | 88/8~95/ | Wheel Hub REAR |
| 03901 5687 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY12#,13#,202,21#,YY121,131,211 ST | 95/5~ | Wheel Hub REAR |
| 03901 1531 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY16#...TW2,LY16#,201,YY201 ST 15T | 95/5~ | Wheel Hub REAR |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 5013 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY50,YY50 125T (T1,T3) | 85/8~87/8 | Wheel Hub REAR INNER |
| 03901 3899 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY50,YY51 (T1,T2,T3) TS ST | 87/8~88/8 | Wheel Hub REAR INNER |
| 03901 1035 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY50,YY5#...(T1,T2,T3,TW) TS ST | 88/8~95/ | Wheel Hub REAR INNER |
| 03901 3835 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY10#,11#,15#,201,YY101,201 ST (125T,1T) | 95/5~ | Wheel Hub REAR INNER |
| 03901 5457 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY16#...(T2,T3,TW1) TS | 95/5~ | Wheel Hub REAR INNER |
| 03901 5355 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY220,270,RZY220 ST | 01/7~ | Wheel Hub REAR INNER |
| 03901 6739 | 90310-50001 | 50 x 70 x 9 | TOYO ACE, DYNA LY230,280,RZY230 (T2,T3,TW3) (125T,1T) | 01/7~ | Wheel Hub REAR INNER |
| 03901 4245 | 90311-62001 | 62 x 85 x 10 | TOYO ACE, DYNA LY2#,3#,RY2#,3#...DOUBLE TIRE | 79/3~85/ | Wheel Hub REAR INNER |
| 03901 5337 | 90311-47001 | 47.5 x 70.6 x 9 | TOYO ACE, DYNA LY50,60,YY5#...ST (TW1,15T) | 85/8~87/8 | Wheel Hub REAR |
| 03901 2659 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY230,RZY230 125T,15T,175T | 01/7~ | Transmission (M/T) REAR EXTENTION |
| 03901 3927 | 90311-38032 | 38 x 58 x 11 | TOYO ACE, DYNA LY230,RZY230 (T2,TW3) (125T,1T) | 01/7~ | Transmission (M/T) REAR EXTENTION |
| 03901 1759 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY2#,3#,RY2#,3# | 79/3~85/ | Transmission (M/T) REAR EXTENTION |
| 03901 5203 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY50,60,YY5#,61 TW,15T | 85/8~87/8 | Transmission (M/T) REAR EXTENTION |
| 03901 7711 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY50,51 TW,LY60,YY52 | 87/8~88/8 | Transmission (M/T) REAR EXTENTION |
| 03901 3729 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY50 (T2,T3) 15T,YY61 T2,T3,T4 | 87/8~88/8 | Transmission (M/T) REAR EXTENTION |
| 03901 3099 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY61 TW1,YY61 TW TB | 87/8~88/8 | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6129 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY51,61,YY61 | 88/8~95/ | Transmission (M/T) REAR EXTENTION |
| 03901 5039 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA YY52 15T | 88/8~95/ | Transmission (M/T) REAR EXTENTION |
| 03901 2671 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY201,YY201 WT | 95/5~ | Transmission (M/T) REAR EXTENTION |
| 03901 1375 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY201,YY201 ST 15T | 95/5~ | Transmission (M/T) REAR EXTENTION |
| 03901 6409 | 90313-62001 | 62 x 81 x 7.5 x 17.5 | TOYO ACE, DYNA LY230,280,RZY230 (125T,15T) ST | 01/7~ | Wheel Hub REAR OUTER |
| 03901 6691 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY220,240,290,RZY220 WT | 01/7~ | Transmission (M/T) REAR EXTENTION |
| 03901 5697 | 90311-38032 | 38 x 58 x 11 | TOYO ACE, DYNA LY50,YY5#...125T,1T | 88/8~95/ | Transmission (M/T) REAR EXTENTION |
| 03901 2469 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY230,RZY230 (TW1,TW2,TW4) 125T | 01/7~ | Transmission (M/T) REAR EXTENTION |
| 03901 7155 | 90311-38020 | 38 x 55 x 8.5 | TOYO ACE, DYNA YY61 | 94/6~95/ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2679 | 90311-38020 | 38 x 55 x 8.5 | TOYO ACE, DYNA YY211 125T LPG | 95/5~96/6 | Transmission (A/T) FRONT OIL PUMP |
| 03901 7699 | 90311-38020 | 38 x 55 x 8.5 | TOYO ACE, DYNA LY10#,11#,16#,YY211 CBR,DEL | 96/10~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 8255 | 90311-38058 | 38 x 55 x 8.5 | TOYO ACE, DYNA YY211 125T LPG | 96/6~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6165 | 90311-38029 | 38 x 55 x 7.5 | TOYO ACE, DYNA LY13#,21# | 95/5~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2447 | 90311-38029 | 38 x 55 x 7.5 | TOYO ACE, DYNA LY230,280 TB | 01/7~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 5229 | 90311-38064 | 38 x 55 x 8.7 | TOYO ACE, DYNA LY220,230,280,RZY220,230 TS | 01/7~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 6629 | 04332-30030 | Kit | TOYO ACE, DYNA YY61 | 94/6~95/ | Transmission (A/T) EXTENTION HOUSING |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4423 | 04332-30030 | Kit | TOYO ACE, DYNA LY10#,11#YY211 | 95/5~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 6183 | 04332-30030 | Kit | TOYO ACE, DYNA LY220,230,RZY220,230 125T ST | 01/7~ | Transmission (A/T) EXTENTION HOUSING |
| 03901 2707 | 90311-38093 | 38 x 65 x 9 | TOYO ACE, DYNA LY12#,13#,202,213,YY121,131,211 | 95/5~ | Transmission (M/T) REAR EXTENTION |
| 03901 6865 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY51,61,YY61,YY52 15T | 88/8~95/ | Transmission (M/T) FRONT COVER |
| 03901 3693 | 90311-45007 | 45 x 62 x 8 | TOYO ACE, DYNA LY131,211 | 95/5~99/5 | Transmission (A/T) EXTENTION HOUSING |
| 03901 1343 | 90311-30115 | 30 x 45 x 8 | TOYO ACE, DYNA LY50 125T (T1,T2,T3) | 85/8~87/8 | Transmission (M/T) FRONT COVER |
| 03901 4331 | 90311-30115 | 30 x 45 x 8 | TOYO ACE, DYNA LY50,YY51 125T | 87/8~88/8 | Transmission (M/T) FRONT COVER |
| 03901 1293 | 90311-30115 | 30 x 45 x 8 | TOYO ACE, DYNA LY50,YY51 | 88/8~90/7 | Transmission (M/T) FRONT COVER |
| 03901 5709 | 90311-300014 | 30 x 45 x 8 | TOYO ACE, DYNA LY50,YY5#...125T,1T | 90/7~95/ | Transmission (M/T) FRONT COVER |
| 03901 4383 | 90311-300014 | 30 x 45 x 8 | TOYO ACE, DYNA LY10#,11#,201,YY101,201 ST (125T,1T) | 95/5~ | Transmission (M/T) FRONT COVER |
| 03901 6705 | 90311-300014 | 30 x 45 x 8 | TOYO ACE, DYNA LY220,RZY220 ST | 01/7~ | Transmission (M/T) FRONT COVER |
| 03901 8005 | 90311-300014 | 30 x 45 x 8 | TOYO ACE, DYNA LY230,RZY230 (T2,TW3) (125T,1T) | 01/7~ | Transmission (M/T) FRONT COVER |
| 03901 1323 | 90311-32106 | 32 x 48 x 8 | TOYO ACE, DYNA JY30,BY3# (TRUCK) | 79/3~85/ | Transmission (M/T) FRONT COVER |
| 03901 2323 | 90311-32106 | 32 x 48 x 8 | TOYO ACE, DYNA YY50 T1,T2,T3 | 85/8~87/8 | Transmission (M/T) FRONT COVER |
| 03901 3487 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY50,YY51 TW,LY60,YY52 | 87/8~88/8 | Transmission (M/T) FRONT COVER |
| 03901 2003 | 90311-38032 | 38 x 58 x 11 | TOYO ACE, DYNA LY220,RZY220 ST | 01/7~ | Transmission (M/T) REAR EXTENTION |
| 03901 2629 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY61 TW1,YY61 TW TB | 87/8~88/8 | Transmission (M/T) FRONT COVER |
| 03901 4309 | 90311-38032 | 38 x 58 x 11 | TOYO ACE, DYNA LY10#,11#,201,YY101,201 ST (125T,1T) | 95/5~ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1307 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY12#,13,15#,16#,201,21#,YY121,131,211 | 95/5~ | Transmission (M/T) FRONT COVER |
| 03901 4607 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY201,YY201 WT | 95/5~ | Transmission (M/T) FRONT COVER |
| 03901 5717 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY201,YY211 ST 15T | 95/5~ | Transmission (M/T) FRONT COVER |
| 03901 5663 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY220,240,290,RZY220 WT | 01/7~ | Transmission (M/T) FRONT COVER |
| 03901 3813 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY230,RZY230 125T,15T,175T | 01/7~ | Transmission (M/T) FRONT COVER |
| 03901 2051 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY230,RZY230 (TW1,TW2,TW4) 125T | 01/7~ | Transmission (M/T) FRONT COVER |
| 03901 6439 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY270,280 | 01/7~ | Transmission (M/T) FRONT COVER |
| 03901 1367 | 90311-45001 | 45 x 62 x 9 | TOYO ACE, DYNA JY30,BY3# | 79/3~85/ | Transmission (M/T) REAR EXTENTION |
| 03901 2275 | 90311-38043 | 38 x 58 x 11 | TOYO ACE, DYNA LY50,YY50 125T (T1,T2,T3) | 85/8~87/8 | Transmission (M/T) REAR EXTENTION |
| 03901 4215 | 90311-38043 | 38 x 58 x 11 | TOYO ACE, DYNA LY50,YY51 | 87/8~88/8 | Transmission (M/T) REAR EXTENTION |
| 03901 3197 | 90311-28004 | 28.6 x 43 x 6.5 | TOYO ACE, DYNA LY2#,3#,RY2#,3# | 79/3~85/ | Transmission (M/T) FRONT COVER |
| 03901 6085 | 90311-32012 | 32 x 53 x 7 | TOYO ACE, DYNA LY50 (T2,T3) 15T,YY61 T2,T3,T4 | 87/8~88/8 | Transmission (M/T) FRONT COVER |
| 03901 1145 | 90311-40001 | 40 x 58 x 11 | VEROSSA GX115,JZX110 | 01/6~ | Transmission (A/T) REAR EXTENTION |
| 03901 1857 | 90311-38064 | 38 x 55 x 8.7 | VEROSSA GX110 | 01/6~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 1985 | 90311-38032 | 38 x 58 x 11 | VEROSSA GX110 | 01/6~ | Transmission (A/T) REAR EXTENTION |
| 03901 4659 | 90311-38070 | 38 x 74 x 11 x 19 | VEROSSA GX11#,JZX110 | 01/6~ | Final Drive PINION |
| 03901 1815 | 90311-38071 | 38 x 63 x 10 x 16.5 | VEROSSA GX11#,JZX110 9EXC.VR25) | 01/6~ | Final Drive DIFF. SIDE |
| 03901 6455 | 90311-43001 | 43 x 70 x 9 x 15.5 | VEROSSA JZX110 (VR25) | 01/6~ | Final Drive DIFF. SIDE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1273 | 90311-38029 | 38 x 55 x 7.5 | VEROSSA GX115,JZX110 | 01/6~ | Transmission (A/T) FRONT OIL PUMP |
| 03901 2097 | 90311-40020 | 40.5 x 52.5 x 6.5 | VEROSSA 1JZGTE JZX110 | 01/6~ | Engine CAM SHAFT (NO.1) |
| 03901 5855 | 90913-02079 | | VEROSSA 1JZ# (IN.) | 01/6~ | Engine VALVE STEM SEAL |
| 03901 3507 | 90913-02093 | | VEROSSA 1GFE (IN. & EX.) | 01/6~ | Engine VALVE STEM SEAL |
| 03901 5913 | 90311-90006 | 90 x 110 x 9.5 | VEROSSA 1JZ#...JZX110 | 01/6~ | Engine CRANK SHAFT REAR |
| 03901 7349 | 90311-75007 | 75 x 100 x 10 | VEROSSA 1GFE GX110 | 01/6~ | Engine CRANK SHAFT REAR |
| 03901 3143 | 90311-46001 | 46 x 63 x 6.5 | VEROSSA 1JZ#...JZX110 | 01/6~ | Engine CRANK SHAFT FRONT |
| 03901 5963 | 90913-02062 | | VEROSSA 1JZ# (EX.) | 01/6~ | Engine VALVE STEM SEAL |
| 03901 3123 | 90311-38056 | 38 x 52.5 x 6 | VEROSSA 1JZGTE JZX110 | 01/6~ | Engine CAM SHAFT (NO.2) |
| 03901 5607 | 04445-22290 | | VEROSSA GX115 | 01/6~ | Steering (P/S) R & P GASKET KIT |
| 03901 4985 | 90311-34027 | 34 x 56 x 6 | VEROSSA 1JZFSE JZX110 | 01/6~ | Engine CAM SHAFT |
| 03901 3691 | 04445-22280 | | VEROSSA GX110,JZX110 | 01/6~ | Steering (P/S) R & P GASKET KIT |
| 03901 6029 | 90311-35013 | 35 x 49 x 6 | VEROSSA 1GFE GX110 | 01/6~ | Engine CAM SHAFT |
| 03901 1989 | 90311-40001 | 40 x 58 x 11 | VEROSSA JZX110 5F | 01/6~ | Transmission (M/T) REAR EXTENTION |
| 03901 3215 | 90311-32012 | 32 x 53 x 7 | VEROSSA JZX110 5F | 01/6~ | Transmission (M/T) FRONT COVER |
| 03901 5711 | 90311-48013 | 48 x 73 x 7 | VEROSSA GX110,JZX110 | 01/6~ | Wheel Hub FRONT |
| 03901 6819 | 90311-45015 | 45 x 62 x 9 | VEROSSA 1GFE GX110 | 01/6~ | Engine TIMING GEAR CASE |
| 03901 1805 | 90311-38075 | 38 x 55 x 7.8 | VITZ, PLATZ NCP1# | 99/8~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 3201 | 90311-75016 | 75 x 107 x 8 | VITZ, PLATZ 1NZFE,2NZFE NCP1# | 99/8~ | Engine CRANK SHAFT REAR |
| 03901 4853 | 90311-73001 | 73.5 x 89 x 8.5 | VITZ, PLATZ 1SZFE SCP1# | 99/1~ | Engine CRANK SHAFT REAR |
| 03901 1789 | 90311-25021 | 25.5 x 37.5 x 6 | VITZ, PLATZ 1NZFE,2NZFE NCP1# | 99/8~ | Engine OIL PUMP |
| 03901 5353 | 90311-35040 | 35 x 49 x 6 | VITZ, PLATZ 1SZFE SCP1# | 99/1~ | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 4677 | 04445-52010 | | VITZ, PLATZ NCP15,16 (4WD) | 99/9~ | Steering (P/S) R & P GASKET KIT |
| 03901 7609 | 04445-52020 | | VITZ, PLATZ SCP1#,NCP10,12 | 99/1~ | Steering (P/S) R & P GASKET KIT |
| 03901 7213 | 90913-02093 | | VITZ, PLATZ 1NZFE,2NZFE( IN. & EX.) | 99/8~ | Engine VALVE STEM SEAL |
| 03901 5681 | 90311-38075 | 38 x 55 x 7.8 | VITZ, PLATZ SCP1#,NCP1# | 99/6~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2145 | 90311-49003 | 49 x 68 x 8.5 | VITZ, PLATZ NCP15,16 (4WD) | 99/9~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 1201 | 90311-38075 | 38 x 55 x 7.8 | VITZ, PLATZ SCP1# | 99/1~99/6 | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 8051 | 90311-49002 | 50 x 64 x 8 | VITZ, PLATZ NCP15,16 (4WD) | 99/8~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 1587 | 90311-34016 | 34 x 54 x 9 x 15.5 | VITZ, PLATZ NCP110,12 | 99/9~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 3061 | 90311-34017 | 34 x 63 x 9 x 16 | VITZ, PLATZ NCP1# | 99/9~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 7487 | 90311-34016 | 34 x 54 x 9 x 15.5 | VITZ, PLATZ NCP110,12 | 99/9~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 2351 | 90311-38076 | 38 x 63 x 9 x 15.5 | VITZ, PLATZ SCP1# | 99/1~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 5179 | 90913-02120 | | VITZ, PLATZ 1SZFE | 99/1~ | Engine VALVE STEM SEAL |
| 03901 1883 | 90311-42055 | 42 x 55 x 7 | VITZ, PLATZ NCP15,16 (4WD) | 99/8~ | Wheel Hub REAR |
| 03901 4533 | 90311-23004 | 23 x 37 x 7 | VITZ, PLATZ SCP1# | 99/1~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 4237 | 90311-38074 | 38 x 54 x 9 x 15.5 | VITZ, PLATZ SCP1# | 99/1~ | Mission & Differential (M/T) TRANSAXLE CASE |
| 03901 4969 | 90311-34017 | 34 x 63 x 9 x 16 | VITZ, PLATZ NCP1# | 99/9~ | Mission & Differential (M/T) TRANSMISSION CASE |
| 03901 4609 | 90311-38074 | 38 x 54 x 9 x 15.5 | VITZ, PLATZ SCP1# | 99/1~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 4039 | 90311-38073 | 38 x 56 x 9 x 15.5 | VITZ, PLATZ SCP1# | 99/1~ | Mission & Differential (M/T) TRANSMISSION CASE |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 6201 | 90311-17009 | 17.5 x 32 x 6 | VITZ, PLATZ SCP1# | 99/1~ | Steering (M/S) RACK HOUSING |
| 03901 3153 | 90311-25011 | 25 x 37 x 8 | VITZ, PLATZ NCP1# | 99/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03901 6411 | 90311-25021 | 25.5 x 37.5 x 6 | WILL VI 2NZFE NCP19 | 00/1~ | Engine OIL PUMP |
| 03901 4521 | 90311-34016 | 34 x 54 x 9 x 15.5 | WILL VI NCP19 | 00/1~ | Mission & Differential (A/T) TRANSAXLE CASE (NO.2) |
| 03901 8117 | 90311-38075 | 38 x 55 x 7.8 | WILL VI NCP19 | 00/1~ | Mission & Differential (A/T) TRANSAXLE HOUSING |
| 03901 5605 | 04445-52020 | | WILL VI NCP19 | 00/1~ | Steering (P/S) R & P GASKET KIT |
| 03901 5925 | 90311-75016 | 75 x 107 x 8 | WILL VI 2NZFE NCP19 | 00/1~ | Engine CRANK SHAFT REAR |
| 03901 4439 | 90913-02093 | | WILL VI 2NZFE (IN. & EX.) | 00/1~ | Engine VALVE STEM SEAL |
| 03901 6881 | 90311-34017 | 34 x 63 x 9 x 16 | WILL VI NCP19 | 00/1~ | Mission & Differential (A/T) TRANSAXLE CASE |
| 03901 3159 | 90311-38075 | 38 x 55 x 7.8 | WILL VI NCP19 | 00/1~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 2931 | 90311-38034 | 38 x 50 x 10.5 | WINDOM 1MZFE,2MZFE MCV2# | 96/8~ | Engine CAM SHAFT |
| 03901 1611 | 90311-19010 | 19 x 32 x 6 | WINDOM VCV1#,MCV2# | 91/10~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 2547 | 90913-02111 | | WINDOM 1MZFE,2MZFE(EX.) | 96/8~ | Engine VALVE STEM SEAL |
| 03901 5833 | 90913-02101 | | WINDOM 1MZFE,2MZFE(IN.) | 96/8~ | Engine VALVE STEM SEAL |
| 03901 7515 | 90913-02062 | | WINDOM 3VZFE,4VZFE(EX.) | 91/10~96/ | Engine VALVE STEM SEAL |
| 03901 1633 | 90913-02095 | | WINDOM 3VZFE,4VZFE(IN.) | 91/10~96/ | Engine VALVE STEM SEAL |
| 03901 3229 | 90311-92008 | 92 x 110 x 9 | WINDOM 1MZFE,2MZFE MCV2# | 96/8~ | Engine CRANK SHAFT REAR |
| 03901 7363 | 90311-92005 | 92 x 110 x 10 | WINDOM 3VZFE,4VZFE VCV1# | 91/10~96/ | Engine CRANK SHAFT REAR |
| 03901 5911 | 90311-40022 | 40 x 55 x 6 | WINDOM 1MZFE,2MZFE MCV2# | 96/8~ | Engine OIL PUMP |
| 03901 3011 | 90311-26003 | 26 x 38 x 6.5 | WINDOM VCV1#,MCV2# | 91/10~ | Steering (P/S) CONTROL VALVE UPPER |
| 03901 7231 | 90311-38034 | 38 x 50 x 10.5 | WINDOM 3VZFE,4VZFE VCV1# | 91/10~96/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.1 TOYOTA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03901 1939 | 90311-40010 | 40 x 56 x 9 x 15.5 | WINDOM VCV1# | 91/10~96/ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 2859 | 04445-33070 | | WINDOM MCV2# | 96/8~ | Steering (P/S) R & P GASKET KIT |
| 03901 7105 | 04445-33030 | | WINDOM VCV11 | 94/9~96/ | Steering (P/S) R & P GASKET KIT |
| 03901 5813 | 04445-33012 | | WINDOM VCV11 | 93/8~94/9 | Steering (P/S) R & P GASKET KIT |
| 03901 6765 | 04445-33040 | | WINDOM VCV10 | 94/9~96/ | Steering (P/S) R & P GASKET KIT |
| 03901 2617 | 04445-33023 | | WINDOM VCV10 | 91/10~94/ 9 | Steering (P/S) R & P GASKET KIT |
| 03901 6083 | 90311-38020 | 38 x 55 x 8.5 | WINDOM VCV,MCV2# | 91/10~ | Mission & Differential (A/T) FRONT OIL PUMP |
| 03901 4925 | 90311-50011 | 50 x 80 x 16.5 x 23 | WINDOM VCV,MCV2# | 91/10~ | Mission & Differential (A/T) DIFF. SIDE |
| 03901 4583 | 90311-40010 | 40 x 56 x 9 x 15.5 | WINDOM MCV2# | 96/8~ | Mission & Differential (A/T) FRONT DIFFERENTIAL |
| 03901 2639 | 90311-40022 | 40 x 55 x 6 | WINDOM 3VZFE,4VZFE VCV1# | 91/10~96/ | Engine OIL PUMP |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 5351 | 91213 PE1 721/2 | 29 x 45 x 8 | ACCORD A18A,A20A CA1.5,6 | 85/5~89/ | Engine CAM SHAFT |
| 03902 7448 | 91203 PG6 003 | 27 x 43 x 9 | ACCORD B18A,B20A CA2,3 | 85/5~89/ | Engine CAM SHAFT |
| 03902 3146 | 91213 PT0 003/4 | 28 x 42 x 8 | ACCORD F18A,F20A,F22A CB1,2,3,4,6,7,9 | 89/9~94/ | Engine CAM SHAFT |
| 03902 5198 | 91213 PT0 003/4 | 28 x 42 x 8 | ACCORD F18B,F20B,F22B CD3,4,5,7,CE1 | 93/9~97/ | Engine CAM SHAFT |
| 03902 3560 | 91213 PT0 003/4 | 28 x 42 x 8 | ACCORD F18B,F20B,F23A CF3,4(SOHC),5,6,7,CL3 | 97/9~ | Engine CAM SHAFT |
| 03902 3488 | 91213 PR3 003/4 | 29 x 43 x 8 | ACCORD G20A CB5 | 89/9~95/ | Engine CAM SHAFT |
| 03902 1211 | 91213 PR3 003/4 | 29 x 43 x 8 | ACCORD H22A,H23A CD6,8,CF2,CL1,2,CH9 | 93/9~ | Engine CAM SHAFT |
| 03902 4010 | 91213 PR3 003/4 | 29 x 43 x 8 | ACCORD F20B CF4(DOHC) | 97/9~ | Engine CAM SHAFT |
| 03902 4163 | 91233 PT0 003 | 27 x 40 x 8 | ACCORD F18B,F20B,F22B CD3,4,5,7,CE1 | 93/9~97/ | Engine OIL UPMP |
| 03902 2885 | 91213 PE1 721/2 | 29 x 45 x 8 | ACCORD EY,ES AC,AD | 83/6~85/ | Engine CAM SHAFT |
| 03902 4280 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | ACCORD CF3,4,6,CL1,3 | 97/9~ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 8762 | 91233 PT0 003 | 27 x 40 x 8 | ACCORD F18A,F20A,F22A CB1,2,3,4,6,7,9 | 89/9~94/ | Engine OIL UPMP |
| 03902 2075 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | ACCORD CB5 | 89/9~93/ | Mission & Differential (A/T) MISSION CASE |
| 03902 8600 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ACCORD CE,CF#,CL#,CH9 | 94/2~ | Mission & Differential (A/T) MISSION CASE |
| 03902 1778 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ACCORD CD# | 93/9~97/ | Mission & Differential (A/T) MISSION CASE |
| 03902 1805 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ACCORD CB1,2,3,4 | 89/9~93/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6737 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | ACCORD CA2,3 | 85/5~89/ | Mission & Differential (A/T) MISSION CASE |
| 03902 3533 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | ACCORD CA1,5 | 85/5~89/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6467 | 91207 P0X 003/4 | 44 x 68 x 8 | ACCORD CF#,CL#,CH9 | 96/9~ | Mission & Differential (A/T) CONVERTER CASE NO.2 |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 3551 | 91207 P0X 003/4 | 44 x 68 x 8 | ACCORD CE1 | 95/6~97/ | Mission & Differential (A/T) CONVERTER CASE NO.2 |
| 03902 2669 | 91233 PT0 003 | 27 x 40 x 8 | ACCORD F18B,F20B,F23A CF3,4,5,6,7,CL3 | 97/9~ | Engine OIL UPMP |
| 03902 7835 | 91 207 639 015 | 44 x 68 x 8 | ACCORD CA#,CB# | 85/5~93/ | Mission & Differential (A/T) CONVERTER CASE NO.2 |
| 03902 4784 | 91214 PC6 003/13 | 80 x 100 x 10 | ACCORD EY,ES...AC,AD | 83/6~85/ | Engine CRANK SHAFT REAR |
| 03902 8735 | 91 207 639 015 | 44 x 68 x 8 | ACCORD CE1 | 94/2~95/6 | Mission & Differential (A/T) CONVERTER CASE NO.2 |
| 03902 2624 | 91214 PC6 003/13 | 80 x 100 x 10 | ACCORD A18A,A20A,B18A,B20A CA# | 85/5~89/ | Engine CRANK SHAFT REAR |
| 03902 6305 | 12211 PZ1 004 | | ACCORD F18B,F20B,F22B,F23A,H22 A,H23A EXHAUST | 93/9~ | Engine VALVE STEM SEAL |
| 03902 5936 | 1221 PZ1 004 | | ACCORD F18A,F20A(SOHC),F22A EXHAUST | 89/9~93/ | Engine VALVE STEM SEAL |
| 03902 2858 | 12210 PZ1 004 | | ACCORD F18B,F20B,F22B,F23A,H22 A,H23A INTAKE | 93/9~ | Engine VALVE STEM SEAL |
| 03902 3344 | 12210 PZ1 004 | | ACCORD F18A,F20A(SOHC),F22A INTAKE | 89/9~93/ | Engine VALVE STEM SEAL |
| 03902 6017 | 12211 PT2 003/4 | | ACCORD F20A(DOHC) EXHAUST | 89/9~93/ | Engine VALVE STEM SEAL |
| 03902 4802 | 12210 PT2 003/4 | | ACCORD F20A(DOHC)..INTAKE | 89/9~93/ | Engine VALVE STEM SEAL |
| 03902 7277 | 12211 PE0 003/4 | | ACCORD B18A,B20A EXHAUST | 85/5~89/ | Engine VALVE STEM SEAL |
| 03902 9185 | 12211 PD2 003 | | ACCORD A18A,A20A INTAKE | 85/5~89/ | Engine VALVE STEM SEAL |
| 03902 8069 | 12210 PD2 003/4 | | ACCORD A18A,A20A,B18A,B20A INTAKE | 85/5~89/ | Engine VALVE STEM SEAL |
| 03902 7916 | 91214 PB2 003 | 76 x 98 x 12 | ACCORD EK SM/C#1221932~,SZ | 80/~83/ | Engine CRANK SHAFT REAR |
| 03902 8438 | 91214 PC6 003/13 | 80 x 100 x 10 | ACCORD F18#,F20#,F22#,F23A,G20A, H22A CB#,CD#,CE1,CF# | 89/9~00/6 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 3029 | 91233 PT0 003 | 27 x 40 x 8 | ACCORD H22A,H23A CD6,8,CF1,2,CH9 | 93/9~ | Engine OIL UPMP |
| 03902 5171 | 91201 PW5 015 | 50 x 70 x 11 | ACCORD CB5 | 89/9~93/ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 2354 | 91214 PB2 003 | 76 x 98 x 12 | ACCORD EP SV,SY | 80/7~83/ | Engine CRANK SHAFT REAR |
| 03902 4127 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACCORD CF5,7,CL2(4WD) | 97/9~ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 8213 | 91214 634 003/4 | 74 x 98 x 12 | ACCORD EK SM C/#~1221931 | 78/9~80/ | Engine CRANK SHAFT REAR |
| 03902 1886 | 91212 PT0 003 | 40 x 52 x 7 | ACCORD F18#,F20#,F22#,F23A,G20A, H22A,H23A | 89/9~ | Engine CRANK SHAFT FRONT |
| 03902 3416 | 91212 PJ5 003/13 | 38 x 53 x 7 | ACCORD B18A,B20A CA2,3 | 85/5~89/ | Engine CRANK SHAFT FRONT |
| 03902 4298 | 91212 PC6 003/4 | 35 x 54 x 8 | ACCORD A18A,A20A CA1.5,6 | 85/5~89/ | Engine CRANK SHAFT FRONT |
| 03902 4856 | 91212 PC6 003/4 | 35 x 54 x 8 | ACCORD EY,ES AC,AD | 83/6~85/ | Engine CRANK SHAFT FRONT |
| 03902 7070 | 91 212 611 003 | 35 x 50 x 8 | ACCORD EP,EK SV,SY,SM,SZ | 78/9~83/ | Engine CRANK SHAFT FRONT |
| 03902 1544 | 91233 PV0 003 | 27 x 41 x 8 | ACCORD G20A CB5 | 89/9~95/ | Engine BALANCER SHAFT |
| 03902 1895 | 91214 PH1 003/13 | 80 x 100 x 10 | ACCORD F18B,F20B,F23A,H22A,H23 A CF#,CL#,CH9 | 00/6~ | Engine CRANK SHAFT REAR |
| 03902 3596 | 91251 SA5 003/5 | 47 x 72.2 x 6 x 8 | ACCORD SZ 3,4DOOR | 81/9~83/ | Wheel Hub FRONT OUTER |
| 03902 8888 | 91216 PH8 003/5 | 28 x 41 x 7 | ACCORD CA3(B20A) | 85/5~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4352 | 91216 PC8 003/5 | 27 x 42 x 7 | ACCORD CA1(A18A),CA2(B18A) | 85/5~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2327 | 91216 PC8 003/5 | 27 x 42 x 7 | ACCORD AC,AD | 83/6~85/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8834 | 91216 689 003/5 | 25 x 40 x 7 | ACCORD SM,SV,SY,SZ | 78/9~83/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 5279 | 91252 692 003/5 | 42 x 56.2 x 7 | ACCORD AC,AD DRUM BRAKE | 83/6~85/ | Wheel Hub REAR |
| 03902 5405 | 91252 692 003/5 | 42 x 56.2 x 7 | ACCORD SZ EXCEPT EXT 3 DOOR | 81/9~83/ | Wheel Hub REAR |
| 03902 7646 | 91252 692 003/5 | 42 x 56.2 x 7 | ACCORD SY | 81/9~83/ | Wheel Hub REAR |
| 03902 8465 | 91252 692 930/1 | 42 x 56.2 x 9.5 | ACCORD AC,AD DISC BRAKE | 83/6~85/ | Wheel Hub REAR |
| 03902 8969 | 91251 634 003/5 | 42 x 60 x 7 | ACCORD SM,SV | 78/9~81/ | Wheel Hub REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 7601 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACCORD CH9 | 98/12~ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 7898 | 91216 PH8 003/5 | 28 x 41 x 7 | ACCORD C8# | 89/9~93/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 7331 | 91251 SA5 003/5 | 47 x 72.2 x 6 x 8 | ACCORD AC | 83/6~85/ | Wheel Hub FRONT OUTER |
| 03902 2714 | 91252 692 930/1 | 42 x 56.2 x 9.5 | ACCORD SZ EXT 3 DOOR | 81/9~83/ | Wheel Hub REAR |
| 03902 3425 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | ACCORD SZ EXCEPT 3,4 DOOR | 81/9~83/ | Wheel Hub FRONT OUTER |
| 03902 3092 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | ACCORD SV,SY | 80/7~83/ | Wheel Hub FRONT OUTER |
| 03902 3767 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | ACCORD SM C/#1200001~ | 80/5~81/ | Wheel Hub FRONT OUTER |
| 03902 2777 | 91251 671 003/5 | 45 x 63.7 x 72.2 x 7.5 | ACCORD SM | 78/9~80/4 | Wheel Hub FRONT OUTER |
| 03902 6908 | 91250 SB0 013/15 | 49 x 64 x 6 x 13 | ACCORD AD ATM | 83/6~85/ | Wheel Hub FRONT INNER |
| 03902 2849 | 91250 SB0 623 | 47 x 64 x 6 x 14 | ACCORD AD MTM | 83/6~85/ | Wheel Hub FRONT INNER |
| 03902 8951 | 91250 SB0 623 | 47 x 64 x 6 x 14 | ACCORD AC | 83/6~85/ | Wheel Hub FRONT INNER |
| 03902 2156 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | ACCORD SV,SY,SZ | 80/7~83/ | Wheel Hub FRONT INNER |
| 03902 7241 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | ACCORD SM C/#1200001~ | 80/5~81/ | Wheel Hub FRONT INNER |
| 03902 8357 | 91250 634 003/5 | 45 x 64 x 9 x 14 | ACCORD SM | 78/9~80/4 | Wheel Hub FRONT INNER |
| 03902 7655 | 91251 SA5 003/5 | 47 x 72.2 x 6 x 8 | ACCORD AD MTM | 83/6~85/ | Wheel Hub FRONT OUTER |
| 03902 7736 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ACCORD CD# | 93/9~97/ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 2804 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ACCORD CF2 | 96/9~ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 6584 | 91251 SB0 013/15 | 49 x 72.2 x 6 x 8 | ACCORD AD ATM | 83/6~85/ | Wheel Hub FRONT OUTER |
| 03902 6071 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ACCORD CE1 | 94/2~97/ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 5603 | 91216 PH8 003/5 | 28 x 41 x 7 | ACCORD CD# | 93/9~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6656 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ACCORD CB1,2,3,4 | 89/9~93/ | Mission & Differential (A/T) CONVERTER CASE NO.1 |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 1481 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | ACCORD CA 2,3 | 85/5~89/ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 5693 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | ACCORD CA1,5 | 85/5~89/ | Mission & Differential (A/T) CONVERTER CASE NO.1 |
| 03902 2957 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | ACCORD CB5 | 89/9~93/ | Mission & Differential (M/T) MISSION CASE |
| 03902 7025 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | ACCORD CF#,CL# | 97/9~ | Mission & Differential (M/T) MISSION CASE |
| 03902 5108 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | ACCORD CD# | 93/9~97/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1373 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | ACCORD CB1,2,3,4 | 89/9~93/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2390 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | ACCORD CA2,3 | 85/5~89/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1742 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | ACCORD AC,AD | 83/6~85/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2084 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | ACCORD CA1 | 85/5~89/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3272 | 91216 PH8 003/5 | 28 x 41 x 7 | ACCORD CF#,CL# | 97/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 7043 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | ACCORD SM,SV,SY,SZ | 78/9~83/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8780 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | ACCORD CA# | 85/5~89/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 1346 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACCORD CB1,2,3,4 | 89/9~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8159 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACCORD CD# | 93/9~97/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3893 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACCORD CF#,CL# | 97/9~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6260 | 91201 PW5 015 | 50 x 70 x 11 | ACCORD CB5 | 89/9~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5792 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | ACCORD SM,SV,SY,SZ | 78/9~83/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4442 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | ACCORD AC,AD | 83/6~85/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2840 | 91 214 679 024 | 65 x 88 x 12 | ACTY TRUCK, VAN, STREET EH TA,TB,VD,VH | 77/8~88/ | Engine CRANK SHAFT REAR |
| 03902 6368 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACTY TRUCK, VAN, STREET HA3,4,5,6,7,HH3,4,5,6 | 90/2~ | Mission & Differential (A/T) CONVERTER CASE (A) |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 8015 | 91203 PG6 003 | 27 x 43 x 9 | ACTY TRUCK, VAN, STREET EH TA,TB,TC,VD,VH | 77/8~88/ | Engine CAM SHAFT |
| 03902 4568 | 91207 P0X 003 | 44 x 68 x 8 | ACTY TRUCK, VAN, STREET HA3,4,5,6,7,HH3,4,5,6 | 94/10~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 9032 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | ACTY TRUCK, VAN, STREET TC,VH(4WD) | 83/2~88/ | Mission & Differential (A/T) MISSION CASE |
| 03902 9077 | 91205 PN1 014 | 35 x 46 x 9 x 12.5 | ACTY TRUCK, VAN, STREET HA1,2,HH1,2 | 88/5~90/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7538 | 91 214 679 024 | 65 x 88 x 12 | ACTY TRUCK, VAN, STREET E07A HA3,4,5,HH3,4 | 90/2~99/ | Engine CRANK SHAFT REAR |
| 03902 8393 | 91205 PZ5 003/4 | 35 x 62 x 9 x 12.5 | ACTY TRUCK, VAN, STREET HA3,4,5,6,7,HH3,4,5 | 90/2~ | Mission & Differential (A/T) MISSION CASE |
| 03902 8906 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | ACTY TRUCK, VAN, STREET HH6 | 99/6~ | Mission & Differential (A/T) MISSION CASE |
| 03902 1850 | 91 207 639 015 | 44 x 68 x 8 | ACTY TRUCK, VAN, STREET HA1,2,3,4,HH1,2,3,4 | 88/5~94/10 | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4226 | 91203 PG6 003 | 27 x 43 x 9 | ACTY TRUCK, VAN, STREET E05A HA1,2,HH1,2 | 88/5~90/ | Engine CAM SHAFT |
| 03902 8672 | 91203 PG6 003 | 27 x 43 x 9 | ACTY TRUCK, VAN, STREET E07A,Z HA3,4,5,6,7,HH3,4,5,6 | 90/2~ | Engine CAM SHAFT |
| 03902 5873 | 91 212 679 014 | 30 x 42 x 8 | ACTY TRUCK, VAN, STREET EH TA,TB,TC,VD,VH | 77/8~88/ | Engine CRANK SHAFT FRONT |
| 03902 3722 | 91212 PN4 003 | 30 x 42 x 7 | ACTY TRUCK, VAN, STREET E05A HA1,2,HH1,2 | 88/5~90/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 6359 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | ACTY TRUCK, VAN, STREET HA1,2,HH1,2 | 88/5~90/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 8024 | 91214 PFB 003 | 65 x 88 x 10 | ACTY TRUCK, VAN, STREET E07Z HA6,7,HH5,6 | 99/5~ | Engine CRANK SHAFT REAR |
| 03902 1994 | 91 214 679 024 | 65 x 88 x 12 | ACTY TRUCK, VAN, STREET E05A HA1,2,HH1,2 | 88/5~90/ | Engine CRANK SHAFT REAR |
| 03902 5972 | 12211 PZ1 004 | | ACTY TRUCK, VAN, STREET E05A,E07A,Z EXHAUST | 88/5~ | Engine VALVE STEM SEAL |
| 03902 2210 | 12210 PZ1 004 | | ACTY TRUCK, VAN, STREET E05A,E07A,Z INTAKE | 88/5~ | Engine VALVE STEM SEAL |
| 03902 5180 | 91250 SC2 003/5 | 45 x 58 x 8 | ACTY TRUCK, VAN, STREET TC,VH(4WD) | 83/2~88/ | Wheel Hub FRONT INNER |
| 03902 2975 | 91212 PN4 003 | 30 x 42 x 7 | ACTY TRUCK, VAN, STREET E07A,Z HA3,4,5,6,7,HH3,4,5,6 | 90/2~ | Engine CRANK SHAFT FRONT |
| 03902 1157 | 91250 679 003/5 | 42 x 51 x 7.5 x 10.5 | ACTY TRUCK, VAN, STREET TA,TB,VD DISC BRAKE | 85/6~88/ | Wheel Hub FRONT |
| 03902 5909 | 91206 PE9 003 | 35 x 56 x 9 x 12.5 | ACTY TRUCK, VAN, STREET TC,VH(4WD) | 83/2~88/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 8411 | 91251 SC2 005 | 45 x 64.2 x 6 x 8 | ACTY TRUCK, VAN, STREET TC,VH(4WD) | 85/8~88/ | Wheel Hub FRONT OUTER |
| 03902 6872 | 91252 634 003/5 | 42 x 60 x 7 | ACTY TRUCK, VAN, STREET TA,TB C/#~1500000 | 77/8~79/10 | Wheel Hub FRONT |
| 03902 7223 | 91251 SA7 023/25 | 45 x 64.2 x 6 x 6.5 | ACTY TRUCK, VAN, STREET TC,VH(4WD) C/#~1100000 | 83/2~85/7 | Wheel Hub FRONT OUTER |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 5810 | 91 252 679 003 | 40 x 53.5 x 8 x 15 | ACTY TRUCK, VAN, STREET TA,TB,VD | 77/8~88/ | Wheel Hub REAR INNER |
| 03902 3443 | 91 252 679 003 | 40 x 53.5 x 8 x 15 | ACTY TRUCK, VAN, STREET HA1,2,3,4,5,HH1,2,3,4 | 88/5~99/ | Wheel Hub REAR INNER |
| 03902 4532 | 91252 SC2 003/5 | 42 x 55 x 7 | ACTY TRUCK, VAN, STREET TC,VH(4WD) | 83/2~88/ | Wheel Hub REAR INNER |
| 03902 6593 | 91257 679 003/13 | 50 x 66 x 8 x 13 | ACTY TRUCK, VAN, STREET TA,TB,VD | 77/8~88/ | Wheel Hub REAR OUTER |
| 03902 2183 | 91257 SJ6 000 | 50 x 64 x 6.8 x 11 | ACTY TRUCK, VAN, STREET HA1,2,3,4,5,HH1,2,3,4 | 88/5~99/ | Wheel Hub REAR OUTER |
| 03902 4748 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | ACTY TRUCK, VAN, STREET TA,TB,TC,VD,VH | 77/8~88/ | Mission & Differential (M/T) MISSION CASE |
| 03902 5477 | 91252 692 003/5 | 42 x 56.2 x 7 | ACTY TRUCK, VAN, STREET TA,TB,VD DRUM BRAKE | 79/11~88/ | Wheel Hub FRONT |
| 03902 7664 | 91216 PA0 003/5 | 22 x 35 x 7 | ACTY TRUCK, VAN, STREET TA,TB,TC,VD,VH | 77/8~88/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6674 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ACTY TRUCK, VAN, STREET HA6,7,HH5,6 | 99/5~ | Mission & Differential (M/T) MISSION CASE |
| 03902 8546 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | ACTY TRUCK, VAN, STREET HA1,2,3,4,5,HH1,2,3,4 | 88/5~99/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1517 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ACTY TRUCK, VAN, STREET HA#,HH# | 88/5~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6503 | 91206 PE9 003 | 35 x 56 x 9 x 12.5 | ACTY TRUCK, VAN, STREET TC,VH(4WD) | 83/2~88/ | Mission & Differential (M/T) CLUTCH CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 6530 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | ACTY TRUCK, VAN, STREET TA,TB,VD | 77/8~88/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5729 | 91216 PZ6 005 | 22 x 36 x 7 | ACTY TRUCK, VAN, STREET HA3,4,5,6,7,HH3,4,5,6 | 90/2~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4757 | 91216 PL6 003 | 20 x 34 x 7 | ACTY TRUCK, VAN, STREET HA1,2,HH1,2 | 88/5~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6935 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | ASCOT / RAFAGA CB5,CE4,5 G20A,G25A | 92/3~97/ | Mission & Differential (A/T) MISSION CASE |
| 03902 8843 | 1221 PT2 003/4 | | ASCOT / RAFAGA F18A,F20A,H23A(DOHC) IEXHAUST | 89/9~95/ | Engine VALVE STEM SEAL |
| 03902 8141 | 91214 PC6 003/13 | 80 x 100 x 10 | ASCOT / RAFAGA F18A,F20A,H23A CB1,2,3,4,CC# | 89/9~95/ | Engine CRANK SHAFT REAR |
| 03902 3119 | 91213 PR3 003/4 | 29 x 43 x 8 | ASCOT / RAFAGA G20A,G25A CB5,CE4,5 | 92/3~97/ | Engine CAM SHAFT |
| 03902 7574 | 91212 PT0 003 | 40 x 52 x 7 | ASCOT / RAFAGA F18A,F20A,H23A CB1,2,3,4,CC# | 89/9~95/ | Engine CRANK SHAFT FRONT |
| 03902 3434 | 91212 PT0 003 | 40 x 52 x 7 | ASCOT / RAFAGA G20A,G25A CB4,5 | 92/3~97/ | Engine CRANK SHAFT FRONT |
| 03902 2192 | 91213 PT0 003/4 | 28 x 42 x 8 | ASCOT / RAFAGA F18A,F20A,H23A CB1,2,3,4,CC# | 89/9~95/ | Engine CAM SHAFT |
| 03902 3083 | 91214 PC6 003/13 | 80 x 100 x 10 | ASCOT / RAFAGA G20A,G25A CB5,CE4,5 | 92/3~97/ | Engine CRANK SHAFT REAR |
| 03902 2615 | 12210 PZ1 004 | | ASCOT / RAFAGA F18A,F20A(SOHC) INTAKE | 89/9~95/ | Engine VALVE STEM SEAL |
| 03902 4559 | 12210 PZ1 004 | | ASCOT / RAFAGA G20A,G25A INTAKE | 92/3~97/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 3011 | 12211 PZ1 004 | | ASCOT / RAFAGA F18A,F20A(SOHC) EXHAUST | 89/9~95/ | Engine VALVE STEM SEAL |
| 03902 5207 | 12210 PT2 003/4 | | ASCOT / RAFAGA F18A,F20A,H23A(DOHC) INTAKE | 89/9~95/ | Engine VALVE STEM SEAL |
| 03902 8978 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ASCOT / RAFAGA CC4,5 H23A | 92/3~95/ | Mission & Differential (A/T) MISSION CASE |
| 03902 8366 | 91201 PW5 015 | 50 x 70 x 11 | ASCOT / RAFAGA CB5,CE4,5 G20A,G25A | 92/3~97/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 9230 | 12211 PZ1 004 | | ASCOT / RAFAGA G20A,G25A EXHAUST | 92/3~97/ | Engine VALVE STEM SEAL |
| 03902 1913 | 91201 PW5 015 | 50 x 70 x 11 | ASCOT / RAFAGA CB5 G20A | 92/3~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6449 | 9121 PH8 003/5 | 28 x 41 x 7 | ASCOT / RAFAGA CB# | 89/9~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 7061 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ASCOT / RAFAGA CB1,2,3,4 F18A,F20A | 89/9~95/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6080 | 9121 PH8 003/5 | 28 x 41 x 7 | ASCOT / RAFAGA CE# | 93/10~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8285 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ASCOT / RAFAGA CC4,5 H23A | 92/3~95/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3470 | 9121 PH8 003/5 | 28 x 41 x 7 | ASCOT / RAFAGA CC# | 92/3~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2237 | 91201 PW5 015 | 50 x 70 x 11 | ASCOT / RAFAGA CE4,5 G20A,G25A | 93/10~97/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5819 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | ASCOT / RAFAGA CB1,2,3,4 F18A,F20A | 89/9~95/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4325 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | ASCOT / RAFAGA CC4,5 H23A | 92/3~95/ | Mission & Differential (M/T) MISSION CASE |
| 03902 6881 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | ASCOT / RAFAGA CB5 G20A | 92/3~93/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4082 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | ASCOT / RAFAGA CE4,5 G20A,G25A | 93/10~97/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4595 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ASCOT / RAFAGA CB1,2,3,4 F20A | 89/9~95/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 5612 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ASCOT / RAFAGA CC4,5 H23A | 92/3~95/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 2381 | 91 207 639 015 | 44 x 68 x 8 | ASCOT / RAFAGA CB#,CC#,CE# | 89/9~97/ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 7565 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ASCOT / RAFAGA CB1,2,3,4 F18A,F20A | 89/9~95/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6026 | 91212 P8A A01 | 41.5 x 56 x 8 | AVANCIER TA3,4 J30A | 00/2~ | Engine CRANK SHAFT FRONT |
| 03902 7961 | 91207 P7Z 003 | 44 x 68 x 8 | AVANCIER TA3,4 | 00/2~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 5558 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | AVANCIER TA1,2 | 99/9~ | Mission & Differential (A/T) MISSION CASE |
| 03902 2435 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | AVANCIER TA3,4 | 00/2~ | Mission & Differential (A/T) MISSION CASE |
| 03902 8798 | 91207 P0X 003/4 | 44 x 68 x 8 | AVANCIER TA1,2 | 99/9~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 3821 | 91213 PT0 003/4 | 28 x 42 x 8 | AVANCIER TA1,2 F23A | 99/9~ | Engine CAM SHAFT |
| 03902 1733 | 91213 P8A A01 | 39.5 x 53 x 8 | AVANCIER TA3,4 J30A | 00/2~ | Engine CAM SHAFT |
| 03902 7016 | 91212 PT0 003 | 40 x 52 x 7 | AVANCIER TA1,2 F23A | 99/9~ | Engine CRANK SHAFT FRONT |
| 03902 4739 | 91233 PT0 003 | 27 x 40 x 8 | AVANCIER TA1,2 F23A | 99/9~ | Engine OIL PUMP |
| 03902 7088 | 91214 PC6 003/13 | 80 x 100 x 10 | AVANCIER TA1,2 F23A | 99/9~ | Engine CRANK SHAFT REAR |
| 03902 6917 | 91214 P8A A01 | 80 x 98 x 10 | AVANCIER TA3,4 J30A | 00/2~ | Engine CRANK SHAFT REAR |
| 03902 8330 | 12210 PZ1 004 | | AVANCIER F23A,J30A INTAKE | 99/9~ | Engine VALVE STEM SEAL |
| 03902 8384 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | AVANCIER TA2 (F23A,4WD) | 99/9~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 6692 | 91206 P0Z 005 | 35 x 54 x 8 x 11.5 | AVANCIER TA4 (J30A,4WD) | 00/2~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 1418 | 91205 P0K 005 | 40 x 56 x 8 x 11.5 | AVANCIER TA1 (F23A,2WD) | 99/9~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 6143 | 12211 PZ1 004 | | AVANCIER F23A,J30A EXHAUST | 99/9~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2282 | 91206 P0Z 005 | 35 x 54 x 8 x 11.5 | AVANCIER TA3 (J30A,2WD) | 00/2~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5045 | 91212 PLC 003/4 | 38 x 50 x 7 | CAPA D15B GA4,6 (E/#9024774~) | 00/02~ | Engine CRANK SHAFT FRONT |
| 03902 2912 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CAPA GA4 | 98/4~02/ | Mission & Differential (4A/T) CONVERTER CASE (A) |
| 03902 4838 | 12210 PZ1 004 | | CAPA D15B INTAKE | 98/4~02/ | Engine VALVE STEM SEAL |
| 03902 4982 | 91207 P0X 003/4 | 44 x 68 x 8 | CAPA GA4 | 98/4~02/ | Mission & Differential (4A/T) CONVERTER CASE (B) |
| 03902 5027 | 91214 PC6 003/13 | 80 x 100 x 10 | CAPA D15B GA4,6 | 98/4~00/12 | Engine CRANK SHAFT REAR |
| 03902 7484 | 12211 PZ1 004 | | CAPA D15B EXHAUST | 98/4~02/ | Engine VALVE STEM SEAL |
| 03902 4001 | 91212 P01 003 | 31 x 46 x 7 | CAPA D15B GA4,6 (E/#~9024773) | 98/4~00/ | Engine CRANK SHAFT FRONT |
| 03902 2561 | 91213 PE1 721/2 | 29 x 45 x 8 | CAPA D15B GA4,6 | 98/4~02/ | Engine CAM SHAFT |
| 03902 1256 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CAPA GA6 | 99/9~02/ | Mission & Differential (HMM) MISSION CASE |
| 03902 6683 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CAPA GA4 | 98/4~02/ | Mission & Differential (HMM) MISSION CASE |
| 03902 5981 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CAPA GA4,6 | 98/4~02/ | Mission & Differential (HMM) FLYWHEEL CASE |
| 03902 7097 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CAPA GA4 | 98/4~02/ | Mission & Differential (4AT) MISSION CASE |
| 03902 5153 | 91214 PH1 003/13 | 80 x 100 x 10 | CAPA D15B GA4,6 | 00/12~02/ | Engine CRANK SHAFT REAR |
| 03902 8960 | 91205 PL1 003 | 38 x 50 x 8 x 11.5 | CITY GA2 | 88/8~94/ | Mission & Differential (A/T) CONVERTER CASE |
| 03902 4991 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | CITY AA,VF | 81/10~86/ | Mission & Differential (A/T) MISSION CASE |
| 03902 1625 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | CITY GA# | 86/10~94/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2120 | 91203 PG6 003 | 27 x 43 x 9 | CITY ER AA,VF | 81/10~86/ | Engine CAM SHAFT |
| 03902 5756 | 91213 PE1 721/2 | 29 x 45 x 8 | CITY D12A,D13C GA1,GA2 | 86/10~94/ | Engine CAM SHAFT |
| 03902 8105 | 91 212 611 003 | 35 x 50 x 8 | CITY ER AA,VF | 81/10~86/ | Engine CRANK SHAFT FRONT |
| 03902 1922 | 91212 PE0 003 | 31 x 46 x 8 | CITY D12A,D13C GA1,GA2 | 86/10~94/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 3227 | 91205 PL0 003 | 35 x 50 x 8 x 11.5 | CITY GA1 | 86/10~94/ | Mission & Differential (A/T) CONVERTER CASE |
| 03902 2876 | 91214 PC6 003/13 | 80 x 100 x 10 | CITY D12A,D13C GA1,GA2 | 86/10~94/ | Engine CRANK SHAFT REAR |
| 03902 5459 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | CITY AA,VF | 81/10~84/ 4 | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2300 | 91214 634 003/4 | 74 x 98 x 12 | CITY ER AA,VF | 81/10~86/ | Engine CRANK SHAFT REAR |
| 03902 3812 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | CITY AA,VF | 81/10~86/ | Mission & Differential (A/T) CONVERTER CASE |
| 03902 1697 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | CITY GA# | 86/10~94/ | Mission & Differential (M/T) MISSION CASE |
| 03902 6953 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | CITY AA C/#1400001~,VF C/#1200001~ | 84/4~86/ | Mission & Differential (M/T) MISSION CASE |
| 03902 6728 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | CITY AA,VF | 81/10~84/ 4 | Mission & Differential (M/T) MISSION CASE |
| 03902 4217 | 91205 PL1 003 | 38 x 50 x 8 x 11.5 | CITY GA2 | 88/8~94/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 1985 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CITY AA C/#1400001~,VF C/#1200001~ | 84/4~86/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2894 | 91216 PA0 003/5 | 22 x 35 x 7 | CITY AA,VF,GA# | 81/10~94/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2021 | 91252 692 003/5 | 42 x 56.2 x 7 | CITY AA,VF | 81/10~86/ | Wheel Hub REAR |
| 03902 6800 | 91251 SA7 023/25 | 45 x 64.2 x 6 x 6.5 | CITY AA C/#~1259221~,VF C/#1101957~ | 83/~86/ | Wheel Hub FRONT OUTER |
| 03902 8897 | 91251 SA7 013/15 | 43 x 64.2 x 6 x 6.5 | CITY AA,VF | 81/10~83/ | Wheel Hub FRONT OUTER |
| 03902 1931 | 91250 SA7 013/15 | 45 x 58 x 67 x 10 | CITY AA,VF | 81/10~86/ | Wheel Hub FRONT INNER |
| 03902 6557 | 91205 PL0 003 | 35 x 50 x 8 x 11.5 | CITY GA1 | 86/10~94/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5162 | 91216 PA0 003/5 | 22 x 35 x 7 | CIVIC SL,SS,SR,ST,VC,VE,WD | 79/7~83/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4406 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CIVIC EK2,3,8,EU1,3 (2WD,SOHC) | 95/9~ | Mission & Differential (A/T) MISSION CASE |
| 03902 6098 | 91212 PM7 003 | 31 x 46 x 8 | CIVIC ZC(DOHC . 1600) EF3,5,EH1 | 87/7~97/ | Engine CRANK SHAFT FRONT |
| 03902 3974 | 91212 PE0 003 | 31 x 46 x 8 | CIVIC D13B,D15B EF1,2,4,EY2 | 87/7~92/9 | Engine CRANK SHAFT FRONT |
| 03902 4028 | 91212 PE0 003 | 31 x 46 x 8 | CIVIC ZC(SOHC . 1600) EF3,5 | 87/7~92/9 | Engine CRANK SHAFT FRONT |
| 03902 6845 | 91212 PE0 003 | 31 x 46 x 8 | CIVIC ZC(1600) AT,AU | 84/10~87/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2696 | 91212 PE0 003 | 31 x 46 x 8 | CIVIC EW(1500) AH,AK,AR | 83/9~87/ | Engine CRANK SHAFT FRONT |
| 03902 5675 | 91212 PE0 003 | 31 x 46 x 8 | CIVIC EV(1300) AG,AJ,VJ | 83/9~87/ | Engine CRANK SHAFT FRONT |
| 03902 1337 | 91 212 611 003 | 35 x 50 x 8 | CIVIC EJ,EN(1300) SL,SS,VC,VE | 79/7~83/ | Engine CRANK SHAFT FRONT |
| 03902 5765 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CIVIC EK3,EJ7,EU1,3,ES1,3 | 95/9~ | Mission & Differential (HMM) FLYWHEEL CASE (2) |
| 03902 4523 | 91207 P4V 004 | 19 x 35 x 7 | CIVIC EK3,EJ7,EU1,3,ES1,3 | 95/9~ | Mission & Differential (HMM) FLYWHEEL CASE (1) |
| 03902 6152 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | CIVIC EH1,EK5 (4WD) | 91/9~00/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 8132 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CIVIC EF3,4,5,EY5,EG5,6,9,EH1 | 87/7~96/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6296 | 91212 P01 003 | 31 x 46 x 7 | CIVIC D13B,D15B,ZC(SOHC) EG3,4,5,7,8,EH1 | 91/9~95/ | Engine CRANK SHAFT FRONT |
| 03902 1598 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CIVIC EF1,2,EY2,4,EG3,4,7,8,EJ1,2,3 | 87/7~00/ | Mission & Differential (A/T) MISSION CASE |
| 03902 1859 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | CIVIC AT,AU | 84/10~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2543 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | CIVIC AK (5 DOOR) | 85/9~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 9050 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | CIVIC AH,AK (3 DOOR,4 DOOR) | 83/9~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 4433 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | CIVIC AG,AJ 4AT | 83/9~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 5864 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | CIVIC AK (5 DOOR) | 83/9~85/8 | Mission & Differential (A/T) MISSION CASE |
| 03902 6386 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | CIVIC AG,AJ 3AT | 83/9~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 4964 | 91207 P0X 003/4 | 44 x 68 x 8 | CIVIC EK#,EU#,ES# | 95/9~ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 1949 | 91 207 639 015 | 44 x 68 x 8 | CIVIC EF#,EG#,EY# | 87/7~95/ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 7619 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CIVIC EK4,5,9,EU2,4,ES2 (4WD,DOHC) | 95/9~ | Mission & Differential (A/T) MISSION CASE |
| 03902 8150 | 91214 PH1 003/13 | 80 x 100 x 10 | CIVIC D15B,D17A | 00/9~ | Engine CRANK SHAFT REAR |
| 03902 8924 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CIVIC EF SEDAN,HATCH BACK | 87/9~91/ | Wheel Hub REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4694 | 12211 PZ1 004 | | CIVIC ZC(SOHC) EXHAUST | 87/7~95/ | Engine VALVE STEM SEAL |
| 03902 8420 | 12211 PZ1 004 | | CIVIC D13B,D15B,D16A,D17A,B16#...EXHAUST | 87/7~ | Engine VALVE STEM SEAL |
| 03902 7853 | 12210 PZ1 004 | | CIVIC ZC(SOHC) INTAKE | 87/7~95/ | Engine VALVE STEM SEAL |
| 03902 7259 | 12210 PZ1 004 | | CIVIC D13B,D15B,D16A,D17A,B16#...INTAKE | 87/7~ | Engine VALVE STEM SEAL |
| 03902 7106 | 12211 PT2 003/4 | | CIVIC ZC(DOHC) EXHAUST | 87/7~95/ | Engine VALVE STEM SEAL |
| 03902 7340 | 12210 PT2 003/4 | | CIVIC ZC(DOHC) INTAKE | 87/7~95/ | Engine VALVE STEM SEAL |
| 03902 7547 | 12209 PD2 003/4 | | CIVIC EV,EW,ZC(SOHC) C VALVE | 83/9~87/ | Engine VALVE STEM SEAL |
| 03902 5513 | 12211 PA6 003/4 | | CIVIC EV,EW,ZC EXHAUST | 83/9~87/ | Engine VALVE STEM SEAL |
| 03902 5081 | 91212 PM7 003 | 31 x 46 x 8 | CIVIC B16#...EK4,9 | 95/9~ | Engine CRANK SHAFT FRONT |
| 03902 6404 | 91214 PH1 003/13 | 80 x 100 x 10 | CIVIC B16# | 89/9~00/ | Engine CRANK SHAFT REAR |
| 03902 7808 | 91212 P01 003 | 31 x 46 x 7 | CIVIC D13B,D15B,ZC(SOHC) EF2,5,EY2,4,5 | 92/10~97/ | Engine CRANK SHAFT FRONT |
| 03902 8699 | 91214 PC6 003/13 | 80 x 100 x 10 | CIVIC EV,EW,ZC,D13B,D15B,D16A | 83/9~00/8 | Engine CRANK SHAFT REAR |
| 03902 6440 | 91214 634 003/4 | 74 x 98 x 12 | CIVIC EJ,EN,EM | 79/7~83/ | Engine CRANK SHAFT REAR |
| 03902 2633 | 91213 PR3 003/4 | 39 x 43 x 8 | CIVIC B16# | 89/9~ | Engine CAM SHAFT |
| 03902 7817 | 91203 PG6 003 | 27 x 43 x 9 | CIVIC ZC(DOHC) | 84/10~95/ | Engine CAM SHAFT |
| 03902 7313 | 91213 PE1 721/2 | 29 x 45 x 8 | CIVIC D13B,D15B,D16A,D17A | 87/7~ | Engine CAM SHAFT |
| 03902 5621 | 91213 PE1 721/2 | 29 x 45 x 8 | CIVIC EV,EW,ZC(SOHC) | 83/9~95/ | Engine CAM SHAFT |
| 03902 3155 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | CIVIC B16A EF9,EG6,9 | 89/9~95/ | Engine CRANK SHAFT FRONT |
| 03902 6719 | 91212 PLC 003/4 | 38 x 50 x 7 | CIVIC D15B,D17A EU1,2,3,4,ES1,2,3 | 00/9~ | Engine CRANK SHAFT FRONT |
| 03902 9113 | 91212 P01 003 | 31 x 46 x 7 | CIVIC D13B,D15B,D16A,ZC(SOHC) EK2,3,5,8,EJ1,3,7 | 95/9~00/ | Engine CRANK SHAFT FRONT |
| 03902 7511 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CIVIC EK3,EJ7,EU1,3,ES1,3 | 95/9~ | Mission & Differential (HMM) MISSION ACSE |
| 03902 4397 | 12210 PD2 003/4 | | CIVIC EV,EW,ZC INTAKE | 83/9~87/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 7169 | 91250 SA0 003/5 | 45 x 64 x 6.5 x 19 | CIVIC SL,SS,SR,ST | 79/7~80/3 | Wheel Hub FRONT INNER |
| 03902 7394 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CIVIC EF1,2,EY2,4,EG3,4,5,6,7,8,9, EJ1 | 87/7~96/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5360 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CIVIC AG,AH,AJ,AK,VJ | 83/9~87/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2363 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | CIVIC SL,SS,SR,ST,VC,VE,WD | 79/7~83/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 9203 | 91216 PH8 003/5 | 28 x 41 x 7 | CIVIC EF9,EG6,9,EK4,9 (B16#) | 89/8~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 7592 | 91216 PH8 003/5 | 28 x 41 x 7 | CIVIC AR,EF4,5,EY5,EH1,EK5,EU 2,4,ES2 (4WD) | 84/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8492 | 91216 PL3 003/5 | 26 x 42 x 7 | CIVIC EU1,3,ES1,3 | 00/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 1796 | 91216 PL3 003/5 | 26 x 42 x 7 | CIVIC EK2,3,8 | 95/9~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8915 | 91216 PL3 003/5 | 26 x 42 x 7 | CIVIC EG3,4,5,7,8,EJ1 | 91/9~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2309 | 91216 PL3 003/5 | 26 x 42 x 7 | CIVIC EF1,2,3 | 87/7~91/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4946 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CIVIC EK2,3,4,8,9,EU1,2,3,4,ES1,2, 3 | 95/9~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 4631 | 91216 PA0 003/5 | 22 x 35 x 7 | CIVIC AG,AH,AJ,AK,VJ | 83/9~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4415 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CIVIC EG3,4,7,8,EJ3 DRUM BRAKE | 91/9~95/ | Wheel Hub REAR |
| 03902 5999 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | CIVIC EF3 | 87/7~91/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 1184 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CIVIC AT,AU | 84/10~87/ | Wheel Hub REAR |
| 03902 8825 | 91 212 611 003 | 35 x 50 x 8 | CIVIC EM(1500) SR,ST,WD | 79/7~83/ | Engine CRANK SHAFT FRONT |
| 03902 1814 | 91252 SB2 003/4 | 37 x 52 x 6 x 8 | CIVIC AG,AH,AJ,AK,VJ | 83/9~84/8 | Wheel Hub REAR |
| 03902 6926 | 91252 692 003/5 | 42 x 56.2 x 7 | CIVIC VC,VE,WD | 79/10~83/ | Wheel Hub REAR |
| 03902 7745 | 91252 692 003/5 | 42 x 56.2 x 7 | CIVIC SL,SS,SR,ST | 79/7~83/ | Wheel Hub REAR |
| 03902 4334 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | CIVIC VC,VE,WD | 79/10~83/ | Wheel Hub FRONT OUTER |
| 03902 1832 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | CIVIC SL,SS,SR,ST | 79/7~83/ | Wheel Hub FRONT OUTER |
| 03902 3857 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | CIVIC VC,VE,WD | 79/10~83/ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 8717 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | CIVIC SL,SS,SR,ST C/#1500000~ | 80/4~83/ | Wheel Hub FRONT INNER |
| 03902 3632 | 91216 PC8 003/5 | 27 x 42 x 7 | CIVIC AT,AU | 84/10~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3263 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | CIVIC AG,AJ 4AT | 83/9~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 3956 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CIVIC AG,AH,AJ,AK,VJ | 84/9~87/ | Wheel Hub REAR |
| 03902 5801 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | CIVIC AT,AU | 84/10~87/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 4973 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CIVIC EK2,3,4,8,9,EU1,2,3,4,ES1,2,3 | 95/9~ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 2921 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CIVIC EF1,2,EY2,4,EG3,4,5,6,7,8,9,EJ1,3,7 | 87/7~00/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 4937 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | CIVIC AT,AU | 84/10~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 4775 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | CIVIC AH,AK (3 DOOR,4 DOOR) | 83/9~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 8654 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | CIVIC AK(5 DOOR) | 83/9~85/8 | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 5315 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | CIVIC AG,AJ 3AT | 83/9~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 3308 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | CIVIC EU2,4,ES2 (4WD) | 00/9~ | Mission & Differential (M/T) MISSION CASE |
| 03902 1634 | 91206 PHR 003 | 35 x 58 x 8 x 11.5 | CIVIC EU1,3,ES1,3 | 00/9~ | Mission & Differential (M/T) MISSION CASE |
| 03902 5414 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | CIVIC EF3,9,EG5,6,9,EK4,9 (DOHC) | 87/10~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 6161 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | CIVIC AG,AH,AJ,AK,VJ | 83/9~87/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1490 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | CIVIC AR,EF4,5,EY5 (4WD) | 84/9~96/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2264 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | CIVIC EH1,EK5 (4WD) | 91/9~00/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7637 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | CIVIC AK(5 DOOR) | 85/9~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 2426 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | CIVIC EK2,3,8 | 95/9~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4235 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | CIVIC SL,SS,SR,ST,VC,VE,WD | 79/7~83/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 1589 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CIVIC AT,AU | 84/10~87/ | Mission & Differential (M/T) MISSION CASE |
| 03902 7403 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | CIVIC EF4,5,EY5 (4WD) | 87/7~96/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 5270 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CIVIC AR,EF4,5,EY5,EH1,EK5 (4WD) | 84/9~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3938 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | CIVIC EF1,2,EY2,4,EG3,4,7,8,EJ1 | 87/10~96/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3056 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | CIVIC EF3,9 | 87/7~91/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8744 | 91213 PE1 721/2 | 29 x 45 x 8 | CONCERTO ZC (SOHC) MA2,MA3 | 88/6~92/ | Engine CAM SHAFT |
| 03902 8195 | 12210 PZ1 004 | | CONCERTO D15B,ZC INTAKE | 88/6~92/ | Engine VALVE STEM SEAL |
| 03902 6611 | 91213 PE1 721/2 | 29 x 45 x 8 | CONCERTO D15B MA1 | 88/6~92/ | Engine CAM SHAFT |
| 03902 7232 | 91212 PE0 003 | 31 x 46 x 8 | CONCERTO ZC (SOHC) MA2,MA3 (E/#~7303754) | 88/6~92/ | Engine CRANK SHAFT FRONT |
| 03902 7250 | 91203 PG6 003 | 27 x 43 x 9 | CONCERTO ZC (DOHC) MA2,MA3 | 88/6~92/ | Engine CAM SHAFT |
| 03902 9041 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CONCERTO MA3 (4WD) | 88/6~92/ | Mission & Differential (A/T) MISSION CASE |
| 03902 3785 | 91212 PE0 003 | 31 x 46 x 8 | CONCERTO D15B MA1 (E/#~7303273) | 88/6~92/ | Engine CRANK SHAFT FRONT |
| 03902 6035 | 91212 P01 003 | 31 x 46 x 7 | CONCERTO D15B MA1(E/#7303274~) | 88/6~92/ | Engine CRANK SHAFT FRONT |
| 03902 2786 | 91212 P01 003 | 31 x 46 x 7 | CONCERTO ZC (SOHC) MA2,MA3(E/#7303755~) | 88/6~92/ | Engine CRANK SHAFT FRONT |
| 03902 5387 | 91214 PC6 003/13 | 80 x 100 x 10 | CONCERTO D15B,ZC MA# | 88/6~92/ | Engine CRANK SHAFT REAR |
| 03902 5549 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CONCERTO MA2 (PGM-FI) | 88/6~92/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2201 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CONCERTO MA1,2 (CARB.) | 88/6~92/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8348 | 12211 PZ1 004 | | CONCERTO D15B,ZC EXHAUST | 88/6~92/ | Engine VALVE STEM SEAL |
| 03902 3587 | 91212 PM7 003 | 31 x 46 x 8 | CONCERTO ZC(DOHC) MA2,MA3 | 88/6~92/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 7682 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | CONCERTO MA2 (PGM-FI) | 88/6~92/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 9176 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CONCERTO MA1,2 | 88/6~92/ | Wheel Hub REAR |
| 03902 1355 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | CONCERTO MA3 (4WD) | 88/6~92/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3128 | 91216 PH8 003/5 | 28 x 41 x 7 | CONCERTO MA3 (4WD) | 88/6~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3686 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CONCERTO MA1,2 (CARB.) | 88/6~92/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6512 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | CONCERTO MA1,2 (CARB.) | 88/6~92/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3920 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | CONCERTO MA2 (PGM-FI) | 88/6~92/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4820 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CONCERTO MA3 (4WD) | 88/6~92/ | Mission & Differential (M/T) MISSION CASE |
| 03902 8249 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CONCERTO MA1,2 (CARB.) | 88/6~92/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 4136 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | CONCERTO MA2 (PGM-FI) | 88/6~92/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 3614 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | CONCERTO MA3 94WD0 | 88/6~92/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 6638 | 91 207 639 015 | 44 x 68 x 8 | CONCERTO MA# | 88/6~92/ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 6944 | 91216 PL3 003/5 | 26 x 42 x 7 | CONCERTO MA1,2 | 88/6~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 1427 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CR-V RD# | 95/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 7160 | 91203 PG6 003 | 27 x 43 x 9 | CR-V B20B | 95/10~ | Engine CAM SHAFT |
| 03902 1661 | 12211 PT2 004 | | CR-V B20B EXHAUST | 95/10~ | Engine VALVE STEM SEAL |
| 03902 4316 | 12210 PT2 003/4 | | CR-V B20B INTAKE | 95/10~ | Engine VALVE STEM SEAL |
| 03902 3461 | 91214 PC6 003/13 | 80 x 100 x 10 | CR-V B20B | 95/10~ | Engine CRANK SHAFT REAR |
| 03902 2597 | 91207 P0X 003/4 | 44 x 68 x 8 | CR-V RD# | 95/10~ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 2534 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | CR-V B20B | 95/10~ | Engine OIL PUMP |
| 03902 4199 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CR-V RD# | 95/10~ | Mission & Differential (A/T) CONVERTER CASE (1) |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2039 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | CR-V RD# | 95/10~ | Mission & Differential (M/T) MISSION CASE |
| 03902 6458 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CR-V RD# | 95/10~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6476 | 91216 PH8 003/5 | 28 x 41 x 7 | CR-V RD# | 95/10~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3677 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | CR-X AF(4AT) | 83/6~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7583 | 91212 PE0 003 | 31 x 46 x 8 | CR-X EV,EW,ZC AE,AF,AS | 83/6~87/ | Engine CRANK SHAFT FRONT |
| 03902 5144 | 91213 PR3 003/4 | 29 x 43 x 8 | CR-X B16A EF8,EG2 | 87/7~97/ | Engine CAM SHAFT |
| 03902 7430 | 91203 PG6 003 | 27 x 43 x 9 | CR-X ZC AS,EF7 | 84/10~92/ | Engine CAM SHAFT |
| 03902 2246 | 91213 PE1 721/2 | 29 x 45 x 8 | CR-X D15B,D16A EF6,EG1,EJ4 | 87/7~97/ | Engine CAM SHAFT |
| 03902 3479 | 91213 PE1 721/2 | 29 x 45 x 8 | CR-X EV,EW AE,AF | 83/6~87/ | Engine CAM SHAFT |
| 03902 5450 | 91212 PE0 003 | 31 x 46 x 8 | CR-X D15B EF6 | 87/7~92/ | Engine CRANK SHAFT FRONT |
| 03902 6782 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | CR-X EF6,EG1,EJ4 D15B,D16A | 87/7~97/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2444 | 91214 PC6 003/13 | 80 x 100 x 10 | CR-X EV,EW,ZC AE,AF,AS | 83/6~87/ | Engine CRANK SHAFT REAR |
| 03902 4253 | 91207 P0X 003/4 | 44 x 68 x 8 | CR-X EG#,EJ$ | 95/10~97/ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 2588 | 91 207 639 015 | 44 x 68 x 8 | CR-X AE,AF,EF#,EG# | 83/6~95/10 | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 5486 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CR-X EF7,EG2 ZC,B16A | 87/7~97/ | Mission & Differential (A/T) MISSION CASE |
| 03902 5837 | 91212 P01 003 | 31 x 46 x 7 | CR-X D15B,D16A EG1,EJ4 | 92/2~97/ | Engine CRANK SHAFT FRONT |
| 03902 8078 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | CR-X EF7 ZC | 87/7~92/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 5738 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | CR-X B16A EF8,EG2 | 87/7~97/ | Engine CRANK SHAFT FRONT |
| 03902 7628 | 91205 611 003/5 | 35 x 56 x 9 x 12.5 | CR-X AE,AF(3AT) | 83/6~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2003 | 91214 PC6 003/13 | 80 x 100 x 10 | CR-X E15B,E16A,ZC EF6,7,EG1,EJ4 | 87/7~97/ | Engine CRANK SHAFT REAR |
| 03902 2372 | 91214 PC6 003/13 | 80 x 100 x 10 | CR-X B16A EF8 | 89/8~92/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4262 | 91214 PH1 003/13 | 80 x 100 x 10 | CR-X B16A EG2 | 92/2~97/ | Engine CRANK SHAFT REAR |
| 03902 5333 | 12210 PZ1 004 | | CR-X D15B,D16A,B16A INTAKE | 87/7~97/ | Engine VALVE STEM SEAL |
| 03902 6107 | 12211 PZ1 004 | | CR-X D15B,D16A,B16A EXHAUST | 87/7~97/ | Engine VALVE STEM SEAL |
| 03902 4505 | 12210 PT2 003/4 | | CR-X ZC INTAKE | 87/7~92/ | Engine VALVE STEM SEAL |
| 03902 1148 | 12211 PT2 003/4 | | CR-X ZC EXHAUST | 87/7~92/ | Engine VALVE STEM SEAL |
| 03902 6764 | 91212 PM7 003 | 31 x 46 x 8 | CR-X ZC EF7 | 87/7~92/ | Engine CRANK SHAFT FRONT |
| 03902 8582 | 91216 PL3 003/5 | 26 x 42 x 7 | CR-X EF6,7 D15B,ZC | 87/7~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8042 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CR-X AS | 84/10~87/ | Wheel Hub REAR |
| 03902 8645 | 91252 B2 003/4 | 37 x 52 x 6 x 8 | CR-X AE,AF | 83/6~84/8 | Wheel Hub REAR |
| 03902 5396 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CR-X AE,AF C/#1100001~ | 84/9~87/ | Wheel Hub REAR |
| 03902 6791 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CR-X EF | 87/7~92/ | Wheel Hub REAR |
| 03902 6206 | 91252 SB2 013 | 40 x 55 x 6 x 8 | CR-X EG DRUM BRAKE | 92/2~95/ | Wheel Hub REAR |
| 03902 6773 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | CR-X AS | 84/10~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 1454 | 91216 PC8 003/5 | 27 x 42 x 7 | CR-X AS | 84/10~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4685 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CR-X EF6,EG1,2,EJ4 .D15B,D16A ,B16A | 87/7~97/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 6548 | 91216 PL3 003/5 | 26 x 42 x 7 | CR-X EG1,EJ4 D15B,D16A | 92/2~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3497 | 91216 PH8 003/5 | 28 x 41 x 7 | CR-X EF8 B16A | 87/7~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 5540 | 91216 PH8 003/5 | 28 x 41 x 7 | CR-X EG2 B16A | 92/2~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6998 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CR-X AE,AF | 83/6~87/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8726 | 91206 611 003/5 | 35 x 68 x 9 x 12.5 | CR-X AE,AF(3AT) | 83/6~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 7115 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CR-X EG1,2,EJ4 D15B,D16A,B16A | 92/2~97/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 1958 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | CR-X AS | 84/10~87/ | Mission & Differential (M/T) CLUTCH CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4190 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | CR-X EF7,8 ZC,B16A | 87/7~92/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6620 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | CR-X AE,AF | 83/6~87/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2759 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | CR-X AS | 84/10~87/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4487 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | CR-X EF6,EG1,EJ4 D15B,D16A | 87/7~97/ | Mission & Differential (M/T) MISSION CASE |
| 03902 8573 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | CR-X EF7,8,EG2 ZC,B16A | 87/7~97/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4460 | 91216 PA0 003/5 | 22 x 35 x 7 | CR-X AE,AF | 83/6~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4883 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | CR-X AF(4AT) | 83/6~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 4676 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | CR-X EF6 D15B | 87/7~92/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5774 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | CR-X AS | 84/10~87/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 1526 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | DOMANI MA4,7 | 92/11~97/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3398 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | DOMANI MA5 (B18B) | 92/11~97/ | Mission & Differential (M/T) MISSION CASE |
| 03902 7502 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | DOMANI MA6,MB5 (4WD) | 92/11~00/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3848 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | DOMANI MA4,5,7 | 92/11~97/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 8114 | 91252 SB2 013 | 40 x 55 x 6 x 8 | DOMANI MA4,5,7 DRUM BRAKE | 92/11~97/ | Wheel Hub REAR |
| 03902 4865 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | DOMANI MA6,MB5 (4WD) | 92/11~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1508 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | DOMANI MB3,4 | 97/1~00/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3830 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | DOMANI MA4,5,7 | 92/11~97/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 1688 | 91216 PH8 003/5 | 28 x 41 x 7 | DOMANI MB5 (4WD) | 97/1~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4064 | 91216 PH8 003/5 | 28 x 41 x 7 | DOMANI MA5 (B18B),MA6 (4WD) | 92/11~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8555 | 91216 PL3 003/5 | 26 x 42 x 7 | DOMANI MA4,7 | 92/11~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 1562 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | DOMANI MA6,MB5 (4WD) | 92/11~00/ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4667 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | DOMANI MB3,4 | 97/1~00/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 5252 | 91216 PL3 003/5 | 26 x 42 x 7 | DOMANI MB3,4 | 97/1~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8060 | 91212 P01 003 | 31 x 46 x 7 | DOMANI ZC,D15B,D16A | 92/11~00/ | Engine CRANK SHAFT FRONT |
| 03902 4172 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | DOMANI MA6,MB5 (4WD) | 92/11~00/ | Mission & Differential (A/T) CONVERTER CASE (1) |
| 03902 3749 | 12211 PZ1 004 | | DOMANI ZC,D15B,D16A EXHAUST | 92/11~00/ | Engine VALVE STEM SEAL |
| 03902 2606 | 12210 PZ1 004 | | DOMANI ZC,D15B,D16A INTAKE | 92/11~00/ | Engine VALVE STEM SEAL |
| 03902 8618 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | DOMANI B18B | 92/11~97/ | Engine CRANK SHAFT FRONT |
| 03902 2966 | 91203 PG6 003 | 27 x 43 x 9 | DOMANI B18B MA5 | 92/11~97/ | Engine CAM SHAFT |
| 03902 1751 | 91213 PE1 721/2 | 29 x 45 x 8 | DOMANI D16A MB4,5 | 97/1~00/ | Engine CAM SHAFT |
| 03902 2732 | 91213 PE1 721/2 | 29 x 45 x 8 | DOMANI D15B MA7,MB3 | 94/2~00/ | Engine CAM SHAFT |
| 03902 4766 | 91213 PE1 721/2 | 29 x 45 x 8 | DOMANI ZC MA4,6 | 92/11~97/ | Engine CAM SHAFT |
| 03902 4370 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | DOMANI MA4,7 | 92/11~97/ | Mission & Differential (A/T) MISSION CASE |
| 03902 5036 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | DOMANI MB3,4 | 97/1~00/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7610 | 91207 P0X 003/4 | 44 x 68 x 8 | DOMANI MB# | 97/1~00/ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 3317 | 91 207 639 015 | 44 x 68 x 8 | DOMANI MA# | 92/11~97/ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 2831 | 91214 PC6 003/13 | 80 x 100 x 10 | DOMANI ZC,D15B,D16A,B18B | 92/11~00/ | Engine CRANK SHAFT REAR |
| 03902 6566 | 91216 PH8 003/5 | 28 x 41 x 7 | HR-V GH1,2,3,4 | 98/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2822 | 91212 PLC 003/4 | 38 x 50 x 7 | HR-V D16A GH1,2,3,4 (E/#9018922~) | 99/7~ | Engine CRANK SHAFT FRONT |
| 03902 3299 | 12211 PZ1 004 | | HR-V D16A EXHAUST | 98/9~ | Engine VALVE STEM SEAL |
| 03902 3290 | 12210 PZ1 004 | | HR-V D16A INTAKE | 98/9~ | Engine VALVE STEM SEAL |
| 03902 6134 | 91214 PH1 003/13 | 80 x 100 x 10 | HR-V D16A GH1,2,3,4 | 01/6~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 3326 | 91214 PC6 003/13 | 80 x 100 x 10 | HR-V D16A GH1,2,3,4 | 98/9~01/6 | Engine CRANK SHAFT REAR |
| 03902 5135 | 91212 P01 003 | 31 x 46 x 7 | HR-V D16A GH1,2,3,4 (E/#~9018921) | 98/9~99/7 | Engine CRANK SHAFT FRONT |
| 03902 4244 | 91213 PE1 721/2 | 29 x 45 x 8 | HR-V D16A GH1,2,3,4 | 98/9~ | Engine CAM SHAFT |
| 03902 8339 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | HR-V GH1,2,3,4 | 98/9~ | Mission & Differential (A/T) MISSION CASE |
| 03902 2498 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | HR-V GH1,2,3,4 | 98/9~ | Mission & Differential (A/T) FLYWHEEL CASE |
| 03902 6332 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | HR-V GH1,2,3,4 | 98/9~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5306 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | HR-V GH1,2,3,4 | 98/9~ | Mission & Differential (M/T) MISSION CASE |
| 03902 6062 | 91205 PZ5 003/4 | 35 x 62 x 9 x 12.5 | INSIGHT ZE1 | 99/11~ | Mission & Differential (A/T) FLYWHEEL CASE |
| 03902 8483 | 12210 PZ1 004 | | INSIGHT ECA1 INTAKE | 99/11~ | Engine VALVE STEM SEAL |
| 03902 4361 | 91214 PHM 003 | 65 x 88 x 9 | INSIGHT ECA1 ZE1 | 99/11~ | Engine CRANK SHAFT REAR |
| 03902 3524 | 12211 PZ1 004 | | INSIGHT ECA1 EXHAUST | 99/11~ | Engine VALVE STEM SEAL |
| 03902 7754 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INSIGHT ZE1 | 99/11~ | Mission & Differential (M/T) MISSION CASE |
| 03902 2336 | 91206 PHR 003 | 35 x 58 x 8 x 11.5 | INSIGHT ZE1 | 99/11~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 4892 | 91216 PHR 003 | 26 x 40 x 7 | INSIGHT ZE1 | 99/11~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 7052 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INSIGHT ZE1 | 99/11~ | Mission & Differential (A/T) MISSION CASE |
| 03902 4118 | 91202 PHM 003 | 40 x 55 x 7 | INSIGHT ECA1 ZE1 | 99/11~ | Engine CRANK SHAFT FRONT |
| 03902 9158 | 91214 PC6 003/13 | 80 x 100 x 10 | INSPIRE, SABER G20A,G25A CC2,3,UA1,2 | 92/1~98/ | Engine CRANK SHAFT REAR |
| 03902 6422 | 91205 PY5 003 | 44.5 x 61 x 8 x 10 | INSPIRE, SABER UA3 | 95/7~98/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7439 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | INSPIRE, SABER UA4,5 | 98/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 6188 | 91213 PR3 003/4 | 29 x 43 x 8 | INSPIRE, SABER G20A,G25A CC2,3,UA1,2 | 92/1~98/ | Engine CAM SHAFT |
| 03902 1229 | 91213 PY3 003 | 35 x 50 x 9.5 | INSPIRE, SABER G32A UA3 | 95/7~98/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4307 | 12211 PZ1 004 | | INSPIRE, SABER G20A,G25A,G32A EXHAUST | 92/1~98/ | Engine VALVE STEM SEAL |
| 03902 5378 | 91212 P8A A01 | 41.5 x 56 x 8 | INSPIRE, SABER J25A,J32A UA4,5 | 98/10~ | Engine CRANK SHAFT FRONT |
| 03902 7196 | 91207 PR9 003 | 46 x 70 x 8 | INSPIRE, SABER UA3 | 95/7~98/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 5954 | 91214 PL2 004 | 80 x 98 x 10 | INSPIRE, SABER G32A UA3 | 95/7~98/ | Engine CRANK SHAFT REAR |
| 03902 5423 | 91214 P8A A01 | 80 x 98 x 10 | INSPIRE, SABER J25A,J32A UA4,5 | 98/10~ | Engine CRANK SHAFT REAR |
| 03902 7997 | 12210 PZ1 004 | | INSPIRE, SABER G20A,G25A,G32A INTAKE | 92/1~98/ | Engine VALVE STEM SEAL |
| 03902 7880 | 91212 PT0 003 | 40 x 52 x 7 | INSPIRE, SABER G20A,G25A CC2,3,UA1,2 | 92/1~98/ | Engine CRANK SHAFT FRONT |
| 03902 7214 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | INSPIRE, SABER UA1,2 | 95/2~98/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7268 | 91207 P7Z 003 | 44 x 68 x 8 | INSPIRE, SABER UA4,5 | 98/10~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 5234 | 91207 P0X 003/4 | 44 x 68 x 8 | INSPIRE, SABER UA1,2 | 95/2~98/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 3641 | 91 207 639 015 | 44 x 68 x 8 | INSPIRE, SABER CC2,3 | 92/1~95/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 6377 | 91206 P0Z 005 | 35 x 54 x 8 x 11.5 | INSPIRE, SABER UA4,5 | 98/10~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 3074 | 91201 PY5 003 | 55 x 75 x 11 | INSPIRE, SABER UA3 | 95/7~98/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 6521 | 91201 PW5 015 | 50 x 70 x 11 | INSPIRE, SABER UA1,2 | 95/2~98/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 1643 | 91201 PW5 015 | 50 x 70 x 11 | INSPIRE, SABER CC2,3 | 92/1~95/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2066 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | INSPIRE, SABER CC2,3 | 92/1~95/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3884 | 91201 PW5 015 | 50 x 70 x 11 | INSPIRE, SABER CC2,3 | 92/1~95/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6008 | 91216 PH8 003/5 | 28 x 41 x 7 | INSPIRE, SABER CC2,3 | 92/1~95/ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2660 | 91213 P8A A01 | 39.5 x 53 x 8 | INSPIRE, SABER J25A,J32A UA4,5 | 98/10~ | Engine CAM SHAFT |
| 03902 8807 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | INSPIRE, SABER CC2,3 | 92/1~95/ | Mission & Differential (A/T) MISSION CASE |
| 03902 3245 | 91212 PY3 003 | 41 x 56 x 8 | INSPIRE, SABER G32A UA3 | 95/7~98/ | Engine CRANK SHAFT FRONT |
| 03902 1679 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | INTEGRA AV,DA1 PGM-FI | 87/5~89/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5711 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | INTEGRA DB9 (4WD) | 93/7~00/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2111 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA EK3 | 96/2~99/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 8051 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA DB6,7,8,DC1,2 | 93/5~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 8501 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA DA5,7 CARB. | 89/4~93/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5000 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | INTEGRA DB1 B18B | 91/10~93/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5099 | 91212 PE0 003 | 31 x 46 x 8 | INTEGRA ZC (DOHC) AV,DA1 | 85/1~87/9 | Engine CRANK SHAFT FRONT |
| 03902 6269 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | INTEGRA DA5,7 PGM-FI | 84/9~93/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 3911 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | INTEGRA AV,DA1,2 CARB. | 85/1~89/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7322 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | INTEGRA AV,DA1 PGM-FI | 85/1~87/4 | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 1112 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | INTEGRA AV,DA1,2 CARB. | 85/1~89/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5324 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | INTEGRA DB7,8,DC2 B18# | 93/4~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 7079 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | INTEGRA DA6,8 B16A | 89/4~93/ | Mission & Differential (M/T) MISSION CASE |
| 03902 8303 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | INTEGRA DA5,7 PGM-FI | 89/4~93/ | Mission & Differential (M/T) MISSION CASE |
| 03902 6251 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | INTEGRA DA6,8 B16A | 89/4~93/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 6818 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | INTEGRA DA5,7 CARB. | 89/4~93/ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 5468 | 91 212 611 003 | 35 x 50 x 8 | INTEGRA EP SU | 80/2~85/ | Engine CRANK SHAFT FRONT |
| 03902 9023 | 91213 PR3 003/4 | 29 x 43 x 8 | INTEGRA B16A,B18C DA6,8,DB8,DC2 | 89/4~00/ | Engine CAM SHAFT |
| 03902 5504 | 91213 PE1 721/2 | 29 x 45 x 8 | INTEGRA ZC (SOHC) DA5,7,DB6,9,DC1 | 89/4~ | Engine CAM SHAFT |
| 03902 3452 | 91203 PG6 003 | 27 x 43 x 9 | INTEGRA B18B DB1,7 | 91/10~95/ | Engine CAM SHAFT |
| 03902 3101 | 91203 PG6 003 | 27 x 43 x 9 | INTEGRA ZC (DOHC) AV,DA1 | 85/1~89/ | Engine CAM SHAFT |
| 03902 3776 | 91 207 639 015 | 44 x 68 x 8 | INTEGRA AV,DA#,DB#,DC# | 85/1~95/9 | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 5216 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | INTEGRA DB6,DC1 ZC | 93/5~ | Mission & Differential (A/T) MISSION CASE |
| 03902 5684 | 91207 P0X 003/4 | 44 x 68 x 8 | INTEGRA DB#,DC# | 95/9~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4046 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | INTEGRA DB1,7,8,9,DC2 | 91/10~00/ | Mission & Differential (A/T) MISSION CASE |
| 03902 4928 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | INTEGRA DA6,8 B16A | 89/4~93/ | Mission & Differential (A/T) MISSION CASE |
| 03902 5261 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | INTEGRA DA5,7 PGM-FI | 89/4~93/ | Mission & Differential (A/T) MISSION CASE |
| 03902 1841 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | INTEGRA AV,DA1 PGM-FI | 87/5~89/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2795 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | INTEGRA AV,DA1 PGM-FI | 85/1~87/4 | Mission & Differential (A/T) MISSION CASE |
| 03902 1301 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | INTEGRA DA5,7 CARB. | 89/4~93/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3380 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | INTEGRA EK3 | 96/2~99/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2678 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | INTEGRA SU | 80/2~85/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6314 | 91250 SA0 003/5 | 45 x 64 x 6.5 x 19 | INTEGRA SU | 80/2~81/8 | Wheel Hub FRONT INNER |
| 03902 6197 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | INTEGRA SU | 81/9~85/ | Wheel Hub FRONT INNER |
| 03902 5891 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | INTEGRA SU | 80/2~85/ | Wheel Hub FRONT OUTER |
| 03902 5018 | 91252 692 003/5 | 42 x 56.2 x 7 | INTEGRA SU | 80/2~85/ | Wheel Hub REAR |
| 03902 4910 | 91252 SB2 013 | 40 x 55 x 6 x 8 | INTEGRA AV | 85/1~89/ | Wheel Hub REAR |
| 03902 2570 | 91252 SB2 013 | 40 x 55 x 6 x 8 | INTEGRA DA1 5 DOOR | 85/10~89/ | Wheel Hub REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 8708 | 91252 SB2 013 | 40 x 55 x 6 x 8 | INTEGRA DA5,6,7,8 | 89/4~93/ | Wheel Hub REAR |
| 03902 6233 | 91252 SB2 013 | 40 x 55 x 6 x 8 | INTEGRA DC1 DRUM BRAKE | 93/5~95/9 | Wheel Hub REAR |
| 03902 8258 | 91216 689 003/5 | 25 x 40 x 7 | INTEGRA SU | 80/2~85/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6494 | 91216 PA0 003/5 | 22 x 35 x 7 | INTEGRA AV,DA1,2 CARB. | 85/1~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4019 | 91216 PC8 003/5 | 27 x 42 x 7 | INTEGRA AV,DA1 PGM-R | 85/1~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 5594 | 91216 PL3 003/5 | 26 x 42 x 7 | INTEGRA DA5,7,DB6,DC1 ZC | 89/4~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4541 | 91216 PL3 003/5 | 26 x 42 x 7 | INTEGRA EK3 D15B | 96/2~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8006 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | INTEGRA EK3 | 96/2~99/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1265 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | INTEGRA DA5,7 PGM-FI | 89/4~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6647 | 91213 PE1 721/2 | 29 x 45 x 8 | INTEGRA D15B EK3 | 96/2~99/ | Engine CAM SHAFT |
| 03902 9014 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | INTEGRA DB9 (4WD) | 93/7~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 5288 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | INTEGRA AV,DA1 PGM-FI | 85/1~89/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3182 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | INTEGRA AV,DA1,2 CARB. | 85/1~89/ | Mission & Differential (M/T) MISSION CASE |
| 03902 5882 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | INTEGRA SU | 80/2~85/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4055 | 91216 PH8 003/5 | 28 x 41 x 7 | INTEGRA DA6,8,DB7,8,DC2 B16A,B18# | 89/4~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2489 | 91205 PL3 B01/2 | 40 x 56 x 8 x 11.5 | INTEGRA DA6,8 B16A | 89/4~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3704 | 91216 PH8 003/5 | 28 x 41 x 7 | INTEGRA DB9 (4WD) | 93/7~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6323 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA EK3 | 96/2~99/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3569 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA DB6,7,8,DC1,2 | 93/5~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7151 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA DA5,7 CARB. | 89/4~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5189 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | INTEGRA DA2 EW | 85/1~89/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3002 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | INTEGRA AV,DA1 ZC | 85/1~89/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 4703 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | INTEGRA DB6,DC1 ZC | 93/5~ | Mission & Differential (M/T) MISSION CASE |
| 03902 6350 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | INTEGRA DB9 (4WD) | 93/7~00/ | Mission & Differential (M/T) CLUTCH CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 7709 | 91214 PH1 003/13 | 80 x 100 x 10 | INTEGRA B18B DB1,7 | 91/10~95/ | Engine CRANK SHAFT REAR |
| 03902 8123 | 91212 PE0 003 | 31 x 46 x 8 | INTEGRA EW DA2 | 86/2~89/ | Engine CRANK SHAFT FRONT |
| 03902 1220 | 91213 PE1 721/2 | 29 x 45 x 8 | INTEGRA EW DA2 | 86/2~89/ | Engine CAM SHAFT |
| 03902 1571 | 12210 PZ1 004 | | INTEGRA ZC (SOHC),D15B,B18#...IN. | 93/5~ | Engine VALVE STEM SEAL |
| 03902 1193 | 91214 PH1 003/13 | 80 x 100 x 10 | INTEGRA B16A,B18C DA6,8,DB8,DC2 | 89/4~ | Engine CRANK SHAFT REAR |
| 03902 8510 | 91214 PC6 003/13 | 80 x 100 x 10 | INTEGRA D15B EK3 | 96/2~99/ | Engine CRANK SHAFT REAR |
| 03902 1310 | 91214 PC6 003/13 | 80 x 100 x 10 | INTEGRA EW,ZC DA1,2,5,7,DB6,9,DC1 | 86/2~ | Engine CRANK SHAFT REAR |
| 03902 1976 | 91214 PB2 003 | 76 x 98 x 12 | INTEGRA EP SU | 80/2~85/ | Engine CRANK SHAFT REAR |
| 03902 7295 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | INTEGRA B18B DB1,7 | 91/10~95/ | Engine CRANK SHAFT FRONT |
| 03902 6431 | 91212 PM7 003 | 31 x 46 x 8 | INTEGRA ZC (DOHC) AV,DA1 | 87/10~89/ | Engine CRANK SHAFT FRONT |
| 03902 8519 | 91212 P01 003 | 31 x 46 x 7 | INTEGRA D15B EK3 | 96/2~99/ | Engine CRANK SHAFT FRONT |
| 03902 6395 | 91212 PE0 003 | 31 x 46 x 8 | INTEGRA ZC (SOHC) DA5,7 (C/#~1200000) | 89/4~91/9 | Engine CRANK SHAFT FRONT |
| 03902 4154 | 91212 P01 003 | 31 x 46 x 7 | INTEGRA ZC (SOHC) DB6,9,DC1 | 93/5~ | Engine CRANK SHAFT FRONT |
| 03902 8096 | 91212 P01 003 | 31 x 46 x 7 | INTEGRA ZC (SOHC) DA5,7 (C/#1200001~) | 91/10~93/ | Engine CRANK SHAFT FRONT |
| 03902 6044 | 12211 PZ1 004 | | INTEGRA ZC 9SOHC),D15B,B18#...EX. | 93/5~ | Engine VALVE STEM SEAL |
| 03902 5720 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | INTEGRA B16A,B18C DA6,8,DB8,DC2 | 89/4~ | Engine CRANK SHAFT FRONT |
| 03902 7034 | 91213 P8A A01 | 39.5 x 53 x 8 | LAGREAT J35A RL1 | 99/6~ | Engine CAM SHAFT |
| 03902 8456 | 12211 PZ1 004 | | LAGREAT J35A EXHAUST | 99/6~ | Engine VALVE STEM SEAL |
| 03902 6224 | 12210 PZ1 004 | | LAGREAT J35A INTAKE | 99/6~ | Engine VALVE STEM SEAL |
| 03902 3668 | 91212 P8A A01 | 41.5 x 56 x 8 | LAGREAT J35A RL1 | 99/6~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2174 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | LAGREAT RL1 | 99/6~ | Mission & Differential (A/T) MISSION CASE |
| 03902 1580 | 91207 P7Z 003 | 44 x 68 x 8 | LAGREAT RL1 | 99/6~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 7349 | 91206 P0Z 005 | 35 x 54 x 8 x 11.5 | LAGREAT RL1 | 99/6~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 3605 | 91214 P8A A01 | 80 x 98 x 10 | LAGREAT J35A RL1 | 99/6~ | Engine CRANK SHAFT REAR |
| 03902 5666 | 91214 PH7 013 | 80 x 98 x 10 | LEGEND C20A,C25A,C27A KA1,2,3,4,5,6 | 85/10~91/ | Engine CRANK SHAFT REAR |
| 03902 8240 | 12210 PZ1 004 | | LEGEND C32A,C35A INTAKE | 90/10~ | Engine VALVE STEM SEAL |
| 03902 4100 | 12211PZ1 004 | | LEGEND C32A,C35A EXHAUST | 90/10~ | Engine VALVE STEM SEAL |
| 03902 1121 | 12211 PT2 003/4 | | LEGEND C20A,C25A,C27A EXHAUST | 85/10~91/ | Engine VALVE STEM SEAL |
| 03902 8879 | 12210 PD2 003/4 | | LEGEND C20A,C25A,C27A INTAKE | 85/10~91/ | Engine VALVE STEM SEAL |
| 03902 9149 | 91214 PL2 004 | 80 x 98 x 10 | LEGEND C32A,C35A KA7,8,9 | 90/10~ | Engine CRANK SHAFT REAR |
| 03902 8987 | 91216 PG1 003/5 | 28 x 43 x 7 | LEGEND KA# | 85/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6863 | 91212 PY3 003 | 41 x 56 x 8 | LEGEND C32A,C35A KA7,8,9 | 90/10~ | Engine CRANK SHAFT FRONT |
| 03902 4343 | 91 207 639 015 | 44 x 68 x 8 | LEGEND KA1,2,3,4,5,6 | 85/10~91/ | Mission & Differential (A/T) CPNVERTER CASE (B) |
| 03902 2165 | 91201 PY5 003/5 | 55 x 75 x 11 | LEGEND KA7,8,9 | 90/10~ | Mission & Differential (A/T) CPNVERTER CASE (A) |
| 03902 5828 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | LEGEND KA1,2,3,4,5,6 | 85/10~91/ | Mission & Differential (A/T) CPNVERTER CASE (A) |
| 03902 8528 | 91201 P6B 003 | 40 x 56 x 9 x 12.5 | LEGEND KA# | 85/10~90/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 6287 | 91207 PR9 003 | 46 x 70 x 8 | LEGEND KA,7,8,9 | 90/10~ | Mission & Differential (A/T) CPNVERTER CASE (B) |
| 03902 2408 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | LEGEND KA1,2,3,4,5,6 | 85/10~91/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2273 | 91205 PY5 003/5 | 44.5 x 61 x 8 x 10 | LEGEND KA,7,8,9 | 90/10~ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4640 | 91213 PH7 004 | 35 x 50 x 8 | LEGEND C20A,C25A,C27A KA1,2,3,4,5,6 | 85/10~91/ | Engine CAM SHAFT |
| 03902 1175 | 91213 PY3 003/4 | 35 x 50 x 9.5 | LEGEND C32A,C35A KA7,8,9 | 90/10~ | Engine CAM SHAFT |
| 03902 4478 | 91212 PH7 013 | 41 x 56 x 8 | LEGEND C20A,C25A,C27A KA1,2,3,4,5,6 | 85/10~91/ | Engine CRANK SHAFT FRONT |
| 03902 6755 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | LEGEND KA# | 85/10~90/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2642 | 12210 PZ1 004 | | LIFE, LIFE DUNK E07#...INTAKE | 97/5~ | Engine VALVE STEM SEAL |
| 03902 2993 | 91214 PFB 003 | 65 x 88 x 10 | LIFE, LIFE DUNK E07Z JB1,2,3,4 | 98/10~ | Engine CRANK SHAFT REAR |
| 03902 3740 | 91252 SD5 003 | 36 x 53 x 6 | LIFE, LIFE DUNK JA4 | 97/5~98/ | Wheel Hub REAR |
| 03902 7700 | 12211 PZ1 004 | | LIFE, LIFE DUNK E07#...EXHAUST | 97/5~ | Engine VALVE STEM SEAL |
| 03902 5657 | 91212 PN4 003 | 30 x 42 x 7 | LIFE, LIFE DUNK E07#...JA4,JB1,2,3,4 | 97/5~ | Engine CRANK SHAFT FRONT |
| 03902 2867 | 91203 PG6 003 | 27 x 43 x 9 | LIFE, LIFE DUNK E07#...JA4,JB1,2,3,4 | 97/5~ | Engine CAM SHAFT |
| 03902 3209 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | LIFE, LIFE DUNK JB3,4 | 00/12~ | Mission & Differential (A/T) MISSION CASE |
| 03902 3659 | 91205 PL6 003/5 | 35 x 58 x 9 x 13.5 | LIFE, LIFE DUNK JB1,2 | 98/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 5576 | 91216 PZ6 005 | 22 x 36 x 7 | LIFE, LIFE DUNK JA4,JB1,2 | 97/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6242 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | LIFE, LIFE DUNK JA4,JB1,2 | 97/5~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3254 | 91205 PL6 003/5 | 35 x 58 x 9 x 13.5 | LIFE, LIFE DUNK JA4,JB1,2 | 97/5~ | Mission & Differential (M/T) MISSION CASE |
| 03902 4586 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | LIFE, LIFE DUNK JA4,JB1,2,3,4 | 97/5~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5990 | 91207 P0X 003/4 | 44 x 68 x 8 | LIFE, LIFE DUNK JA4,JB1,2,3,4 | 97/5~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 6053 | 91 214 679 024 | 65 x 88 x 12 | LIFE, LIFE DUNK E07A JA4 | 97/5~98/ | Engine CRANK SHAFT REAR |
| 03902 8177 | 91205 PZ5 003/4 | 35 x 62 x 9 x 12.5 | LIFE, LIFE DUNK JA4 | 97/5~98/ | Mission & Differential (A/T) MISSION CASE |
| 03902 8789 | 91213 PE1 721/2 | 29 x 45 x 8 | LOGO D13B GA3,5 | 96/10~01/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 6089 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | LOGO GA3,5 HMM | 96/10~01/ | Mission & Differential (A/T) FLYWHEEL CASE |
| 03902 4424 | 12211 PZ1 004 | | LOGO D13B EXHAUST | 96/10~01/ | Engine VALVE STEM SEAL |
| 03902 7493 | 12210 PZ1 004 | | LOGO D13B INTAKE | 96/10~01/ | Engine VALVE STEM SEAL |
| 03902 1463 | 91216 PL3 003/5 | 26 x 42 x 7 | LOGO GA3 | 96/10~01/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4955 | 91212 PLC 003/4 | 38 x 50 x 7 | LOGO D13B GA3,5 (E/#6305803~) | 00/~01/ | Engine CRANK SHAFT FRONT |
| 03902 3173 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | LOGO GA5 HMM | 98/11~01/ | Mission & Differential (A/T) MISSION CASE |
| 03902 3794 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | LOGO GA3 | 96/10~01/ | Mission & Differential (A/T) MISSION CASE |
| 03902 7556 | 91207 P0X 003/4 | 44 x 68 x 8 | LOGO GA3 | 96/10~01/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 3758 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | LOGO GA3 | 96/10~01/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 7781 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | LOGO GA3 | 96/10~01/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1409 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | LOGO GA3 | 96/10~01/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7007 | 91214 PC6 003/13 | 80 x 100 x 10 | LOGO D13B GA3,5 | 96/10~01/ | Engine CRANK SHAFT REAR |
| 03902 4469 | 91212 P01 003 | 31 x 46 x 7 | LOGO D13B GA3,5 (E/#~6305802) | 96/10~00/ | Engine CRANK SHAFT FRONT |
| 03902 7772 | 91214 PL2 003/4 | 80 x 98 x 10 | NSX NA1,NA2 C30A,C32B | 90/8~ | Engine CRANK SHAFT REAR |
| 03902 7844 | 91255 SL0 000 | 81.2 x 89.3 x 1.6 | NSX NA1,NA2 | 90/8~ | Wheel Hub REAR BEARING INNER |
| 03902 1274 | 12210 PZ1 004 | | NSX C30A,C32B INTAKE | 90/8~ | Engine VALVE STEM SEAL |
| 03902 1823 | 91212 PR7 A01 | 42 x 56 x 7 x 8 | NSX NA1,NA2 C30A,C32B | 90/8~ | Engine CRANK SHAFT FRONT |
| 03902 8312 | 91213 PR7 A01 | 29 x 43 x 8 | NSX NA1,NA2 C30A,C32B | 90/8~ | Engine CAM SHAFT |
| 03902 3992 | 91207 PR8 005 | 42 x 63 x 9 x 12.5 | NSX NA1 | 90/8~ | Mission & Differential (A/T) MISSION CASE |
| 03902 7907 | 91207 PR9 003 | 46 x 70 x 8 | NSX NA1 | 90/8~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 1319 | 91206 PR8 005 | 40 x 68 x 9 x 12 | NSX NA1 | 90/8~ | Mission & Differential (A/T) CONVERTER CASE (A) |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 9131 | 91207 PR8 005 | 42 x 63 x 9 x 12.5 | NSX NA1,NA2 | 90/8~ | Mission & Differential (M/T) MISSION CASE |
| 03902 2453 | 91206 PR8 005 | 40 x 68 x 9 x 12 | NSX NA1,NA2 | 90/8~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3515 | 91216 PR8 005 | 32 x 46 x 7 | NSX NA1,NA2 | 90/8~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3929 | 12211 PZ1 004 | | NSX C30A,C32B EXHAUST | 90/8~ | Engine VALVE STEM SEAL |
| 03902 3875 | 91206 P0Z 005 | 35 x 54 x 8 x 11.5 | ODYSSEY RA5,8,9 | 97/10~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 9095 | 12211 PZ1 004 | | ODYSSEY F22B,F23A,J30A EXHAUST | 94/9~ | Engine VALVE STEM SEAL |
| 03902 8753 | 12210 PZ1 004 | | ODYSSEY F22B,F23A,J30A INTAKE | 94/9~ | Engine VALVE STEM SEAL |
| 03902 6170 | 91214 P8A A01 | 80 x 98 x 10 | ODYSSEY J30A RA5,8,9 | 97/10~ | Engine CRANK SHAFT REAR |
| 03902 7988 | 91214 PC6 003/13 | 80 x 100 x 10 | ODYSSEY F22B,F23A RA1,2,3,4,6,7 | 94/9~ | Engine CRANK SHAFT REAR |
| 03902 8996 | 91212 P8A A01 | 41.5 x 56 x 8 | ODYSSEY J30A RA5,8,9 | 97/10~ | Engine CRANK SHAFT FRONT |
| 03902 7286 | 91212 PT0 003 | 40 x 52 x 7 | ODYSSEY F22B,F23A RA1,2,3,4,6,7 | 94/9~ | Engine CRANK SHAFT FRONT |
| 03902 4874 | 91233 PT0 003 | 27 x 40 x 8 | ODYSSEY F22B,F23A RA1,2,3,4,6,7 | 94/9~ | Engine OIL PUMP |
| 03902 8474 | 91213 P8A A01 | 39.5 x 53 x 8 | ODYSSEY J30A RA5,8,9 | 97/10~ | Engine CAM SHAFT |
| 03902 9248 | 91213 PT0 003/4 | 28 x 42 x 8 | ODYSSEY F22B,F23A RA1,2,3,4,6,7 | 94/9~ | Engine CAM SHAFT |
| 03902 1760 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | ODYSSEY RA5,8,9 | 97/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 5063 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | ODYSSEY RA1,2,3,4,6,7 | 94/9~ | Mission & Differential (A/T) MISSION CASE |
| 03902 4730 | 91207 P0X 003/4 | 44 x 68 x 8 | ODYSSEY RA1,2,3,4,6,7 | 94/9~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 5432 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ODYSSEY RA2,3,4,6,7 | 94/9~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 9122 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | ODYSSEY RA1 | 94/9~97/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 6890 | 91207 P7Z 003 | 44 x 68 x 8 | ODYSSEY RA5,8,9 | 97/10~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 7952 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | ORTHIA EL1 | 96/5~02/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2507 | 12211 PT2 003/4 | | ORTHIA B18B,B20B EXHAUST | 96/5~02/ | Engine VALVE STEM SEAL |
| 03902 2723 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ORTHIA EL1,2,3 | 96/5~02/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 7304 | 91207 P0X 003/4 | 44 x 68 x 8 | ORTHIA EL1,2,3 | 96/5~02/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 6899 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | ORTHIA EL1,2,3 | 96/5~02/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6980 | 91203 PG6 003 | 27 x 43 x 9 | ORTHIA B18B,B20B EL1,2,3 | 96/5~02/ | Engine CAM SHAFT |
| 03902 8852 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | ORTHIA B18B,B20B EL1,2,3 | 96/5~02/ | Engine CRANK SHAFT FRONT |
| 03902 5648 | 91214 PC6 003/13 | 80 x 100 x 10 | ORTHIA B18B,B20B EL1,2,3 | 96/5~02/ | Engine CRANK SHAFT REAR |
| 03902 6215 | 12210 PT2 003/4 | | ORTHIA B18B,B20B INTAKE | 96/5~02/ | Engine VALVE STEM SEAL |
| 03902 7691 | 91216 PH8 003/5 | 28 x 41 x 7 | ORTHIA EL1 | 96/5~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 2741 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | ORTHIA EL1 | 96/5~02/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7385 | 12211 PZ1 004 | | PARTNER D13B,15B,D16A EXHAUST | 96/3~ | Engine VALVE STEM SEAL |
| 03902 7718 | 91212 P01 003 | 31 x 46 x 7 | PARTNER D15B EY7 (E/#~8003694) | 96/3~99/5 | Engine CRANK SHAFT FRONT |
| 03902 7790 | 91212 P01 003 | 31 x 46 x 7 | PARTNER D16A EY8,9 9E/#~8001945) | 96/3~99/5 | Engine CRANK SHAFT FRONT |
| 03902 1202 | 91212 PLC 003/4 | 38 x 50 x 7 | PARTNER D13B EY6 (E/#8001073~) | 99/5~ | Engine CRANK SHAFT FRONT |
| 03902 3020 | 91212 PLC 003/4 | 38 x 50 x 7 | PARTNER D15B (EY7 (E/#8003695~) | 99/5~ | Engine CRANK SHAFT FRONT |
| 03902 5522 | 91212 PLC 003/4 | 38 x 50 x 7 | PARTNER D16A EY8,9 (E/#8001946~) | 99/5~ | Engine CRANK SHAFT FRONT |
| 03902 3542 | 91212 P01 003 | 31 x 46 x 7 | PARTNER D13B EY6 (E/#~8001072) | 96/3~99/5 | Engine CRANK SHAFT FRONT |
| 03902 1616 | 12210 PZ1 004 | | PARTNER D13B,15B,D16A INTAKE | 96/3~ | Engine VALVE STEM SEAL |
| 03902 6539 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PARTNER EY6,7,9 (2WD) | 96/3~ | Mission & Differential (A/T) CONVERTER CASE (A) |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 1445 | 91214 PC6 003/13 | 80 x 100 x 10 | PARTNER D13B,15B,D16A EY6,7,8,9 | 96/3~ | Engine CRANK SHAFT REAR |
| 03902 2480 | 91213 PE1 721/2 | 29 x 45 x 8 | PARTNER D13B,15B,D16A EY6,7,8,9 | 96/3~ | Engine CAM SHAFT |
| 03902 1382 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | PARTNER EY8 (4WD) | 96/3~ | Mission & Differential (A/T) MISSION CASE |
| 03902 8168 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | PARTNER EY6,7,9 (2WD) | 96/3~ | Mission & Differential (A/T) MISSION CASE |
| 03902 5495 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | PARTNER EY8 (4WD) | 96/3~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2984 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | PARTNER EY8 (4WD) | 96/3~ | Mission & Differential (M/T) MISSION CASE |
| 03902 3947 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | PARTNER EY6,7,9 (2WD) | 96/3~ | Mission & Differential (M/T) MISSION CASE |
| 03902 3407 | 91205 P25 J01/2 | 35 x 54 x 8 x 11.5 | PARTNER EY8 (4WD) | 96/3~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7205 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PARTNER EY6,7,9 (2WD) | 96/3~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8321 | 91216 PL3 003/5 | 26 x 42 x 7 | PARTNER EY6,7,9 (2WD) | 96/3~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 1706 | 91207 P0X 003/4 | 44 x 68 x 8 | PARTNER EY# | 96/3~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 3191 | 91216 PH8 003/5 | 28 x 41 x 7 | PARTNER EY8 (4WD) | 96/3~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3164 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | PRELUDE BA4,5 120,130,BA7 | 89/11~91/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1868 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PRELUDE BA4,5 120,130,BA7 | 89/11~91/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2030 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PRELUDE BA8,9,BB1,4 | 91/9~96/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 4721 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PRELUDE BB5,6,7,8 | 96/11~00/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3839 | 91205 PK5 E40/1 | 42 x 56 x 8 x 11.5 | PRELUDE BA5 TCS | 89/11~91/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 5090 | 91201 P6J 003 | 44 x 60 x 8 x 13 | PRELUDE BB6 ATTS | 96/11~00/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8663 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | PRELUDE SN | 78/11~82/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4271 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | PRELUDE AB | 82/11~91/ | Mission & Differential (M/T) MISSION CASE |
| 03902 5342 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | PRELUDE BB5,7 | 97/9~00/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 4091 | 91206 PK5 003 | 35 x 62 x 9 x 12.5 | PRELUDE BA4,5 100,110 | 87/4~89/10 | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 9194 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | PRELUDE AB100 | 82/11~83/9 | Mission & Differential (M/T) CLUTCH CASE |
| 03902 9104 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | PRELUDE BA8,9,BB1,4 | 91/9~96/ | Mission & Differential (M/T) MISSION CASE |
| 03902 4829 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | PRELUDE BB5,6,7,8 | 96/11~00/ | Mission & Differential (M/T) MISSION CASE |
| 03902 7799 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | PRELUDE AB,BA1 | 82/11~87/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5747 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | PRELUDE BA4,5 100,110 | 87/4~89/10 | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5441 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PRELUDE BB6,8 | 96/11~00/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 3236 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | PRELUDE BA8,9,BB1,4,5,7 | 91/9~97/9 | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2705 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | PRELUDE BA1 | 85/7~87/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2291 | 91252 692 003/5 | 42 x 56.2 x 7 | PRELUDE AB DRUM BRAKE | 82/11~87/ | Wheel Hub REAR |
| 03902 4604 | 91250 634 003/5 | 45 x 64 x 9 x 14 | PRELUDE SN100 | 78/11~79/ | Wheel Hub FRONT INNER |
| 03902 8222 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | PRELUDE SN110,200,300 C/#1100001~ | 79/~82/ | Wheel Hub FRONT INNER |
| 03902 7466 | 91250 SB0 625 | 47 x 64 x 6 x 14 | PRELUDE AB MTM | 82/11~87/ | Wheel Hub FRONT INNER |
| 03902 6989 | 91250 SB0 013/15 | 49 x 64 x 6 x 13 | PRELUDE AB ATM | 82/11~87/ | Wheel Hub FRONT INNER |
| 03902 3578 | 91251 692 003/5 | 45 x 72.2 x 7.5 x 8.5 | PRELUDE SN | 78/11~82/ | Wheel Hub FRONT OUTER |
| 03902 2417 | 91251 SA5 003/5 | 47 x 72.2 x 6 x 8 | PRELUDE AB MTM | 82/11~87/ | Wheel Hub FRONT OUTER |
| 03902 8267 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | PRELUDE BA1#,BA4,5 100,110 | 85/7~89/10 | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3362 | 91252 692 003/5 | 42 x 56.2 x 7 | PRELUDE SN | 78/11~82/ | Wheel Hub REAR |
| 03902 8942 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | PRELUDE AB110,120,125 | 83/10~87/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2525 | 91252 692 930/1 | 42 x 56.2 x 9.5 | PRELUDE AB DISC BRAKE | 82/11~87/ | Wheel Hub REAR |
| 03902 2903 | 91216 689 003/5 | 25 x 40 x 7 | PRELUDE SN | 78/11~82/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4658 | 91216 PC8 003/5 | 27 x 42 x 7 | PRELUDE AB | 82/11~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6602 | 91216 PH8 003/5 | 28 x 41 x 7 | PRELUDE BA# | 85/7~96/ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 3389 | 91216 PH8 003/5 | 28 x 41 x 7 | PRELUDE BB# | 91/9~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4379 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | PRELUDE SN | 78/11~82/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3371 | 91205 PK5 E40/1 | 42 x 56 x 8 x 11.5 | PRELUDE BA5 TCS | 89/11~91/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2147 | 91251 SB0 013/15 | 49 x 72.2 x 6 x 8 | PRELUDE AB ATM | 82/11~87/ | Wheel Hub FRONT OUTER |
| 03902 2345 | 12210 PD2 003/4 | | PRELUDE B20A,21A (DOHC) INTAKE | 87/4~89/10 | Engine VALVE STEM SEAL |
| 03902 6413 | 91 207 639 015 | 44 x 68 x 8 | PRELUDE AB,BA#,BB1,4 | 82/11~96/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 7367 | 91214 PC6 003/13 | 80 x 100 x 10 | PRELUDE B20A,21A BA1,4,5,7 | 87/4~91/ | Engine CRANK SHAFT REAR |
| 03902 2012 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | PRELUDE BA4,5 120,130,BA7 | 89/11~91/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2228 | 91214 PC6 003/13 | 80 x 100 x 10 | PRELUDE H22A BB1,4,6,8 | 91/9~00/ | Engine CRANK SHAFT REAR |
| 03902 2138 | 12211 PE0 003/4 | | PRELUDE ES INTAKE | 82/11~83/9 | Engine VALVE STEM SEAL |
| 03902 7187 | 12210 PD2 003/4 | | PRELUDE ES,B20A (SOHC) INTAKE | 83/10~91/ | Engine VALVE STEM SEAL |
| 03902 1328 | 12211 PD2 003 | | PRELUDE ES,B20A (SOHC) EXHAUST | 82/11~91/ | Engine VALVE STEM SEAL |
| 03902 5009 | 91214 PB2 003 | 76 x 98 x 12 | PRELUDE EK SN(C/#1221937~) | 80/~82/ | Engine CRANK SHAFT REAR |
| 03902 8627 | 12209 PD2 003/4 | | PRELUDE ES C VALVE | 83/10~87/ | Engine VALVE STEM SEAL |
| 03902 7889 | 91214 PC6 003/13 | 80 x 100 x 10 | PRELUDE ES AB | 82/11~87/ | Engine CRANK SHAFT REAR |
| 03902 5585 | 12210 PT2 003/4 | | PRELUDE B20A,21A,F22B (DOHC) INTAKE | 89/11~00/ | Engine VALVE STEM SEAL |
| 03902 4496 | 12211 PE0 003/4 | | PRELUDE B20A,21A (DOHC) EXHAUST | 87/4~89/10 | Engine VALVE STEM SEAL |
| 03902 3353 | 12211 PT2 003/4 | | PRELUDE B20A,21A,F22B (DOHC) EXHAUST | 89/11~00/ | Engine VALVE STEM SEAL |
| 03902 8231 | 12210 PZ1 004 | | PRELUDE H22A INTAKE | 91/9~00/ | Engine VALVE STEM SEAL |
| 03902 1724 | 12210 PZ1 004 | | PRELUDE F22B (SOHC) INTAKE | 96/11~00/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 1715 | 12211 PZ1 004 | | PRELUDE H22A EXHAUST | 91/9~00/ | Engine VALVE STEM SEAL |
| 03902 1499 | 12211 PZ1 004 | | PRELUDE F22B (SOHC) EXHAUST | 96/11~00/ | Engine VALVE STEM SEAL |
| 03902 8771 | 12209 PA5 003/4 | | PRELUDE ES C VALVE | 82/11~83/ 9 | Engine VALVE STEM SEAL |
| 03902 1607 | 91213 PE1 721/2 | 29 x 45 x 8 | PRELUDE B20A(SOHC) BA4,5 | 87/4~91/ | Engine CAM SHAFT |
| 03902 5639 | 91207 P0X 003/4 | 44 x 68 x 8 | PRELUDE BB5,6,7,8 | 96/11~00/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4145 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | PRELUDE AB,BA1 | 82/11~87/ | Mission & Differential (A/T) MISSION CASE |
| 03902 8564 | 91206 PK4 003 | 40 x 66 x 8 x 11.5 | PRELUDE BA4,5,7,8,9,BB1,4 | 87/4~96/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6962 | 91214 PC6 003/13 | 80 x 100 x 10 | PRELUDE F22B BA8,9,BB5,7 | 91/9~00/ | Engine CRANK SHAFT REAR |
| 03902 8087 | 91213 PE1 721/2 | 29 x 45 x 8 | PRELUDE ES AB | 82/11~87/ | Engine CAM SHAFT |
| 03902 2516 | 91214 634 003/4 | 74 x 98 x 12 | PRELUDE EK SN(C/#~1221936) | 78/11~79/ | Engine CRANK SHAFT REAR |
| 03902 6854 | 91203 PG6 003 | 27 x 43 x 9 | PRELUDE B20A,21A(DOHC) BA1,4,5,7 | 87/4~91/ | Engine CAM SHAFT |
| 03902 1400 | 91213 PT0 003/4 | 28 x 42 x 8 | PRELUDE F22B BA8,9,BB5,7 | 91/9~00/ | Engine CAM SHAFT |
| 03902 8870 | 91212 PT0 003 | 40 x 52 x 7 | PRELUDE F22B BA8,9,BB5,7 | 91/9~00/ | Engine CRANK SHAFT FRONT |
| 03902 1130 | 91233 PT0 003 | 27 x 40 x 8 | PRELUDE F22B BA8,9,BB5,7 | 91/9~00/ | Engine OIL PUMP |
| 03902 3038 | 91233 PT0 003 | 27 x 40 x 8 | PRELUDE H22A BB1,4,6,8 | 91/9~00/ | Engine OIL PUMP |
| 03902 7862 | 91 212 611 003 | 35 x 50 x 8 | PRELUDE EK SN | 78/11~82/ | Engine CRANK SHAFT FRONT |
| 03902 5369 | 91212 PC6 003/4 | 35 x 54 x 8 | PRELUDE ES AB | 82/11~87/ | Engine CRANK SHAFT FRONT |
| 03902 7673 | 91212 PJ5 003/5 | 38 x 53 x 7 | PRELUDE B20A,21A BA1,4,5,7 | 85/7~91/ | Engine CRANK SHAFT FRONT |
| 03902 7358 | 91212 PT0 003 | 40 x 52 x 7 | PRELUDE H22A BB1,4,6,8 | 91/9~00/ | Engine CRANK SHAFT FRONT |
| 03902 4919 | 91213 PR3 003/4 | 29 x 43 x 8 | PRELUDE H22A BB1,4,6,8 | 91/9~00/ | Engine CAM SHAFT |
| 03902 8636 | 91201 P6R 003 | 40 x 56 x 9 x 12.5 | PRELUDE BB5,6,7,8 | 96/11~00/ | Mission & Differential (A/T) MISSION CASE |
| 03902 5243 | 91202 PCZ 003 | 35 x 56 x 9 x 14.5 | S2000 AP1 | 99/4~ | Differential SIDE |
| 03902 9059 | 91212 PCX 003 | 43 x 58 x 8 | S2001 AP1 F20C | 99/4~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2768 | 91214 PCX 003 | 80 x 98 x 10 | S2002 AP1 F20C | 99/4~ | Engine CRANK SHAFT REAR |
| 03902 1391 | 12210 PZ1 004 | | S2003 F20C INTAKE | 99/4~ | Engine VALVE STEM SEAL |
| 03902 2687 | 91216 PG1 005 | 28 x 43 x 7 | S2004 AP1 | 99/4~ | Transmission FRONT |
| 03902 1283 | 91201 PCY 003 | 40 x 60 x 9 x 12.5 | S2005 AP1 | 99/4~ | Transmission REAR |
| 03902 7142 | 12211 PZ1 004 | | S2006 F20C EXHAUST | 99/4~ | Engine VALVE STEM SEAL |
| 03902 6665 | 91201 PCZ 003 | 40 x 64 x 10 x 16 | S2007 AP1 | 99/4~ | Differential PINION |
| 03902 8861 | 91207 P0X 003/4 | 44 x 68 x 8 | S-MX RH1,2 | 96/11~02/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4901 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | S-MX RH1,2 | 96/11~02/ | Mission & Differential (A/T) TRNSMISSION CASE |
| 03902 6575 | 91203 PG6 003 | 27 x 43 x 9 | S-MX B20B RH1,2 | 96/11~02/ | Engine CAM SHAFT |
| 03902 5702 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | S-MX B20B RH1,2 | 96/11~02/ | Engine CRANK SHAFT FRONT |
| 03902 2930 | 91214 PC6 003/13 | 80 x 100 x 10 | S-MX B20B RH1,2 | 96/11~02/ | Engine CRANK SHAFT REAR |
| 03902 8402 | 12210 PT2 003/4 | | S-MX B20B INTAKE | 96/11~02/ | Engine VALVE STEM SEAL |
| 03902 7520 | 12211 PT2 003/4 | | S-MX B20B EXHAUST | 96/11~02/ | Engine VALVE STEM SEAL |
| 03902 8447 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | S-MX RH1,2 | 96/11~02/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 2048 | 12210 PT2 003/4 | | STEP WAGON B20B INTAKE | 95/10~ | Engine VALVE STEM SEAL |
| 03902 4847 | 12211 PT2 003/4 | | STEP WAGON B20B EXHAUST | 95/10~ | Engine VALVE STEM SEAL |
| 03902 2471 | 91214 PC6 003/13 | 80 x 100 x 10 | STEP WAGON B20B | 95/10~ | Engine CRANK SHAFT REAR |
| 03902 1364 | 91203 PG6 003 | 27 x 43 x 9 | STEP WAGON B20B | 95/10~ | Engine CAM SHAFT |
| 03902 6836 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | STEP WAGON RF# | 95/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 4208 | 91207 P0X 003/4 | 44 x 68 x 8 | STEP WAGON RF# | 95/10~ | Mission & Differential (A/T) CONVERTER CASE (2) |
| 03902 1472 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | STEP WAGON RF# | 95/10~ | Mission & Differential (A/T) CONVERTER CASE (1) |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 7826 | 91212 PR3 003 | 38 x 50 x 7.4 x 8.1 | STEP WAGON B20B | 95/10~ | Engine OIL PUMP |
| 03902 9167 | 91207 P7Z 003 | 44 x 68 x 8 | STREAM RN3,4 | 00/10~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 1904 | 91214 PY3 003 | 80 x 98 x 10 | STREAM K20A RN4 (4WD) | 01/1~ | Engine CRANK SHAFT REAR |
| 03902 9140 | 91214 PNA 014 | 80 x 98 x 10 | STREAM K20A RN3(2WD) | 00/10~ | Engine CRANK SHAFT REAR |
| 03902 4388 | 91214 PH1 003/13 | 80 x 100 x 10 | STREAM D17A RN1,2 | 00/10~ | Engine CRANK SHAFT REAR |
| 03902 1436 | 91212 PNA 003 | 43 x 58 x 7 | STREAM K20A RN3,4 | 00/10~ | Engine TIMING CHAIN CASE |
| 03902 9239 | 91212 PLC 003/4 | 38 x 50 x 7 | STREAM D17A RN1,2 | 00/10~ | Engine CRANK SHAFT FRONT |
| 03902 2129 | 91213 PE1 721/2 | 29 x 45 x 8 | STREAM D17A RN1,2 | 00/10~ | Engine CAM SHAFT |
| 03902 6971 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | STREAM RN3,4 (K20A,2WD,4WD) | 00/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 7412 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | STREAM RN1,2 | 00/10~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 1139 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | STREAM RN1 (D17A,2WD) | 00/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 8681 | 91207 P0X 003/4 | 44 x 68 x 8 | STREAM RN1,2 | 00/10~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 3983 | 91206 PHR 003 | 35 x 58 x 8 x 11.5 | STREAM RN3,4 | 00/10~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 7934 | 12211 PZ1 004 | | STREAM D17A,K20A | 00/10~ | Engine VALVE STEM SEAL |
| 03902 7178 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | STREAM RN2 (D17A,4WD) | 00/10~ | Mission & Differential (A/T) MISSION CASE |
| 03902 4109 | 12210 PZ1 004 | | STREAM D17A,K20A INTAKE | 00/10~ | Engine VALVE STEM SEAL |
| 03902 7727 | 91207 P0X 003/4 | 44 x 68 x 8 | TODAY JA4 C/2016962~ | 94/4~98/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4550 | 12209 MB9 003 | | TODAY EH JW1 | 85/8~88/ | Engine VALVE STEM SEAL |
| 03902 4649 | 12211 PZ1 004 | | TODAY E05A,E07A EXHAUST | 88/2~98/ | Engine VALVE STEM SEAL |
| 03902 1238 | 12210 PZ1 004 | | TODAY E05A,E07A INTAKE | 88/2~98/ | Engine VALVE STEM SEAL |
| 03902 6710 | 91 214 679 024 | 65 x 88 x 12 | TODAY EH,E05A,E07A JA#,JW# | 85/8~98/ | Engine CRANK SHAFT REAR |
| 03902 6341 | 91 212 679 014 | 30 x 42 x 8 | TODAY EH JW1 | 85/8~88/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4811 | 91212 PN4 003 | 30 x 42 x 7 | TODAY E05A,E07A JA#,JW# | 88/2~98/ | Engine CRANK SHAFT FRONT |
| 03902 1940 | 91203 PG6 003 | 27 x 43 x 9 | TODAY EH,E05A,E07A JA#,JW# | 85/8~98/ | Engine CAM SHAFT |
| 03902 6629 | 91205 PZ5 003/4 | 35 x 62 x 9 x 12.5 | TODAY JW3 C/#2053064~ | 93/2~98/ | Mission & Differential (A/T) MISSION CASE |
| 03902 4181 | 91205 PZ5 003/4 | 35 x 62 x 9 x 12.5 | TODAY JA4,5 | 93/1~98/ | Mission & Differential (A/T) MISSION CASE |
| 03902 4514 | 91206 PZ4 003 | 35 x 62 x 6 x 12.5 | TODAY JW3 C/#~2053063 | 93/2~98/ | Mission & Differential (A/T) MISSION CASE |
| 03902 3803 | 91206 PZ4 003 | 35 x 62 x 6 x 12.5 | TODAY JA2 | 90/2~93/ | Mission & Differential (A/T) MISSION CASE |
| 03902 8690 | 91205 PN1 014 | 35 x 46 x 9 x 12.5 | TODAY JA1,JW1,2 | 85/8~90/ | Mission & Differential (A/T) MISSION CASE |
| 03902 5054 | 91252 SD5 003 | 36 x 53 x 6 | TODAY JA1,2,JW1,2,3 92WD) | 85/8~98/ | Wheel Hub REAR |
| 03902 2462 | 91207 P0X 003/4 | 44 x 68 x 8 | TODAY JA5 C/#2000791~ | 94/4~98/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 6485 | 91 207 639 015 | 44 x 68 x 8 | TODAY JA5 C/#2000790 | 93/1~94/4 | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 8276 | 91 207 639 015 | 44 x 68 x 8 | TODAY JA4 C/#2016961 | 93/1~94/4 | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 7925 | 91 207 639 015 | 44 x 68 x 8 | TODAY JA1,2,JW1,2 | 85/8~98/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 3866 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | TODAY JA4,5 | 93/1~98/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 1535 | 91205 PZ4 003 | 35 x 56 x 9 x 12.5 | TODAY JA2 | 90/2~93/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 8294 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | TODAY JA1,JW2 | 88/2~90/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 9212 | 91205 PL6 003/5 | 35 x 58 x 9 x 13.5 | TODAY JA1,2,3,4,5,JW2,3,4 | 88/2~98/ | Mission & Differential (M/T) MISSION CASE |
| 03902 6116 | 91205 PL8 003/5 | 35 x 68 x 9 x 12.5 | TODAY JW1 | 85/8~88/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2219 | 91205 PL6 003/5 | 35 x 56 x 8 x 11.5 | TODAY JA1,2,3,4,5,JW2,3,4 | 88/2~98/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7124 | 91216 PZ6 005 | 22 x 36 x 7 | TODAY JA2,3,4,5,JW3,4 | 90/2~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3281 | 91216 PL6 003/5 | 20 x 34 x 7 | TODAY JA1,JW2 | 88/2~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 9086 | 91216 PA0 003/5 | 22 x 35 x 7 | TODAY JW1 | 85/8~98/ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 4451 | 91205 PZ4 003 | 35 x 56 x 9 x 12.5 | TODAY JW3 C/#~2051893 | 93/2~98/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 4793 | 91207 P0X 003/4 | 44 x 68 x 8 | TODAY JW3 | 93/2~98/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 2579 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | TODAY JW3 C/E#2051894~ | 93/2~98/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 7475 | 91233 PT0 003 | 27 x 40 x 8 | TORNEO F18B,F20B,H22A | 97/9~ | Engine OIL PUMP |
| 03902 5531 | 12211 PZ1 004 | | TORNEO F18B,F20B,H22A EXHAUST | 97/9~ | Engine VALVE STEM SEAL |
| 03902 8591 | 12210 PZ1 004 | | TORNEO F18B,F20B,H22A INTAKE | 97/9~ | Engine VALVE STEM SEAL |
| 03902 5117 | 91214 PC6 003/13 | 80 x 100 x 10 | TORNEO F18B,F20B,H22A | 97/9~00/6 | Engine CRANK SHAFT REAR |
| 03902 3335 | 91212 PT0 003 | 40 x 52 x 7 | TORNEO F18B,F20B,H22A | 97/9~ | Engine CRANK SHAFT FRONT |
| 03902 3065 | 91213 PR3 003/4 | 29 x 43 x 8 | TORNEO F20B,H22A DOHC | 97/9~ | Engine CAM SHAFT |
| 03902 4073 | 91213 PT0 003/4 | 28 x 42 x 8 | TORNEO F18B,F20B SOHC | 97/9~ | Engine CAM SHAFT |
| 03902 1769 | 91206 PK4 003 | 40 x 56 x 8 x 11.5 | TORNEO CF#,CL# | 97/9~ | Mission & Differential (A/T) MISSION CASE |
| 03902 7943 | 91207 P0X 003/4 | 44 x 68 x 8 | TORNEO CF#,CL# | 97/9~ | Mission & Differential (A/T) COMVERTER CASE (B) |
| 03902 8537 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | TORNEO CE5 4WD | 97/9~ | Mission & Differential (A/T) COMVERTER CASE (A) |
| 03902 3965 | 91205 P0X 005 | 40 x 56 x 8 x 11.5 | TORNEO CF#,CL#...2WD | 97/9~ | Mission & Differential (A/T) COMVERTER CASE (A) |
| 03902 3200 | 91206 PX5 003/5 | 40 x 58 x 8 x 11.5 | TORNEO CF#,CL#...2WD | 97/9~ | Mission & Differential (M/T) MISSION CASE |
| 03902 2939 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | TORNEO CF#,CL#...2WD | 97/9~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3137 | 91216 PH8 003 | 28 x 41 x 7 | TORNEO CF#,CL#...2WD | 97/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6809 | 91214 PH1 003/13 | 80 x 100 x 10 | TORNEO F18B,F20B,H22A | 00/6~ | Engine CRANK SHAFT REAR |
| 03902 9221 | 91206 PL3 A01/2 | 35 x 62 x 8 x 11.5 | VAMOS HM1,2 | 99/6~ | Mission & Differential (M/T) MISSION CASE |
| 03902 3506 | 12211 PZ1 004 | | VAMOS E07Z EXHAUST | 99/6~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 2813 | 12210PZ1 004 | | VAMOS E07Z INTAKE | 99/6~ | Engine VALVE STEM SEAL |
| 03902 7133 | 91214 PFB 003 | 65 x 88 x 10 | VAMOS E07Z HM1,2 | 99/6~ | Engine CRANK SHAFT REAR |
| 03902 2948 | 91212 PN4 003 | 30 x 42 x 7 | VAMOS E07Z HM1,2 | 99/6~ | Engine CRANK SHAFT FRONT |
| 03902 2093 | 91203 PG6 003 | 27 x 43 x 9 | VAMOS E07Z HM1,2 | 99/6~ | Engine CAM SHAFT |
| 03902 5126 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | VAMOS HM1 TURBO,HM2 (4WD) | 99/6~ | Mission & Differential (A/T) MISSION CASE |
| 03902 1877 | 91205 PZ5 003/4 | 35 x 62 x 9 x 12.5 | VAMOS HM1 EXCEPT TURBO | 99/6~ | Mission & Differential (A/T) MISSION CASE |
| 03902 6827 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | VAMOS HM1,2 | 99/6~ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 7871 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | VAMOS HM1,2 | 99/6~ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8033 | 91216 PZ6 005 | 22 x 36 x 7 | VAMOS HM1,2 | 99/6~ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 5927 | 91207 P0X 003/4 | 44 x 68 x 8 | VAMOS HM1,2 | 99/6~ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4622 | 91216 PC8 003/5 | 27 x 42 x 7 | VIGOR AD | 83/6~85/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3695 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | VIGOR CA2,3 B18A,B20A | 85/5~89/ | Mission & Differential (M/T) MISSION CASE |
| 03902 1292 | 91206 PC8 003/5 | 40 x 76 x 8 x 12.5 | VIGOR AD PGM-FI | 83/6~85/ | Mission & Differential (M/T) MISSION CASE |
| 03902 2552 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | VIGOR CA1 A18A | 85/5~89/ | Mission & Differential (M/T) MISSION CASE |
| 03902 8429 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | VIGOR AD CARB. | 83/6~85/ | Mission & Differential (M/T) MISSION CASE |
| 03902 5945 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | VIGOR SZ | 81/9~83/ | Mission & Differential (M/T) MISSION CASE |
| 03902 3623 | 91201 PW5 015 | 50 x 70 x 11 | VIGOR CB5 | 89/10~93/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 8609 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | VIGOR CA# | 85/5~89/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 3902 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | VIGOR AD | 83/6~85/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2651 | 91205 689 003/5 | 35 x 62 x 9 x 12.5 | VIGOR SZ | 81/9~83/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 7979 | 91216 PH8 003/5 | 28 x 41 x 7 | VIGOR CC2,3 G20A,G25A | 92/1~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 8186 | 91216 PH8 003/5 | 28 x 41 x 7 | VIGOR CB5 G20A | 89/10~93/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 4712 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | VIGOR CB5 | 89/10~93/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 7763 | 91216 PC8 003/5 | 27 x 42 x 7 | VIGOR CA1,2 A18A,B18A | 85/5~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 3650 | 91201 PW5 015 | 50 x 70 x 11 | VIGOR CC# | 92/1~95/ | Mission & Differential (M/T) CLUTCH CASE |
| 03902 2399 | 91212 PT0 003 | 40 x 52 x 7 | VIGOR G20A,G25A CB5,CC2,3 | 89/10~95/ | Engine CRANK SHAFT FRONT |
| 03902 7421 | 91212 PJ5 003/5 | 38 x 53 x 7 | VIGOR B18A,B20A CA2,3 | 85/5~89/ | Engine CRANK SHAFT FRONT |
| 03902 7376 | 91212 PC6 003/4 | 35 x 54 x 8 | VIGOR A18A,A20A CA1,5 | 85/5~89/ | Engine CRANK SHAFT FRONT |
| 03902 2057 | 91212 PC6 003/4 | 35 x 54 x 8 | VIGOR ES AD | 83/6~85/ | Engine CRANK SHAFT FRONT |
| 03902 1247 | 91 212 611 003 | 35 x 50 x 8 | VIGOR EK SZ | 81/9~83/ | Engine CRANK SHAFT FRONT |
| 03902 2255 | 91213 PR3 003/4 | 29 x 43 x 8 | VIGOR G20A,G25A CB5,CC2,3 | 89/10~95/ | Engine CAM SHAFT |
| 03902 1553 | 91203 PG6 003 | 27 x 43 x 9 | VIGOR B18A,B20A CA2,3 | 85/5~89/ | Engine CAM SHAFT |
| 03902 1652 | 91213 PE1 721/2 | 29 x 45 x 8 | VIGOR ES,A18A,A20A AD,CA1,5 | 83/6~89/ | Engine CAM SHAFT |
| 03902 3713 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | VIGOR CB5,CC# | 89/10~95/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6125 | 91216 689 003/5 | 25 x 40 x 7 | VIGOR SZ | 81/9~83/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 6278 | 91205 PC9 003/5 | 35 x 62 x 9 x 12.5 | VIGOR CA1 A18A | 85/5~89/ | Mission & Differential (A/T) MISSION CASE |
| 03902 9005 | 91216 PH8 003/5 | 28 x 41 x 7 | VIGOR CA3 B20A | 85/5~89/ | Mission & Differential (M/T) INPUT SHAFT |
| 03902 5855 | 91251 SA5 003/5 | 47 x 72.2 x 6 x 8 | VIGOR AD MT(CARB.) | 83/6~85/ | Wheel Hub FRONT OUTER |
| 03902 2102 | 12211 PZ1 004 | | VIGOR G20A,G25A EXHAUST | 89/10~95/ | Engine VALVE STEM SEAL |
| 03902 5963 | 12210 PZ1 004 | | VIGOR G20A,G25A INTAKE | 89/10~95/ | Engine VALVE STEM SEAL |
| 03902 5225 | 12211 PE0 003/4 | | VIGOR B18A,B20A EXHAUST | 85/5~89/ | Engine VALVE STEM SEAL |
| 03902 8933 | 12210 PD2 003/4 | | VIGOR B18A,B20A INTAKE | 85/5~89/ | Engine VALVE STEM SEAL |
| 03902 5072 | 91250 SB0 625 | 47 x 64 x 6 x 14 | VIGOR AD MT(CARB.) | 83/6~85/ | Wheel Hub FRONT INNER |
| 03902 3110 | 91250 SA2 003/5 | 45 x 64 x 6.5 x 13.5 | VIGOR SZ | 81/9~83/ | Wheel Hub FRONT INNER |
| 03902 8816 | 91233 PV0 003 | 27 x 41 x 8 | VIGOR G20A CB5 | 89/10~95/ | Engine BALANCER SHAFT |
| 03902 1166 | 91251 SA5 003/5 | 47 x 72.2 x 6 x 8 | VIGOR SZ | 81/9~83/ | Wheel Hub FRONT OUTER |
| 03902 5567 | 91206 PW5 015 | 40 x 56 x 8 x 9.5 | VIGOR CC# | 92/1~95/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 5900 | 91251 SB0 013/15 | 49 x 72.2 x 6 x 8 | VIGOR AD MT(PGM-FI) | 84/6~85/ | Wheel Hub FRONT OUTER |
| 03902 1670 | 91251 SB0 013/15 | 49 x 72.2 x 6 x 8 | VIGOR AD AT | 83/6~85/ | Wheel Hub FRONT OUTER |
| 03902 3218 | 91252 692 003/5 | 42 x 56.2 x 7 | VIGOR SZ,AD DRUM BRAKE | 81/9~85/ | Wheel Hub REAR |
| 03902 5918 | 12209 PD2 003/4 | | VIGOR ES C VALVE | 83/6~85/ | Engine VALVE STEM SEAL |
| 03902 3047 | 12211 PD2 003 | | VIGOR ES,A18A,A20A EXHAUST | 83/6~89/ | Engine VALVE STEM SEAL |
| 03902 9068 | 91205 PC9 711 | 40 x 62 x 8 x 11.5 | VIGOR AD | 83/6~85/ | Mission & Differential (A/T) MISSION CASE |
| 03902 6179 | 91250 SB0 013/15 | 49 x 64 x 6 x 13 | VIGOR AD AT | 83/6~85/ | Wheel Hub FRONT INNER |
| 03902 8204 | 12210 PD2 003/4 | | VIGOR ES,A18A,A20A INTAKE | 83/6~89/ | Engine VALVE STEM SEAL |
| 03902 4577 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | VIGOR CA2,3,5 B18A,B20A,A20A | 85/5~89/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 1787 | 91206 PC9 003/5 | 35 x 76 x 9 x 12.5 | VIGOR CA1 A18A | 85/5~89/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 8375 | 91201 PW5 015 | 50 x 70 x 11 | VIGOR CB5,CC# | 89/10~95/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 3731 | 91 207 639 015 | 44 x 68 x 8 | VIGOR AD,CA#,CB5,CC# | 81/9~95/ | Mission & Differential (A/T) CONVERTER CASE (B) |
| 03902 4289 | 91206 PC9 711 | 40 x 76 x 9 x 12.5 | VIGOR AD | 83/6~85/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 5846 | 91250 SB0 013/15 | 49 x 64 x 6 x 13 | VIGOR AD MT(PGM-FI) | 84/6~85/ | Wheel Hub FRONT INNER |
| 03902 5783 | 91205 PC8 934/5 | 38 x 54 x 8 x 11.5 | VIGOR CA2,3,5 B18A,B20A,A20A | 85/5~89/ | Mission & Differential (A/T) MISSION CASE |
| 03902 1967 | 91252 692 930/1 | 42 x 56.2 x 9.5 | VIGOR SZ,AD DISC BRAKE | 81/9~85/ | Wheel Hub REAR |
| 03902 7457 | 91214 PB2 003 | 76 x 98 x 12 | VIGOR EK SZ | 81/9~83/ | Engine CRANK SHAFT REAR |
| 03902 4037 | 91214 PC6 003/13 | 80 x 100 x 10 | VIGOR ES,A18A,A20A AD,CA1,5 | 83/6~89/ | Engine CRANK SHAFT REAR |
| 03902 7529 | 91214 PC6 003/13 | 80 x 100 x 10 | VIGOR G20A,G25A CB5,CC2,3 | 89/10~95/ | Engine CRANK SHAFT REAR |
| 03902 4613 | 12211 PZ1 004 | | Z E07Z EXHAUST | 98/10~01/ | Engine VALVE STEM SEAL |
| 03902 2318 | 91212 PN4 003 | 30 x 42 x 7 | Z E07Z PA1 | 98/10~01/ | Engine CRANK SHAFT FRONT |
| 03902 5297 | 91214 PFB 003 | 65 x 88 x 10 | Z E07Z PA1 | 98/10~01/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.2 HONDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03902 5630 | 12210 PZ1 004 | | Z E07Z INTAKE | 98/10~01/ | Engine VALVE STEM SEAL |
| 03902 7970 | 91203 PG6 003 | 27 x 43 x 9 | Z E07Z PA1 | 98/10~01/ | Engine CAM SHAFT |
| 03902 6746 | 91206 689 003/5 | 35 x 76 x 9 x 12.5 | Z PA1 | 98/10~01/ | Mission & Differential (A/T) MISSION CASE |
| 03902 2750 | 91206 PL6 003/5 | 35 x 56 x 8 x 11.5 | Z PA1 | 98/10~01/ | Mission & Differential (A/T) CONVERTER CASE (A) |
| 03902 6701 | 91207 P0X 003/4 | 44 x 68 x 8 | Z PA1 | 98/10~01/ | Mission & Differential (A/T) CONVERTER CASE (B) |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5361 | 12279-AD205 | 84 x 104 x 8.5 | 180SX RS13 SR20DET | 97/9~99/ | Engine CRANK SHAFT REAR |
| 03903 3139 | 13207-D4200 | | 180SX RS13 SR20DT,SR20DET(IN.0 | 91/1~99/ | Engine VALVE STEM SEAL |
| 03903 3429 | 13207-D0101 | | 180SX RS13 SR20DT,SR20DET(EX.) | 97/9~99/ | Engine VALVE STEM SEAL |
| 03903 3363 | 12279-85Y00 | 84 x 104 x 11 | 180SX RS13 SR20DT,SR20DET | 91/1~97/9 | Engine CRANK SHAFT REAR |
| 03903 5695 | 12279-85Y00 | 84 x 104 x 11 | 180SX RS13 CA18DT | 90/4~91/1 | Engine CRANK SHAFT REAR |
| 03903 3355 | 12279-D0100 | 84 x 104 x 11 | 180SX RS13 CA18DT | 89/3~90/4 | Engine CRANK SHAFT REAR |
| 03903 3967 | 13510-53J00 | 46 x 58 x 7 | 180SX RS13 SR20DT,SR20DET | 91/1~99/ | Engine CRANK SHAFT FRONT |
| 03903 1215 | 13042-16V00 | 40 x 52 x 7 | 180SX RS13 CA18DT | 89/3~91/1 | Engine CRANK SHAFT FRONT |
| 03903 1129 | 38342-N3100 | 35 x 55 x 11 x 18 | 180SX RS13 | 89/3~99/ | Final Drive DIFF. SIDE |
| 03903 2101 | 38189-21G00 | 40 x 75 x 12 x 19 | 180SX RS13 CA18DT,SR20DT | 89/3~99/ | Final Drive PINION |
| 03903 3887 | 38189-N3112 | 40 x 75 x 13.5 x 21 | 180SX RS13 SR20DT,SR20DET | 91/7~99/ | Final Drive PINION |
| 03903 3991 | 38189-Y0810 | 40 x 75 x 12 | 180SX RS13 ANTI SKID | 89/3~91/7 | Final Drive PINION |
| 03903 2549 | 32136-U0100 | 35 x 50 x 11 | 180SX RS13 | 89/3~99/ | Transmission (M/T) REAR EXTENSION |
| 03903 3483 | 32114-Y4000 | 30 x 45 x 8 | 180SX RS13 | 89/3~99/ | Transmission (M/T) FRONT COVER |
| 03903 2995 | 13042-16V00 | 40 x 52 x 7 | 180SX RS13 CA18DT | 89/3~91/1 | Engine CAM SHAFT |
| 03903 1511 | 13207-D4200 | | 180SX RS13 CA18DT | 89/3~91/1 | Engine VALVE STEM SEAL |
| 03903 3573 | 49365-10V26 | | AD (VAN, WAGON) / WINGROAD Y10,CY10 | 90/10~99/ | Steering (P/S) PINION SEAL KIT |
| 03903 5337 | 48125-11A00 | 15 x 32 x 6 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Steering GEAR |
| 03903 4099 | 48125-60R00 | 16 x 26 x 7 | AD (VAN, WAGON) / WINGROAD Y10 | 90/10~99/ | Steering GEAR |
| 03903 1449 | 49297-86A25 | | AD (VAN, WAGON) / WINGROAD Y10 | 90/10~99/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4873 | 49297-4M426 | | AD (VAN, WAGON) / WINGROAD Y11..QG13DE,QG15DE (2WD),QG18DE,QG18DEN | 99/5~00/9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 3309 | 49297-4M427 | | AD (VAN, WAGON) / WINGROAD Y11..QG13DE,QG15DE (2WD),QG18DE,QG18DEN | 00/9~02/9 | Steering (P/S) GEAR HOUSING KIT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4045 | 49297-8N025 | | AD (VAN, WAGON) / WINGROAD Y11..QG13DE,QG15DE (2WD),QG18DE,QG18DEN | 02/9~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 5277 | 49297-4M587 | | AD (VAN, WAGON) / WINGROAD Y11 YD22DD,SR20VE,QR20DE (2WD),QG18DE | 99/5~00/9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 3095 | 49365-V0227 | | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Steering (P/S) PINION SEAL KIT |
| 03903 1399 | 38342-8E001 | 32.5 x 56 x 8 x 14 | AD (VAN, WAGON) / WINGROAD Y11 SE20VE,QR20DE(CVT) | 00/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2437 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5685 | 49297-4M586 | | AD (VAN, WAGON) / WINGROAD Y11 YD22DD,SR20VE,QR20DE (2WD),QG18DE | 00/9~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4321 | 48029-W0501 | 17.5 x 32 x 7 | AD (VAN, WAGON) / WINGROAD Y11 YD22DD(4WD) | 99/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2227 | 48029-W0501 | 17.5 x 32 x 7 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD17(4WD) | 90/10~99/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1937 | 38342-31X01 | 33 x 56 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y11 YD22DD(2WD) | 99/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2423 | 38342-31X01 | 33 x 56 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y10,CY10 SR18DE,CD20(2WD) | 90/10~99/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5631 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y11 QG15DE,QG18DE | 99/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3107 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD20(2WD) | 90/10~99/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1639 | 13042-01M00 | 40 x 55 x 9 | AD (VAN, WAGON) / WINGROAD VB11 E13S,E15S | 82/10~90/ | Engine CAM SHAFT |
| 03903 4755 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y10 GA13D#(F3) | 90/10~99/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3341 | 13510-AD200 | 50 x 62 x 7 | AD (VAN, WAGON) / WINGROAD Y11 YD22DD | 99/5~ | Engine CRANK SHAFT FRONT |
| 03903 4995 | 38342-8E002 | 41.5 x 90 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE(CVT) (NSD) | 00/5~ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2745 | 38342-8E000 | 40 x 52 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y11 QR20DE | 01/10~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1677 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#(F4),GA15D#,CD17 (2WD) | 90/10~99/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3479 | 12279-D0100 | 84 x 104 x 11 | AD (VAN, WAGON) / WINGROAD VB11 CD17 | 82/10~90/ | Engine CRANK SHAFT REAR |
| 03903 5659 | 13207-5L300 | | AD (VAN, WAGON) / WINGROAD Y11 YD22DD(IN.) | 99/5~01/10 | Engine VALVE STEM SEAL |
| 03903 2531 | 13207-53Y00 | | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE | 99/5~ | Engine VALVE STEM SEAL |
| 03903 3913 | 13207-53Y00 | | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#,GA15D# | 90/10~99/ | Engine VALVE STEM SEAL |
| 03903 5167 | 13207-D4200 | | AD (VAN, WAGON) / WINGROAD Y11 YD22DD(IN.) | 01/10~ | Engine VALVE STEM SEAL |
| 03903 1895 | 13207-D4200 | | AD (VAN, WAGON) / WINGROAD Y11 YD22DD(EX.) | 99/5~ | Engine VALVE STEM SEAL |
| 03903 4303 | 13207-D4200 | | AD (VAN, WAGON) / WINGROAD CY10,Y11 SR18DE,SR20VE,QR20DE | 96/5~99/ | Engine VALVE STEM SEAL |
| 03903 6495 | 13207-D0101 | | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD17,CD20 | 82/10~99/ | Engine VALVE STEM SEAL |
| 03903 3441 | 13207-01M01 | | AD (VAN, WAGON) / WINGROAD VB11 E13S,E15S | 82/10~90/ | Engine VALVE STEM SEAL |
| 03903 5821 | 12279-AD205 | 84 x 104 x 8.5 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE, SR20VE,QR20DE,YD22DD | 99/5~ | Engine CRANK SHAFT REAR |
| 03903 5261 | 12279-AD205 | 84 x 104 x 8.5 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#,GA15#,CD20,SR18 DE | 97/6~99/ | Engine CRANK SHAFT REAR |
| 03903 6063 | 13510-V7202 | 40 x 52 x 7 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE # | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 5957 | 12279-85Y00 | 84 x 104 x 11 | AD (VAN, WAGON) / WINGROAD Y10 CD17 | 90/10~97/ | Engine CRANK SHAFT REAR |
| 03903 5289 | 13042-D0100 | 34 x 48 x 8 | AD (VAN, WAGON) / WINGROAD VB11,Y10,CY10 CD17,CD20 | 82/10~90/ | Engine CAM SHAFT |
| 03903 1499 | 12279-01M00 | 80 x 100 x 10 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | | E13S,E15S | | |
| 03903 5109 | 38342-31X01 | 33 x 56 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE(CVT) | 99/5~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1797 | 13510-2J200 | 46 x 58 x 7 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE,QR20DE | 99/5~ | Engine CRANK SHAFT FRONT |
| 03903 4489 | 38342-8E000 | 40 x 52 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE(CVT) EXCEPT(NSD) | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 3639 | 13510-53J00 | 46 x 58 x 7 | AD (VAN, WAGON) / WINGROAD CY10 SR18DE | 90/10~99/ | Engine CRANK SHAFT FRONT |
| 03903 5613 | 13042-16V00 | 40 x 52 x 7 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE # | 99/5~00/7 | Engine CRANK SHAFT FRONT |
| 03903 4617 | 13042-16V00 | 40 x 52 x 7 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#,GA15D#,CD20 | 90/10~99/ | Engine CRANK SHAFT FRONT |
| 03903 4009 | 13510-16A00 | 33 x 47 x 8 | AD (VAN, WAGON) / WINGROAD VB11,Y10 CD17 | 82/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 3415 | 13510-01M00 | 36 x 49 x 7 | AD (VAN, WAGON) / WINGROAD VB11 E13S,E15S | 82/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 2063 | 13168-01M00 | 32 x 50 x 8 | AD (VAN, WAGON) / WINGROAD VB11 E13S,E15S | 82/10~90/ | Engine JACK SHAFT |
| 03903 2761 | 12279-85Y00 | 84 x 104 x 11 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#,GA15#,CD20,SR18 DE | 90/10~97/ 6 | Engine CRANK SHAFT REAR |
| 03903 5059 | 43232-87N00 | 47 x 67 x 10 x 16 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,SR18DE ANTI SKID (4WD) | 90/10~99/ | Wheel Hub REAR OUTER |
| 03903 5715 | 38342-D2100 | 40 x 56 x 65 x 20 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD17,CD20 (NSD)(2WD) | 90/10~99/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5021 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE | 99/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 1559 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD17 EXCEPT (NSD) | 90/10~99/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1991 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#(ALL) | 90/10~99/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6269 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5767 | 32113-03E00 | 27.9 x 43 x 8 | AD (VAN, WAGON) / WINGROAD Y11 YD22DD | 99/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5075 | 32113-03E00 | 27.9 x 43 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD20(4WD) | 90/10~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1507 | 32113-M8000 | 25 x 40 x 8 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE | 99/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3681 | 32113-M8000 | 25 x 40 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD20(2WD) | 90/10~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2621 | 32113-M8000 | 25 x 40 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#,GA15D#,CD17 | 90/10~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 6517 | 38342-03E00 | 39 x 59 x 11 x 17 | AD (VAN, WAGON) / WINGROAD Y11 YD22DD | 99/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 3319 | 40232-33P00 | 56 x 76 x 6 x 11 | AD (VAN, WAGON) / WINGROAD Y11(2WD) | 99/5~ | Wheel Hub REAR OUTER |
| 03903 6251 | 43252-H1000 | 41 x 56 x 7 | AD (VAN, WAGON) / WINGROAD Y10,CY10 WITHOUT ANTI SKID(4WD) | 90/10~99/ | Wheel Hub REAR |
| 03903 1195 | 43252-87N10 | 30 x 55 x 9 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,SR18DE ANTI SKID (4WD) | 90/10~99/ | Wheel Hub REAR INNER |
| 03903 5841 | 40232-33P00 | 56 x 76 x 6 x 11 | AD (VAN, WAGON) / WINGROAD Y11(4WD) | 99/5~ | Wheel Hub REAR INNER |
| 03903 1117 | 40232-33P00 | 56 x 76 x 6 x 11 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE | 99/5~ | Wheel Hub REAR |
| 03903 6275 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE(CVT) (NSD) | 99/5~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 2029 | 43252-M7001 | 43 x 54 x 7.5 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Wheel Hub REAR |
| 03903 6557 | 33111-31X00 | 60 x 76 x 9 | AD (VAN, WAGON) / WINGROAD CY10 SR18DE(4WD) | 90/10~99/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3267 | 40232-M5661 | 52 x 67 x 7 | AD (VAN, WAGON) / WINGROAD VB11 E15S,CD17 | 82/10~90/ | Wheel Hub FRONT OUTER |
| 03903 2545 | 40232-M0215 | 48 x 62 x 7 | AD (VAN, WAGON) / WINGROAD VB11 E13S | 82/10~90/ | Wheel Hub FRONT OUTER |
| 03903 6515 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | AD (VAN, WAGON) / WINGROAD Y10,CY10 | 90/10~99/ | Wheel Hub FRONT INNER |
| 03903 2215 | 40227-M5605 | 52 x 68 x 13 | AD (VAN, WAGON) / WINGROAD VB11 E15S,CD17 | 82/10~90/ | Wheel Hub FRONT INNER |
| 03903 1475 | 40227-M3005 | 48 x 62 x 13 | AD (VAN, WAGON) / WINGROAD VB11 E13S | 82/10~90/ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2901 | 32113-M8000 | 25 x 40 x 8 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2791 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE (F4)EXCEPT(NSD) | 99/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1279 | 40227-50Y01 | 56 x 74.2 x 10.3 | AD (VAN, WAGON) / WINGROAD Y10,CY10 | 90/10~99/ | Wheel Hub FRONT OUTER |
| 03903 2409 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y11 QG15DE,QG18DE EXCEPT (NSD) | 99/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 5099 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE,QG15DE,QG18DE (F4),(NSD) | 99/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1857 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AD (VAN, WAGON) / WINGROAD Y10,CY10 SR18DE(4WD) | 90/10~99/ | Mission & Differential (A/T) MISSION CASE |
| 03903 2373 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y11 SR20VE(CVT) EXCEPT(NSD) | 99/5~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 1785 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y10,CY10 SR18DE(2WD) EXCEPT(NSD) | 90/10~99/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3935 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#(F4),GA15D#,CD17 ,CD20 | 90/10~99/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4277 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y10 GA13D#(F3) | 90/10~99/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3001 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6183 | 38342-06R01 | 52 x 78 x 9 | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD20(4WD) | 99/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1293 | 38342-31X01 | 33 x 56 x 8 x 13 | AD (VAN, WAGON) / WINGROAD Y11 QG15DE,QG18DE (NSD) | 99/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1863 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD17 EXCEPT (NSD) | 90/10~99/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1319 | 38342-56E00 | 43 x 90 x 12 x 21 | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD20(4WD) | 90/10~99/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5503 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD17,CD20,SR18DE (3WD)(NSD) | 90/10~99/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3851 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AD (VAN, WAGON) / WINGROAD Y11 QG15DE,QG18DE EXCEPT (NSD) | 99/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1373 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD VB11 | 82/10~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3531 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AD (VAN, WAGON) / WINGROAD Y11 QG15DE,QG18DE (NSD) | 99/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 2895 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA13D#(ALL) | 90/10~99/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4159 | 38342-M8001 | 40 x 56 x 8 | AD (VAN, WAGON) / WINGROAD Y11 QG13DE | 99/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6401 | 38342-D2100 | 40 x 56 x 65 x 20 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD20 (NSD),(2WD) | 90/10~99/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6217 | 33111-56E00 | 60 x 78 x 9 | AD (VAN, WAGON) / WINGROAD Y10,CY10 CD20(4WD) | 90/10~99/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5247 | 33111-06R00 | 52 x 66 x 9 | AD (VAN, WAGON) / WINGROAD Y10,CY10 GA15D#,CD20(4WD) | 90/10~99/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2201 | 38342-03E01 | 33 x 59 x 11 x 17 | AD (VAN, WAGON) / WINGROAD Y11 YD22DD (2WD) | 99/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2039 | 38189-01G17 | 35 x 67 x 13 x 19 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 03/8~ | Front Final Drive PINION |
| 03903 4741 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | ATLAS / CABSTAR (1T~1.5T) F23 QD32 ABS (4WD) | 99/6~02/8 | Front Final Drive PINION |
| 03903 5569 | 33142-33G10 | 42 x 66 x 10 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25(4WD) | 92/10~99/6 | Transfer CASE(REAR) |
| 03903 5839 | 43252-H1000 | 41 x 56 x 7 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~92/ | Front Final Drive DIFF.SIDE(LH) |
| 03903 3611 | 43252-H1000 | 41 x 56 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 92/1~97/8 | Front Final Drive DIFF.SIDE(LH) |
| 03903 2989 | 33142-33G10 | 42 x 66 x 10 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 99/6~ | Transfer CASE(REAR) |
| 03903 3425 | 33142-01J10 | 50 x 72.5 x 10 x 18.3 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 00/10~ | Transfer CASE(REAR) |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2963 | 38189-21G00 | 40 x 75 x 12 x 19 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~91/7 | Front Final Drive PINION |
| 03903 4019 | 38189-21G17 | 40 x 75 x 13.5 x 22 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 91/7~92/ | Front Final Drive PINION |
| 03903 5849 | 38189-21G17 | 40 x 75 x 13.5 x 22 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 92/1~97/8 | Front Final Drive PINION |
| 03903 5003 | 38189-21G17 | 40 x 75 x 13.5 x 22 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 97/8~03/3 | Front Final Drive PINION |
| 03903 6453 | 38189-01G16 | 35 x 67 x 13.7 x 19.5 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 99/6~03/8 | Front Final Drive PINION |
| 03903 5911 | 38189-21G17 | 40 x 75 x 13.5 x 20.5 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 03/3~ | Front Final Drive PINION |
| 03903 4289 | 33142-01J01 | 50 x 72.5 x 12 x 19.5 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 97/8~00/10 | Transfer CASE(REAR) |
| 03903 5079 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F22 Z20S | 90/7~92/ | Transmission REAR EXTENSION |
| 03903 4973 | 38189-01G16 | 35 x 67 x 13.7 x 19.5 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25(4WD) | 92/10~99/6 | Front Final Drive PINION |
| 03903 2057 | 33111-01J00 | 50 x 72 x 12 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~92/ | Transfer COVER |
| 03903 4835 | 32113-VB000 | 32 x 45 x 8 | ATLAS / CABSTAR (1T~1.5T) F23 QD32 | 92/1~ | Transmission FRONT COVER |
| 03903 3113 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F22 SD25,TD27(2WD) | 82/2~92/ | Transmission REAR EXTENSION |
| 03903 1223 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S,KD20E,TD27,QD32 (ST) | 92/1~ | Rear Final Drive PINION |
| 03903 1919 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(2WD) | 92/1~97/8 | Transmission REAR EXTENSION |
| 03903 2695 | 43252-H1000 | 41 x 56 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 78/6~ | Front Final Drive DIFF.SIDE(LH) |
| 03903 4721 | 32136-U0100 | 35 x 50 x 11 | ATLAS / CABSTAR (1T~1.5T) F22 Z20S | 82/2~90/7 | Transmission REAR EXTENSION |
| 03903 4575 | 32136-U0100 | 35 x 50 x 11 | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA16S,NA20S,KA20DE,SD23,TD23 | 82/2~92/ | Transmission REAR EXTENSION |
| 03903 1911 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(2WD) | 97/8~ | Transmission REAR EXTENSION |
| 03903 6263 | 32136-01J00 | 44 x 62 x 10 | ATLAS / CABSTAR (1T~1.5T) F22,F23 TD27,QD32(4WD) | 82/2~ | Transmission REAR EXTENSION |
| 03903 2925 | 33142-01J01 | 50 x 72.5 x 12 x 19.5 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 92/1~97/8 | Transfer CASE(REAR) |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4189 | 33111-01J00 | 50 x 72 x 12 | ATLAS / CABSTAR (1T~1.5T) F23 TD27,QD32(4WD) | 92/1~99/6 | Transfer COVER |
| 03903 3269 | 33111-01J00 | 50 x 72 x 12 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 99/6~ | Transfer COVER |
| 03903 1141 | 33111-20N00 | 36.5 x 60 x 10 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25 | 92/1~99/6 | Transfer COVER |
| 03903 5371 | 33111-20N00 | 36.5 x 60 x 10 | ATLAS / CABSTAR (1T~1.5T) F23 TD27 | 99/6~ | Transfer COVER |
| 03903 3745 | 33216-01J00 | 40 x 75 x 12 x 17.9 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~92/ | Transfer CASE(FRONT) |
| 03903 1359 | 33216-01J00 | 40 x 75 x 12 x 17.9 | ATLAS / CABSTAR (1T~1.5T) F23(4WD) | 92/1~92/11 | Transfer CASE(FRONT) |
| 03903 3323 | 33216-33G01 | 40 x 75 x 12 x 20 | ATLAS / CABSTAR (1T~1.5T) F23(4WD) | 92/11~ | Transfer CASE(FRONT) |
| 03903 2003 | 33142-01J01 | 50 x 72.5 x 12 x 19.5 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~92/ | Transfer CASE(REAR) |
| 03903 5401 | 32136-U0100 | 35 x 50 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(2WD) | 99/6~ | Transmission REAR EXTENSION |
| 03903 6429 | 12279-5L300 | 80 x 100 x 8.5 | ATLAS / CABSTAR (1T~1.5T) F23 NA16S,NA20S,KD20E | 97/8~ | Engine CRANK SHAFT REAR |
| 03903 4615 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | ATLAS / CABSTAR (1T~1.5T) F22 HG FINAL DRIVE SD25,TD27 | 88/10~92/ | Rear Final Drive PINION |
| 03903 2731 | 13510-53J00 | 46 x 58 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 KD20E | 99/6~ | Engine CRANK SHAFT FRONT |
| 03903 2351 | 13510-43G01 | 58 x 80 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD27,QD32 | 00/2~ | Engine CRANK SHAFT FRONT |
| 03903 2783 | 12279-R4611 | 80 x 100 x 13 | ATLAS / CABSTAR (1T~1.5T) F22 Z16S,Z20S | 82/2~90/7 | Engine CRANK SHAFT REAR |
| 03903 3969 | 12279-T7202 | 80 x 100 x 10 | ATLAS / CABSTAR (1T~1.5T) F22 SD23,SD25 | 82/2~86/11 | Engine CRANK SHAFT REAR |
| 03903 2451 | 12279-43G02 | 86 x 100 x 10 | ATLAS / CABSTAR (1T~1.5T) F22 TD23,TD27 | 86/11~92/ | Engine CRANK SHAFT REAR |
| 03903 2497 | 13510-43G00 | 58 x 80 x 10 | ATLAS / CABSTAR (1T~1.5T) F22 TD23,TD27 | 86/11~92/ | Engine CRANK SHAFT FRONT |
| 03903 4985 | 12279-58S00 | 80 x 100 x 10 | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA16S,NA20S | 90/7~97/8 | Engine CRANK SHAFT REAR |
| 03903 2973 | 13042-T7200 | 58 x 80 x 12 | ATLAS / CABSTAR (1T~1.5T) F22 SD23,SD25 | 82/2~86/11 | Engine CRANK SHAFT FRONT |
| 03903 2519 | 12279-43G05 | RETAINER ID 86 | ATLAS / CABSTAR (1T~1.5T) F23 TD25,TD27,QD32 | 95/5~ | Engine CRANK SHAFT REAR |
| 03903 4975 | 13207-D0101 | | ATLAS / CABSTAR (1T~1.5T) F23 KD20E | 99/6~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3303 | 13207-V1700 | | ATLAS / CABSTAR (1T~1.5T) F22 SD23,TD23,SD25,TD27 | 82/2~92/ | Engine VALVE STEM SEAL |
| 03903 2089 | 13207-V1700 | | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25,TD27,QD32 | 92/1~ | Engine VALVE STEM SEAL |
| 03903 1783 | 13207-81W00 | | ATLAS / CABSTAR (1T~1.5T) F22 Z16S,Z20S | 82/2~ | Engine VALVE STEM SEAL |
| 03903 6519 | 32114-Y4000 | 30 x 45 x 8 | ATLAS / CABSTAR (1T~1.5T) F23 TD27 | 97/8~ | Transmission FRONT COVER |
| 03903 2371 | 40232-01G00 | 54 x 75.3 x 12 x 18 | ATLAS / CABSTAR (1T~1.5T) F23(2WD) | 92/1~99/6 | Wheel Hub FRONT |
| 03903 2169 | 12279-43G02 | 86 x 100 x 10 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD27 | 92/1~95/5 | Engine CRANK SHAFT REAR |
| 03903 2701 | 38189-N3100 | 40 x 75 x 12 x 17.5 | ATLAS / CABSTAR (1T~1.5T) F22 CAFINAL DRIVE Z16S,NA16S,Z20S,NA20S,SD23,TD23, | 82/2~91/7 | Rear Final Drive PINION |
| 03903 2455 | 38342-01G00 | 32 x 52 x 10.5 x 15.5 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 99/6~ | Front Final Drive DIFF.SIDE(LH) |
| 03903 1315 | 38342-N3100 | 35 x 55 x 11 x 8 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~92/ | Front Final Drive DIFF.SIDE(RH) |
| 03903 5731 | 38342-N3100 | 35 x 55 x 11 x 8 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 92/1~97/8 | Front Final Drive DIFF.SIDE(RH) |
| 03903 5393 | 38342-N3100 | 35 x 55 x 11 x 8 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(4WD) | 99/6~ | Front Final Drive DIFF.SIDE(RH) |
| 03903 3821 | 38342-01G01 | 29 x 52 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25(4WD) | 92/10~ | Front Final Drive DIFF.SIDE(RH) |
| 03903 4491 | 38342-01G01 | 29 x 52 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(4WD) | 99/6~ | Front Final Drive DIFF.SIDE(RH) |
| 03903 3701 | 13510-43G00 | 58 x 80 x 10 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25,TD27,QD32 | 82/1~00/2 | Engine CRANK SHAFT FRONT |
| 03903 2763 | 38189-C7000 | 42 x 76 x 12 x 21 | ATLAS / CABSTAR (1T~1.5T) F22 HGFINAL DRIVE Z20S,NA20S,SD25,TD27 | 82/2~88/10 | Rear Final Drive PINION |
| 03903 4809 | 38342-01G00 | 32 x 52 x 10.5 x 15.5 | ATLAS / CABSTAR (1T~1.5T) F23 TD23,TD25(4WD) | 92/10~ | Front Final Drive DIFF.SIDE(LH) |
| 03903 3805 | 38189-P0101 | 45 x 75 x 12 | ATLAS / CABSTAR (1T~1.5T) F22 HE,HF FINAL DRIVE Z16,SD23,TD23 | 82/2~90/ | Rear Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3779 | 38189-N3112 | 40 x 75 x 13.5 x 21 | ATLAS / CABSTAR (1T~1.5T) F22 CA FINAL DRIVE Z16S,NA16S,Z20S,NA20S,SD23,TD23 | 91/7~92/ | Rear Final Drive PINION |
| 03903 3467 | 38189-N3112 | 40 x 75 x 13.5 x 21 | ATLAS / CABSTAR (1T~1.5T) F23 NA16S,NA20S,KD20E,TD23,TD25,KD20E,TD27,QD32 | 92/1~ | Rear Final Drive PINION |
| 03903 4199 | 38189-P0117 | 45 x 75 x 14 x 19.5 | ATLAS / CABSTAR (1T~1.5T) F23 NA16S,NA20S,TD23 (WT) | 92/1~ | Rear Final Drive PINION |
| 03903 2635 | 13207-42L00 | | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA16S,NA20S | 90/7~99/8 | Engine VALVE STEM SEAL |
| 03903 3635 | 13042-A8601 | 48 x 70 x 9 | ATLAS / CABSTAR (1T~1.5T) F22 Z16S,NA16S,Z20S,NA20S | 82/2~92/ | Engine CRANK SHAFT FRONT |
| 03903 2077 | 13042-A8601 | 48 x 70 x 9 | ATLAS / CABSTAR (1T~1.5T) F23 NA16S,NA20S | 92/1~99/6 | Engine CRANK SHAFT FRONT |
| 03903 4795 | 40227-31G00 | 50 x 72 x 14.5 | ATLAS / CABSTAR (1T~1.5T) F22,F23(4WD) | 88/10~ | Front Final Drive SIDE SHAFT |
| 03903 4921 | 43252-VW000 | 35 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 KA20DE(1.3T) (ST) | 99/6~ | Wheel Hub REAR INNER |
| 03903 3545 | 43232-T6200 | 65 x 90 x 10 | ATLAS / CABSTAR (1T~1.5T) F22 (WT) | 82/2~92/2 | Wheel Hub REAR INNER |
| 03903 6277 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27 (ALL) | 99/6~ | Wheel Hub REAR INNER |
| 03903 3533 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 KA20DE(1.5T)WITHOUT ABS (ST) | 99/6~ | Wheel Hub REAR INNER |
| 03903 5159 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 QD32 WITHOUT ABS (ST) | 95/6~ | Wheel Hub REAR INNER |
| 03903 1017 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD25(ST) (ALL) | 95/6~ | Wheel Hub REAR INNER |
| 03903 5531 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD25,Q32 (ST) | 95/6~ | Wheel Hub REAR INNER |
| 03903 2171 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1T) (ST) | 95/6~ | Wheel Hub REAR INNER |
| 03903 4579 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(1.5T) (ST) | 92/1~97/8 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1351 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(1T) (ST) | 92/1~97/8 | Wheel Hub REAR INNER |
| 03903 2223 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1.5T) (ALL) | 92/1~99/6 | Wheel Hub REAR INNER |
| 03903 2805 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA20S,TD27 (ST) | 90/7~95/6 | Wheel Hub REAR INNER |
| 03903 5749 | 43232-11G00 | 65 x 90 x 11.4 | ATLAS / CABSTAR (1T~1.5T) F23 (WT) | 92/1~ | Wheel Hub REAR INNER |
| 03903 3225 | 43252-VW000 | 35 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(1T) (ST) | 99/6~ | Wheel Hub REAR INNER |
| 03903 4161 | 38212-73000 | 34 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F22 Z16,SD23,TD23 (ST) | 82/2~90/7 | Wheel Hub REAR INNER |
| 03903 1983 | 43252-VW000 | 35 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1.25T) (ST) | 95/6~ | Wheel Hub REAR INNER |
| 03903 5667 | 43252-VW000 | 35 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 TD25 (ST) | 95/6~ | Wheel Hub REAR INNER |
| 03903 5823 | 43252-VW000 | 35 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1T) (ST) | 92/1~95/6 | Wheel Hub REAR INNER |
| 03903 1629 | 43252-VW000 | 35 x 55 x 11 | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA16S,TD23 (ST) | 90/7~95/6 | Wheel Hub REAR INNER |
| 03903 3645 | 40227-20N00 | 51 x 93 x 24 | ATLAS / CABSTAR (1T~1.5T) F22,F23(4WD) | 88/10~ | Wheel Hub FRONT INNER DRIVE SHAFT |
| 03903 4901 | 40232-31G00 | 57 x 79 x 9 x 13.5 | ATLAS / CABSTAR (1T~1.5T) F22(4WD) | 88/10~92/ | Wheel Hub FRONT |
| 03903 3147 | 40232-31G00 | 57 x 79 x 9 x 13.5 | ATLAS / CABSTAR (1T~1.5T) F23(4WD) | 92/1~ | Wheel Hub FRONT |
| 03903 5657 | 40232-01G00 | 54 x 75.3 x 12 x 18 | ATLAS / CABSTAR (1T~1.5T) F23 WITHOUT ABS(2WD) | 99/6~ | Wheel Hub FRONT |
| 03903 3505 | 40232-01G00 | 54 x 75.3 x 12 x 18 | ATLAS / CABSTAR (1T~1.5T) F22(2WD) | 88/10~92/ | Wheel Hub FRONT |
| 03903 2377 | 40232-B9500 | 54 x 65 x 13 | ATLAS / CABSTAR (1T~1.5T) F22 | 80/2~88/10 | Wheel Hub FRONT |
| 03903 5435 | 32114-Y4000 | 30 x 45 x 8 | ATLAS / CABSTAR (1T~1.5T) F23 NA16S,NA20S,KA20DE,TD23,TD25 | 92/1~ | Transmission FRONT COVER |
| 03903 1207 | 43252-T3200 | 38 x 62 x 11 | ATLAS / CABSTAR (1T~1.5T) F22 Z20,SD25,TD27 (ST) | 82/2~90/7 | Wheel Hub REAR INNER |
| 03903 5439 | 32113-86401 | 28 x 40 x 8 | ATLAS / CABSTAR (1T~1.5T) F22 RS5W81A | 82/2~90/7 | Transmission FRONT COVER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5357 | 40232-3S600 | 54 x 65 x 10 x 15 | ATLAS / CABSTAR (1T~1.5T) F23 ABS(2WD) | 99/6~ | Wheel Hub FRONT |
| 03903 2599 | 43252-VH300 | 40 x 65 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 QD32(ABS) (ST) | 99/6~ | Wheel Hub REAR INNER |
| 03903 3885 | 32114-Y4000 | 30 x 45 x 8 | ATLAS / CABSTAR (1T~1.5T) F22 NA20S,TD23 | 90/7~92/ | Transmission FRONT COVER |
| 03903 5919 | 32114-Y4000 | 30 x 45 x 8 | ATLAS / CABSTAR (1T~1.5T) F22 RS5W71B,R4W71B,R4W71C,RS5W71C,Z16,Z20,TD23 | 82/2~90/7 | Transmission FRONT COVER |
| 03903 1851 | 32113-86401 | 28 x 40 x 8 | ATLAS / CABSTAR (1T~1.5T) F22 TD27 (F5) | 90/7~92/ | Transmission FRONT COVER |
| 03903 4279 | 43232-01J10 | 67 x 90 x 12.5 x 20 | ATLAS / CABSTAR (1T~1.5T) F23 KA20DE,QD32 ABS (ST) | 96/6~ | Wheel Hub REAR OUTER |
| 03903 6299 | 43252-T6200 | 33 x 44 x 7 | ATLAS / CABSTAR (1T~1.5T) F22,F23 (WT) | 82/2~ | Wheel Hub REAR OUTER |
| 03903 2257 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD27 (ALL) | 99/6~ | Wheel Hub REAR OUTER |
| 03903 3695 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 KA20DE(1.5T) WITHOUT ABS (ST) | 99/6~ | Wheel Hub REAR OUTER |
| 03903 1533 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 QD32 WITHOUT ABS (ST) | 95/6~ | Wheel Hub REAR OUTER |
| 03903 4723 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD25(ST) (ALL) | 95/6~ | Wheel Hub REAR OUTER |
| 03903 2565 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD25,QD32 (ST) | 95/6~ | Wheel Hub REAR OUTER |
| 03903 6507 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1T) (ST) | 95/6~ | Wheel Hub REAR OUTER |
| 03903 1029 | 43232-01G00 | 50 x 70 x 12 x 17 | ATLAS / CABSTAR (1T~1.5T) F23 KA20DE(1.3T) (ST) | 99/6~ | Wheel Hub REAR OUTER |
| 03903 1715 | 43232-01G00 | 50 x 70 x 12 x 17 | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA16S,TD23 (ST) | 90/7~95/6 | Wheel Hub REAR OUTER |
| 03903 3529 | 32113-86401 | 28 x 40 x 8 | ATLAS / CABSTAR (1T~1.5T) F23 TD27 | 92/1~97/8 | Transmission FRONT COVER |
| 03903 4139 | 43232-B5000 | 50 x 67 x 11 | ATLAS / CABSTAR (1T~1.5T) F22 Z16,SD23,TD23 9ST) | 82/2~90/7 | Wheel Hub REAR OUTER |
| 03903 2883 | 43232-01G00 | 50 x 70 x 12 x 17 | ATLAS / CABSTAR (1T~1.5T) F23 TD25 (ST) | 95/6~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1423 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD2791.5T) (ST) | 92/1~97/8 | Wheel Hub REAR OUTER |
| 03903 5057 | 43232-01G00 | 50 x 70 x 12 x 17 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1.25T) (ST) | 95/6~ | Wheel Hub REAR OUTER |
| 03903 3629 | 43232-01G00 | 50 x 70 x 12 x 17 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S(1T) (ST) | 92/1~95/6 | Wheel Hub REAR OUTER |
| 03903 5457 | 43252-VH300 | 40 x 65 x 11 | ATLAS / CABSTAR (1T~1.5T) F23 KA20DE(1.5T)ABS (ST) | 99/6~ | Wheel Hub REAR INNER |
| 03903 2017 | 43232-01G00 | 50 x 70 x 12 x 17 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(1T) (ST) | 99/6~ | Wheel Hub REAR OUTER |
| 03903 6525 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F22 Z20,SD25,TD27 (ST) | 82/2~90/7 | Wheel Hub REAR OUTER |
| 03903 4241 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F22,F23 NA20S,TD27 (ST) | 90/7~95/6 | Wheel Hub REAR OUTER |
| 03903 5273 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 NA20S (1.5T) | 92/1~99/6 | Wheel Hub REAR OUTER |
| 03903 2657 | 09061-0001P | 68 x 82 x 7 | ATLAS / CABSTAR (1T~1.5T) F23 TD27(1T) (ST) | 92/1~97/8 | Wheel Hub REAR OUTER |
| 03903 5873 | 32136-02T00 | 50 x 74 x 12 | ATLAS / CABSTAR (2T~3T) H40 FD35# | 86/11~92/ | Transmission (M/T) REAR EXTENSION |
| 03903 5297 | 32136-02T00 | 50 x 74 x 12 | ATLAS / CABSTAR (2T~3T) H41 FD42(2WD),FD46 | 91/10~95/ | Transmission (M/T) REAR EXTENSION |
| 03903 3059 | 32136-Z5000 | 58 x 75 x 9 | ATLAS / CABSTAR (2T~3T) H40 6 SPEED | 81/12~86/ 11 | Transmission (M/T) REAR EXTENSION |
| 03903 4701 | 32136-01J00 | 44 x 62 x 10 | ATLAS / CABSTAR (2T~3T) H41 FD42(4WD) | 92/11~95/ | Transmission (M/T) REAR EXTENSION |
| 03903 5485 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (2T~3T) H41 BD30,ED35 | 91/10~95/ | Transmission (M/T) REAR EXTENSION |
| 03903 1497 | 33216-33G01 | 40 x 75 x 12 x 20 | ATLAS / CABSTAR (2T~3T) H41(4WD) | 92/11~95/ | Transfer FRONT COVER |
| 03903 2707 | 13207-81W00 | | ATLAS / CABSTAR (2T~3T) H40 Z20# | 81/12~90/ 6 | Engine VALVE STEM SEAL |
| 03903 4381 | 33142-01J01 | 50 x 72.5 x 12 x 19.5 | ATLAS / CABSTAR (2T~3T) H41(4WD) | 92/11~95/ | Transfer REAR COVER |
| 03903 6225 | 38189-J2000 | 42 x 72.5 x 12 | ATLAS / CABSTAR (2T~3T) H40 HH FINAL DRIVE | 81/12~90/ 11 | Final Drive PINION |
| 03903 4089 | 33111-01J00 | 50 x 72 x 12 | ATLAS / CABSTAR (2T~3T) H41(4WD) | 92/11~95/ | Transfer FRONT OIL PUMP |
| 03903 1841 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (2T~3T) H40 EXCEPT | 86/11~92/ | Transmission (M/T) REAR EXTENSION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | | FD35# | | |
| 03903 6009 | 32136-J6500 | 40 x 62 x 11 | ATLAS / CABSTAR (2T~3T) H40 5 SPEED | 81/12~86/ 11 | Transmission (M/T) REAR EXTENSION |
| 03903 2357 | 32219-Z5003 | 32 x 45 x 8 | ATLAS / CABSTAR (2T~3T) H41 FD46 | 91/10~95/ | Transmission (M/T) FRONT COVER |
| 03903 3121 | 32219-Z5003 | 32 x 45 x 8 | ATLAS / CABSTAR (2T~3T) H40 FD35# | 86/11~91/ | Transmission (M/T) FRONT COVER |
| 03903 6045 | 13207-V1700 | | ATLAS / CABSTAR (2T~3T) H40,H41 BD30 | 89/5~95/ | Engine VALVE STEM SEAL |
| 03903 2653 | 13207-42L00 | | ATLAS / CABSTAR (2T~3T) H40 NA20S | 90/6~92/ | Engine VALVE STEM SEAL |
| 03903 5595 | 13207-Z5001 | | ATLAS / CABSTAR (2T~3T) H40,H41 ED33,ED35 | 89/5~95/ | Engine VALVE STEM SEAL |
| 03903 3567 | 38189-61500 | 56 x 72 x 9 | ATLAS / CABSTAR (2T~3T) H40 HJ FINAL DRIVE | 81/12~90/ 10 | Final Drive PINION |
| 03903 6413 | 12279-T7202 | 80 x 100 x 10 | ATLAS / CABSTAR (2T~3T) H40 SD25 | 81/12~86/ 11 | Engine CRANK SHAFT REAR |
| 03903 1235 | 13207-Z5001 | | ATLAS / CABSTAR (2T~3T) H40,H41 ED33#,FD35#,FD42,FD46 | 81/12~95/ | Engine VALVE STEM SEAL |
| 03903 4673 | 13207-V1700 | | ATLAS / CABSTAR (2T~3T) H40 TD27 | 86/11~90/ 6 | Engine VALVE STEM SEAL |
| 03903 5121 | 13510-43G00 | 58 x 80 x 10 | ATLAS / CABSTAR (2T~3T) H40 TD27 | 86/11~90/ 6 | Engine CRANK SHAFT FRONT |
| 03903 5111 | 43253-T9310 | 96.9 x 101.7 x 2.4 | ATLAS / CABSTAR (2T~3T) H40 FD33T,FD35T (TURBO) | 81/12~92/ | Wheel Hub REAR O-RING |
| 03903 3233 | 12279-0T001 | 108 x 135 x 9 | ATLAS / CABSTAR (2T~3T) H41 FD42,FD46 | 91/10~86/ 11 | Engine CRANK SHAFT REAR |
| 03903 4469 | 12279-58S00 | 80 x 100 x 10 | ATLAS / CABSTAR (2T~3T) H40 NA20S | 90/6~92/ | Engine CRANK SHAFT REAR |
| 03903 1973 | 12279-01T00 | 105 x 135 x 9 | ATLAS / CABSTAR (2T~3T) H41 ED35 | 91/10~92/ | Engine CRANK SHAFT REAR |
| 03903 5671 | 12279-01T00 | 105 x 135 x 9 | ATLAS / CABSTAR (2T~3T) H40 ED33,ED35,FD33#,FD35# | 81/12~90/ 6 | Engine CRANK SHAFT REAR |
| 03903 2221 | 12279-43G02 | 86 x 100 x 10 | ATLAS / CABSTAR (2T~3T) H40,H41 BD30 | 89/5~92/ | Engine CRANK SHAFT REAR |
| 03903 3527 | 12279-43G02 | 86 x 100 x 10 | ATLAS / CABSTAR (2T~3T) H40 TD27 | 86/11~90/ 6 | Engine CRANK SHAFT REAR |
| 03903 5961 | 12279-R4611 | 80 x 100 x 13 | ATLAS / CABSTAR (2T~3T) H40 Z20# | 81/12~90/ 6 | Engine CRANK SHAFT REAR |
| 03903 4845 | 12278-T9000 | 62 x 85 x 12.5 | ATLAS / CABSTAR (2T~3T) H41 ED35,FD42,FD46 | 91/10~86/ 11 | Engine CRANK SHAFT FRONT |
| 03903 3751 | 13510-43G00 | 58 x 80 x 10 | ATLAS / CABSTAR (2T~3T) H40,H41 BD30 | 89/5~90/8 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2733 | 38189-J2011 | 42 x 72.5 x 13 x 21 | ATLAS / CABSTAR (2T~3T) H40,H41 HH FINAL DRIVE | 90/11~92/ | Final Drive PINION |
| 03903 4909 | 13043-T7200 | 58 x 80 x 12 | ATLAS / CABSTAR (2T~3T) H40 SD25 | 81/12~92/ | Engine CRANK SHAFT FRONT |
| 03903 2207 | 13042-A8601 | 48 x 70 x 9 | ATLAS / CABSTAR (2T~3T) H40 Z20#,NA20S | 81/12~92/ | Engine CRANK SHAFT FRONT |
| 03903 4829 | 48029-04100 | 17 x 31 x 7 | ATLAS / CABSTAR (2T~3T) H40 Z20#,TD27,BD30,ED33 | 89/5~90/6 | Steering WORM |
| 03903 5645 | 48029-04100 | 17 x 31 x 7 | ATLAS / CABSTAR (2T~3T) H40 LONG BODY 2T (R5,RA) | 82/5~86/11 | Steering WORM |
| 03903 4789 | 48040-82100 | 35 x 48 x 8 | ATLAS / CABSTAR (2T~3T) H40 Z20#,TD27,BD30,ED33 | 89/5~90/6 | Steering SECTOR SHAFT |
| 03903 5895 | 48040-82100 | 35 x 48 x 8 | ATLAS / CABSTAR (2T~3T) H40 2T | 81/12~89/5 | Steering SECTOR SHAFT |
| 03903 4529 | 38189-Z5004 | 60 x 114 x 8 x 12.5 | ATLAS / CABSTAR (2T~3T) H41 HK FINAL DRIVE | 91/10~95/ | Final Drive PINION |
| 03903 4573 | 38189-T8011 | 56 x 72 x 11 x 18 | ATLAS / CABSTAR (2T~3T) H40,H41 HJ FINAL DRIVE | 90/10~92/ | Final Drive PINION |
| 03903 3417 | 12278-T9000 | 62 x 85 x 12.5 | ATLAS / CABSTAR (2T~3T) H40 ED33,ED35,FD33#,FD35# | 81/12~92/ | Engine CRANK SHAFT FRONT |
| 03903 2187 | 13207-V1700 | | ATLAS / CABSTAR (2T~3T) H40 SD25 | 81/12~86/11 | Engine VALVE STEM SEAL |
| 03903 6205 | 32113-86401 | 28 x 40 x 8 | ATLAS / CABSTAR (2T~3T) H40 EXCEPT FD35# | 86/11~92/ | Transmission (M/T) FRONT COVER |
| 03903 4519 | 32113-86401 | 28 x 40 x 8 | ATLAS / CABSTAR (2T~3T) H41 BD30 | 91/10~95/ | Transmission (M/T) FRONT COVER |
| 03903 6459 | 32113-86401 | 28 x 40 x 8 | ATLAS / CABSTAR (2T~3T) H40 5 SPEED | 81/12~86/11 | Transmission (M/T) FRONT COVER |
| 03903 2521 | 43253-76000 | 89.4 x 95.6 x 3.1 | ATLAS / CABSTAR (2T~3T) H40 EXCEPT FD33T,FD35T | 81/12~92/ | Wheel Hub REAR O-RING |
| 03903 4163 | 43254-0T000 | 51 x 64 x 9.5 | ATLAS / CABSTAR (2T~3T) H41 | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 2993 | 43252-T9310 | 43 x 52 x 10.3 | ATLAS / CABSTAR (2T~3T) H40 FD33T,FD35T (TURBO) | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 6529 | 43252-T9300 | 40 x 49 x 10.3 | ATLAS / CABSTAR (2T~3T) H40 AMBULANCE | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 5597 | 43252-T9300 | 40 x 49 x 10.3 | ATLAS / CABSTAR (2T~3T) H40 HIGH DECK | 81/12~92/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1217 | 43252-T9300 | 40 x 49 x 10.3 | ATLAS / CABSTAR (2T~3T) H40 3T | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 5723 | 40227-0T000 | 77 x 91 x 6 x 10 | ATLAS / CABSTAR (2T~3T) H41(2WD) | 91/10~95/ | Wheel Hub FRONT |
| 03903 5567 | 43252-J2000 | 38 x 47 x 10 | ATLAS / CABSTAR (2T~3T) H40 LOW DECK | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 5945 | 43252-J2000 | 38 x 47 x 10 | ATLAS / CABSTAR (2T~3T) H40 2T,2.75T | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 1871 | 43232-0T000 | 80 x 101 x 10.5 | ATLAS / CABSTAR (2T~3T) H41 | 91/10~95/ | Wheel Hub REAR INNER |
| 03903 4201 | 43252-82100 | 80 x 105 x 13 | ATLAS / CABSTAR (2T~3T) H40 (WT) | 81/12~92/ | Wheel Hub REAR INNER |
| 03903 2461 | 43213-76000 | 78.4 x 95 x 8 | ATLAS / CABSTAR (2T~3T) H40 (ST) | 81/12~92/ | Wheel Hub REAR INNER |
| 03903 2677 | 40227-0T300 | 97.5 x 111 x 6 x 10.9 | ATLAS / CABSTAR (2T~3T) H41(4WD) | 92/11~95/ | Wheel Hub FRONT |
| 03903 1859 | 32219-Z5003 | 32 x 45 x 8 | ATLAS / CABSTAR (2T~3T) H40 6 SPEED | 81/12~86/ 11 | Transmission (M/T) FRONT COVER |
| 03903 1081 | 40227-J5110 | 60 x 82 x 7 | ATLAS / CABSTAR (2T~3T) H40 | 81/12~92/ | Wheel Hub FRONT |
| 03903 2181 | 43252-J2000 | 38 x 47 x 10 | ATLAS / CABSTAR (2T~3T) H40 VACUUM TRUCK | 81/12~92/ | Wheel Hub REAR OUTER |
| 03903 4511 | 49297-WA025 | | AVENIR W11 | 98/8~00/1 0 | Steering (P/S) GEAR HOUSING KIT |
| 03903 2551 | 33111-56E00 | 60 x 78 x 9 | AVENIR W10 SR20DET | 95/8~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3767 | 48125-60R00 | 16 x 26 x 7 | AVENIR W10 | 90/5~93/ | Steering WORM |
| 03903 2493 | 49297-WA026 | | AVENIR W11 | 00/10~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3207 | 38342-06R01 | 52 x 78 x 9 | AVENIR W11 QR20DE(F4) | 02/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5417 | 38342-8E001 | 32.5 x 56 x 8 x 14 | AVENIR W11 MCVT | 02/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1059 | 49365-10V26 | | AVENIR W10,W11 | 90/5~ | Steering (P/S) PINION GEAR KIT |
| 03903 5449 | 38342-8E001 | 32.5 x 56 x 8 x 14 | AVENIR W11 MCVT(2WD) | 00/5~02/8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4611 | 49297-5Y085 | | AVENIR W10 | 90/5~98/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1289 | 38342-8E000 | 40 x 52 x 8 x 13 | AVENIR W11 QG18DE(F4) | 0/7 | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5679 | 33111-06R00 | 52 x 66 x 9 | AVENIR W11 MCVT(4WD) | 00/5~02/8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4831 | 33111-31X00 | 60 x 76 x 9 | AVENIR W10 SR20DE(4WD) | 95/8~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2155 | 33111-56E00 | 60 x 78 x 9 | AVENIR W11 SR20DE#(F4) | 98/8~02/8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2179 | 38342-31X01 | 33 x 56 x 8 x 13 | AVENIR W11 CVT | 98/8~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4047 | 13042-D0100 | 34 x 48 x 8 | AVENIR W10 CD20# | 90/5~98/ | Engine CAM SHAFT FRONT |
| 03903 4369 | 12279-85Y00 | 84 x 104 x 11 | AVENIR W10 EXCEPT CD20# | 90/5~98/ | Engine CRANK SHAFT REAR |
| 03903 1711 | 38342-31X01 | 33 x 56 x 8 x 13 | AVENIR W11 CD20ET(F4) | 98/8~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2965 | 38342-31X01 | 33 x 56 x 8 x 13 | AVENIR W10 SR18D#,SR20DE(2WD),CD 20# | 90/5~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3503 | 33111-31X00 | 60 x 76 x 9 | AVENIR W10 (4WD) | 90/10~95/ 8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2189 | 13510-V7202 | 40 x 52 x 7 | AVENIR W11 QG18DE | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 5023 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W11 QG18DE(F4) | 98/8~00/7 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2383 | 13207-D0101 | | AVENIR CD20#,QG18DE | 90/5~ | Engine VALVE STEM SEAL |
| 03903 1295 | 13207-D4200 | | AVENIR SR20DE#(IN.) | 90/5~ | Engine VALVE STEM SEAL |
| 03903 2613 | 13207-D4200 | | AVENIR SR18D#,QR20DE | 90/5~ | Engine VALVE STEM SEAL |
| 03903 3069 | 13207-D0101 | | AVENIR SR20DE#(EX.) | 90/5~ | Engine VALVE STEM SEAL |
| 03903 1055 | 12279-AD205 | 84 x 104 x 8.5 | AVENIR W11 | 98/8~ | Engine CRANK SHAFT REAR |
| 03903 2715 | 12279-AD205 | 84 x 104 x 8.5 | AVENIR W10..CD20# | 97/10~98/ | Engine CRANK SHAFT REAR |
| 03903 1495 | 13510-2J200 | 46 x 58 x 7 | AVENIR W11 QR20DE | 02/8~ | Engine CRANK SHAFT FRONT |
| 03903 6329 | 13510-2J200 | 46 x 58 x 7 | AVENIR W11 SR20DE# | 00/5~ | Engine CRANK SHAFT FRONT |
| 03903 1041 | 13042-D0100 | 34 x 48 x 8 | AVENIR W11 CD20ET | 98/8~00/ | Engine CAM SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5721 | 13510-V7202 | 40 x 52 x 7 | AVENIR W11 CD20ET | 00/1~00/7 | Engine CRANK SHAFT FRONT |
| 03903 2945 | 13510-53J00 | 46 x 58 x 7 | AVENIR W11 SR20DE# | 98/8~00/5 | Engine CRANK SHAFT FRONT |
| 03903 1661 | 13510-53J00 | 46 x 58 x 7 | AVENIR W10 SR18D#,SR20DE# | 90/5~98/ | Engine CRANK SHAFT FRONT |
| 03903 4551 | 13042-16V00 | 40 x 52 x 7 | AVENIR W11 QG18DE | 98/8~00/7 | Engine CRANK SHAFT FRONT |
| 03903 6469 | 13042-16V00 | 40 x 52 x 7 | AVENIR W11 CD20ET | 98/8~00/1 | Engine CRANK SHAFT FRONT |
| 03903 5053 | 13042-16V00 | 40 x 52 x 7 | AVENIR W10 GA16DS,CD20# | 90/5~98/ | Engine CRANK SHAFT FRONT |
| 03903 3067 | 13042-16A11 | 36 x 50 x 8 | AVENIR W10 CD20# | 90/5~98/ | Engine CAM SHAFT REAR |
| 03903 3811 | 12279-85Y00 | 84 x 104 x 11 | AVENIR W10 CD20# | 90/5~97/10 | Engine CRANK SHAFT REAR |
| 03903 6175 | 43252-H1000 | 41 x 56 x 7 | AVENIR W10 (4WD) | 90/10~93/1 | Wheel Hub REAR |
| 03903 3453 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AVENIR W10 GA16DS(4WD) | 90/10~93/1 | Mission & Differential (M/T) MISSION CASE |
| 03903 6521 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W10 SR18D#,SR20DE,CD20 | 90/5~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4007 | 38342-D2100 | 40 x 56 x 65 x 20 | AVENIR W10 GA16DS(2WD) | 90/5~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3959 | 32113-M8000 | 25 x 40 x 8 | AVENIR W10,W11 | 90/5~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5871 | 40232-33P00 | 56 x 76 x 6 x 11 | AVENIR W11 SR20DE(4WDDORF4),SR20 DET | 98/8~98/12 | Wheel Hub REAR IN. & OUT. |
| 03903 1597 | 43232-87N00 | 47 x 67 x 10 x 16 | AVENIR W10 SR20DE#(4WD) | 93/1~98/ | Wheel Hub REAR OUTER |
| 03903 2593 | 43252-87N10 | 30 x 55 x 9 | AVENIR W10 SR20DE#(4WD) | 93/1~98/ | Wheel Hub REAR INNER |
| 03903 2109 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AVENIR W10 SR18DE,SR20DE NON SLIP DIFF. | 93/1~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5441 | 43252-H1000 | 41 x 56 x 7 | AVENIR W10 GA16DS(4WD) | 93/1~98/ | Wheel Hub REAR |
| 03903 4263 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AVENIR W10 4WD | 93/1~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2427 | 40232-33P00 | 56 x 76 x 6 x 11 | AVENIR W11 | 98/8~ | Wheel Hub FRONT IN. & OUT. |
| 03903 2271 | 40232-33P00 | 56 x 76 x 6 x 11 | AVENIR W10 SR20DE#(4WD) | 95/8~98/ | Wheel Hub FRONT IN. & OUT. |
| 03903 6369 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W10 GA16DS,CD20 | 90/5~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5169 | 40232-51E10 | 56 x 72 x 8 x 11.5 | AVENIR W10 GE16DS(4WD) | 95/8~98/ | Wheel Hub FRONT IN. & OUT. |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2061 | 13207-53Y00 | | AVENIR GA16DS | 90/5~ | Engine VALVE STEM SEAL |
| 03903 5781 | 40232-51E10 | 56 x 72 x 8 x 11.5 | AVENIR W10 4WD | 90/5~95/8 | Wheel Hub FRONT IN. & OUT. |
| 03903 3051 | 40232-51E10 | 56 x 72 x 8 x 11.5 | AVENIR W10 2WD | 90/5~98/ | Wheel Hub FRONT IN. & OUT. |
| 03903 6345 | 40232-33P00 | 56 x 76 x 6 x 11 | AVENIR W11 EXCEPT SR20DE(4WDDORF4),SR20 DET | 98/8~98/12 | Wheel Hub REAR |
| 03903 3155 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AVENIR W10 4WD(WITHOUT TURBO) | 90/10~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6049 | 38342-8E002 | 41.5 x 90 x 8 x 12 | AVENIR W11 LIMITED SLIP DIFF. | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 3027 | 38342-8E000 | 40 x 52 x 8 x 13 | AVENIR W11 QG18DE | 0/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 3459 | 38342-8E000 | 40 x 52 x 8 x 13 | AVENIR W11 MCVT | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6291 | 38342-81X03 | 42 x 90 x 12 x 22.1 | AVENIR W11 SR20DET | 00/9~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6455 | 38342-81X00 | 39 x 59 x 8 x 13.7 | AVENIR W11 QR20DE(F4) | 02/8~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2801 | 38342-56E00 | 43 x 90 x 12 x 21 | AVENIR W11 SE20DE(F4) | 98/8~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 4725 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W11 | 98/8~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5445 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AVENIR W11 LIMITED SLIP DIFF. | 98/8~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 6423 | 38342-D2100 | 40 x 56 x 65 x 20 | AVENIR W10 GA16DS(2WD) | 90/5~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3317 | 38342-31X02 | 42 x 90 x 9.5 x 13 | AVENIR W10 2WD(NON SLIP DIFF.) | 93/1~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5683 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W11 QG18DE,CD20ET(F4) | 98/8~00/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 3007 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W11 CVT | 98/8~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 3481 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W10 2WD(WITHOUT TURBO) | 90/5~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4051 | 38342-31X00 | 40 x 56 x 8 x 13.5 | AVENIR W11 | 98/8~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2589 | 38342-74N00 | 40 x 56 x 11.3 x 24 | AVENIR W10 CD20 | 90/5~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2001 | 33111-06R00 | 52 x 66 x 9 | AVENIR W10 (4WD) | 93/1~98/ | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1243 | 33111-06R00 | 52 x 66 x 9 | AVENIR W10 GA16DS(4WD) | 90/10~93/1 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1389 | 38342-31X01 | 33 x 56 x 8 x 13 | AVENIR W10 SR18D#,SR20DE | 90/5~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2253 | 38342-56E00 | 43 x 90 x 12 x 21 | AVENIR W10,W11 SR20DET | 95/8~00/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 2697 | 38342-M8001 | 40 x 56 x 8 | BE-1 BK10 | 87/1~88/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1197 | 38342-M8001 | 40 x 56 x 8 | BE-2 BK10 | 87/1~88/ | Mission & Differential (A/T) MISSION CASE |
| 03903 2917 | 13207-D0101 | | BE-3 BK10 MA10S | 87/1~88/ | Engine VALVE STEM SEAL |
| 03903 2823 | 12279-01B10 | 75 x 94 x 10 | BE-4 BK10 MA10S | 87/1~88/ | Engine CRANK SHAFT REAR |
| 03903 5187 | 13510-01B00 | 38 x 54 x 7 | BE-5 BK10 MA10S | 87/1~88/ | Engine CRANK SHAFT FRONT |
| 03903 5191 | 13510-01B00 | 38 x 54 x 7 | BE-6 BK10 MA10S | 87/1~88/ | Engine CAM SHAFT |
| 03903 4227 | 40232-M0215 | 48 x 62 x 7 | BE-7 BK10 | 87/1~88/ | Wheel Hub FRONT GREASE SEAL |
| 03903 2269 | 38342-01B00 | 38 x 58 x 11 x 17 | BE-8 BK10 | 87/1~88/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4117 | 40227-M3005 | 48 x 62 x 13 | BE-9 BK10 | 87/1~88/ | Wheel Hub FRONT DUST SEAL |
| 03903 5903 | 43252-01B00 | 38 x 50.3 x 10 | BE-10 BK10 | 87/1~88/ | Wheel Hub REAR |
| 03903 3791 | 32113-01B00 | 20 x 35 x 8 | BE-11 BK10 | 87/1~88/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3907 | 48125-11A00 | 17.5 x 32 x 6 | BE-12 BK10 | 87/1~88/ | Steering GEAR |
| 03903 4037 | 38342-01B00 | 38 x 58 x 11 x 17 | BE-13 BK10 | 87/1~88/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4643 | 49365-10V26 | | BLUEBIRD (FWD) U12,U13,U14 | 87/9~01/ | Steering (P/S) PINION GEAR KIT |
| 03903 3981 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD (FWD) U11 CA16S | 85/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2393 | 49297-10V85 | | BLUEBIRD (FWD) U13 KA24DE | 93/8~96/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 2939 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E | 83/10~85/8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4531 | 38342-8E001 | 32.5 x 56 x 8 x 14 | BLUEBIRD (FWD) U18 SR20#(CVT) | 00/5~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1037 | 48125-01E00 | 17 x 30 x 8 | BLUEBIRD (FWD) U11 | 83/9~87/ | Steering (P/S) GEAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4385 | 49297-10V25 | | BLUEBIRD (FWD) U12 | 87/9~91/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1085 | 49297-10V86 | | BLUEBIRD (FWD) U13 (2WD).SR18DE,(2WD).SR20DE,(2WD).CD20,GA16DS | 91/9~96/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4087 | 38342-8E000 | 40 x 52 x 8 x 13 | BLUEBIRD (FWD) U14 QG18D# | 00/5~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3081 | 49297-10V87 | | BLUEBIRD (FWD) U13 (4WD0.SR18DE,(4WD).SR20DE,(4WD).CD20,SR20DET | 91/9~96/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4487 | 33111-31X00 | 60 x 76 x 9 | BLUEBIRD (FWD) U14 SR18DE,SR20DE | 97/9~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5757 | 49297-AA085 | | BLUEBIRD (FWD) U14 (4WD).SR18DE,(4WD).SR20E | 96/1~01/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 5703 | 33111-56E00 | 60 x 78 x 9 | BLUEBIRD (FWD) U12 SR20D(4WD),SR20DT | 89/10~91/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1233 | 49277-42L00 | | BLUEBIRD (FWD) U12 | 87/9~91/ | Steering (P/S) PINION SEAL SET |
| 03903 2243 | 13042-D0100 | 34 x 48 x 8 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E#,CA20S,VG20# | 83/10~90/ | Engine CAM SHAFT |
| 03903 4523 | 13042-D0100 | 34 x 48 x 8 | BLUEBIRD (FWD) U12 CA16S,CA18I | 87/9~91/ | Engine CAM SHAFT |
| 03903 2527 | 13042-D0100 | 34 x 48 x 8 | BLUEBIRD (FWD) U13 CD20 | 91/9~96/ | Engine CAM SHAFT |
| 03903 5973 | 13042-D0100 | 34 x 48 x 8 | BLUEBIRD (FWD) U14 CD20# | 96/1~01/ | Engine CAM SHAFT |
| 03903 5991 | 49297-86A26 | | BLUEBIRD (FWD) U14 (2WD).SR18DE,(2WD).SR20DE,CD20DE,QG18# | 96/1~01/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4141 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U14 QG18D# | 98/9~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1989 | 13207-D0101 | | BLUEBIRD (FWD) U11 VG20#(IN.) | 84/10~87/ | Engine VALVE STEM SEAL |
| 03903 6023 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U11 CA18DT | 85/8~87/9 | Engine CAM SHAFT |
| 03903 1101 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD (FWD) U12 CA16S | 87/9~91/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4707 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U11...CA18ET,CA20S,VG20#,LD20 | 83/10~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1759 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U11...CA18# | 85/8~90/ | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3891 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U12 (2WD) | 87/9~89/10 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5565 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U12 CA18I,LD20,SR20D(2WD) | 89/10~91/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1541 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) WU12 | 91/2~91/12 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4429 | 33111-31X00 | 60 x 76 x 9 | BLUEBIRD (FWD) U12 SR18DI(4WD) | 89/10~91/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2709 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U13 GA16DS | 91/9~96/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1045 | 33111-31X00 | 60 x 76 x 9 | BLUEBIRD (FWD) U14 F4(4WD) | 96/1~97/9 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5067 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U12 SR18DI(2WD) | 89/10~91/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2349 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U13 SR18DE,SR20DE,CD20 | 91/9~96/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2485 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U14 CVT | 97/9~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6335 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U14 CD20# | 96/1~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2501 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U14 SR18DE(XE,LEGRN),SR20DE(LEGRN) | 96/1~98/9 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5981 | 33111-56E00 | 60 x 78 x 9 | BLUEBIRD (FWD) U12 (4WD) | 87/9~89/10 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2767 | 33111-56E00 | 60 x 78 x 9 | BLUEBIRD (FWD) U13 SR20DET | 91/9~96/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4797 | 33111-31X00 | 60 x 76 x 9 | BLUEBIRD (FWD) U13 SR18DE(SSSA,ARXLA) | 91/9~96/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3785 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U13 KA24DE | 93/8~96/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3661 | 13207-81W00 | | BLUEBIRD (FWD) U11 VG20#(EX.) | 84/10~87/ | Engine VALVE STEM SEAL |
| 03903 5031 | 38342-8E002 | 41.5 x 90 x 8 x 12 | BLUEBIRD (FWD) U14 SR18DE,SR20DE | 01/4~01/ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1819 | 13207-D0101 | | BLUEBIRD (FWD) U11 CA16S,18S,18E#,20S | 83/10~87/ | Engine VALVE STEM SEAL |
| 03903 2983 | 38342-01E00 | 33 x 56 x 48.5 x 24.5 | BLUEBIRD (FWD) U13 CD20 | 91/9~96/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4299 | 13207-D0101 | | BLUEBIRD (FWD) U12 CA16S,18I | 87/9~91/ | Engine VALVE STEM SEAL |
| 03903 5065 | 13207-D0101 | | BLUEBIRD (FWD) U13 CD20 | 91/9~95/ | Engine VALVE STEM SEAL |
| 03903 1675 | 13207-D0101 | | BLUEBIRD (FWD) U13 KA24DE | 93/8~95/ | Engine VALVE STEM SEAL |
| 03903 1591 | 13207-D0101 | | BLUEBIRD (FWD) U13 SR20DET(EX.) | 91/9~93/8 | Engine VALVE STEM SEAL |
| 03903 1761 | 13207-D0101 | | BLUEBIRD (FWD) U14 CD20 | 96/1~01/ | Engine VALVE STEM SEAL |
| 03903 4753 | 13207-21002 | | BLUEBIRD (FWD) U11 LD20 | 83/10~85/ 12 | Engine VALVE STEM SEAL |
| 03903 5375 | 13207-81W00 | | BLUEBIRD (FWD) U11 LD20 | 85/12~87/ | Engine VALVE STEM SEAL |
| 03903 4485 | 12279-58S00 | 80 x 100 x 10 | BLUEBIRD (FWD) U11,U12 LD20 | 83/10~91/ | Engine CRANK SHAFT REAR |
| 03903 6159 | 13207-81W00 | | BLUEBIRD (FWD) U12 LD20 | 87/9~91/ | Engine VALVE STEM SEAL |
| 03903 5845 | 13207-D4200 | | BLUEBIRD (FWD) U11 CA18DT | 85/8~87/ | Engine VALVE STEM SEAL |
| 03903 5163 | 13207-D4200 | | BLUEBIRD (FWD) U12 CA18D,18DT | 87/9~89/1 0 | Engine VALVE STEM SEAL |
| 03903 4335 | 13207-D4200 | | BLUEBIRD (FWD) U12 SR18D#,SR20D# | 89/10~91/ | Engine VALVE STEM SEAL |
| 03903 6485 | 13207-D4200 | | BLUEBIRD (FWD) U13 SR18D#,SR20D# EXCEPT SR20DET(EX.) | 89/10~95/ | Engine VALVE STEM SEAL |
| 03903 2809 | 13207-D4200 | | BLUEBIRD (FWD) U14 SR18DE,SR20DE | 96/1~01/ | Engine VALVE STEM SEAL |
| 03903 6077 | 13207-D4200 | | BLUEBIRD (FWD) U14 SR20VE | 97/9~01/ | Engine VALVE STEM SEAL |
| 03903 4447 | 13207-D4200 | | BLUEBIRD (FWD) WU12(IN.) | 91/2~91/1 2 | Engine VALVE STEM SEAL |
| 03903 5543 | 13207-53Y00 | | BLUEBIRD (FWD) U13 GA16DS | 91/9~95/ | Engine VALVE STEM SEAL |
| 03903 6163 | 13207-D0101 | | BLUEBIRD (FWD) WU12(EX.) | 91/2~91/1 2 | Engine VALVE STEM SEAL |
| 03903 5773 | 13510-53J00 | 46 x 58 x 7 | BLUEBIRD (FWD) U14 SR18DE,SR20DE | 96/1~01/ | Engine CRANK SHAFT FRONT |
| 03903 3877 | 13510-60U00 | 50 x 65 x 8 | BLUEBIRD (FWD) U12 LD20 | 87/9~91/ | Engine CAM SHAFT |
| 03903 1103 | 13510-16A00 | 33 x 47 x 8 | BLUEBIRD (FWD) U11 CA16S,CA18#,CA20S | 83/10~85/ 8 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4521 | 13510-16A00 | 33 x 47 x 8 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E# | 85/8~90/ | Engine CRANK SHAFT FRONT |
| 03903 4301 | 13510-16A00 | 33 x 47 x 8 | BLUEBIRD (FWD) U12 CA16S,CA18I | 87/9~91/ | Engine CRANK SHAFT FRONT |
| 03903 2779 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U11 CA18DT | 85/8~87/9 | Engine CRANK SHAFT FRONT |
| 03903 4025 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U12 CA18D,CA18DT | 87/9~89/ | Engine CRANK SHAFT FRONT |
| 03903 5037 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U13 GA16DS,CD20 | 91/9~96/ | Engine CRANK SHAFT FRONT |
| 03903 2385 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U14 QG18D# | 98/9~00/7 | Engine CRANK SHAFT FRONT |
| 03903 1593 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U14 CD20# | 96/1~99/10 | Engine CRANK SHAFT FRONT |
| 03903 4939 | 12279-AD205 | 84 x 104 x 8.5 | BLUEBIRD (FWD) U14 | 96/1~01/ | Engine CRANK SHAFT REAR |
| 03903 3021 | 13510-53J00 | 46 x 58 x 7 | BLUEBIRD (FWD) U13 SR18DE,SR20DE#,KA24DE | 91/9~96/ | Engine CRANK SHAFT FRONT |
| 03903 5397 | 12279-58S00 | 80 x 100 x 10 | BLUEBIRD (FWD) U13 KA24DE | 93/8~96/ | Engine CRANK SHAFT REAR |
| 03903 1909 | 13510-53J00 | 46 x 58 x 7 | BLUEBIRD (FWD) WU12 | 91/2~91/12 | Engine CRANK SHAFT FRONT |
| 03903 6257 | 13510-88G10 | 33 x 47 x 7 | BLUEBIRD (FWD) U11 VG20# | 84/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 3693 | 13510-V7202 | 40 x 52 x 7 | BLUEBIRD (FWD) U14 QG18D# | 00/7~01/ | Engine CRANK SHAFT FRONT |
| 03903 6043 | 13510-2J200 | 46 x 58 x 7 | BLUEBIRD (FWD) U14 SR20VE | 97/9~01/ | Engine CRANK SHAFT FRONT |
| 03903 1339 | 12279-85Y00 | 84 x 104 x 11 | BLUEBIRD (FWD) U11 CA16S,CA18#,CA20S,VG20# | 83/10~90/ | Engine CRANK SHAFT REAR |
| 03903 6499 | 12279-85Y00 | 84 x 104 x 11 | BLUEBIRD (FWD) U12 EXCEPT LD20 | 87/9~91/ | Engine CRANK SHAFT REAR |
| 03903 1097 | 12279-85Y00 | 84 x 104 x 11 | BLUEBIRD (FWD) U13 GA16DS,SR18DE,SR20DE#, CD20 | 91/9~95/ | Engine CRANK SHAFT REAR |
| 03903 3277 | 12279-85Y00 | 84 x 104 x 11 | BLUEBIRD (FWD) WU12 | 91/2~91/12 | Engine CRANK SHAFT REAR |
| 03903 1743 | 13042-16V00 | 40 x 52 x 7 | BLUEBIRD (FWD) U12 CA18D,CA18DT | 87/9~89/10 | Engine CAM SHAFT |
| 03903 1433 | 13510-53J00 | 46 x 58 x 7 | BLUEBIRD (FWD) U12 SR18DI,SR20D# | 89/10~91/ | Engine CRANK SHAFT FRONT |
| 03903 2079 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U12 CA18DI(2WD) | 89/10~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2143 | 32113-03E00 | 27.9 x 43 x 8 | BLUEBIRD (FWD) U13 SR18DE,SR20DE# | 91/9~96/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5241 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E,CA20S | 83/10~90/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6125 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U12 CA16S | 87/9~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5061 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U12 CA18I(2WD) | 87/9~89/10 | Mission & Differential (M/T) MISSION CASE |
| 03903 5555 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U13 GA16DS,CD20 | 91/9~96/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4211 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U14 CD20# | 96/1~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4293 | 38342-03E00 | 39 x 59 x 11 x 17 | BLUEBIRD (FWD) U11 CA18ET,CA18DT,VG20#,LD20 | 83/10~90/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4527 | 38342-03E00 | 39 x 59 x 11 x 17 | BLUEBIRD (FWD) U12 CA18I | 89/10~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2773 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E | 83/10~85/8 | Mission & Differential (A/T) MISSION CASE |
| 03903 2785 | 38342-03E00 | 39 x 59 x 11 x 17 | BLUEBIRD (FWD) U13 SR18DE,SR20DE | 91/9~96/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2513 | 32113-M8000 | 25 x 40 x 8 | BLUEBIRD (FWD) U14 | 96/1~01/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2337 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U14 WITHOUT NON SLIP DIFF. (2WD) | 96/1~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1023 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U12 CA18DI(LSD) | 89/10~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2277 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U14 NON SLIP DIFF. | 96/1~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6551 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U14 (4WD) | 96/1~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1525 | 38342-56E00 | 43 x 90 x 12 x 21 | BLUEBIRD (FWD) U12 (4WD) | 87/9~89/10 | Mission & Differential (M/T) MISSION CASE |
| 03903 6523 | 38342-56E00 | 43 x 90 x 12 x 21 | BLUEBIRD (FWD) U12 SR20D#(4WD) | 89/10~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3439 | 38342-56E00 | 43 x 90 x 12 x 21 | BLUEBIRD (FWD) U13 SR20DET | 91/9~96/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6449 | 38342-51E00 | 46 x 90 x 11 | BLUEBIRD (FWD) U12 CA18D(LSD) | 87/9~89/10 | Mission & Differential (M/T) MISSION CASE |
| 03903 2481 | 38342-03E00 | 39 x 59 x 11 x 17 | BLUEBIRD (FWD) U12 CA18D(2WD),LD20,SR20D(2WD) | 87/9~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3957 | 43252-03E01 | 43 x 54 x 6 | BLUEBIRD (FWD) U11 VAN | 85/8~90/ | Wheel Hub REAR |
| 03903 3901 | 13510-V7202 | 40 x 52 x 7 | BLUEBIRD (FWD) U14 CD20E | 99/10~01/ | Engine CRANK SHAFT FRONT |
| 03903 6259 | 13207-53Y00 | | BLUEBIRD (FWD) U14 QG18D# | 98/9~01/ | Engine VALVE STEM SEAL |
| 03903 4107 | 40227-01E01 | 56 x 72 x 10 | BLUEBIRD (FWD) U11 | 83/10~90/ | Wheel Hub FRONT DUST SEAL |
| 03903 6181 | 40232-01E01 | 56 x 72 x 8 x 11 | BLUEBIRD (FWD) U11 ALL | 83/10~87/9 | Wheel Hub FRONT GREASE SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3349 | 40232-51E10 | 56 x 72 x 8 x 11.5 | BLUEBIRD (FWD) U11 WAGON,VAN,MAXIMA | 87/9~90/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1827 | 40232-51E10 | 56 x 72 x 8 x 11.5 | BLUEBIRD (FWD) U12 | 87/9~90/ | Wheel Hub FRONT IN. & OUT. |
| 03903 5533 | 40232-33P00 | 56 x 76 x 6 x 11 | BLUEBIRD (FWD) WU12 | 91/2~91/12 | Wheel Hub FRONT IN. & OUT. |
| 03903 1929 | 40232-33P00 | 56 x 76 x 6 x 11 | BLUEBIRD (FWD) U13 | 91/9~96/ | Wheel Hub FRONT IN. & OUT. |
| 03903 4133 | 32113-03E00 | 27.9 x 43 x 8 | BLUEBIRD (FWD) U12 CA18I(4WD),CA18D#,SR20#,LD20 | 87/9~91/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 4435 | 43252-M7001 | 43 x 54 x 7.5 | BLUEBIRD (FWD) U11 VAN | 83/10~85/8 | Wheel Hub REAR |
| 03903 6461 | 32113-03E00 | 27.9 x 43 x 8 | BLUEBIRD (FWD) U11 CA18ET,CA18DT,VG20#,LD20 | 83/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 6579 | 43252-03E01 | 43 x 54 x 6 | BLUEBIRD (FWD) U11 SEDAN,HARD TOP,WAGON | 83/10~90/ | Wheel Hub REAR |
| 03903 5837 | 43252-03E01 | 43 x 54 x 6 | BLUEBIRD (FWD) U12 (2WD) | 87/9~91/ | Wheel Hub REAR |
| 03903 5739 | 40232-51E10 | 56 x 72 x 8 x 11.5 | BLUEBIRD (FWD) U12 (4WD) | 87/9~91/ | Wheel Hub REAR IN. & OUT. |
| 03903 4931 | 40232-51E10 | 56 x 72 x 8 x 11.5 | BLUEBIRD (FWD) U13 | 91/9~96/ | Wheel Hub REAR IN. & OUT. |
| 03903 3833 | 40232-33P00 | 56 x 76 x 6 x 11 | BLUEBIRD (FWD) U14 | 96/1~01/ | Wheel Hub REAR IN. & OUT. |
| 03903 2325 | 32113-M8000 | 25 x 40 x 8 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E,CA20S | 83/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 6211 | 32113-M8000 | 25 x 40 x 8 | BLUEBIRD (FWD) U12 CA18I(2WD),CA16S,SR18DI | 87/9~91/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3741 | 32113-M8000 | 25 x 40 x 8 | BLUEBIRD (FWD) U13 GA16DS,CD20 | 91/9~96/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 6333 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U11 CA16S,CA18S,CA18E | 83/10~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2643 | 40232-33P00 | 56 x 76 x 6 x 11 | BLUEBIRD (FWD) U14 | 96/1~01/ | Wheel Hub FRONT IN. & OUT. |
| 03903 3127 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | BLUEBIRD (FWD) U11 CA18# | 85/8~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1763 | 38342-51E00 | 46 x 90 x 11 | BLUEBIRD (FWD) U12 SR20D(2WD) LSD | 89/10~91/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2617 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U14 SR18DE,SR20DE,CD20 | 96/1~97/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 2137 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U14 CVT,CD20#,SR18DE(XE,LERN),QG18DE | 97/9~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 5257 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U12 SR18DI(4WD)OR(LSD) | 89/10~91/ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5395 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U13 LSD | 91/9~96/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6543 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U13 SR18DE(SSSA,ARXZ,ARX LA) | 91/9~96/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6431 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U14 NON SLIP DIFF. | 96/1~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 1369 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U14 (4WD) | 96/1~97/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 5499 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U12 SR18DI(2WD) | 89/10~91/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3917 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | BLUEBIRD (FWD) U11 CA18ET,CA20S,LD20 | 83/10~85/8 | Mission & Differential (A/T) MISSION CASE |
| 03903 3689 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD (FWD) U12 CA16S | 87/9~91/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3017 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | BLUEBIRD (FWD) U12 CA18I,CA18D,LD20,SR20D (2WD) | 87/9~91/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3845 | 38342-21X01 | 39 x 57 x 11 x 17 | BLUEBIRD (FWD) U11 VG20# | 84/10~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1717 | 38342-56E00 | 43 x 90 x 12 x 21 | BLUEBIRD (FWD) U12 (4WD) | 87/9~89/10 | Mission & Differential (A/T) MISSION CASE |
| 03903 6145 | 38342-56E00 | 43 x 90 x 12 x 21 | BLUEBIRD (FWD) U12 SR20D(4WD),SR20DT | 89/10~91/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5745 | 38342-56E00 | 43 x 90 x 12 x 21 | BLUEBIRD (FWD) U13 SR20DET | 91/9~96/ | Mission & Differential (A/T) MISSION CASE |
| 03903 2769 | 38342-21X04 | 46 x 90 x 11 x 15.7 | BLUEBIRD (FWD) U12 LSD EXCEPT SR18DI | 88/10~89/10 | Mission & Differential (A/T) MISSION CASE |
| 03903 5607 | 38342-21X04 | 46 x 90 x 11 x 15.7 | BLUEBIRD (FWD) WU12 | 91/2~91/12 | Mission & Differential (A/T) MISSION CASE |
| 03903 6119 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | BLUEBIRD (FWD) U13 KA24DE | 93/8~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1923 | 38342-8E000 | 40 x 52 x 8 x 13 | BLUEBIRD (FWD) U14 CVT,CD20E,QG18DE | 00/5~01/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4889 | 38342-31X02 | 42 x 90 x 9.5 x 13 | BLUEBIRD (FWD) U14 SR18DE,SR20DE | 97/9~01/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 2471 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U14 SR18DE(2WD),SR20DE(2WD) | 96/1~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5985 | 38342-8E002 | 41.5 x 90 x 8 x 12 | BLUEBIRD (FWD) U14 NON SLIP DIFF. | 00/5~01/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6151 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U12 CA16S | 87/9~91/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4379 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U12 CA18I(2WD) | 87/9~89/10 | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1303 | 38342-D2100 | 40 x 56 x 65 x 20 | BLUEBIRD (FWD) U13 GA16DS | 91/9~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1347 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U11 CA18ET,18DT,VG20#,LD20 | 83/10~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6511 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U12 CA18D(2WD),LD20D | 87/9~89/10 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4155 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U12 SR20D(2WD),CA18I,LD2 | 89/10~91/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3451 | 38342-03E01 | 33 x 59 x 11 x 17 | BLUEBIRD (FWD) U13 18DE,SR20DE | 91/9~96/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6167 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U13 GA16DS,SR18DE,CD20,SR20DE(ARXG) | 91/9~96/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5491 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U12 SR18DI(2WD) | 83/10~91/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2457 | 38342-51E00 | 46 x 90 x 11 | BLUEBIRD (FWD) U13 NON SLIP DIFF. | 91/9~96/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5853 | 38342-31X01 | 33 x 56 x 8 x 13 | BLUEBIRD (FWD) U14 NON SLIP DIFF. | 98/9~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2741 | 33111-56E00 | 60 x 78 x 9 | BLUEBIRD (FWD) U12 4WD | 87/9~89/10 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2659 | 33111-56E00 | 60 x 78 x 9 | BLUEBIRD (FWD) U12 SR20D#(4WD) | 89/10~91/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5939 | 33111-56E00 | 60 x 78 x 9 | BLUEBIRD (FWD) U13 SR20DET | 91/9~96/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2191 | 33111-31X00 | 60 x 76 x 9 | BLUEBIRD (FWD) U12 SR18DI(4WD) | 89/10~91/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6383 | 33111-31X00 | 60 x 76 x 9 | BLUEBIRD (FWD) U14 4WD | 96/1~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2871 | 38342-01E00 | 33 x 56 x 48.5 x 24.5 | BLUEBIRD (FWD) U11 CA20S | 83/10~85/8 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2647 | 38342-01E00 | 33 x 56 x 48.5 x 24.5 | BLUEBIRD (FWD) U14 CD20# | 96/1~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1735 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD (FWD) U11 CA16S | 85/8~90/ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3543 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD (FWD) U14 QG18DE | 98/9~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4895 | 13510-05E00 | 46 x 58 x 8 | BLUEBIRD (FWD) U11,U12 LD20 | 83/10~91/ | Engine CRANK SHAFT FRONT |
| 03903 4347 | 13510-05E00 | 46 x 58 x 8 | BLUEBIRD (RWD) 910 CA16S,CA18# | 82/10~83/ | Engine CRANK SHAFT FRONT |
| 03903 4627 | 38342-21000 | 32 x 52 x 11 x 15.5 | BLUEBIRD (RWD) 910 | 79/10~84/ | Final Drive DIFF. SIDE |
| 03903 4075 | 48137-36700 | 26 x 40 x 7 | BLUEBIRD (RWD) 810,910 Z18P,S.LD20.F4 | 76/7~83/ | Steering SECTOR SHAFT |
| 03903 2295 | 48029-W0501 | 17.5 x 32 x 7 | BLUEBIRD (RWD) 810 ALL | 78/8~79/ | Steering WORM |
| 03903 3727 | 48125-78500 | 17 x 35 x 8 | BLUEBIRD (RWD) 910 EXCEPT Z18P,S.LD20.F4 | 79/10~83/ | Steering WORM |
| 03903 4635 | 13042-D0100 | 34 x 48 x 8 | BLUEBIRD (RWD) 910 CA16S,CA18# | 82/10~83/ | Engine CAM SHAFT |
| 03903 1291 | 13042-A8601 | 48 x 70 x 9 | BLUEBIRD (RWD) 810 L16,L18,L20,Z16,Z18 | 76/7~79/ | Engine CRANK SHAFT FRONT |
| 03903 2005 | 38342-21000 | 32 x 52 x 11 x 15.5 | BLUEBIRD (RWD) 810 R160,R180 | 76/7~79/ | Final Drive DIFF. SIDE |
| 03903 5935 | 13042-A8601 | 48 x 70 x 9 | BLUEBIRD (RWD) 910 LD20# | 80/3~88/2 | Engine CRANK SHAFT FRONT |
| 03903 5791 | 48029-04100 | 17 x 31 x 7 | BLUEBIRD (RWD) 810 ALL | 76/7~78/ | Steering WORM |
| 03903 2825 | 13510-05E00 | 46 x 58 x 8 | BLUEBIRD (RWD) 910 LD20 | 88/2~93/ | Engine CRANK SHAFT FRONT |
| 03903 3621 | 12279-R4611 | 80 x 100 x 13 | BLUEBIRD (RWD) 810 L16,L18,20,Z16,Z18 | 76/7~79/ | Engine CRANK SHAFT REAR |
| 03903 2671 | 12279-D0100 | 84 x 104 x 11 | BLUEBIRD (RWD) 910 CA16S,CA18# | 82/10~83/ | Engine CRANK SHAFT REAR |
| 03903 1255 | 12279-58S00 | 80 x 100 x 10 | BLUEBIRD (RWD) 910 EXCEPT CA16S,CA18# | 79/10~93/ | Engine CRANK SHAFT REAR |
| 03903 5345 | 13207-81W00 | | BLUEBIRD (RWD) L#,Z#,LD# | 79/10~ | Engine VALVE STEM SEAL |
| 03903 2829 | 13207-D0101 | | BLUEBIRD (RWD) CA16S,CA18# | 82/10~83/ | Engine VALVE STEM SEAL |
| 03903 5885 | 13042-A8601 | 48 x 70 x 9 | BLUEBIRD (RWD) 910 L16S,Z16S,Z18#,Z20 | 79/10~83/ | Engine CRANK SHAFT FRONT |
| 03903 3755 | 43232-21000 | 40 x 62 x 10 | BLUEBIRD (RWD) 910 S. S. S. | 79/10~89/ | Wheel Hub REAR |
| 03903 2597 | 40232-A0101 | 48 x 62 x 6 | BLUEBIRD (RWD) 810 DISC BRAKE | 76/7~79/ | Wheel Hub FRONT |
| 03903 2279 | 40232-N7100 | 46 x 59.1 x 12 | BLUEBIRD (RWD) 810 DRUM BRAKE | 76/7~79/ | Wheel Hub FRONT |
| 03903 1349 | 40232-N7100 | 46 x 59.1 x 12 | BLUEBIRD (RWD) 910 | 79/10~93/ | Wheel Hub FRONT |
| 03903 4989 | 43252-H1000 | 41 x 56 x 7 | BLUEBIRD (RWD) 810 EXCEPT S. S. S.+L20A | 76/7~79/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3653 | 48029-W0501 | 17.5 x 32 x 7 | BLUEBIRD (RWD) 910 Z18P,S.LD20.F4 | 79/10~83/ | Steering WORM |
| 03903 4569 | 43232-21000 | 40 x 62 x 10 | BLUEBIRD (RWD) 810 S. S. S.+L20A | 76/7~79/ | Wheel Hub REAR |
| 03903 2083 | 38189-P0101 | 45 x 75 x 12 | BLUEBIRD (RWD) 910 HE# | 79/10~84/ | Final Drive PINION |
| 03903 3871 | 32113-N2101 | 34 x 50 x 7 | BLUEBIRD (RWD) 810 FS5W63A,F4W63L,R3W65L | 76/7~79/ | Transmission FRONT COVER |
| 03903 4649 | 32113-N2101 | 34 x 50 x 7 | BLUEBIRD (RWD) 910 F4W63L,R3W65L | 79/10~89/ | Transmission FRONT COVER |
| 03903 3239 | 38189-U3000 | 35 x 67 x 12 x 18 | BLUEBIRD (RWD) 910 R160,R180 | 79/10~84/ | Final Drive PINION |
| 03903 4271 | 43252-H1000 | 41 x 56 x 7 | BLUEBIRD (RWD) 910 EXCEPT S. S. S. | 79/10~93/ | Wheel Hub REAR |
| 03903 4275 | 38189-P0101 | 45 x 75 x 12 | BLUEBIRD (RWD) 810 H190 | 76/7~79/ | Final Drive PINION |
| 03903 1003 | 32114-Y4000 | 30 x 45 x 8 | BLUEBIRD (RWD) 810 FS5W71B,F4W71B | 76/7~79/ | Transmission FRONT COVER |
| 03903 5769 | 38189-U3000 | 35 x 67 x 12 x 18 | BLUEBIRD (RWD) 810 R160,R180 | 76/7~79/ | Final Drive PINION |
| 03903 2445 | 38189-A6100 | 35 x 64 x 13 | BLUEBIRD (RWD) 910 H165B | 79/10~93/ | Final Drive PINION |
| 03903 1337 | 38189-A6100 | 35 x 64 x 13 | BLUEBIRD (RWD) 810 H165B | 76/7~79/ | Final Drive PINION |
| 03903 3679 | 32136-U0100 | 35 x 50 x 11 | BLUEBIRD (RWD) 810,91 | 76/7~93/ | Transmission REAR EXTENTION |
| 03903 2807 | 32114-Y4000 | 30 x 45 x 8 | BLUEBIRD (RWD) 910 FS5W71B,F4W71B,Z18P,LD 20 | 79/10~93/ | Transmission FRONT COVER |
| 03903 1035 | tyutyut | | BLUEBIRD (RWD) 45645646 | 666 | Steering (P/S) 67868 |
| 03903 2781 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD SYLPHY G10 BC | 01/10~03/ 2 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3733 | 38342-8E000 | 40 x 52 x 8 x 13 | BLUEBIRD SYLPHY G10 (2WD),EXCEPT CVT,MCVT | 00/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6245 | 13207-D4200 | | BLUEBIRD SYLPHY G10 QR20DD | 00/8~ | Engine VALVE STEM SEAL |
| 03903 5743 | 12279-AD205 | 84 x 104 x 8.5 | BLUEBIRD SYLPHY G10 | 00/8~ | Engine CRANK SHAFT REAR |
| 03903 5801 | 13510-2J200 | 46 x 58 x 7 | BLUEBIRD SYLPHY G10 QR20DD | 00/8~ | Engine CRANK SHAFT FRONT |
| 03903 6315 | 13510-V7202 | 40 x 52 x 7 | BLUEBIRD SYLPHY G10 QG15DE,QG18DE | 00/8~ | Engine CRANK SHAFT FRONT |
| 03903 4039 | 38342-8E001 | 32.5 x 56 x 8 x 14 | BLUEBIRD SYLPHY G10 CVT | 03/2~ | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4367 | 38342-8E001 | 32.5 x 56 x 8 x 14 | BLUEBIRD SYLPHY G10 MCVT | 00/8~03/2 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4893 | 13207-53Y00 | | BLUEBIRD SYLPHY G10 QG15DE,QG18DE | 00/8~ | Engine VALVE STEM SEAL |
| 03903 4413 | 32113-M8000 | 25 x 40 x 8 | BLUEBIRD SYLPHY G10 | 00/8~03/2 | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3831 | 38342-8E000 | 40 x 52 x 8 x 13 | BLUEBIRD SYLPHY G10 TRN | 03/2~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1431 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD SYLPHY G10 | 00/8~01/10 | Mission & Differential (A/T) MISSION CASE |
| 03903 2183 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD SYLPHY G10 EXCEPT BC,TRN | 00/8~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4401 | 38342-8E000 | 40 x 52 x 8 x 13 | BLUEBIRD SYLPHY G10 TRN | 03/2~ | Mission & Differential (M/T) MISSION CASE |
| 03903 3495 | 38342-31X00 | 40 x 56 x 8 x 13.5 | BLUEBIRD SYLPHY G10 BC | 01/10~03/2 | Mission & Differential (M/T) MISSION CASE |
| 03903 4991 | 38342-M8001 | 40 x 56 x 8 | BLUEBIRD SYLPHY G10 EXCEPT BC,TRN | 00/8~ | Mission & Differential (M/T) MISSION CASE |
| 03903 5967 | 33111-06R00 | 52 x 66 x 9 | BLUEBIRD SYLPHY G10 (4WD) | 00/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4773 | 38189-J2000 | 42 x 72.5 x 12 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Final Drive PINION |
| 03903 2475 | 32136-J6500 | 40 x 62 x 11 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Transmission REAR |
| 03903 5299 | 32113-86401 | 28 x 40 x 8 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Transmission FRONT |
| 03903 1353 | 43253-76000 | 89.4 x 95.6 x 3.1 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Wheel Hub REAR O-RING |
| 03903 1605 | 48040-82100 | 35 x 48 x 8 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Steering SECTOR SHAFT |
| 03903 1757 | 43252-82100 | 80 x 105 x 13 | CABALL / CLIPPER C240,C340 DOUBLE TIRE | 73/~83/7 | Wheel Hub REAR INNER |
| 03903 6479 | 13207-66700 | | CABALL / CLIPPER H20 | 73/~83/7 | Engine VALVE STEM SEAL |
| 03903 3369 | 43213-76000 | 78.4 x 95 x 8 | CABALL / CLIPPER C240,C340 SINGLE TIRE | 73/~83/7 | Wheel Hub REAR INNER |
| 03903 5641 | 43252-J2000 | 38 x 47 x 10 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Wheel Hub REAR OUTER |
| 03903 4589 | 13510-E0700 | 45 x 68 x 12 | CABALL / CLIPPER H20 | 73/~83/7 | Engine CRANK SHAFT FRONT |
| 03903 5095 | 12279-90016 | 62 x 85 x 13 | CABALL / CLIPPER ED30,ED33 | 76/5~83/7 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5553 | 12279-32200 | | CABALL / CLIPPER H20 | 73/~80/10 | Engine CRANK SHAFT REAR |
| 03903 6053 | 12279-Z5001 | 105 x 135 x 13 | CABALL / CLIPPER ED30,ED33 | 76/5~83/7 | Engine CRANK SHAFT REAR |
| 03903 5355 | 13207-Z5001 | | CABALL / CLIPPER ED30,ED33 | 76/5~83/7 | Engine VALVE STEM SEAL |
| 03903 3145 | 40227-J5110 | 60 x 82 x 7 | CABALL / CLIPPER C240,C340 | 73/~83/7 | Wheel Hub FRONT |
| 03903 3705 | 12279-58000 | | CABALL / CLIPPER H20 | 80/11~83/7 | Engine CRANK SHAFT REAR |
| 03903 6191 | 13207-01W00 | | CABSTAR / HOMER J16,H20 | 79/9~81/12 | Engine VALVE STEM SEAL |
| 03903 4257 | 13207-08000 | | CABSTAR / HOMER J15,J16 | 76/1~79/8 | Engine VALVE STEM SEAL |
| 03903 3731 | 13207-76200 | | CABSTAR / HOMER SD22 | 76/1~81/12 | Engine VALVE STEM SEAL |
| 03903 2309 | 13510-E0700 | 45 x 68 x 12 | CABSTAR / HOMER H20 | 76/1~81/12 | Engine CRANK SHAFT FRONT |
| 03903 6577 | 12279-32200 | | CABSTAR / HOMER H20 | 76/1~80/10 | Engine CRANK SHAFT REAR |
| 03903 1611 | 13207-66700 | | CABSTAR / HOMER H20 | 76/1~81/12 | Engine VALVE STEM SEAL |
| 03903 3631 | 13043-T7200 | 58 x 80 x 12 | CABSTAR / HOMER SD22 | 76/1~81/12 | Engine CRANK SHAFT FRONT |
| 03903 4345 | 12279-58000 | | CABSTAR / HOMER J16,H20 | 80/11~81/12 | Engine CRANK SHAFT REAR |
| 03903 5377 | 13042-B3000 | 39.7 x 62 x 11 | CABSTAR / HOMER J15,J16 | 76/1~81/12 | Engine CRANK SHAFT FRONT |
| 03903 4651 | 38189-P0101 | 45 x 75 x 12 | CABSTAR / HOMER F20 H190 FINAL DRIVE | 76/1~81/12 | Final Drive PINION |
| 03903 2525 | 38189-C7000 | 42 x 76 x 12 x 21 | CABSTAR / HOMER F20 H233B FINAL DRIVE | 76/1~81/12 | Final Drive PINION |
| 03903 3687 | 32136-J6500 | 40 x 62 x 11 | CABSTAR / HOMER F20 RS5W81A,R4W81A T/M | 78/4~81/12 | Transmission REAR |
| 03903 3055 | 32136-U0100 | 35 x 50 x 11 | CABSTAR / HOMER F20 R4W63L,R4W71B T/M | 76/1~81/12 | Transmission REAR |
| 03903 3579 | 32113-86401 | 28 x 40 x 8 | CABSTAR / HOMER F20 RS5W81A,R4W81A T/M | 78/4~81/12 | Transmission FRONT |
| 03903 3549 | 32114-Y4000 | 30 x 45 x 8 | CABSTAR / HOMER F20 R4W70B T/M | 76/1~81/12 | Transmission FRONT |
| 03903 2579 | 40232-B9500 | 54 x 65 x 13 | CABSTAR / HOMER F20 | 78/4~81/12 | Wheel Hub FRONT |
| 03903 3823 | 12279-09400 | | CABSTAR / HOMER J15,J16 | 76/1~80/10 | Engine CRANK SHAFT REAR |
| 03903 4665 | 32113-N2101 | 34 x 50 x 7 | CABSTAR / HOMER F20 R4W63L T/M | 76/1~79/8 | Transmission FRONT |
| 03903 4565 | 26134-6401P | 57 x 73 x 7 | CABSTAR / HOMER F20 | 76/1~78/3 | Wheel Hub FRONT |
| 03903 3199 | 43252-J0300 | 39.5 x 62 x 11 | CABSTAR / HOMER F20 H20,SD22 | 76/1~76/6 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2595 | 43252-T3200 | 38 x 62 x 11 | CABSTAR / HOMER F20 H20,SD22(EXCEPT FLAT LOW) | 78/7~81/12 | Wheel Hub REAR INNER |
| 03903 6447 | 43252-82100 | 80 x 105 x 13 | CABSTAR / HOMER F20 H20,SD22(FLAT LOW) | 78/4~81/12 | Wheel Hub REAR INNER |
| 03903 2255 | 38212-73000 | 34 x 55 x 11 | CABSTAR / HOMER F20 J15,J16 | 76/1~81/12 | Wheel Hub REAR INNER |
| 03903 5997 | 09061-0001P | 68 x 82 x 7 | CABSTAR / HOMER F20 H20,SD22(EXCEPT FLAT LOW) | 76/1~81/12 | Wheel Hub REAR OUTER |
| 03903 3713 | 43252-J2000 | 38 x 47 x 10 | CABSTAR / HOMER F20 H20,SD22(FLAT LOW) | 78/4~81/12 | Wheel Hub REAR OUTER |
| 03903 3595 | 43232-B5000 | 50 x 67 x 11 | CABSTAR / HOMER F20 J15,J16 | 76/1~81/12 | Wheel Hub REAR OUTER |
| 03903 2411 | 12279-76200 | | CABSTAR / HOMER SD22 | 76/1~81/12 | Engine CRANK SHAFT REAR |
| 03903 2459 | 43232-01G00 | 50 x 70 x 12 x 17 | CARAVAN / HONY / URVAN E24 WITHOUT ABS | 86/9~01/ | Wheel Hub REAR OUTER |
| 03903 6439 | 33111-20N00 | 36.5 x 60 x 10 | CARAVAN / HONY / URVAN E24 ALL(4WD) | 87/10~90/10 | Transfer COVER |
| 03903 4315 | 32114-Y4000 | 30 x 45 x 8 | CARAVAN / HONY / URVAN E23 EXCEPT J16 | 80/8~86/ | Transmission FRONT COVER |
| 03903 5353 | 43232-01G00 | 50 x 70 x 12 x 17 | CARAVAN / HONY / URVAN E25 WITHOUT(AIR BAG OR ABS) | 01/4~ | Wheel Hub REAR OUTER |
| 03903 2359 | 43232-42G10 | 55 x 74 x 10 x 13.5 | CARAVAN / HONY / URVAN E24 ABS | 97/5~01/ | Wheel Hub REAR OUTER |
| 03903 6331 | 43232-42G10 | 55 x 74 x 10 x 13.5 | CARAVAN / HONY / URVAN E25 AIR BAG OR ABS | 01/4~ | Wheel Hub REAR OUTER |
| 03903 2081 | 32113-N2101 | 34 x 50 x 7 | CARAVAN / HONY / URVAN E20 R4W63L T/M | 75/11~80/ | Transmission FRONT COVER |
| 03903 1729 | 32113-N2101 | 34 x 50 x 7 | CARAVAN / HONY / URVAN E23 J16 | 80/8~82/ | Transmission FRONT COVER |
| 03903 1737 | 32114-Y4000 | 30 x 45 x 8 | CARAVAN / HONY / URVAN E20 R4W71B | 75/11~80/ | Transmission FRONT COVER |
| 03903 2355 | 32114-Y4000 | 30 x 45 x 8 | CARAVAN / HONY / URVAN E24 | 86/9~01/ | Transmission FRONT COVER |
| 03903 1501 | 32114-Y4000 | 30 x 45 x 8 | CARAVAN / HONY / URVAN E25 EXCEPT ZD30DDTI | 01/4~ | Transmission FRONT COVER |
| 03903 3973 | 32113-VB000 | 32 x 45 x 8 | CARAVAN / HONY / URVAN E25 ZD30DDTI | 03/5~ | Transmission FRONT COVER |
| 03903 4095 | 32136-U0100 | 35 x 50 x 11 | CARAVAN / HONY / URVAN E20,E23,E24 | 75/11~01/ | Transmission REAR EXTENSION |
| 03903 4715 | 33142-33G10 | 42 x 66 x 10 | CARAVAN / HONY / URVAN E25 ZD30DDTI | 03/5~ | Transmission REAR EXTENSION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4869 | 33111-20N00 | 36.5 x 60 x 10 | CARAVAN / HONY / URVAN E24 TD27(4WD),TD27T(4WD) | 90/10~99/ | Transfer COVER |
| 03903 2251 | 33111-20N00 | 36.5 x 60 x 10 | CARAVAN / HONY / URVAN E24 QD32 | 99/6~01/ | Transfer COVER |
| 03903 3771 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | CARAVAN / HONY / URVAN E25 ZD30DDTI | 02/9~ | Final Drive PINION |
| 03903 3377 | 32136-U0100 | 35 x 50 x 11 | CARAVAN / HONY / URVAN E25 ZD30DD(2WD),KA20DE | 01/4~ | Transmission REAR EXTENSION |
| 03903 6117 | 12279-T7202 | 80 x 100 x 10 | CARAVAN / HONY / URVAN E24 LD20T(ALL) | 87/5~90/ | Engine CRANK SHAFT REAR |
| 03903 5881 | 13510-43G01 | 58 x 80 x 7 | CARAVAN / HONY / URVAN E24 QD32 | 00/2~01/ | Engine CRANK SHAFT FRONT |
| 03903 3865 | 12279-58S00 | 80 x 100 x 10 | CARAVAN / HONY / URVAN E24 NA20S | 90/8~93/10 | Engine CRANK SHAFT REAR |
| 03903 5041 | 12279-85Y00 | 84 x 104 x 11 | CARAVAN / HONY / URVAN E24 VG30E | 88/10~94/11 | Engine CRANK SHAFT REAR |
| 03903 1363 | 12279-43G02 | 86 x 100 x 10 | CARAVAN / HONY / URVAN E24 TD23,TD27# | 86/9~95/5 | Engine CRANK SHAFT REAR |
| 03903 1839 | 12279-32200 | | CARAVAN / HONY / URVAN E20,E23 H20 | 75/11~81/2 | Engine CRANK SHAFT REAR |
| 03903 2405 | 12279-58000 | | CARAVAN / HONY / URVAN E23 J15,J16 | 81/2~82/5 | Engine CRANK SHAFT REAR |
| 03903 3493 | 12279-5L300 | 80 x 100 x 8.5 | CARAVAN / HONY / URVAN E24 NA20S | 93/10~99/ | Engine CRANK SHAFT REAR |
| 03903 4325 | 12279-76200 | | CARAVAN / HONY / URVAN E20,E23 SD22,SD23 | 78/4~82/5 | Engine CRANK SHAFT REAR |
| 03903 2969 | 12279-5L300 | 80 x 100 x 8.5 | CARAVAN / HONY / URVAN E24,E25 KA20DE,KA24DE | 99/6~ | Engine CRANK SHAFT REAR |
| 03903 6069 | 12279-T7202 | 80 x 100 x 10 | CARAVAN / HONY / URVAN E24 LD20T(MT) | 86/9~87/5 | Engine CRANK SHAFT REAR |
| 03903 4407 | 12279-T7202 | 80 x 100 x 10 | CARAVAN / HONY / URVAN E23 SD23 | 82/5~86/ | Engine CRANK SHAFT REAR |
| 03903 4561 | 12279-R4611 | 80 x 100 x 13 | CARAVAN / HONY / URVAN E24 LD20T(AT) | 86/9~87/5 | Engine CRANK SHAFT REAR |
| 03903 3983 | 12279-R4611 | 80 x 100 x 13 | CARAVAN / HONY / URVAN E24 Z20# | 86/9~95/ | Engine CRANK SHAFT REAR |
| 03903 3897 | 12279-R4611 | 80 x 100 x 13 | CARAVAN / HONY / URVAN E20,E23 Z18,Z20,LD20T | 78/10~86/ | Engine CRANK SHAFT REAR |
| 03903 6079 | 38189-N3112 | 40 x 75 x 13.5 | CARAVAN / HONY / URVAN E24 QD32,VG30E | 03/3~ | Final Drive PINION |
| 03903 5165 | 12279-09400 | | CARAVAN / HONY / URVAN E20,E23 J15,J16 | 75/11~81/2 | Engine CRANK SHAFT REAR |
| 03903 4319 | 13207-C6000 | | CARAVAN / HONY / URVAN J16 | 79/10~82/5 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4887 | 13207-42L00 | | CARAVAN / HONY / URVAN NA20S | 90/8~99/ | Engine VALVE STEM SEAL |
| 03903 6029 | 13207-81W00 | | CARAVAN / HONY / URVAN LD20T,Z20# | 86/9~95/ | Engine VALVE STEM SEAL |
| 03903 6025 | 13207-81W00 | | CARAVAN / HONY / URVAN VG30E(IN.) | 88/10~01/ | Engine VALVE STEM SEAL |
| 03903 4329 | 13207-V1700 | | CARAVAN / HONY / URVAN QD32 | 96/8~01/ | Engine VALVE STEM SEAL |
| 03903 1667 | 13207-V1700 | | CARAVAN / HONY / URVAN TD23,TD27# | 86/9~99/ | Engine VALVE STEM SEAL |
| 03903 1135 | 13207-V1700 | | CARAVAN / HONY / URVAN SD23 | 82/6~86/8 | Engine VALVE STEM SEAL |
| 03903 3723 | 12279-AD205 | 84 x 104 x 8.5 | CARAVAN / HONY / URVAN E24 VG30E | 94/11~01/ | Engine CRANK SHAFT REAR |
| 03903 4971 | 13207-D0101 | | CARAVAN / HONY / URVAN VG30E(EX.) | 88/10~01/ | Engine VALVE STEM SEAL |
| 03903 4507 | 13510-2J200 | 46 x 58 x 7 | CARAVAN / HONY / URVAN E24,E25 KA20DE,KA24DE | 99/10~ | Engine CRANK SHAFT FRONT |
| 03903 1811 | 13207-66700 | | CARAVAN / HONY / URVAN H20 | 75/11~82/5 | Engine VALVE STEM SEAL |
| 03903 1025 | 13207-76200 | | CARAVAN / HONY / URVAN SD22 | 78/4~82/5 | Engine VALVE STEM SEAL |
| 03903 2881 | 13207-21002 | | CARAVAN / HONY / URVAN Z18,Z20,LD20T | 78/10~86/8 | Engine VALVE STEM SEAL |
| 03903 1865 | 12279-2W201 | | CARAVAN / HONY / URVAN E25 ZD30DD# | 01/4~ | Engine CRANK SHAFT REAR |
| 03903 1879 | 12279-43G05 | | CARAVAN / HONY / URVAN E24 QD32 | 99/11~ | Engine CRANK SHAFT REAR |
| 03903 4193 | 12279-43G05 | | CARAVAN / HONY / URVAN E24 TD27#,QD32 | 95/5~99/11 | Engine CRANK SHAFT REAR |
| 03903 4109 | 13207-D0101 | | CARAVAN / HONY / URVAN KA20DE,KA24DE,ZD30DD# | 99/6~ | Engine VALVE STEM SEAL |
| 03903 1375 | 38189-N3100 | 40 x 75 x 12 x 17.5 | CARAVAN / HONY / URVAN E23 EXCEPT J16,Z18 | 80/8~85/1 | Final Drive PINION |
| 03903 2369 | 13510-2W201 | 52 x 66 x 7 | CARAVAN / HONY / URVAN E25 ZD30DD# | 01/4~ | Engine CRANK SHAFT FRONT |
| 03903 6075 | 38189-P0101 | 45 x 75 x 12 | CARAVAN / HONY / URVAN E24 HF FINAL DRIVE | 86/9~91/7 | Final Drive PINION |
| 03903 4541 | 38189-P0101 | 45 x 75 x 12 | CARAVAN / HONY / URVAN E23 Z18.CT | 85/1~86/ | Final Drive PINION |
| 03903 6195 | 38189-P0101 | 45 x 75 x 12 | CARAVAN / HONY / URVAN E23 V.Z18 | 82/5~85/1 | Final Drive PINION |
| 03903 4781 | 38189-P0101 | 45 x 75 x 12 | CARAVAN / HONY / URVAN E23 J16 | 80/8~82/5 | Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3931 | 38189-P0101 | 45 x 75 x 12 | CARAVAN / HONY / URVAN E20 H190 FINAL DRIVE | 75/11~80/ | Final Drive PINION |
| 03903 2049 | 38189-N3112 | 40 x 75 x 13.5 | CARAVAN / HONY / URVAN E25 KA20DE,KA24DE,ZD30DD | 01/4~ | Final Drive PINION |
| 03903 6293 | 38189-N3100 | 40 x 75 x 12 x 17.5 | CARAVAN / HONY / URVAN E23 EXCEPT Z18.CT | 85/1~86/ | Final Drive PINION |
| 03903 5655 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CARAVAN / HONY / URVAN E24 HF FINAL DRIVE | 91/7~03/3 | Final Drive PINION |
| 03903 5181 | 38189-C7000 | 42 x 76 x 12 x 21 | CARAVAN / HONY / URVAN E20 N233B FINAL DRIVE | 75/11~80/ | Final Drive PINION |
| 03903 2259 | 33142-33G10 | 42 x 66 x 10 | CARAVAN / HONY / URVAN E24,E25 4WD | 87/10~ | Transfer CASE(REAR) |
| 03903 6399 | 33216-33G01 | 40 x 75 x 12 x 20 | CARAVAN / HONY / URVAN E24,E25 4WD | 93/5~ | Transfer CASE(FRONT) |
| 03903 4343 | 33216-01J00 | 40 x 75 x 12 x 17.9 | CARAVAN / HONY / URVAN E24 4WD | 87/10~93/5 | Transfer CASE(FRONT) |
| 03903 6353 | 33111-30C00 | 40 x 60 x 10 | CARAVAN / HONY / URVAN E25 ZD30DD(AT),ZD30DDTI | 01/4~ | Transfer COVER |
| 03903 2735 | 33111-30C00 | 40 x 60 x 10 | CARAVAN / HONY / URVAN E24 (TD27T(4WD),QD32 | 90/10~99/6 | Transfer COVER |
| 03903 3663 | 38189-N3100 | 40 x 75 x 12 x 17.5 | CARAVAN / HONY / URVAN E24 CA FINAL DRIVE | 86/9~91/7 | Final Drive PINION |
| 03903 4105 | 13042-A8601 | 48 x 70 x 9 | CARAVAN / HONY / URVAN E24 Z20#,NA20S | 86/9~99/ | Engine CRANK SHAFT FRONT |
| 03903 2185 | 13510-05E00 | 46 x 58 x 8 | CARAVAN / HONY / URVAN E24 LD20T | 86/9~90/ | Engine CRANK SHAFT FRONT |
| 03903 1961 | 13510-88G10 | 33 x 47 x 7 | CARAVAN / HONY / URVAN E24 VG30E | 88/10~95/8 | Engine CRANK SHAFT FRONT |
| 03903 5535 | 13510-53J00 | 46 x 58 x 7 | CARAVAN / HONY / URVAN E24 KA20DE,KA24DE | 99/6~99/10 | Engine CRANK SHAFT FRONT |
| 03903 4867 | 13042-16V00 | 40 x 52 x 7 | CARAVAN / HONY / URVAN E24 VG30E | 95/8~01/ | Engine CRANK SHAFT FRONT |
| 03903 5875 | 13510-43G00 | 58 x 80 x 10 | CARAVAN / HONY / URVAN E24 TD23,TD27#,QD32 | 86/9~00/2 | Engine CRANK SHAFT FRONT |
| 03903 3421 | 13510-E0700 | 45 x 68 x 12 | CARAVAN / HONY / URVAN E20,E23 H20 | 75/11~82/ | Engine CRANK SHAFT FRONT |
| 03903 3819 | 38189-N3112 | 40 x 75 x 13.5 | CARAVAN / HONY / URVAN E24 CA FINAL DRIVE | 91/7~03/3 | Final Drive PINION |
| 03903 4359 | 13042-B3000 | 39.7 x 62 x 11 | CARAVAN / HONY / URVAN E20,E23 J15,J16 | 75/11~82/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6073 | 33111-20N00 | 36.5 x 60 x 10 | CARAVAN / HONY / URVAN E25 ZD30DD(MT) | 01/4~ | Transfer COVER |
| 03903 4477 | 13042-A8601 | 48 x 70 x 9 | CARAVAN / HONY / URVAN E23 Z18,Z20,LD20T | 78/10~86/ | Engine CRANK SHAFT FRONT |
| 03903 2849 | 13510-60U00 | 50 x 65 x 8 | CARAVAN / HONY / URVAN E24 LD20T | 86/9~90/ | Engine CAM SHAFT |
| 03903 5303 | 13042-D0100 | 34 x 48 x 8 | CARAVAN / HONY / URVAN E24 VG30E | 88/10~01/ | Engine CAM SHAFT |
| 03903 1581 | 48125-01N00 | | CARAVAN / HONY / URVAN E24 | 86/9~88/ | Steering WORM |
| 03903 4743 | 48137-01N00 | 36 x 50 x 7 | CARAVAN / HONY / URVAN E24 | 86/9~88/ | Steering SECTOR SHAFT |
| 03903 2929 | 43232-B5000 | 50 x 67 x 11 | CARAVAN / HONY / URVAN E20 | 75/11~80/ | Wheel Hub REAR OUTER |
| 03903 1391 | 13043-T7200 | 58 x 80 x 12 | CARAVAN / HONY / URVAN E20,E23 SD22,SD23 | 78/4~86/ | Engine CRANK SHAFT FRONT |
| 03903 6037 | 26134-6401P | 57 x 73 x 7 | CARAVAN / HONY / URVAN E20 | 75/11~78/3 | Wheel Hub FRONT |
| 03903 3215 | 43232-P4500 | 35 x 55 x 11 | CARAVAN / HONY / URVAN E23 V.6/9.MT | 83/5~86/ | Wheel Hub REAR OUTER |
| 03903 1565 | 43232-B5000 | 50 x 67 x 11 | CARAVAN / HONY / URVAN E23 EXCEPT V.6/9.MT | 83/5~86/ | Wheel Hub REAR OUTER |
| 03903 3765 | 40232-B9500 | 54 x 65 x 13 | CARAVAN / HONY / URVAN E20 | 78/4~80/7 | Wheel Hub FRONT |
| 03903 4151 | 40232-B9500 | 54 x 65 x 13 | CARAVAN / HONY / URVAN E23 | 80/8~86/ | Wheel Hub FRONT |
| 03903 1561 | 40232-01G00 | 54 x 75.3 x 12 x 18 | CARAVAN / HONY / URVAN E24 2WD | 86/9~97/5 | Wheel Hub FRONT |
| 03903 4619 | 40232-01G00 | 54 x 75.3 x 12 x 18 | CARAVAN / HONY / URVAN E24 2WD(WITHOUT ABS) | 97/5~99/6 | Wheel Hub FRONT |
| 03903 1803 | 40232-31G00 | 57 x 79 x 9 x 13.5 | CARAVAN / HONY / URVAN E24 4WD | 87/10~01/ | Wheel Hub FRONT |
| 03903 1885 | 40232-3S600 | 54 x 65 x 10 x 15 | CARAVAN / HONY / URVAN E24 2WD(ABS) | 97/5~99/6 | Wheel Hub FRONT |
| 03903 2953 | 40232-3S600 | 54 x 65 x 10 x 15 | CARAVAN / HONY / URVAN E24 2WD | 99/6~01/ | Wheel Hub FRONT |
| 03903 4283 | 43252-0W000 | 36 x 55 x 11 | CARAVAN / HONY / URVAN E25 AIR BAG OR ABS | 01/4~ | Wheel Hub REAR INNER |
| 03903 3115 | 38212-73000 | 34 x 55 x 11 | CARAVAN / HONY / URVAN E20 J15,J16 | 75/11~80/ | Wheel Hub REAR INNER |
| 03903 4847 | 38212-73000 | 34 x 55 x 11 | CARAVAN / HONY / URVAN E20 H20 | 75/11~78/3 | Wheel Hub REAR INNER |
| 03903 5467 | 38212-73000 | 34 x 55 x 11 | CARAVAN / HONY / URVAN E23 | 80/8~86/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2847 | 43232-P4500 | 35 x 55 x 11 | CARAVAN / HONY / URVAN E20 H20,SD22,Z20 | 78/4~80/ | Wheel Hub REAR INNER |
| 03903 5207 | 43252-VW000 | 35 x 55 x 11 | CARAVAN / HONY / URVAN E24 | 86/9~01/ | Wheel Hub REAR INNER |
| 03903 1939 | 43252-VW000 | 35 x 55 x 11 | CARAVAN / HONY / URVAN E25 WITHOUT(AIR BAG OR ABS) | 01/4~ | Wheel Hub REAR INNER |
| 03903 1403 | 43232-B5000 | 50 x 67 x 11 | CARAVAN / HONY / URVAN E23 ALL | 80/8~83/4 | Wheel Hub REAR OUTER |
| 03903 5455 | 40227-20N00 | 51 x 93 x 24 | CARAVAN / HONY / URVAN E24 4WD | 87/10~01/ | Wheel Hub FRONT DUST SEAL |
| 03903 3593 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CEDRIC Y34 VQ30DET(F4) | 01/12~ | Final Drive PINION |
| 03903 1619 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CEDRIC Y31 CA20P,NA20P,RB20P | 91/7~ | Final Drive PINION |
| 03903 6085 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CEDRIC Y30 HE,HF FINAL DRIVE | 91/7~97/ | Final Drive PINION |
| 03903 5629 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEDRIC Y34 EXCEPT VQ30DET(F4) | 99/6~ | Final Drive PINION |
| 03903 5817 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEDRIC Y33 ABS,TURBO | 97/6~99/ | Final Drive PINION |
| 03903 1181 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEDRIC Y33 ALL (EXCEPT ABS,TURBO) | 95/6~97/6 | Final Drive PINION |
| 03903 2381 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEDRIC Y32 ALL (EXCEPT ABS) | 91/6~95/ | Final Drive PINION |
| 03903 4425 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CEDRIC WY30 | 97/8~99/ | Final Drive PINION |
| 03903 1139 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEDRIC Y30 CA# FINAL DRIVE | 91/7~97/ | Final Drive PINION |
| 03903 4179 | 48029-04100 | 17 x 31 x 7 | CEDRIC 330,43 | 75/6~83/ | Steering WORM |
| 03903 5285 | 38189-Y0810 | 40 x 75 x 12 | CEDRIC Y33 VG20E,VG30E,VQ25DE,VQ 30DE(T)Y31,RD28 | 97/6~99/ | Final Drive PINION |
| 03903 2587 | 38189-Y0810 | 40 x 75 x 12 | CEDRIC Y30,Y31,Y32,Y33 ABS | 84/6~99/ | Final Drive PINION |
| 03903 1077 | 38189-P00101 | 45 x 75 x 12 | CEDRIC Y31 CA20P,RB20P | 87/6~91/ | Final Drive PINION |
| 03903 5043 | 38189-P00101 | 45 x 75 x 12 | CEDRIC Y30 HE,HF FINAL DRIVE | 83/6~91/7 | Final Drive PINION |
| 03903 6089 | 38189-P00101 | 45 x 75 x 12 | CEDRIC 330,43 | 75/6~83/ | Final Drive PINION |
| 03903 5513 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEDRIC Y31 VG20#,VG30#,RD28 | 91/7~ | Final Drive PINION |
| 03903 2499 | 49203-V0225 | | CEDRIC Y30(~87.12),Y31(~89.6) | | Steering P/S (RB Type) WORM GEAR KIT |
| 03903 2047 | 38189-N3100 | 40 x 75 x 12 x 17.5 | CEDRIC Y31 VG20#,VG30#,RD28 | 87/6~91/7 | Final Drive PINION |
| 03903 1509 | 40232-V7000 | 54 x 75.2 x 11.5 x 16 | CEDRIC Y30 ALL | 95/11~97/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1679 | 49297-15V25 | | CEDRIC Y31 PR24SA | 87/6~89/ | Steering P/S (RP Type) GEAR HOUSING KIT |
| 03903 3893 | 49277-Y0102 | | CEDRIC Y31 | 89/6~91/ | Steering P/S (RB Type) PISTON SEAL SET |
| 03903 3399 | 49277-11G10 | | CEDRIC Y31 | 87/6~89/6 | Steering P/S (RB Type) PISTON SEAL SET |
| 03903 4853 | 49277-Y0102 | | CEDRIC Y30 | 83/6~87/ | Steering P/S (RB Type) PISTON SEAL SET |
| 03903 4769 | 49321-Y0100 | 28 x 40 x 8 | CEDRIC 330,43 | 75/6~83/ | Steering SECTOR SHAFT |
| 03903 1019 | 49365-V0227 | | CEDRIC Y30(~87.12),Y31(~89.6) | | Steering P/S (RB Type) WORM GEAR KIT |
| 03903 4197 | 38342-N3100 | 35 x 55 x 11 x 18 | CEDRIC Y31 VG20#,VG30#,RD28(F5+AT ) | 87/6~91/ | Final Drive DIFF. SIDE |
| 03903 3591 | 49202-01C26 | | CEDRIC Y30,Y31 | 83/6~91/ | Steering P/S (RB Type) SECTOR SHAFT KIT |
| 03903 1021 | 49345-11G25 | | CEDRIC Y31 | 87/6~91/ | Steering P/S (RB Type) GEAR HOUSING KIT |
| 03903 3413 | 49345-Y0125 | | CEDRIC Y30 | 83/6~97/ | Steering P/S (RB Type) GEAR HOUSING KIT |
| 03903 4977 | 48029-W0501 | 17.5 x 32 x 7 | CEDRIC Y30,Y31 | 83/6~97/ | Steering WORM |
| 03903 4021 | 48040-82100 | 35 x 48 x 8 | CEDRIC Y30,Y31 | 83/6~97/ | Steering SECTOR SHAFT |
| 03903 2203 | 38342-N3100 | 35 x 55 x 11 x 18 | CEDRIC Y32,Y33,Y34 | 91/6~ | Final Drive DIFF. SIDE |
| 03903 2303 | 49201-V0125 | | CEDRIC Y30,Y31 | 83/6~91/ | Steering P/S (RB Type) ADJUSTER SCREW KIT |
| 03903 6189 | 40232-V7000 | 54 x 75.2 x 11.5 x 16 | CEDRIC (S)Y31 DISK BRAKE(WITHOUT ABS) | 87/6~ | Wheel Hub FRONT |
| 03903 2625 | 40232-V7000 | 54 x 75.2 x 11.5 x 16 | CEDRIC WY30 | 97/8~99/ | Wheel Hub FRONT |
| 03903 2237 | 43232-P4500 | 35 x 55 x 11 | CEDRIC 330,43 | 75/6~83/ | Wheel Hub REAR |
| 03903 5591 | 40232-1P450 | 59 x 80.3 x 6 x 11.5 | CEDRIC Y33,Y34 RB25DET | 97/6~ | Wheel Hub FRONT IN. & OUT. |
| 03903 4653 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | CEDRIC Y33,Y34 EXCEPT RB25DET | 95/6~ | Wheel Hub FRONT |
| 03903 1621 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | CEDRIC Y32 | 91/6~93/6 | Wheel Hub FRONT |
| 03903 3711 | 40232-17V00 | 54 x 75.3 x 10 x 15 | CEDRIC (S)Y31 WITHOUT ABS | 87/6~ | Wheel Hub FRONT |
| 03903 5411 | 43252-VW000 | 35 x 55 x 11 | CEDRIC Y30 ALL | 87/4~97/ | Wheel Hub REAR |
| 03903 4067 | 49297-10V25 | | CEDRIC Y31 PR26SC,PR26SE | 87/6~91/ | Steering P/S (RP Type) GEAR HOUSING KIT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1069 | 43252-VW000 | 35 x 55 x 11 | CEDRIC (S)Y31 CA20P,NA20P,RB20P,RD28 (R4) | 87/6~ | Wheel Hub REAR |
| 03903 2479 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y31 VG20DT,VG20D#,RB20P | 87/6~91/ | Engine CRANK SHAFT FRONT |
| 03903 2543 | 40232-V7000 | 54 x 75.2 x 11.5 x 16 | CEDRIC Y30 DISK BRAKE | 85/6~95/11 | Wheel Hub FRONT |
| 03903 2067 | 40232-F1700 | 51 x 65 x 13 | CEDRIC 330 | 75/6~79/ | Wheel Hub FRONT |
| 03903 1725 | 40232-B9500 | 54 x 65 x 13 | CEDRIC Y30 DRUM BRAKE | 85/5~95/11 | Wheel Hub FRONT |
| 03903 1779 | 40232-B9500 | 54 x 65 x 13 | CEDRIC Y30 ALL | 83/6~85/6 | Wheel Hub FRONT |
| 03903 3457 | 40232-B9500 | 54 x 65 x 13 | CEDRIC 430 | 79/6~83/ | Wheel Hub FRONT |
| 03903 3217 | 40232-18V00 | 54 x 65 x 8.3 x 11.5 | CEDRIC (S)Y31 DRUM BRAKE | 87/6~ | Wheel Hub FRONT |
| 03903 5039 | 32114-Y4000 | 30 x 45 x 8 | CEDRIC 330,430,Y30,(S)Y31,WY30 | 75/6~ | Transmission FRONT COVER |
| 03903 5139 | 32136-01G10 | 42 x 58 x 9.5 | CEDRIC (S)Y31 VG30E | 87/6~ | Transmission REAR EXTENTION |
| 03903 5889 | 32136-V5000 | 35 x 50 x 90 x 49.5 | CEDRIC Y30 CA20S(F5),VG20#(F5),VG30E(F5) | 83/6~85/2 | Transmission REAR EXTENTION |
| 03903 1893 | 32136-U0100 | 35 x 50 x 11 | CEDRIC WY30 | 97/8~99/ | Transmission REAR EXTENTION |
| 03903 2247 | 32136-U0100 | 35 x 50 x 11 | CEDRIC (S)Y31 VG20E,RD28 | 87/6~ | Transmission REAR EXTENTION |
| 03903 1453 | 32136-U0100 | 35 x 50 x 11 | CEDRIC (S)Y31 R4 | 87/6~ | Transmission REAR EXTENTION |
| 03903 6375 | 32136-U0100 | 35 x 50 x 11 | CEDRIC Y30 ALL | 85/2~97/ | Transmission REAR EXTENTION |
| 03903 3431 | 43232-P4500 | 35 x 55 x 11 | CEDRIC Y30 ALL | 83/6~87/4 | Wheel Hub REAR |
| 03903 1791 | 32136-U0100 | 35 x 50 x 11 | CEDRIC 330,43 | 75/6~83/ | Transmission REAR EXTENTION |
| 03903 1213 | 38189-N3100 | 40 x 75 x 12 x 17.5 | CEDRIC Y30 CA# FINAL DRIVE | 84/6~91/7 | Final Drive PINION |
| 03903 1011 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CEDRIC Y32 VG30DT | 91/6~94/7 | Wheel Hub REAR IN. & OUT. |
| 03903 3847 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CEDRIC Y33 | 95/6~99/ | Wheel Hub REAR IN. & OUT. |
| 03903 1967 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CEDRIC Y32 ALL | 94/7~95/ | Wheel Hub REAR IN. & OUT. |
| 03903 5281 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CEDRIC Y32 VG20E,VG30R,VG30D,RD28 | 91/6~94/7 | Wheel Hub REAR IN. & OUT. |
| 03903 5861 | 43232-F6100 | 40 x 62 x 9 x 13 | CEDRIC (S)Y31 VG20#,VG30#,RD28(F5+AT) | 87/6~ | Wheel Hub REAR |
| 03903 5575 | 43252-VW000 | 35 x 55 x 11 | CEDRIC WY30 | 97/8~99/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1903 | 32136-U0100 | 35 x 50 x 11 | CEDRIC Y30 CA20#(R4),LD28(R4 OR F5) | 83/6~85/2 | Transmission REAR EXTENTION |
| 03903 5347 | 12279-D0100 | 84 x 104 x 11 | CEDRIC Y31 CA20#,VG20#,VG30# | 83/6~89/5 | Engine CRANK SHAFT REAR |
| 03903 4423 | 12279-AD205 | 84 x 104 x 8.5 | CEDRIC WY30 | 97/8~99/ | Engine CRANK SHAFT REAR |
| 03903 2313 | 12279-AD205 | 84 x 104 x 8.5 | CEDRIC Y33 VG20E,VG30E | 85/6~99/ | Engine CRANK SHAFT REAR |
| 03903 3291 | 12279-58S00 | 80 x 100 x 10 | CEDRIC Y30,Y31,Y32 RD28,RB20P,L20P,LD28 | 85/6~97/ | Engine CRANK SHAFT REAR |
| 03903 1843 | 12279-85Y00 | 84 x 104 x 11 | CEDRIC Y32 VG30# | 91/6~95/ | Engine CRANK SHAFT REAR |
| 03903 2115 | 12279-85Y00 | 84 x 104 x 11 | CEDRIC Y30,Y31 CA20#,VG20#,VG30# | 83/6~97/ | Engine CRANK SHAFT REAR |
| 03903 6131 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y30 VG20E | 95/8~97/ | Engine CRANK SHAFT FRONT |
| 03903 1047 | 12279-76200 | | CEDRIC 330,430 SD20,SD22 | 75/6~81/3 | Engine CRANK SHAFT REAR |
| 03903 6013 | 13207-21002 | | CEDRIC L20,L28,Z20,LD20,LD28 | 79/6~85/7 | Engine VALVE STEM SEAL |
| 03903 2919 | 12279-T7202 | 80 x 100 x 10 | CEDRIC Y31 RD28,RB20P | 85/6~90/10 | Engine CRANK SHAFT REAR |
| 03903 1481 | 12279-T7202 | 80 x 100 x 10 | CEDRIC 430 SD20 | 81/4~83/ | Engine CRANK SHAFT REAR |
| 03903 4943 | 12279-R4611 | 80 x 100 x 13 | CEDRIC 330,430 L20#,L28#,Z20,LD28 | 75/6~83/ | Engine CRANK SHAFT REAR |
| 03903 4001 | 13510-31U00 | 48 x 60 x 7 | CEDRIC Y34 VQ20DE,VQ25DD,VQ30D# | 99/6~ | Engine CRANK SHAFT FRONT |
| 03903 2977 | 13510-31U00 | 48 x 60 x 7 | CEDRIC Y33 VQ25DE,VQ30DE(T) | 95/6~99/ | Engine CRANK SHAFT FRONT |
| 03903 3203 | 13510-88G10 | 33 x 47 x 7 | CEDRIC Y33 VG30E | 95/6~95/8 | Engine CRANK SHAFT FRONT |
| 03903 2145 | 12279-32200 | | CEDRIC 330 H20P | 75/6~ | Engine CRANK SHAFT REAR |
| 03903 3087 | 13207-D0101 | | CEDRIC VG20E(EX.) | 97/8~ | Engine VALVE STEM SEAL |
| 03903 5999 | 13207-5L300 | | CEDRIC RB25DET(IN.) | 99/6~01/1 | Engine VALVE STEM SEAL |
| 03903 3357 | 13207-D4200 | | CEDRIC VQ30DET.VQ25DD,VQ30DD,VQ20DE | 99/6~ | Engine VALVE STEM SEAL |
| 03903 4355 | 13207-D4200 | | CEDRIC RB25DET | 01/1~ | Engine VALVE STEM SEAL |
| 03903 5225 | 13207-D4200 | | CEDRIC RB25DET(EX.) | 99/6~01/1 | Engine VALVE STEM SEAL |
| 03903 1935 | 13207-D4200 | | CEDRIC VG20DT,30D# | 87/6~ | Engine VALVE STEM SEAL |
| 03903 5069 | 13207-81W00 | | CEDRIC VG20E(IN.) | 97/7~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3517 | 12279-5L300 | 80 x 100 x 8.5 | CEDRIC Y33 RD28,RB25DET | 95/6~99/ | Engine CRANK SHAFT REAR |
| 03903 4169 | 13207-V1700 | | CEDRIC SD20,22 | 81/4~ | Engine VALVE STEM SEAL |
| 03903 3223 | 12279-5L300 | 80 x 100 x 8.5 | CEDRIC Y34 RB25DET | 99/6~ | Engine CRANK SHAFT REAR |
| 03903 6051 | 13207-D0101 | | CEDRIC RB20P(IN.) | 87/6~ | Engine VALVE STEM SEAL |
| 03903 1925 | 13207-D0101 | | CEDRIC VG20E,30E,30T(IN.) | 83/6~97/7 | Engine VALVE STEM SEAL |
| 03903 3499 | 13207-D0101 | | CEDRIC RD28 | 85/6~ | Engine VALVE STEM SEAL |
| 03903 3249 | 13207-D0101 | | CEDRIC CA20# | 83/6~ | Engine VALVE STEM SEAL |
| 03903 6103 | 13207-76200 | | CEDRIC SD20,22 | 79/6~81/3 | Engine VALVE STEM SEAL |
| 03903 5027 | 13510-88G10 | 33 x 47 x 7 | CEDRIC Y30 CA20# | 83/6~95/ | Engine CRANK SHAFT FRONT |
| 03903 3329 | 13207-81W00 | | CEDRIC VG20E,30E,30T(EX.) | 83/6~97/7 | Engine VALVE STEM SEAL |
| 03903 1577 | 49365-10V26 | | CEDRIC Y32 | 91/6~95/ | Steering P/S (RP Type) WORM GEAR KIT |
| 03903 2429 | 13510-88G10 | 33 x 47 x 7 | CEDRIC Y32 VG20E,VG30E# | 91/6~95/ | Engine CRANK SHAFT FRONT |
| 03903 3191 | 13042-D0100 | 34 x 48 x 8 | CEDRIC Y33 VG20E,VG30E,RD28 | 95/6~99/ | Engine CAM SHAFT |
| 03903 3227 | 13042-D0100 | 34 x 48 x 8 | CEDRIC Y32 VG20E,VG30E,RD28 | 91/6~95/ | Engine CAM SHAFT |
| 03903 1595 | 13042-D0100 | 34 x 48 x 8 | CEDRIC Y31 CA20#,VG20E#,VG30E#,RD 28 | 87/6~91/ | Engine CAM SHAFT |
| 03903 3523 | 13042-D0100 | 34 x 48 x 8 | CEDRIC Y30 | 83/6~97/ | Engine CAM SHAFT |
| 03903 3729 | 49277-G5200 | | CEDRIC Y32 | 91/6~95/ | Steering P/S (RP Type) WORM GEAR KIT |
| 03903 5917 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y31 RB20P,VG20DT,VG30D# | 87/6~91/ | Engine CAM SHAFT |
| 03903 6489 | 49365-10V26 | | CEDRIC Y33 | 95/6~99/ | Steering P/S (RP Type) WORM GEAR KIT |
| 03903 1815 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y33 VG30D# | 91/6~95/ | Engine CAM SHAFT |
| 03903 5963 | 49365-10V26 | | CEDRIC Y31 PR26SC,PR26SE | 87/6~91/ | Steering P/S (RP Type) WORM GEAR KIT |
| 03903 5383 | 49365-V227 | | CEDRIC Y31 PR24SA | 87/6~89/ | Steering P/S (RP Type) WORM GEAR KIT |
| 03903 1343 | 49297-AG027 | | CEDRIC Y34 | 00/8~ | Steering P/S (RP Type) GEAR HOUSING KIT |
| 03903 3375 | 49297-AG026 | | CEDRIC Y34 | 99/6~00/8 | Steering P/S (RP Type) GEAR HOUSING KIT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1425 | 49297-5Y085 | | CEDRIC Y33 VG20E,VG30E,RD28,VQ25 D,VQ30D# | 95/6~99/ | Steering P/S (RP Type) GEAR HOUSING KIT |
| 03903 5701 | 49297-61U26 | | CEDRIC Y33 RB25DE | 97/6~99/ | Steering P/S (RP Type) GEAR HOUSING KIT |
| 03903 4017 | 49277-42L00 | | CEDRIC Y31 | 87/6~91/ | Steering P/S (RP Type) WORM GEAR KIT |
| 03903 3295 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y30,Y31,Y32 RD28 | 85/6~93/6 | Engine CRANK SHAFT FRONT |
| 03903 4081 | 49297-61U26 | | CEDRIC Y32 | 91/6~95/ | Steering P/S (RP Type) GEAR HOUSING KIT |
| 03903 1485 | 13510-88G10 | 33 x 47 x 7 | CEDRIC Y30 VG20#,VG30# | 83/6~95/8 | Engine CRANK SHAFT FRONT |
| 03903 2997 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y34 RB25DET | 99/6~ | Engine CRANK SHAFT FRONT |
| 03903 1107 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y33 RD28 | 95/6~99/ | Engine CRANK SHAFT FRONT |
| 03903 5125 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y33 VG20E,VG30E,RB25DET | 95/8~99/ | Engine CRANK SHAFT FRONT |
| 03903 1957 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y32 VG30D# | 91/6~95/ | Engine CRANK SHAFT FRONT |
| 03903 6081 | 13042-D0100 | 34 x 48 x 8 | CEDRIC WY30 | 97/8~99/ | Engine CAM SHAFT |
| 03903 3725 | 13042-16V00 | 40 x 52 x 7 | CEDRIC WY30 | 97/8~99/ | Engine CRANK SHAFT FRONT |
| 03903 2981 | 13510-88G10 | 33 x 47 x 7 | CEDRIC Y31 VG20E,VG30E# | 87/6~91/ | Engine CRANK SHAFT FRONT |
| 03903 3491 | 13510-E0700 | 45 x 68 x 12 | CEDRIC 330 H20P | 75/6~79/ | Engine CRANK SHAFT FRONT |
| 03903 3003 | 13043-T7200 | 58 x 80 x 12 | CEDRIC 330,430 SD20,SD22 | 75/6~83/ | Engine CRANK SHAFT FRONT |
| 03903 6483 | 13042-A8601 | 48 x 70 x 9 | CEDRIC Y30 L20#,LD28 | 83/6~95/ | Engine CRANK SHAFT FRONT |
| 03903 5805 | 13042-A8601 | 48 x 70 x 9 | CEDRIC 330,430 L20#,L28#,Z20,LD28 | 75/6~83/ | Engine CRANK SHAFT FRONT |
| 03903 2401 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y34 RB25DET | 99/6~ | Engine CAM SHAFT |
| 03903 3361 | 13042-16V00 | 40 x 52 x 7 | CEDRIC Y33 RB25DET | 97/6~99/ | Engine CAM SHAFT |
| 03903 2611 | 13207-81W00 | | CEDRIC L20 | 85/7~87/ | Engine VALVE STEM SEAL |
| 03903 1067 | 13207-81W00 | | CEDRIC RB20P(EX.) | 87/6~ | Engine VALVE STEM SEAL |
| 03903 6433 | 40232-33P00 | 56 x 76 x 6 x 11 | CEFIRO (FWD) A32,WA32 | 94/8~00/ | Wheel Hub FRONT OUTER |
| 03903 4749 | 13207-D4200 | | CEFIRO (FWD) A32,WA32,CA33 VQ20DE,VQ25D#,VQ30DE | 94/8~02/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6417 | 40232-33P00 | 56 x 76 x 6 x 11 | CEFIRO (FWD) A32,WA32 | 94/8~00/ | Wheel Hub FRONT INNER |
| 03903 2669 | 32113-03E00 | 27.9 x 43 x 8 | CEFIRO (FWD) A32,WA32,CA33 | 94/8~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1201 | 38342-03E00 | 39 x 59 x 11 x 17 | CEFIRO (FWD) A32,CA33 WITHOUT LSD | 94/8~01/1 | Mission & Differential (M/T) MISSION CASE |
| 03903 1435 | 38342-51E00 | 46 x 90 x 11 | CEFIRO (FWD) A32 LSD | 88/9~98/11 | Mission & Differential (M/T) MISSION CASE |
| 03903 5835 | 38342-51E00 | 46 x 90 x 11 | CEFIRO (FWD) CA33 LSD | 96/12~01/1 | Mission & Differential (M/T) MISSION CASE |
| 03903 2787 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | CEFIRO (FWD) A32 LSD | 98/11~ | Mission & Differential (M/T) MISSION CASE |
| 03903 4285 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | CEFIRO (FWD) CA33 LSD | 01/1~02/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5415 | 38342-81X00 | 39 x 59 x 8 x 13.7 | CEFIRO (FWD) A32,CA33 WITHOUT LSD | 01/1~ | Mission & Differential (M/T) MISSION CASE |
| 03903 4415 | 38342-03E01 | 33 x 59 x 11 x 17 | CEFIRO (FWD) A32 | 94/8~98/1 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3979 | 38342-03E01 | 33 x 59 x 11 x 17 | CEFIRO (FWD) CA33 | 98/12~01/1 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3097 | 38342-81X01 | 33 x 59 x 9 x 15.6 | CEFIRO (FWD) A32 | 98/1~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5609 | 13510-31U00 | 48 x 60 x 7 | CEFIRO (FWD) A32,WA32,CA33 VQ20DE,VQ25D#,VQ30DE | 94/8~02/ | Engine CRANK SHAFT FRONT |
| 03903 1127 | 38342-81X01 | 33 x 59 x 9 x 15.6 | CEFIRO (FWD) CA33 | 01/1~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2345 | 12296-31020 | RETAINER ID 97 (F) | CEFIRO (FWD) A32,WA32,CA33 VQ20DE,VQ25D#,VQ30DE | 94/8~02/ | Engine CRANK SHAFT REAR |
| 03903 3667 | 49365-10V26 | | CEFIRO (FWD) A32,WA32 | 94/8~00/ | Steering (P/S) PINION GEAR KIT |
| 03903 6267 | 49297-5Y085 | | CEFIRO (FWD) A32,WA32 | 94/8~00/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4911 | 38342-81X01 | 33 x 59 x 9 x 15.6 | CEFIRO (FWD) A32,WA32,CA33 | 00/9~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2507 | 38342-81X02 | 46 x 90 x 10.5 x 15.5 | CEFIRO (FWD) A32,WA32,CA33 LSD | 00/9~02/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4003 | 38342-81X00 | 39 x 59 x 8 x 13.7 | CEFIRO (FWD) A32,WA32,CA33 WITHOUT LSD | 00/9~02/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5199 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | CEFIRO (FWD) A32,WA32,CA33 LSD | 94/8~00/9 | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4181 | 38342-03E00 | 39 x 59 x 11 x 17 | CEFIRO (FWD) CA33 WITHOUT LSD | 98/12~00/6 | Mission & Differential (A/T) MISSION CASE |
| 03903 3157 | 38342-03E01 | 33 x 59 x 11 x 17 | CEFIRO (FWD) A32,WA32,CA33 | 94/8~00/9 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6561 | 38342-03E00 | 39 x 59 x 11 x 17 | CEFIRO (FWD) A32,WA32 WITHOUT LSD | 94/8~00/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 3075 | 38189-U3000 | 35 x 67 x 12 x 18 | CEFIRO (RWD) A31 RB20 EXCEPT (HICAS) | 88/9~90/8 | Final Drive PINION |
| 03903 2961 | 38342-21000 | 32 x 52 x 11 x 15.5 | CEFIRO (RWD) A31 RB20 EXCEPT (HICAS) | 88/9~90/8 | Final Drive DIFF. SIDE |
| 03903 4057 | 38189-21G00 | 40 x 75 x 12 x 19 | CEFIRO (RWD) A31 RB20D,RB20DT | 88/9~~91/7 | Final Drive PINION |
| 03903 3519 | 38189-21G00 | 40 x 75 x 12 x 19 | CEFIRO (RWD) A31 RB20E(HICAS) | 88/9~90/8 | Final Drive PINION |
| 03903 1167 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CEFIRO (RWD) A31 RB20D,RB20DT | 91/7~94/ | Final Drive PINION |
| 03903 2931 | 38189-U3011 | 35 x 67 x 13.8 x 19.5 | CEFIRO (RWD) A31 RB20E | 92/6~94/ | Final Drive PINION |
| 03903 4585 | 32136-U0100 | 35 x 50 x 11 | CEFIRO (RWD) A31 | 88/9~94/ | Transmission REAR EXTENTION |
| 03903 2867 | 38189-U3000 | 35 x 67 x 12 x 18 | CEFIRO (RWD) A31 RB20E | 90/8~92/8 | Final Drive PINION |
| 03903 3565 | 38342-21000 | 32 x 52 x 11 x 15.5 | CEFIRO (RWD) A31 RB20E | 90/8~94/ | Final Drive DIFF. SIDE |
| 03903 4455 | 13042-16V00 | 40 x 52 x 7 | CEFIRO (RWD) A31 RB20#,RB25D | 88/9~94/ | Engine CRANK SHAFT FRONT |
| 03903 1959 | 32114-Y4000 | 30 x 45 x 8 | CEFIRO (RWD) A31 | 88/9~94/ | Transmission FRONT COVER |
| 03903 5221 | 38189-Y0810 | 40 x 75 x 12 | CEFIRO (RWD) A31 ANTI SKID | 88/9~94/ | Final Drive PINION |
| 03903 5011 | 38342-N3100 | 35 x 55 x 11 x 18 | CEFIRO (RWD) A31 RB20E(HICAS) | 88/9~90/8 | Final Drive DIFF. SIDE |
| 03903 2903 | 38342-N3100 | 35 x 55 x 11 x 18 | CEFIRO (RWD) A31 RB20D,RB20DT | 88/9~94/ | Final Drive DIFF. SIDE |
| 03903 2159 | 38342-N3100 | 35 x 55 x 11 x 18 | CEFIRO (RWD) A31 ANTI SKID | 88/9~94/ | Final Drive DIFF. SIDE |
| 03903 4341 | 49297-10V25 | | CEFIRO (RWD) A31 | 88/9~94/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4403 | 49365-10V26 | | CEFIRO (RWD) A31 | 88/9~94/ | Steering (P/S) WORM GEAR KIT |
| 03903 4581 | 13207-D4200 | | CEFIRO (RWD) A31 RB20D#,RB25D | 88/9~94/ | Engine VALVE STEM SEAL |
| 03903 2011 | 13042-16V00 | 40 x 52 x 7 | CEFIRO (RWD) A31 RB20#,RB25D | 88/9~94/ | Engine CAM SHAFT |
| 03903 3397 | 12279-T7202 | 80 x 100 x 10 | CEFIRO (RWD) A31 RB20# | 88/9~90/1 | Engine CRANK SHAFT REAR |
| 03903 3353 | 12279-58S00 | 80 x 100 x 10 | CEFIRO (RWD) A31 RB20#,RB25D | 90/1~94/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5677 | 13207-D0101 | | CEFIRO (RWD) A31 RB20E(IN.) | 88/9~94/ | Engine VALVE STEM SEAL |
| 03903 5283 | 13207-81W00 | | CEFIRO (RWD) A31 RB20E(EX.) | 88/9~94/ | Engine VALVE STEM SEAL |
| 03903 4711 | 40232-33P00 | 56 x 76 x 6 x 11 | CEFIRO (RWD) A31 (4WD) | 90/8~94/ | Wheel Hub FRONT INNER |
| 03903 5253 | 49297-42L00 | | CEFIRO (RWD) A31 | 88/9~94/ | Steering (P/S) PINION SEAL SET |
| 03903 2619 | 43252-30P00 | 58 x 77 x 8 | CEFIRO (RWD) A31 (4WD) | 90/8~94/ | Wheel Hub REAR |
| 03903 3195 | 40232-33P00 | 56 x 76 x 6 x 11 | CEFIRO (RWD) A31 (4WD) | 90/8~94/ | Wheel Hub FRONT OUTER |
| 03903 1503 | 49277-42L00 | | CIMA Y31 | 88/1~91/ | Steering (P/S) PISTON SEAL SET |
| 03903 4691 | 38189-N3100 | 40 x 75 x 12 x 17.5 | CIMA Y31 CIMA-1 WITHOUT(ABS) | 88/1~91/ | Final Drive PINION |
| 03903 5119 | 38189-Y0810 | 40 x 75 x 12 | CIMA Y31 CIMA-1(ABS),CIMA-2,CIMA-L | 88/1~91/ | Final Drive PINION |
| 03903 4535 | 38189-Y0810 | 40 x 75 x 12 | CIMA FGY33 (ABS) | 96/6~01/ | Final Drive PINION |
| 03903 1467 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CIMA FGY32 | 91/8~97/ | Final Drive PINION |
| 03903 3563 | 38189-N3112 | 40 x 75 x 13.5 x 21 | CIMA FGY33 WITHOUT(ABS) | 96/6~01/ | Final Drive PINION |
| 03903 6135 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CIMA F50 | 01/1~ | Final Drive PINION |
| 03903 5753 | 38342-N3100 | 35 x 55 x 11 x 18 | CIMA Y31,FGY32,FGY33,F50 | 88/1~ | Final Drive DIFF. SIDE |
| 03903 3671 | 49365-10V26 | | CIMA Y31 | 88/1~91/ | Steering WORM GEAR SEAL KIT |
| 03903 2803 | 49297-10V25 | | CIMA Y31 | 88/1~91/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 5367 | 49365-10V26 | | CIMA FGY32 | 91/8~01/ | Steering (P/S) PINION GEAR KIT |
| 03903 5073 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CIMA FGY32 VH41DE(4WD) | 92/9~97/ | Wheel Hub REAR OUTER |
| 03903 1137 | 49277-G5200 | | CIMA FGY32 | 91/8~97/ | Steering (P/S) PISTON SEAL SET |
| 03903 5107 | 13042-16V00 | 40 x 52 x 7 | CIMA Y31,FGY32 VG30D# | 88/1~97/ | Engine CAM SHAFT |
| 03903 5783 | 13042-16V00 | 40 x 52 x 7 | CIMA Y31,FGY32 VG30D# | 88/1~97/ | Engine CRANK SHAFT FRONT |
| 03903 5087 | 13510-60U00 | 50 x 65 x 8 | CIMA FGY32,FGY33 VH41DE | 91/8~01/ | Engine CRANK SHAFT FRONT |
| 03903 5923 | 13510-2J200 | 46 x 58 x 7 | CIMA F50..VK45DD | 01/1~ | Engine CRANK SHAFT FRONT |
| 03903 3925 | 12279-D0100 | 84 x 104 x 11 | CIMA Y31 VG30D# | 88/1~89/6 | Engine CRANK SHAFT REAR |
| 03903 2311 | 12279-85Y00 | 84 x 104 x 11 | CIMA FGY33 VH41DE | 96/6~97/9 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1189 | 12279-AD205 | 84 x 104 x 8.5 | CIMA FGY33 VH41DE | 97/9~01/ | Engine CRANK SHAFT REAR |
| 03903 4245 | 12279-AD205 | 84 x 104 x 8.5 | CIMA F50 VK45DD | 01/1~ | Engine CRANK SHAFT REAR |
| 03903 2469 | 12296-31U20 | RETAINER ID 97 (F) | CIMA FGY33,F50 VQ30DET | 96/6~ | Engine CRANK SHAFT REAR |
| 03903 4421 | 49297-61U26 | | CIMA FGY32 | 91/8~97/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 6535 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | CIMA FGY32 VH41DE(ALL) | 91/8~93/9 | Wheel Hub REAR INNER |
| 03903 5893 | 13510-31U00 | 48 x 60 x 7 | CIMA FGY33,F50 VQ30DET | 96/6~ | Engine CRANK SHAFT FRONT |
| 03903 3649 | 13207-D0101 | | CIMA FGY32 VH41DE(IN.) | 91/8~93/4 | Engine VALVE STEM SEAL |
| 03903 3899 | 40232-V7000 | 54 x 75.2 x 11.5 x 16 | CIMA Y31 WITHOUT(ABS) | 88/1~91/ | Wheel Hub FRONT |
| 03903 5619 | 40232-17V00 | 54 x 75.3 x 10 x 15 | CIMA Y31 (ABS) | 88/1~91/ | Wheel Hub FRONT |
| 03903 3515 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | CIMA FGY32,FGY33 (2WD) | 91/8~01/ | Wheel Hub FRONT |
| 03903 2743 | 40232-1P450 | 59 x 80.3 x 6 x 11.5 | CIMA FGY32,FGY33,F50 (4WD) | 91/8~ | Wheel Hub FRONT INNER |
| 03903 6283 | 40232-1P450 | 59 x 80.3 x 6 x 11.5 | CIMA FGY32,FGY33,F50 (4WD) | 91/8~ | Wheel Hub FRONT OUTER |
| 03903 1731 | 43232-F6100 | 40 x 62 x 9 x 13 | CIMA Y31 | 88/1~91/ | Wheel Hub REAR |
| 03903 1873 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CIMA FGY32 VG30DET | 94/7~96/6 | Wheel Hub REAR INNER |
| 03903 4149 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CIMA FGY32 VH41DE((STD)+(DSP)+(2WD)) | 95/9~96/6 | Wheel Hub REAR INNER |
| 03903 1875 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | CIMA FGY33 VH41DE(4WD) | 98/9~01/ | Wheel Hub REAR OUTER |
| 03903 4097 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | CIMA FGY32 VG30DET | 93/9~94/7 | Wheel Hub REAR INNER |
| 03903 2441 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CIMA FGY33 VH41DE(4WD) | 97/9~98/9 | Wheel Hub REAR OUTER |
| 03903 3997 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | CIMA FGY32 VH41DE EXCEPT( (STD)+(DSP)+(2WD)) | 95/9~96/6 | Wheel Hub REAR INNER |
| 03903 4981 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | CIMA FGY32 VH41DE(ALL) | 96/6~97/ | Wheel Hub REAR INNER |
| 03903 5405 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | CIMA FGY33 VH41DE(4WD) | 98/9~01/ | Wheel Hub REAR INNER |
| 03903 4533 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CIMA FGY33 VH41DE(4WD) | 97/9~98/9 | Wheel Hub REAR INNER |
| 03903 5161 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CIMA FGY32 VG30DET | 94/7~96/ | Wheel Hub REAR OUTER |
| 03903 4467 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CIMA FGY32 VH41DE(2WD) | 95/9~96/6 | Wheel Hub REAR OUTER |
| 03903 2897 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CIMA FGY33 VQ30DET,VH41DE(2WD) | 96/6~01/ | Wheel Hub REAR OUTER |
| 03903 4449 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CIMA FGY32 VG30DET | 93/9~94/7 | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4445 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CIMA FGY32 VH41DE(2WD) | 91/8~95/9 | Wheel Hub REAR OUTER |
| 03903 4145 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | CIMA FGY32 VH41DE(2WD) | 96/6~97/ | Wheel Hub REAR OUTER |
| 03903 3057 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | CIMA FGY33 VQ30DET,VH41DE(2WD) | 96/6~01/ | Wheel Hub REAR INNER |
| 03903 2555 | 13207-D4200 | | CIMA F50 VQ30DET,VK45DD | 01/1~ | Engine VALVE STEM SEAL |
| 03903 2509 | 13207-42L00 | | CIMA FGY32 VH41DE(EX.) | 91/8~97/ | Engine VALVE STEM SEAL |
| 03903 3627 | 13207-D4200 | | CIMA FGY33 VQ30DET | 96/6~01/ | Engine VALVE STEM SEAL |
| 03903 6071 | 13207-D4200 | | CIMA Y31,FGY32 VG30D# | 88/1~97/ | Engine VALVE STEM SEAL |
| 03903 5433 | 13207-D0101 | | CIMA FGY33 VH41DE FLPG1(IN.) | 99/11~01/ | Engine VALVE STEM SEAL |
| 03903 5025 | 13207-6P000 | | CIMA FGY33 VH41DE(IN. & EX.) | 96/6~99/11 | Engine VALVE STEM SEAL |
| 03903 5527 | 13207-6P000 | | CIMA FGY33 VH41DE EXCEPT FLPG1(IN.) | 99/11~01/ | Engine VALVE STEM SEAL |
| 03903 5639 | 12279-85Y00 | 84 x 104 x 11 | CIMA Y31,FGY32 VG30D#,VH30D#,VH41DE | 89/6~97/ | Engine CRANK SHAFT REAR |
| 03903 1897 | 13207-67U00 | | CIMA FGY32 VH41DE(IN.) | 93/4~97/ | Engine VALVE STEM SEAL |
| 03903 2581 | 43254-0T000 | 51 x 64 x 9.5 | CIVILIAN W41 TD42# | 99/2~ | Wheel Hub REAR OUTER |
| 03903 2125 | 43253-76000 | 89.4 x 95.6 x 3.1 | CIVILIAN W40 Z22S,ED33,ED35 | 82/8~93/4 | Wheel Hub REAR O-RING |
| 03903 1187 | 43253-T9310 | 96.9 x 101.7 x 2.4 | CIVILIAN W40 FD33T,TD42 | 84/6~93/4 | Wheel Hub REAR O-RING |
| 03903 1123 | 32113-86401 | 28 x 40 x 8 | CIVILIAN W40 Z22S,ED33,ED35 | 82/8~99/ | Transmission FRONT COVER |
| 03903 4827 | 43254-0T000 | 51 x 64 x 9.5 | CIVILIAN W40 | 93/4~99/ | Wheel Hub REAR OUTER |
| 03903 4851 | 32113-VB000 | 32 x 45 x 8 | CIVILIAN W41 TD42# | 99/2~ | Transmission FRONT COVER |
| 03903 6533 | 43252-82100 | 80 x 105 x 13 | CIVILIAN W40 | 82/8~93/4 | Wheel Hub REAR INNER |
| 03903 5259 | 32136-J6500 | 40 x 62 x 11 | CIVILIAN W40 Z22S,ED33,ED35 | 82/8~99/ | Transmission REAR EXTENSION |
| 03903 3173 | 32219-Z5003 | 32 x 45 x 8 | CIVILIAN W40 FD33T,TD42 | 84/6~99/ | Transmission FRONT COVER |
| 03903 4877 | 43252-T9310 | 43 x 52 x 10.3 | CIVILIAN W40 FD33T,TD42 | 84/6~93/4 | Wheel Hub REAR OUTER |
| 03903 1371 | 43252-J2000 | 38 x 47 x 10 | CIVILIAN W40 Z22S,ED33,ED35 | 82/8~93/4 | Wheel Hub REAR OUTER |
| 03903 4699 | 43232-0T000 | 80 x 101 x 10.5 | CIVILIAN W41 TD42# | 99/2~ | Wheel Hub REAR INNER |
| 03903 3511 | 40227-0T000 | 77 x 91 x 6 x 10 | CIVILIAN W40 | 93/4~99/ | Wheel Hub FRONT |
| 03903 3379 | 43213-76000 | 78.4 x 95 x 8 | CIVILIAN W40 VAN | 84/6~88/5 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5325 | 40227-0T000 | 77 x 91 x 6 x 10 | CIVILIAN W41 TD42# | 99/2~ | Wheel Hub FRONT |
| 03903 5461 | 32136-Z5000 | 58 x 75 x 9 | CIVILIAN W40 FD33T | 84/6~88/5 | Transmission REAR EXTENSION |
| 03903 6559 | 13510-43G00 | 58 x 80 x 10 | CIVILIAN W40,W41 TD42 | 88/5~00/2 | Engine CRANK SHAFT FRONT |
| 03903 4331 | 43232-0T000 | 80 x 101 x 10.5 | CIVILIAN W40 | 93/4~99/ | Wheel Hub REAR INNER |
| 03903 5301 | 40227-J5110 | 60 x 82 x 7 | CIVILIAN W40 | 82/8~93/4 | Wheel Hub FRONT |
| 03903 2413 | 13207-V1700 | | CIVILIAN TD42# | 88/5~ | Engine VALVE STEM SEAL |
| 03903 1261 | 13207-Z5001 | | CIVILIAN ED33,ED35,FD33T | 82/8~97/11 | Engine VALVE STEM SEAL |
| 03903 4807 | 12279-43G02 | 86 x 100 x 10 | CIVILIAN W40 TD42 | 88/5~95/8 | Engine CRANK SHAFT REAR |
| 03903 5349 | 12279-01T00 | 105 x 135 x 9 | CIVILIAN W40 ED33,ED35,FD33T | 82/8~99/ | Engine CRANK SHAFT REAR |
| 03903 5145 | 12279-R4611 | 80 x 100 x 13 | CIVILIAN W40 Z22S | 82/8~88/5 | Engine CRANK SHAFT REAR |
| 03903 2765 | 13510-51N01 | 60 x 80 x 7 | CIVILIAN W40,W41 TD42T | 95/8~ | Engine CRANK SHAFT FRONT |
| 03903 5009 | 13510-43G01 | 58 x 80 x 7 | CIVILIAN W41 TD42 | 00/2~ | Engine CRANK SHAFT FRONT |
| 03903 2717 | 13042-A8601 | 48 x 70 x 9 | CIVILIAN W40 Z22S | 82/8~88/5 | Engine CRANK SHAFT FRONT |
| 03903 2141 | 12279-T9000 | 62 x 85 x 12.5 | CIVILIAN W40 ED33,ED35,FD33T | 82/8~99/ | Engine CRANK SHAFT FRONT |
| 03903 4497 | 32136-02T00 | 50 x 74 x 12 | CIVILIAN W40,W41 TD42# | 88/5~ | Transmission REAR EXTENSION |
| 03903 3589 | 48029-04100 | 17 x 31 x 7 | CIVILIAN W40 | 82/8~93/4 | Steering WORM |
| 03903 5869 | 48040-82100 | 35 x 48 x 8 | CIVILIAN W40 | 82/8~93/4 | Steering SECTOR SHAFT |
| 03903 3487 | 38189-T8011 | 56 x 72 x 11 x 18 | CIVILIAN W41 TD42# | 99/2~ | Final Drive PINION |
| 03903 5171 | 38189-T8011 | 56 x 72 x 11 x 18 | CIVILIAN W40 TD42 | 91/10~99/ | Final Drive PINION |
| 03903 1211 | 38189-61500 | 56 x 72 x 9 | CIVILIAN W40 FD33T,TD42 | 84/6~91/10 | Final Drive PINION |
| 03903 5515 | 38189-J2011 | 42 x 72.5 x 13 x 21 | CIVILIAN W40 ED35 | 90/11~99/ | Final Drive PINION |
| 03903 2075 | 38189-J2000 | 42 x 72.5 x 12 | CIVILIAN W40 Z22S,ED33,ED35 | 82/8~90/11 | Final Drive PINION |
| 03903 5287 | 13207-81W00 | | CIVILIAN Z22S | 82/8~88/5 | Engine VALVE STEM SEAL |
| 03903 1877 | 13207-Z5500 | | CIVILIAN ED35 | 97/11~99/ | Engine VALVE STEM SEAL |
| 03903 2533 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CREW K30 NA20P(WITHOUT ABS),RB20E,RD28E | 03/5~ | Final Drive PINION |
| 03903 2831 | 13042-D0100 | 34 x 48 x 8 | CREW K30(S) RD28(E) | 93/7~ | Engine CAM SHAFT |
| 03903 6541 | 40232-17V00 | 54 x 75.3 x 10.15 | CREW K30(S) | 93/7~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2275 | 43252-H1000 | 41 x 56 x 7 | CREW K30(S) | 93/7~ | Wheel Hub REAR |
| 03903 2855 | 32114-Y4000 | 30 x 45 x 8 | CREW K30(S) | 93/7~ | Transmission (M/T) FRONT COVER |
| 03903 3187 | 32136-U0100 | 35 x 50 x 11 | CREW K30(S) | 93/7~ | Transmission (M/T) REAR EXTENSION |
| 03903 2889 | 38189-P0101 | 45 x 75 x 12 | CREW K30(S) | 99/8~03/5 | Final Drive PINION |
| 03903 4805 | 38189-P0117 | 45 x 75 x 14 x 19.5 | CREW K30(S) | 93/7~99/8 | Final Drive PINION |
| 03903 1753 | 12279-5L300 | 80 x 100 x 8.5 | CREW K30(S) ALL | 93/10~ | Engine CRANK SHAFT REAR |
| 03903 1987 | 13207-81W00 | | CREW RB20E(EX.) | 94/1~ | Engine VALVE STEM SEAL |
| 03903 6501 | 13207-D0101 | | CREW RB20E(IN.) | 94/1~ | Engine VALVE STEM SEAL |
| 03903 1275 | 13207-D0101 | | CREW RD28(E) | 93/7~ | Engine VALVE STEM SEAL |
| 03903 5321 | 38189-P0101 | 45 x 75 x 12 | CREW K30 NA20P WITH ABS | 03/5~ | Final Drive PINION |
| 03903 4843 | 13207-42L00 | | CREW NA20P | 93/7~02/6 | Engine VALVE STEM SEAL |
| 03903 6007 | 13042-16V00 | 40 x 52 x 7 | CREW K30(S) RB20E | 94/1~ | Engine CAM SHAFT |
| 03903 3213 | 12279-5L300 | 80 x 100 x 8.5 | CREW K30 EXCEPT NA20P | 93/7~93/10 | Engine CRANK SHAFT REAR |
| 03903 5937 | 12279-58S00 | 80 x 100 x 10 | CREW K30 NA20P | 93/7~93/10 | Engine CRANK SHAFT REAR |
| 03903 2511 | 13510-0H600 | 48 x 70 x 7 | CREW K30 NA20P | 93/7~ | Engine CRANK SHAFT FRONT |
| 03903 2837 | 13510-V7202 | 40 x 52 x 7 | CREW K30(S) RD28E | 99/8~ | Engine CRANK SHAFT FRONT |
| 03903 6407 | 13042-16V00 | 40 x 52 x 7 | CREW K30(S) RD28 | 93/7~99/8 | Engine CRANK SHAFT FRONT |
| 03903 1013 | 13042-16V00 | 40 x 52 x 7 | CREW K30(S) RB20E | 94/1~ | Engine CRANK SHAFT FRONT |
| 03903 2447 | 13207-D0101 | | CREW NA20P | 02/6~ | Engine VALVE STEM SEAL |
| 03903 3585 | 13510-V7202 | 40 x 52 x 7 | CUBE Z10 CGA3DE | 99/11`02/ | Engine CRANK SHAFT FRONT |
| 03903 4957 | 38342-M8001 | 40 x 56 x 8 | CUBE Z10 (CVT) | 98/2~99/11 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4255 | 13207-53Y00 | | CUBE Z11,GZ11 CR14DE | 02/10~ | Engine VALVE STEM SEAL |
| 03903 2851 | 13207-53Y00 | | CUBE Z10 CG13DE,CGA3DE | 98/2~02/ | Engine VALVE STEM SEAL |
| 03903 3471 | 12279-AD205 | 84 x 104 x 8.5 | CUBE Z11,GZ11 CR14DE | 02/10~ | Engine CRANK SHAFT REAR |
| 03903 2147 | 12279-AD205 | 84 x 104 x 8.5 | CUBE Z10 CG13DE,CGA3DE | 98/2~02/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2615 | 13510-V7202 | 40 x 52 x 7 | CUBE Z11,GZ11 CR14DE | 02/10~ | Engine CRANK SHAFT FRONT |
| 03903 3193 | 38342-8E000 | 40 x 52 x 8 x 13 | CUBE Z11,GZ11 | 02/10~ | Mission & Differential (A/T) MISSION CASE |
| 03903 3623 | 38342-M8001 | 40 x 56 x 8 | CUBE Z10 (CVT) | 98/2~99/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 4513 | 40227-21B00 | 48 x 62 x 6 x 10 | CUBE Z10 | 98/2~02/ | Wheel Hub FRONT DUST SEAL |
| 03903 4307 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | CUBE Z10 | 98/2~02/ | Wheel Hub FRONT GREASE SEAL |
| 03903 3971 | 38342-06R00 | 52 x 70 x 9 | CUBE Z10 (CVT),(MCVT),(4WD) | 99/11~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6361 | 38342-8E000 | 40 x 52 x 8 x 13 | CUBE Z10 (F4) | 00/9~02/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5793 | 13042-16V00 | 40 x 52 x 7 | CUBE Z10 CG13DE | 98/2~99/11 | Engine CRANK SHAFT FRONT |
| 03903 1007 | 38342-31X00 | 40 x 56 x 8 x 13.5 | CUBE Z10 (F4) | 98/2~00/9 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3655 | 38342-31X00 | 40 x 56 x 8 x 13.5 | CUBE Z10 (F4) | 98/2~00/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 4803 | 38342-32X00 | 40 x 52 x 8 x 13 | CUBE Z10 (CVT),(MCVT),(2WD) | 99/11~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2819 | 38342-8E000 | 40 x 52 x 8 x 13 | CUBE Z10 (F4) | 00/9~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1489 | 38342-8E000 | 40 x 52 x 8 x 13 | CUBE Z11,GZ11 | 02/10~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2483 | 49297-5M385 | | CUBE Z10 CENTER BUSH | 98/2~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 2403 | 49297-65F25 | | CUBE Z10 WITHOUT CENTER BUSH | 00/8~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 6109 | 49365-10V26 | | CUBE Z10 | 98/2~ | Steering (P/S) PINION GEAR KIT |
| 03903 6307 | 38342-8E000 | 40 x 52 x 8 x 13 | CUBE Z10 (CVT),(MCVT) | 99/11~02/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5035 | 49321-Y0100 | 28 x 40 x 8 | DATSUN TRUCK D21 | 85/8~92/8 | Steering SECTOR SHAFT |
| 03903 4583 | 38189-P0117 | 45 x 75 x 14 x 19.5 | DATSUN TRUCK D21 HF# FINAL DRIVE | 91/7~97/ | Rear Final Drive PINION |
| 03903 5047 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D21 HG# FINAL DRIVE | 92/8~97/ | Rear Final Drive PINION |
| 03903 3305 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D22 QD32 | 97/1~01/6 | Rear Final Drive PINION |
| 03903 2899 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D22 KA24DE(F5) | 99/6~01/6 | Rear Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5765 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D22 ABS(NA20S,TD27) | 97/1~97/12 | Rear Final Drive PINION |
| 03903 5653 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D22 LSD(NA20S,TD27) | 97/12~99/6 | Rear Final Drive PINION |
| 03903 2755 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D22 LSD AND ABS(KA20DE,KA24DE.R4) | 99/6~02/ | Rear Final Drive PINION |
| 03903 1641 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | DATSUN TRUCK D22 ABS(KA20DE,KA24DE.R4) | 99/6~02/ | Rear Final Drive PINION |
| 03903 4035 | 38189-N3112 | 40 x 75 x 13.5 x 21 | DATSUN TRUCK D22 LSD(KA20DE,KA24DE.R4) | 99/6~02/ | Rear Final Drive PINION |
| 03903 3335 | 49321-Y0100 | 28 x 40 x 8 | DATSUN TRUCK 720 | 79/9~85/ | Steering SECTOR SHAFT |
| 03903 3501 | 38189-N3112 | 40 x 75 x 13.5 x 21 | DATSUN TRUCK D22 NA20S,TD27,KA24DE | 97/1~99/6 | Rear Final Drive PINION |
| 03903 5051 | 48137-92G00 | 34 x 44 x 8 | DATSUN TRUCK D21 | 92/8~97/ | Steering SECTOR SHAFT |
| 03903 6367 | 48029-W0501 | 17.5 x 32 x 7 | DATSUN TRUCK 720 | 79/9~85/ | Steering WORM |
| 03903 4705 | 48029-W0501 | 17.5 x 32 x 7 | DATSUN TRUCK D21 | 85/8~92/8 | Steering WORM |
| 03903 3243 | 48029-92G00 | 18 x 30 x 8 | DATSUN TRUCK D21 | 82/8~97/ | Steering WORM |
| 03903 4549 | 49202-01C26 | | DATSUN TRUCK D21 2WD | 87/8~97/ | Steering (P/S) SECTOR SHAFT KIT |
| 03903 4251 | 49202-01C26 | | DATSUN TRUCK D22 2WD | 97/1~99/6 | Steering (P/S) SECTOR SHAFT KIT |
| 03903 1899 | 49202-01C26 | | DATSUN TRUCK D22 KA20DE,KA24DE.AT.R4,TD27 | 99/6~ | Steering (P/S) SECTOR SHAFT KIT |
| 03903 6427 | 49202-Y0127 | | DATSUN TRUCK D21 4WD | 85/8~92/8 | Steering (P/S) SECTOR SHAFT KIT |
| 03903 4043 | 49321-55G26 | | DATSUN TRUCK D21 4WD | 92/8~97/ | Steering (P/S) SECTOR SHAFT KIT |
| 03903 6471 | 48137-36700 | 26 x 40 x 7 | DATSUN TRUCK 620 | 72/~79/ | Steering SECTOR SHAFT |
| 03903 1393 | 38342-01G01 | 39 x 52 x 11 | DATSUN TRUCK D22 4WD | 97/1~02/ | Front Final Drive DIFF. SIDE (RH) |
| 03903 2991 | 33111-31G00 | 50 x 72 x 12 | DATSUN TRUCK D21,D22 MT | 85/8~02/ | Transfer COVER |
| 03903 1853 | 33111-46G00 | 50 x 72 x 12 | DATSUN TRUCK D21,D22 A/T | 92/8~00/7 | Transfer COVER |
| 03903 4101 | 33114-C6901 | 45 x 72 x 14 | DATSUN TRUCK 720 | 80/4~85/ | Transfer COVER |
| 03903 3659 | 33216-33G01 | 40 x 75 x 12 x 20 | DATSUN TRUCK D21,D22 | 85/8~02/ | Transfer CASE (FRONT) |
| 03903 1459 | 33114-C6901 | 45 x 72 x 14 | DATSUN TRUCK 720 | 80/4~85/ | Transfer CASE (FRONT) |
| 03903 2273 | 33142-33G10 | 42 x 66 x 10 | DATSUN TRUCK D21,D22 | 85/8~02/ | Transfer CASE (REAR) |
| 03903 1649 | 33114-C6901 | 45 x 72 x 14 | DATSUN TRUCK 720 | 80/4~85/ | Transfer CASE (REAR) |
| 03903 1159 | 38189-U3000 | 35 x 67 x 12 x 18 | DATSUN TRUCK 720 4WD | 80/4~85/ | Front Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3795 | 38189-01G00 | 35 x 67 x 12 x 20.5 | DATSUN TRUCK D21 4WD | 85/8~91/7 | Front Final Drive PINION |
| 03903 5669 | 38189-N3112 | 40 x 75 x 13.5 x 21 | DATSUN TRUCK D22 KA20DE,KA24DE(R4,F4) | 99/6~02/ | Rear Final Drive PINION |
| 03903 1917 | 38342-01G00 | 32 x 52 x 10.5 x 15.5 | DATSUN TRUCK D22 4WD | 97/1~02/ | Front Final Drive DIFF. SIDE (LH) |
| 03903 6171 | 49345-Y0125 | | DATSUN TRUCK D21 2WD,4WD | 85/8~92/8 | Steering (P/S) GEAR HOUSING KIT |
| 03903 4709 | 40227-31G00 | 50 x 72 x 14.5 | DATSUN TRUCK D21,D22 | 85/8~02/ | Front Final Drive SIDE SHAFT (RH) |
| 03903 2263 | 38189-A6100 | 35 x 64 x 13 | DATSUN TRUCK 620 | 72/~79/ | Rear Final Drive PINION |
| 03903 1965 | 38189-A6100 | 35 x 64 x 13 | DATSUN TRUCK 720 J16 | 79/9~81/12 | Rear Final Drive PINION |
| 03903 2299 | 38189-N3100 | 40 x 75 x 12 x 17.5 | DATSUN TRUCK D21 CA# FINAL DRIVE | 85/8~91/7 | Rear Final Drive PINION |
| 03903 2431 | 38189-P0101 | 45 x 75 x 12 | DATSUN TRUCK 720 L18,SD22 | 79/9~81/12 | Rear Final Drive PINION |
| 03903 3867 | 38189-P0101 | 45 x 75 x 12 | DATSUN TRUCK 720 ALL | 82/1~85/ | Rear Final Drive PINION |
| 03903 3561 | 38189-P0101 | 45 x 75 x 12 | DATSUN TRUCK D21 HF# FINAL DRIVE | 85/8~91/7 | Rear Final Drive PINION |
| 03903 2559 | 38189-N3112 | 40 x 75 x 13.5 x 21 | DATSUN TRUCK D21 CA# FINAL DRIVE | 91/7~97/ | Rear Final Drive PINION |
| 03903 1687 | 38189-N3112 | 40 x 75 x 13.5 x 21 | DATSUN TRUCK D22 QD32 | 01/6~02/ | Rear Final Drive PINION |
| 03903 5537 | 38189-01G16 | 35 x 67 x 13.7 x 19.5 | DATSUN TRUCK D21,D22 4WD | 91/7~02/ | Front Final Drive PINION |
| 03903 1241 | 12279-5L300 | 80 x 100 x 8.5 | DATSUN TRUCK D22 NA20S,KA20DE,KA24# | 97/1~02/ | Engine CRANK SHAFT FRONT |
| 03903 6243 | 13510-43G00 | 58 x 80 x 10 | DATSUN TRUCK D21 TD23,TD27# | 87/8~97/ | Engine CRANK SHAFT FRONT |
| 03903 5333 | 13510-43G00 | 58 x 80 x 10 | DATSUN TRUCK D22 QD32,TD27 | 97/1~00/2 | Engine CRANK SHAFT FRONT |
| 03903 5877 | 13510-53J00 | 46 x 58 x 7 | DATSUN TRUCK D22 KA20DE,KA24# | 97/1~02/ | Engine CRANK SHAFT FRONT |
| 03903 5381 | 13510-43G01 | 58 x 80 x 7 | DATSUN TRUCK D22 QD32,TD27 | 00/2~02/ | Engine CRANK SHAFT FRONT |
| 03903 2673 | 12279-T7202 | 80 x 100 x 10 | DATSUN TRUCK 720 SD22,SD33 | 82/1~85/ | Engine CRANK SHAFT FRONT |
| 03903 3251 | 12279-T7202 | 80 x 100 x 10 | DATSUN TRUCK D21 SD23 | 85/8~87/8 | Engine CRANK SHAFT FRONT |
| 03903 4457 | 12279-76200 | | DATSUN TRUCK 620,720 SD22 | 78/9~81/12 | Engine CRANK SHAFT FRONT |
| 03903 5717 | 12279-09400 | | DATSUN TRUCK 620,720 J15,J16 | 72/~80/10 | Engine CRANK SHAFT FRONT |
| 03903 1891 | 12279-58000 | | DATSUN TRUCK 720 J16 | 80/11~81/12 | Engine CRANK SHAFT FRONT |
| 03903 3047 | 49321-55G26 | | DATSUN TRUCK D22 4WD | 97/1~99/6 | Steering (P/S) SECTOR SHAFT KIT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3297 | 12279-58S00 | 80 x 100 x 10 | DATSUN TRUCK D21 NA16S,NA20S,Z16S,Z18S,Z 20S | 85/8~97/ | Engine CRANK SHAFT FRONT |
| 03903 2293 | 13042-B3000 | 39.7 x 62 x 11 | DATSUN TRUCK 620,720 J15,J16 | 72,~81/12 | Engine CRANK SHAFT FRONT |
| 03903 4015 | 12279-43G05 | | DATSUN TRUCK D21 TD27# | 95/8~97/ | Engine CRANK SHAFT FRONT |
| 03903 3781 | 12279-43G05 | | DATSUN TRUCK D22 QD32,TD27 | 97/1~02/ | Engine CRANK SHAFT FRONT |
| 03903 3945 | 13207-21002 | | DATSUN TRUCK L18,Z16,Z18 | 79/9~85/7 | Engine VALVE STEM SEAL |
| 03903 6107 | 13207-76200 | | DATSUN TRUCK SD22 | 78/9~83/4 | Engine VALVE STEM SEAL |
| 03903 3657 | 13207-C6000 | | DATSUN TRUCK J16 | 79/9~81/2 | Engine VALVE STEM SEAL |
| 03903 2585 | 13207-D0101 | | DATSUN TRUCK KA20DE,KA24# | 97/1~02/ | Engine VALVE STEM SEAL |
| 03903 5681 | 13207-V1700 | | DATSUN TRUCK SD23 | 83/4~87/8 | Engine VALVE STEM SEAL |
| 03903 4167 | 13207-V1700 | | DATSUN TRUCK TD23,TD27#,QD32 | 87/8~02/ | Engine VALVE STEM SEAL |
| 03903 3953 | 13207-81W00 | | DATSUN TRUCK Z16S,Z18S,Z20S | 85/8~89/9 | Engine VALVE STEM SEAL |
| 03903 2341 | 12279-43G02 | 86 x 100 x 10 | DATSUN TRUCK D21 TD23,TD27# | 87/8~95/8 | Engine CRANK SHAFT FRONT |
| 03903 3863 | 49201-V0125 | | DATSUN TRUCK D21 2WD | 87/8~97/ | Steering (P/S) ADJUSTER SCREW KIT |
| 03903 1685 | 32114-Y4000 | 30 x 45 x 8 | DATSUN TRUCK D21,D22 | 85/8~02/ | Transmission FRONT COVER |
| 03903 2725 | 49345-Y0125 | | DATSUN TRUCK D22 NA20S | 97/1~99/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4979 | 49345-11G25 | | DATSUN TRUCK D21 2WD | 92/8~97/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1855 | 49345-11G25 | | DATSUN TRUCK D22 2WD | 97/1~99/6 | Steering (P/S) GEAR HOUSING KIT |
| 03903 5523 | 49345-11G25 | | DATSUN TRUCK D22 KA20DE,KA24DE.AT.R4,T D27 | 99/6~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 6239 | 49345-55G26 | | DATSUN TRUCK D21 4WD | 92/8~97/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3405 | 49345-55G26 | | DATSUN TRUCK D22 4WD | 97/1~99/6 | Steering (P/S) GEAR HOUSING KIT |
| 03903 3263 | 49345-55G26 | | DATSUN TRUCK D22 QD32,KA24DE(MT.F5+AT. F4) | 99/6~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4949 | 49203-V0225 | | DATSUN TRUCK D21 2WD | 87/8~97/ | Steering (P/S) WORM GEAR KIT |
| 03903 1333 | 13042-T7200 | 58 x 80 x 12 | DATSUN TRUCK D21 SD23 | 85/8~87/8 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3135 | 49203-Y0127 | | DATSUN TRUCK D21 4WD | 85/8~92/8 | Steering (P/S) WORM GEAR KIT |
| 03903 1985 | 13042-T7200 | 58 x 80 x 12 | DATSUN TRUCK 620,720 SD22,SD33 | 78/9~85/ | Engine CRANK SHAFT FRONT |
| 03903 5131 | 49201-V0125 | | DATSUN TRUCK D21 4WD | 85/8~92/8 | Steering (P/S) ADJUSTER SCREW KIT |
| 03903 5271 | 49227-Y0102 | | DATSUN TRUCK D21 2WD | 87/8~97/ | Steering (P/S) PISTON SEAL SET |
| 03903 4443 | 49227-Y0102 | | DATSUN TRUCK D21 4WD | 85/8~92/8 | Steering (P/S) PISTON SEAL SET |
| 03903 6537 | 13042-A8601 | 48 x 70 x 9 | DATSUN TRUCK 720 L18,Z16,Z18 | 79/9~85/ | Engine CRANK SHAFT FRONT |
| 03903 4563 | 13042-A8601 | 48 x 70 x 9 | DATSUN TRUCK D21 Z16S,Z18S,Z20S,NA16S,NA 20S | 85/8~97/ | Engine CRANK SHAFT FRONT |
| 03903 2575 | 13042-A8601 | 48 x 70 x 9 | DATSUN TRUCK D22 NA20S | 97/1~99/6 | Engine CRANK SHAFT FRONT |
| 03903 3651 | 49321-55G26 | | DATSUN TRUCK D22 QD32,KA24DE(MT.F5+AT. F4) | 99/6~ | Steering (P/S) SECTOR SHAFT KIT |
| 03903 4215 | 49203-V0225 | | DATSUN TRUCK D22 | 97/1~ | Steering (P/S) WORM GEAR KIT |
| 03903 1465 | 40232-50W01 | 57 x 79 x 10.5 x 16 | DATSUN TRUCK 720 4WD | 83/4~85/ | Wheel Hub FRONT |
| 03903 6019 | 32136-U0100 | 35 x 50 x 11 | DATSUN TRUCK 620,720,D21,D22 | 72/~02/ | Transmission REAR EXTENSION |
| 03903 3485 | 13207-42L00 | | DATSUN TRUCK NA16S,NA20S | 89/9~02/ | Engine VALVE STEM SEAL |
| 03903 6473 | 33111-01J00 | 50 x 72 x 12 | DATSUN TRUCK D22 AT | 00/7~02/ | Transfer COVER |
| 03903 3943 | 40227-73000 | 48 x 65 x 10 | DATSUN TRUCK 620 | 72/~77/8 | Wheel Hub FRONT |
| 03903 5947 | 40232-B9500 | 54 x 65 x 13 | DATSUN TRUCK 620 | 77/9~79/ | Wheel Hub FRONT |
| 03903 4023 | 40232-B9500 | 54 x 65 x 13 | DATSUN TRUCK 720 2WD | 79/9~85/ | Wheel Hub FRONT |
| 03903 5049 | 40232-01G00 | 54 x 75.3 x 12 x 18 | DATSUN TRUCK D21 2WD | 85/8~97/ | Wheel Hub FRONT |
| 03903 1161 | 40232-31G00 | 57 x 79 x 9 x 13.5 | DATSUN TRUCK D21 4WD | 85/8~97/ | Wheel Hub FRONT |
| 03903 2933 | 40232-31G00 | 57 x 79 x 9 x 13.5 | DATSUN TRUCK D22 4WD | 97/1~02/ | Wheel Hub FRONT |
| 03903 4383 | 40232-3S600 | 54 x 65 x 10 x 15 | DATSUN TRUCK D22 2WD | 97/1~02/ | Wheel Hub FRONT |
| 03903 1091 | 40227-41W03 | 60 x 90 x 22 | DATSUN TRUCK 720 4WD | 80/4~83/3 | Wheel Hub FRONT DRIVE SHAFT |
| 03903 5311 | 40227-50W01 | 50 x 72 x 83 x 16.2 | DATSUN TRUCK 720 4WD | 83/4~85/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 3873 | 40227-31G00 | 50 x 72 x 14.5 | DATSUN TRUCK D21 .4WD | 85/8~97/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 1083 | 43232-42G10 | 55 x 74 x 10 x 13.5 | DATSUN TRUCK D21 DIFF. LOCK | 92/8~97/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1683 | 32114-Y4000 | 30 x 45 x 8 | DATSUN TRUCK 720 EXCEPT J16 | 79/9~85/ | Transmission FRONT COVER |
| 03903 1169 | 40232-41W00 | 72 x 88 x 7 | DATSUN TRUCK 720 4WD | 80/4~83/3 | Wheel Hub FRONT |
| 03903 3739 | 40227-31G01 | 50 x 93 x 24 | DATSUN TRUCK D21 .4WD | 85/8~97/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 3259 | 32113-N2101 | 34 x 50 x 7 | DATSUN TRUCK 620,720 J16 | 72/~81/ | Transmission FRONT COVER |
| 03903 3489 | 32114-Y4000 | 30 x 45 x 8 | DATSUN TRUCK 620 SD22 | 78/8~79/ | Transmission FRONT COVER |
| 03903 2023 | 43232-42G10 | 55 x 74 x 10 x 13.5 | DATSUN TRUCK D22 ABS | 97/1~02/ | Wheel Hub REAR OUTER |
| 03903 5603 | 43232-01G00 | 50 x 70 x 12 x 17 | DATSUN TRUCK D22 WITHOUT ABS | 97/1~02/ | Wheel Hub REAR OUTER |
| 03903 3929 | 43232-01G00 | 50 x 70 x 12 x 17 | DATSUN TRUCK D21 WITHOUT DIFF. LOCK | 85/8~97/ | Wheel Hub REAR OUTER |
| 03903 3763 | 43232-B5000 | 50 x 67 x 11 | DATSUN TRUCK 620,72 | 72/~85/ | Wheel Hub REAR OUTER |
| 03903 5625 | 43252-VW000 | 35 x 55 x 11 | DATSUN TRUCK D21,D22 | 85/8~02/ | Wheel Hub REAR INNER |
| 03903 6341 | 38212-73000 | 34 x 55 x 11 | DATSUN TRUCK 620,72 | 72/~85/ | Wheel Hub REAR INNER |
| 03903 5505 | 40227-20N00 | 51 x 93 x 24 | DATSUN TRUCK D22 4WD | 97/1~02/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 3857 | 12279-43G05 | | ELGRAND E50 QD32ETI | 97/5~99/8 | Engine CRANK SHAFT REAR |
| 03903 2117 | 13207-D4200 | | ELGRAND E50,E51 VQ35DE | 97/5~ | Engine VALVE STEM SEAL |
| 03903 2007 | 13207-81W00 | | ELGRAND E50 VG33E(IN.) | 97/5~00/8 | Engine VALVE STEM SEAL |
| 03903 2689 | 13207-V1700 | | ELGRAND E50 QD32ETI | 97/5~99/8 | Engine VALVE STEM SEAL |
| 03903 4451 | 13207-D0101 | | ELGRAND E50 ZD30DDTI | 99/8~ | Engine VALVE STEM SEAL |
| 03903 2737 | 13207-D0101 | | ELGRAND E50 VG33E(EX.) | 97/5~00/8 | Engine VALVE STEM SEAL |
| 03903 6481 | 12279-2W201 | | ELGRAND E50 ZD30DDTI | 99/8~ | Engine CRANK SHAFT REAR |
| 03903 4063 | 33142-33G10 | 42 x 66 x 10 | ELGRAND E50,E51 (4WD) | 97/5~ | Transfer CASE (REAR) |
| 03903 5993 | 40232-31G00 | 57 x 79 x 9 x 13.5 | ELGRAND E50 | 97/5~ | Wheel Hub FRONT |
| 03903 1825 | 40227-31G01 | 50 x 93 x 24 | ELGRAND E50 (4WD) | 97/5~ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 6129 | 43252-0W000 | 36 x 55 x 11 | ELGRAND E50 | 97/5~ | Wheel Hub REAR INNER |
| 03903 1805 | 43232-42G10 | 55 x 74 x 10 x 13.5 | ELGRAND E50 | 97/5~ | Wheel Hub REAR OUTER |
| 03903 5239 | 31375-51X03 | 46 x 63 x 7.7 x 8.5 | ELGRAND E50,E51 (4WD) | 97/5~ | Transfer COVER |
| 03903 1625 | 12296-31U20 | | ELGRAND E50,E51 VQ35DE | 00/8~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3815 | 33216-33G01 | 40 x 75 x 12 x 20 | ELGRAND E50,E51 (4WD) | 97/5~ | Transfer CASE (FRONT) |
| 03903 3673 | 12279-AD205 | 84 x 104 x 8.5 | ELGRAND E50 VG33E | 97/5~00/8 | Engine CRANK SHAFT REAR |
| 03903 5275 | 38189-P0117 | 45 x 75 x 14 x 19.5 | ELGRAND E51 | 02/5~ | Final Drive PINION |
| 03903 4791 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | ELGRAND E50 | 97/5~ | Final Drive PINION |
| 03903 4613 | 38342-N3100 | 35 x 55 x 11 x 18 | ELGRAND E51 | 02/5~ | Final Drive DIFF. SIDE |
| 03903 6553 | 13510-31U00 | 48 x 60 x 7 | ELGRAND E50,E51 VQ35DE | 00/8~ | Engine CRANK SHAFT FRONT |
| 03903 4121 | 13042-16V00 | 40 x 52 x 7 | ELGRAND E50 VG33E | 97/5~00/8 | Engine CRANK SHAFT FRONT |
| 03903 3555 | 13510-43G00 | 58 x 80 x 10 | ELGRAND E50 QD32ETI | 97/5~99/8 | Engine CRANK SHAFT FRONT |
| 03903 5331 | 13042-D0100 | 34 x 48 x 8 | ELGRAND E50 VG33E | 97/5~00/8 | Engine CAM SHAFT |
| 03903 4557 | 13510-2W201 | 52 x 66 x 7 | ELGRAND E50 ZD30DDTI | 99/8~ | Engine CRANK SHAFT FRONT |
| 03903 2835 | 38342-D2100 | 40 x 56 x 65 x 20 | EXA KN13 | 86/10~90/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4609 | 39252-52A00 | 52 x 78.4 x 9.5 | EXA KN13 | 86/10~ | Wheel Hub FRONT |
| 03903 4459 | 32113-M8000 | 25 x 40 x 8 | EXA KN13 | 86/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5737 | 38342-01E00 | 33 x 56 x 48.5 x 24.5 | EXA KN13 | 86/10~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4397 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | EXA KN13 WITHOUT LSD | 86/10~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3271 | 38342-21X04 | 46 x 90 x 11 x 15.7 | EXA KN13 WITH LSD | 88/4~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6437 | 13207-D4200 | | EXA CA16D | 86/10~90/ | Engine VALVE STEM SEAL |
| 03903 6505 | 38342-03E01 | 33 x 59 x 11 x 17 | EXA KN13 | 86/10~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4363 | 49365-V0227 | | EXA KN13 | 86/10~90/ | Steering (P/S) PINION GEAR KIT |
| 03903 2633 | 13042-16V00 | 40 x 52 x 7 | EXA KN13 CA16D | 86/10~90/ | Engine CAM SHAFT |
| 03903 6093 | 13042-16V00 | 40 x 52 x 7 | EXA KN13 CA16D | 86/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 2721 | 12279-D0100 | 84 x 104 x 11 | EXA KN13 CA16D | 86/10~90/ | Engine CRANK SHAFT REAR |
| 03903 3045 | 43232-50A00 | 40 x 52 x 6 x 10 | EXA KN13 DRUM BRAKE | 88/5~90/ | Wheel Hub REAR |
| 03903 4601 | 38342-81X00 | 39 x 59 x 8 x 13.7 | EXPERT VW11 YD22DD(4WD) | 00/6~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2887 | 38342-8E000 | 40 x 52 x 8 x 13 | EXPERT VW11 QG18DE(ALL),YD22DD(2WD) | 00/11~ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2705 | 38342-31X00 | 40 x 56 x 8 x 13.5 | EXPERT VW11 QG18DE(2WD) | 99/6~00/7 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5761 | 38342-31X01 | 33 x 56 x 8 x 13 | EXPERT VW11 YD22DD(2WD) | 99/6~02/8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4859 | 33111-06R00 | 52 x 66 x 9 | EXPERT VW11 QG18DE(4WD) | 99/6~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2607 | 13510-AD200 | 50 x 62 x 7 | EXPERT VW11 YD22DD | 99/6~ | Engine CRANK SHAFT FRONT |
| 03903 5557 | 38342-8E000 | 40 x 52 x 8 x 13 | EXPERT VW11 QG18DE(2WD) | 00/7~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1771 | 38342-8E001 | 32.5 x 56 x 8 x 14 | EXPERT VW11 YD22DD(2WD) | 02/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1281 | 12279-AD205 | 84 x 104 x 8.5 | EXPERT VW11 QG18DE,YD22DD | 99/6~ | Engine CRANK SHAFT REAR |
| 03903 4481 | 13207-53Y00 | | EXPERT VW11 QG18DE | 99/6~ | Engine VALVE STEM SEAL |
| 03903 3837 | 13207-5L300 | | EXPERT VW11 YD22DD(IN.) | 99/6~02/8 | Engine VALVE STEM SEAL |
| 03903 3909 | 38342-06R01 | 52 x 78 x 9 | EXPERT VW11 YD22DD(4WD) | 99/6~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5085 | 13042-16V00 | 40 x 52 x 7 | EXPERT VW11 QG18DE | 99/6~00/7 | Engine CRANK SHAFT FRONT |
| 03903 2287 | 38342-31X00 | 40 x 56 x 8 x 13.5 | EXPERT VW11 QG18DE(ALL),YD22DD(2WD) | 99/6~00/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 5507 | 13207-5L300 | | EXPERT VW11 YD22DD(IN. & EX.) | 02/8~ | Engine VALVE STEM SEAL |
| 03903 3685 | 13207-D4200 | | EXPERT VW11 YD22DD(EX.) | 99/6~02/8 | Engine VALVE STEM SEAL |
| 03903 1447 | 38342-03E00 | 39 x 59 x 11 x 17 | EXPERT VW11 YD22DD(4WD) | 99/6~00/6 | Mission & Differential (A/T) MISSION CASE |
| 03903 4669 | 38342-81X01 | 33 x 59 x 9 x 15.6 | EXPERT VW11 | 99/6~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4823 | 40232-33P00 | 56 x 76 x 6 x 11 | EXPERT VW11 | 99/6~ | Wheel Hub FRONT IN. & OUT. |
| 03903 2875 | 38342-81X00 | 39 x 59 x 8 x 13.7 | EXPERT VW11 | 99/6~ | Mission & Differential (M/T) MISSION CASE |
| 03903 2133 | 40232-33P00 | 56 x 76 x 6 x 11 | EXPERT VW11(4WD) | 99/6~ | Wheel Hub REAR IN. & OUT. |
| 03903 2315 | 13510-V7202 | 40 x 52 x 7 | EXPERT VW11 QG18DE | 00/7~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2941 | 32113-03E00 | 27.9 x 43 x 8 | EXPERT VW11 | 99/6~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5407 | 38189-Y0810 | 40 x 75 x 12 | FAIRLADY Z Z31 RC41 | 86/10~89/ | Final Drive PINION |
| 03903 6393 | 38189-N3112 | 40 x 75 x 13.5 x 21 | FAIRLADY Z Z32 VG30D | 93/9~00/ | Final Drive PINION |
| 03903 4409 | 38189-P0117 | 45 x 75 x 14 x 19.5 | FAIRLADY Z Z32 VG35DE | 02/7~ | Final Drive PINION |
| 03903 3141 | 38189-21G00 | 40 x 75 x 12 x 19 | FAIRLADY Z Z32 VG30D | 89/7~93/9 | Final Drive PINION |
| 03903 5693 | 38189-U3000 | 35 x 67 x 12 x 18 | FAIRLADY Z S130 2LITTER(WITHOUT TURBO),2.8LITTER(AT) | 78/8~83/ | Final Drive PINION |
| 03903 1905 | 38189-40P00 | 50 x 86 x 13 x 19 | FAIRLADY Z Z32 VG30DTT | 89/7~00/ | Final Drive PINION |
| 03903 5263 | 38189-N3100 | 40 x 75 x 12 x 17.5 | FAIRLADY Z Z31 RC35,43,46 FINAL DRIVE | 86/10~89/ | Final Drive PINION |
| 03903 3229 | 38189-N3100 | 40 x 75 x 12 x 17.5 | FAIRLADY Z S130 2LITTER(TURBO),2.8LITTER(MT) | 78/8~83/ | Final Drive PINION |
| 03903 3721 | 38342-21000 | 32 x 52 x 11 x 15.5 | FAIRLADY Z S130 2LITTER(WITHOUT TURBO),2.8LITTER(AT) | 78/8~83/ | Final Drive DIFF. SIDE |
| 03903 4065 | 38342-N3100 | 35 x 55 x 11 x 18 | FAIRLADY Z S130 2LITTER(TURBO),2.8LITTER(MT) | 78/8~83/ | Final Drive DIFF. SIDE |
| 03903 3961 | 38189-N3100 | 40 x 75 x 12 x 17.5 | FAIRLADY Z Z31 ALL | 83/9~86/10 | Final Drive PINION |
| 03903 4357 | 13510-31U00 | 48 x 60 x 7 | FAIRLADY Z Z33 VQ35DE | 02/7~ | Engine CRANK SHAFT FRONT |
| 03903 6255 | 13207-D4200 | | FAIRLADY Z VQ35DE | 02/7~ | Engine VALVE STEM SEAL |
| 03903 6001 | 13207-D4200 | | FAIRLADY Z VG30D# | 86/10~00/ | Engine VALVE STEM SEAL |
| 03903 2987 | 13207-D4200 | | FAIRLADY Z RB20D | 85/10~89/ | Engine VALVE STEM SEAL |
| 03903 2231 | 13207-D0101 | | FAIRLADY Z VG20T,30T(IN.) | 83/9~89/ | Engine VALVE STEM SEAL |
| 03903 3181 | 13207-81W00 | | FAIRLADY Z VG20T,30T(EX.) | 83/9~89/ | Engine VALVE STEM SEAL |
| 03903 5601 | 12279-85Y00 | 84 x 104 x 11 | FAIRLADY Z Z32..ALL | 89/7~98/10 | Engine CRANK SHAFT REAR |
| 03903 1409 | 12279-AD205 | 84 x 104 x 8.5 | FAIRLADY Z Z32..ALL | 98/10~00/ | Engine CRANK SHAFT REAR |
| 03903 6323 | 32136-CD000 | 43.5 x 60 x 8 | FAIRLADY Z Z33 | 02/7~ | Transmission (M/T) REAR EXTENSION |
| 03903 5851 | 12279-85Y00 | 84 x 104 x 11 | FAIRLADY Z Z31..VG30D | 86/10~89/ | Engine CRANK SHAFT REAR |
| 03903 3433 | 12279-D0100 | 84 x 104 x 11 | FAIRLADY Z Z31 VG20T,VG30T | 83/9~86/10 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6395 | 12279-85Y00 | 84 x 104 x 11 | FAIRLADY Z Z31 VG30T | 86/10~89/ | Engine CRANK SHAFT REAR |
| 03903 2563 | 12279-R4611 | 80 x 100 x 13 | FAIRLADY Z S130 L20#,L28E | 78/8~83/ | Engine CRANK SHAFT REAR |
| 03903 4437 | 38342-N3100 | 35 x 55 x 11 x 18 | FAIRLADY Z Z31 | 83/9~89/ | Final Drive DIFF. SIDE |
| 03903 3079 | 13510-88G10 | 33 x 47 x 7 | FAIRLADY Z Z31 VG20T,VG30T | 83/9~89/ | Engine CRANK SHAFT FRONT |
| 03903 3609 | 13042-16V00 | 40 x 52 x 7 | FAIRLADY Z Z32 | 89/7~00/ | Engine CRANK SHAFT FRONT |
| 03903 1493 | 13042-16V00 | 40 x 52 x 7 | FAIRLADY Z Z31 RB20T,VG30D | 85/10~89/ | Engine CRANK SHAFT FRONT |
| 03903 3381 | 13042-A8601 | 48 x 70 x 9 | FAIRLADY Z S130 L20#,L28E | 78/8~83/ | Engine CRANK SHAFT FRONT |
| 03903 1949 | 13042-16V00 | 40 x 52 x 7 | FAIRLADY Z Z32 | 89/7~00/ | Engine CAM SHAFT |
| 03903 4997 | 13042-16V00 | 40 x 52 x 7 | FAIRLADY Z Z31 RB20T,VG30D | 85/10~89/ | Engine CAM SHAFT |
| 03903 2025 | 13042-D0100 | 34 x 48 x 8 | FAIRLADY Z Z31 VG20T,VG30T | 83/9~89/ | Engine CAM SHAFT |
| 03903 2603 | 48125-01E00 | 17 x 30 x 8 | FAIRLADY Z Z31 | 83/9~86/ | Steering WORM |
| 03903 1119 | 38342-40P00 | 50 x 70 x 14 x 20 | FAIRLADY Z Z32 VG30DTT | 89/7~00/ | Final Drive DIFF. SIDE |
| 03903 5759 | 38342-N3100 | 35 x 55 x 11 x 18 | FAIRLADY Z Z33 VQ35DE | 02/7~ | Final Drive DIFF. SIDE |
| 03903 2891 | 38342-N3100 | 35 x 55 x 11 x 18 | FAIRLADY Z Z32 VG30D | 89/7~00/ | Final Drive DIFF. SIDE |
| 03903 2999 | 12279-T7202 | 80 x 100 x 10 | FAIRLADY Z Z31 RB20T | 85/10~89/ | Engine CRANK SHAFT REAR |
| 03903 4129 | 43232-21000 | 40 x 62 x 10 | FAIRLADY Z Z31 | 83/9~86/10 | Wheel Hub REAR |
| 03903 6435 | 32136-01G10 | 42 x 58 x 9.5 | FAIRLADY Z Z32 | 89/7~00/ | Transmission (M/T) REAR EXTENSION |
| 03903 5399 | 13207-81W00 | | FAIRLADY Z L20#,L28E | 78/8~83/ | Engine VALVE STEM SEAL |
| 03903 1669 | 43252-40P00 | 64 x 77 x 8 | FAIRLADY Z Z32 VG30DTT | 89/7~00/ | Wheel Hub REAR |
| 03903 1381 | 43232-F6100 | 40 x 62 x 9 x 13 | FAIRLADY Z Z31 | 86/10~89/ | Wheel Hub REAR |
| 03903 3699 | 43232-21000 | 40 x 62 x 10 | FAIRLADY Z S130 | 78/8~83/ | Wheel Hub REAR |
| 03903 1837 | 40232-33P00 | 56 x 76 x 6 x 11 | FAIRLADY Z Z32 | 89/7~00/ | Wheel Hub FRONT |
| 03903 3749 | 40232-41L00 | 46 x 69.4 x 11 x 16 | FAIRLADY Z Z31 | 86/10~89/ | Wheel Hub FRONT |
| 03903 4777 | 40232-N7100 | 46 x 59.1 x 12 | FAIRLADY Z Z31 | 83/9~86/10 | Wheel Hub FRONT |
| 03903 3469 | 40232-A0101 | 48 x 62 x 6 | FAIRLADY Z S130 | 78/8~83/ | Wheel Hub FRONT |
| 03903 2833 | 32114-Y4000 | 30 x 45 x 8 | FAIRLADY Z S130 | 78/8~83/ | Transmission (M/T) FRONT COVER |
| 03903 1361 | C2113-P9500 | 31.8 x 44.5 x 6.4 | FAIRLADY Z Z31 VG30T | 83/9~86/10 | Transmission (M/T) FRONT COVER |
| 03903 2749 | 43252-30P00 | 58 x 77 x 8 | FAIRLADY Z Z32 VG30D | 89/7~00/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4885 | C2136-06P01 | 38 x 55 x 90 x 44 | FAIRLADY Z Z31 VG30T | 83/9~86/10 | Transmission (M/T) REAR EXTENSION |
| 03903 6055 | 32136-V5000 | 35 x 50 x 90 x 49.5 | FAIRLADY Z Z31 VG20T | 83/9~85/2 | Transmission (M/T) REAR EXTENSION |
| 03903 4049 | 32136-U0100 | 35 x 50 x 11 | FAIRLADY Z Z31 RB20T,VG20T | 85/2~89/ | Transmission (M/T) REAR EXTENSION |
| 03903 3803 | 32136-U0100 | 35 x 50 x 11 | FAIRLADY Z Z30 VG20T | 85/2~85/10 | Transmission (M/T) REAR EXTENSION |
| 03903 5811 | 32113-CD000 | 30 x 45 x 7 | FAIRLADY Z Z33 | 02/7~ | Transmission (M/T) FRONT COVER |
| 03903 6391 | 32136-01G10 | 42 x 58 x 9.5 | FAIRLADY Z Z31 VG30D | 86/10~89/ | Transmission (M/T) REAR EXTENSION |
| 03903 2033 | 32114-Y4000 | 30 x 45 x 8 | FAIRLADY Z Z32 | 89/7~00/ | Transmission (M/T) FRONT COVER |
| 03903 2947 | 32114-Y4000 | 30 x 45 x 8 | FAIRLADY Z Z31 VG20T,VG30D,RB20T | 83/9~89/ | Transmission (M/T) FRONT COVER |
| 03903 5373 | 32136-U0100 | 35 x 50 x 11 | FAIRLADY Z S130 | 78/8~83/ | Transmission (M/T) REAR EXTENSION |
| 03903 4717 | 38342-M8001 | 40 x 56 x 8 | FIGARO FK10 | 92/2~92/12 | Mission & Differential (A/T) MISSION CASE |
| 03903 1787 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | FIGARO FK10 | 92/2~92/12 | Wheel Hub FRONT GREASE SEAL |
| 03903 4027 | 40227-21B00 | 48 x 62 x 6 x 10 | FIGARO FK10 | 92/2~92/12 | Wheel Hub FRONT DUST SEAL |
| 03903 1755 | 12279-01B10 | 75 x 94 x 10 | FIGARO FK10 MA10T | 92/2~92/12 | Engine CRANK SHAFT REAR |
| 03903 3183 | 38342-M8001 | 40 x 56 x 8 | FIGARO FK10 | 92/2~92/12 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4739 | 49365-V0227 | | FIGARO FK10 | 92/2~92/12 | Steering (P/S) WORM GEAR KIT |
| 03903 3841 | 49297-21B25 | | FIGARO FK10 | 92/2~92/12 | Steering (P/S) GEAR HOUSING KIT |
| 03903 5815 | 13510-01B00 | 38 x 54 x 7 | FIGARO FK10 MA10T | 92/2~92/12 | Engine CAM SHAFT |
| 03903 6359 | 13510-01B00 | 38 x 54 x 7 | FIGARO FK10 MA10T | 92/2~92/12 | Engine CRANK SHAFT FRONT |
| 03903 1931 | 13207-D0101 | | FIGARO FK10 MA10T | 92/2~92/12 | Engine VALVE STEM |
| 03903 4787 | 40227-21B00 | 48 x 62 x 6 x 10 | HIPER MINI EA0 | 99/9~ | Wheel Hub FRONT DUST SEAL |
| 03903 5205 | 38342-8E000 | 40 x 52 x 8 x 13 | HIPER MINI EA0 | 00/7~ | Mission & Differential (A/T) DIFF. SIDE (RH) |
| 03903 1297 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | HIPER MINI EA0 | 99/9~ | Wheel Hub FRONT GREASE SEAL |
| 03903 2467 | 40227-21B00 | 48 x 62 x 6 x 10 | HIPER MINI EA0 | 99/9~ | Wheel Hub REAR GREASE INNER |
| 03903 1419 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | HIPER MINI EA0 | 99/9~ | Wheel Hub REAR GREASE OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1817 | 38342-31X00 | 40 x 56 x 8 x 13.5 | HIPER MINI EA0 | 99/9~00/7 | Mission & Differential (A/T) DIFF. SIDE (LH) |
| 03903 2571 | 38342-8E000 | 40 x 52 x 8 x 13 | HIPER MINI EA0 | 00/7~ | Mission & Differential (A/T) DIFF. SIDE (LH) |
| 03903 5521 | 38342-31X00 | 40 x 56 x 8 x 13.5 | HIPER MINI EA0 | 99/9~00/7 | Mission & Differential (A/T) DIFF. SIDE (RH) |
| 03903 5431 | 13510-16A00 | 33 x 47 x 8 | LAUREL C32,C33 CA18# | 84/10~93/ | Engine CRANK SHAFT FRONT |
| 03903 1573 | 13042-16V00 | 40 x 52 x 7 | LAUREL C32,C33,C34,C35 RB20#,RB25# | 84/10~ | Engine CRANK SHAFT FRONT |
| 03903 5965 | 48040-82100 | 35 x 48 x 8 | LAUREL C31 Z18#,Z20S,CA18S | 80/11~84/ | Steering SECTOR SHAFT |
| 03903 2365 | 13042-D0100 | 34 x 48 x 8 | LAUREL C31 CA18# | 80/11~84/ | Engine CAM SHAFT |
| 03903 5599 | 13042*A8601 | 48 x 70 x 9 | LAUREL C31 L20#,L28E,LD20,LD28,Z18# ,Z20S | 80/11~84/ | Engine CRANK SHAFT FRONT |
| 03903 6149 | 13042-D0100 | 34 x 48 x 8 | LAUREL C34,C35 RD28# | 93/1~ | Engine CAM SHAFT |
| 03903 3601 | 13042-D0100 | 34 x 48 x 8 | LAUREL C33 CA18#,RD28 | 88/12~93/ | Engine CAM SHAFT |
| 03903 4801 | 13042-D0100 | 34 x 48 x 8 | LAUREL C32 CA18#,VG20#,RD28 | 84/10~88/ | Engine CAM SHAFT |
| 03903 3743 | 13042*A8601 | 48 x 70 x 9 | LAUREL C32 LD28 | 84/10~88/ | Engine CRANK SHAFT FRONT |
| 03903 5389 | 49365-10V26 | | LAUREL C33 EXCEPT MEDALIST,CLUB-L (HICAS) | 88/12~93/ | Steering (P/S) PINION GEAR KIT |
| 03903 2267 | 49365-V0227 | | LAUREL C32 EXCEPT LD28 | 84/10~88/ | Steering (P/S) PINION GEAR KIT |
| 03903 5307 | 48125-01E00 | 17 x 30 x 8 | LAUREL C32 CA18# | 84/10~88/ | Steering GEAR |
| 03903 5231 | 38342-N3100 | 35 x 55 x 11 x 18 | LAUREL C33,C34 RB20D#,RB25DE,RD28 | 88/12~97/ | Final Drive DIFF. SIDE |
| 03903 1251 | 48029-W0501 | 17.5 x 32 x 7 | LAUREL C31 Z18#,Z20S,CA18S | 80/11~84/ | Steering WORM |
| 03903 6311 | 38342-N3100 | 35 x 55 x 11 x 18 | LAUREL C35 | 97/6~ | Final Drive DIFF. SIDE |
| 03903 1521 | 38342-N3100 | 35 x 55 x 11 x 18 | LAUREL C31,C32 RC FINAL DRIVE | 80/11~88/ | Final Drive DIFF. SIDE |
| 03903 2059 | 13042-16V00 | 40 x 52 x 7 | LAUREL C32,C33,C34,C35 RD28# | 84/10~99/ 8 | Engine CRANK SHAFT FRONT |
| 03903 4029 | 38342-21000 | 32 x 52 x 11 x 15.5 | LAUREL C33,C34 CA18I,RB20E | 88/12~97/ | Final Drive DIFF. SIDE |
| 03903 5925 | 13207-21002 | | LAUREL C31,C32 L20#,L28E,LD20,LD28,Z18# ,Z20S | 80/11~84/ 9 | Engine VALVE STEM SEAL |
| 03903 6199 | 13207-D4200 | | LAUREL C35 RB20D#,RB25D#(EX.) | 97/6~ | Engine VALVE STEM SEAL |
| 03903 1427 | 38189-Y0810 | 40 x 75 x 12 | LAUREL C35 RB25DE(2WD),RB20DE,RD 28 | 97/6~ | Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4475 | 38342-21000 | 32 x 52 x 11 x 15.5 | LAUREL C31 RB FINAL DRIVE | 80/11~84/ | Final Drive DIFF. SIDE |
| 03903 2771 | 13207-D4200 | | LAUREL C32,C33,C34 RB20D#,RB25D# | 86/10~97/ 6 | Engine VALVE STEM SEAL |
| 03903 4069 | 13207-5L300 | | LAUREL C35 RB20D#,RB25D#(IN.) | 97/6~ | Engine VALVE STEM SEAL |
| 03903 6035 | 13207-81W00 | | LAUREL C32,C33,C34 RB20E,VG20T(EX.) | 84/10~97/ | Engine VALVE STEM SEAL |
| 03903 1401 | 13207-D0101 | | LAUREL C32,C33,C34 RB20E,VG20T(IN.) | 84/10~97/ | Engine VALVE STEM SEAL |
| 03903 3093 | 13207-81W00 | | LAUREL C31,C32 LD28 | 84/9~ | Engine VALVE STEM SEAL |
| 03903 4295 | 13207-D0101 | | LAUREL C31,C32,C33 CA18# | 82/10~93/ | Engine VALVE STEM SEAL |
| 03903 5611 | 13510-V7202 | 40 x 52 x 7 | LAUREL C35 RD28 | 99/8~ | Engine CRANK SHAFT FRONT |
| 03903 3869 | 12279-5L300 | 80 x 100 x 8.5 | LAUREL C35 RB20DE,RB25D#,RD28# | 97/6~ | Engine CRANK SHAFT REAR |
| 03903 4567 | 12279-58S00 | 80 x 100 x 10 | LAUREL C32,C33,C34 RB20#,RB25#,RD28 | 88/12~97/ | Engine CRANK SHAFT REAR |
| 03903 6487 | 12279-85Y00 | 84 x 104 x 11 | LAUREL C33 CA18I | 90/4~93/ | Engine CRANK SHAFT REAR |
| 03903 5153 | 12279-D0100 | 84 x 104 x 11 | LAUREL C32,C33 CA18#,VG20# | 84/10~90/ 4 | Engine CRANK SHAFT REAR |
| 03903 3955 | 12279-T7202 | 80 x 100 x 10 | LAUREL C33 RB20#,RD28 | 88/12~90/ 10 | Engine CRANK SHAFT REAR |
| 03903 2539 | 12279-01M00 | 80 x 100 x 10 | LAUREL C32..RB20#,RD28 | 84/10~88/ | Engine CRANK SHAFT REAR |
| 03903 5831 | 12279-R4611 | 80 x 100 x 13 | LAUREL C32 LD28 | 84/10~88/ | Engine CRANK SHAFT REAR |
| 03903 6467 | 13207-D0101 | | LAUREL C32,C33,C34,C35 RD28 | 86/10~ | Engine VALVE STEM SEAL |
| 03903 2943 | 38189-21G00 | 40 x 75 x 12 x 19 | LAUREL C33 RB20D#,RB25DE,RD28 | 88/12~91/ 7 | Final Drive PINION |
| 03903 5223 | 39252-35F03 | 57.9 x 82 x 7.35 | LAUREL C33,C34,C35 | 88/12~ | Wheel Hub REAR |
| 03903 2645 | 43232-F6100 | 40 x 62 x 9 x 13 | LAUREL C32 VG20#(ALL),RB20E(HARD TOP) | 85/7~88/ | Wheel Hub REAR |
| 03903 2893 | 43252-H1000 | 41 x 56 x 7 | LAUREL C32 RB20E(SEDAN),CA18#,RD 28(ALL) | 86/10~88/ | Wheel Hub REAR |
| 03903 2869 | 43252-H1000 | 41 x 56 x 7 | LAUREL C32 CA18S,RD28(HARD TOP) | 84/10~86/ 10 | Wheel Hub REAR |
| 03903 3607 | 43252-H1000 | 41 x 56 x 7 | LAUREL C32 CA18#,RB20E,LD28(SEDA N) | 84/10~86/ 10 | Wheel Hub REAR |
| 03903 5779 | 43252-H1000 | 41 x 56 x 7 | LAUREL C31 CA18S,Z20S(ALL),L20S(SE DAN)DIESEL | 82/10~84/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1405 | 43252-H1000 | 41 x 56 x 7 | LAUREL C31 L20E(SGL,MD),(SEDAN)DIESEL | 80/11~82/9 | Wheel Hub REAR |
| 03903 4393 | 32113-N2101 | 34 x 50 x 7 | LAUREL C31 F4W63L T/M | 80/11~84/ | Transmission (M/T) FRONT COVER |
| 03903 6177 | 43232-21000 | 40 x 62 x 10 | LAUREL C32 VG20#(ALL),RB20E(HARD TOP) | 84/10~85/7 | Wheel Hub REAR |
| 03903 1821 | 43232-21000 | 40 x 62 x 10 | LAUREL C31 L20E(GX),(SEDAN),L20E(HARD TOP) | 81/2~84/ | Wheel Hub REAR |
| 03903 1563 | 43232-21000 | 40 x 62 x 10 | LAUREL C31 L20E(SGL,MD),(HARD TOP) | 80/11~81/1 | Wheel Hub REAR |
| 03903 5719 | 38189-U3011 | 35 x 67 x 13.8 x 19.5 | LAUREL C34 RB20E | 93/1~ | Final Drive PINION |
| 03903 5797 | 40232-33P00 | 56 x 76 x 6 x 11 | LAUREL C34,C35 (4WD) | | Wheel Hub FRONT |
| 03903 4249 | 40232-41L00 | 46 x 69.4 x 11 x 16 | LAUREL C32 | 84/10~88/ | Wheel Hub FRONT |
| 03903 1665 | 40232-N7100 | 46 x 59.1 x 12 | LAUREL C31 | 80/11~84/ | Wheel Hub FRONT |
| 03903 5335 | 32136-V5000 | 35 x 50 x 90 x 49.5 | LAUREL C32 CA18#,RB20E,VG20# | 84/10~85/2 | Transmission (M/T) REAR EXTENSION |
| 03903 3509 | 32136-U0100 | 35 x 50 x 11 | LAUREL C33,C34 | 88/12~98/ | Transmission (M/T) REAR EXTENSION |
| 03903 5687 | 43252-H1000 | 41 x 56 x 7 | LAUREL C31 18S,Z20S(ALL),L20S(SEDAH) | 80/11~82/9 | Wheel Hub REAR |
| 03903 4849 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LAUREL C33 RB20D#,RB25DE,RD28 | 91/7~93/ | Final Drive PINION |
| 03903 2557 | 43232-21000 | 40 x 62 x 10 | LAUREL C31 L20ET,L28E(ALL) | 80/11~84/ | Wheel Hub REAR |
| 03903 5151 | 32114-Y4000 | 30 x 45 x 8 | LAUREL C31 FS5W71B,F4W71B T/M | 80/11~84/ | Transmission (M/T) FRONT COVER |
| 03903 2265 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LAUREL C35 RB25DET | 98/9~ | Final Drive PINION |
| 03903 4631 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LAUREL C35 RB25DE(4WD) | 97/6~ | Final Drive PINION |
| 03903 6041 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LAUREL C34 RB20DE,RB25DE,RD28 | 93/1~97/ | Final Drive PINION |
| 03903 2885 | 38189-Y0810 | 40 x 75 x 12 | LAUREL C35 RB25DET | 97/6~98/9 | Final Drive PINION |
| 03903 4305 | 38189-Y0810 | 40 x 75 x 12 | LAUREL C31,C32,C33,C34 ANTI SKID | 80/11~97/ | Final Drive PINION |
| 03903 2591 | 38189-P0101 | 45 x 75 x 12 | LAUREL C32 HE,HF FINAL DRIVE | 84/10~88/ | Final Drive PINION |
| 03903 1111 | 32136-U0100 | 35 x 50 x 11 | LAUREL C31 | 80/11~84/ | Transmission (M/T) REAR EXTENSION |
| 03903 3071 | 38189-U3000 | 35 x 67 x 12 x 18 | LAUREL C33 CA18I,RB20E | 88/12~93/ | Final Drive PINION |
| 03903 4659 | 38189-U3000 | 35 x 67 x 12 x 18 | LAUREL C31 RB FINAL DRIVE | 80/11~84/ | Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3023 | 38189-N3100 | 40 x 75 x 12 x 17.5 | LAUREL C31,C32 RC FINAL DRIVE | 80/11~88/ | Final Drive PINION |
| 03903 4955 | 38189-A6100 | 35 x 64 x 13 | LAUREL C31 HC FINAL DRIVE | 80/11~84/ | Final Drive PINION |
| 03903 3423 | 32136-50L02 | 35 x 50 x 65 x 45 | LAUREL C32 LD28 | 84/10~85/ 2 | Transmission (M/T) REAR EXTENSION |
| 03903 5529 | 32136-U0100 | 35 x 50 x 11 | LAUREL C32 (ALL) | 85/2~88/ | Transmission (M/T) REAR EXTENSION |
| 03903 3547 | 38189-P0101 | 45 x 75 x 12 | LAUREL C31 HE FINAL DRIVE | 80/11~84/ | Final Drive PINION |
| 03903 2417 | 32114-Y4000 | 30 x 45 x 8 | LAUREL C32,C33,C34 | 84/10~98/ | Transmission (M/T) FRONT COVER |
| 03903 1703 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | LEOPARD / J FERIE JPY32 VG30DE | 92/6~96/ | Wheel Hub REAR OUTER |
| 03903 2873 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | LEOPARD / J FERIE JPY33 | 96/3~99/ | Wheel Hub REAR OUTER |
| 03903 6091 | 40232-0P020 | 61 x 78 x 8.2 x 12.2 | LEOPARD / J FERIE JPY32 VH41DE | 92/6~96/ | Wheel Hub REAR OUTER |
| 03903 2811 | 32114-Y4000 | 30 x 45 x 8 | LEOPARD / J FERIE F30,F31 | 80/9~92/ | Transmission (M/T) FRONT COVER |
| 03903 1535 | 32136-U0100 | 35 x 50 x 11 | LEOPARD / J FERIE F30,F31 | 80/9~92/ | Transmission (M/T) REAR EXTENSION |
| 03903 1607 | 38189-A6100 | 35 x 64 x 13 | LEOPARD / J FERIE F30 Z18S | 80/9~86/ | Final Drive PINION |
| 03903 3677 | 38189-N3100 | 40 x 75 x 12 x 17.5 | LEOPARD / J FERIE F30 L20ET,VG30T | 81/8~86/ | Final Drive PINION |
| 03903 5329 | 38189-Y0810 | 40 x 75 x 12 | LEOPARD / J FERIE F31 VG20DT,VG30D ANTI SKID | 86/2~92/ | Final Drive PINION |
| 03903 5789 | 38189-N3100 | 40 x 75 x 12 x 17.5 | LEOPARD / J FERIE F31 VG20DT,VG30D EXCEPT ANTI SKID | 86/2~91/7 | Final Drive PINION |
| 03903 6197 | 40232-0P000 | 64 x 77 x 8.4 x 12.7 | LEOPARD / J FERIE JPY32 VH41DE | 92/6~96/ | Wheel Hub REAR INNER |
| 03903 3801 | 40232-41L00 | 46 x 69.4 x 11 x 16 | LEOPARD / J FERIE F31 EXCEPT ANTI SKID | 89/6~92/ | Wheel Hub FRONT |
| 03903 3843 | 38189-Y0810 | 40 x 75 x 12 | LEOPARD / J FERIE F31 VG30DT (TYPE F) | 86/2~92/ | Final Drive PINION |
| 03903 1479 | 38189-N3100 | 40 x 75 x 12 x 17.5 | LEOPARD / J FERIE F31 VG20E,VG20T | 86/2~91/7 | Final Drive PINION |
| 03903 3559 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | LEOPARD / J FERIE JPY33 | 96/3~99/ | Wheel Hub REAR INNER |
| 03903 4377 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | LEOPARD / J FERIE JPY32 VG30DE | 92/6~96/ | Wheel Hub REAR INNER |
| 03903 3933 | 43232-F6100 | 40 x 62 x 9 x 13 | LEOPARD / J FERIE F31 | 86/2~91/ | Wheel Hub REAR |
| 03903 5615 | 43252-H1000 | 41 x 56 x 7 | LEOPARD / J FERIE F30 Z18S | 80/9~86/ | Wheel Hub REAR |
| 03903 4661 | 43232-21000 | 40 x 62 x 10 | LEOPARD / J FERIE F30 L20E,L28E,VG30T | 80/9~86/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6179 | 40232-1P450 | 59 x 80.3 x 6 x 11.5 | LEOPARD / J FERIE JPY33 RB25DET | 96/3~99/ | Wheel Hub FRONT |
| 03903 4361 | 40232-F6500 | 46 x 59 x 11.6 | LEOPARD / J FERIE F31 ANTI SKID | 89/6~92/ | Wheel Hub FRONT |
| 03903 2449 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | LEOPARD / J FERIE JPY32 | 92/6~96/ | Wheel Hub FRONT |
| 03903 1071 | 40232-41L00 | 46 x 69.4 x 11 x 16 | LEOPARD / J FERIE F31 ALL | 86/2~89/6 | Wheel Hub FRONT |
| 03903 6221 | 40232-N7100 | 46 x 59.1 x 12 | LEOPARD / J FERIE F30 | 80/9~86/ | Wheel Hub FRONT |
| 03903 4923 | 38189-Y0810 | 40 x 75 x 12 | LEOPARD / J FERIE JPY32 VG30DE EXCEPT (TYPE F) | 92/6~96/ | Final Drive PINION |
| 03903 4389 | 13510-31U00 | 48 x 60 x 7 | LEOPARD / J FERIE JPY33 VQ25DE,VQ30D# | 96/3~99/ | Engine CRANK SHAFT FRONT |
| 03903 3715 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | LEOPARD / J FERIE JPY33 VG20E,VG30E,VQ25DE,VQ 30D# | 96/3~99/ | Wheel Hub FRONT |
| 03903 2505 | 12296-31U20 | RETAINER ID 97 (F) | LEOPARD / J FERIE JPY33 VQ25DE,VQ30D# | 96/3~99/ | Engine CRANK SHAFT REAR |
| 03903 1227 | 13042-16V00 | 40 x 52 x 7 | LEOPARD / J FERIE JPY32 VG30DE | 92/6~96/ | Engine CRANK SHAFT FRONT |
| 03903 3463 | 13042-16V00 | 40 x 52 x 7 | LEOPARD / J FERIE JPY33 RB25DET,VG20E,VG30E | 96/3~99/ | Engine CRANK SHAFT FRONT |
| 03903 1745 | 13510-88G10 | 33 x 47 x 7 | LEOPARD / J FERIE F30 VGET | 85/9~86/ | Engine CRANK SHAFT FRONT |
| 03903 2727 | 13510-60U00 | 50 x 65 x 8 | LEOPARD / J FERIE JPY32 VH41DE | 92/6~96/ | Engine CRANK SHAFT FRONT |
| 03903 4433 | 12279-R4611 | 80 x 100 x 13 | LEOPARD / J FERIE F30 Z18S,L20#,L28E | 80/9~86/ | Engine CRANK SHAFT REAR |
| 03903 3927 | 12279-D0100 | 84 x 104 x 11 | LEOPARD / J FERIE F30 VG30ET | 85/6~96/ | Engine CRANK SHAFT REAR |
| 03903 3031 | 12279-D0100 | 84 x 104 x 11 | LEOPARD / J FERIE F31 VG20#,VG30D# | 86/2~89/2 | Engine CRANK SHAFT REAR |
| 03903 5707 | 12279-85Y00 | 84 x 104 x 11 | LEOPARD / J FERIE F31 VG20#,VG30D# | 89/2~92/ | Engine CRANK SHAFT REAR |
| 03903 1889 | 12279-85Y00 | 84 x 104 x 11 | LEOPARD / J FERIE JPY32 VG30DE,VH41DE | 92/6~96/ | Engine CRANK SHAFT REAR |
| 03903 3773 | 12279-85Y00 | 84 x 104 x 11 | LEOPARD / J FERIE JPY33 VG20E,VG30E | 96/3~97/1 0 | Engine CRANK SHAFT REAR |
| 03903 4137 | 13042-16V00 | 40 x 52 x 7 | LEOPARD / J FERIE F31 VG20DT,VG30D# | 88/8~92/ | Engine CRANK SHAFT FRONT |
| 03903 5341 | 12279-5L300 | 80 x 100 x 8.5 | LEOPARD / J FERIE JPY33 RB25DET | 97/10~99/ | Engine CRANK SHAFT REAR |
| 03903 3285 | 13207-21002 | | LEOPARD / J FERIE F30 Z18S,L20#,L28E | 80/9~86/ | Engine VALVE STEN SEAL |
| 03903 6281 | 38189-Y0810 | 40 x 75 x 12 | LEOPARD / J FERIE JPY32 VG30DE ANTI SKID | 93/6~96/ | Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4655 | 13207-D0101 | | LEOPARD / J FERIE F31 VG20E#(IN.) | 86/2~92/ | Engine VALVE STEN SEAL |
| 03903 4883 | 13510-88G10 | 33 x 47 x 7 | LEOPARD / J FERIE F31 VG20E# | 86/2~92/ | Engine CRANK SHAFT FRONT |
| 03903 1943 | 13207-D0101 | | LEOPARD / J FERIE JPY33 VG20E,VG30E(IN.) | 96/3~99/ | Engine VALVE STEN SEAL |
| 03903 3583 | 13207-81W00 | | LEOPARD / J FERIE F31 VG20E#(EX.) | 86/2~92/ | Engine VALVE STEN SEAL |
| 03903 2285 | 13207-81W00 | | LEOPARD / J FERIE JPY33 (VG20E,VG30E(EX.) | 96/3~99/ | Engine VALVE STEN SEAL |
| 03903 4625 | 13207-D4200 | | LEOPARD / J FERIE F31 VG20DT,VG30D# | 86/2~92/ | Engine VALVE STEN SEAL |
| 03903 3615 | 13207-D4200 | | LEOPARD / J FERIE JPY32 VG30DE | 92/6~96/ | Engine VALVE STEN SEAL |
| 03903 4375 | 13207-D4200 | | LEOPARD / J FERIE JPY33 RB25DET,VQ25DE,VQ30D # | 96/3~99/ | Engine VALVE STEN SEAL |
| 03903 6381 | 13207-42L00 | | LEOPARD / J FERIE JPY32 VH41DE(EX.) | 92/6~96/ | Engine VALVE STEN SEAL |
| 03903 4837 | 12279-AD205 | 84 x 104 x 8.5 | LEOPARD / J FERIE JPY33 VG20E | 97/10~99/ | Engine CRANK SHAFT REAR |
| 03903 2399 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LEOPARD / J FERIE JPY32 VG30DE (TYPE F) EXCEPT ANTI SKID | 93/6~96/ | Final Drive PINION |
| 03903 3473 | 13207-D0101 | | LEOPARD / J FERIE JPY32 VH41DE(IN.) | 92/6~96/ | Engine VALVE STEN SEAL |
| 03903 1151 | 13042-A8601 | 48 x 70 x 9 | LEOPARD / J FERIE F30 Z18S,L20#,L28E | 80/9~86/ | Engine CRANK SHAFT FRONT |
| 03903 2035 | 38189-Y0810 | 40 x 75 x 12 | LEOPARD / J FERIE JPY33 VG20E,VG30E,VQ25DE,VQ 30DE,VQ30DD | 96/3~99/ | Final Drive PINION |
| 03903 3005 | 38189-Y0810 | 40 x 75 x 12 | LEOPARD / J FERIE JPY33 WITHOUT(TCS)+(ABS) | 96/3~99/ | Final Drive PINION |
| 03903 2375 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LEOPARD / J FERIE F31 VG20E,VG20T | 91/7~92/ | Final Drive PINION |
| 03903 1781 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LEOPARD / J FERIE JPY32 VH41DE | 92/6~96/ | Final Drive PINION |
| 03903 6497 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LEOPARD / J FERIE JPY33 VQ30DET (TCS)+(ABS) | 96/3~99/ | Final Drive PINION |
| 03903 1183 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LEOPARD / J FERIE JPY33 RB25DET | 97/10~99/ | Final Drive PINION |
| 03903 1513 | 38342-21000 | 32 x 52 x 11 x 15.5 | LEOPARD / J FERIE F30 RB# FINAL DRIVE | 80/9~86/ | Final Drive DIFF. SIDE |
| 03903 1835 | 38342-N3100 | 35 x 55 x 11 x 18 | LEOPARD / J FERIE F30,F31 RC# FINAL DRIVE | 81/8~92/ | Final Drive DIFF. SIDE |
| 03903 6203 | 38342-N3100 | 35 x 55 x 11 x 18 | LEOPARD / J FERIE JPY32,JPY33 | 92/6~99/ | Final Drive DIFF. SIDE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4073 | 13042-D0100 | 34 x 48 x 8 | LEOPARD / J FERIE F31 VG20E# | 86/2~92/ | Engine CAM SHAFT |
| 03903 2909 | 13042-16V00 | 40 x 52 x 7 | LEOPARD / J FERIE JPY33 RB25DET | 97/10~99/ | Engine CAM SHAFT |
| 03903 4219 | 38189-N3112 | 40 x 75 x 13.5 x 21 | LEOPARD / J FERIE F31 VG20DT,VG30D EXCEPT ANTI SKID | 91/7~92/ | Final Drive PINION |
| 03903 1321 | 49297-61U26 | | LEOPARD / J FERIE JPY32 | 92/6~96/ | Power Steering GEAR HOUSING KIT |
| 03903 1829 | 13042-16V00 | 40 x 52 x 7 | LEOPARD / J FERIE F31 VG20DT,VG30D# | 86/2~92/ | Engine CAM SHAFT |
| 03903 2665 | 13042-D0100 | 34 x 48 x 8 | LEOPARD / J FERIE JPY33 VG20E,VG30E | 96/3~99/ | Engine CAM SHAFT |
| 03903 4623 | 13042-16V00 | 40 x 52 x 7 | LEOPARD / J FERIE JPY32 VG30DE | 92/6~96/ | Engine CAM SHAFT |
| 03903 5777 | 13042-D0100 | 34 x 48 x 8 | LEOPARD / J FERIE F30 VG30ET | 85/9~86/ | Engine CAM SHAFT |
| 03903 6207 | 49359-10V26 | | LEOPARD / J FERIE JPY33 RB25DET,VQ30DD,VQ30DET | 97/10~99/ | Power Steering WORM GEAR KIT |
| 03903 5855 | 49365-10V26 | | LEOPARD / J FERIE JPY33 | 96/3~99/ | Power Steering WORM GEAR KIT |
| 03903 4177 | 49365-10V26 | | LEOPARD / J FERIE JPY32 | 92/6~96/ | Power Steering WORM GEAR KIT |
| 03903 1093 | 49297-5Y085 | | LEOPARD / J FERIE JPY33 VG20E,VG30E,VQ25DE,VQ30D# | 96/3~99/ | Power Steering GEAR HOUSING KIT |
| 03903 6303 | 49297-61U26 | | LEOPARD / J FERIE JPY33 RB25DET | 97/10~99/ | Power Steering GEAR HOUSING KIT |
| 03903 5183 | 38342-31X01 | 33 x 56 x 8 x 13 | LUCINO (COUPE / HATCBACK) N15 SR18DE(2WD) | 95/1~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1723 | 13042-16V00 | 40 x 52 x 7 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE | 94/5~00/7 | Engine CRANK SHAFT FRONT |
| 03903 4783 | 48029-W0501 | 17.5 x 32 x 7 | LUCINO (COUPE / HATCBACK) N15 GADE(4WD) | 95/1~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2609 | 38189-U3011 | 35 x 67 x 13.8 x 19.5 | LUCINO (COUPE / HATCBACK) N15(4WD) | 94/5~ | Final Drive PINION |
| 03903 5675 | 38342-21000 | 32 x 52 x 11 x 15.5 | LUCINO (COUPE / HATCBACK) N15(4WD) | 94/5~ | Final Drive DIFF.SIDE |
| 03903 2333 | 40227-50W01 | 50 x 72 x 83 x 16.2 | LUCINO (COUPE / HATCBACK) N15 SR18DE(4WD) | 95/1~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2757 | 13510-53J00 | 46 x 58 x 7 | LUCINO (COUPE / HATCBACK) B14,N15 SR18DE | 94/5~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1633 | 13510-2J200 | 46 x 58 x 7 | LUCINO (COUPE / HATCBACK) B14,N15 SR16VE | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 5001 | 12279-85Y00 | 84 x 104 x 11 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE,SR16VE, SR18DE | 94/5~97/9 | Engine CRANK SHAFT REAR |
| 03903 4441 | 12279-AD205 | 84 x 104 x 8.5 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE,SR16VE, SR18DE | 97/9~ | Engine CRANK SHAFT REAR |
| 03903 3159 | 13207-53Y00 | | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE | 94/5~ | Engine VALVE STEM SEAL |
| 03903 1769 | 38342-31X00 | 40 x 56 x 8 x 13.5 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE (NSD) | 94/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3409 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | LUCINO (COUPE / HATCBACK) N15(4WD) | 94/5~ | Wheel Hub REAR INNER |
| 03903 1927 | 13207-D4200 | | LUCINO (COUPE / HATCBACK) B14,N15 SR16VE,SR18DE | 94/5~ | Engine VALVE STEM SEAL |
| 03903 2523 | 38342-M8001 | 40 x 56 x 8 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE (EXCEPT NSD) (2WD) | 94/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3143 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | LUCINO (COUPE / HATCBACK) B14,N15 | 94/5~ | Wheel Hub FRONT INNER |
| 03903 1287 | 40227-50Y01 | 56 x 74.2 x 10.3 | LUCINO (COUPE / HATCBACK) B14,N15 | 94/5~ | Wheel Hub FRONT OUTER |
| 03903 2691 | 40227-50Y01 | 56 x 74.2 x 10.3 | LUCINO (COUPE / HATCBACK) N15(4WD) | 94/5~ | Wheel Hub REAR OUTER |
| 03903 3787 | 38342-M8001 | 40 x 56 x 8 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE (EXCEPT NSD) | 94/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 5477 | 32113-M8000 | 25 x 40 x 8 | LUCINO (COUPE / HATCBACK) B14,N15 | 94/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2711 | 38342-31X02 | 42 x 90 x 9.5 x 13 | LUCINO (COUPE / HATCBACK) B14,N15 SR16VE,SR18DE | 94/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 5317 | 38342-31X02 | 42 x 90 x 9.5 x 13 | LUCINO (COUPE / HATCBACK) N15 SR18DE(2WD) | 95/1~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1801 | 38342-D2100 | 40 x 56 x 65 x 20 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE (NSD) (2WD) | 94/5~ | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1421 | 38342-31X01 | 33 x 56 x 8 x 13 | LUCINO (COUPE / HATCBACK) B14,N15 SR16VE,SR18DE (2WD) | 94/5~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3293 | 33111-31X00 | 60 x 76 x 9 | LUCINO (COUPE / HATCBACK) N15 SR18DE(4WD) | 95/1~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2093 | 33111-06R00 | 52 x 66 x 9 | LUCINO (COUPE / HATCBACK) N15 GA15DE(4WD) | 95/1~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2233 | 38342-31X00 | 40 x 56 x 8 x 13.5 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE EXCEPT( NSD) | 94/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6169 | 38342-31X02 | 42 x 90 x 9.5 x 13 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE (NSD) | 94/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2799 | 38342-D2100 | 40 x 56 x 65 x 20 | LUCINO (COUPE / HATCBACK) B14,N15 GA15DE,GA16DE (NSD) | 94/5~ | Mission & Differential (M/T) MISSION CASE |
| 03903 3461 | 38342-01B00 | 38 x 58 x 11 x 17 | MARCH K10 WITHOUT TURBO | 85/2~92/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1155 | 38342-M8001 | 40 x 56 x 8 | MARCH K11 CVT | 92/1~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1613 | 49365-10V26 | | MARCH K11 | 92/1~02/ | Power Steering PINION GEAR KIT |
| 03903 1219 | 49297-86A25 | | MARCH K11 | 92/1~02/ | Power Steering GEAR HOUSING HOUSING KIT |
| 03903 6539 | 48125-60R00 | 16 x 26 x 7 | MARCH K11 | 92/1~ | Steering GEAR |
| 03903 4941 | 48125-17B01 | | MARCH K10 TURBO | 85/2~92/ | Steering GEAR |
| 03903 1945 | 48125-11A00 | 17.5 x 32 x 6 | MARCH K10 WITHOUT TURBO | 82/10~92/ | Steering GEAR |
| 03903 6531 | 38342-D2100 | 40 x 56 x 65 x 20 | MARCH K11 CG13DE(NON SLIP DIFF.) | 92/1~99/11 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3793 | 38342-M8001 | 40 x 56 x 8 | MARCH K11 CVT(4WD) WITHOUT NON SLIP DIFF. | 92/1~99/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 3077 | 40232-M0215 | 48 x 62 x 7 | MARCH K10 ALL | 82/10~88/8 | Wheel Hub FRONT GREASE SEAL |
| 03903 2937 | 13510-01B00 | 38 x 54 x 7 | MARCH K10 MA10#,MA9RT | 82/10~92/ | Engine CRANK SHAFT FRONT |
| 03903 3109 | 38342-M8001 | 40 x 56 x 8 | MARCH K10 | 82/10~92/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1095 | 38342-8E000 | 40 x 52 x 8 x 13 | MARCH K12 | 02/2~ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2397 | 38342-8E000 | 40 x 52 x 8 x 13 | MARCH K11 CVT(ALL) | 99/11~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6327 | 38342-8E000 | 40 x 52 x 8 x 13 | MARCH K11 F4(2WD) | 00/10~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2815 | 38342-31X00 | 40 x 58 x 8 x 13.5 | MARCH K11 F4(2WD) | 92/1~00/10 | Mission & Differential (A/T) MISSION CASE |
| 03903 1441 | 38342-D2100 | 40 x 56 x 65 x 20 | MARCH K11 CVT(2WD) NON SLIP DIFF. | 92/1~99/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 3995 | 38342-31X00 | 40 x 56 x 8 x 13.5 | MARCH K11 F4 | 92/1~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1329 | 12279-85Y00 | 84 x 104 x 11 | MARCH K11 CG10DE | 92/1~93/1 | Engine CRANK SHAFT REAR |
| 03903 4751 | 13207-53Y00 | | MARCH CR10DE,CR12DE,CR14DE | 02/2~ | Engine VALVE STEM SEAL |
| 03903 5643 | 13207-53Y00 | | MARCH CG10DE,CG13DE,CGA3DE | 92/1~02/ | Engine VALVE STEM SEAL |
| 03903 6493 | 13207-D0101 | | MARCH MA09#,MA10# | 82/10~92/ | Engine VALVE STEM SEAL |
| 03903 4591 | 12279-AD205 | 84 x 104 x 8.5 | MARCH K12 | 02/2~ | Engine CRANK SHAFT REAR |
| 03903 1537 | 12279-AD205 | 84 x 104 x 8.5 | MARCH K11 CGA3DE | 99/11~02/ | Engine CRANK SHAFT REAR |
| 03903 1539 | 12279-AD205 | 84 x 104 x 8.5 | MARCH K11 CG13DE | 95/12~99/11 | Engine CRANK SHAFT REAR |
| 03903 4595 | 49277-D0301 | | MARCH K11 | 92/1~02/ | Power Steering PISTON SEAL SET |
| 03903 2157 | 12279-85Y00 | 84 x 104 x 11 | MARCH K11 CG13DE | 92/1~95/12 | Engine CRANK SHAFT REAR |
| 03903 3099 | 13510-01B00 | 38 x 54 x 7 | MARCH K10 MA10#,MA9RT | 82/10~92/ | Engine CAM SHAFT |
| 03903 6105 | 12279-01B10 | 75 x 94 x 10 | MARCH K10 MA10#,MA9RT | 82/10~92/ | Engine CRANK SHAFT REAR |
| 03903 4543 | 13510-V7202 | 40 x 52 x 7 | MARCH K12 | 02/2~ | Engine CRANK SHAFT FRONT |
| 03903 5979 | 13510-V7202 | 40 x 52 x 7 | MARCH K11 CGA3DE | 99/11~02/ | Engine CRANK SHAFT FRONT |
| 03903 2219 | 13510-V7202 | 40 x 52 x 7 | MARCH K11 CG10DE | 98/12~02/ | Engine CRANK SHAFT FRONT |
| 03903 2361 | 13510-01B00 | 38 x 54 x 7 | MARCH K11 CG10DE | 92/1~98/12 | Engine CRANK SHAFT FRONT |
| 03903 3035 | 13510-01B00 | 38 x 54 x 7 | MARCH K11 CG10DE | 92/1~99/11 | Engine CRANK SHAFT FRONT |
| 03903 3941 | 38342-D2100 | 40 x 56 x 65 x 20 | MARCH K11 CVT(NON SLIP DIFF.) | 92/1~02/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4987 | 12279-AD205 | 84 x 104 x 8.5 | MARCH K11 CG10DE | 93/1~02/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1953 | 38342-8E000 | 40 x 52 x 8 x 13 | MARCH K12 | 02/2~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1379 | 32113-01B00 | 20 x 35 x 8 | MARCH K10 ALL | 82/10~85/2 | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2055 | 32113-M8000 | 25 x 40 x 8 | MARCH K11 EXCEPT CG10DE | 92/1~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2041 | 32113-M8000 | 25 x 40 x 8 | MARCH K11 CG10DE | 97/5~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5847 | 32113-M8000 | 25 x 40 x 8 | MARCH K10 TURBO | 85/2~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1277 | 43252-01B00 | 38 x 50.3 x 10 | MARCH K10 MA10# ENGINE | 88/8~89/1 | Wheel Hub REAR |
| 03903 1869 | 43252-01B00 | 38 x 50.3 x 10 | MARCH K10 ALL | 82/10~88/8 | Wheel Hub REAR |
| 03903 3541 | 32113-01B00 | 20 x 35 x 8 | MARCH K10 WITHOUT TURBO | 85/2~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5425 | 40227-21B00 | 48 x 62 x 6 x 10 | MARCH K10 ALL | 89/1~92/ | Wheel Hub FRONT DUST SEAL |
| 03903 2421 | 40227-21B00 | 48 x 62 x 6 x 10 | MARCH K11 | 92/1~02/ | Wheel Hub FRONT DUST SEAL |
| 03903 2177 | 40227-M3005 | 48 x 62 x 13 | MARCH K10 MA10# ENGINE | 88/8~89/1 | Wheel Hub FRONT DUST SEAL |
| 03903 3019 | 40227-M3005 | 48 x 62 x 13 | MARCH K10 ALL | 82/10~88/8 | Wheel Hub FRONT DUST SEAL |
| 03903 4731 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | MARCH K11 | 92/1~02/ | Wheel Hub FRONT GREASE SEAL |
| 03903 4187 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | MARCH K10 ALL | 89/1~92/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1089 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | MARCH K10 MA09RT ENGINE | 88/8~89/1 | Wheel Hub FRONT GREASE SEAL |
| 03903 3641 | 40232-M0215 | 48 x 62 x 7 | MARCH K10 MA10# ENGINE | 88/8~89/1 | Wheel Hub FRONT GREASE SEAL |
| 03903 3371 | 38342-M8001 | 40 x 56 x 8 | MARCH K10 | 82/10~92/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3053 | 38342-M8001 | 40 x 56 x 8 | MARCH K11 CG10DE | 97/5~02/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4011 | 40227-21B00 | 48 x 62 x 6 x 10 | MARCH K10 MA09RT ENGINE | 88/8~89/1 | Wheel Hub FRONT DUST SEAL |
| 03903 3237 | 32113-01B00 | 20 x 35 x 8 | MARCH K11 CG10DE | 92/1~97/5 | Mission & Differential (M/T) INPUT SHAFT |
| 03903 4899 | 38342-AX000 | 40 x 55 x 8 x 13 | MARCH K12 | 02/2~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2097 | 38342-01B00 | 38 x 58 x 11 x 17 | MARCH K11 CG10DE | 92/1~97/5 | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5637 | 38342-D2100 | 40 x 56 x 65 x 20 | MARCH K10 MA9RT ENGINE | 88/8~92/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1147 | 38342-M8001 | 40 x 56 x 8 | MARCH K11 CG13DE(WITHOUT NON SLIP DIFF.) | 92/1~02/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2651 | 38342-M8001 | 40 x 56 x 8 | MARCH K10 MA10T ENGINE | 85/2~92/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4745 | 38342-AX000 | 40 x 55 x 8 x 13 | MARCH K12 | 02/2~ | Mission & Differential (M/T) MISSION CASE |
| 03903 5747 | 38342-M8001 | 40 x 56 x 8 | MARCH K11 CG13DE(WITHOUT NON SLIP DIFF.) | 92/1~02/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5481 | 38342-01B00 | 38 x 58 x 11 x 17 | MARCH K10 ALL | 82/10~85/ 2 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5103 | 38342-M8001 | 40 x 56 x 8 | MARCH K10 MA10T ENGINE | 85/2~92/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1765 | 38342-01B00 | 38 x 58 x 11 x 17 | MARCH K11 CG10DE | 92/1~97/5 | Mission & Differential (M/T) MISSION CASE |
| 03903 5387 | 38342-M8001 | 40 x 56 x 8 | MARCH K11 CG10DE | 97/5~02/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1981 | 38342-D2100 | 40 x 56 x 65 x 20 | MARCH K10 MA9RT ENGINE | 88/8~92/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2641 | 38342-D2100 | 40 x 56 x 65 x 20 | MARCH K11 CG13DE(NON SLIP DIFF.) | 92/1~99/1 1 | Mission & Differential (M/T) MISSION CASE |
| 03903 1355 | 38342-01B00 | 38 x 58 x 11 x 17 | MARCH K10 ALL | 82/10~85/ 2 | Mission & Differential (M/T) MISSION CASE |
| 03903 3497 | 38342-01B00 | 38 x 58 x 11 x 17 | MARCH K10 WITHOUT TURBO | 85/2~92/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5157 | 49297-10V26 | | MAXIMA J30 | 88/10~94/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1143 | 49365-10V26 | | MAXIMA J30 | 88/10~94/ | Steering (P/S) PINION GEAR KIT |
| 03903 5149 | 40232-33P00 | 56 x 76 x 6 x 11 | MAXIMA J30 VG30E,VE30DE | 90/5~94/ | Wheel Hub FRONT INNER |
| 03903 6573 | 40232-30R11 | 56 x 76 x 7.5 x 11 | MAXIMA J30 VG30E | 88/10~90/ 5 | Wheel Hub FRONT OUTER |
| 03903 2477 | 40232-33P00 | 56 x 76 x 6 x 11 | MAXIMA J30 VG30E,VE30DE | 90/5~94/ | Wheel Hub FRONT OUTER |
| 03903 1385 | 38342-21X01 | 39 x 57 x 11 x 17 | MAXIMA J30 VG30E | 88/10~91/ 8 | Mission & Differential (A/T) MISSION CASE |
| 03903 6143 | 38342-03E00 | 39 x 59 x 11 x 17 | MAXIMA J30 VE30DE(EXCEPT LSD) | 91/8~94/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6357 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | MAXIMA J30 VE30DE(LSD) | 91/8~94/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5865 | 40232-30R11 | 56 x 76 x 7.5 x 11 | MAXIMA J30 VG30E | 88/10~90/ 5 | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6033 | 13042-D0100 | 34 x 48 x 8 | MAXIMA J30 VG30E | 88/10~91/8 | Engine CAM SHAFT |
| 03903 4483 | 13510-88G10 | 33 x 47 x 7 | MAXIMA J30 VG30E | 88/10~91/8 | Engine CRANK SHAFT FRONT |
| 03903 2283 | 13510-97E10 | 48 x 60 x 7 | MAXIMA J30 VG30DE | 91/8~94/ | Engine CRANK SHAFT FRONT |
| 03903 1557 | 12279-D0100 | 84 x 104 x 11 | MAXIMA J30 VG30E | 88/10~89/2 | Engine CRANK SHAFT REAR |
| 03903 4183 | 12279-85Y00 | 84 x 104 x 11 | MAXIMA J30 VG30E | 89/2~91/8 | Engine CRANK SHAFT REAR |
| 03903 4323 | 12279-85Y00 | 84 x 104 x 11 | MAXIMA J30 VG30DE | 91/8~94/ | Engine CRANK SHAFT REAR |
| 03903 2045 | 13207-D0101 | | MAXIMA J30 VG30E(EX.) | 88/10~91/8 | Engine VALVE STEM SEAL |
| 03903 3029 | 13207-D4200 | | MAXIMA J30 VG30DE | 91/8~94/ | Engine VALVE STEM SEAL |
| 03903 1795 | 13207-81W00 | | MAXIMA J30 VG30E(IN.) | 88/10~91/8 | Engine VALVE STEM SEAL |
| 03903 3605 | 38342-03E01 | 33 x 59 x 11 x 17 | MAXIMA J30 | 88/10~91/4 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5203 | 33142-33G10 | 42 x 66 x 10 | MISTRAL R20 | 94/2~97/ | Transfer CASE (REAR) |
| 03903 1177 | 12279-7C600 | 86 x 100 x 10 | MISTRAL R20 TD27TI | 96/10~97/ | Engine CRANK SHAFT REAR |
| 03903 1543 | 12279-43G02 | 86 x 100 x 10 | MISTRAL R20 TD27T | 94/2~96/10 | Engine CRANK SHAFT REAR |
| 03903 3797 | 13510-43G01 | 58 x 80 x 7 | MISTRAL R20 TD27TI | 96/11~97/ | Engine CRANK SHAFT FRONT |
| 03903 4993 | 13510-43G00 | 58 x 80 x 10 | MISTRAL R20 TD27T# | 94/2~96/11 | Engine CRANK SHAFT FRONT |
| 03903 5229 | 13207-V1700 | | MISTRAL R20 TD27T# | 94/2~97/ | Engine VALVE STEM SEAL |
| 03903 4719 | 38189-01G16 | 35 x 67 x 13.7 x 19.5 | MISTRAL R20 | 94/2~97/ | Final Drive PINION (FRONT) |
| 03903 5209 | 33111-46G00 | 50 x 72 x 12 | MISTRAL R20 TD27T | 94/2~95/9 | Transfer COVER |
| 03903 4767 | 33216-33G01 | 40 x 75 x 12 x 20 | MISTRAL R20 | 94/2~97/ | Transfer CASE (FRONT) |
| 03903 4353 | 33111-46G00 | 50 x 72 x 12 | MISTRAL R20 TD27TI | 96/10~97/ | Transfer COVER |
| 03903 5063 | 33111-31G00 | 50 x 72 x 12 | MISTRAL R20 TD27T | 95/9~96/10 | Transfer COVER |
| 03903 6465 | 43252-VW000 | 35 x 55 x 11 | MISTRAL R20 | 94/2~97/ | Wheel Hub REAR SHAFT |
| 03903 1583 | 40227-31G01 | 50 x 93 x 24 | MISTRAL R20 | 94/2~97/ | Wheel Hub FRONT DUST SEAL |
| 03903 1299 | 40232-31G00 | 57 x 79 x 9 x 13.5 | MISTRAL R20 | 94/2~97/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1545 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | MISTRAL R20 | 94/2~97/ | Final Drive PINION (REAR) |
| 03903 5237 | 43232-42G10 | 55 x 74 x 10 x | MISTRAL R20 | 94/2~97/ | Wheel Hub REAR HUB |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | 13.5 | | | |
| 03903 2209 | 27431-73H30 | 34.5 x 52 x 8 | MOCO MG21S 2WD,4WD | 02/4~ | Mission & Differential (A/T) DIFF. SIDE (LH) |
| 03903 5705 | 43491-70D01 | 42 x 55 x 7 | MOCO MG21S 4WD | 02/4~ | Wheel Hub REAR |
| 03903 2985 | 37432-73H10 | 40 x 54 x 7 | MOCO MG21S 4WD | 02/8~ | Mission & Differential (A/T) DIFF. SIDE (RH) |
| 03903 3103 | 09283-28022 | 28 x 47 x 7 | MOCO MG21S 4WD | 02/8~ | Final Drive PINION |
| 03903 3665 | 09283-35040 | 35 x 47 x 6 | MOCO MG21S K6A | 02/4~ | Engine CRANK SHAFT FRONT |
| 03903 2087 | 09283-79001 | 79 x 99 x 8 | MOCO MG21S K6A | 02/4~ | Engine CRANK SHAFT REAR |
| 03903 5005 | 09289-05012 | | MOCO MG21S K6A | 02/4~ | Engine VALVE STEM SEAL |
| 03903 2297 | 27431-73H10 | 34.5 x 54 x 8.5 x 10 | MOCO MG21S 2WD | 02/4~02/8 | Mission & Differential (A/T) DIFF. SIDE (RH) |
| 03903 3999 | 38342-M8001 | 40 x 56 x 8 | PAO PK10 | 89/1~92/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1057 | 13207-D0101 | | PAO PK10 MA10S | 89/1~92/ | Engine VALVE STEM SEAL |
| 03903 3747 | 12279-01B10 | 75 x 94 x 10 | PAO PK10 MA10S | 89/1~92/ | Engine CRANK SHAFT REAR |
| 03903 4761 | 13510-01B00 | 38 x 54 x 7 | PAO PK10 MA10S | 89/1~92/ | Engine CRANK SHAFT FRONT |
| 03903 1647 | 13510-01B00 | 38 x 54 x 7 | PAO PK10 MA10S | 89/1~92/ | Engine CAM SHAFT |
| 03903 5635 | 32113-01B00 | 20 x 35 x 8 | PAO PK10 | 89/1~92/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3287 | 40232-21B00 | 52 x 68 x 7.5 x 11.7 | PAO PK10 | 89/1~92/ | Wheel Hub FRONT GREASE SEAL |
| 03903 6241 | 40227-21B00 | 48 x 62 x 6 x 10 | PAO PK10 | 89/1~92/ | Wheel Hub FRONT DUST SEAL |
| 03903 1313 | 38342-01B00 | 38 x 58 x 11 x 17 | PAO PK10 | 89/1~92/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4599 | 38342-01B00 | 38 x 58 x 11 x 17 | PAO PK10 | 89/1~92/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4147 | 38342-M8001 | 40 x 56 x 8 | PAO PK10 | 89/1~92/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6113 | 49345-VC325 | | PATROL Y61 | 97/10~ | Steering (P/S) PINION GEAR KIT |
| 03903 5295 | 13510-V7202 | 40 x 52 x 7 | PATROL Y60 RD28T | 94/10~97/ | Engine CRANK SHAFT FRONT |
| 03903 4431 | 13042-16V00 | 40 x 52 x 7 | PATROL Y61 RD28TI | 97/10~99/ 6 | Engine CRANK SHAFT FRONT |
| 03903 1907 | 13510-43G01 | 58 x 80 x 7 | PATROL Y60 TD42 | 87/10~97/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4233 | 13510-V7202 | 40 x 52 x 7 | PATROL Y61 RD28TI | 99/6~99/9 | Engine CRANK SHAFT FRONT |
| 03903 4217 | 13510-43G00 | 58 x 80 x 10 | PATROL Y60 TB42S | 87/10~91/10 | Engine CRANK SHAFT FRONT |
| 03903 5493 | 13043-T7200 | 58 x 80 x 12 | PATROL 160 | 80/6~87/ | Engine CRANK SHAFT FRONT |
| 03903 3717 | 13042-D0100 | 34 x 48 x 8 | PATROL Y61 | 97/10~99/9 | Engine CAM SHAFT |
| 03903 3697 | 13042-D0100 | 34 x 48 x 8 | PATROL Y60 | 94/10~97/ | Engine CAM SHAFT |
| 03903 3525 | 38189-J2000 | 42 x 72.5 x 12 | PATROL Y60 TB42S | 87/10~90/10 | Final Drive PINION (REAR) |
| 03903 5143 | 49201-V0125 | | PATROL Y60 | 87/10~93/8 | Steering (P/S) ADJUSTER SCREW KIT |
| 03903 5045 | 13510-43G00 | 58 x 80 x 10 | PATROL Y61 TB45E | 97/10~02/7 | Engine CRANK SHAFT FRONT |
| 03903 6097 | 49345-55G26 | | PATROL Y60 | 93/8~ | Steering (P/S) PINION GEAR KIT |
| 03903 1585 | 49345-11G25 | | PATROL Y60 | 87/10~93/8 | Steering (P/S) PINION GEAR KIT |
| 03903 3949 | 49321-52N26 | | PATROL Y60,Y61 | 93/8~ | Steering (P/S) SECTOR SHAFT KIT |
| 03903 2817 | 49202-01J25 | | PATROL Y60 | 87/10~93/8 | Steering (P/S) SECTOR SHAFT KIT |
| 03903 1221 | 48029-04100 | 17 x 31 x 7 | PATROL 160.Y60 | 80/6~ | Steering WORM |
| 03903 4461 | 48040-82100 | 35 x 48 x 8 | PATROL 160.Y60 | 80/6~ | Steering SECTOR SHAFT |
| 03903 5235 | 38189-J2011 | 42 x 72.5 x 13 x 21 | PATROL Y60 TB42S | 90/11~97/ | Final Drive PINION (REAR) |
| 03903 6285 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | PATROL Y61 ALL | 97/10~ | Final Drive PINION (REAR) |
| 03903 2037 | 38189-N3100 | 40 x 75 x 12 x 17.5 | PATROL 160 CA# FINAL DRIVE | 80/6~83/8 | Final Drive PINION (REAR) |
| 03903 4223 | 38189-J2000 | 42 x 72.5 x 12 | PATROL 160 HH# FINAL DRIVE | 83/8~87/ | Final Drive PINION (REAR) |
| 03903 3255 | 38189-C7000 | 42 x 76 x 12 x 21 | PATROL Y60 TD42 | 87/10~91/10 | Final Drive PINION (REAR) |
| 03903 4287 | 13510-43G01 | 58 x 80 x 7 | PATROL Y60 TB42S,TB42E | 91/10~97/ | Engine CRANK SHAFT FRONT |
| 03903 4419 | 13207-C6000 | | PATROL PF40(IN.) | 80/6~87/ | Engine VALVE STEM SEAL |
| 03903 4225 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | PATROL Y60 TD42#,TB42E,RD28T | 91/10~97/ | Final Drive PINION (REAR) |
| 03903 5665 | 12279-5L300 | 80 x 100 x 8.5 | PATROL Y61 RD28TI | 99/6~99/9 | Engine CRANK SHAFT REAR |
| 03903 3553 | 13207-C6010 | | PATROL PF40(EX.) | 80/6~87/ | Engine VALVE STEM SEAL |
| 03903 3825 | 13207-C8702 | | PATROL SD33 OVER SIZE = 0.40 | 83/8~87/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3117 | 13207-C8701 | | PATROL SD33 OVER SIZE = 0.20 | 83/8~87/ | Engine VALVE STEM SEAL |
| 03903 5217 | 13207-C8700 | | PATROL SD33 STD | 83/8~87/ | Engine VALVE STEM SEAL |
| 03903 4265 | 13207-42L00 | | PATROL TB42S,TB42E,TB45E | 87/10~ | Engine VALVE STEM SEAL |
| 03903 4927 | 13207-V1700 | | PATROL TD42,TD42T | 87/10~02/11 | Engine VALVE STEM SEAL |
| 03903 5453 | 13207-D0101 | | PATROL RD28T#,ZD30DDTI,TB48DE | 94/10~ | Engine VALVE STEM SEAL |
| 03903 5735 | 12279-43G02 | 86 x 100 x 10 | PATROL Y60 TB42#,TD42 | 87/10~95/8 | Engine CRANK SHAFT REAR |
| 03903 1249 | 13207-76200 | | PATROL SD33 | 80/6~83/8 | Engine VALVE STEM SEAL |
| 03903 5663 | 38189-C7000 | 42 x 76 x 12 x 21 | PATROL 160 HG# FINAL DRIVE | 80/6~87/ | Final Drive PINION (REAR) |
| 03903 2205 | 12279-VC101 | RETAINER ID 85 | PATROL Y61 ZD30DDTI | 99/9~02/11 | Engine CRANK SHAFT REAR |
| 03903 4055 | 12279-VC101 | RETAINER ID 85 | PATROL Y61 TD42T | 97/10~02/11 | Engine CRANK SHAFT REAR |
| 03903 1387 | 12279-51N00 | RETAINER ID 96 (S) | PATROL Y60 TD42T | 93/8~97/ | Engine CRANK SHAFT REAR |
| 03903 1237 | 13510-51N01 | 60 x 80 x 7 | PATROL Y60 TD42T | 93/8~97/ | Engine CRANK SHAFT FRONT |
| 03903 1695 | 12279-5L300 | 80 x 100 x 8.5 | PATROL Y61 RD28TI | 97/10~99/6 | Engine CRANK SHAFT REAR |
| 03903 6513 | 12279-43G02 | 86 x 100 x 10 | PATROL Y60 TB42# | 95/8~97/ | Engine CRANK SHAFT REAR |
| 03903 2739 | 12279-C8610 | SPLIT SEAL | PATROL 160 SD33# | 86/3~87/ | Engine CRANK SHAFT REAR |
| 03903 1491 | 12279-58000 | SPLIT SEAL | PATROL 160 RF40 | 80/6~87/ | Engine CRANK SHAFT REAR |
| 03903 3993 | 12279-76200 | SPLIT SEAL | PATROL 160 SD33# | 80/6~86/3 | Engine CRANK SHAFT REAR |
| 03903 6491 | 13510-C6000 | 50 x 72 x 9 | PATROL 160 ALL | 82/8~87/ | Engine TIMING GEAR COVER |
| 03903 3161 | 13043-43700 | 50 x 72 x 12 | PATROL 160 ALL | 80/6~82/7 | Engine TIMING GEAR COVER |
| 03903 3789 | 13510-VC200 | 58 x 80 x 8 | PATROL Y61 TB48DE | 02/11~ | Engine CRANK SHAFT FRONT |
| 03903 4333 | 13510-VC200 | 58 x 80 x 8 | PATROL Y61 TB45E | 02/7~02/11 | Engine CRANK SHAFT FRONT |
| 03903 1477 | 13510-2W201 | 52 x 66 x 7 | PATROL Y61 ZD30DDTI | 99/9~02/11 | Engine CRANK SHAFT FRONT |
| 03903 1615 | 13510-51N01 | 60 x 80 x 7 | PATROL Y61 TD42T | 97/10~02/11 | Engine CRANK SHAFT FRONT |
| 03903 5155 | 12279-06J00 | RETAINER ID 84 (F) | PATROL Y60 TD42 | 95/8~97/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4291 | 40533-01J00 | 34 x 44 x 10 | PATROL Y61 | 97/10~ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 1121 | 32114-Y4000 | 30 x 45 x 8 | PATROL Y60 RD28T | 94/10~97/ | Transmission (M/T) FRONT COVER |
| 03903 4841 | 32113-86401 | 28 x 40 x 8 | PATROL 160,Y60(TB42S) | 80/6~95/ | Transmission (M/T) FRONT COVER |
| 03903 4875 | 43252-VH300 | 40 x 65 x 11 | PATROL Y61 | 97/10~ | Wheel Hub REAR AXLE SHAFT |
| 03903 2391 | 43252-T3200 | 38 x 62 x 11 | PATROL 160 HARD TOP | 80/6~83/8 | Wheel Hub REAR AXLE SHAFT |
| 03903 1693 | 43252-C6000 | 42 x 65 x 11 | PATROL Y60 | 87/10~97/ | Wheel Hub REAR AXLE SHAFT |
| 03903 2675 | 43252-C6000 | 42 x 65 x 11 | PATROL 160 ALL | 83/8~87/ | Wheel Hub REAR AXLE SHAFT |
| 03903 3083 | 43252-C6000 | 42 x 65 x 11 | PATROL 160 VAN | 80/6~83/8 | Wheel Hub REAR AXLE SHAFT |
| 03903 4593 | 43232-01J10 | 67 x 90 x 12.5 x 20 | PATROL Y61 | 97/10~ | Wheel Hub REAR HUB |
| 03903 5921 | 32114-Y4000 | 30 x 45 x 8 | PATROL Y61 RD28TI | 97/10~99/9 | Transmission (M/T) FRONT COVER |
| 03903 1971 | 09061-0001P | 68 x 82 x 7 | PATROL 160 | 80/6~87/ | Wheel Hub REAR HUB |
| 03903 3165 | 40533-C6000 | 33 x 66 x 13 | PATROL 160 | 80/6~87/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 1225 | 40533-01J00 | 34 x 44 x 10 | PATROL Y60 | 87/10~97/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 4907 | 40232-01J00 | 60 x 68 x 11 x 17.5 | PATROL Y61 | 97/10~ | Wheel Hub FRONT GREASE SEAL |
| 03903 3827 | 40232-01J00 | 60 x 68 x 11 x 17.5 | PATROL Y60 | 87/10~97/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1171 | 40227-C8200 | 65 x 88 x 9 x 18 | PATROL Y61 | 97/10~ | Wheel Hub FRONT DUST SEAL |
| 03903 5649 | 40227-C8200 | 65 x 88 x 9 x 18 | PATROL Y60 | 87/10~97/ | Wheel Hub FRONT DUST SEAL |
| 03903 1443 | 40227-C8200 | 65 x 88 x 9 x 18 | PATROL 160 ALL | 83/4~87/ | Wheel Hub FRONT DUST SEAL |
| 03903 2443 | 40227-C6000 | 65 x 88 x 11 x 16.8 | PATROL 160 ALL | 80/6~83/4 | Wheel Hub FRONT DUST SEAL |
| 03903 4621 | 12279-58S00 | 80 x 100 x 10 | PATROL Y60 RD28T | 94/10~97/8 | Engine CRANK SHAFT REAR |
| 03903 1719 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | PATROL Y61 ALL | 97/10~ | Final Drive PINION (FRONT) |
| 03903 5647 | 43232-01J10 | 67 x 90 x 12.5 x 20 | PATROL Y60 | 87/10~97/ | Wheel Hub REAR HUB |
| 03903 5447 | 33142-01J01 | 50 x 72.5 x 12 x 19.5 | PATROL Y60 TD42#,TB42E,RD28T | 87/10~97/ | Transfer CASE (REAR) |
| 03903 5443 | 38189-N3100 | 40 x 75 x 12 x 17.5 | PATROL 160 | 80/6~87/ | Final Drive PINION (FRONT) |
| 03903 6031 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | PATROL Y60 ALL | 91/11~97/ | Final Drive PINION (FRONT) |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6415 | 32219-Z5003 | 32 x 45 x 8 | PATROL Y60 TD42#,TB42E | 87/10~97/ | Transmission (M/T) FRONT COVER |
| 03903 1807 | 38189-C7000 | 42 x 76 x 12 x 21 | PATROL Y60 ALL | 87/10~91/ 11 | Final Drive PINION (FRONT) |
| 03903 4685 | 38189-C7000 | 42 x 76 x 12 x 21 | PATROL Y60 ALL | 87/10~91/ 11 | Final Drive PINION (FRONT) |
| 03903 4463 | 33142-01J01 | 50 x 72.5 x 12 x 19.5 | PATROL Y61 TD42T,TB45E,RD28TI,ZD30DDTI | 97/10~02/ 11 | Transfer CASE (REAR) |
| 03903 4663 | 33111-C8000 | 45 x 68 x 7.9 | PATROL Y60 TB42S | 87/10~97/ | Transfer CASE (REAR) |
| 03903 5471 | 33111-C6200 | 45 x 68 x 12 x 13 | PATROL 160 F4W81A | 80/6~85/10 | Transfer CASE (FRONT) |
| 03903 2971 | 33216-33G01 | 40 x 75 x 12 x 20 | PATROL Y61 ALL | 97/10~ | Transfer CASE (FRONT) |
| 03903 1125 | 33216-33G01 | 40 x 75 x 12 x 20 | PATROL Y60 ALL | 93/8~97/ | Transfer CASE (FRONT) |
| 03903 6317 | 33111-01J00 | 50 x 72 x 12 | PATROL Y60 RD28T.AT | 94/10~97/ | Transfer COVER |
| 03903 1673 | 32113-VB000 | 32 x 45 x 8 | PATROL Y61 ZD30DDTI | 99/9~02/11 | Transmission (M/T) FRONT COVER |
| 03903 2975 | 38189-N3100 | 40 x 75 x 12 x 17.5 | PATROL 160,Y60(TB42S) | 80/6~ | Transfer COVER |
| 03903 6379 | 33142-01J10 | 50 x 72.5 x 10 x 18.3 | PATROL Y61 TB48DE | 02/11~ | Transfer CASE (REAR) |
| 03903 4515 | 33216-01J00 | 40 x 75 x 12 x 17.9 | PATROL Y60 ALL | 87/10~93/ 8 | Transfer CASE (FRONT) |
| 03903 2131 | 32113-VB000 | 32 x 45 x 8 | PATROL Y61 TD42T | 97/10~02/ 11 | Transmission (M/T) FRONT COVER |
| 03903 1721 | 33111-01J00 | 50 x 72 x 12 | PATROL Y60 TD42#,TB42E | 87/10~97/ | Transfer COVER |
| 03903 2291 | 33111-01J00 | 50 x 72 x 12 | PATROL Y61 TD42T,TB45#,TB48#,RD28TI.AT.ZD30DDTI | 97/10~ | Transfer COVER |
| 03903 5621 | 33111-31G00 | 50 x 72 x 12 | PATROL Y60 RD28T.MT | 94/10~97/ | Transfer COVER |
| 03903 2363 | 33111-31G00 | 50 x 72 x 12 | PATROL Y61 RD28TI.MT | 97/10~99/ 9 | Transfer COVER |
| 03903 1411 | 33111-C8000 | 45 x 68 x 7.9 | PATROL 160 FS5W81A | 83/8~87/ | Transfer CASE (FRONT) |
| 03903 5977 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRAIRIE M12 CVT WITH LSD | 00/8~ | Mission & Differential (A/T) MISSION CASE |
| 03903 4819 | 33111-56E00 | 60 x 78 x 9 | PRAIRIE M12 AT.R4 | 98/11~01/ 5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2329 | 33111-56E00 | 60 x 78 x 9 | PRAIRIE M11 4WD | 88/9~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6567 | 38342-06R01 | 52 x 78 x 9 | PRAIRIE M10 CA20S | 87/2~88/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2135 | 38342-31X01 | 33 x 56 x 8 x 13 | PRAIRIE M12 CVT | 98/11~00/ 5 | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3879 | 38342-06R01 | 52 x 78 x 9 | PRAIRIE M12 AT.R4 | 01/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5581 | 38342-06R00 | 52 x 70 x 9 | PRAIRIE M10 CA20S | 85/10~87/2 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3325 | 49297-5Y085 | | PRAIRIE M11 2WD,4WD | 88/9~97/5 | Steering (P/S) GEAR HOUSING KIT |
| 03903 6095 | 40232-30R11 | 56 x 76 x 7.5 x 11 | PRAIRIE M11 CA20S,KA24E | 92/2~95/8 | Wheel Hub REAR IN. & OUT. |
| 03903 4229 | 38342-03E01 | 33 x 59 x 11 x 17 | PRAIRIE M11 2WD | 88/9~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3037 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | PRAIRIE M11 2WD | 88/9~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5697 | 40232-51E10 | 56 x 72 x 8 x 11.5 | PRAIRIE M10 4WD | 85/10~88/ | Wheel Hub FRONT IN. & OUT. |
| 03903 2211 | 40232-30R11 | 56 x 76 x 7.5 x 11 | PRAIRIE M11 2WD,4WD | 88/9~90/8 | Wheel Hub FRONT IN. & OUT. |
| 03903 5907 | 40232-33P00 | 56 x 76 x 6 x 11 | PRAIRIE M12 SR20DE(T),QR20DE | 98/11~ | Wheel Hub REAR IN. & OUT. |
| 03903 4863 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRAIRIE M12 CVT WITHOUT LSD | 98/11~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 3683 | 49297-5Y085 | | PRAIRIE M11 2WD | 97/5~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4235 | 40232-33P00 | 56 x 76 x 6 x 11 | PRAIRIE M11 2WD,4WD | 90/8~99/ | Wheel Hub FRONT IN. & OUT. |
| 03903 4547 | 38342-8E000 | 40 x 52 x 8 x 13 | PRAIRIE M12 CVT WITHOUT LSD | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1039 | 38342-56E00 | 43 x 90 x 12 x 21 | PRAIRIE M12 AT.R4 | 98/11~00/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 6011 | 38342-56E00 | 43 x 90 x 12 x 21 | PRAIRIE M11 4WD | 88/9~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6555 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRAIRIE M12 CVT WITH LSD | 98/11~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 2583 | 49297-5Y085 | | PRAIRIE M12 SR20DE | 98/11~99/10 | Steering (P/S) GEAR HOUSING KIT |
| 03903 4267 | 38342-M8001 | 40 x 56 x 8 | PRAIRIE M10 CA18S | 82/8~88/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5755 | 38342-M8001 | 40 x 56 x 8 | PRAIRIE M10 CA18S | 82/8~88/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3475 | 38342-81X01 | 33 x 59 x 9 x 15.6 | PRAIRIE M11 2WD | 90/9~95/8 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3577 | 38342-06R01 | 52 x 78 x 9 | PRAIRIE M10 CA20S | 87/2~88/ | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5129 | 38342-81X00 | 39 x 59 x 8 x 13.7 | PRAIRIE M12 AT.R4 | 01/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 5559 | 38342-81X03 | 42 x 90 x 12 x 22.1 | PRAIRIE M12 AT.R4 | 00/9~01/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 6547 | 38342-06R00 | 52 x 70 x 9 | PRAIRIE M10 CA20S | 85/10~87/2 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2601 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | PRAIRIE M10 CA20S | 85/10~88/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1395 | 38342-56E00 | 43 x 90 x 12 x 21 | PRAIRIE M11 4WD | 88/9~95/8 | Mission & Differential (M/T) MISSION CASE |
| 03903 2149 | 40232-M5661 | 52 x 67 x 7 | PRAIRIE M10 2WD | 82/8~88/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1867 | 40232-33P00 | 56 x 76 x 6 x 11 | PRAIRIE M12 SR20DE(T),QR20DE | 98/11~ | Wheel Hub FRONT IN. & OUT. |
| 03903 1377 | 38342-8E001 | 32.5 x 56 x 8 x 14 | PRAIRIE M12 CVT | 00/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4815 | 49297-50R25 | | PRAIRIE M11 4WD | 97/5~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1273 | 38342-03E01 | 33 x 59 x 11 x 17 | PRAIRIE M11 2WD | 88/9~90/9 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2321 | 38342-81X00 | 39 x 59 x 8 x 13.7 | PRAIRIE M11 2WD | 90/9~95/8 | Mission & Differential (M/T) MISSION CASE |
| 03903 2119 | 38342-03E00 | 39 x 59 x 11 x 17 | PRAIRIE M11 2WD | 88/9~90/9 | Mission & Differential (M/T) MISSION CASE |
| 03903 5787 | 38342-03E00 | 39 x 59 x 11 x 17 | PRAIRIE M10 CA20S | 85/10~88/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1317 | 38342-M8001 | 40 x 56 x 8 | PRAIRIE M10 E15S,CA18S | 82/8~88/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4503 | 32113-03E00 | 27.9 x 43 x 8 | PRAIRIE M11 | 88/9~95/8 | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1473 | 43252-M7001 | 43 x 54 x 7.5 | PRAIRIE M10 2WD | 82/8~88/ | Wheel Hub REAR AXLE SHAFT |
| 03903 4695 | 38342-M8001 | 40 x 56 x 8 | PRAIRIE M10 E15S,CA18S | 82/8~88/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4539 | 43232-87N00 | 47 x 67 x 10 x 16 | PRAIRIE M11 SR20DE | 95/8~99/ | Wheel Hub REAR HUB |
| 03903 3977 | 32113-03E00 | 27.9 x 43 x 8 | PRAIRIE M10 CA20S | 85/10~88/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5727 | 43252-87N10 | 30 x 55 x 9 | PRAIRIE M11 SR20DE | 95/8~99/ | Wheel Hub REAR AXLE SHAFT |
| 03903 1883 | 40232-51E10 | 56 x 72 x 8 x 11.5 | PRAIRIE M10 4WD | 85/10~88/ | Wheel Hub REAR IN. & OUT. |
| 03903 1263 | 40232-30R11 | 56 x 76 x 7.5 x 11 | PRAIRIE M11 CA20S,KA24E | 88/9~90/8 | Wheel Hub REAR IN. & OUT. |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6575 | 33111-56E00 | 60 x 78 x 9 | PRAIRIE M11 4WD | 88/9~95/8 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5511 | 40232-33P00 | 56 x 76 x 6 x 11 | PRAIRIE M11 CA20S,KA24E | 90/9~92/2 | Wheel Hub REAR IN. & OUT. |
| 03903 3063 | 40277-M5605 | 52 x 68 x 13 | PRAIRIE M10 2WD | 82/8~88/ | Wheel Hub FRONT DUST SEAL |
| 03903 4747 | 32113-M8000 | 25 x 40 x 8 | PRAIRIE M10 E15S,CA18S | 82/8~88/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1073 | 13207-01M01 | | PRAIRIE E15S | 82/8~88/ | Engine VALVE STEM SEAL |
| 03903 2751 | 13207-42L00 | | PRAIRIE KA24E(EX.) | 90/9~95/ | Engine VALVE STEM SEAL |
| 03903 2859 | 13207-D4200 | | PRAIRIE SR20DET(IN.) | 99/10~01/ | Engine VALVE STEM SEAL |
| 03903 3985 | 13207-D4200 | | PRAIRIE SR20DE,QR20DE | 95/8~ | Engine VALVE STEM SEAL |
| 03903 4729 | 13207-D0101 | | PRAIRIE SE20DET(EX.) | 99/10~01/ | Engine VALVE STEM SEAL |
| 03903 4261 | 12279-D0100 | 84 x 104 x 11 | PRAIRIE M10,M11 CA18S,CA20S | 82/8~90/4 | Engine CRANK SHAFT REAR |
| 03903 2649 | 13207-D0101 | | PRAIRIE KA24E(IN.) | 90/9~95/ | Engine VALVE STEM SEAL |
| 03903 2249 | 13207-D0101 | | PRAIRIE CA18S,CA20S | 82/8~99/ | Engine VALVE STEM SEAL |
| 03903 1515 | 13510-16A00 | 33 x 47 x 8 | PRAIRIE M10 CA18S,CA20S | 82/8~88/ | Engine CRANK SHAFT FRONT |
| 03903 2631 | 49297-WF527 | | PRAIRIE M12 QR20DE | 01/15~02/9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 1549 | 49297-WF925 | | PRAIRIE M12 QR20DE | 02/9~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4209 | 49365-10V26 | | PRAIRIE M11,M12 | 88/9~ | Steering (P/S) PINION GEAR KIT |
| 03903 6083 | 49297-WF526 | | PRAIRIE M12 SR20DE,SR20DET | 99/10~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3603 | 12279-58S00 | 80 x 100 x 10 | PRAIRIE M11 KA24E | 90/9~95/8 | Engine CRANK SHAFT REAR |
| 03903 4919 | 12279-AD205 | 84 x 104 x 8.5 | PRAIRIE M12 SR20DE(T),QR20DE | 98/11~ | Engine CRANK SHAFT REAR |
| 03903 5227 | 13042-D0100 | 34 x 48 x 8 | PRAIRIE M10,M11 CA18S,CA20S | 82/8~95/8 | Engine CAM SHAFT |
| 03903 2085 | 13510-01M00 | 36 x 49 x 7 | PRAIRIE M10 E15S | 82/8~88/ | Engine CRANK SHAFT FRONT |
| 03903 4505 | 13042-01M00 | 40 x 55 x 9 | PRAIRIE M10 E15S | 82/8~88/ | Engine CAM SHAFT |
| 03903 2225 | 13510-16A00 | 33 x 47 x 8 | PRAIRIE M11..CA20S(2WD) | 88/9~89/5 | Engine CRANK SHAFT FRONT |
| 03903 4605 | 13510-2J200 | 46 x 58 x 7 | PRAIRIE M12 SR20DE(T) | 00/5~01/5 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2415 | 12279-AD205 | 84 x 104 x 8.5 | PRAIRIE M11 SR20DE | 95/8~99/ | Engine CRANK SHAFT REAR |
| 03903 5193 | 12279-85Y00 | 84 x 104 x 11 | PRAIRIE M11 CA20S | 90/4~95/8 | Engine CRANK SHAFT REAR |
| 03903 5419 | 13168-01M00 | 32 x 50 x 8 | PRAIRIE M10 E15S | 82/8~88/ | Engine JACK SHAFT |
| 03903 2683 | 13510-2J200 | 46 x 58 x 7 | PRAIRIE M12 QR20DE | 01/5~ | Engine CRANK SHAFT FRONT |
| 03903 1417 | 13510-53J00 | 46 x 58 x 7 | PRAIRIE M11 KA24E,SR20DE | 90/9~99/ | Engine CRANK SHAFT FRONT |
| 03903 5901 | 13510-88G10 | 33 x 47 x 7 | PRAIRIE M11 CA20S | 89/5~99/ | Engine CRANK SHAFT FRONT |
| 03903 4071 | 13510-88G10 | 33 x 47 x 7 | PRAIRIE M11 CA20S(4WD) | 88/9~89/5 | Engine CRANK SHAFT FRONT |
| 03903 6121 | 13510-53J00 | 46 x 58 x 7 | PRAIRIE M12..SR20DE(T) | 98/11~00/5 | Engine CRANK SHAFT FRONT |
| 03903 2473 | 12279-01M00 | 80 x 100 x 10 | PRAIRIE M10 E15S | 82/8~88/ | Engine CRANK SHAFT REAR |
| 03903 3537 | 13510-31U00 | 48 x 60 x 7 | PRESAGE / BASSARA U30,JU30,U31 VQ30DE,VQ35DE | 98/6~ | Engine CRANK SHAFT FRONT |
| 03903 3385 | 38342-81X02 | 46 x 90 x 10.5 x 15.5 | PRESAGE / BASSARA U30,JU30 (2WD)&(LSD) | 88/9~95/8 | Mission & Differential (A/T) MISSION CASE |
| 03903 4771 | 13207-5L300 | | PRESAGE / BASSARA U30,JU30 YD25DDT(IN.) | 98/6~03/ | Engine VALVE STEM SEAL |
| 03903 3197 | 13207-D4200 | | PRESAGE / BASSARA U30,JU30 YD25DDT(EX.) | 98/6~03/ | Engine VALVE STEM SEAL |
| 03903 3965 | 13207-D4200 | | PRESAGE / BASSARA U30,JU30,U31 QR25DE,VQ30DE,VQ35DE | 98/6~ | Engine VALVE STEM SEAL |
| 03903 2797 | 13207-D0101 | | PRESAGE / BASSARA U30,JU30 KA24DE | 98/6~01/8 | Engine VALVE STEM SEAL |
| 03903 1323 | 12279-31U20 | RETAINER ID 97 (F) | PRESAGE / BASSARA U30,JU30,U31 VQ30DE,VQ35DE | 98/6~ | Engine CRANK SHAFT REAR |
| 03903 3875 | 12279-5L300 | 80 x 100 x 8.5 | PRESAGE / BASSARA U30,JU30 KA24DE | 98/6~ | Engine CRANK SHAFT REAR |
| 03903 3395 | 12279-AD205 | 84 x 104 x 8.5 | PRESAGE / BASSARA U30,JU30, QR25DE,YD25DDT | 98/6~ | Engine CRANK SHAFT REAR |
| 03903 5029 | 13510-AD200 | 50 x 62 x 7 | PRESAGE / BASSARA U30,JU30 YD25DDT | 98/6~01/8 | Engine CRANK SHAFT FRONT |
| 03903 5863 | 40232-33P00 | 56 x 76 x 6 x 11 | PRESAGE / BASSARA U30,JU30 | 98/6~03/ | Wheel Hub FRONT IN. & OUT. |
| 03903 5413 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | PRESAGE / BASSARA U30,JU30 (2WD)&(LSD) | 98/6~00/8 | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1031 | 40232-0P010 | 58 x 73 x 8.2 x 12.9 | PRESAGE / BASSARA U30,JU30 (4WD) | 98/6~03/ | Wheel Hub REAR IN. & OUT. |
| 03903 4427 | 38342-03E01 | 33 x 59 x 11 x 17 | PRESAGE / BASSARA U30,JU30 (2WD) | 98/6~00/8 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4961 | 38342-03E00 | 39 x 59 x 11 x 17 | PRESAGE / BASSARA U30,JU30 (4WD) | 98/6~00/8 | Mission & Differential (A/T) MISSION CASE |
| 03903 4681 | 13510-2J200 | 46 x 58 x 7 | PRESAGE / BASSARA U30,JU30,U31 QR25DE | 01/8~ | Engine CRANK SHAFT FRONT |
| 03903 5539 | 38342-81X00 | 39 x 59 x 8 x 13.7 | PRESAGE / BASSARA U30,JU30 (2WD)&WITHOUT(LSD) | 00/8~03/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1469 | 38342-81X00 | 39 x 59 x 8 x 13.7 | PRESAGE / BASSARA U30,JU30 (4WD) | 00/8~03/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4891 | 38342-81X02 | 46 x 90 x 10.5 x 15.5 | PRESAGE / BASSARA U31 (LSD) | 03/6~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1157 | 38342-81X01 | 33 x 59 x 9 x 15.6 | PRESAGE / BASSARA U30,JU30,U31 (2WD) | 00/8~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4983 | 38342-06R01 | 52 x 78 x 9 | PRESAGE / BASSARA U30,JU30,U31 (4WD) | 98/6~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4697 | 13510-53J00 | 46 x 58 x 7 | PRESAGE / BASSARA U30,JU30 KA24DE | 98/6~01/8 | Engine CRANK SHAFT FRONT |
| 03903 5519 | 38342-81X00 | 39 x 59 x 8 x 13.7 | PRESAGE / BASSARA U31 WITHOUT(LSD) | 03/6~ | Mission & Differential (A/T) MISSION CASE |
| 03903 3245 | 38342-03E00 | 39 x 59 x 11 x 17 | PRESAGE / BASSARA U30,JU30 (2WD)&WITHOUT(LSD) | 98/6~00/8 | Mission & Differential (A/T) MISSION CASE |
| 03903 5729 | 13207-53Y00 | | PRESEA GA15# | 90/6~00/ | Engine VALVE STEM SEAL |
| 03903 6419 | 13510-53J00 | 46 x 58 x 7 | PRESEA R11 SR18DE,SR20DE | 95/1~00/ | Engine CRANK SHAFT FRONT |
| 03903 3133 | 13510-V7202 | 40 x 52 x 7 | PRESEA R11 GA15DE | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 5421 | 12279-85Y00 | 84 x 104 x 11 | PRESEA R10 GA15DS,SR18D#,SR20DE | 90/6~95/ | Engine CRANK SHAFT REAR |
| 03903 4871 | 12279-AD205 | 84 x 104 x 8.5 | PRESEA R11 | 95/1~00/ | Engine CRANK SHAFT REAR |
| 03903 5725 | 13207-D0101 | | PRESEA SR20D(EX.) | 90/6~95/ | Engine VALVE STEM SEAL |
| 03903 4231 | 13207-D4200 | | PRESEA SR18#,SD20DE | 90/6~00/ | Engine VALVE STEM SEAL |
| 03903 6227 | 13510-53J00 | 46 x 58 x 7 | PRESEA R10 SR18D#,SR20DE | 90/6~95/ | Engine CRANK SHAFT FRONT |
| 03903 5589 | 13042-16V00 | 40 x 52 x 7 | PRESEA R10 GA15DE | 90/6~95/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4727 | 13207-D4200 | | PRESEA SR20D(IN.) | 90/6~95/ | Engine VALVE STEM SEAL |
| 03903 5989 | 38342-31X01 | 33 x 56 x 8 x 13 | PRESEA R10 SR18D#,SR20DE | 90/6~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5525 | 49297-65F25 | | PRESEA R11 | 95/1~ | Power Steering GEAR HOUSING KIT |
| 03903 1517 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRESEA R10 SE20D | 90/6~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3947 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRESEA R10 SR18D#(NON SLIP DIFF.) | 90/6~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5033 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRESEA R11 SR18D#,SR20DE(NON SLIP DIFF.) | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6127 | 38342-M8001 | 40 x 56 x 8 | PRESEA R10 GA15DS | 90/6~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3769 | 38342-M8001 | 40 x 56 x 8 | PRESEA R11 GA15DE | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4603 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRESEA R10 SR18D# | 90/6~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2979 | 38342-D2100 | 40 x 56 x 65 x 20 | PRESEA R11 GA15DE(NON SLIP DIFF.) | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1637 | 38342-D2100 | 40 x 56 x 65 x 20 | PRESEA R11 GA15DE(NON SLIP DIFF.) | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6389 | 38342-31X01 | 33 x 56 x 8 x 13 | PRESEA R11 SR18DE,SR20DE | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5833 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRESEA R10 GA15DS,SR18D# | 90/6~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3963 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRESEA R11 WITHOUT NON SLIP DIFF. | 95/1~01/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 4313 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRESEA R10 SE20D | 90/6~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4959 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRESEA R10 SR18D#(NON SLIP DIFF.) | 90/6~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3393 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRESEA R11 NON SLIP DIFF. | 95/1~01/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 1451 | 38342-D2100 | 40 x 56 x 65 x 20 | PRESEA R10 GA15DS(NON SLIP DIFF.) | 90/6~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5931 | 49365-10V26 | | PRESEA R10,R11 | 90/6~ | Power Steering PINION GEAR KIT |
| 03903 4351 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | PRESEA R11 | 95/1~00/ | Wheel Hub FONT GREASE SEAL |
| 03903 4855 | 38342-8E000 | 40 x 52 x 8 x 13 | PRESEA R11 WITHOUT NON SLIP DIFF. | 01/4~ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1887 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRESEA R11 NON SLIP DIFF. | 01/4~ | Mission & Differential (A/T) MISSION CASE |
| 03903 5089 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRESEA R10 GA15DE | 90/6~95/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4153 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRESEA R11 GA15DE | 95/1~00/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5305 | 38342-31X01 | 33 x 56 x 8 x 13 | PRESEA R10 SR18D#,SR20DE | 90/6~95/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1191 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRESEA R11 SR18D#,SR20DE | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4737 | 49297-86A25 | | PRESEA R10 | 90/6~95/ | Power Steering GEAR HOUSING KIT |
| 03903 5363 | 13042-16V00 | 40 x 52 x 7 | PRESEA R11 GA15DE | 95/1~00/7 | Engine CRANK SHAFT FRONT |
| 03903 5249 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | PRESEA R10 | 90/6~95/ | Wheel Hub FONT GREASE SEAL |
| 03903 4127 | 40227-50Y01 | 56 x 74.2 x 10.3 | PRESEA R10 | 90/6~95/ | Wheel Hub FRONT DUST SEAL |
| 03903 4553 | 32113-M8000 | 25 x 40 x 8 | PRESEA R10,R11 | 90/6~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 4113 | 38342-M8001 | 40 x 56 x 8 | PRESEA R10 GA15DE | 90/6~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2139 | 38342-M8001 | 40 x 56 x 8 | PRESEA R11 GA15DE | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1471 | 38342-D2100 | 40 x 56 x 65 x 20 | PRESEA R10 GA15DS(NON SLIP DIFF.) | 90/6~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 4091 | 38342-31X01 | 33 x 56 x 8 x 13 | PRESEA R11 SR18DE,SR20DE | 95/1~00/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6305 | 40227-50Y01 | 56 x 74.2 x 10.3 | PRESEA R11 | 95/1~00/ | Wheel Hub FRONT DUST SEAL |
| 03903 3111 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA P11E | 96/11~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3105 | 49297-53E25 | | PRIMERA P10 | 90/2~95/ | Power Steering GEAR HOUSING KIT |
| 03903 5391 | 38342-06R01 | 52 x 78 x 9 | PRIMERA P12 QR20DE | 01/1~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3669 | 38342-8E001 | 32.5 x 56 x 8 x 14 | PRIMERA P12 CVT,MCVT | 01/1~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3419 | 38342-8E001 | 32.5 x 56 x 8 x 14 | PRIMERA (W)P11 SR20#(CVT) | 00/5~01/ | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1253 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA P12 QG18DE | 02/2~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1601 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA (W)P11 QG18DE | 00/7~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5733 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA (W)P11 QG18DD | 00/5~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2153 | 33111-31X00 | 60 x 76 x 9 | PRIMERA WP11 SR20DE | 97/9~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1301 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRIMERA (W)P11 CVT(NON SLIP DIFF.) | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2465 | 33111-31X00 | 60 x 76 x 9 | PRIMERA P10 4WD | 90/10~95/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4253 | 49365-10V26 | | PRIMERA P10,P11 | 90/2~ | Power Steering WORM GEAR KIT |
| 03903 4173 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA (W)P11 SR20#(CVT) | 98/9~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4913 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA (W)P11 CVT | 97/9~98/9 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5369 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA (W)P11 SR18DE | 95/9~98/9 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4259 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA (W)P11 QG18DE | 98/9~00/7 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6187 | 38342-81X00 | 39 x 59 x 8 x 13.7 | PRIMERA P12 QR20DE | 01/1~ | Mission & Differential (A/T) MISSION CASE |
| 03903 5343 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRIMERA P12 MCVT(NON SLIP DIFF.) | 02/5~03/7 | Mission & Differential (A/T) MISSION CASE |
| 03903 4453 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRIMERA P12 CVT | 02/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1663 | 33111-31X00 | 60 x 76 x 9 | PRIMERA P11 4WD | 95/9~01/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4947 | 12279-85Y00 | 84 x 104 x 11 | PRIMERA P10(E) | 90/2~97/ | Engine CRANK SHAFT REAR |
| 03903 6261 | 40232-30R11 | 56 x 76 x 7.5 x 11 | PRIMERA P10 ALL | 90/2~90/10 | Wheel Hub FRONT IN.& OUT. |
| 03903 3937 | 13207-53Y00 | | PRIMERA QG18# | 98/9~ | Engine VALVE STEM SEAL |
| 03903 3163 | 13207-D4200 | | PRIMERA SR20#,QR20DE,QR25DD | 94/9~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3387 | 13207-D4200 | | PRIMERA SR18D# | 90/2~01/ | Engine VALVE STEM SEAL |
| 03903 4689 | 13207-D4200 | | PRIMERA SR20D#(IN.) | 90/2~94/9 | Engine VALVE STEM SEAL |
| 03903 5019 | 13207-D0101 | | PRIMERA SR20D#(EX.) | 90/2~94/9 | Engine VALVE STEM SEAL |
| 03903 4405 | 12279-AD205 | 84 x 104 x 8.5 | PRIMERA P12 | 01/1~ | Engine CRANK SHAFT REAR |
| 03903 1325 | 49297-86A26 | | PRIMERA P11 2WD | 95/9~ | Power Steering GEAR HOUSING KIT |
| 03903 3101 | 12279-85Y00 | 84 x 104 x 11 | PRIMERA P11(E) ALL | 95/9~97/6 | Engine CRANK SHAFT REAR |
| 03903 5465 | 49297-AA085 | | PRIMERA P11 4WD | 95/9~ | Power Steering GEAR HOUSING KIT |
| 03903 2863 | 13510-2J200 | 46 x 58 x 7 | PRIMERA P12 SR20VE,QR20DE,QR25DD | 01/1~ | Engine CRANK SHAFT FRONT |
| 03903 1705 | 13510-2J200 | 46 x 58 x 7 | PRIMERA (W)P11 SR20VE | 97/9~01/ | Engine CRANK SHAFT FRONT |
| 03903 1977 | 13510-2J200 | 46 x 58 x 7 | PRIMERA (W)P11(E) SR18DE,SR20DE | 95/9~ | Engine CRANK SHAFT FRONT |
| 03903 4281 | 13510-V7202 | 40 x 52 x 7 | PRIMERA P12 QG18DE | 02/2~ | Engine CRANK SHAFT FRONT |
| 03903 3647 | 13510-V7202 | 40 x 52 x 7 | PRIMERA (W)P11 QG18D# | 00/7~01/ | Engine CRANK SHAFT FRONT |
| 03903 6157 | 13510-53J00 | 46 x 58 x 7 | PRIMERA P10 | 90/2~95/ | Engine CRANK SHAFT FRONT |
| 03903 5859 | 13042-16V00 | 40 x 52 x 7 | PRIMERA (W)P11 QG18D# | 98/9~00/7 | Engine CRANK SHAFT FRONT |
| 03903 6165 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA (W)P11 QG18DD | 98/9~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6213 | 12279-AD205 | 84 x 104 x 8.5 | PRIMERA (W)P11(E) ALL | 97/6~01/ | Engine CRANK SHAFT REAR |
| 03903 4915 | 38342-03E00 | 39 x 59 x 11 x 17 | PRIMERA P12 ALL | 01/8~02/12 | Mission & Differential (M/T) MISSION CASE |
| 03903 6565 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA P10 2WD | 90/2~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1847 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA P11 QG18DE WITHOUT NON SLIP DIFF. | 98/9~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5101 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRIMERA (W)P11 SR18DE(NON SLIP DIFF.) | 00/11~01/ | Mission & Differential (A/T) MISSION CASE |
| 03903 2387 | 38342-8H500 | 39 x 59 x 8 x 13.7 | PRIMERA P12 ALL | 02/12~03/7 | Mission & Differential (M/T) MISSION CASE |
| 03903 5291 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA P10(E) 2WD | 90/2~97/ | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2319 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA (W)P11 4WD | 95/9~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5819 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA P10 (2WD)(NON SLIP DIFF.) | 90/9~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1311 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA P10 4WD | 90/10~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2699 | 38342-31X01 | 33 x 56 x 8 x 13 | PRIMERA (W)P11 2WD | 95/9~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6319 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA P10 2WD | 90/2~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1571 | 38342-03E01 | 33 x 59 x 11 x 17 | PRIMERA P12 | 01/8~03/7 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5843 | 32113-8H500 | 27 x 42 x 7 | PRIMERA P12 | 01/8~03/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5563 | 32113-M8000 | 25 x 40 x 8 | PRIMERA (W)P11 | 95/9~01 | Mission & Differential (M/T) INPUT SHAFT |
| 03903 4951 | 32113-M8000 | 25 x 40 x 8 | PRIMERA P10 | 90/2~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1461 | 40232-33P00 | 56 x 76 x 6 x 11 | PRIMERA (W)P11 4WD | 95/9~01 | Wheel Hub REAR IN. & OUT. |
| 03903 6503 | 40232-33P00 | 56 x 76 x 6 x 11 | PRIMERA P10 4WD | 90/10~95/ | Wheel Hub REAR IN. & OUT. |
| 03903 5463 | 40232-2F001 | 56 x 76 x 6 x 12 | PRIMERA P11E | 96/6~ | Wheel Hub FRONT IN.& OUT. |
| 03903 2661 | 40232-33P00 | 56 x 76 x 6 x 11 | PRIMERA (W)P11 | 95/9~01 | Wheel Hub FRONT IN.& OUT. |
| 03903 1553 | 40232-33P00 | 56 x 76 x 6 x 11 | PRIMERA P10(E) ALL | 90/10~97/ | Wheel Hub FRONT IN.& OUT. |
| 03903 1523 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA (W)P11 2WD | 95/9~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3923 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA (W)P11 CVT | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6545 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PRIMERA (W)P11 SR20DE | 01/4~ | Mission & Differential (A/T) MISSION CASE |
| 03903 4929 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA P12 MCVT | 01/1~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2453 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA P12 QG18DE | 02/2~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1383 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA (W)P11 (2WD)(NON SLIP DIFF.) | 95/9~01/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6173 | 38342-8E000 | 40 x 52 x 8 x 13 | PRIMERA (W)P11 QG18DE | 00/11~01/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4339 | 33111-31X00 | 60 x 76 x 9 | PRIMERA P10 4WD | 90/10~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6287 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA (W)P11 CVT(NON SLIP DIFF.) | 97/9~00/5 | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3569 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA (W)P11 QG18DE(NON SLIP DIFF.) | 98/9~00/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 1861 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA (W)P11 SR18DE(NON SLIP DIFF.) | 95/9~98/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 3321 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA P10(E) 2WD | 90/2~97/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4525 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA P11 4WD | 95/9~97/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 3289 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA P10 (4WD)(NON SLIP DIFF.) | 90/9~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5983 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA P10 4WD | 90/10~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6233 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA P11E | 96/11~ | Mission & Differential (A/T) MISSION CASE |
| 03903 3905 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA (W)P11 QG18DE | 98/9~00/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 2261 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA (W)P11 CVT | 97/9~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 3551 | 33111-31X00 | 60 x 76 x 9 | PRIMERA (W)P11 4WD | 95/9~01/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5105 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PRIMERA (W)P11 SR18DE | 95/9~98/9 | Mission & Differential (A/T) MISSION CASE |
| 03903 4103 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PRIMERA (W)P11 SR20DE | 97/9~01/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 6397 | 43232-50A00 | 40 x 52 x 6 x 10 | PULSAR N13 2WD | 86/5~90/ | Wheel Hub REAR |
| 03903 4639 | 43252-M7001 | 43 x 54 x 7.5 | PULSAR N10,N12 | 78/5~86/ | Wheel Hub REAR |
| 03903 2307 | 40227-50Y01 | 56 x 74.2 x 10.3 | PULSAR N15 | 95/1~00/ | Wheel Hub FRONT DUST SEAL |
| 03903 2911 | 40227-50Y01 | 56 x 74.2 x 10.3 | PULSAR N14 | 90/8~95/ | Wheel Hub FRONT DUST SEAL |
| 03903 5115 | 39252-52A00 | 52 x 78.4 x 9.5 | PULSAR N13 | 86/5~90/ | Wheel Hub FRONT DUST SEAL |
| 03903 2495 | 40227-M5605 | 52 x 68 x 13 | PULSAR N10,N12 A14,E15,CD17 | 78/5~86/ | Wheel Hub FRONT DUST SEAL |
| 03903 1053 | 40227-M3005 | 48 x 62 x 13 | PULSAR N10,N12 A12,E13 | 78/5~86/ | Wheel Hub FRONT DUST SEAL |
| 03903 3011 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | PULSAR N14 4WD | 90/8~95/ | Wheel Hub REAR INNER |
| 03903 5551 | 40232-M0215 | 48 x 62 x 7 | PULSAR N10,N12 A12,E13 | 78/5~86/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1933 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | PULSAR N15 4WD | 95/1~00/ | Wheel Hub REAR INNER |
| 03903 1941 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | PULSAR N14 | 90/8~95/ | Wheel Hub FRONT GREASE SEAL |
| 03903 5951 | 49297-53A25 | | PULSAR N13 | 86/5~90/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 2163 | 40232-51E10 | 56 x 72 x 8 x 11.5 | PULSAR N13 4WD | 86/5~90/ | Wheel Hub REAR IN. & OUT. |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1947 | 13510-H1010 | 38 x 55 x 9 | PULSAR N10 A12,A14 | 78/5~81/2 | Engine CRANK SHAFT FRONT |
| 03903 2955 | 13168-01M00 | 32 x 50 x 8 | PULSAR N10,N12,N13 E13,E15 | 81/3~88/ | Engine JACK SHAFT |
| 03903 5689 | 13042-16A11 | 36 x 50 x 8 | PULSAR N15 CD20 | 95/1~00/ | Engine CAM SHAFT REAR |
| 03903 1777 | 13042-16V00 | 40 x 52 x 7 | PULSAR N13 CA16D | 86/5~88/ | Engine CAM SHAFT FRONT |
| 03903 2839 | 13042-D0100 | 34 x 48 x 8 | PULSAR N15 CD20 | 95/1~00/ | Engine CAM SHAFT FRONT |
| 03903 5177 | 13042-D0100 | 34 x 48 x 8 | PULSAR N12,N13,N14 CD17 | 83/5~95/ | Engine CAM SHAFT FRONT |
| 03903 1099 | 13042-01M00 | 40 x 55 x 9 | PULSAR N10,N12,N13 E13,E15 | 81/3~88/ | Engine CAM SHAFT FRONT |
| 03903 6027 | 49365-10V26 | | PULSAR N13,N14,N15 | 86/5~ | Steering (P/S) PINION GEAR KIT |
| 03903 5495 | 13510-16A00 | 33 x 47 x 8 | PULSAR N12,N13,N14 CD17 | 83/5~95/ | Engine CRANK SHAFT FRONT |
| 03903 5351 | 49297-86A25 | | PULSAR N14 | 90/8~95/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4195 | 13042-16V00 | 40 x 52 x 7 | PULSAR N15 CD20 | 95/1~00/ | Engine CRANK SHAFT FRONT |
| 03903 2301 | 48125-60R00 | 16 x 26 x 7 | PULSAR N14 | 90/8~95/ | Steering GEAR |
| 03903 2951 | 48125-50A00 | 15 x 30 x 8 x 10.5 | PULSAR N13 | 86/5~90/ | Steering GEAR |
| 03903 2069 | 48125-78500 | 17 x 35 x 8 | PULSAR N12 | 82/5~86/ | Steering GEAR |
| 03903 1075 | 33111-06R00 | 52 x 66 x 9 | PULSAR N13,N14,N15 4WD | 86/5~00/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5077 | 33111-31X00 | 60 x 76 x 9 | PULSAR N15 SR18DE(5DOOR) | 96/5~00/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4509 | 38342-31X01 | 33 x 56 x 8 x 13 | PULSAR N14,N15..SRDE(EXCEPT 5DOOR) | 90/8~00/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2685 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PULSAR N15 GA15DE(2WD),GA16DE,CD20(2WD) | 95/1~00/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5975 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PULSAR N14 GA13DS,GA15DS(2WD),GA16DE,CD17 | 90/8~95/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5309 | 38342-03E01 | 33 x 59 x 11 x 17 | PULSAR N13 CA16D | 87/1~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3339 | 49297-65F25 | | PULSAR N15 | 95/1~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3617 | 12279-85Y00 | 84 x 104 x 11 | PULSAR N14 GA13,GA15,GA16,SR18DE, SR20DET | 90/8~95/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2161 | 13207-53Y00 | | PULSAR GA13DS,GA15#,GA16# | 90/8~00/ | Engine VALVE STEM SEAL |
| 03903 1969 | 13207-77A00 | | PULSAR GA15#(EX.) | 88/4~90/ | Engine VALVE STEM SEAL |
| 03903 4693 | 13207-D4200 | | PULSAR SR20DET(IN.) | 90/8~95/ | Engine VALVE STEM SEAL |
| 03903 4471 | 13207-D4200 | | PULSAR GA15#(IN.) | 88/4~90/ | Engine VALVE STEM SEAL |
| 03903 2281 | 13207-D4200 | | PULSAR CA16D,SR16VE,SR18DE | 86/5~90/ | Engine VALVE STEM SEAL |
| 03903 5135 | 13207-H7200 | | PULSAR A12S,A14# | 78/5~81/2 | Engine VALVE STEM SEAL |
| 03903 2175 | 13207-D0101 | | PULSAR SR20DET(EX.) | 90/8~95/ | Engine VALVE STEM SEAL |
| 03903 2065 | 13207-D0101 | | PULSAR CD17,CD20 | 83/5~00/ | Engine VALVE STEM SEAL |
| 03903 5883 | 13207-01M01 | | PULSAR E13,E15 | 81/3~90/ | Engine VALVE STEM SEAL |
| 03903 6509 | 13510-01M00 | 36 x 49 x 7 | PULSAR N10,N12,N13 E13,E15 | 81/3~88/ | Engine CRANK SHAFT FRONT |
| 03903 2627 | 12279-85Y00 | 84 x 104 x 11 | PULSAR N15 ALL | 95/1~97/9 | Engine CRANK SHAFT REAR |
| 03903 1831 | 38342-M8001 | 40 x 56 x 8 | PULSAR N13 E13S,GA15S(2WD),CD17 F3 | 88/4~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5017 | 12279-D0100 | 84 x 104 x 11 | PULSAR N13 GA15 | 88/4~90/ | Engine CRANK SHAFT REAR |
| 03903 2213 | 12279-D0100 | 84 x 104 x 11 | PULSAR N12,N13,N14 CD17,CA16D | 83/5~95/ | Engine CRANK SHAFT REAR |
| 03903 6387 | 12279-01M00 | 80 x 100 x 10 | PULSAR N10,N12,N13 E13,E15 | 81/3~88/ | Engine CRANK SHAFT REAR |
| 03903 1681 | 12279-H2311 | 60 x 82 x 12 | PULSAR N10 A12,A14 | 78/5~81/2 | Engine CRANK SHAFT REAR |
| 03903 1199 | 13510-2J200 | 46 x 58 x 7 | PULSAR N15 SR16VE | 97/9~00/ | Engine CRANK SHAFT FRONT |
| 03903 3175 | 13510-V7202 | 40 x 52 x 7 | PULSAR N15 GA15DE,GA16DE | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 3131 | 13510-53J00 | 46 x 58 x 7 | PULSAR M14,N15 SR18DE,SR20DET | 90/8~00/ | Engine CRANK SHAFT FRONT |
| 03903 3219 | 13042-16V00 | 40 x 52 x 7 | PULSAR N13 CA16D | 86/5~90/ | Engine CRANK SHAFT FRONT |
| 03903 1697 | 13042-16V00 | 40 x 52 x 7 | PULSAR N13,N14,N15 GA13,GA15#,GA16# | 88/9~00/7 | Engine CRANK SHAFT FRONT |
| 03903 1153 | 12279-AD205 | 84 x 104 x 8.5 | PULSAR N15 ALL | 97/9~00/ | Engine CRANK SHAFT REAR |
| 03903 1747 | 38342-M8001 | 40 x 56 x 8 | PULSAR N13 E13S,E15#,CD17,GA15#...2 WD | 86/5~90/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4969 | 38342-M8001 | 40 x 56 x 8 | PULSAR N14 GA13DS,GA15DS,CD17 2WD | 90/8~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2165 | 38342-M8001 | 40 x 56 x 8 | PULSAR N13 E13S,E15#,CD17,GA15#...2 WD | 86/5~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6349 | 38342-M8001 | 40 x 56 x 8 | PULSAR N10,N12 | 81/3~86/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4175 | 38342-56E00 | 43 x 90 x 12 x 21 | PULSAR N15 CD20(4WD) | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2099 | 38342-56E00 | 43 x 90 x 12 x 21 | PULSAR N14 SR20DET(4WD) | 90/8~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1643 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PULSAR N14,N15 SR18DE | 90/8~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1845 | 38342-D2100 | 40 x 56 x 65 x 20 | PULSAR N15 GA15DE(4WD),GA16DE,C D20(2WD) | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3703 | 38342-D2100 | 40 x 56 x 65 x 20 | PULSAR N14 GA15DS(4WD),GA16DE | 90/8~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1203 | 38342-D2100 | 40 x 56 x 65 x 20 | PULSAR N13 E15#(4WD),GA15#(4WD),C A16D | 86/5~90/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1457 | 38342-03E00 | 39 x 59 x 11 x 17 | PULSAR N13 GA15#(2WD) F4 | 88/4~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2935 | 38342-M8001 | 40 x 56 x 8 | PULSAR N14 GA13DS,GA15DS,CD17 2WD | 90/8~95/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3043 | 38342-31X01 | 33 x 56 x 8 x 13 | PULSAR N14,N15 SR18DE | 90/8~96/5 | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3253 | 38342-M8001 | 40 x 56 x 8 | PULSAR N10,N12 | 81/3~86/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2123 | 32113-03E00 | 27.9 x 43 x 8 | PULSAR N15 CD20(4WD) | 95/1~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1115 | 32113-03E00 | 27.9 x 43 x 8 | PULSAR N14 SR20DET(4WD) | 90/8~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 6047 | 32113-M8000 | 25 x 40 x 8 | PULSAR N15 EXCEPT CD20(4WD) | 95/1~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3401 | 32113-M8000 | 25 x 40 x 8 | PULSAR N14 EXCEPT SR20DET(4WD) | 90/8~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2561 | 32113-M8000 | 25 x 40 x 8 | PULSAR N10,N12,N13 | 81/3~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3333 | 30402-M0101 | 28 x 40 x 8 | PULSAR N10 | 78/5~81/2 | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2927 | 40227-50Y01 | 56 x 74.2 x 10.3 | PULSAR N15 4WD | 95/1~00/ | Wheel Hub REAR OUTER |
| 03903 5661 | 40227-50Y01 | 56 x 74.2 x 10.3 | PULSAR N14 4WD | 90/8~95/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4817 | 38342-M8001 | 40 x 56 x 8 | PULSAR N15 GA15DE(2WD) | 95/1~00/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3123 | 38342-M8001 | 40 x 56 x 8 | PULSAR N13 E13S,E15#,CD17 F3 | 88/4~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 2553 | 40232-M5661 | 52 x 67 x 7 | PULSAR N10,N12 A14,E15,CD17 | 78/5~86/ | Wheel Hub FRONT GREASE SEAL |
| 03903 5483 | 38342-M8001 | 40 x 56 x 8 | PULSAR N13 E13S,E15S(2WD),CD17 | 86/5~88/4 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 2379 | 38342-8E002 | 41.5 x 90 x 8 x 12 | PULSAR N15 (NON SLIP DIFF. ALL),SR18DE | 01/4~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1015 | 38342-8E000 | 40 x 52 x 8 x 13 | PULSAR N15 GA15DE(WITHOUT NON SLIP DIFF.)CD20 | 01/4~ | Mission & Differential (A/T) MISSION CASE |
| 03903 3171 | 38342-21X01 | 39 x 57 x 11 x 17 | PULSAR N13 GA15#(2WD) F4 | 88/4~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3883 | 38342-21X01 | 39 x 57 x 11 x 17 | PULSAR N13 E15E(2WD) | 86/5~88/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 4657 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | PULSAR N13 CA16D | 87/1~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5133 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PULSAR N15 (NON SLIP DIFF. ALL),SR18DE | 95/1~01/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 2323 | 38342-31X02 | 42 x 90 x 9.5 x 13 | PULSAR N14 SR18DE | 90/8~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3951 | 38342-M8001 | 40 x 56 x 8 | PULSAR N15 GA15DE(2WD,WITHOUT NON SLIP DIFF.) | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3829 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PULSAR N14 GA13DS,GA15DS,GA16DE, CD17 | 90/8~95/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5711 | 38342-D2100 | 40 x 56 x 65 x 20 | PULSAR N15 NON SLIP DIFF. | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1043 | 38342-M8001 | 40 x 56 x 8 | PULSAR N13 E13S,E15S,E15E(4WD),CD17 | 86/5~88/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 4373 | 38342-01E00 | 33 x 56 x 48.5 x 24.5 | PULSAR N13 CA16D | 86/5~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2339 | 33111-06R00 | 52 x 66 x 9 | PULSAR N15 GA15DE(4WD) | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4349 | 33111-06R00 | 52 x 66 x 9 | PULSAR N14 GA15DS(4WD) | 90/8~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1269 | 33111-06R00 | 52 x 66 x 9 | PULSAR N13 E15#(4WD),GA15#(4WD) | 86/5~90/ | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5451 | 33111-31X00 | 60 x 76 x 9 | PULSAR N15 SR18DE | 96/5~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1555 | 33111-56E00 | 60 x 78 x 9 | PULSAR N15 CD20(4WD) | 95/1~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1645 | 33111-56E00 | 60 x 78 x 9 | PULSAR N14 SR20DET(4WD) | 90/8~95/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6153 | 38342-31X01 | 33 x 56 x 8 x 13 | PULSAR N15 SR16VE | 96/5~00/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3265 | 38342-03E00 | 39 x 59 x 11 x 17 | PULSAR N13 E15E(2WD) | 86/5~88/4 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6451 | 38342-31X00 | 40 x 56 x 8 x 13.5 | PULSAR N15 WITHOUT NON SLIP DIFF.(GA15DE,GA16DE,CD20) | 95/1~01/4 | Mission & Differential (A/T) MISSION CASE |
| 03903 2015 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | PULSAR N15 | 95/1~00/ | Wheel Hub FRONT GREASE SEAL |
| 03903 4041 | 13510-53J00 | 46 x 58 x 7 | RASHEEN RB14 SR18DE,SR20DE | 97/1~ | Engine CRANK SHAFT FRONT |
| 03903 3637 | 33111-06R00 | 52 x 66 x 9 | RASHEEN RB14 | 94/12~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2305 | 33111-06R00 | 52 x 66 x 9 | RASHEEN RB14 | 94/12~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5741 | 38189-U3011 | 35 x 67 x 13.8 x 19.5 | RASHEEN RB14 | 94/12~ | Final Drive PINION |
| 03903 3759 | 38342-21000 | 32 x 52 x 11 x 15.5 | RASHEEN RB14 | 94/12~ | Final Drive DIFF.SIDE |
| 03903 4925 | 49297-65F25 | | RASHEEN RB14 | 94/12~ | Power Steering GEAR HOUSING KIT |
| 03903 2845 | 32113-M8000 | 25 x 40 x 8 | RASHEEN RB14 | 94/12~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5933 | 13042-16V00 | 40 x 52 x 7 | RASHEEN RB14 GA15DE | 94/12~00/7 | Engine CRANK SHAFT FRONT |
| 03903 2347 | 38342-D2100 | 40 x 56 x 65 x 20 | RASHEEN RB14 | 94/12~ | Mission & Differential (M/T) MISSION CASE |
| 03903 5673 | 13510-V7202 | 40 x 52 x 7 | RASHEEN RB14 GA15DE | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 4629 | 12279-85Y00 | 84 x 104 x 11 | RASHEEN RB14 GA15DE | 94/12~98/1 | Engine CRANK SHAFT REAR |
| 03903 3091 | 12279-85Y00 | 84 x 104 x 11 | RASHEEN RB14 SR18DE | 97/1~98/1 | Engine CRANK SHAFT REAR |
| 03903 4411 | 12279-AD205 | 84 x 104 x 8.5 | RASHEEN RB14 GA15DE | 98/1~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5097 | 12279-AD205 | 84 x 104 x 8.5 | RASHEEN RB14 SR18DE,SR20DE | 98/1~ | Engine CRANK SHAFT REAR |
| 03903 3599 | 13207-D4200 | | RASHEEN RB14 SR18DE,SR20DE | 97/1~ | Engine VALVE STEM SEAL |
| 03903 1531 | 13207-53Y00 | | RASHEEN RB14 GA15DE | 94/12~ | Engine VALVE STEM SEAL |
| 03903 6273 | 49365-10V26 | | RASHEEN RB14 | 94/12~ | Power Steering PINION SEAL KIT |
| 03903 1283 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | RASHEEN RB14 | 94/12~ | Wheel Hub FRONT INNER |
| 03903 1397 | 40227-50Y01 | 56 x 74.2 x 10.3 | RASHEEN RB14 | 94/12~ | Wheel Hub FRONT OUTER |
| 03903 3205 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | RASHEEN RB14 | 94/12~ | Wheel Hub REAR INNER |
| 03903 4473 | 40227-50Y01 | 56 x 74.2 x 10.3 | RASHEEN RB14 | 94/12~ | Wheel Hub REAR OUTER |
| 03903 4779 | 38342-31X00 | 40 x 56 x 8 x 13.5 | RASHEEN RB14 | 94/12~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6441 | 13379-01M00 | 80 x 100 x 10 | S-CARGO G20 E15S | 89/1~91/ | Engine CARNK SHAFT REAR |
| 03903 1833 | 13207-01M01 | | S-CARGO G20 E15S | 89/1~91/ | Engine VALVE STEM SEAL |
| 03903 3881 | 13510-01M00 | 36 x 49 x 7 | S-CARGO G20 E15S | 89/1~91/ | Engine CARNK SHAFT FRONT |
| 03903 5403 | 13168-01M00 | 32 x 50 x 8 | S-CARGO G20 E15S | 89/1~91/ | Engine JACK SHAFT |
| 03903 6571 | 13042-01M00 | 40 x 55 x 9 | S-CARGO G20 E15S | 89/1~91/ | Engine CAM SHAFT |
| 03903 6237 | 38342-M8001 | 40 x 56 x 8 | S-CARGO G20 | 89/1~91/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3849 | 38342-M8001 | 40 x 56 x 8 | S-CARGO G20 | 89/1~91/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6549 | 43252-M7001 | 43 x 54 x 7.5 | S-CARGO G20 | 89/1~91/ | Wheel Hub REAR |
| 03903 5691 | 40232-M5661 | 52 x 67 x 7 | S-CARGO G20 | 89/1~91/ | Wheel Hub FRONT GREASE SEAL |
| 03903 5189 | 40227-M5605 | 52 x 68 x 13 | S-CARGO G20 | 89/1~91/ | Wheel Hub FRONT DUST SEAL |
| 03903 4157 | 13042-D0100 | 34 x 48 x 8 | SILVIA / GAZELLE S12 CA18S,CA18ET | 83/8~88/ | Engine CAM SHAFT |
| 03903 4053 | 13510-53J00 | 46 x 58 x 7 | SILVIA / GAZELLE S12,S13,S14,S15 SR20# | 91/1~00/4 | Engine CRANK SHAFT FRONT |
| 03903 5475 | 13042-16V00 | 40 x 52 x 7 | SILVIA / GAZELLE S12,S13 CA18D,CA18DT | 86/2~91/1 | Engine CRANK SHAFT FRONT |
| 03903 5127 | 13510-16A00 | 33 x 47 x 8 | SILVIA / GAZELLE S12 CA18S,CA18ET | 83/8~88/ | Engine CRANK SHAFT FRONT |
| 03903 5887 | 13042-A8601 | 48 x 70 x 9 | SILVIA / GAZELLE S10,S11,S110 L18#,Z18#,Z20# | 75/10~83/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5573 | 13042-16V00 | 40 x 52 x 7 | SILVIA / GAZELLE S12 CA18DET | 86/2~88/ | Engine CAM SHAFT |
| 03903 1733 | 12279-R4611 | 80 x 100 x 13 | SILVIA / GAZELLE S10,S11,S110 L18#,Z18#,Z20# | 75/10~83/ | Engine CRANK SHAFT REAR |
| 03903 2173 | 49365-10V26 | | SILVIA / GAZELLE S13,S14,S15 | 88/5~ | Steering (P/S) PINION GEAR KIT |
| 03903 3211 | 13207-D4200 | | SILVIA / GAZELLE S14,S15 SR20DE(ALL) | 93/10~ | Engine VALVE STEM SEAL |
| 03903 4675 | 49297-4M485 | | SILVIA / GAZELLE S15 .4WS | 99/8~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4493 | 49297-65F25 | | SILVIA / GAZELLE S15 .4WS | 99/1~99/8 | Steering (P/S) GEAR HOUSING KIT |
| 03903 2245 | 49297-4M427 | | SILVIA / GAZELLE S15 2WS | 00/9~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4999 | 49297-6M026 | | SILVIA / GAZELLE S15 2WS | 99/1~00/9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 6425 | 13042-16V00 | 40 x 52 x 7 | SILVIA / GAZELLE S13 CA18D# | 88/5~91/1 | Engine CAM SHAFT |
| 03903 4269 | 38342-N3100 | 35 x 55 x 11 x 18 | SILVIA / GAZELLE S14 2WS (ABS OR NSD OR AERO SPORTS) | 93/10~99/ | Final Drive DIFF. SIDE |
| 03903 1671 | 13207-21002 | | SILVIA / GAZELLE S10,S11 L18#,Z18#,Z20# | 75/10~79/ | Engine VALVE STEM SEAL |
| 03903 2827 | 13207-D0101 | | SILVIA / GAZELLE S12,S13 CA18S,CA18ET | 83/8~88/4 | Engine VALVE STEM SEAL |
| 03903 2489 | 12279-AD205 | 84 x 104 x 8.5 | SILVIA / GAZELLE S14,S15 SR20D# | 97/9~ | Engine CRANK SHAFT REAR |
| 03903 1551 | 13207-D0101 | | SILVIA / GAZELLE S13,S14,S15 SR20D,SR20DT,SR20DET(EX.) | 91/1~ | Engine VALVE STEM SEAL |
| 03903 2031 | 12279-85Y00 | 84 x 104 x 11 | SILVIA / GAZELLE S14 SR20D# | 93/10~97/9 | Engine CRANK SHAFT REAR |
| 03903 1005 | 13510-2J200 | 46 x 58 x 7 | SILVIA / GAZELLE S15 SR20D# | 00/4~ | Engine CRANK SHAFT FRONT |
| 03903 3307 | 13207-D4200 | | SILVIA / GAZELLE S13 CA18D#(ALL) | 88/5~91/1 | Engine VALVE STEM SEAL |
| 03903 2027 | 13510-R2000 | 42 x 55 x 9 | SILVIA / GAZELLE S110,S12 FJ20# | 82/4~86/2 | Engine CRANK SHAFT FRONT |
| 03903 6057 | 13207-D4200 | | SILVIA / GAZELLE S13,S14,S15 SR20D,SR20DT,SR20DET(IN.) | 91/1~ | Engine VALVE STEM SEAL |
| 03903 1231 | 49297-65F25 | | SILVIA / GAZELLE S14 | 93/10~99/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1229 | 12279-85Y00 | 84 x 104 x 11 | SILVIA / GAZELLE S13 SR20# | 91/1~93/ | Engine CRANK SHAFT REAR |
| 03903 3839 | 12279-85Y00 | 84 x 104 x 11 | SILVIA / GAZELLE S13 CA18D# | 90/4~91/1 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2777 | 12279-D0100 | 84 x 104 x 11 | SILVIA / GAZELLE S12,S13 CA18S,CA18ET | 83/8~90/4 | Engine CRANK SHAFT REAR |
| 03903 6301 | 12279-01M00 | 80 x 100 x 10 | SILVIA / GAZELLE S110,S12 FJ20# | 82/4~86/2 | Engine CRANK SHAFT REAR |
| 03903 4191 | 13207-81W00 | | SILVIA / GAZELLE S110 Z18#,Z20E | 79/3~83/ | Engine VALVE STEM SEAL |
| 03903 4083 | 38189-20E10 | 35 x 67 x 12 x 19.5 | SILVIA / GAZELLE S14 2WS SR20DE(ABS) | 93/10~99/ | Final Drive PINION |
| 03903 5799 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S14 4WS ABS | 93/10~96/6 | Final Drive PINION |
| 03903 5561 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S14 2WS SR20DE(NSD)+(ABS) | 93/10~99/ | Final Drive PINION |
| 03903 2241 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S13 SR20D#(LSD)+(ANTI SKID) | 88/5~93/ | Final Drive PINION |
| 03903 1691 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S13 CA18D# EXCEPT ANTI SKID | 88/5~93/ | Final Drive PINION |
| 03903 5007 | 38189-P0101 | 45 x 75 x 12 | SILVIA / GAZELLE S12 CA18S HE38(AT) | 86/2~88/ | Final Drive PINION |
| 03903 5627 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S14 4WS ALL | 96/6~99/ | Final Drive PINION |
| 03903 6409 | 38189-P0101 | 45 x 75 x 12 | SILVIA / GAZELLE S110 Z18T,FJ20E | 79/3~83/ | Final Drive PINION |
| 03903 2905 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SILVIA / GAZELLE S13 SR20D(LSD) | 88/5~93/ | Final Drive PINION |
| 03903 6321 | 13207-01M00 | | SILVIA / GAZELLE S110,S12 FJ20# | 82/4~86/2 | Engine VALVE STEM SEAL |
| 03903 4799 | 38189-U3011 | 35 x 67 x 13.8 x 19.5 | SILVIA / GAZELLE S14 2WS SR20DE EXCEPT (ABS OR NSD OR AERO SPORTS) | 93/10~99/ | Final Drive PINION |
| 03903 2435 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SILVIA / GAZELLE S13 SR20DT EXCEPT LSD OR ANTI SKID | 88/5~93/ | Final Drive PINION |
| 03903 3275 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SILVIA / GAZELLE S14 2WS SR20DE(NSD)(AERO SPORTS) | 93/10~96/6 | Final Drive PINION |
| 03903 4123 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SILVIA / GAZELLE S14 2WS SR20DET EXCEPT ABS | 93/10~99/ | Final Drive PINION |
| 03903 3153 | 38342-N3100 | 35 x 55 x 11 x 18 | SILVIA / GAZELLE S15 ALL | 99/1~ | Final Drive DIFF. SIDE |
| 03903 5929 | 38342-N3100 | 35 x 55 x 11 x 18 | SILVIA / GAZELLE S13 CA18DT,SR20DT (ALL) | 88/5~93/ | Final Drive DIFF. SIDE |
| 03903 5943 | 48128-01E00 | 17 x 30 x 8 | SILVIA / GAZELLE S12 | 83/8~88/ | Steering GEAR |
| 03903 6039 | 48029-W0501 | 17.5 x 32 x 7 | SILVIA / GAZELLE S110 | 79/3~83/ | Steering WORM |
| 03903 5867 | 48029-04100 | 17 x 31 x 7 | SILVIA / GAZELLE S10,S11 | 75/10~79/ | Steering WORM |
| 03903 1365 | 48137-36700 | 26 x 40 x 7 | SILVIA / GAZELLE S110 Z18# | 79/3~83/ | Steering SECTOR SHAFT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1963 | 48137-16500 | 24 x 35 x 8 | SILVIA / GAZELLE S10,S11 | 75/10~79/ | Steering SECTOR SHAFT |
| 03903 3061 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SILVIA / GAZELLE S14 4WS EXCEPT ABS | 93/10~96/6 | Final Drive PINION |
| 03903 5117 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S14 2WS SR20DET(ABS) | 93/10~99/ | Final Drive PINION |
| 03903 5927 | 38189-21G00 | 40 x 75 x 12 x 19 | SILVIA / GAZELLE S13 CA18D#(ANTI SKID) | 88/5~93/ | Final Drive PINION |
| 03903 2865 | 38342-N3100 | 35 x 55 x 11 x 18 | SILVIA / GAZELLE S13 CA18D,SR20D (ABS OR LSD) | 88/5~93/ | Final Drive DIFF. SIDE |
| 03903 5215 | 38342-N3100 | 35 x 55 x 11 x 18 | SILVIA / GAZELLE S12 CA18DT,FJ20#(RC FINAL DRIVE) | 83/8~88/ | Final Drive DIFF. SIDE |
| 03903 5245 | 38342-21000 | 32 x 52 x 11 x 15.5 | SILVIA / GAZELLE S14 2WS SE20DE EXCEPT (ABS OR NSD OR AERO SPORTS) | 93/10~99/ | Final Drive DIFF. SIDE |
| 03903 2841 | 38342-21000 | 32 x 52 x 11 x 15.5 | SILVIA / GAZELLE S13 CA18D,SR20D EXCEPT (ABS) OR (LSD) | 88/5~93/ | Final Drive DIFF. SIDE |
| 03903 2353 | 38342-21000 | 32 x 52 x 11 x 15.5 | SILVIA / GAZELLE S12 CA18T | 83/8~88/ | Final Drive DIFF. SIDE |
| 03903 5501 | 49297-35F25 | | SILVIA / GAZELLE S13 2WD | 88/5~93/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 2239 | 38342-N3100 | 35 x 55 x 11 x 18 | SILVIA / GAZELLE S14 4WS ALL | 93/10~99/ | Final Drive DIFF. SIDE |
| 03903 3753 | 32113-89F00 | 30 x 42 x 7 | SILVIA / GAZELLE S15 6 SPEED | 99/1~ | Transmission (M/T) FRONT COVER |
| 03903 1921 | 38189-U3000 | 35 x 67 x 12 x 18 | SILVIA / GAZELLE S12 CA18T | 83/8~88/ | Final Drive PINION |
| 03903 1915 | 38189-N3100 | 40 x 75 x 12 x 17.5 | SILVIA / GAZELLE S12 CA18DT,FJ20# | 83/8~88/ | Final Drive PINION |
| 03903 2107 | 38189-A6100 | 35 x 64 x 13 | SILVIA / GAZELLE S12 CA18S HE37(AT) | 86/2~88/ | Final Drive PINION |
| 03903 5941 | 38189-A6100 | 35 x 64 x 13 | SILVIA / GAZELLE S12 CA18S(AT,ALL) | 83/8~86/2 | Final Drive PINION |
| 03903 3025 | 38189-A6100 | 35 x 64 x 13 | SILVIA / GAZELLE S12 CA18S(MT),CA18E(ALL) | 83/8~88/ | Final Drive PINION |
| 03903 3455 | 38189-A6100 | 35 x 64 x 13 | SILVIA / GAZELLE S110 Z18S.E,Z20E | 79/3~83/ | Final Drive PINION |
| 03903 2753 | 38189-A6100 | 35 x 64 x 13 | SILVIA / GAZELLE S10,S11 | 75/10~79/ | Final Drive PINION |
| 03903 4967 | 31375-51X03 | 46 x 63 x 7.7 x 8.5 | SILVIA / GAZELLE S14,S15 | 94/8~ | Transmission (M/T) FRONT OIL PUMP |
| 03903 2605 | 31344-21X00 | 46 x 63.15 x 7.5 | SILVIA / GAZELLE S13,S14 | 88/5~94/8 | Transmission (M/T) FRONT OIL PUMP |
| 03903 2327 | 31344-X0101 | 42 x 60 x 9 | SILVIA / GAZELLE S110,S12 | 79/3~88/ | Transmission (M/T) FRONT OIL PUMP |
| 03903 6147 | 32136-89F00 | 38 x 58 x 11 | SILVIA / GAZELLE S15 6 SPEED | 99/1~ | Transmission (M/T) REAR EXTENSION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5243 | 32136-U0100 | 35 x 50 x 11 | SILVIA / GAZELLE S15 5 SPEED | 99/1~ | Transmission (M/T) REAR EXTENSION |
| 03903 1701 | 38189-U3000 | 35 x 67 x 12 x 18 | SILVIA / GAZELLE S13 SR20D EXCEPT LSD OR ANTI SKID | 88/5~93/ | Final Drive PINION |
| 03903 3903 | 32136-U0100 | 35 x 50 x 11 | SILVIA / GAZELLE S12,S13,S14 | 83/8~99/ | Transmission (M/T) REAR EXTENSION |
| 03903 4917 | 40232-N7100 | 46 x 59.1 x 12 | SILVIA / GAZELLE S12 | 83/8~86/2 | Wheel Hub FRONT |
| 03903 5081 | 32114-Y4000 | 30 x 45 x 8 | SILVIA / GAZELLE S15 5 SPEED | 99/1~ | Transmission (M/T) FRONT COVER |
| 03903 1589 | 32114-Y4000 | 30 x 45 x 8 | SILVIA / GAZELLE S12,S13,S14 | 83/8~99/ | Transmission (M/T) FRONT COVER |
| 03903 1793 | 32114-Y4000 | 30 x 45 x 8 | SILVIA / GAZELLE S110 5 SPEED | 79/3~83/ | Transmission (M/T) FRONT COVER |
| 03903 1455 | 32113-N2101 | 34 x 50 x 7 | SILVIA / GAZELLE S110 4 SPEED | 79/3~83/ | Transmission (M/T) FRONT COVER |
| 03903 4555 | 32113-N2101 | 34 x 50 x 7 | SILVIA / GAZELLE S10,S11 | 75/10~79/ | Transmission (M/T) FRONT COVER |
| 03903 1439 | 43232-F6100 | 40 x 62 x 9 x 13 | SILVIA / GAZELLE S12 CA18ET,CA18DET | 86/2~88/ | Wheel Hub REAR |
| 03903 1823 | 43232-21000 | 40 x 62 x 10 | SILVIA / GAZELLE S12 CA18ET,FJ20# | 83/8~86/2 | Wheel Hub REAR |
| 03903 5651 | 43252-H1000 | 41 x 56 x 7 | SILVIA / GAZELLE S12 CA18S,CA18E | 83/8~88/ | Wheel Hub REAR |
| 03903 2195 | 43252-H1000 | 41 x 56 x 7 | SILVIA / GAZELLE S10,S11,S110 | 75/10~83/ | Wheel Hub REAR |
| 03903 2487 | 40232-30F00 | 46 x 69.6 x 10 x 14.8 | SILVIA / GAZELLE S12 | 86/2~88/ | Wheel Hub FRONT |
| 03903 5497 | 40232-A0101 | 48 x 62 x 6 | SILVIA / GAZELLE S10,S11,S110 | 75/10~83/ | Wheel Hub FRONT |
| 03903 1163 | 38189-Y0810 | 40 x 75 x 12 | SILVIA / GAZELLE S15 ALL | 99/1~ | Final Drive PINION |
| 03903 4667 | 32136-U0100 | 35 x 50 x 11 | SILVIA / GAZELLE S110 | 79/3~83/ | Transmission (M/T) REAR EXTENSION |
| 03903 1849 | 13042-D0100 | 34 x 48 x 8 | SKYLINE R30,R31,R32 CA18# | 82/10~93/ | Engine CAM SHAFT |
| 03903 2529 | 12279-R4611 | 80 x 100 x 13 | SKYLINE R30 Z18S,Z20E,L20#,LD20,LD28 | 81/8~89/ | Engine CRANK SHAFT FRONT |
| 03903 5233 | 13510-R2000 | 42 x 55 x 9 | SKYLINE R30 FJ20# | 81/10~85/ | Engine CRANK SHAFT FRONT |
| 03903 4205 | 13510-31U00 | 48 x 60 x 7 | SKYLINE V35 VQ25DD,VQ30DD,VQ35DE | 01/6~ | Engine CRANK SHAFT FRONT |
| 03903 3089 | 13042-16V00 | 40 x 52 x 7 | SKYLINE R34 RB25D#,RB26DETT | 98/5~ | Engine CRANK SHAFT FRONT |
| 03903 1741 | 13042-16V00 | 40 x 52 x 7 | SKYLINE R33 RB20#,RB25D#,RB26DETT | 93/8~99/ | Engine CRANK SHAFT FRONT |
| 03903 6457 | 13042-16V00 | 40 x 52 x 7 | SKYLINE R32 RB20#,RB25DE,RB26D# | 89/5~94/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3613 | 13042-16V00 | 40 x 52 x 7 | SKYLINE R31 RB20#,RD28 | 85/8~90/ | Engine CRANK SHAFT FRONT |
| 03903 4309 | 13510-16A00 | 33 x 47 x 8 | SKYLINE R30,R31,R32 CA18# | 85/8~89/ | Engine CRANK SHAFT FRONT |
| 03903 5969 | 13042-A8601 | 48 x 70 x 9 | SKYLINE R30 Z18S,Z20E,L20#,LD20,LD28 | 81/8~89/ | Engine CRANK SHAFT FRONT |
| 03903 5359 | 38189-P0101 | 45 x 75 x 12 | SKYLINE R30 HE FINAL DRIVE | 81/8~85/ | Final Drive PINION |
| 03903 5015 | 13042-D0100 | 34 x 48 x 8 | SKYLINE R31 RD28 | 85/8~89/ | Engine CAM SHAFT |
| 03903 4399 | 12279-T7202 | 80 x 100 x 10 | SKYLINE R32 RB20# | 89/5~90/1 | Engine CRANK SHAFT FRONT |
| 03903 4125 | 48125-51S00 | 17 x 30 x 8 x 10.5 | SKYLINE R31 | 85/8~90/ | Steering GEAR |
| 03903 6289 | 48029-W0501 | 17.5 x 32 x 7 | SKYLINE R30 | 81/8~85/ | Steering WORM |
| 03903 4879 | 48040-82100 | 35 x 48 x 8 | SKYLINE R30 | 81/8~85/ | Steering SECTOR SHAFT |
| 03903 6347 | 38342-15U00 | 34.5 x 53.5 x 8 | SKYLINE R34 RB26DETT(V-SPEC&V-SPECII) | 99/1~ | Final Drive DIFF. SIDE |
| 03903 1305 | 38342-15U00 | 34.5 x 53.5 x 8 | SKYLINE R33 RB25DET(LSD),RB26DETT (V-SPEC&N1) | 93/8~99/ | Final Drive DIFF. SIDE |
| 03903 4677 | 38342-N3100 | 35 x 55 x 11 x 18 | SKYLINE V35 | 01/6~ | Final Drive DIFF. SIDE |
| 03903 3427 | 38342-N3100 | 35 x 55 x 11 x 18 | SKYLINE R34 RB20DE,RB25DE,RB26DETT(EXCEPT V-SPEC&V-SPECII) | 99/10~ | Final Drive DIFF. SIDE |
| 03903 3273 | 38342-N3100 | 35 x 55 x 11 x 18 | SKYLINE R34 RB20DE,RB25DE,RB26DETT(EXCEPT V-SPEC&V-SPECII) | 99/1~99/10 | Final Drive DIFF. SIDE |
| 03903 2051 | 38342-N3100 | 35 x 55 x 11 x 18 | SKYLINE R32 RB20D#,RB25DE,RB26D# | 89/5~94/ | Final Drive DIFF. SIDE |
| 03903 1341 | 13042-16V00 | 40 x 52 x 7 | SKYLINE R31,R32,R33,R34 RB20#,RB25D#,RB26D# | 85/8~ | Engine CAM SHAFT |
| 03903 2655 | 13207-D0101 | | SKYLINE R30 CA18# | 81/8~85/ | Engine VALVE STEM SEAL |
| 03903 4813 | 32114-Y4000 | 30 x 45 x 8 | SKYLINE R30 EXCEPT F4W63L T/M | 81/8~83/8 | Transmission (M/T) FRONT COVER |
| 03903 5365 | 32114-Y4000 | 30 x 45 x 8 | SKYLINE R30 ALL | 83/8~85/ | Transmission (M/T) FRONT COVER |
| 03903 3761 | 13207-42L00 | | SKYLINE R31,R32 RB20E,RB20T(EX.) | 85/8~93/ | Engine VALVE STEM SEAL |
| 03903 6193 | 13207-D4200 | | SKYLINE V35 VQ25DD,VQ30DD,VQ35DE | 01/6~ | Engine VALVE STEM SEAL |
| 03903 3513 | 13207-D4200 | | SKYLINE R34 RB20D#,RB25D#(EX.) | 98/5~ | Engine VALVE STEM SEAL |
| 03903 2681 | 13207-D4200 | | SKYLINE R32,R33,R34 RB26D#(IN.) | 89/5~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1653 | 13207-D4200 | | SKYLINE R31,R32,R33 RB20D#,RB25D# | 85/8~98/ | Engine VALVE STEM SEAL |
| 03903 3633 | 13207-81W00 | | SKYLINE R30 Z18S,Z20E,L20#,LD20,LD28 | 81/8~85/ | Engine VALVE STEM SEAL |
| 03903 6215 | 13207-D0101 | | SKYLINE R32,R33,R34 RB26D#(EX.) | 89/5~ | Engine VALVE STEM SEAL |
| 03903 2915 | 12279-01M00 | 80 x 100 x 10 | SKYLINE R30 FJ20# | 81/10~85/ | Engine CRANK SHAFT FRONT |
| 03903 1529 | 13207-D0101 | | SKYLINE R31 CA18S,RD28 | 85/8~89/ | Engine VALVE STEM SEAL |
| 03903 3209 | 12279-01M00 | 80 x 100 x 10 | SKYLINE R31 RB20#,RD28 | 85/8~90/ | Engine CRANK SHAFT FRONT |
| 03903 2121 | 13207-01M01 | | SKYLINE R30 FJ20# | 81/8~85/ | Engine VALVE STEM SEAL |
| 03903 6067 | 12296-31U20 | RETAINER ID 97 (F) | SKYLINE V35 VQ25DD,VQ30DD,VQ35DE | 01/6~ | Engine CRANK SHAFT FRONT |
| 03903 5517 | 12279-AD205 | 84 x 104 x 8.5 | SKYLINE R34 RBRB25D#,RB26DETT | 98/5~ | Engine CRANK SHAFT FRONT |
| 03903 6223 | 12279-AD205 | 84 x 104 x 8.5 | SKYLINE R33 RB25D#,RB26DETT | 97/6~99/ | Engine CRANK SHAFT FRONT |
| 03903 5173 | 12279-58S00 | 80 x 100 x 10 | SKYLINE R33 RB25D#,RB26DETT | 93/8~97/6 | Engine CRANK SHAFT FRONT |
| 03903 2463 | 12279-58S00 | 80 x 100 x 10 | SKYLINE R32 RB20#,RB25DE,RB26D# | 90/1~94/ | Engine CRANK SHAFT FRONT |
| 03903 3855 | 12279-85Y00 | 84 x 104 x 11 | SKYLINE R32 CA18# | 90/4~93/ | Engine CRANK SHAFT FRONT |
| 03903 4839 | 12279-D0100 | 84 x 104 x 11 | SKYLINE R32 CA18# | 89/5~90/4 | Engine CRANK SHAFT FRONT |
| 03903 6137 | 12279-D0100 | 84 x 104 x 11 | SKYLINE R30,R31 CA18# | 82/10~90/4 | Engine CRANK SHAFT FRONT |
| 03903 4417 | 38342-N3100 | 35 x 55 x 11 x 18 | SKYLINE R30,R31 RC FINAL DRIVE | 81/8~89/ | Final Drive DIFF. SIDE |
| 03903 5459 | 13207-D0101 | | SKYLINE R31,R32 RB20E,RB20T(IN.) | 85/8~93/ | Engine VALVE STEM SEAL |
| 03903 1881 | 38189-U3000 | 35 x 67 x 12 x 18 | SKYLINE R32 CA18I,RB20E | 89/5~93/ | Final Drive PINION |
| 03903 6463 | 40232-33P00 | 56 x 76 x 6 x 11 | SKYLINE R32 2WD | 89/5~93/ | Wheel Hub FRONT |
| 03903 1979 | 40232-41L00 | 46 x 69.4 x 11 x 16 | SKYLINE R31 | 85/8~90/ | Wheel Hub FRONT |
| 03903 3345 | 32114-Y4000 | 30 x 45 x 8 | SKYLINE R31,R32,R33 | 85/8~99/ | Transmission (M/T) FRONT COVER |
| 03903 5385 | 38342-N3100 | 35 x 55 x 11 x 18 | SKYLINE R33 RB25DET(EXCEPT LSD),RB26DETT(EXCEPT V-SPEC&N1) | 93/8~99/ | Final Drive DIFF. SIDE |
| 03903 3799 | 32136-AA402 | 35 x 52 x 7 | SKYLINE R34 RB26DETT | 99/1~ | Transmission (M/T) FRONT COVER |
| 03903 4311 | 32136-U0100 | 35 x 50 x 11 | SKYLINE R30,R31,R32 | 81/8~93/ | Transmission (M/T) REAR EXTENSION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1609 | 32136-U0100 | 35 x 50 x 11 | SKYLINE R33,R34 RB20E,RB25DE | 93/8~ | Transmission (M/T) REAR EXTENSION |
| 03903 6563 | 32136-01G10 | 42 x 58 x 9.5 | SKYLINE R33,R34 RB25DET | 93/8~ | Transmission (M/T) REAR EXTENSION |
| 03903 3279 | 38189-A6100 | 35 x 64 x 13 | SKYLINE R30 HC FINAL DRIVE | 81/8~85/ | Final Drive PINION |
| 03903 6229 | 38189-N3100 | 40 x 75 x 12 x 17.5 | SKYLINE R30,R31 RC FINAL DRIVE | 81/8~89/ | Final Drive PINION |
| 03903 4671 | 38189-N3100 | 40 x 75 x 12 x 17.5 | SKYLINE R31 CA FINAL DRIVE | 85/8~90/ | Final Drive PINION |
| 03903 3989 | 40232-33P00 | 56 x 76 x 6 x 11 | SKYLINE R33 2WD | 93/8~98/ | Wheel Hub FRONT |
| 03903 3137 | 38342-21000 | 32 x 52 x 11 x 15.5 | SKYLINE R33 RB20E | 93/8~99/ | Final Drive DIFF. SIDE |
| 03903 5195 | 40232-N7100 | 46 x 59.1 x 12 | SKYLINE R30 | 81/8~85/ | Wheel Hub FRONT |
| 03903 1799 | 38342-21000 | 32 x 52 x 11 x 15.5 | SKYLINE R32 CA18I,RB20E | 89/5~93/ | Final Drive DIFF. SIDE |
| 03903 2013 | 38342-21000 | 32 x 52 x 11 x 15.5 | SKYLINE R30 RB FINAL DRIVE | 81/8~85/ | Final Drive DIFF. SIDE |
| 03903 1061 | 38189-21G00 | 40 x 75 x 12 x 19 | SKYLINE R32 RB20D#,RB26D#(NSD) | 89/5~91/7 | Final Drive PINION |
| 03903 1727 | 38189-P0117 | 45 x 75 x 14 x 19.5 | SKYLINE V35 | 01/6~ | Final Drive PINION |
| 03903 5279 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SKYLINE R34 RB25D#,RB26DETT(4WD) | 98/5~ | Final Drive PINION |
| 03903 5585 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SKYLINE R33 RB25D# | 93/8~98/ | Final Drive PINION |
| 03903 5201 | 38189-N3112 | 40 x 75 x 13.5 x 21 | SKYLINE R32 RB20D#,RB25DE,RB26D# | 91/7~94/ | Final Drive PINION |
| 03903 2335 | 38189-U3011 | 35 x 67 x 13.8 x 19.5 | SKYLINE R33 RB20(EXCEPT NSD) | 93/8~98/ | Final Drive PINION |
| 03903 2879 | 38189-Y0810 | 40 x 75 x 12 | SKYLINE R34 RB20DE,RB25DE(2WD) | 98/5~ | Final Drive PINION |
| 03903 6021 | 38189-Y0810 | 40 x 75 x 12 | SKYLINE R31,R32,R33 ANTI SKID | 85/8~99/ | Final Drive PINION |
| 03903 5807 | 38189-P0101 | 45 x 75 x 12 | SKYLINE R31 HE,HF FINAL DRIVE | 85/8~90/ | Final Drive PINION |
| 03903 4703 | 38189-U3000 | 35 x 67 x 12 x 18 | SKYLINE R30 RB FINAL DRIVE | 81/8~85/ | Final Drive PINION |
| 03903 6249 | 43252-40P00 | 64 x 77 x 8 | SKYLINE R32,R33,R34 RB26D# | 89/5~ | Wheel Hub REAR |
| 03903 3327 | 32114-Y4000 | 30 x 45 x 8 | SKYLINE R34 EXCEPT RB26DETT | 98/5~ | Transmission (M/T) FRONT COVER |
| 03903 4013 | 40232-33P00 | 56 x 76 x 6 x 11 | SKYLINE R34 2WD | 98/5~ | Wheel Hub FRONT |
| 03903 2679 | 13207-5L300 | | SKYLINE R34 RB20D#,RB25D#(IN.) | 98/5~ | Engine VALVE STEM SEAL |
| 03903 3331 | 43252-30P00 | 58 x 77 x 8 | SKYLINE R34 RB25D#(HICAS) | 98/5~ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1975 | 43252-30P00 | 58 x 77 x 8 | SKYLINE R32 RB20DT,RB20DET(COLD DISTRICT) | 89/5~93/ | Wheel Hub REAR |
| 03903 2789 | 43232-F6100 | 40 x 62 x 9 x 13 | SKYLINE R31 RB20#,RD28(SEDAN,HARD TOP) | 85/8~89/ | Wheel Hub REAR |
| 03903 5995 | 40232-33P00 | 56 x 76 x 6 x 11 | SKYLINE R33 4WD | 93/8~99/ | Wheel Hub FRONT IN. & OUT. |
| 03903 5803 | 43252-H1000 | 41 x 56 x 7 | SKYLINE R31 CA18S,RB20ET(WAGON) | 85/8~90/ | Wheel Hub REAR |
| 03903 3015 | 43252-H1000 | 41 x 56 x 7 | SKYLINE R30 Z18S,Z20E,LD20,CA18# | 81/8~85/ | Wheel Hub REAR |
| 03903 5771 | 40232-33P00 | 56 x 76 x 6 x 11 | SKYLINE R34 4WD | 98/5~ | Wheel Hub FRONT IN. & OUT. |
| 03903 5267 | 43232-21000 | 40 x 62 x 10 | SKYLINE R30 L20#,FJ20#,LD28 | 81/8~85/ | Wheel Hub REAR |
| 03903 6385 | 40232-33P00 | 56 x 76 x 6 x 11 | SKYLINE R32 4WD | 89/5~94/ | Wheel Hub FRONT IN. & OUT. |
| 03903 5879 | 32113-N2101 | 34 x 50 x 7 | SKYLINE R30 F4W63L T/M | 81/8~83/8 | Transmission (M/T) FRONT COVER |
| 03903 1751 | 13042-16V00 | 40 x 52 x 7 | STAGEA WC34 RB20#,RB25#,RB26DETT | 96/9~01/ | Engine CRANK SHAFT FRONT |
| 03903 1463 | 13207-D0101 | | STAGEA WC34 RB26DETT(EX.) | 97/11~01/ | Engine VALVE STEM SEAL |
| 03903 6295 | 13042-16V00 | 40 x 52 x 7 | STAGEA WC34 RB20#,RB25#,RB26DETT | 96/9~01/ | Engine CAM SHAFT |
| 03903 5219 | 38342-N3100 | 35 x 55 x 11 x 18 | STAGEA WC34,M35 | 96/9~ | Final Drive DIFF.SIDE |
| 03903 2503 | 38189-P0117 | 45 x 75 x 14 x 19.5 | STAGEA M35 VQ30DD,VQ35DE | 03/3~ | Final Drive PINION |
| 03903 4637 | 38189-N3112 | 40 x 75 x 13.5 x 21 | STAGEA M35 VQ30DD | 01/10~03/3 | Final Drive PINION |
| 03903 6355 | 38189-N3112 | 40 x 75 x 13.5 x 21 | STAGEA M35 VQ35DET(HICAS) | 01/10~03/5 | Final Drive PINION |
| 03903 3049 | 13207-D0101 | | STAGEA WC34 RB20E(IN.) | 96/9~97/8 | Engine VALVE STEM SEAL |
| 03903 6231 | 38189-N3112 | 40 x 75 x 13.5 x 21 | STAGEA M35 VQ35DET(EXCEPT HICAS) | 01/10~ | Final Drive PINION |
| 03903 5147 | 13207-D4200 | | STAGEA WC34 RB25DET(IN.) | 96/9~98/8 | Engine VALVE STEM SEAL |
| 03903 5545 | 38189-P0117 | 45 x 75 x 14 x 19.5 | STAGEA M35 VQ35DET(HICAS) | 03/5~ | Final Drive PINION |
| 03903 4683 | 12296-31U20 | | STAGEA M35 VQ25D#,VQ30DD,VQ35DE | 01/10~ | Engine CRANK SHAFT REAR |
| 03903 1367 | 12279-AD205 | 84 x 104 x 8.5 | STAGEA WC34 RB20#,RB25#,RB26DETT | 97/6~01/ | Engine CRANK SHAFT REAR |
| 03903 1579 | 12279-85Y00 | 84 x 104 x 11 | STAGEA WC34 RB20#,RB25# | 96/9~97/6 | Engine CRANK SHAFT REAR |
| 03903 3167 | 13510-31U00 | 48 x 60 x 7 | STAGEA M35 VQ25D#,VQ30DD,VQ35DE | 01/10~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3835 | 13207-D4200 | | STAGEA WC34 RB20DE,RB25DE#(EX.) | 96/9~01/ | Engine VALVE STEM SEAL |
| 03903 4597 | 13207-5L300 | | STAGEA WC34 RB20DE,RB25DE#(IN.) | 97/8~01/ | Engine VALVE STEM SEAL |
| 03903 2759 | 13207-D4200 | | STAGEA WC34 RB26DETT(IN.) | 97/11~01/ | Engine VALVE STEM SEAL |
| 03903 4135 | 13207-D4200 | | STAGEA M35 VQ25D#,VQ30DD,VQ35DE | 01/10~ | Engine VALVE STEM SEAL |
| 03903 5213 | 38189-N3112 | 40 x 75 x 13.5 x 21 | STAGEA M35 VQ25DD(ALL) | 01/10~ | Final Drive PINION |
| 03903 4061 | 13207-81W00 | | STAGEA WC34 RB20E(EX.) | 96/9~97/8 | Engine VALVE STEM SEAL |
| 03903 2197 | 13207-D4200 | | STAGEA WC34 RB25DE(IN.) | 96/9~97/8 | Engine VALVE STEM SEAL |
| 03903 4391 | 40227-50W01 | 50 x 72 x 83 x 16.2 | STAGEA WC34 4WD | 96/9~01/ | Wheel Hub FRONT GREASE SEAL |
| 03903 4833 | 40232-33P00 | 56 x 76 x 6 x 11 | STAGEA WC34 4WD | 96/9~01/ | Wheel Hub FRONT OUTER |
| 03903 6003 | 40232-33P00 | 56 x 76 x 6 x 11 | STAGEA WC34 4WD | 96/9~01/ | Wheel Hub FRONT INNER |
| 03903 1087 | 43252-40P00 | 64 x 77 x 8 | STAGEA WC34 RB25DET(MT) | 96/9~01/ | Wheel Hub REAR |
| 03903 2637 | 32114-Y4000 | 30 x 45 x 8 | STAGEA WC34 RB25DET,RB26DETT(4WD ) | 98/8~01/ | Transmission (M/T) FRONT COVER |
| 03903 2921 | 32113-CD000 | 30 x 45 x 7 | STAGEA M35 VQ35DE | 03/6~ | Transmission (M/T) FRONT COVER |
| 03903 4115 | 32136-CD000 | 43.5 x 60 x 8 | STAGEA M35 VQ35DE | 03/6~ | Transmission (M/T) REAR EXTENSION |
| 03903 5437 | 38189-Y0810 | 40 x 75 x 12 | STAGEA WC34 RB20#,RB25DE(2WD) | 96/9~01/ | Final Drive PINION |
| 03903 1345 | 38189-N3112 | 40 x 75 x 13.5 x 21 | STAGEA WC34 RB25DE(4WD) | 96/9~01/ | Final Drive PINION |
| 03903 4059 | 38189-N3112 | 40 x 75 x 13.5 x 21 | STAGEA WC34 RB25DET,RB26DETT(ALL) | 96/9~01/ | Final Drive PINION |
| 03903 2167 | 32113-M8000 | 25 x 40 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2331 | 38342-M8001 | 40 x 56 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4221 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | STANZA (FWD) / AUSTER T12 CA18# | 85/10~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 6373 | 38342-M8001 | 40 x 56 x 8 | STANZA (FWD) / AUSTER T12 CA16S | 85/10~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 5469 | 38342-M8001 | 40 x 56 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Mission & Differential (A/T) MISSION CASE |
| 03903 2111 | 38342-03E01 | 33 x 59 x 11 x 17 | STANZA (FWD) / AUSTER T12 CA18T,CA18D,CA18DT | 85/10~90/ | Mission & Differential (M/T) CLUTCH HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4111 | 38342-D2100 | 40 x 56 x 65 x 20 | STANZA (FWD) / AUSTER T12 CA16S,CA18I | 85/10~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2959 | 38342-03E00 | 39 x 59 x 11 x 17 | STANZA (FWD) / AUSTER T12 CA18T,CA18D,CA18DT | 85/10~90/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3311 | 38342-D2100 | 40 x 56 x 65 x 20 | STANZA (FWD) / AUSTER T12 CA16S,CA18I | 85/10~90/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6111 | 38342-M8001 | 40 x 56 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Mission & Differential (M/T) MISSION CASE |
| 03903 2729 | 38342-M8001 | 40 x 56 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1009 | 32113-M8000 | 25 x 40 x 8 | STANZA (FWD) / AUSTER T12 CA16S,CA18I | 85/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 3013 | 43252-03E01 | 43 x 54 x 6 | STANZA (FWD) / AUSTER T12 | 85/10~90/ | Wheel Hub REAR |
| 03903 4371 | 43252-M7001 | 43 x 54 x 7.5 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Wheel Hub REAR |
| 03903 3185 | 32113-03E00 | 27.9 x 43 x 8 | STANZA (FWD) / AUSTER T12 CA18T,CA18D,CA18DT | 85/10~90/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2407 | 13510-16A00 | 33 x 47 x 8 | STANZA (FWD) / AUSTER T11 CA16S,CA18# | 81/6~85/ | Engine CRANK SHAFT FRONT |
| 03903 3125 | 13207-D4200 | | STANZA (FWD) / AUSTER T12 CA18D,CA18DT | 85/10~90/ | Engine VALVE STEM SEAL |
| 03903 1773 | 13207-D0101 | | STANZA (FWD) / AUSTER T12 CA16S,CA18I,CA18T | 85/10~90/ | Engine VALVE STEM SEAL |
| 03903 2747 | 13207-D0101 | | STANZA (FWD) / AUSTER T11 CA16S,CA18S,CA18E | 81/6~90/ | Engine VALVE STEM SEAL |
| 03903 5269 | 12279-D0100 | 84 x 104 x 11 | STANZA (FWD) / AUSTER T12 CA16S,CA18# | 85/10~90/ | Engine CRANK SHAFT REAR |
| 03903 3149 | 12279-D0100 | 84 x 104 x 11 | STANZA (FWD) / AUSTER T11 CA16S,CA18# | 81/6~85/ | Engine CRANK SHAFT REAR |
| 03903 2217 | 49365-V0227 | | STANZA (FWD) / AUSTER T12 | 85/10~90/ | Steering (P/S) PINION GEAR SEAL KIT |
| 03903 1415 | 13510-16A00 | 33 x 47 x 8 | STANZA (FWD) / AUSTER T12 CA16S,CA18I,CA18T | 85/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 3625 | 38342-M8001 | 40 x 56 x 8 | STANZA (FWD) / AUSTER T12 CA16S | 85/10~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6247 | 13042-16V00 | 40 x 52 x 7 | STANZA (FWD) / AUSTER T12 CA18D,CA18DT | 85/10~90/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2877 | 13042-D0100 | 34 x 48 x 8 | STANZA (FWD) / AUSTER T12 CA16S,CA18I,CA18T | 85/10~90/ | Engine CAM SHAFT |
| 03903 3817 | 38342-03E01 | 33 x 59 x 11 x 17 | STANZA (FWD) / AUSTER T12 CA18# | 85/10~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1651 | 13042-D0100 | 34 x 48 x 8 | STANZA (FWD) / AUSTER T11 CA16S,CA18# | 81/6~85/ | Engine CAM SHAFT |
| 03903 6115 | 40227-01E01 | 56 x 72 x 10 | STANZA (FWD) / AUSTER T12 | 85/10~88/ 1 | Wheel Hub DUST SEAL |
| 03903 4337 | 48125-78500 | 17 x 35 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Steering GEAR |
| 03903 5473 | 13042-16V00 | 40 x 52 x 7 | STANZA (FWD) / AUSTER T12 CA18D,CA18DT | 85/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 5427 | 40232-51E10 | 56 x 72 x 8 x 11.5 | STANZA (FWD) / AUSTER T12 | 85/10~90/ | Wheel Hub FRONT GREASE SEAL |
| 03903 6475 | 40232-D0101 | 52 x 70 x 8 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Wheel Hub FRONT GREASE SEAL |
| 03903 1913 | 40227-D0101 | 56 x 72 x 12.5 | STANZA (FWD) / AUSTER T11 | 81/6~85/ | Wheel Hub DUST SEAL |
| 03903 1655 | 48125-01E00 | 17 x 30 x 8 | STANZA (FWD) / AUSTER T12 | 85/10~90/ | Steering GEAR |
| 03903 6185 | 32113-N2101 | 34 x 50 x 7 | STANZA (RWD) A10,A11 FS5W63A,F4W63L T/M | 77/5~81/ | Transmission FRONT |
| 03903 3299 | 40232-21000 | 42 x 55 x 8 | STANZA (RWD) A10,A11 DISC BRAKE | 77/5~81/ | Wheel Hub FRONT |
| 03903 1079 | 43252-H1000 | 41 x 56 x 7 | STANZA (RWD) A10,A11 | 77/5~81/ | Wheel Hub REAR |
| 03903 3367 | 32114-Y4000 | 30 x 45 x 8 | STANZA (RWD) A10,A11 FS5W63A,F4W63L T/M | 77/5~81/ | Transmission FRONT |
| 03903 5709 | 32136-U0100 | 35 x 50 x 11 | STANZA (RWD) A10,A11 FS5W63A,F4W63 T/M | 77/5~81/ | Transmission REAR |
| 03903 1809 | 32136-H5000 | 30 x 45 x 77 x 45 | STANZA (RWD) A10,A11 FS5W63A,F4W63L T/M | 77/5~81/ | Transmission REAR |
| 03903 4119 | 38189-A6100 | 35 x 64 x 13 | STANZA (RWD) A10,A11 | 77/5~81/ | Final Drive PINION |
| 03903 5775 | 48029-04100 | 17 x 31 x 7 | STANZA (RWD) A10,A11 | 77/5~79/6 | Steering WORM |
| 03903 3477 | 48029-W0501 | 17.5 x 32 x 7 | STANZA (RWD) A11 | 79/7~81/ | Steering WORM |
| 03903 5897 | 13510-H1010 | 38 x 55 x 9 | STANZA (RWD) A10,A11 A14S | 79/7~81/ | Engine CRANK SHAFT FRONT |
| 03903 2573 | 13042-A8601 | 48 x 70 x 9 | STANZA (RWD) A10,A11 L16,Z16,Z18 | 79/7~81/ | Engine CRANK SHAFT FRONT |
| 03903 2367 | 12279-H2311 | 60 x 82 x 12 | STANZA (RWD) A10,A11 A14S | 79/7~81/ | Engine CRANK SHAFT REAR |
| 03903 3033 | 12279-R4611 | 80 x 100 x 13 | STANZA (RWD) A10,A11 L16,Z16,Z18 | 79/7~81/ | Engine CRANK SHAFT REAR |
| 03903 5327 | 13207-21002 | | STANZA (RWD) A10,A11 L16,Z16,Z18 | 79/7~81/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1063 | 48137-36700 | 26 x 40 x 7 | STANZA (RWD) A10,A11 | 77/5~81/ | Steering SECTOR SHAFT |
| 03903 4571 | 40232-N7100 | 46 x 59.1 x 12 | STANZA (RWD) A10,A11 DRUM BRAKE | 77/5~81/ | Wheel Hub FRONT |
| 03903 1813 | 13207-H7200 | | STANZA (RWD) A10,A11 A14S | 79/7~81/ | Engine VALVE STEM SEAL |
| 03903 2913 | 40232-M0215 | 48 x 62 x 7 | SUNNY (FWD) B11 E13S | 81/10~85/ | Wheel Hub FRONT GREASE SEAL |
| 03903 6405 | 43252-M7001 | 43 x 54 x 7.5 | SUNNY (FWD) B11 EXCEPT E15ET | 81/10~85/ | Wheel Hub REAR |
| 03903 5313 | 40227-50Y01 | 56 x 74.2 x 10.3 | SUNNY (FWD) B14 | 94/1~98/ | Wheel Hub FRONT DUST SEAL |
| 03903 2857 | 40227-50Y01 | 56 x 74.2 x 10.3 | SUNNY (FWD) B13 | 90/1~94/ | Wheel Hub FRONT DUST SEAL |
| 03903 3643 | 39252-52A00 | 52 x 78.4 x 9.5 | SUNNY (FWD) B12 | 85/9~90/ | Wheel Hub FRONT DUST SEAL |
| 03903 5623 | 40227-M5605 | 52 x 68 x 13 | SUNNY (FWD) B11 E15S,CD17 | 81/10~85/ | Wheel Hub FRONT DUST SEAL |
| 03903 3201 | 40227-M3005 | 48 x 62 x 13 | SUNNY (FWD) B11 E13S | 81/10~85/ | Wheel Hub FRONT DUST SEAL |
| 03903 3347 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | SUNNY (FWD) B14 | 94/1~98/ | Wheel Hub FRONT GREASE SEAL |
| 03903 6337 | 40232-M5661 | 52 x 67 x 7 | SUNNY (FWD) B11 E15S,CD17 | 81/10~85/ | Wheel Hub FRONT GREASE SEAL |
| 03903 6477 | 38342-D2100 | 40 x 56 x 65 x 20 | SUNNY (FWD) B13 GA15DS,CD17 (NSD,2WD).GA15DS,GA16 DE,CD17(4WD) | 90/1~94/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5547 | 43232-50A00 | 40 x 52 x 6 x 10 | SUNNY (FWD) B12 (2WD) REAR DRUM BRAKE | 85/9~90/ | Wheel Hub REAR |
| 03903 5175 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B11(ALL) | 81/10~85/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1109 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | SUNNY (FWD) B13 | 90/1~94/ | Wheel Hub FRONT GREASE SEAL |
| 03903 6351 | 32113-M8000 | 25 x 40 x 8 | SUNNY (FWD) B15 QG13DE,QG15DE | 98/10~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1265 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B15 QG13DE,QG15DE(2WD) | 98/10~ | Mission & Differential (M/T) MISSION CASE |
| 03903 3281 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B14 GA13DE,GA15DE EXCEPT(NSD,2WD) | 94/1~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5959 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B13 GA13DS,GA15DS EXCEPT(NSD),CD17 EXCEPT(NSD)... | 90/1~94/ | Mission & Differential (M/T) MISSION CASE |
| 03903 5605 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B12 E13S,E15S,E15E,CD17,GA1 5S,GA15E 2WD | 85/9~90/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3085 | 38342-D2100 | 40 x 56 x 65 x 20 | SUNNY (FWD) B13 GA15DS,CD17 (NSD,2WD) | 90/1~94/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3465 | 32113-03E00 | 27.9 x 43 x 8 | SUNNY (FWD) B14 CD20(4WD) | 94/1~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 5813 | 38342-D2100 | 40 x 56 x 65 x 20 | SUNNY (FWD) B14 GA15DE(NSD),CD20(2WD) ,GA15DE,GA16DE(4WD) | 94/1~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 6297 | 40232-51E10 | 56 x 72 x 8 x 11.5 | SUNNY (FWD) B12 4WD | 85/9~90/ | Wheel Hub REAR IN. & OUT. |
| 03903 5795 | 32113-M8000 | 25 x 40 x 8 | SUNNY (FWD) B14 EXCEPT CD20(4WD) | 94/1~98/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 1955 | 32113-M8000 | 25 x 40 x 8 | SUNNY (FWD) B11,B12,B13 | 81/10~94/ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2105 | 40227-50Y01 | 56 x 74.2 x 10.3 | SUNNY (FWD) B14 4WD | 94/1~98/ | Wheel Hub REAR OUTER |
| 03903 1173 | 40227-50Y01 | 56 x 74.2 x 10.3 | SUNNY (FWD) B13 4WD | 90/1~94/ | Wheel Hub REAR OUTER |
| 03903 5489 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | SUNNY (FWD) B14 4WD | 94/1~98/ | Wheel Hub REAR INNER |
| 03903 3783 | 40232-50Y00 | 55 x 68 x 8 x 11.5 | SUNNY (FWD) B13 4WD | 90/1~94/ | Wheel Hub REAR INNER |
| 03903 1627 | 32113-03E00 | 27.9 x 43 x 8 | SUNNY (FWD) B15 SR16VE,YD22DD | 98/10~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 4679 | 33111-56E00 | 60 x 78 x 9 | SUNNY (FWD) B14 CD20(4WD) | 94/1~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6201 | 38342-31X02 | 42 x 90 x 9.5 x 13 | SUNNY (FWD) B14 GA15DE,GA16DE(NSD),SR 18DE(ALL) | 94/1~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3507 | 33111-06R00 | 52 x 66 x 9 | SUNNY (FWD) B12 E15S,GA15#(4WD) | 87/9~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2853 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B12 RN3FO1A(2WD) | 85/9~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3301 | 38342-D2100 | 40 x 56 x 65 x 20 | SUNNY (FWD) B12 E15T,E15S,GA15#,CA16D(4 WD) | 85/9~90/ | Mission & Differential (M/T) MISSION CASE |
| 03903 3911 | 33111-06R00 | 52 x 66 x 9 | SUNNY (FWD) B13 GA15DS,CD17(4WD) | 90/1~94/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2151 | 33111-06R00 | 52 x 66 x 9 | SUNNY (FWD) B14 GA15DE(4WD) | 94/1~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 6161 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B12 RN3F01A,RL3F01A | 85/9~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 3445 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B12 RL4F03A | 89/5~90/ | Mission & Differential (A/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3939 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B13 GA13DS(ALL),GA15DS,GA 16DE,CD17 EXCEPT(NSD) | 90/1~94/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4465 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B14 GA13DE,GA15DE EXCEPT(NSD),GA16DE | 94/1~98/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1569 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B15 (ALL) | 98/10~ | Mission & Differential (A/T) MISSION CASE |
| 03903 5909 | 38342-D2100 | 40 x 56 x 65 x 20 | SUNNY (FWD) B12 E15T | 85/9~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 4935 | 33111-31X00 | 60 x 76 x 9 | SUNNY (FWD) B13 SR18DE(4WD) | 90/1~94/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5315 | 38342-03E00 | 39 x 59 x 11 x 17 | SUNNY (FWD) B15 YD22DD | 98/10~ | Mission & Differential (M/T) MISSION CASE |
| 03903 6155 | 38342-31X01 | 33 x 56 x 8 x 13 | SUNNY (FWD) B13,B14 SR18DE | 90/1~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1193 | 38342-03E01 | 33 x 59 x 11 x 17 | SUNNY (FWD) B15 SR16VE | 98/10~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2517 | 38342-D2100 | 40 x 56 x 65 x 20 | SUNNY (FWD) B14 GA15DE(NSD),CD20(2WD) ,GA16DE(ALL) | 94/1~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 5593 | 38342-21X01 | 39 x 57 x 11 x 17 | SUNNY (FWD) B12 RL4F02A E15T,E15E,GA15# | 85/9~89/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 3775 | 38342-21X00 | 39 x 57 x 15.5 x 21.5 | SUNNY (FWD) B12 RL4F02A CA16D | 86/8~90/ | Mission & Differential (A/T) MISSION CASE |
| 03903 1767 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B14 GA13DE,GA15DE 2WD | 94/1~98/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1713 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B13 GA13DS,GA15DS EXCEPT(NSD),CD17 2WD | 90/1~94/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 1033 | 38342-M8001 | 40 x 56 x 8 | SUNNY (FWD) B12 E13S,E15S,E15E,CD17,GA1 5S,GA15E 2WD | 85/9~90/ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 2667 | 38342-51E00 | 46 x 90 x 11 | SUNNY (FWD) B15 SR16VE | 98/10~ | Mission & Differential (M/T) MISSION CASE |
| 03903 4937 | 38342-56E00 | 43 x 90 x 12 x 21 | SUNNY (FWD) B14 CD20(4WD) | 94/1~98/ | Mission & Differential (M/T) MISSION CASE |
| 03903 1247 | 38342-31X02 | 42 x 90 x 9.5 x 13 | SUNNY (FWD) B15 QG15DE(4WD) | 98/10~ | Mission & Differential (M/T) MISSION CASE |
| 03903 6061 | 38342-31X02 | 42 x 90 x 9.5 x 13 | SUNNY (FWD) B13,B14 SR18DE | 90/1~98/ | Mission & Differential (M/T) MISSION CASE |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4903 | 38342-31X02 | 42 x 90 x 9.5 x 13 | SUNNY (FWD) B13 GA15DS,GA15DS,GA16DE, CD17(NSD),SR18DE(ALL) | 90/1~94/ | Mission & Differential (A/T) MISSION CASE |
| 03903 4005 | 48029-W0501 | 17.5 x 32 x 7 | SUNNY (FWD) B12 RN3F01A,RL3F01A(4WD) | 85/9~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5123 | 13207-01M01 | | SUNNY (FWD) B11 E13S,E15# | 81/10~90/ | Engine VALVE STEM SEAL |
| 03903 2535 | 13207-D4200 | | SUNNY (FWD) B12 CA16D | 86/8~90/ | Engine VALVE STEM SEAL |
| 03903 5899 | 48029-W0501 | 17.5 x 32 x 7 | SUNNY (FWD) B14 CD20(4WD) | 94/1~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6209 | 13207-D4200 | | SUNNY (FWD) B13,B14 GA15DS | 87/9~90/ | Engine VALVE STEM SEAL |
| 03903 4033 | 13207-D0101 | | SUNNY (FWD) B11,B12,B13,B14 CD17,CD20 | 81/10~ | Engine VALVE STEM SEAL |
| 03903 3735 | 13207-D4200 | | SUNNY (FWD) B13,B14 SR18DE | 90/1~98/ | Engine VALVE STEM SEAL |
| 03903 3065 | 13207-D4200 | | SUNNY (FWD) B15 QG13DE,G15DE,QG18DD | 98/10~ | Engine VALVE STEM SEAL |
| 03903 5479 | 13207-D4200 | | SUNNY (FWD) B15 SR16VE | 98/10~ | Engine VALVE STEM SEAL |
| 03903 1505 | 13207-D4200 | | SUNNY (FWD) B15 YD22DD(EX.) | 99/9~ | Engine VALVE STEM SEAL |
| 03903 2537 | 13207-5L300 | | SUNNY (FWD) B15 YD22DD(IN.) | 99/9~ | Engine VALVE STEM SEAL |
| 03903 4247 | 48029-W0501 | 17.5 x 32 x 7 | SUNNY (FWD) B13 GA15DS(4WD) | 90/1~94/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6065 | 12279-AD205 | 84 x 104 x 8.5 | SUNNY (FWD) B15 QG13DE,QG15DE,QG18DD ,YD22DD | 98/10~ | Engine CRANK SHAFT FRONT |
| 03903 1657 | 38342-31X01 | 33 x 56 x 8 x 13 | SUNNY (FWD) B13 SR18DE(2WD) | 90/1~94/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1659 | 13207-53Y00 | | SUNNY (FWD) B13,B14 GA13D#,GA15D#,GA16DE | 90/1~94/ | Engine VALVE STEM SEAL |
| 03903 1175 | 38342-03E01 | 33 x 59 x 11 x 17 | SUNNY (FWD) B12 RL4F02A CA16D | 86/8~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 5949 | 38342-31X01 | 33 x 56 x 8 x 13 | SUNNY (FWD) B15 YD22DD(2WD) | 98/10~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3129 | 38342-31X01 | 33 x 56 x 8 x 13 | SUNNY (FWD) B14 SR18DE(2WD) | 94/1~98/ | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3221 | 38342-03E00 | 39 x 59 x 11 x 17 | SUNNY (FWD) B12 RL4F02A E15T,E15E,GA15# | 85/9~89/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3581 | 49297-5M385 | | SUNNY (FWD) B15 YD22DD | 00/9~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3283 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B15 QG13DE,QG15DE,QG18DD 2WD | 98/10~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6569 | 48029-W0501 | 17.5 x 32 x 7 | SUNNY (FWD) B15 QG15DE(4WD) | 98/10~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1775 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B14 GA13DE,GA15DE,GA16DE, CD20 2WD | 94/1~98/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1749 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B12 RL4F03A | 89/5~90/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4327 | 12279-85Y00 | 84 x 104 x 11 | SUNNY (FWD) B14 GA13DS,GA15DS,GA16DE, SR18DE,CD20 | 94/1~98/ | Engine CRANK SHAFT FRONT |
| 03903 2433 | 13510-V7202 | 40 x 52 x 7 | SUNNY (FWD) B15 QG13DE,QG15DE,QG18DD | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 1245 | 13510-2J200 | 46 x 58 x 7 | SUNNY (FWD) B15 SR16VE | 98/10~ | Engine CRANK SHAFT FRONT |
| 03903 1413 | 13510-AD200 | 50 x 62 x 7 | SUNNY (FWD) B15 YD22DD | 98/10~ | Engine CRANK SHAFT FRONT |
| 03903 1267 | 12279-01M00 | 80 x 100 x 10 | SUNNY (FWD) B11,B12 E13S,E15# | 81/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 1689 | 12279-D0100 | 84 x 104 x 11 | SUNNY (FWD) B11,B12,B13 CD17 | 81/10~94/ | Engine CRANK SHAFT FRONT |
| 03903 5579 | 12279-85Y00 | 84 x 104 x 11 | SUNNY (FWD) B13 GA13DS,GA15DS,GA16DE, SR18DE | 90/1~94/ | Engine CRANK SHAFT FRONT |
| 03903 5323 | 38342-31X00 | 40 x 56 x 8 x 13.5 | SUNNY (FWD) B13 GA13DS,GA15DS,GA16DE, CD17 2WD | 90/1~94/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4243 | 13042-16V00 | 40 x 52 x 7 | SUNNY (FWD) B12 CA16D | 86/8~90/ | Engine CRANK SHAFT FRONT |
| 03903 2775 | 49297-8N025 | | SUNNY (FWD) B15 QG13DE,QG15DE,18DD | 02/5~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4085 | 13042-01M00 | 40 x 55 x 9 | SUNNY (FWD) B11,B12 E13S,E15# | 81/10~90/ | Engine CAM SHAFT |
| 03903 5541 | 13042-D0100 | 34 x 48 x 8 | SUNNY (FWD) B11,B12,B13,B14 CD17,CD20 | 82/10~98/ | Engine CAM SHAFT |
| 03903 2923 | 13042-16V00 | 40 x 52 x 7 | SUNNY (FWD) B12 CA16D | 86/8~90/ | Engine CAM SHAFT |
| 03903 1205 | 13168-01M00 | 32 x 50 x 8 | SUNNY (FWD) B11,B12 E13S,E15# | 81/10~90/ | Engine JACK SHAFT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1307 | 13510-16A00 | 33 x 47 x 8 | SUNNY (FWD) B11,B12,B13 CD17 | 81/10~94/ | Engine CRANK SHAFT FRONT |
| 03903 1901 | 49297-D0301 | | SUNNY (FWD) B13 | 90/1~94/ | Steering (P/S) PISTON SEAL SET |
| 03903 1407 | 13042-16V00 | 40 x 52 x 7 | SUNNY (FWD) B12 GA15# | 87/9~90/ | Engine CRANK SHAFT FRONT |
| 03903 1357 | 13042-16V00 | 40 x 52 x 7 | SUNNY (FWD) B13 GA13DS,GA15DS,GA16DE | 90/1~94/ | Engine CRANK SHAFT FRONT |
| 03903 4645 | 13042-16V00 | 40 x 52 x 7 | SUNNY (FWD) B14 GA13DE,GA15DE,GA16DE, CD20 | 94/1~98/ | Engine CRANK SHAFT FRONT |
| 03903 4713 | 13042-16V00 | 40 x 52 x 7 | SUNNY (FWD) B15 QG13DE,QG15DE,QG18DD | 98/10~00/ 7 | Engine CRANK SHAFT FRONT |
| 03903 2663 | 13510-53J00 | 46 x 58 x 7 | SUNNY (FWD) B13,B14 SR18DE | 90/1~98/ | Engine CRANK SHAFT FRONT |
| 03903 3351 | 40227-50W01 | 50 x 72 x 83 x 16.2 | SUNNY (FWD) B13 SR18DE(4WD) | 90/1~94/ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3571 | 13510-01M00 | 36 x 49 x 7 | SUNNY (FWD) B11,B12 E13S,E15# | 81/10~90/ | Engine CRANK SHAFT FRONT |
| 03903 5379 | 49297-65F25 | | SUNNY (FWD) B14 | 94/1~98/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 2095 | 38342-21000 | 32 x 52 x 11 x 15.5 | SUNNY (FWD) B12,B13,B14,B15(4WD) | 85/9~ | Final Drive DIFF. SIDE |
| 03903 2289 | 48125-11A00 | 17.5 x 32 x 6 | SUNNY (FWD) B11 | 81/10~85/ | Steering SECTOR SHAFT |
| 03903 3241 | 48125-50A00 | 15 x 30 x 8 x 10.5 | SUNNY (FWD) B12 CD17 | 85/9~90/ | Steering SECTOR SHAFT |
| 03903 3859 | 48125-50A00 | 15 x 30 x 8 x 10.5 | SUNNY (FWD) B12 (ALL) | 87/9~90/ | Steering SECTOR SHAFT |
| 03903 3807 | 48125-50A00 | 15 x 30 x 8 x 10.5 | SUNNY (FWD) B13 | 90/1~94/ | Steering SECTOR SHAFT |
| 03903 1995 | 49297-86A25 | | SUNNY (FWD) B13 | 90/1~94/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 5509 | 38189-U3000 | 35 x 67 x 12 x 18 | SUNNY (FWD) B12,B13,B14,B15(4WD) | 85/9~ | Final Drive PINION |
| 03903 1437 | 49297-4M426 | | SUNNY (FWD) B15 QG13DE,QG15DE,QG18DD | 98/10~00/ 9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 2639 | 49297-4M427 | | SUNNY (FWD) B15 QG13DE,QG15DE,QG18DD | 00/9~05/5 | Steering (P/S) GEAR HOUSING KIT |
| 03903 5617 | 49297-4M587 | | SUNNY (FWD) B15 YD22DD | 99/9~00/9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 6139 | 49297-6M026 | | SUNNY (FWD) B15 SR16VE | 98/10~00/ 9 | Steering (P/S) GEAR HOUSING KIT |
| 03903 3853 | 49297-5M328 | | SUNNY (FWD) B15 SR16VE | 00/9~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3921 | 49365-V0227 | | SUNNY (FWD) B12 | 85/9~90/ | Steering (P/S) PINION SEAL KIT |
| 03903 2009 | 49365-10V26 | | SUNNY (FWD) B13,B14 | 90/1~98/ | Steering (P/S) PINION SEAL KIT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4365 | 49297-53A25 | | SUNNY (FWD) B12 | 85/9~90/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 3557 | 32114-Y4000 | 30 x 45 x 8 | SUNNY (RWD) B310 FS5W60A,F4W60L T/M | 77/11~83/ | Transmission FRONT COVER |
| 03903 3737 | 32136-G1001 | 30 x 45 x 62 x 41 | SUNNY (RWD) B120 | 75/10~94/ | Transmission REAR EXTENSION |
| 03903 5487 | 13207-H7200 | | SUNNY (RWD) B120,B310 A12,A13,A14,A15 | 75/10~94/ | Engine VALVE STEM SEAL |
| 03903 4897 | 32136-H5000 | 30 x 45 x 77 x 45 | SUNNY (RWD) B310 | 77/11~83/ | Transmission REAR EXTENSION |
| 03903 3235 | 40232-21000 | 42 x 55 x 8 | SUNNY (RWD) B120 | 75/10~94/ | Wheel Hub FRONT |
| 03903 3315 | 40232-21000 | 42 x 55 x 8 | SUNNY (RWD) B310 | 77/11~83/ | Wheel Hub FRONT |
| 03903 3391 | 43252-H1000 | 41 x 56 x 7 | SUNNY (RWD) B120 | 75/10~94/ | Wheel Hub REAR |
| 03903 1547 | 43252-H1000 | 41 x 56 x 7 | SUNNY (RWD) B310 | 77/11~83/ | Wheel Hub REAR |
| 03903 5339 | 32113-H3100 | 24 x 40 x 8 | SUNNY (RWD) B310 F456A T/M | 77/11~83/ | Transmission FRONT COVER |
| 03903 5915 | 38189-A6100 | 35 x 64 x 13 | SUNNY (RWD) B120 | 75/10~94/ | Final Drive PINION |
| 03903 2541 | 38189-A6100 | 35 x 64 x 13 | SUNNY (RWD) B310 | 77/11~83/ | Final Drive PINION |
| 03903 4861 | 48137-H1002 | 25 x 38 x 7 | SUNNY (RWD) B120 | 75/10~94/ | Steering SECTOR SHAFT |
| 03903 6219 | 48137-H1002 | 25 x 38 x 7 | SUNNY (RWD) B310 | 77/11~83/ | Steering SECTOR SHAFT |
| 03903 1599 | 48029-H5000 | 17 x 30 x 7 | SUNNY (RWD) B310 | 77/11~83/ | Steering WORM |
| 03903 3539 | 13510-H1010 | 38 x 55 x 9 | SUNNY (RWD) B120 A12S | 75/10~94/ | Engine CRANK SHAFT FRONT |
| 03903 5587 | 13510-H1010 | 38 x 55 x 9 | SUNNY (RWD) B310 A12S,A13,A14,A15 | 77/11~83/ | Engine CRANK SHAFT FRONT |
| 03903 2235 | 12279-H2311 | 60 x 82 x 12 | SUNNY (RWD) B120 A12S | 75/10~94/ | Engine CRANK SHAFT REAR |
| 03903 2967 | 12279-H2311 | 60 x 82 x 12 | SUNNY (RWD) B310 A12S,A13,A14,A15 | 77/11~83/ | Engine CRANK SHAFT REAR |
| 03903 3389 | 32113-H3100 | 24 x 40 x 8 | SUNNY (RWD) B120 | 75/10~94/ | Transmission FRONT COVER |
| 03903 3437 | 13510-2J200 | 46 x 58 x 7 | TEANA J31 QR25DE | 03/2~ | Engine CRANK SHAFT FRONT |
| 03903 6309 | 38189-4N500 | 32.5 x 57 x 9 x 17 | TEANA J31 QR25DE | 03/2~ | Final Drive PINION |
| 03903 3151 | 38342-81X00 | 39 x 59 x 8 x 13.7 | TEANA J31 | 03/2~ | Mission & Differential (A/T) MISSION CASE |
| 03903 4273 | 38342-06R01 | 52 x 78 x 9 | TEANA J31 QR25DE(AT) | 03/2~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4953 | 38342-81X01 | 33 x 59 x 9 x 15.6 | TEANA J31 VQ23DE(AT),VQ35DE(MC VT) | 03/2~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1789 | 13510-31U00 | 48 x 60 x 7 | TEANA J31 VQ23DE,VQ35DE | 03/2~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3177 | 12279-AD205 | 84 x 104 x 8.5 | TEANA J31 QR25DE | 03/2~ | Engine CRANK SHAFT REAR |
| 03903 6403 | 12296-31U20 | RETAINER ID 97 (F) | TEANA J31 VQ23DE,VQ35DE | 03/2~ | Engine CRANK SHAFT REAR |
| 03903 4793 | 13207-D4200 | | TEANA J31 QR25DE,VQ23DE,VQ35DE | 03/2~ | Engine VALVE STEM SEAL |
| 03903 1999 | 49297-9Y025 | | TEANA J31 | 03/2~ | Power Steering GEAR HOUSING KIT |
| 03903 1429 | 38342-4N500 | 38 x 55 x 8 x 13.5 | TEANA J31 QR25DE | 03/2~ | Final Drive DIFF. SIDE |
| 03903 3179 | 13510-43G01 | 58 x 80 x 7 | TERRANO / LGURUS R50,JR50 TD27TI | 97/6~02/ | Engine CRANK SHAFT FRONT |
| 03903 6101 | 38189-C7000 | 42 x 76 x 12 x 21 | TERRANO / LGURUS WD21 TD27T,VG30# | 87/10~93/1 | Rear Final Drive PINION |
| 03903 3411 | 38189-01G16 | 35 x 67 x 13.7 x 19.5 | TERRANO / LGURUS WD21 TD27# | 91/7~95/ | Front Final Drive PINION |
| 03903 3443 | 49203-Y0127 | | TERRANO / LGURUS WD21 | 86/8~93/1 | Power Steering WORM GEAR KIT |
| 03903 3257 | 49345-55G25 | | TERRANO / LGURUS WD21 | 93/1~95/ | Power Steering GEAR HOUSING KIT |
| 03903 5113 | 49345-Y0125 | | TERRANO / LGURUS WD21 | 86/8~93/1 | Power Steering GEAR HOUSING KIT |
| 03903 3407 | 49321-55G25 | | TERRANO / LGURUS WD21 | 93/1~95/ | Power Steering SECTOR SHAFT KIT |
| 03903 1133 | 49202-Y0127 | | TERRANO / LGURUS WD21 | 86/8~93/1 | Power Steering SECTOR SHAFT KIT |
| 03903 1951 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | TERRANO / LGURUS R50,JR50 | 95/9~02/ | Rear Final Drive PINION |
| 03903 2199 | 38189-C7123 | 42 x 76 x 13.6 x 21.5 | TERRANO / LGURUS WD21 TD27T,VG30# | 93/1~95/ | Rear Final Drive PINION |
| 03903 2395 | 49297-0W025 | | TERRANO / LGURUS R50 | 93/1~ | Power Steering GEAR HOUSING KIT |
| 03903 6265 | 38189-N3100 | 40 x 75 x 12 x 17.5 | TERRANO / LGURUS WD21 TD27 | 86/8~91/7 | Rear Final Drive PINION |
| 03903 6421 | 49365-0W025 | | TERRANO / LGURUS R50 | 93/1~ | Power Steering PINION GEAR KIT |
| 03903 1065 | 38342-01G00 | 32 x 52 x 10.5 x 15.5 | TERRANO / LGURUS WD21 TD27# | 86/8~95/ | Front Final Drive DIFF. SIDE (LH) |
| 03903 2091 | 38342-N3100 | 35 x 55 x 11 x 18 | TERRANO / LGURUS R50,JR50 | 95/9~02/ | Front Final Drive DIFF. SIDE (LH) |
| 03903 3975 | 38342-N3100 | 35 x 55 x 11 x 18 | TERRANO / LGURUS WD21 VG30# | 87/10~95/ | Front Final Drive DIFF. SIDE (LH) |
| 03903 4933 | 40227-31G00 | 50 x 72 x 14.5 | TERRANO / LGURUS WD21,R50,JR50 | 86/8~02/ | Front Final Drive SIDE SHAFT (RH) |
| 03903 4143 | 38189-21G17 | 40 x 75 x 13.5 x 20.5 | TERRANO / LGURUS R50,JR50 | 03/3~ | Front Final Drive PINION |
| 03903 6123 | 38189-21G17 | 40 x 75 x 13.5 x 22 | TERRANO / LGURUS R50,JR50 | 95/9~03/3 | Front Final Drive PINION |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2623 | 38189-21G17 | 40 x 75 x 13.5 x 22 | TERRANO / LGURUS WD21 VG30# | 91/7~95/ | Front Final Drive PINION |
| 03903 1997 | 38189-21G00 | 40 x 75 x 12 x 19 | TERRANO / LGURUS WD21 VG30# | 87/10~91/7 | Front Final Drive PINION |
| 03903 2113 | 38189-N3112 | 40 x 75 x 13.5 x 21 | TERRANO / LGURUS WD21 TD27 | 91/7~93/1 | Rear Final Drive PINION |
| 03903 4641 | 12279-85Y00 | 84 x 104 x 11 | TERRANO / LGURUS WD21 VG30# | 89/2~95/ | Engine CRANK SHAFT REAR |
| 03903 5293 | 13510-2W201 | 52 x 66 x 7 | TERRANO / LGURUS R50,JR50 ZD30DDTI | 99/2~02/ | Engine CRANK SHAFT FRONT |
| 03903 5583 | 13207-81W00 | | TERRANO / LGURUS R50,JR50 VG33E(IN.) | 95/9~01/10 | Engine VALVE STEM SEAL |
| 03903 1131 | 13207-81W00 | | TERRANO / LGURUS WD21 VG30#(IN.) | 87/10~95/ | Engine VALVE STEM SEAL |
| 03903 4963 | 13207-V1700 | | TERRANO / LGURUS R50,JR50 TD27TI,QD32TI | 95/9~99/2 | Engine VALVE STEM SEAL |
| 03903 2127 | 13207-V1700 | | TERRANO / LGURUS WD21 TD27# | 86/8~95/ | Engine VALVE STEM SEAL |
| 03903 4811 | 13207-D0101 | | TERRANO / LGURUS R50,JR50 ZD30DDTI | 99/2~02/ | Engine VALVE STEM SEAL |
| 03903 1259 | 13207-D0101 | | TERRANO / LGURUS R50,JR50 VG33E(EX.) | 95/9~01/10 | Engine VALVE STEM SEAL |
| 03903 1527 | 13207-D0101 | | TERRANO / LGURUS WD21 VG30#(EX.) | 87/10~95/ | Engine VALVE STEM SEAL |
| 03903 3231 | 49277-Y0102 | | TERRANO / LGURUS WD21 | 87/8~93/1 | Power Steering PISTON SEAL SET |
| 03903 5319 | 12279-AD205 | 84 x 104 x 8.5 | TERRANO / LGURUS R50,JR50 VG33E | 97/6~01/10 | Engine CRANK SHAFT REAR |
| 03903 3041 | 12279-85Y00 | 84 x 104 x 11 | TERRANO / LGURUS R50,JR50 VG33E | 95/9~97/6 | Engine CRANK SHAFT REAR |
| 03903 3919 | 12279-43G02 | 86 x 100 x 10 | TERRANO / LGURUS WD21 TD27# | 86/8~95/ | Engine CRANK SHAFT REAR |
| 03903 3009 | 12279-D0100 | 84 x 104 x 11 | TERRANO / LGURUS WD21 VG30# | 87/10~89/2 | Engine CRANK SHAFT REAR |
| 03903 5809 | 13510-43G01 | 58 x 80 x 7 | TERRANO / LGURUS R50,JR50 QD32TI | 96/8~02/ | Engine CRANK SHAFT FRONT |
| 03903 3895 | 13510-V7202 | 40 x 52 x 7 | TERRANO / LGURUS R50,JR50 VG33E | 00/8~02/ | Engine CRANK SHAFT FRONT |
| 03903 4093 | 13510-88G10 | 33 x 47 x 7 | TERRANO / LGURUS WD21 VG30# | 87/10~95/ | Engine CRANK SHAFT FRONT |
| 03903 4395 | 13042-16V00 | 40 x 52 x 7 | TERRANO / LGURUS R50,JR50 VG33E | 95/9~00/8 | Engine CRANK SHAFT FRONT |
| 03903 2719 | 13510-43G00 | 58 x 80 x 10 | TERRANO / LGURUS WD21,R50,JR50 TD27# | 86/8~97/6 | Engine CRANK SHAFT FRONT |
| 03903 6279 | 13042-D0100 | 34 x 48 x 8 | TERRANO / LGURUS WD21,R50,JR50 VG30#,VG33E | 87/10~02/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6015 | 12279-2W201 | RETAINER ID 86 (F) | TERRANO / LGURUS R50,JR50 ZD30DDTI | 99/2~02/ | Engine CRANK SHAFT REAR |
| 03903 3447 | 43252-VW000 | 35 x 55 x 11 | TERRANO / LGURUS WD21 | 86/8~95/ | Wheel Hub REAR INNER |
| 03903 2693 | 38189-01G00 | 35 x 67 x 12 x 20.5 | TERRANO / LGURUS WD21 TD27# | 86/8~91/7 | Front Final Drive PINION |
| 03903 1271 | 40232-31G00 | 57 x 79 x 9 x 13.5 | TERRANO / LGURUS WD21 | 86/8~95/ | Wheel Hub FRONT |
| 03903 2577 | 40232-31G00 | 57 x 79 x 9 x 13.5 | TERRANO / LGURUS R50,JR50 | 95/9~ | Wheel Hub FRONT |
| 03903 2957 | 12279-43G05 | RETAINER ID 86 (F) | TERRANO / LGURUS R50,JR50 TD27TI,QD32TI | 95/9~99/2 | Engine CRANK SHAFT REAR |
| 03903 4165 | 40227-31G01 | 50 x 93 x 24 | TERRANO / LGURUS R50,JR50 4WD | 95/9~ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 2547 | 43252-0W000 | 36 x 55 x 11 | TERRANO / LGURUS R50,JR50 | 95/9~02/ | Wheel Hub REAR INNER |
| 03903 5549 | 43232-01G00 | 50 x 70 x 12 x 17 | TERRANO / LGURUS WD21 (ALL) | 86/8~87/8 | Wheel Hub REAR OUTER |
| 03903 6377 | 43232-01G00 | 50 x 70 x 12 x 17 | TERRANO / LGURUS WD21 TD27 | 87/8~93/ | Wheel Hub REAR OUTER |
| 03903 5251 | 43232-42G10 | 55 x 74 x 10 x 13.5 | TERRANO / LGURUS WD21 TD27,VG30# | 87/10~95/ | Wheel Hub REAR OUTER |
| 03903 2907 | 32114-Y4000 | 30 x 45 x 8 | TERRANO / LGURUS WD21,R50 MT | 86/8~95/ | Transmission FRONT COVER |
| 03903 3073 | 33111-31G00 | 50 x 72 x 12 | TERRANO / LGURUS WD21 MT | 86/8~95/ | Transfer (M/T) COVER |
| 03903 5699 | 33111-31G00 | 50 x 72 x 12 | TERRANO / LGURUS R50 TD27IT SEV(MT) | 95/9~02/ | Transfer (M/T) COVER |
| 03903 5825 | 33142-33G10 | 42 x 66 x 10 | TERRANO / LGURUS WD21,R50,JR50 | 86/8~02/ | Transfer (A/T) CASE(REAR) |
| 03903 1145 | 33111-46G00 | 50 x 72 x 12 | TERRANO / LGURUS WD21,JR50 | 87/10~95/ | Transfer (A/T) COVER |
| 03903 4633 | 33111-46G00 | 50 x 72 x 12 | TERRANO / LGURUS R50 SEV | 95/9~02/ | Transfer (A/T) COVER |
| 03903 1257 | 31375-51X03 | 46 x 63 x 7.7 x 8.5 | TERRANO / LGURUS R50 SE,LE,XE | 95/9~02/ | Transfer (A/T) COVER |
| 03903 2229 | 33216-33G01 | 40 x 75 x 12 x 20 | TERRANO / LGURUS WD21,R50,JR50 | 86/8~02/ | Transfer (A/T) CASE(FRONT) |
| 03903 3261 | 43232-42G10 | 55 x 74 x 10 x 13.5 | TERRANO / LGURUS R50,JR50 | 95/9~02/ | Wheel Hub REAR OUTER |
| 03903 3809 | 40227-31G01 | 50 x 93 x 24 | TERRANO / LGURUS WD21 | 86/8~95/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 5091 | 38342-31X00 | 40 x 56 x 8 x 13.5 | TINO V10 SR20DE EXCEPT(LSD) | 98/12~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 4237 | 38342-31X00 | 40 x 56 x 8 x 13.5 | TINO V10 QG18DE | 98/12~00/7 | Mission & Differential (A/T) CONVERTER HOUSING |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3039 | 38342-8E002 | 41.5 x 90 x 8 x 12 | TINO V10 SR20DE (LSD) | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 1327 | 38342-8E002 | 41.5 x 90 x 8 x 12 | TINO V10 QG18DE(LSD) | 00/11~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6443 | 38342-8E000 | 40 x 52 x 8 x 13 | TINO V10 SR20DE EXCEPT(LSD) | 00/5~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6271 | 38342-8E000 | 40 x 52 x 8 x 13 | TINO V10 QG18DE EXCEPT(LSD) | 00/11~ | Mission & Differential (A/T) MISSION CASE |
| 03903 4825 | 38342-31X02 | 42 x 90 x 9.5 x 13 | TINO V10 SR20DE (LSD) | 98/12~00/5 | Mission & Differential (A/T) MISSION CASE |
| 03903 4545 | 38342-31X00 | 40 x 56 x 8 x 13.5 | TINO V10 QG18DE EXCEPT EM29(HYBRID) | 00/3~ | Mission & Differential (A/T) MISSION CASE |
| 03903 2193 | 13207-D4200 | | TINO V10 SR20DE | 98/12~ | Engine VALVE STEM SEAL |
| 03903 2723 | 38342-31X02 | 42 x 90 x 9.5 x 13 | TINO V10 QG18DE(LSD) | 98/12~00/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 3169 | 38342-31X01 | 33 x 56 x 8 x 13 | TINO V10 QG18DE EXCEPT EM29(HYBRID) | 00/3~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 6411 | 38342-8E001 | 32.5 x 56 x 8 x 14 | TINO V10 SR20DE | 00/5~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1209 | 49297-AA085 | | TINO V10 | 98/12~00/9 | Power Steering GEAR HOUSING KIT |
| 03903 5891 | 49297-4U026 | | TINO V10 | 00/9~ | Power Steering GEAR HOUSING KIT |
| 03903 2103 | 13510-5U300 | 37 x 60 x 12 | TINO V10 QG18DE EXCEPT EM19(HYBRID) | 00/3~ | Engine OIL PUMP |
| 03903 6133 | 13042-16V00 | 40 x 52 x 7 | TINO V10 QG18DE | 98/12~00/7 | Engine CRANK SHAFT FRONT |
| 03903 3119 | 13510-53J00 | 46 x 58 x 7 | TINO V10 SR20DE | 98/12~ | Engine CRANK SHAFT FRONT |
| 03903 2053 | 38342-31X00 | 40 x 56 x 8 x 13.5 | TINO V10 QG18DE EXCEPT(LSD) | 98/12~00/11 | Mission & Differential (A/T) MISSION CASE |
| 03903 5093 | 12279-AD205 | 84 x 104 x 8.5 | TINO V10 QG18DE,SR20DE | 98/12~ | Engine CRANK SHAFT REAR |
| 03903 2567 | 38342-31X01 | 33 x 56 x 8 x 13 | TINO V10 SR20DE | 98/12~00/5 | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4821 | 13207-53Y00 | | TINO V10 QG18DE | 98/12~ | Engine VALVE STEM SEAL |
| 03903 4857 | 13510-V7202 | 40 x 52 x 7 | TINO V10 QG18DE | 00/7~ | Engine CRANK SHAFT FRONT |
| 03903 2317 | 38342-8E000 | 40 x 52 x 8 x 13 | TINO V10 QG18DE | 00/7~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 1445 | 43252-H1000 | 41 x 56 x 7 | VANETTE COACH, VAN, TRUCK C22,TC22 | 85/9~94/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 2861 | 13510-H1010 | 38 x 55 x 9 | VANETTE COACH, VAN, TRUCK C120,C22,TC22 A12,A14,A15 | 78/10~94/ | Engine CRANK SHAFT FRONT |
| 03903 1309 | 32136-H5000 | 30 x 45 x 77 x 45 | VANETTE COACH, VAN, TRUCK C120 ALL | 78/10~81/ 6 | Transmission REAR EXTENSION |
| 03903 5013 | 32114-Y4000 | 30 x 45 x 8 | VANETTE COACH, VAN, TRUCK C22,TC22 | 85/9~94/ | Transmission FRONT COVER |
| 03903 6141 | 32114-Y4000 | 30 x 45 x 8 | VANETTE COACH, VAN, TRUCK C120 VAN.A12 | 85/8~88/ | Transmission FRONT COVER |
| 03903 1617 | 32114-Y4000 | 30 x 45 x 8 | VANETTE COACH, VAN, TRUCK C120 EXCEPT CT,VAN.A12 | 78/10~88/ | Transmission FRONT COVER |
| 03903 4439 | 32113-H3100 | 24 x 40 x 8 | VANETTE COACH, VAN, TRUCK C120 CT,VAN.A12 | 78/10~85/ 8 | Transmission FRONT COVER |
| 03903 6253 | 32136-U0100 | 35 x 50 x 11 | VANETTE COACH, VAN, TRUCK C120 LD20#,Z20 | 81/6~88/ | Transmission REAR EXTENSION |
| 03903 3691 | 43232-G3210 | 56 x 78 x 10 | VANETTE COACH, VAN, TRUCK C120 TRUCK LONG BODY | 82/10~88/ | Wheel Hub REAR INNER |
| 03903 4687 | 32136-U0100 | 35 x 50 x 11 | VANETTE COACH, VAN, TRUCK C22,TC22 LD20#,CA20 | 85/9~94/ | Transmission REAR EXTENSION |
| 03903 2795 | 43252-H1000 | 41 x 56 x 7 | VANETTE COACH, VAN, TRUCK C120 EXCEPT TRUCK LONG BODY | 78/10~88/ | Wheel Hub REAR |
| 03903 5185 | 13510-60U00 | 50 x 65 x 8 | VANETTE COACH, VAN, TRUCK C22,TC22 LD20# | 85/9~94/ | Engine CAM SHAFT |
| 03903 1113 | 40232-30R11 | 56 x 76 x 7.5 x 11 | VANETTE COACH, VAN, TRUCK C22,TC22 4WD | 88/9~94/ | Wheel Hub FRONT IN. & OUT. |
| 03903 5827 | 40232-G5100 | 48 x 62 x 11 x 20.5 | VANETTE COACH, VAN, TRUCK C22,TC22 2WD | 85/9~94/ | Wheel Hub FRONT |
| 03903 6017 | 40232-A0101 | 48 x 62 x 6 | VANETTE COACH, VAN, TRUCK C120 DISC BRAKE | 78/10~88/ | Wheel Hub FRONT |
| 03903 1149 | 43252-G3200 | 25 x 35 x 7 | VANETTE COACH, VAN, TRUCK C120 TRUCK LONG BODY | 82/10~88/ | Wheel Hub REAR OUTER |
| 03903 5987 | 38189-P0101 | 45 x 75 x 12 | VANETTE COACH, VAN, TRUCK C22 HE,HF FINAL DRIVE | 85/9~91/7 | Final Drive PINION |
| 03903 2419 | 49365-10V26 | | VANETTE COACH, VAN, TRUCK C22 RP TYPE | 88/9~94/ | Steering (P/S) WORM GEAR KIT |
| 03903 1567 | 49365-V0226 | | VANETTE COACH, VAN, TRUCK C22 GB TYPE | 85/9~88/9 | Steering (P/S) WORM GEAR KIT |
| 03903 4495 | 49202-01C26 | | VANETTE COACH, VAN, TRUCK C22 GB TYPE | 85/9~88/9 | Steering (P/S) SECTOR SHAFT KIT |
| 03903 6325 | 48125-G8300 | 18.5 x 32 x 8.5 x 9.5 | VANETTE COACH, VAN, TRUCK TC22 | 88/11~94/ | Steering WORM |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3619 | 48137-G4000 | 28.6 x 40 x 8 | VANETTE COACH, VAN, TRUCK C22,TC22 | 85/9~94/ | Steering SECTOR SHAFT |
| 03903 4499 | 48137-H1002 | 25 x 38 x 7 | VANETTE COACH, VAN, TRUCK C120 | 78/10~88/ | Steering SECTOR SHAFT |
| 03903 5211 | 32136-H5000 | 30 x 45 x 77 x 45 | VANETTE COACH, VAN, TRUCK C120 DX.A12+A15 | 81/6~85/8 | Transmission REAR EXTENSION |
| 03903 4647 | 38189-P0101 | 45 x 75 x 12 | VANETTE COACH, VAN, TRUCK TC22 HF FINAL DRIVE | 88/11~91/7 | Final Drive PINION |
| 03903 5265 | 13042-D0100 | 34 x 48 x 8 | VANETTE COACH, VAN, TRUCK C22 CA20 | 85/9~91/ | Engine CAM SHAFT |
| 03903 4185 | 38189-P0101 | 45 x 75 x 12 | VANETTE COACH, VAN, TRUCK C120 HE FINAL DRIVE | 81/6~88/ | Final Drive PINION |
| 03903 3675 | 38189-A6100 | 35 x 64 x 13 | VANETTE COACH, VAN, TRUCK C22 HC FINAL DRIVE | 85/9~94/ | Final Drive PINION |
| 03903 4785 | 38189-A6100 | 35 x 64 x 13 | VANETTE COACH, VAN, TRUCK C120 HC,HD FINAL DRIVE | 78/10~88/ | Final Drive PINION |
| 03903 5409 | 32136-H5010 | 30 x 45 x 77 x 51 | VANETTE COACH, VAN, TRUCK C22,TC22 A12,A15 | 85/9~94/ | Transmission REAR EXTENSION |
| 03903 3359 | 32136-H5010 | 30 x 45 x 77 x 51 | VANETTE COACH, VAN, TRUCK C120 A12,A15 | 81/6~88/ | Transmission REAR EXTENSION |
| 03903 2073 | 32136-H5010 | 30 x 45 x 77 x 51 | VANETTE COACH, VAN, TRUCK C120 CT | 81/6~82/10 | Transmission REAR EXTENSION |
| 03903 4905 | 38189-P0117 | 45 x 75 x 14 x 19.5 | VANETTE COACH, VAN, TRUCK C22,TC22 HF FINAL DRIVE | 91/7~94/ | Final Drive PINION |
| 03903 3521 | 49365-10V26 | | VANETTE COACH, VAN, TRUCK TC22 RP TYPE | 88/11~94/ | Steering (P/S) WORM GEAR KIT |
| 03903 5829 | 13042-A8601 | 48 x 70 x 9 | VANETTE COACH, VAN, TRUCK TC22 Z20S,NA20S | 88/11~94/ | Engine CRANK SHAFT FRONT |
| 03903 3337 | 13042-A8601 | 48 x 70 x 9 | VANETTE COACH, VAN, TRUCK C120 Z20,LD20# | 81/6~88/ | Engine CRANK SHAFT FRONT |
| 03903 1575 | 13510-88G10 | 33 x 47 x 7 | VANETTE COACH, VAN, TRUCK C22 CA20 | 85/9~94/ | Engine CRANK SHAFT FRONT |
| 03903 2713 | 13510-05E00 | 46 x 58 x 8 | VANETTE COACH, VAN, TRUCK C22,TC22 LD20# | 85/9~94/ | Engine CRANK SHAFT FRONT |
| 03903 3575 | 12279-R4611 | 80 x 100 x 13 | VANETTE COACH, VAN, TRUCK C120,C22 Z20,LD20# | 81/6~87/6 | Engine CRANK SHAFT REAR |
| 03903 3313 | 12279-R4611 | 80 x 100 x 13 | VANETTE COACH, VAN, TRUCK TC22 Z20S | 88/11~90/8 | Engine CRANK SHAFT REAR |
| 03903 3373 | 12279-H2311 | 60 x 82 x 12 | VANETTE COACH, VAN, TRUCK C120,C22,TC22 A12,A14,A15 | 78/10~94/ | Engine CRANK SHAFT REAR |
| 03903 2843 | 12279-T7202 | 80 x 100 x 10 | VANETTE COACH, VAN, TRUCK TC22 LD20# | 88/11~94/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5763 | 12279-85Y00 | 84 x 104 x 11 | VANETTE COACH, VAN, TRUCK C22 CA20 | 85/9~91/ | Engine CRANK SHAFT REAR |
| 03903 1587 | 12279-58S00 | 80 x 100 x 10 | VANETTE COACH, VAN, TRUCK C22 LD20# | 87/6~94/ | Engine CRANK SHAFT REAR |
| 03903 5913 | 12279-58S00 | 80 x 100 x 10 | VANETTE COACH, VAN, TRUCK TC22 NA20S | 90/8~94/ | Engine CRANK SHAFT REAR |
| 03903 5083 | 40232-N7100 | 46 x 59.1 x 12 | VANETTE COACH, VAN, TRUCK C120 DRUM BRAKE | 78/10~82/ | Wheel Hub FRONT |
| 03903 1993 | 13207-21002 | | VANETTE COACH, VAN, TRUCK LD20 | 81/6~85/9 | Engine VALVE STEM SEAL |
| 03903 4387 | 13207-D0101 | | VANETTE COACH, VAN, TRUCK CA20 | 85/8~91/ | Engine VALVE STEM SEAL |
| 03903 3889 | 13207-42L00 | | VANETTE COACH, VAN, TRUCK NA20S | 90/8~94/ | Engine VALVE STEM SEAL |
| 03903 3365 | 13207-H7200 | | VANETTE COACH, VAN, TRUCK A15# | 80/6~94/ | Engine VALVE STEM SEAL |
| 03903 4733 | 13207-H7200 | | VANETTE COACH, VAN, TRUCK A14(EX.) | 78/10~81/6 | Engine VALVE STEM SEAL |
| 03903 5971 | 13219-H1000 | | VANETTE COACH, VAN, TRUCK A14(IN.) | 78/10~81/6 | Engine VALVE STEM SEAL |
| 03903 4765 | 13219-H1000 | | VANETTE COACH, VAN, TRUCK A12 | 78/10~82/9 | Engine VALVE STEM SEAL |
| 03903 5197 | 13207-81W00 | | VANETTE COACH, VAN, TRUCK LD20# | 85/9~94/ | Engine VALVE STEM SEAL |
| 03903 4031 | 13207-81W00 | | VANETTE COACH, VAN, TRUCK Z20S | 81/6~94/ | Engine VALVE STEM SEAL |
| 03903 2425 | 13207-H7200 | | VANETTE COACH, VAN, TRUCK A12# | 82/9~94/ | Engine VALVE STEM SEAL |
| 03903 5633 | 12279-H2311 | 60 x 82 x 12 | VANETTE LARGO C120,GC22 A15 | 82/9~93/ | Engine CARNK SHAFT REAR |
| 03903 5751 | 12279-T7202 | 80 x 100 x 10 | VANETTE LARGO GC22 LD20# | 86/11~92/1 | Engine CARNK SHAFT REAR |
| 03903 5255 | 13207-H7200 | | VANETTE LARGO A15 | 82/9~93/ | Engine VALVE STEM SEAL |
| 03903 3435 | 13207-D0101 | | VANETTE LARGO CA18T,CA20S,CD20TI,KA24DE | 86/5~99/ | Engine VALVE STEM SEAL |
| 03903 2389 | 13207-21002 | | VANETTE LARGO Z20,LD20 | 82/9~86/1 | Engine VALVE STEM SEAL |
| 03903 1635 | 12279-5L300 | 80 x 100 x 8.5 | VANETTE LARGO W30 KA24DE | 97/10~99/ | Engine CARNK SHAFT REAR |
| 03903 6365 | 12279-AD205 | 84 x 104 x 8.5 | VANETTE LARGO W30 CD20TI | 97/10~99/ | Engine CARNK SHAFT REAR |
| 03903 1051 | 12279-58S00 | 80 x 100 x 10 | VANETTE LARGO W30 KA24DE | 93/5~97/10 | Engine CARNK SHAFT REAR |
| 03903 5571 | 12279-85Y00 | 84 x 104 x 11 | VANETTE LARGO W30 CD20TI | 93/5~97/10 | Engine CARNK SHAFT REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 5577 | 12279-R4611 | 80 x 100 x 13 | VANETTE LARGO C120,GC22 Z20,LD20# | 82/9~86/11 | Engine CARNK SHAFT REAR |
| 03903 2687 | 43232-01G00 | 50 x 70 x 12 x 17 | VANETTE LARGO GC22 4WD | 86/11~93/ | Wheel Hub REAR OUTER |
| 03903 1239 | 13207-81W00 | | VANETTE LARGO LD20 | 86/1~93/ | Engine VALVE STEM SEAL |
| 03903 1739 | 12279-58S00 | 80 x 100 x 10 | VANETTE LARGO GC22 LD20# | 92/1~93/ | Engine CARNK SHAFT REAR |
| 03903 4577 | 40232-G5100 | 48 x 62 x 11 x 20.5 | VANETTE LARGO GC22 2WD | 86/5~93/ | Wheel Hub FRONT |
| 03903 4517 | 38189-P0101 | 45 x 75 x 12 | VANETTE LARGO C120 Z20,LD20# | 82/9~86/ | Final Drive PINION |
| 03903 2703 | 38189-N3100 | 40 x 75 x 12 x 17.5 | VANETTE LARGO GC22 (4WD)+CA FINAL DRIVE | 86/11~91/7 | Final Drive PINION |
| 03903 2515 | 38189-A6100 | 35 x 64 x 13 | VANETTE LARGO C120 A15 | 82/9~85/ | Final Drive PINION |
| 03903 3987 | 32136-H5010 | 30 x 45 x 77 x 51 | VANETTE LARGO GC22 R5 | 86/5~93/ | Transmission REAR EXTENTION |
| 03903 5953 | 32136-U0100 | 35 x 50 x 11 | VANETTE LARGO GC22 F5 | 86/5~93/ | Transmission REAR EXTENTION |
| 03903 3597 | 32136-U0100 | 35 x 50 x 11 | VANETTE LARGO C120 LD20#,Z20 | 82/9~86/ | Transmission REAR EXTENTION |
| 03903 2021 | 12279-85Y00 | 84 x 104 x 11 | VANETTE LARGO GC22 CA18T,CA20S | 90/4~93/ | Engine CARNK SHAFT REAR |
| 03903 5055 | 12279-D0100 | 84 x 104 x 11 | VANETTE LARGO GC22 CA18T,CA20S | 86/5~90/4 | Engine CARNK SHAFT REAR |
| 03903 4775 | 38189-P0101 | 45 x 75 x 12 | VANETTE LARGO GC22 HF FINAL DRIVE | 86/5~91/7 | Final Drive PINION |
| 03903 1179 | 40232-A0101 | 48 x 62 x 6 | VANETTE LARGO C120 | 82/9~86/ | Wheel Hub FRONT |
| 03903 6339 | 32136-H5000 | 30 x 45 x 77 x 45 | VANETTE LARGO C120 A15 | 82/9~85/ | Transmission REAR EXTENTION |
| 03903 5137 | 40232-31G00 | 57 x 79 x 9 x 13.5 | VANETTE LARGO GC22 4WD | 86/11~93/ | Wheel Hub FRONT |
| 03903 4479 | 40232-33P00 | 56 x 76 x 6 x 11 | VANETTE LARGO W30 2WD | 93/5~99/ | Wheel Hub FRONT |
| 03903 2343 | 40232-1C100 | 56 x 72 x 7 x 10.2 | VANETTE LARGO W30 4WD | 93/5~99/ | Wheel Hub FRONT INNER |
| 03903 4131 | 40232-33P00 | 56 x 76 x 6 x 11 | VANETTE LARGO W30 4WD | 93/5~99/ | Wheel Hub FRONT OUTER |
| 03903 4757 | 40227-31G01 | 50 x 93 x 24 | VANETTE LARGO GC22 4WD | 86/11~93/ | Wheel Hub FRONT DRIVE SHAFT |
| 03903 6099 | 43252-H1000 | 41 x 56 x 7 | VANETTE LARGO C120 | 82/9~86/ | Wheel Hub REAR |
| 03903 5071 | 13510-05E00 | 46 x 58 x 8 | VANETTE LARGO GC22 LD20# | 86/5~93/ | Engine CRANK SHAFT FRONT |
| 03903 1165 | 32114-Y4000 | 30 x 45 x 8 | VANETTE LARGO GC22 | 86/5~93/ | Transmission FRONT COVER |
| 03903 4501 | 43252-H1000 | 41 x 56 x 7 | VANETTE LARGO GC22 2WD | 86/5~93/ | Wheel Hub REAR |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 6527 | 43252-VW000 | 35 x 55 x 11 | VANETTE LARGO GC22 4WD | 86/11~93/ | Wheel Hub REAR INNER |
| 03903 1331 | 13510-H1010 | 38 x 55 x 9 | VANETTE LARGO C120,GC22 A15 | 82/9~93/ | Engine CRANK SHAFT FRONT |
| 03903 2491 | 13510-88G10 | 33 x 47 x 7 | VANETTE LARGO GC22 (4WD)(CA18T+CA20S) | 86/11~93/ | Engine CRANK SHAFT FRONT |
| 03903 5785 | 13510-53J00 | 46 x 58 x 7 | VANETTE LARGO W30 KA24DE | 93/5~99/ | Engine CRANK SHAFT FRONT |
| 03903 2821 | 32114-Y4000 | 30 x 45 x 8 | VANETTE LARGO C120 | 82/9~86/ | Transmission FRONT COVER |
| 03903 1049 | 13510-16A00 | 33 x 47 x 8 | VANETTE LARGO GC22 (2WD)(CA18T+CA20S) | 86/5~93/ | Engine CRANK SHAFT FRONT |
| 03903 6313 | 38189-N3112 | 40 x 75 x 13.5 x 21 | VANETTE LARGO GC22 (4WD)(AT) | 91/7~93/ | Final Drive PINION |
| 03903 1699 | 13042-A8601 | 48 x 70 x 9 | VANETTE LARGO C120 Z20,LD20# | 82/9~86/ | Engine CRANK SHAFT FRONT |
| 03903 5905 | 13042-16A11 | 36 x 50 x 8 | VANETTE LARGO W30 CD20TI | 93/5~99/ | Engine CAM SHAFT REAR |
| 03903 6087 | 13510-60U00 | 50 x 65 x 8 | VANETTE LARGO GC22 LD20# | 86/5~93/ | Engine CAM SHAFT FRONT |
| 03903 4239 | 13042-D0100 | 34 x 48 x 8 | VANETTE LARGO W30 CD20TI | 93/5~99/ | Engine CAM SHAFT FRONT |
| 03903 4077 | 13042-D0100 | 34 x 48 x 8 | VANETTE LARGO GC22 CA18T,CA20S | 86/5~93/ | Engine CAM SHAFT FRONT |
| 03903 1707 | 49297-AA085 | | VANETTE LARGO W30 | 93/5~ | Steering (P/S) GEAR HOUSING KIT |
| 03903 4171 | 48137-G4000 | 28.6 x 40 x 8 | VANETTE LARGO C120 | 82/9~86/ | Steering SECTOR SHAFT |
| 03903 2629 | 38189-N3112 | 40 x 75 x 13.5 x 21 | VANETTE LARGO W30 | 93/5~99/ | Final Drive PINION |
| 03903 4865 | 13042-16V00 | 40 x 52 x 7 | VANETTE LARGO W30 CD20TI | 93/5~99/ | Engine CRANK SHAFT FRONT |
| 03903 3403 | 49365-10V26 | | VANETTE LARGO GC22 RP TYPE | 88/9~93/ | Steering (P/S) WORM GEAR KIT |
| 03903 1631 | 38189-P0117 | 45 x 75 x 14 x 19.5 | VANETTE LARGO GC22 (2WD),(4WD)(MT) | 91/7~93/ | Final Drive PINION |
| 03903 1623 | 38342-N3100 | 35 x 55 x 11 x 18 | VANETTE LARGO W30 | 93/5~99/ | Final Drive DIFF. SIDE |
| 03903 6363 | 48040-82100 | 35 x 48 x 8 | VANETTE LARGO GC22 | 86/5~93/ | Steering SECTOR SHAFT |
| 03903 5429 | 48029-W0501 | 17.5 x 32 x 7 | VANETTE LARGO GC22 | 86/5~93/ | Steering WORM |
| 03903 3709 | 49202-13C25 | | VANETTE LARGO GC22 GB TYPE | 86/5~93/ | Steering (P/S) SECTOR SHAFT KIT |
| 03903 3861 | 49345-11G25 | | VANETTE LARGO GC22 GB TYPE | 86/5~93/ | Steering (P/S) GEAR HOUSING KIT |
| 03903 1709 | 49203-V0225 | | VANETTE LARGO GC22 GB TYPE | 86/5~93/ | Steering (P/S) WORM GEAR KIT |
| 03903 5141 | 40232-33P00 | 56 x 76 x 6 x 11 | VANETTE SERENA C23 4WD | 91/6~99/ | Wheel Hub FRONT OUTER |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 4203 | 38342-81X00 | 39 x 59 x 8 x 13.7 | VANETTE SERENA C24 R4 | 00/6~ | Transmission (A/T) MISSION CASE |
| 03903 1185 | 38342-31X01 | 33 x 56 x 8 x 13 | VANETTE SERENA C24 CVT(2WD) | 99/6~00/5 | Transmission (A/T) CONVERTER HOUSING |
| 03903 4207 | 38342-8E002 | 41.5 x 90 x 8 x 12 | VANETTE SERENA C24 CVT(LSD) | 00/5~ | Transmission (A/T) MISSION CASE |
| 03903 1335 | 38342-8E000 | 40 x 52 x 8 x 13 | VANETTE SERENA C24 CVT | 00/5~ | Transmission (A/T) MISSION CASE |
| 03903 2949 | 33111-06R00 | 52 x 66 x 9 | VANETTE SERENA C24 CVT(4WD) | 99/6~01/12 | Transmission (A/T) CONVERTER HOUSING |
| 03903 3343 | 38342-81X02 | 46 x 90 x 10.5 x 15.5 | VANETTE SERENA C24 R4(LSD) | 00/9~ | Transmission (A/T) MISSION CASE |
| 03903 5955 | 38342-03E01 | 33 x 59 x 11 x 17 | VANETTE SERENA C24 R4(2WD) | 99/6~00/9 | Transmission (A/T) CONVERTER HOUSING |
| 03903 4965 | 38342-80X00 | 46 x 90 x 10.5 x 15.7 | VANETTE SERENA C24 R4(LSD) | 99/6~00/9 | Transmission (A/T) MISSION CASE |
| 03903 4763 | 38342-31X02 | 42 x 90 x 9.5 x 13 | VANETTE SERENA C24 CVT(LSD) | 99/6~00/5 | Transmission (A/T) MISSION CASE |
| 03903 1285 | 38342-31X00 | 40 x 56 x 8 x 13.5 | VANETTE SERENA C24 CVT | 99/6~00/5 | Transmission (A/T) MISSION CASE |
| 03903 4297 | 43252-H1000 | 41 x 56 x 7 | VANETTE SERENA C23 | 91/6~99/ | Wheel Hub REAR |
| 03903 1487 | 40232-1C100 | 56 x 72 x 7 x 10.2 | VANETTE SERENA C23 4WD | 91/6~99/ | Wheel Hub FRONT INNER |
| 03903 6371 | 40232-33P00 | 56 x 76 x 6 x 11 | VANETTE SERENA C23 2WD | 91/6~99/ | Wheel Hub FRONT |
| 03903 4759 | 13510-2J200 | 46 x 58 x 7 | VANETTE SERENA C24 QR20DE,QR25DE | 01/12~ | Engine CRANK SHAFT FRONT |
| 03903 6445 | 38342-06R01 | 52 x 78 x 9 | VANETTE SERENA C24 R4(4WD) | 99/6~01/12 | Transmission (A/T) CONVERTER HOUSING |
| 03903 4213 | 32136-U0100 | 35 x 50 x 11 | VANETTE SERENA C23 | 91/6~99/ | Transmission (M/T) REAR EXTENSION |
| 03903 6059 | 13042-D0100 | 34 x 48 x 8 | VANETTE SERENA C23 CD20# | 91/6~99/ | Engine CAM SHAFT FRONT |
| 03903 3915 | 32114-Y4000 | 30 x 45 x 8 | VANETTE SERENA C23 | 91/6~99/ | Transmission (M/T) FRONT COVER |
| 03903 2129 | 13207-5L300 | | VANETTE SERENA YD25DDTI(IN.) | 99/6~02/ | Engine VALVE STEM SEAL |
| 03903 5179 | 13207-53Y00 | | VANETTE SERENA GA16D# | 91/6~ | Engine VALVE STEM SEAL |
| 03903 4881 | 13207-D4200 | | VANETTE SERENA YD25DDTI(EX.0 | 99/6~02/ | Engine VALVE STEM SEAL |
| 03903 5713 | 13207-D4200 | | VANETTE SERENA SR20DE,QR20DE,QR25DE | 91/6~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 3719 | 13207-D0101 | | VANETTE SERENA CD20# | 91/6~ | Engine VALVE STEM SEAL |
| 03903 4079 | 12279-AD205 | 84 x 104 x 8.5 | VANETTE SERENA C24 SR20DE,QR20DE,QR25DE, YD25DDTI | 99/6~ | Engine CRANK SHAFT REAR |
| 03903 5857 | 12279-AD205 | 84 x 104 x 8.5 | VANETTE SERENA C23 GA16D#,SR20DE,CD20# | 98/1~99/ | Engine CRANK SHAFT REAR |
| 03903 2793 | 12279-85Y00 | 84 x 104 x 11 | VANETTE SERENA C23 GA16D#,SR20DE,CD20# | 91/6~98/1 | Engine CRANK SHAFT REAR |
| 03903 3757 | 13510-2J200 | 46 x 58 x 7 | VANETTE SERENA C24 SR20DE | 00/6~01/12 | Engine CRANK SHAFT FRONT |
| 03903 1483 | 13510-53J00 | 46 x 58 x 7 | VANETTE SERENA C23 SR20DE | 91/6~99/ | Engine CRANK SHAFT FRONT |
| 03903 2813 | 13510-53J00 | 46 x 58 x 7 | VANETTE SERENA C24 SR20DE | 99/6~00/6 | Engine CRANK SHAFT FRONT |
| 03903 4945 | 13042-16A11 | 36 x 50 x 8 | VANETTE SERENA C23 CD20# | 91/6~99/ | Engine CAM SHAFT REAR |
| 03903 3449 | 38342-06R01 | 52 x 78 x 9 | VANETTE SERENA C24 QR20DE(R4) | 01/12~ | Transmission (A/T) CONVERTER HOUSING |
| 03903 2019 | 49365-10V26 | | VANETTE SERENA C23 | 91/6~99/ | Steering (P/S) WORM GEAR KIT |
| 03903 2043 | 48125-0C000 | | VANETTE SERENA C23 | 91/6~99/ | Steering SECTOR SHAFT |
| 03903 4559 | 38342-4N500 | 38 x 55 x 8 x 13.5 | VANETTE SERENA C24 4WD | 99/6~ | Final Drive DIFF.SIDE |
| 03903 3189 | 38342-N3100 | 35 x 55 x 11 x 18 | VANETTE SERENA C23 SR20DE,CD20T | 91/6~99/ | Final Drive DIFF.SIDE |
| 03903 1105 | 38189-4N500 | 32.5 x 57 x 9 x 17 | VANETTE SERENA C24 4WD | 99/6~ | Final Drive PINION |
| 03903 6235 | 38189-N3112 | 40 x 75 x 13.5 x 21 | VANETTE SERENA C23 SR20DE,CD20T | 91/6~99/ | Final Drive PINION |
| 03903 3777 | 38189-P0117 | 45 x 75 x 14 x 19.5 | VANETTE SERENA C23 GA16D#,CD20 | 91/6~99/ | Final Drive PINION |
| 03903 2071 | 38342-8E001 | 32.5 x 56 x 8 x 14 | VANETTE SERENA C24 CVT | 01/12~ | Transmission (A/T) CONVERTER HOUSING |
| 03903 2569 | 38342-8E001 | 32.5 x 56 x 8 x 14 | VANETTE SERENA C24 CVT(2WD) | 00/5~01/12 | Transmission (A/T) CONVERTER HOUSING |
| 03903 6343 | 38342-81X01 | 33 x 59 x 9 x 15.6 | VANETTE SERENA C24 QR25DE | 01/12~ | Transmission (A/T) CONVERTER HOUSING |
| 03903 3383 | 38342-81X01 | 33 x 59 x 9 x 15.6 | VANETTE SERENA C24 R4(2WD) | 00/9~01/12 | Transmission (A/T) CONVERTER HOUSING |
| 03903 4587 | 13042-16V00 | 40 x 52 x 7 | VANETTE SERENA C23 GA16D#,CD20# | 91/6~99/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.3 NISSAN / DATSUN

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03903 1027 | 38342-03E00 | 39 x 59 x 11 x 17 | VANETTE SERENA C24 R4 | 99/6~00/6 | Transmission (A/T) MISSION CASE |
| 03903 3247 | 12279-AD205 | 84 x 104 x 8.5 | X-TRAIL T30 SR20VET,QR20DE | 00/10~ | Engine CRANK SHAFT REAR |
| 03903 3587 | 13207-D4200 | | X-TRAIL T30 QR20DE | 00/10~ | Engine VALVE STEM SEAL |
| 03903 1603 | 13510-2J200 | 46 x 58 x 7 | X-TRAIL T30 SR20VET,QR20DE | 00/10~ | Engine CRANK SHAFT FRONT |
| 03903 3813 | 38342-4N500 | 38 x 55 x 8 x 13.5 | X-TRAIL T30 | 00/10~ | Final Drive DIFF. SIDE |
| 03903 4537 | 38189-8H510 | 50 x 72 x 10 | X-TRAIL T30 | 00/10~ | Final Drive PINION REAR |
| 03903 4317 | 38189-8H500 | 32.5 x 57 x 9 x 17.5 | X-TRAIL T30 | 00/10~ | Final Drive PINION FRONT |
| 03903 1519 | 38342-06R01 | 52 x 78 x 9 | X-TRAIL T30(4WD) | 00/10~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 3707 | 38342-81X01 | 33 x 59 x 9 x 15.6 | X-TRAIL T30(2WD) | 00/10~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03903 4607 | 38342-81X00 | 39 x 59 x 8 x 13.7 | X-TRAIL T30 | 00/10~ | Mission & Differential (A/T) MISSION CASE |
| 03903 6005 | 38342-06R01 | 52 x 78 x 9 | X-TRAIL T30 | 00/10~ | Mission & Differential (M/T) CLUTCH HOUSING |
| 03903 3535 | 38342-8H500 | 39 x 59 x 8 x 13.7 | X-TRAIL T30 | 02/12~ | Mission & Differential (M/T) MISSION CASE |
| 03903 4735 | 38342-03E00 | 39 x 59 x 11 x 17 | X-TRAIL T30 | 00/10~02/12 | Mission & Differential (M/T) MISSION CASE |
| 03903 5423 | 32113-8H500 | 27 x 42 x 7 | X-TRAIL T30 | 00/10~ | Mission & Differential (M/T) INPUT SHAFT |
| 03903 2439 | 13207-8H600 | | X-TRAIL T30 SR20VET | 00/10~03/6 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 8123 | 55515-00Z00 | 145 X 175 X 15.5 | CD TRUCK (2XD-4) CD | 77/~ | Trunnion SHAFT |
| 03904 4075 | 38189-90018 | 80 X 135 X 15 X 25.5 | CD TRUCK (2XD-4) CD3#,4#,5#,6# | 95/2~ | Differential PINION |
| 03904 6132 | 43090-90060 | 154 X 175 X 13 | CD TRUCK (2XD-4) CD48,53,55 | 01/1~ | Wheel Hub REAR INNER (F&R) |
| 03904 5538 | 43090-90000 | 124 X 170 X 14.5 | CD TRUCK (2XD-4) CD3#,4#,5# | 72/~85/5 | Wheel Hub REAR INNER (F&R) |
| 03904 3679 | 43090-Z5000 | 130 X 150 X 10 | CD TRUCK (2XD-4) CD32,45,46,47,48,52,53,54,55 | 89/10~ | Wheel Hub FRONT |
| 03904 5626 | 43090-Z5000 | 130 X 150 X 10 | CD TRUCK (2XD-4) CD3#,4#,5# | 72/~89/9 | Wheel Hub FRONT |
| 03904 2898 | 32219-90018 | 56 X 72 X 9 | CD TRUCK (2XD-4) CD MPS6 | 86/2~89/12 | Transmission FRONT |
| 03904 6242 | 32219-90018 | 56 X 72 X 9 | CD TRUCK (2XD-4) CD MTS6,7,ART2 | 86/2~ | Transmission FRONT |
| 03904 7111 | 32219-90018 | 56 X 72 X 9 | CD TRUCK (2XD-4) CD ATS7 | 97/10~ | Transmission FRONT |
| 03904 1567 | 32219-90018 | 56 X 72 X 9 | CD TRUCK (2XD-4) CD ATS6 | 86/2~87/9 | Transmission FRONT |
| 03904 7661 | 38189-90016 | 80 X 135 X 12 X 26 | CD TRUCK (2XD-4) CD3#,4#,5#,6# | 72/1~95/1 | Differential PINION |
| 03904 4845 | 32219-90014 | 48 X 65 X 9 | CD TRUCK (2XD-4) CD | 72/~83/ | Transmission FRONT |
| 03904 1369 | 43090-90060 | 154 X 175 X 13 | CD TRUCK (2XD-4) CD46,47,53,54 | 85/5~90/ | Wheel Hub REAR INNER (F&R) |
| 03904 2436 | 55515-Z3000 | 130 X 160 X 14 | CD TRUCK (2XD-4) CD | 72/~77/ | Trunnion SHAFT |
| 03904 7353 | 38212-00Z01 | 74 X 156 X 14 X 22 | CD TRUCK (2XD-4) CD32,45,48,52,53,55 | 94/4~ | Wheel Hub REAR OUTER (F) |
| 03904 1809 | 38212-90013 | 74 X 156 X 13 X 17.5 | CD TRUCK (2XD-4) CD320,450,510,520,530,620 | 89/10~95/ | Wheel Hub REAR OUTER (F) |
| 03904 3954 | 38212-90006 | 60 X 72 X 7.5 | CD TRUCK (2XD-4) CD46,47,53,54 | 89/10~90/ | Wheel Hub REAR OUTER (F) |
| 03904 7628 | 38212-90006 | 60 X 72 X 7.5 | CD TRUCK (2XD-4) CD3#,4#,5# | 72/~89/9 | Wheel Hub REAR OUTER (F) |
| 03904 5802 | 32219-90018 | 56 X 72 X 9 | CD TRUCK (2XD-4) CD MPS6,7 | 99/1~ | Transmission FRONT |
| 03904 2744 | 43090-00Z00 | 154 X 175 X 13.5 | CD TRUCK (2XD-4) CD32,45,48,52,53,55 GREASE HUB | 94/4~00/12 | Wheel Hub REAR INNER (F&R) |
| 03904 1215 | 43090-00Z00 | 154 X 175 X 13.5 | CD TRUCK (2XD-4) CD320,450,510,520,620 GREASE HUB | 89/10~95/ | Wheel Hub REAR INNER (F&R) |
| 03904 2183 | 32219-90014 | 48 X 65 X 9 | CD TRUCK (2XD-4) CD ATS6 | 87/10~96/ | Transmission FRONT |
| 03904 3008 | 32136-NA001 | 90 X 115 X 14 | CD TRUCK (2XD-4) CD48,53,55 ART2 | 02/7~ | Transmission REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4856 | 32219-90073 | 56 X 72 X 10 | CD TRUCK (2XD-4) CD MPS6,7 | 90/1~98/12 | Transmission FRONT |
| 03904 2524 | 32136-90062 | 70 X 88 X 12 | CD TRUCK (2XD-4) CD3#,4#,5# | 72/~85/ | Transmission REAR |
| 03904 8112 | 32136-90062 | 70 X 88 X 12 | CD TRUCK (2XD-4) CD46,53,54 MPS6 | 86/2~90/ | Transmission REAR |
| 03904 2315 | 32136-90106 | 70 X 88 X 11 | CD TRUCK (2XD-4) CD32,45,48,52,53,55 MPS6,7 | 92/1~ | Transmission REAR |
| 03904 6407 | 32136-90106 | 70 X 88 X 11 | CD TRUCK (2XD-4) CD320,450,510,520,530,620 MPS6,7 | 88/5~96/ | Transmission REAR |
| 03904 2645 | 32136-90107 | 80 X 100 X 13 | CD TRUCK (2XD-4) CD32,45,46,48,52,53,54,55 MTS6,7,ATS6,7 | 86/2~02/6 | Transmission REAR |
| 03904 3569 | 43090-Z5000 | 130 X 150 X 10 | CD TRUCK (2XD-4) CD320,450,520,530,620 GREASE HUB | 89/10~95/ | Wheel Hub FRONT |
| 03904 1578 | 32136-90061 | 90 X 115 X 13 | CD TRUCK (2XD-4) CD45,48,52,53,55 ART2 | 97/10~02/6 | Transmission REAR |
| 03904 5307 | 37526-90003 | 80 X 110 X 10 X 16 | CD TRUCK (2XD-4) CD | 90/~ | Propeller Shaft CENTER BEARING |
| 03904 3646 | 32136-NA002 | 80 X 100 X 14 | CD TRUCK (2XD-4) CD48,53,55 MTS6,7,ATS7 | 02/7~ | Transmission REAR |
| 03904 3085 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD33,43,51 | 72/~79/ | Propeller Shaft CENTER BEARING |
| 03904 2920 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD45 TMH460(C/#~019999) | 79/~83/ | Propeller Shaft CENTER BEARING |
| 03904 6605 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD52 PS410 | 79/~83/ | Propeller Shaft CENTER BEARING |
| 03904 3789 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD53 F/R5.571 | 83/~86/ | Propeller Shaft CENTER BEARING |
| 03904 4625 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD46 F/R5.143,5.571 | 84/~86/ | Propeller Shaft CENTER BEARING |
| 03904 6627 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD46,47,53,54 | 86/~89/ | Propeller Shaft CENTER BEARING |
| 03904 1380 | 37526-90002 | 60 X 82 X 12 | CD TRUCK (2XD-4) CD45 TMH600(C/3~019999) | 79/~83/ | Propeller Shaft CENTER BEARING |
| 03904 6165 | 37526-90002 | 60 X 82 X 12 | CD TRUCK (2XD-4) CD46 F/R4.625,4.875 | 84/~86/ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 3404 | 37526-90002 | 60 X 82 X 12 | CD TRUCK (2XD-4) CD53 F/R5.143,5.857 | 83/~86/ | Propeller Shaft CENTER BEARING |
| 03904 2887 | 37526-90002 | 60 X 82 X 12 | CD TRUCK (2XD-4) CD45 TMH460 F/R4.875 | 83/~84/ | Propeller Shaft CENTER BEARING |
| 03904 7045 | 37526-90000 | 55 X 75 X 12 | CD TRUCK (2XD-4) CD45 TMH460 F/R5.143 | 83/~84/ | Propeller Shaft CENTER BEARING |
| 03904 2788 | 32136-90107 | 80 X 100 X 13 | CD TRUCK (2XD-4) CD320,450,510,520,530,620 MTS6,7,ATS6 | 88/4~96/ | Transmission REAR |
| 03904 8090 | 37526-90002 | 60 X 82 X 12 | CD TRUCK (2XD-4) CD52 PS510 | 79/~83/ | Propeller Shaft CENTER BEARING |
| 03904 6649 | 32219-90018 | 56 X 72 X 9 | CF TRUCK (4WD) CF52,53,55,520 | 89/3~ | Transmission FRONT |
| 03904 5219 | 1-09625-017-0 | 68 X 124 X 11.5 X 27 | CF TRUCK (4WD) CF52 GHHR,GHH5 | 95/11~00/ | Differential PINION |
| 03904 3503 | 38189-90019 | 80 X 135 X 15 X 24.5 | CF TRUCK (4WD) CF52,520 HYPOYD | 95/2~01/ | Differential PINION |
| 03904 2843 | 43090-90060 | 154 X 175 X 13 | CF TRUCK (4WD) CF46 | 85/5~90/ | Wheel Hub REAR INNER |
| 03904 4647 | 38189-90018 | 80 X 135 X 15 X 25.5 | CF TRUCK (4WD) CF52,53,55,520 LARGE HYPOYD | 95/2~ | Differential PINION |
| 03904 6572 | 38189-90016 | 80 X 135 X 12 X 26 | CF TRUCK (4WD) CF52,520 | 88/6~95/1 | Differential PINION |
| 03904 3162 | 32136-90061 | 90 X 115 X 13 | CF TRUCK (4WD) CF52,53,55,520 | 89/3~ | Transmission REAR |
| 03904 7694 | 38212-00Z01 | 74 X 156 X 14 X 22 | CF TRUCK (4WD) CF52,53,55,520 | 95/1~ | Wheel Hub REAR OUTER |
| 03904 6187 | 38212-90013 | 74 X 156 X 13 X 17.5 | CF TRUCK (4WD) CF520 | 90/4~94/12 | Wheel Hub REAR OUTER |
| 03904 6957 | 37526-90000 | 55 X 75 X 12 | CF TRUCK (4WD) CF52,520 | 90/6~00/ | Propeller Shaft CENTER BEARING |
| 03904 3492 | 43090-00Z00 | 154 X 175 X 13.5 | CF TRUCK (4WD) CF52,53,55 | 95/6`00/12 | Wheel Hub REAR INNER |
| 03904 4460 | 1-09625-309-0 | 150 X 180 X 14 | CF TRUCK (4WD) CF52 GHHR,GHH5 | 95/11~00/ | Wheel Hub FRONT |
| 03904 7078 | 55515-90000 | 120 X 150 X 14 | CF TRUCK (4WD) CF52..EXCEPT GHHR,GHH5 | 95/6~00/ | Wheel Hub FRONT |
| 03904 4394 | 55515-90000 | 120 X 150 X 14 | CF TRUCK (4WD) CF45,46,520 | 80/7~00/ | Wheel Hub FRONT |
| 03904 6682 | 43090-90060 | 154 X 175 X 13 | CF TRUCK (4WD) CF53,55 | 01/1~ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7837 | 43090-00Z00 | 154 X 175 X 13.5 | CF TRUCK (4WD) CF520 | 90/4~95/ | Wheel Hub REAR INNER |
| 03904 6847 | 38212-90006 | 60 X 72 X 7.5 | CF TRUCK (4WD) CF45,46 | 80/7~90/ | Wheel Hub REAR OUTER |
| 03904 6341 | 43090-90000 | 124 X 170 X 14.5 | CF TRUCK (4WD) CF45,46 | 80/7~85/5 | Wheel Hub REAR INNER |
| 03904 4867 | 40227-Z5001 | 100 X 114 X 12 | CG TRUCK (2-2XD-D) CG48X,55A,X | 94/11~ | Wheel Hub FRONT (REARWARD) |
| 03904 8035 | 40227-Z5001 | 100 X 114 X 12 | CG TRUCK (2-2XD-D) CG55X | 99/10~ | Wheel Hub FRONT (FORWARD) |
| 03904 3448 | 43090-Z5000 | 130 X 150 X 10 | CG TRUCK (2-2XD-D) CG45,52,53,55A,C | 94/11~00/ | Wheel Hub FRONT (FORWARD) |
| 03904 7375 | 43090-90060 | 154 X 175 X 13 | CG TRUCK (2-2XD-D) CG48Z,55Y,Z EXCEPT LOW DECK | 01/1~ | Wheel Hub REAR INNER (F&R) |
| 03904 3723 | 43090-Z5000 | 130 X 150 X 10 | CG TRUCK (2-2XD-D) CG320,450,520 | 88/8~00/ | Wheel Hub FRONT (FORWARD) |
| 03904 3833 | 40227-90012 | 124 X 146 X 14 | CG TRUCK (2-2XD-D) CG48,55Y,Z | 99/10~ | Wheel Hub FRONT (FORWARD) |
| 03904 2810 | 40227-Z5001 | 100 X 114 X 12 | CG TRUCK (2-2XD-D) CG45,53 20T,22T | 94/11~00/ | Wheel Hub FRONT (REARWARD) |
| 03904 2854 | 40227-Z5001 | 100 X 114 X 12 | CG TRUCK (2-2XD-D) CG320,450,520 | 88/8~00/ | Wheel Hub FRONT (REARWARD) |
| 03904 5362 | 43090-Z5000 | 130 X 150 X 10 | CG TRUCK (2-2XD-D) CG45,53 25T | 95/2~00/ | Wheel Hub FRONT (REARWARD) |
| 03904 3052 | 43090-Z5000 | 130 X 150 X 10 | CG TRUCK (2-2XD-D) CG55C | 95/2~00/ | Wheel Hub FRONT (REARWARD) |
| 03904 2986 | 40227-Z5001 | 100 X 114 X 12 | CG TRUCK (2-2XD-D) CG52 | 94/11~00/ | Wheel Hub FRONT (REARWARD) |
| 03904 1589 | 40227-90012 | 124 X 146 X 14 | CG TRUCK (2-2XD-D) CG48Y,Z,55Y,Z | 99/10~ | Wheel Hub FRONT (REARWARD) |
| 03904 5549 | 43090-Z5001 | 127 X 146 X 10 | CG TRUCK (2-2XD-D) CG27,45A,B,48X,Y,52,53 A,B,X,55A,X | 94/11~ | Wheel Hub REAR INNER (F&R) |
| 03904 2876 | 43090-Z5001 | 127 X 146 X 10 | CG TRUCK (2-2XD-D) CG320,450,520 | 88/8~00/ | Wheel Hub REAR INNER (F&R) |
| 03904 1952 | 38212-00Z01 | 74 X 156 X 14 X 22 | CG TRUCK (2-2XD-D) CG45C,53C C/#~10000 | 95/2~96/ | Wheel Hub REAR OUTER (F&R) |
| 03904 2634 | 32136-NA002 | 80 X 100 X 14 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5#...MTS6,7, ATS7 | 02/7~ | Transmission REAR |
| 03904 2491 | 32136-90107 | 80 X 100 X 13 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5#...MTS6,7, ATS7 | 88/5~02/6 | Transmission REAR |
| 03904 3030 | 32136-90106 | 70 X 88 X 11 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5#...MPS6,7, APS7 | 89/8~ | Transmission REAR |
| 03904 6528 | 32219-90073 | 56 X 72 X 10 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5#...MPS6,7 | 88/5~98/7 | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7133 | 32219-90018 | 56 X 72 X 9 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5#...MPS6,7 | 98/8~ | Transmission FRONT |
| 03904 3734 | 32219-90018 | 56 X 72 X 9 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5#...MTS6,7, ATS7 | 89/2~ | Transmission FRONT |
| 03904 2216 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5# | 88/8~93/2 | Differential PINION |
| 03904 6638 | 55515-00Z00 | 145 X 175 X 15.5 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5# | 89/12~ | Trunnion SHAFT |
| 03904 2095 | 43090-Z5001 | 127 X 146 X 10 | CG TRUCK (2-2XD-D) CG45C,53C C/# 10001~ | 95/11~00/ | Wheel Hub REAR INNER (F&R) |
| 03904 5395 | 38212-00Z01 | 74 X 156 X 14 X 22 | CG TRUCK (2-2XD-D) CG48Z,55Y,Z EXCEPT LOW DECK | 99/10~ | Wheel Hub REAR OUTER (F&R) |
| 03904 5120 | 43090-Z5001 | 127 X 146 X 10 | CG TRUCK (2-2XD-D) CG48Z,55Y,Z LOW DECK | 99/10~ | Wheel Hub REAR INNER (F&R) |
| 03904 6286 | 38212-Z5007 | 57 X 123 X 11 X 21 | CG TRUCK (2-2XD-D) CG48Z,55Y,Z LOW DECK | 99/10~ | Wheel Hub REAR OUTER (F&R) |
| 03904 3998 | 38212-Z5007 | 57 X 123 X 11 X 21 | CG TRUCK (2-2XD-D) CG45C,53C C/#10001~ | 95/11~00/ | Wheel Hub REAR OUTER (F&R) |
| 03904 2502 | 38212-Z5007 | 57 X 123 X 11 X 21 | CG TRUCK (2-2XD-D) CG27,45A,B,48X,Y,52,53 A,B,X,55A,X | 94/11~ | Wheel Hub REAR OUTER (F&R) |
| 03904 6869 | 38189-Z5005 | 60 X 114 X 12 X 24 | CG TRUCK (2-2XD-D) CG2#,3#,4#,5# | 93/3~ | Differential PINION |
| 03904 7155 | 38212-Z5000 | 47 X 56 X 7 | CG TRUCK (2-2XD-D) CG320,450,520 | 88/8~01/ | Wheel Hub REAR OUTER (F&R) |
| 03904 7287 | 43090-00Z00 | 154 X 175 X 13.5 | CG TRUCK (2-2XD-D) CG55C | 95/2~00/ | Wheel Hub REAR INNER (F&R) |
| 03904 7166 | 43090-00Z00 | 154 X 175 X 13.5 | CG TRUCK (2-2XD-D) CG48Z,55Y,Z EXCEPT LOW DECK | 99/10~00/ 12 | Wheel Hub REAR INNER (F&R) |
| 03904 6924 | 43090-00Z00 | 154 X 175 X 13.5 | CG TRUCK (2-2XD-D) CG45C,53C C/#~10000 | 95/2~96/ | Wheel Hub REAR INNER (F&R) |
| 03904 7584 | 37526-90003 | 80 X 110 X 10 X 16 | CG TRUCK (2-2XD-D) CG27,45,48,52,53,55 | 93/12 | Propeller Shaft CENTER BEARING |
| 03904 6121 | 38212-00Z01 | 74 X 156 X 14 X 22 | CG TRUCK (2-2XD-D) CG55C | 95/2~00/ | Wheel Hub REAR OUTER (F&R) |
| 03904 5692 | 38212-90008 | 51 X 62 X 7 | CK TRUCK / TRACTOR CK85,86 | 79/6~ | Wheel Hub REAR OUTER |
| 03904 6308 | 43090-58000 | 95 X 135 X 13 | CK TRUCK / TRACTOR CK10 | 70/1~79/ | Wheel Hub REAR INNER |
| 03904 2975 | 32219-90002 | 42 X 65 X 9 | CK TRUCK / TRACTOR CK15,20 | 70/~76/2 | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7408 | 38212-90006 | 60 X 72 X 7.5 | CK TRUCK / TRACTOR CK55#...SPIDER HUB | 00/1~ | Wheel Hub REAR OUTER |
| 03904 2128 | 38212-90006 | 60 X 72 X 7.5 | CK TRUCK / TRACTOR CK15,20,3#,4#,5#,6# | 70/1~90/ | Wheel Hub REAR OUTER |
| 03904 2238 | 38212-58001 | 45 X 55 X 10 | CK TRUCK / TRACTOR CK10 | 70/1~79/ | Wheel Hub REAR OUTER |
| 03904 1281 | 43090-00Z00 | 154 X 175 X 13.5 | CK TRUCK / TRACTOR CK481,551B.D.E EXCEPT SPIDER HUB | 95/3~ | Wheel Hub REAR INNER |
| 03904 4042 | 43090-00Z00 | 154 X 175 X 13.5 | CK TRUCK / TRACTOR CK52,53,451,482,521,531, 541,542,552B.D.E.K,631,6 32 | 94/11~00/ 12 | Wheel Hub REAR INNER |
| 03904 5571 | 43090-00Z00 | 154 X 175 X 13.5 | CK TRUCK / TRACTOR CK450,520,540,610,620 GREASE HUB | 89/12~95/ | Wheel Hub REAR INNER |
| 03904 6451 | 38212-00Z01 | 74 X 156 X 14 X 22 | CK TRUCK / TRACTOR CK5#,45#,48#,52#,53#,54 #,61#,62#,63# | 95/1~ | Wheel Hub REAR OUTER |
| 03904 3151 | 43090-90060 | 154 X 175 X 13 | CK TRUCK / TRACTOR CK31,46,51,54,60,66,67 | 85/5~90/ | Wheel Hub REAR INNER |
| 03904 5890 | 43235-50000 | 101 X 121 X 8 | CK TRUCK / TRACTOR CK10 | 70/1~79/ | Wheel Hub REAR AXLE END |
| 03904 1886 | 43090-90012 | 140 X 170 X 14 | CK TRUCK / TRACTOR CK85,86 | 79/6~ | Wheel Hub REAR INNER |
| 03904 1358 | 43090-90000 | 124 X 170 X 14.5 | CK TRUCK / TRACTOR CK15,20,3#,4#,5#,6# | 70/1~85/5 | Wheel Hub REAR INNER |
| 03904 4449 | 40227-90012 | 124 X 146 X 14 | CK TRUCK / TRACTOR CK86 | 80/12~ | Wheel Hub FRONT |
| 03904 7430 | 43090-Z5000 | 130 X 150 X 10 | CK TRUCK / TRACTOR CK52,53,451,48#,521,531, 541,542,55#,63# | 90/1~ | Wheel Hub FRONT |
| 03904 3261 | 43090-Z5000 | 130 X 150 X 10 | CK TRUCK / TRACTOR CK450,520,540,610,620 GREASE HUB | 90/1~95/ | Wheel Hub FRONT |
| 03904 6495 | 43090-Z5000 | 130 X 150 X 10 | CK TRUCK / TRACTOR CK1#,2#,3#,4#,5#,6# | 70/1~90/ | Wheel Hub FRONT |
| 03904 1325 | 40232-C0400 | 85 X 111 X 10 | CK TRUCK / TRACTOR CK85 | 79/6~80/ | Wheel Hub FRONT |
| 03904 3360 | 43090-90060 | 154 X 175 X 13 | CK TRUCK / TRACTOR CK53,482,542,552B.D.E. K,632 | 01/1~ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7639 | 32219-90018 | 56 X 72 X 9 | CK TRUCK / TRACTOR CK31,46,54,66,67 17 INCH CLUTCH | 83/7~90/ | Transmission FRONT |
| 03904 7760 | 32136-C0400 | 55 X 70 X 9 | CK TRUCK / TRACTOR CK85 TMH260 | 79/6~80/ | Transmission REAR |
| 03904 2678 | 32136-C0400 | 55 X 70 X 9 | CK TRUCK / TRACTOR CK10 | 70/~79/ | Transmission REAR |
| 03904 1468 | 32136-90062 | 70 X 88 X 12 | CK TRUCK / TRACTOR CK4#,5#,6#...TMH600 | 75/~87/ | Transmission REAR |
| 03904 1996 | 32136-90062 | 70 X 88 X 12 | CK TRUCK / TRACTOR CK450,520 MPS5 | 89/1~95/ | Transmission REAR |
| 03904 6770 | 32136-90062 | 70 X 88 X 12 | CK TRUCK / TRACTOR CK15,20,31 | 70/~90/ | Transmission REAR |
| 03904 7188 | 32136-Z5000 | 58 X 75 X 9 | CK TRUCK / TRACTOR CK86 | 80/12~ | Transmission REAR |
| 03904 2084 | 32136-Z5000 | 58 X 75 X 9 | CK TRUCK / TRACTOR CK85 TMH750 | 79/6~80/ | Transmission REAR |
| 03904 1853 | 38212-90013 | 74 X 156 X 13 X 17.5 | CK TRUCK / TRACTOR CK5#,45#,52#,54#,61#,62# | 90/1~94/12 | Wheel Hub REAR OUTER |
| 03904 5428 | 32219-90018 | 56 X 72 X 9 | CK TRUCK / TRACTOR CK4#,5#,6#...MTS6#,7#, MTPO,MRT2#,ART2#,ATS7# | 89/~ | Transmission FRONT |
| 03904 4911 | 38212-00Z01 | 74 X 156 X 14 X 22 | CK TRUCK / TRACTOR CK55#...EXCEPT SPIDER HUB | 00/1~ | Wheel Hub REAR OUTER |
| 03904 4482 | 32219-90018 | 56 X 72 X 9 | CK TRUCK / TRACTOR CK450,520 MPS5 | 89/1~94/ | Transmission FRONT |
| 03904 1633 | 32115-C0400 | 58 X 75 X 9 | CK TRUCK / TRACTOR CK85 TMH260 | 79/6~80/ | Transmission FRONT |
| 03904 5450 | 32219-90014 | 48 X 65 X 9 | CK TRUCK / TRACTOR CK31 MPS5 | 86/5~90/ | Transmission FRONT |
| 03904 3283 | 32219-90014 | 48 X 65 X 9 | CK TRUCK / TRACTOR CK31,46,54,66,67 16 INCH CLUTCH | 83/7~90/ | Transmission FRONT |
| 03904 7276 | 32219-90014 | 48 X 65 X 9 | CK TRUCK / TRACTOR CK15,20,40,45,50,60 | 76/3~89/ | Transmission FRONT |
| 03904 1974 | 32219-Z5003 | 32 X 45 X 8 | CK TRUCK / TRACTOR CK86 | 80/12~ | Transmission FRONT |
| 03904 4790 | 32219-Z5003 | 32 X 45 X 8 | CK TRUCK / TRACTOR CK85 TMH750 | 79/6~80/ | Transmission FRONT |
| 03904 5857 | 32136-90106 | 70 X 88 X 11 | CK TRUCK / TRACTOR CK4#,5#,6#...MPS6#,7# | 88/5~ | Transmission REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 2777 | 32219-90073 | 56 X 72 X 10 | CK TRUCK / TRACTOR CK52,450,520,521,531 MPS6#,7# | 88/5~97/ | Transmission FRONT |
| 03904 2535 | 38189-90103 | 70 X 115 X 14 X 20 | CK TRUCK / TRACTOR CK45,50,60 EXCEPT PLANETARY | 77/~83/ | Differential PINION |
| 03904 1875 | 32115-C0400 | 58 X 75 X 9 | CK TRUCK / TRACTOR CK10 | 70/~79/ | Transmission FRONT |
| 03904 3173 | 38189-90018 | 80 X 135 X 15 X 25.5 | CK TRUCK / TRACTOR CK52,53,450,520,521,531 | 95/2~01/ | Differential PINION |
| 03904 5758 | 32136-90107 | 80 X 100 X 13 | CK TRUCK / TRACTOR CK4#,5#,6#...MTS6#,7#, MTPO,ATS75 | 87/~02/6 | Transmission REAR |
| 03904 5065 | 38189-90016 | 80 X 135 X 12 X 26 | CK TRUCK / TRACTOR CK45,50,60 PLANETARY | 77/~83/ | Differential PINION |
| 03904 2040 | 38189-90016 | 80 X 135 X 12 X 26 | CK TRUCK / TRACTOR CK46,51,54,66,67 | 83/~90/ | Differential PINION |
| 03904 2381 | 38189-90016 | 80 X 135 X 12 X 26 | CK TRUCK / TRACTOR CK52,450,520,531,540,61 0,620 | 88/6~95/1 | Differential PINION |
| 03904 1171 | 38189-90016 | 80 X 135 X 12 X 26 | CK TRUCK / TRACTOR CK31 | 79/10~90/ | Differential PINION |
| 03904 1424 | 38189-90016 | 80 X 135 X 12 X 26 | CK TRUCK / TRACTOR CK20(HYPOID) C/# 021942~ | 77/~79/ | Differential PINION |
| 03904 5989 | 38189-90007 | 85 X 125 X 14 | CK TRUCK / TRACTOR CK40 HYPOID | 75/~79/ | Differential PINION |
| 03904 3316 | 38189-90007 | 85 X 125 X 14 | CK TRUCK / TRACTOR CK15,20DD C/#~021941 | 70/~77/ | Differential PINION |
| 03904 6825 | 38189-90002 | 70 X 115 X 15 | CK TRUCK / TRACTOR CK40 EXCEPT HYPOID | 75/~79/ | Differential PINION |
| 03904 5230 | 32136-NA001 | 90 X 115 X 14 | CK TRUCK / TRACTOR CK4#,5#,6#...ART2#,MR T2# | 02/7~ | Transmission REAR |
| 03904 4878 | 38189-50000 | 64 X 85 X 12 | CK TRUCK / TRACTOR CK10 | 70/~79/ | Differential PINION |
| 03904 6946 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | CK TRUCK / TRACTOR CK85,86 | 79/6~ | Differential PINION |
| 03904 4779 | 37526-90002 | 60 X 82 X 12 | CK TRUCK / TRACTOR CK31 TMH600 | 79/10~90/ | Propeller Shaft CENTER BEARING |
| 03904 6110 | 37526-90000 | 55 X 75 X 12 | CK TRUCK / TRACTOR CK31 TMH400 | 79/10~90/ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 6473 | 37526-90000 | 55 X 75 X 12 | CK TRUCK / TRACTOR CK20 | 70/~79/ | Propeller Shaft CENTER BEARING |
| 03904 3118 | 37520-58000 | 52 X 80 X 8 | CK TRUCK / TRACTOR CK10,15 | 70/~79/ | Propeller Shaft CENTER BEARING |
| 03904 2590 | 32136-NA002 | 80 X 100 X 14 | CK TRUCK / TRACTOR CK4#,5#,6#...ATS7#,MTS 7# | 02/7~ | Transmission REAR |
| 03904 3987 | 32136-90061 | 90 X 115 X 13 | CK TRUCK / TRACTOR CK4#,5#,6#...ART2#,MR T2# | 92/9~02/6 | Transmission REAR |
| 03904 7771 | 38189-90002 | 70 X 115 X 15 | CK TRUCK / TRACTOR CK20L,N,R,T,D,G,GL,M | 70/~79/ | Differential PINION |
| 03904 5417 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) LK21#,25#,26#,LF260,MF 260 | 93/3~ | Wheel Hub REAR INNER |
| 03904 3580 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,25#,26#,2 81 | 91/10~99/ | Wheel Hub REAR INNER |
| 03904 2293 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) CM86,87,88,89,CL8#,NK 110 | 83/5~95/ | Wheel Hub REAR INNER |
| 03904 1611 | 43090-Z5000 | 130 X 150 X 10 | CONDOR TRUCK (3.5T~7T) CM80,84,85,90 | 74/9~83/ | Wheel Hub REAR INNER |
| 03904 4636 | FA45A-375A0 | 106 X 122 X 10 | CONDOR TRUCK (3.5T~7T) LK262,26A,MK262,26A LOW DECK 4WD | 99/5~ | Wheel Hub FRONT |
| 03904 6209 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PK251 C/#~20000 7T LOW DECK | 97/3~ | Wheel Hub REAR INNER |
| 03904 3393 | 40227-90012 | 124 X 146 X 14 | CONDOR TRUCK (3.5T~7T) PK260 DOUBLE CAB | 95/6~ | Wheel Hub FRONT |
| 03904 3514 | 43090-90060 | 154 X 175 X 13 | CONDOR TRUCK (3.5T~7T) CP8# | 85/2~93/ | Wheel Hub REAR INNER |
| 03904 3305 | 40227-90012 | 124 X 146 X 14 | CONDOR TRUCK (3.5T~7T) PK251 C/#~20000 EXCEPT 7T LOW DECK | 95/6~98/ | Wheel Hub FRONT |
| 03904 4372 | FA45A-375A0 | 106 X 122 X 10 | CONDOR TRUCK (3.5T~7T) LF260,MF260 | 97/9~ | Wheel Hub FRONT |
| 03904 2568 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PK251,260 C/# 20001~ EXCEPT REAR AXLE 9.5T | 97/3~ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 3844 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PK252(13T),25A(13T),262(13T) LOW DECK | 99/7~ | Wheel Hub REAR INNER |
| 03904 7870 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PK260 C/#~20000 SINGLE CAB | 94/9~98/ | Wheel Hub REAR INNER |
| 03904 7529 | 43090-00Z00 | 154 X 175 X 13.5 | CONDOR TRUCK (3.5T~7T) PK210,211,250,251(8T) | 93/3~ | Wheel Hub REAR INNER |
| 03904 6319 | 43090-90012 | 140 X 170 X 14 | CONDOR TRUCK (3.5T~7T) LF210,211,MF210,211 | 94/4~ | Wheel Hub REAR INNER |
| 03904 2656 | 43090-90060 | 154 X 175 X 13 | CONDOR TRUCK (3.5T~7T) PK252(15T),25A(15T),262(15T) LOW DECK | 01/1~ | Wheel Hub REAR INNER |
| 03904 7617 | 43090-90060 | 154 X 175 X 13 | CONDOR TRUCK (3.5T~7T) PK26A(15T) SINGLE CAB AND LOW DECK | 02/4~ | Wheel Hub REAR INNER |
| 03904 7606 | 43090-90060 | 154 X 175 X 13 | CONDOR TRUCK (3.5T~7T) PK26A DOUBLE CAB | 02/4~ | Wheel Hub REAR INNER |
| 03904 4834 | 40227-90012 | 124 X 146 X 14 | CONDOR TRUCK (3.5T~7T) CP8#,PK21#,PK250(7T) | 85/2~ | Wheel Hub FRONT |
| 03904 3536 | 43090-00Z00 | 154 X 175 X 13.5 | CONDOR TRUCK (3.5T~7T) PK251 C/#~20000 EXCEPT 7T LOW DECK | 95/6~98/ | Wheel Hub REAR INNER |
| 03904 5604 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PK26A(13T) SINGLE CAB AND LOW DECK | 02/4~ | Wheel Hub REAR INNER |
| 03904 5780 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) CL8#,CM8#,90,NK110 | 74/9~95/ | Wheel Hub FRONT |
| 03904 3624 | 32136-90106 | 70 X 88 X 11 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...MPS# | 91/11~96/ | Transmission REAR |
| 03904 2513 | 32136-90106 | 70 X 88 X 11 | CONDOR TRUCK (3.5T~7T) MK250,251,252,260 MPS# | 91/11~ | Transmission REAR |
| 03904 6814 | 32136-90062 | 70 X 88 X 12 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...MLS# | 92/4~02/ | Transmission REAR |
| 03904 1303 | 32136-90062 | 70 X 88 X 12 | CONDOR TRUCK (3.5T~7T) CP8#...MLS#,TMH781 | 84/12~01/ | Transmission REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 2733 | 32136-Z5003 | 65 X 78 X 9 | CONDOR TRUCK (3.5T~7T) LK21#,25#,26#...MKS#,MLS# | 93/3~ | Transmission REAR |
| 03904 6385 | 32136-Z5003 | 65 X 78 X 9 | CONDOR TRUCK (3.5T~7T) CL8#...MLS#,TMH780 | 84/7~01/ | Transmission REAR |
| 03904 7232 | 32136-Z5003 | 65 X 78 X 9 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,25#,26#,2B1 MKS#,MLS# | 91/10~ | Transmission REAR |
| 03904 3976 | 32136-Z5003 | 65 X 78 X 9 | CONDOR TRUCK (3.5T~7T) CM87,88 MLS# | 84/12~93/ | Transmission REAR |
| 03904 7243 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) LK21#,25#,260 | 93/3~ | Wheel Hub FRONT |
| 03904 2304 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) PK251,260 C/#20001~EXCEPT REAR AXLE 9.5T | 97/3~ | Wheel Hub REAR OUTER |
| 03904 7199 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) LF210,211,MF210,211 | 94/4~ | Wheel Hub FRONT |
| 03904 4658 | 43090-00Z00 | 154 X 175 X 13.5 | CONDOR TRUCK (3.5T~7T) PK251,260 C/# 20001~REAR AXLE 9.5T | 98/2~ | Wheel Hub REAR INNER |
| 03904 2392 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) LK262,MK262,26A EXCEPT LOW DECK 4WD | 99/5~ | Wheel Hub FRONT |
| 03904 2953 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) MK12#,130,21#,25#,260,26B,2B1 | 91/10~99/ | Wheel Hub FRONT |
| 03904 4053 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) PK251 C/#~20000 7T LOW DECK | 95/6~98/ | Wheel Hub FRONT |
| 03904 6517 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) PK251,260 C/# 20001~EXCEPT HEAVYDUTY | 97/3~ | Wheel Hub FRONT |
| 03904 7067 | 40227-Z5001 | 100 X 114 X 12 | CONDOR TRUCK (3.5T~7T) PK260 C/#~20000 SINGLE CAB | 94/9~98/ | Wheel Hub FRONT |
| 03904 1204 | 43090-Z5000 | 130 X 150 X 10 | CONDOR TRUCK (3.5T~7T) PK250(8T),251(8T),25A,252,262,26A,PW25# | 93/4~ | Wheel Hub FRONT |
| 03904 6858 | 43090-Z5000 | 130 X 150 X 10 | CONDOR TRUCK (3.5T~7T) PK251,260 C/# 20001~HEAVYDUTY | 97/3~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7881 | 43090-Z5000 | 130 X 150 X 10 | CONDOR TRUCK (3.5T~7T) PK251,260 C/# 20001~REAR AXLE 9.5T | 98/2~ | Wheel Hub FRONT |
| 03904 7947 | 32136-02T00 | 50 X 74 X 12 | CONDOR TRUCK (3.5T~7T) NK110 | 90/7~93/ | Transmission REAR |
| 03904 1743 | 32219-90075 | 48 X 65 X 9 X 9.5 | CONDOR TRUCK (3.5T~7T) MK25#,26#...MPS# | 96/10~ | Transmission FRONT |
| 03904 6979 | 32219-Z5003 | 32 X 45 X 8 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,25#,26#... MHS# | 91/11~ | Transmission FRONT |
| 03904 3712 | 32219-Z5003 | 32 X 45 X 8 | CONDOR TRUCK (3.5T~7T) MF21#,LF21#...MHS# | 94/3~00/ | Transmission FRONT |
| 03904 3019 | 32219-Z5003 | 32 X 45 X 8 | CONDOR TRUCK (3.5T~7T) CL8#...MHS#,TMH760 | 84/7~94/ | Transmission FRONT |
| 03904 4284 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) CM87,88 MLS# | 84/5~93/ | Transmission FRONT |
| 03904 2007 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,25#,26#2 B1 MKS#,MLS# | 91/10~ | Transmission FRONT |
| 03904 5010 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) MF260,LF260 MLS# | 97/10~00/ | Transmission FRONT |
| 03904 5582 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) CL8#...MLS#,TMH780 | 84/7~98/ | Transmission FRONT |
| 03904 7342 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) LK21#,25#,26#...MKS#,M LS# | 93/3~ | Transmission FRONT |
| 03904 2447 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) PK252(13T),PK25A(13T), PK262(13T) LOW DECK | 99/7~ | Wheel Hub REAR OUTER |
| 03904 2766 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...MLS# | 92/4~95/ | Transmission FRONT |
| 03904 4988 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PW25# | 97/3~ | Wheel Hub REAR OUTER (F&R) |
| 03904 5725 | 32219-90075 | 48 X 65 X 9 X 9.5 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...MPS# | 96/10~ | Transmission FRONT |
| 03904 2414 | 32219-90075 | 48 X 65 X 9 X 9.5 | CONDOR TRUCK (3.5T~7T) PW25# | 96/10~ | Transmission FRONT |
| 03904 7991 | 32219-90076 | 48 X 65 X 9 X 10 | CONDOR TRUCK (3.5T~7T) MK25#,26#...MPS# | 91/11~96/ 10 | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7221 | 32219-90076 | 48 X 65 X 9 X 10 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...MPS# | 91/11~96/ 10 | Transmission FRONT |
| 03904 6033 | 32136-Z5000 | 58 X 75 X 9 | CONDOR TRUCK (3.5T~7T) CM80,85,86,89,90 | 74/9~ | Transmission REAR |
| 03904 3338 | 32136-Z5000 | 58 X 75 X 9 | CONDOR TRUCK (3.5T~7T) CM87,88..MHS#,MHP# | 84/5~93/ | Transmission REAR |
| 03904 4757 | 32136-Z5000 | 58 X 75 X 9 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,25#,26#... MHS# | 91/11~ | Transmission REAR |
| 03904 7419 | 32136-Z5000 | 58 X 75 X 9 | CONDOR TRUCK (3.5T~7T) MF21#,LF21#...MHS# | 93/11~00/ | Transmission REAR |
| 03904 6759 | 32136-Z5000 | 58 X 75 X 9 | CONDOR TRUCK (3.5T~7T) CL8#...MHS#,TMH760 | 84/7~94/ | Transmission REAR |
| 03904 3063 | 32219-Z5005 | 42 X 60 X 8 | CONDOR TRUCK (3.5T~7T) CP8# | 84/12~98/ | Transmission FRONT |
| 03904 7540 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) PK26A(13T) SINGLE CAB AND DECK | 02/4~ | Wheel Hub REAR OUTER |
| 03904 2832 | 43090-00Z00 | 154 X 175 X 13.5 | CONDOR TRUCK (3.5T~7T) PK260 DOUBLE CAB | 95/6~ | Wheel Hub REAR INNER |
| 03904 6154 | 43090-Z5001 | 127 X 146 X 10 | CONDOR TRUCK (3.5T~7T) PW25# | 97/3~ | Wheel Hub REAR INNER (F&R) |
| 03904 1347 | 38212-Z5000 | 47 X 56 X 7 | CONDOR TRUCK (3.5T~7T) CM8#,9#,CL8#,NK110 | 74/9~ | Wheel Hub REAR OUTER |
| 03904 5483 | 38212-90006 | 60 X 72 X 7.5 | CONDOR TRUCK (3.5T~7T) CP8# | 85/2~93/ | Wheel Hub REAR OUTER |
| 03904 5560 | 38212-90008 | 51 X 62 X 7 | CONDOR TRUCK (3.5T~7T) LF210,211,MF210,211 | 94/4~ | Wheel Hub REAR OUTER |
| 03904 6737 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,25#,26#,2 B1 | 91/10~99/ | Wheel Hub REAR OUTER |
| 03904 7056 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) LK21#,25#,26#,LF260,MF 260 | 93/3~ | Wheel Hub REAR OUTER |
| 03904 3041 | 32136-90106 | 70 X 88 X 11 | CONDOR TRUCK (3.5T~7T) PW25# | 99/1~ | Transmission REAR |
| 03904 7364 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) PK251 C/#~20000 7T LOW DECK | 97/3~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4768 | 32219-Z5003 | 32 X 45 X 8 | CONDOR TRUCK (3.5T~7T) CM87,88..MHP#,MHS# | 84/5~93/ | Transmission FRONT |
| 03904 7518 | 38212-Z5007 | 57 X 123 X 11 X 21 | CONDOR TRUCK (3.5T~7T) PK260 C/#~20000 SINGLE CAB | 94/9~98/ | Wheel Hub REAR OUTER |
| 03904 4493 | 32219-Z5003 | 32 X 45 X 8 | CONDOR TRUCK (3.5T~7T) CM80,85,86,89,90,NK110 | 74/9~ | Transmission FRONT |
| 03904 5340 | 38212-90013 | 74 X 156 X 13 X 17.5 | CONDOR TRUCK (3.5T~7T) PK210,211,250,PK251(8T ) | 93/3~94/1 2 | Wheel Hub REAR OUTER |
| 03904 1435 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK210,211,250,PK251(8T ) | 95/1~ | Wheel Hub REAR OUTER |
| 03904 3371 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK252(15T),PK25A(15T), PK262(15T) LOW DECK | 99/7~ | Wheel Hub REAR OUTER |
| 03904 7925 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK251 C/#~20000 EXCEPT 7T LOW DECK | 95/6~98/ | Wheel Hub REAR OUTER |
| 03904 7958 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK251,260 C/# 20001~REAR AXLE 9.5T | 98/2~ | Wheel Hub REAR OUTER |
| 03904 4603 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK260 DOUBLE CAB | 95/6~ | Wheel Hub REAR OUTER |
| 03904 4537 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK26A(15T) SINGLE CAB AND LOW DECK | 02/4~ | Wheel Hub REAR OUTER |
| 03904 1897 | 38212-00Z01 | 74 X 156 X 14 X 22 | CONDOR TRUCK (3.5T~7T) PK26A DOUBLE CAB | 02/4~ | Wheel Hub REAR OUTER |
| 03904 5637 | 43090-00Z00 | 154 X 175 X 13.5 | CONDOR TRUCK (3.5T~7T) PK252(15T),262(15T) LOW DECK | 99/7~01/1 | Wheel Hub REAR INNER |
| 03904 1985 | 38189-90067 | 70 X 124 X 12 X 24 | CONDOR TRUCK (3.5T~7T) MK250,251,260,262 FLY WHEEL | 91/10~ | Final Drive PINION |
| 03904 4086 | 12279-Z5508 | 110 X 148 X 11 | CONDOR TRUCK (3.5T~7T) FE6E(E343) WITH PTO | 94/11~00/ | Engine CRANK SHAFT REAR |
| 03904 7815 | 12279-Z5503 | 110 X 135 X 9 | CONDOR TRUCK (3.5T~7T) FE6#...WITHOUT PTO | 84/5~92/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 6077 | 12279-Z5503 | 110 X 135 X 9 | CONDOR TRUCK (3.5T~7T) FE6A,FE6E,FE6T WITHOUT PTO | 93/1~97/ | Engine CRANK SHAFT REAR |
| 03904 6275 | 12270-Z5502 | 110 X 135 X 14 | CONDOR TRUCK (3.5T~7T) FE6A,FE6F WITHOUT PTO | 98/9~ | Engine CRANK SHAFT REAR |
| 03904 1226 | 12270-Z5503 | 120 X 145 X 13 | CONDOR TRUCK (3.5T~7T) FE6TA,FE6TB,FU6TB WITHOUT PTO | 98/9~ | Engine CRANK SHAFT REAR |
| 03904 1237 | 12279-Z5500 | 105 X 135 X 9 | CONDOR TRUCK (3.5T~7T) FD6 WITHOUT PTO | 83/5~86/ | Engine CRANK SHAFT REAR |
| 03904 6880 | 12279-Z5502 | 100 X 142 X 12 | CONDOR TRUCK (3.5T~7T) FD6,ED6 WITH PTO | 74/9~86/ | Engine CRANK SHAFT REAR |
| 03904 6715 | 12279-Z5502 | 100 X 142 X 12 | CONDOR TRUCK (3.5T~7T) FE6#...WITH PTO | 84/5~92/ | Engine CRANK SHAFT REAR |
| 03904 3965 | 12279-Z5502 | 100 X 142 X 12 | CONDOR TRUCK (3.5T~7T) FE6E(E226 OR 23KG) WITH PTO | 94/11~00/ | Engine CRANK SHAFT REAR |
| 03904 1721 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | CONDOR TRUCK (3.5T~7T) CM8#,9# | 74/9~94/ | Final Drive PINION |
| 03904 5241 | 12279-Z5506 | 120 X 145 X 10 | CONDOR TRUCK (3.5T~7T) FE6TA,FE6TB WITHOUT PTO | 93/1~97/ | Engine CRANK SHAFT REAR |
| 03904 4196 | 38189-Z5006 | 60 X 114 X 12 X 25 | CONDOR TRUCK (3.5T~7T) MF210,LF210 EXCEPT FRONT HUB FLY WHEEL | 93/10~01/ | Final Drive PINION |
| 03904 1655 | 12279-01T00 | 105 X 135 X 9 | CONDOR TRUCK (3.5T~7T) FD35T | 90/7~93/ | Engine CRANK SHAFT REAR |
| 03904 5087 | 12279-Z5508 | 110 X 148 X 11 | CONDOR TRUCK (3.5T~7T) FE6A,FE6T WITH PTO | 93/1~98/ | Engine CRANK SHAFT REAR |
| 03904 1908 | 12279-Z5502 | 100 X 142 X 12 | CONDOR TRUCK (3.5T~7T) FE6F(226NM) WITH PTO | 98/9~ | Engine CRANK SHAFT REAR |
| 03904 3558 | 12279-Z5508 | 110 X 148 X 11 | CONDOR TRUCK (3.5T~7T) FE6F(343NM) WITH PTO | 99/2~ | Engine CRANK SHAFT REAR |
| 03904 4152 | 12279-Z6000 | 112 X 147 X 17 | CONDOR TRUCK (3.5T~7T) MD92 | 94/2~ | Engine CRANK SHAFT REAR |
| 03904 7749 | 12279-0T001 | 108 X 135 X 9 | CONDOR TRUCK (3.5T~7T) FD46TA | 96/9~00/ | Engine CRANK SHAFT REAR |
| 03904 6539 | 13207-Z5001 | | CONDOR TRUCK (3.5T~7T) FD35T | 90/7~93/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4207 | 13207-Z5500 | | CONDOR TRUCK (3.5T~7T) FD6,FE6A,FE6B,FE6C,FD46T#,FU6T# | 74/9~02/3 | Engine VALVE STEM SEAL |
| 03904 7969 | 13207-Z5500 | | CONDOR TRUCK (3.5T~7T) FE6T# | 84/5~98/8 | Engine VALVE STEM SEAL |
| 03904 3932 | 13207-Z5500 | | CONDOR TRUCK (3.5T~7T) FU6TB INTAKE | 02/4~ | Engine VALVE STEM SEAL |
| 03904 6044 | 13207-V1700 | | CONDOR TRUCK (3.5T~7T) FE6E,FE6F,MD92 | 92/4~ | Engine VALVE STEM SEAL |
| 03904 2458 | 13207-V1700 | | CONDOR TRUCK (3.5T~7T) FE6T# | 98/9~ | Engine VALVE STEM SEAL |
| 03904 7265 | 13207-Z5900 | | CONDOR TRUCK (3.5T~7T) FU6TB EXHAUST | 02/4~ | Engine VALVE STEM SEAL |
| 03904 5736 | 32136-Z5000 | 58 X 75 X 9 | CONDOR TRUCK (3.5T~7T) CP8#...MHS# | 84/12~93/ | Transmission REAR |
| 03904 1556 | 12279-Z5508 | 110 X 148 X 11 | CONDOR TRUCK (3.5T~7T) FE6A,FE6E,FE6T WITH PTO | 93/1~94/11 | Engine CRANK SHAFT REAR |
| 03904 1534 | 38189-Z5005 | 60 X 114 X 12 X 24 | CONDOR TRUCK (3.5T~7T) PW25# | 97/11~ | Final Drive PINION |
| 03904 3767 | 12278-Z5501 | 58 X 82 X 10 | CONDOR TRUCK (3.5T~7T) FE6#...CM87,88,89,CP8#,CL8# | 84/5~95/ | Engine CRANK SHAFT FRONT |
| 03904 5670 | 12278-T9000 | 62 X 85 X 12.5 | CONDOR TRUCK (3.5T~7T) FD46#...MK12#,130 | 95/1~00/ | Engine CRANK SHAFT FRONT |
| 03904 5494 | 12278-T9000 | 62 X 85 X 12.5 | CONDOR TRUCK (3.5T~7T) FD35 NK110 | 90/7~93/ | Engine CRANK SHAFT FRONT |
| 03904 1710 | 12278-90016 | 62 X 85 X 13 | CONDOR TRUCK (3.5T~7T) FD6,ED6 CM80,85,90 | 74/9~83/ | Engine CRANK SHAFT FRONT |
| 03904 1523 | 38189-90067 | 70 X 124 X 12 X 24 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...FLY WHEEL | 92/8~01/ | Final Drive PINION |
| 03904 2194 | 12278-Z5501 | 58 X 82 X 10 | CONDOR TRUCK (3.5T~7T) FE6#...MF21#,MK21#,25#,LF21#,LK21#,25#,PK21#,25#, | 91/10~ | Engine CRANK SHAFT FRONT |
| 03904 1941 | 38189-90018 | 80 X 135 X 15 X 25.5 | CONDOR TRUCK (3.5T~7T) PK21#,25#,26#...WITHOUT FLY WHEEL | 89/4~01/ | Final Drive PINION |
| 03904 5923 | 38189-Z5005 | 60 X 114 X 12 X 24 | CONDOR TRUCK (3.5T~7T) MK12#,13#,21#,252,25A,25B,26A,26B,2B1 | 93/3~ | Final Drive PINION |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 3525 | 38189-Z5005 | 60 X 114 X 12 X 24 | CONDOR TRUCK (3.5T~7T) MF21#,26#,LF21#,26#...FRONT HUB FLY WHEEL | 93/10~ | Final Drive PINION |
| 03904 5615 | 38189-Z5005 | 60 X 114 X 12 X 24 | CONDOR TRUCK (3.5T~7T) LK21#,25#,26#...WITHOUT FLY WHEEL | 92/8~ | Final Drive PINION |
| 03904 3349 | 38189-Z5005 | 60 X 114 X 12 X 24 | CONDOR TRUCK (3.5T~7T) MK250,251,260,262 WITHOUT FLY WHEEL | 91/10~ | Final Drive PINION |
| 03904 4009 | 38189-90016 | 80 X 135 X 12 X 26 | CONDOR TRUCK (3.5T~7T) CP8# | 84/12~94/ | Final Drive PINION |
| 03904 4130 | 12279-Z5507 | 120 X 148 X 11 | CONDOR TRUCK (3.5T~7T) FE6TA WITH PTO | 93/1~ | Engine CRANK SHAFT REAR |
| 03904 6000 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | CONDOR TRUCK (3.5T~7T) CL8# | 84/7~93/ | Final Drive PINION |
| 03904 5109 | 38189-90067 | 70 X 124 X 12 X 24 | CONDOR TRUCK (3.5T~7T) LK21#,25#,26#...FLY WHEEL | 88/8~ | Final Drive PINION |
| 03904 6583 | 12278-Z6000 | 88 X 123 X 16 | CONDOR TRUCK (3.5T~7T) MD92 MK26#,LK26#,PK26# | 94/1~ | Engine CRANK SHAFT FRONT |
| 03904 4592 | 12279-Z5001 | 105 X 135 X 13 | CONDOR TRUCK (3.5T~7T) FD6,ED6 WITHOUT PTO | 74/9~83/ | Engine CRANK SHAFT REAR |
| 03904 4559 | 12278-Z5500 | 60 X 82 X 12 | CONDOR TRUCK (3.5T~7T) FD6 CM86 | 83/5~86/ | Engine CRANK SHAFT FRONT |
| 03904 4823 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | CONDOR TRUCK (3.5T~7T) NK110 | 90/7~93/ | Final Drive PINION |
| 03904 3129 | 38212-90006 | 60 X 72 X 7.5 | CV TRUCK (2-2XD) CV3#,4#,5#,6# | 72/~90/ | Wheel Hub REAR OUTER |
| 03904 4251 | 32219-90073 | 56 X 72 X 10 | CV TRUCK (2-2XD) CCV320,450,520,620 MPS5,6,7 | 88/5~96/ | Transmission FRONT |
| 03904 3800 | 32219-90018 | 56 X 72 X 9 | CV TRUCK (2-2XD) CV27,48 | 98/8~ | Transmission FRONT |
| 03904 5175 | 32219-90018 | 56 X 72 X 9 | CV TRUCK (2-2XD) CV32,45,63 MTS6,7 | 91/12~01/ | Transmission FRONT |
| 03904 2249 | 32219-90018 | 56 X 72 X 9 | CV TRUCK (2-2XD) CV320,450,520,620 MTS6,7 | 88/12~01/ | Transmission FRONT |
| 03904 8057 | 32219-90018 | 56 X 72 X 9 | CV TRUCK (2-2XD) CV46,47,51,54,461 | 83/5~90/ | Transmission FRONT |
| 03904 7914 | 32219-90002 | 42 X 65 X 9 | CV TRUCK (2-2XD) CV31,40,60 | 72/~76/ | Transmission FRONT |
| 03904 8002 | 32219-90014 | 48 X 65 X 9 | CV TRUCK (2-2XD) CV66 | 84/3~90/ | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 1248 | 32219-90014 | 48 X 65 X 9 | CV TRUCK (2-2XD) CV32,41,45,50,55,56 | 72/~86/ | Transmission FRONT |
| 03904 6561 | 38212-90013 | 74 X 156 X 13 X 17.5 | CV TRUCK (2-2XD) CV320,450,520,620 | 90/1~ | Wheel Hub REAR OUTER |
| 03904 7804 | 32136-90062 | 70 X 88 X 12 | CV TRUCK (2-2XD) CV TMH460,600,MPS6 | 83/5~90/ | Transmission REAR |
| 03904 7177 | 43090-00Z00 | 154 X 175 X 13.5 | CV TRUCK (2-2XD) CV27,32,45,48,63 | 94/11~00/ 12 | Wheel Hub REAR INNER |
| 03904 4702 | 43090-00Z00 | 154 X 175 X 13.5 | CV TRUCK (2-2XD) CV320,450,520,620 GREASE HUB | 90/1~95/ | Wheel Hub REAR INNER |
| 03904 3272 | 43090-90060 | 154 X 175 X 13 | CV TRUCK (2-2XD) CV27,48 | 01/1~ | Wheel Hub REAR INNER |
| 03904 5901 | 43090-90060 | 154 X 175 X 13 | CV TRUCK (2-2XD) CV46,47,51,54,66 | 85/5~90/ | Wheel Hub REAR INNER |
| 03904 5967 | 43090-90000 | 124 X 170 X 14.5 | CV TRUCK (2-2XD) CV3#,4#,5#,6# | 72/~85/5 | Wheel Hub REAR INNER |
| 03904 6506 | 43090-Z5000 | 130 X 150 X 10 | CV TRUCK (2-2XD) CV27,32,45,46,47,48,51,5 4,56,63,66 | 90/1~ | Wheel Hub FRONT (F&R) |
| 03904 8013 | 43090-Z5000 | 130 X 150 X 10 | CV TRUCK (2-2XD) CV320,450,520,620 GREASE HUB | 90/1~95/ | Wheel Hub FRONT (F&R) |
| 03904 5263 | 43090-Z5000 | 130 X 150 X 10 | CV TRUCK (2-2XD) CV3#,4#,5#,6# | 72/~90/ | Wheel Hub FRONT (F&R) |
| 03904 1820 | 38212-00Z01 | 74 X 156 X 14 X 22 | CV TRUCK (2-2XD) CV27,32,45,48,63 | 94/11~ | Wheel Hub REAR OUTER |
| 03904 2546 | 37526-90000 | 55 X 75 X 12 | CV TRUCK (2-2XD) CV46,47,54 | 83/5~90/ | Propeller Shaft CENTER BEARING |
| 03904 5076 | 38189-90018 | 80 X 135 X 15 X 25.5 | CV TRUCK (2-2XD) CV27,32,45,48,63 | 95/2~ | Differential PINION |
| 03904 1600 | 38189-90016 | 80 X 135 X 12 X 26 | CV TRUCK (2-2XD) CV320,450,520,620 | 88/6~95/ | Differential PINION |
| 03904 2062 | 38189-90016 | 80 X 135 X 12 X 26 | CV TRUCK (2-2XD) CV50 TURBO C/# 083001~ | 83/~84/ | Differential PINION |
| 03904 5824 | 38189-90016 | 80 X 135 X 12 X 26 | CV TRUCK (2-2XD) CV32,45,46,47,50,51,54,6 3,66 | 79/~95/1 | Differential PINION |
| 03904 2557 | 38189-90016 | 80 X 135 X 12 X 26 | CV TRUCK (2-2XD) CV32 C/# 000192~ | 77/~79/ | Differential PINION |
| 03904 2271 | 38189-90007 | 85 X 125 X 14 | CV TRUCK (2-2XD) CV32 C/#~000191 | 75/~77/ | Differential PINION |
| 03904 1402 | 38189-90007 | 85 X 125 X 14 | CV TRUCK (2-2XD) CV31 | 72/~76/ | Differential PINION |
| 03904 2106 | 32219-90073 | 56 X 72 X 10 | CV TRUCK (2-2XD) CV32,45,63 MPS6,7 | 91/5~00/ | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4812 | 37526-90000 | 55 X 75 X 12 | CV TRUCK (2-2XD) CV45,50 PS410 | 79/~83/ | Propeller Shaft CENTER BEARING |
| 03904 7936 | 32136-90062 | 70 X 88 X 12 | CV TRUCK (2-2XD) CV3#,4#,5#,6# | 72/~83/ | Transmission REAR |
| 03904 1138 | 38189-90002 | 70 X 115 X 15 | CV TRUCK (2-2XD) CV40 | 72/~76/ | Differential PINION |
| 03904 1831 | 37526-90002 | 60 X 82 X 12 | CV TRUCK (2-2XD) CV45,50 PS510 | 79/~83/ | Propeller Shaft CENTER BEARING |
| 03904 5593 | 37526-90002 | 60 X 82 X 12 | CV TRUCK (2-2XD) CV66 | 84/4~90/ | Propeller Shaft CENTER BEARING |
| 03904 4317 | 32136-NA002 | 80 X 100 X 14 | CV TRUCK (2-2XD) CV MTS6,7,ATS7 | 02/7~ | Transmission REAR |
| 03904 3943 | 32136-NA001 | 90 X 115 X 14 | CV TRUCK (2-2XD) CV MRT2 | 02/7~ | Transmission REAR |
| 03904 2909 | 32136-90061 | 90 X 115 X 13 | CV TRUCK (2-2XD) CV MRT2 | 99/9~02/6 | Transmission REAR |
| 03904 5879 | 32136-90107 | 80 X 100 X 13 | CV TRUCK (2-2XD) CV MTS6,7,ATS7 | 86/2~02/6 | Transmission REAR |
| 03904 7463 | 32136-90106 | 70 X 88 X 11 | CV TRUCK (2-2XD) CV MPS5,6,7 | 90/1~ | Transmission REAR |
| 03904 1864 | 37526-90000 | 55 X 75 X 12 | CV TRUCK (2-2XD) CV31,40,51 | 72/~86/ | Propeller Shaft CENTER BEARING |
| 03904 4526 | 38189-90101 | 105 X 135 X 14 X 20.5 | CW TRUCK / TRACTOR (2XD-D) CW50 C/#030947~ | 77/~79/ | Differential PINION(FORWARD ) |
| 03904 3921 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW54,66,67..MTPO.17IN CH CLUTCH+MTR7 | 86/6~90/ | Transmission FRONT |
| 03904 2117 | 32136-90107 | 80 X 100 X 13 | CW TRUCK / TRACTOR (2XD-D) CW46,53,54,66 TRUCK | 85/5~90/ | Transmission REAR |
| 03904 5054 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW54,66,67 MTPO. 15INCH CLUTCH+MTR9 | 86/6~90/ | Transmission FRONT |
| 03904 2337 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW51,61 | 79/~82/ | Transmission FRONT |
| 03904 1149 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW52,66 TMH500 ,TMH850 | 82/~86/ | Transmission FRONT |
| 03904 2073 | 32219-90012 | 42 X 55 X 9 | CW TRUCK / TRACTOR (2XD-D) CW50 TMH500(C/#~023909) | 72/~76/2 | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7298 | 32219-90002 | 42 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW50 TMH3#(C/#~023909) | 72/~76/2 | Transmission FRONT |
| 03904 4515 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW52,66 TMH500 ,TMH850 | 82/~86/ | Transmission FRONT |
| 03904 6055 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW45 F/R5.857,6.500 | 79/~86/ | Transmission FRONT |
| 03904 5516 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW52,60 TRUCK | 79/~86/ | Transmission FRONT |
| 03904 5153 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW46,53,54,66 MTS6.17INCH CLUTCH+MTS7 | 85/5~90/ | Transmission FRONT |
| 03904 5978 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW45 F/R6.166,6.833 | 79/~86/ | Transmission FRONT |
| 03904 5703 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63,541, 542,551,552,631,632 | 91/10~ | Transmission FRONT |
| 03904 6396 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW450,510,520,530,540,6 10,620 MTPO,MTS6,7 | 88/12~01/ | Transmission FRONT |
| 03904 2139 | 32219-90073 | 56 X 72 X 10 | CW TRUCK / TRACTOR (2XD-D) CW450,510,520,530,540,6 10,620 MPS6,7 | 88/5~96/ | Transmission FRONT |
| 03904 1688 | 32136-90062 | 70 X 88 X 12 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 72/~85/5 | Transmission REAR |
| 03904 2172 | 32136-90062 | 70 X 88 X 12 | CW TRUCK / TRACTOR (2XD-D) CW52,66 TMH500 | 82/~86/ | Transmission REAR |
| 03904 4581 | 32136-90106 | 70 X 88 X 11 | CW TRUCK / TRACTOR (2XD-D) CW48,53,55 MPS6,7,APS7 | 98/8~ | Transmission REAR |
| 03904 1501 | 32136-90106 | 70 X 88 X 11 | CW TRUCK / TRACTOR (2XD-D) CW450,510,520,530,540,6 10,620 MPS6,7 | 88/5~96/ | Transmission REAR |
| 03904 7210 | 32136-90107 | 80 X 100 X 13 | CW TRUCK / TRACTOR (2XD-D) CW52,66 TMH500 | 82/~86/ | Transmission REAR |
| 03904 1116 | 38189-90064 | 82 X 110 X 10 X 16 | CW TRUCK / TRACTOR (2XD-D) CW450,510,520,530,540,6 10,620 | 88/5~90/ | Differential PINION(FORWARD ) |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4735 | 32219-90018 | 56 X 72 X 9 | CW TRUCK / TRACTOR (2XD-D) CW46,53 TMH600 | 83/~85/5 | Transmission FRONT |
| 03904 4328 | 43090-00Z00 | 154 X 175 X 13.5 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63 EXCEPT LOW DECK | 94/11~00/ 12 | Wheel Hub REAR INNER (F&R) |
| 03904 4097 | 43090-Z5000 | 130 X 150 X 10 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 72/~89/9 | Wheel Hub FRONT |
| 03904 5164 | 43090-Z5000 | 130 X 150 X 10 | CW TRUCK / TRACTOR (2XD-D) CW510,520,530,540,541,542,551,552,610,620,631,632. | 89/10~ | Wheel Hub FRONT |
| 03904 1963 | 43090-Z5000 | 130 X 150 X 10 | CW TRUCK / TRACTOR (2XD-D) CW45,46,52,53,54,55,60,61,63,66,67 | 89/10~ | Wheel Hub FRONT |
| 03904 4680 | 40227-90014 | 150 X 175 X 14 | CW TRUCK / TRACTOR (2XD-D) CW450 | 90/8~ | Wheel Hub FRONT |
| 03904 1479 | 43090-90000 | 124 X 170 X 14.5 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 72/~85/5 | Wheel Hub REAR INNER (F&R) |
| 03904 4240 | 43090-Z5001 | 127 X 146 X 10 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63 LOW DECK | 94/11~ | Wheel Hub REAR INNER (F&R) |
| 03904 3855 | 43090-Z5001 | 127 X 146 X 10 | CW TRUCK / TRACTOR (2XD-D) CW450 | 90/8~ | Wheel Hub REAR INNER (F&R) |
| 03904 2711 | 43090-90060 | 154 X 175 X 13 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 85/5~89/9 | Wheel Hub REAR INNER (F&R) |
| 03904 1512 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW46,53,54,66 MTS6.15INCH CLUTCH+MTPO | 85/5~90/ | Transmission FRONT |
| 03904 7793 | 43090-90060 | 154 X 175 X 13 | CW TRUCK / TRACTOR (2XD-D) CW542,552 | 01/1~ | Wheel Hub REAR INNER (F&R) |
| 03904 4691 | 32136-90107 | 80 X 100 X 13 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63,541, 542,551,552,631,632 MTS6,7 | 91/5~02/6 | Transmission REAR |
| 03904 4020 | 43090-00Z00 | 154 X 175 X 13.5 | CW TRUCK / TRACTOR (2XD-D) CW510,520,530,540,541,542,551,552,610,620,631,632. | 89/10~00/ 12 | Wheel Hub REAR INNER (F&R) |
| 03904 5186 | 38212-Z5000 | 47 X 56 X 7 | CW TRUCK / TRACTOR (2XD-D) CW450 | 90/8~ | Wheel Hub REAR OUTER (F&R) |
| 03904 8079 | 38212-90006 | 60 X 72 X 7.5 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 72/~89/9 | Wheel Hub REAR OUTER (F&R) |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 3756 | 38212-90013 | 74 X 156 X 13 X 17.5 | CW TRUCK / TRACTOR (2XD-D) CW510,520,530,540,610,620 | 89/10~94/12 | Wheel Hub REAR OUTER (F&R) |
| 03904 1413 | 38212-Z5007 | 57 X 123 X 11 X 21 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63 LOW DECK | 94/11~ | Wheel Hub REAR OUTER (F&R) |
| 03904 2348 | 38212-00Z01 | 74 X 156 X 14 X 22 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63 EXCEPT LOW DECK | 94/11~ | Wheel Hub REAR OUTER (F&R) |
| 03904 3822 | 38212-00Z01 | 74 X 156 X 14 X 22 | CW TRUCK / TRACTOR (2XD-D) CW530,540,541,542,551,552,631,632 | 95/1~ | Wheel Hub REAR OUTER (F&R) |
| 03904 6363 | 55515-00Z00 | 145 X 175 X 15.5 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 79/~ | Trunnion SHAFT |
| 03904 5329 | 32219-90014 | 48 X 65 X 9 | CW TRUCK / TRACTOR (2XD-D) CW50 C/# 023910~ | 76/3~79/ | Transmission FRONT |
| 03904 6264 | 43090-90060 | 154 X 175 X 13 | CW TRUCK / TRACTOR (2XD-D) CW48,53,55 EXCEPT LOW DECK | 01/1~ | Wheel Hub REAR INNER (F&R) |
| 03904 1160 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6#...LOW DECK | 88/8~93/2 | Differential PINION(REARWARD) |
| 03904 3657 | 32136-90107 | 80 X 100 X 13 | CW TRUCK / TRACTOR (2XD-D) CW54,66,67 MTPO | 88/6~90/ | Transmission REAR |
| 03904 4416 | 38189-90018 | 80 X 135 X 15 X 25.5 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6#...EXCEPT LOW DECK | 95/2~ | Differential PINION(REARWARD) |
| 03904 7826 | 38189-90016 | 80 X 135 X 12 X 26 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6#...EXCEPT LOW DECK | 80/1~95/1 | Differential PINION(REARWARD) |
| 03904 5527 | 38189-90016 | 80 X 135 X 12 X 26 | CW TRUCK / TRACTOR (2XD-D) CW50 C/# 030947~ | 77/~79/ | Differential PINION(REARWARD) |
| 03904 7738 | 38189-90007 | 85 X 125 X 14 | CW TRUCK / TRACTOR (2XD-D) CW50 C/#~030946 | 72/~77/ | Differential PINION(REARWARD) |
| 03904 3866 | 38189-90069 | 85 X 110 X 14.5 X 20.5 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 95/7~ | Differential PINION(FORWARD) |
| 03904 1182 | 38189-90064 | 82 X 110 X 10 X 16 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6# | 91/1~95/6 | Differential PINION(FORWARD) |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 2051 | 38189-90101 | 105 X 135 X 14 X 20.5 | CW TRUCK / TRACTOR (2XD-D) CW45,46,51,52,53,54,60,61,66,67 | 79/~90/ | Differential PINION(FORWARD) |
| 03904 6066 | 38189-90008 | 105 X 135 X 14 | CW TRUCK / TRACTOR (2XD-D) CW50 C/#~030946 | 72/~77/ | Differential PINION(FORWARD) |
| 03904 2722 | 37526-90002 | 60 X 82 X 12 | CW TRUCK / TRACTOR (2XD-D) CW510,520,610 | 90/1~ | Propeller Shaft CENTER BEARING |
| 03904 6550 | 37526-90002 | 60 X 82 X 12 | CW TRUCK / TRACTOR (2XD-D) CW46,52,53,54,60,66 | 79/~90/ | Propeller Shaft CENTER BEARING |
| 03904 1677 | 32136-90061 | 90 X 115 X 13 | CW TRUCK / TRACTOR (2XD-D) CW54,66,67 MTR7,MTR9 | 88/6~90/ | Transmission REAR |
| 03904 1842 | 38189-Z5005 | 60 X 114 X 12 X 24 | CW TRUCK / TRACTOR (2XD-D) CW4#,5#,6#...LOW DECK | 93/3~ | Differential PINION(REARWARD) |
| 03904 3217 | 37526-90002 | 60 X 82 X 12 | CW TRUCK / TRACTOR (2XD-D) CW45 C/#015001~ | 82/~86/ | Propeller Shaft CENTER BEARING |
| 03904 5274 | 32136-90107 | 80 X 100 X 13 | CW TRUCK / TRACTOR (2XD-D) CW450,510,520,530,540,610,620 MTPO,MTS6,7 | 88/4~97/ | Transmission REAR |
| 03904 2227 | 32136-90061 | 90 X 115 X 13 | CW TRUCK / TRACTOR (2XD-D) CW52,66 TMH850 | 82/~86/ | Transmission REAR |
| 03904 1622 | 32136-90061 | 90 X 115 X 13 | CW TRUCK / TRACTOR (2XD-D) CW45,48,52,53,55,63,541,542,551,552,631,632 MRT2,A | 94/4~02/6 | Transmission REAR |
| 03904 6935 | 37526-90000 | 55 X 75 X 12 | CW TRUCK / TRACTOR (2XD-D) CW45 C/#~014999 | 79/~82/ | Propeller Shaft CENTER BEARING |
| 03904 6176 | 32136-NA001 | 90 X 115 X 14 | CW TRUCK / TRACTOR (2XD-D) CW48,53,55,542,552,632 MRT2,ART2 | 02/7~ | Transmission REAR |
| 03904 3877 | 32136-NA002 | 80 X 100 X 14 | CW TRUCK / TRACTOR (2XD-D) CW48,53,55,542,552,632 MTS6,7,ATS7 | 02/7~ | Transmission REAR |
| 03904 7309 | 37526-90000 | 55 X 75 X 12 | CW TRUCK / TRACTOR (2XD-D) CW50 PS410,450 | 72/~79/ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4273 | 32136-90061 | 90 X 115 X 13 | CW TRUCK / TRACTOR (2XD-D) CW450,510,520,530,540,610,620 MRT2 | 92/9~97/ | Transmission REAR |
| 03904 3294 | 37526-90002 | 60 X 82 X 12 | CW TRUCK / TRACTOR (2XD-D) CW50 PS500,550 | 72/~79/ | Propeller Shaft CENTER BEARING |
| 03904 3547 | 38212-00Z01 | 74 X 156 X 14 X 22 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 | 95/1~ | Wheel Hub REAR OUTER (F&R) |
| 03904 4383 | 55515-00Z00 | 145 X 175 X 15.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 | 89/6~00/ | Trunnion SHAFT |
| 03904 2612 | 32219-90018 | 56 X 72 X 9 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 MTPO | 89/3~ | Transmission FRONT |
| 03904 7254 | 32136-90061 | 90 X 115 X 13 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 MTPO | 89/3~ | Transmission REAR |
| 03904 3701 | 38189-90019 | 80 X 135 X 24.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 FRONT DRIVE | 95/2~01/ | Differential PINION |
| 03904 4064 | 38189-90018 | 80 X 135 X 15 X 25.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 F/R 5.857,6.833 | 95/2~01/ | Differential PINION |
| 03904 3437 | 38212-90013 | 74 X 156 X 13 X 17.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ520 | 89/9~94/12 | Wheel Hub REAR OUTER (F&R) |
| 03904 7331 | 55515-90000 | 120 X 150 X 14 | CZ TRUCK (ALL WHEEL DRIVE) CZ50,51,520 | 81/9~98/ | Wheel Hub FRONT |
| 03904 6143 | 1-09625-017-0 | 68 X 124 X 11.5 X 27 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 NHHR | 95/11~ | Differential PINION |
| 03904 2029 | 38189-90016 | 80 X 135 X 12 X 26 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,520 | 88/6~95/1 | Differential PINION |
| 03904 7859 | 38212-90006 | 60 X 72 X 7.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ50,51 | 81/9~90/ | Wheel Hub REAR OUTER (F&R) |
| 03904 7441 | 43090-00Z00 | 154 X 175 X 13.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ520 | 89/9~98/ | Wheel Hub REAR INNER (F&R) |
| 03904 4108 | 43090-00Z00 | 154 X 175 X 13.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ53,55 | 95/6~00/12 | Wheel Hub REAR INNER (F&R) |
| 03904 5318 | 43090-90060 | 154 X 175 X 13 | CZ TRUCK (ALL WHEEL DRIVE) CZ55 | 01/1~ | Wheel Hub REAR INNER (F&R) |
| 03904 6748 | 43090-90000 | 124 X 170 X 14.5 | CZ TRUCK (ALL WHEEL DRIVE) CZ50,51 | 81/9~85/5 | Wheel Hub REAR INNER (F&R) |
| 03904 6220 | 55515-90000 | 120 X 150 X 14 | CZ TRUCK (ALL WHEEL DRIVE) CZ53B C/3~20000(EXCEPT NHHR) | 95/6~98/ | Wheel Hub FRONT |
| 03904 3811 | 1-09625-309-0 | 150 X 180 X 14 | CZ TRUCK (ALL WHEEL DRIVE) CZ53B C/#~20000(NHHR) | 95/11~98/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 6726 | 1-09625-309-0 | 150 X 180 X 14 | CZ TRUCK (ALL WHEEL DRIVE) CZ53B C/#20001~ | 98/1~00/ | Wheel Hub FRONT |
| 03904 7320 | 43090-90060 | 154 X 175 X 13 | CZ TRUCK (ALL WHEEL DRIVE) CZ51 | 85/5~90/ | Wheel Hub REAR INNER (F&R) |
| 03904 3910 | 43090-90060 | 154 X 175 X 13 | UD BUS RA46,52,RP80,U(A)32 | 85/5~91/ | Wheel Hub REAR INNER |
| 03904 4295 | 12278-90016 | 62 X 85 X 13 | UD BUS ED6,FD6 RM90,80 | 75/~84/ | Engine CRANK SHAFT FRONT |
| 03904 3382 | 12278-90010 | 70 X 88 X 9 | UD BUS RD8,10 RA50,51,60 | 76/~85/ | Engine CRANK SHAFT FRONT |
| 03904 4185 | 12278-90010 | 70 X 88 X 9 | UD BUS RE8 RA52 | 84/~86/ | Engine CRANK SHAFT FRONT |
| 03904 7848 | 12278-90006 | 62 X 85 X 13.5 | UD BUS RD6H U(A)20 | 73/~80/ | Engine CRANK SHAFT FRONT |
| 03904 4933 | 12278-90006 | 62 X 85 X 13.5 | UD BUS PE6H U(A)30,31,32 | 73/~88/ | Engine CRANK SHAFT FRONT |
| 03904 4119 | 12278-90006 | 62 X 85 X 13.5 | UD BUS PP6H U36 | 80/~82/ | Engine CRANK SHAFT FRONT |
| 03904 6990 | 12278-90006 | 62 X 85 X 13.5 | UD BUS PE6T RA46 | 85/~90/ | Engine CRANK SHAFT FRONT |
| 03904 1732 | 12279-96006 | 126 X 150 X 14 | UD BUS RE8 UA510 | 90/4~92/5 | Engine CRANK SHAFT FRONT |
| 03904 1666 | 12278-97001 | 125 X 150 X 13 | UD BUS RE8 UA510 | 92/6~97/ | Engine CRANK SHAFT FRONT |
| 03904 7980 | 12279-96006 | 126 X 150 X 14 | UD BUS RF10 RD620 | 91/5~92/3 | Engine CRANK SHAFT FRONT |
| 03904 7595 | 38189-Z5005 | 60 X 114 X 12 X 24 | UD BUS EN210,211,250 | 93/10~ | Differential PINION |
| 03904 1270 | 12278-Z5501 | 58 X 82 X 10 | UD BUS FE6#...RM2#,8#,RP2#,8#, RB8#,RN2# | 84/~ | Engine CRANK SHAFT FRONT |
| 03904 2799 | 12278-Z5501 | 58 X 82 X 10 | UD BUS FE6#...EN2# | 93/5~ | Engine CRANK SHAFT FRONT |
| 03904 6099 | 12278-Z5501 | 58 X 82 X 10 | UD BUS FE6#...JM2#,JP2# | 89/11~ | Engine CRANK SHAFT FRONT |
| 03904 2601 | 12278-Z5501 | 58 X 82 X 10 | UD BUS FU6#...RM2B1,252 | 99/2~ | Engine CRANK SHAFT FRONT |
| 03904 6352 | 12278-97000 | 70 X 88 X 8 | UD BUS RF8 RA53 | 86/~94/ | Engine CRANK SHAFT FRONT |
| 03904 8145 | 12278-97000 | 70 X 88 X 8 | UD BUS RF8 UA50 | 88/~90/ | Engine CRANK SHAFT FRONT |
| 03904 6022 | 12278-96001 | 62 X 85 X 12 | UD BUS RF6H UA33,440 | 88/~ | Engine CRANK SHAFT FRONT |
| 03904 3074 | 43090-Z5001 | 127 X 146 X 10 | UD BUS RB80,RN210,252 | 88/7~ | Wheel Hub REAR INNER |
| 03904 4900 | 12279-96006 | 126 X 150 X 14 | UD BUS RF8 R520,UA520 | 90/4~92/5 | Engine CRANK SHAFT FRONT |
| 03904 6429 | 38189-90016 | 80 X 135 X 12 X 26 | UD BUS RA50,51,52,53,46 | 77/10~95/ 1 | Differential PINION |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | | HYPOID | | |
| 03904 4339 | 32136-Z5003 | 65 X 78 X 9 | UD BUS RM210,211,250,252,2B1, RN210,252 MLS6 | 90/6~ | Transmission REAR |
| 03904 3426 | 32136-Z5003 | 65 X 78 X 9 | UD BUS JM210,250,252,JP211,250, 252 MLS6 | 90/6~ | Transmission REAR |
| 03904 7485 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | UD BUS RM80,81,90 | 75/6~ | Differential PINION |
| 03904 3206 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | UD BUS RB80 | 88/7`92/ | Differential PINION |
| 03904 4141 | 38189-Z5002 | 60 X 114 X 12.5 X 29 | UD BUS JM210,JP211,RM210 | 88/8~93/2 | Differential PINION |
| 03904 8101 | 38189-90002 | 70 X 115 X 15 | UD BUS RA50,U(A)20,30 SPIRIAL BEVEL | 76/3~80/ | Differential PINION |
| 03904 1391 | 38189-90007 | 85 X 125 X 14 | UD BUS RA50 HYPOID | 76/3~77/9 | Differential PINION |
| 03904 6781 | 38189-90007 | 85 X 125 X 14 | UD BUS RA51,52,53,46 RETARDER | 80/4~94/ | Differential PINION |
| 03904 5835 | 38189-Z5005 | 60 X 114 X 12 X 24 | UD BUS JM210,250,252,JP211,250, 252 | 93/3~ | Differential PINION |
| 03904 1754 | 38189-90016 | 80 X 135 X 12 X 26 | UD BUS U(A)32,33,50 HYPOID | 88/6~90/ | Differential PINION |
| 03904 3415 | 38189-Z5005 | 60 X 114 X 12 X 24 | UD BUS RM210,211,250,252,2B1, RN210,252 | 93/3~ | Differential PINION |
| 03904 1259 | 38189-90016 | 80 X 135 X 12 X 26 | UD BUS RP80,210 | 86/2~95/1 | Differential PINION |
| 03904 5373 | 38189-90016 | 80 X 135 X 12 X 26 | UD BUS UA440,510,520,RA520,53 0,RD620 | 88/7~95/1 | Differential PINION |
| 03904 7397 | 38189-90103 | 70 X 115 X 14 X 20 | UD BUS RA60 | 80/2~84/ | Differential PINION |
| 03904 4801 | 38189-90103 | 70 X 115 X 14 X 20 | UD BUS U(A)31,36 | 80/2~84/ | Differential PINION |
| 03904 4504 | 38189-90009 | 65 X 95 X 14 | UD BUS U(A)20 RETARDER | 76/3~80/ | Differential PINION |
| 03904 5747 | 38189-90018 | 80 X 135 X 15 X 25.5 | UD BUS RP210,211,250,252 | 95/2~ | Differential PINION |
| 03904 2161 | 38189-90018 | 80 X 135 X 15 X 25.5 | UD BUS UA440,510,520,RA520,53 0,RD620 | 95/2~01/ | Differential PINION |
| 03904 7782 | 12278-97001 | 125 X 150 X 13 | UD BUS RF8 RA520,UA520 | 92/6~97/ | Engine CRANK SHAFT FRONT |
| 03904 3327 | 38189-90007 | 85 X 125 X 14 | UD BUS U(A)32,3350 RETARDER | 88/6~90/ | Differential PINION |
| 03904 4999 | 13207-V1700 | | UD BUS FE6F,FE6T | 98/8~ | Engine VALVE STEM SEAL |
| 03904 1930 | 12270-Z5502 | 110 X 135 X 14 | UD BUS FE6E EN210,211,250 | 97/10~00/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4471 | 12270-Z5502 | 110 X 135 X 14 | UD BUS FE6F JM252,JP252,RM252,RN252 | 98/8~ | Engine CRANK SHAFT REAR |
| 03904 4889 | 12270-Z5503 | 120 X 145 X 13 | UD BUS FE6T EN210,211,250,252 | 97/10~ | Engine CRANK SHAFT REAR |
| 03904 2260 | 12270-Z5503 | 120 X 145 X 13 | UD BUS FE6T JM252,JP252,RM252,RN252,RP252 | 99/6~ | Engine CRANK SHAFT REAR |
| 03904 2370 | 12270-Z5503 | 120 X 145 X 13 | UD BUS FU6#...RM2B1,252 | 99/2~ | Engine CRANK SHAFT REAR |
| 03904 4955 | 12279-96007 | 138 X 162 X 14 | UD BUS RF6H UA33,440 | 88/~ | Engine CRANK SHAFT REAR |
| 03904 7705 | 12279-Z5506 | 120 X 145 X 10 | UD BUS FE6T EN210,211,250 | 93/7~97/9 | Engine CRANK SHAFT REAR |
| 03904 5934 | 12278-96001 | 62 X 85 X 12 | UD BUS PF6H U440 | 90/4~99/ | Engine CRANK SHAFT FRONT |
| 03904 3096 | 13207-V1700 | | UD BUS FE6E | 94/5~99/ | Engine VALVE STEM SEAL |
| 03904 2821 | 12270-97007 | 133 X 157 X 18 X 22 | UD BUS RE8 UA510 | 93/8~95/ | Engine CRANK SHAFT REAR |
| 03904 4427 | 13207-97000 | | UD BUS RD8,10,RE8,10,RF8,10,RG8(IN.) | 76/~ | Engine VALVE STEM SEAL |
| 03904 4438 | 13207-97001 | | UD BUS PE6# | 79/~90/ | Engine VALVE STEM SEAL |
| 03904 4922 | 13207-97001 | | UD BUS PF6H | 89/10~93/ | Engine VALVE STEM SEAL |
| 03904 1644 | 13207-97001 | | UD BUS RD8,10,RE8,10,RF8,10,RG8(EX.) | 76/~ | Engine VALVE STEM SEAL |
| 03904 6968 | 13207-Z5500 | | UD BUS FD6,FE6B,FE6T | 74/9~98/7 | Engine VALVE STEM SEAL |
| 03904 6704 | 13207-Z5500 | | UD BUS FU6T | 99/2~02/3 | Engine VALVE STEM SEAL |
| 03904 6253 | 13207-Z5500 | | UD BUS FU6T(IN.) | 02/4~ | Engine VALVE STEM SEAL |
| 03904 5868 | 13207-Z5900 | | UD BUS FU6T(EX.) | 02/4~ | Engine VALVE STEM SEAL |
| 03904 6792 | 12279-Z5506 | 120 X 145 X 10 | UD BUS FE6T JM250,JP250,RM211,250, RN210,RP211,250 | 95/3~00/ | Engine CRANK SHAFT REAR |
| 03904 7573 | 12279-Z5503 | 110 X 135 X 9 | UD BUS FE6#...RM81,210,RP80,210,211,250,RB80 | 84/~ | Engine CRANK SHAFT REAR |
| 03904 7683 | 12278-97001 | 125 X 150 X 13 | UD BUS RF10 RD620 | 92/4~97/ | Engine CRANK SHAFT FRONT |
| 03904 6660 | 12278-90013 | 68.7 X 90.5 X 7.5 | UD BUS RD8,10 RA50,51,60 | 76/~85/ | Engine CRANK SHAFT FRONT(OUTSIDE) |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7727 | 12278-90013 | 68.7 X 90.5 X 7.5 | UD BUS RE8 RA52 | 84/~85/ | Engine CRANK SHAFT FRONT(OUTSIDE) |
| 03904 7496 | 12279-96006 | 126 X 150 X 14 | UD BUS PD6H U(A)20 | 73/~80/ | Engine CRANK SHAFT REAR |
| 03904 5659 | 12279-96006 | 126 X 150 X 14 | UD BUS PE6H U(A)30,31,32 | 73/~88/ | Engine CRANK SHAFT REAR |
| 03904 7122 | 12279-96006 | 126 X 150 X 14 | UD BUS PP6H U36 | 80/~82/ | Engine CRANK SHAFT REAR |
| 03904 2689 | 12279-96006 | 126 X 150 X 14 | UD BUS PE6T RA46 | 85/~90/ | Engine CRANK SHAFT REAR |
| 03904 2425 | 12279-96006 | 126 X 150 X 14 | UD BUS RD8,10 RA50,51,60 | 76/~85/ | Engine CRANK SHAFT REAR |
| 03904 6484 | 12270-97007 | 133 X 157 X 18 X 22 | UD BUS RF8..RA53,520,UA520 | 93/8~95/ | Engine CRANK SHAFT REAR |
| 03904 2700 | 12279-Z5001 | 105 X 135 X 13 | UD BUS ED6,FD6 RM90,80 | 75/~84/ | Engine CRANK SHAFT REAR |
| 03904 8046 | 12270-97007 | 133 X 157 X 18 X 22 | UD BUS RF10 RD620 | 93/8~95/ | Engine CRANK SHAFT REAR |
| 03904 2667 | 12279-Z5503 | 110 X 135 X 9 | UD BUS FE6#...JM210,JP211 | 89/11~96/ | Engine CRANK SHAFT REAR |
| 03904 1446 | 12279-Z5503 | 110 X 135 X 9 | UD BUS FE6E EN210,211,250 | 94/7~97/9 | Engine CRANK SHAFT REAR |
| 03904 4361 | 12279-Z5503 | 110 X 135 X 9 | UD BUS FE6E JM250,JP250,RM211,250, RN210 | 95/3~97/ | Engine CRANK SHAFT REAR |
| 03904 2205 | 12279-97006 | 133 X 157 X 14 | UD BUS RE8 UA50,510 | 88/~93/7 | Engine CRANK SHAFT REAR |
| 03904 2326 | 12279-97006 | 133 X 157 X 14 | UD BUS RF8 RA53,520,UA520 | 86/~93/7 | Engine CRANK SHAFT REAR |
| 03904 7650 | 12279-97006 | 133 X 157 X 14 | UD BUS RF10 RD620 | 90/7~93/7 | Engine CRANK SHAFT REAR |
| 03904 4724 | 12270-96003 | 138 X 162 X 14 | UD BUS PF6H U440 | 88/4~95/ | Engine CRANK SHAFT REAR |
| 03904 5208 | 32136-Z5003 | 65 X 78 X 9 | UD BUS RM81 TMH780,MLS60 | 84/11~90/ | Transmission REAR |
| 03904 1193 | 12279-96006 | 126 X 150 X 14 | UD BUS RE8 RA52 | 84/~86/ | Engine CRANK SHAFT REAR |
| 03904 2964 | 38212-Z5000 | 47 X 56 X 7 | UD BUS RM80,81,90,210,JM210,R B80 | 75/~95/ | Wheel Hub REAR OUTER |
| 03904 1336 | 43090-00Z00 | 154 X 175 X 13.5 | UD BUS RA53 C/# 00253~(ABS) | 90/7~92/ | Wheel Hub REAR INNER |
| 03904 3690 | 43090-00Z00 | 154 X 175 X 13.5 | UD BUS UA440,452,460,4E0,510,5 20,521 EXCEPT NON STEP BUS | 90/3~00/1 2 | Wheel Hub REAR INNER |
| 03904 7474 | 43090-00Z00 | 154 X 175 X 13.5 | UD BUS RA520,530,531,550,552 | 90/6~00/1 2 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 3778 | 43090-00Z00 | 154 X 175 X 13.5 | UD BUS RP210,211,250,252 | 91/8~00/12 | Wheel Hub REAR INNER |
| 03904 4229 | 43090-90000 | 124 X 170 X 14.5 | UD BUS DA50 | 82/2~84/ | Wheel Hub REAR INNER(FORWARD) |
| 03904 6693 | 43090-90060 | 154 X 175 X 13 | UD BUS DA66,67,GA66 | 84/5~93/ | Wheel Hub REAR INNER(FORWARD) |
| 03904 6374 | 43090-90060 | 154 X 175 X 13 | UD BUS RD630,RG550,620 | 01/1~ | Wheel Hub REAR INNER(FORWARD) |
| 03904 6418 | 38212-90013 | 74 X 156 X 13 X 17.5 | UD BUS RA520,530,531,550,RP210,211 | 90/6~94/12 | Wheel Hub REAR OUTER |
| 03904 5461 | 43090-Z5000 | 130 X 150 X 10 | UD BUS DA50,66,67,GA66,RD620,630,RG550,620 | 82/2~ | Wheel Hub REAR INNER(REARWARD) |
| 03904 2997 | 43090-90060 | 154 X 175 X 13 | UD BUS U(A)33,34,50 | 84/3~90/ | Wheel Hub REAR INNER |
| 03904 4350 | 38212-90006 | 60 X 72 X 7.5 | UD BUS RA46,50,51,52,60,RP80 | 73/~91/ | Wheel Hub REAR OUTER |
| 03904 6088 | 38212-90006 | 60 X 72 X 7.5 | UD BUS U(A)20,31,32,34,50 | 73/~90/ | Wheel Hub REAR OUTER |
| 03904 5769 | 38212-90006 | 60 X 72 X 7.5 | UD BUS RA53 C/# ~00252 | 86/3~91/ | Wheel Hub REAR OUTER |
| 03904 3195 | 38212-90006 | 60 X 72 X 7.5 | UD BUS RA53 C/# 00253~(EXCEPT ABS) | 90/7~92/ | Wheel Hub REAR OUTER |
| 03904 1699 | 38212-90006 | 60 X 72 X 7.5 | UD BUS DA50,66,67,GA66 | 82/2~93/ | Wheel Hub REAR OUTER |
| 03904 5142 | 38212-90008 | 51 X 62 X 7 | UD BUS JP211,250,252 | 91/8~ | Wheel Hub REAR OUTER |
| 03904 2018 | 38212-90013 | 74 X 156 X 13 X 17.5 | UD BUS UA440,510,520 | 90/3~95/ | Wheel Hub REAR OUTER |
| 03904 7144 | 32136-Z5003 | 65 X 78 X 9 | UD BUS EN210,211,250,252 | 93/5~01/ | Transmission REAR |
| 03904 3602 | 43090-00Z00 | 154 X 175 X 13.5 | UD BUS RD620,630,RG550,620 | 90/3~00/12 | Wheel Hub REAR INNER(FORWARD) |
| 03904 5439 | 43090-Z5000 | 130 X 150 X 10 | UD BUS RM80,90 | 75/~84/ | Wheel Hub REAR INNER |
| 03904 3899 | 40227-Z5001 | 100 X 114 X 12 | UD BUS RB80 | 88/7~92/ | Wheel Hub FRONT |
| 03904 5384 | 40227-Z5001 | 100 X 114 X 12 | UD BUS JM210,250,252 | 91/8~ | Wheel Hub FRONT |
| 03904 1765 | 40227-Z5001 | 100 X 114 X 12 | UD BUS EN210,211,250,252 | 94/6~ | Wheel Hub FRONT |
| 03904 6836 | 40227-Z5001 | 100 X 114 X 12 | UD BUS RN210,252 | 96/7~ | Wheel Hub FRONT |
| 03904 8068 | 43090-Z5000 | 130 X 150 X 10 | UD BUS RA4#,5#,6# | 73/~ | Wheel Hub FRONT |
| 03904 3107 | 43090-Z5000 | 130 X 150 X 10 | UD BUS RP80,210,211,250,252 | 86/2~ | Wheel Hub FRONT |
| 03904 7892 | 43090-Z5000 | 130 X 150 X 10 | UD BUS DA50,66,67,GA66,RD620,630,RG550,620 | 82/2~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 2480 | 43090-Z5000 | 130 X 150 X 10 | UD BUS U(A)2#,3#,4#,5#...EXCEPT NON STEP BUS | 73/~ | Wheel Hub FRONT |
| 03904 4944 | 43090-90060 | 154 X 175 X 13 | UD BUS UA452,460,4E0,521 EXCEPT NON STEP BUS | 01/1~ | Wheel Hub REAR INNER |
| 03904 7672 | 40227-90012 | 124 X 146 X 14 | UD BUS JP211,250,252 | 91/8~ | Wheel Hub FRONT |
| 03904 6231 | 43090-90060 | 154 X 175 X 13 | UD BUS RA531,550,552,RP250,252 | 01/1~ | Wheel Hub REAR INNER |
| 03904 4218 | 43090-90000 | 124 X 170 X 14.5 | UD BUS RA50,51,52,60 | 73/~85/5 | Wheel Hub REAR INNER |
| 03904 5681 | 43090-90000 | 124 X 170 X 14.5 | UD BUS U(A)20,30,31,32,36 | 73/~85/5 | Wheel Hub REAR INNER |
| 03904 5032 | 43090-Z5001 | 127 X 146 X 10 | UD BUS RM81,210,211,250,252,281 | 84/11~ | Wheel Hub REAR INNER |
| 03904 7023 | 43090-Z5001 | 127 X 146 X 10 | UD BUS EN210,211,250,252,JM210,250,252 | 91/8~ | Wheel Hub REAR INNER |
| 03904 2623 | 43090-90012 | 140 X 170 X 14 | UD BUS JP211,250,252 | 91/8~ | Wheel Hub REAR INNER |
| 03904 7507 | 43090-90060 | 154 X 175 X 13 | UD BUS RA53 C/#~00252 | 86/3~91/ | Wheel Hub REAR INNER |
| 03904 4306 | 43090-90060 | 154 X 175 X 13 | UD BUS RA53 C/# 00253~(EXCEPT ABS) | 90/7~92/ | Wheel Hub REAR INNER |
| 03904 6198 | 38212-90013 | 74 X 156 X 13 X 17.5 | UD BUS RD620,630,RG550,620 | 90/3~94/12 | Wheel Hub REAR OUTER |
| 03904 5131 | 43090-Z5000 | 130 X 150 X 10 | UD BUS UA272 NON STEP BUS | 00/1~ | Wheel Hub FRONT |
| 03904 4163 | 32136-Z5000 | 58 X 75 X 9 | UD BUS RM210,211,250,252,RN210,252 MHS5 | 86/10~ | Transmission REAR |
| 03904 5252 | 38212-90013 | 74 X 156 X 13 X 17.5 | UD BUS RA53 C/# 00253~(ABS) | 90/7~92/ | Wheel Hub REAR OUTER |
| 03904 3668 | 32219-Z5005 | 42 X 60 X 8 | UD BUS RB80 GREC | 88/7~92/ | Transmission FRONT |
| 03904 8024 | 32219-Z5005 | 42 X 60 X 8 | UD BUS RM210,211,250,252,2B1, RN210,252 MLS6 | 88/3~ | Transmission FRONT |
| 03904 3613 | 32219-Z5005 | 42 X 60 X 8 | UD BUS JM210,250,252,JP211,250,252 MLS6 | 88/3~ | Transmission FRONT |
| 03904 5714 | 32219-Z5005 | 42 X 60 X 8 | UD BUS RP210,211,250,252 MLS6 | 91/1~ | Transmission FRONT |
| 03904 5648 | 32219-Z5005 | 42 X 60 X 8 | UD BUS EN210,211,250,252 | 93/5~ | Transmission FRONT |
| 03904 5285 | 32136-Z5000 | 58 X 75 X 9 | UD BUS RM90,80 | 75/6~84/ | Transmission REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 7012 | 32219-90076 | 48 X 65 X 9 X 10 | UD BUS RP211,250 MPS | 93/9~97/ | Transmission FRONT |
| 03904 2755 | 32136-Z5000 | 58 X 75 X 9 | UD BUS RB80 MHS5,RP80 | 86/2~92/ | Transmission REAR |
| 03904 7089 | 32219-90075 | 48 X 65 X 9 X 9.5 | UD BUS RP252 MPS | 96/10~ | Transmission FRONT |
| 03904 5296 | 32136-Z5000 | 58 X 75 X 9 | UD BUS JM210,250,252,JP211,250, 252 MHS5 | 86/10~ | Transmission REAR |
| 03904 5912 | 32136-90062 | 70 X 88 X 12 | UD BUS RA4#,5#,6# | 73/~94/ | Transmission REAR |
| 03904 3459 | 32136-90062 | 70 X 88 X 12 | UD BUS U(A)20,3#,50 | 73/~90/ | Transmission REAR |
| 03904 3591 | 32136-90062 | 70 X 88 X 12 | UD BUS UA440,510,520,RA520,R D620 APS5,MPS5 | 89/1~96/ | Transmission REAR |
| 03904 4031 | 32136-90062 | 70 X 88 X 12 | UD BUS RP210,211,250,252 MLS6 | 90/11~ | Transmission REAR |
| 03904 2579 | 32136-90106 | 70 X 88 X 11 | UD BUS RP211,250,252 MPS | 94/7~ | Transmission REAR |
| 03904 3228 | 32136-90107 | 80 X 100 X 13 | UD BUS UA440,510,520,RA520,53 0,RD620 MTS6 | 89/5~97/ | Transmission REAR |
| 03904 2931 | 40227-Z5001 | 100 X 114 X 12 | UD BUS RM80,81,90,210,211,250, 252,2B1 | 75/~ | Wheel Hub FRONT |
| 03904 1776 | 32136-Z5000 | 58 X 75 X 9 | UD BUS RM81 TMH700,760,MHS50 | 84/11~90/ | Transmission REAR |
| 03904 1457 | 32219-Z5003 | 32 X 45 X 8 | UD BUS RM210,211,250,252,RN21 0,252 MHS5 | 86/10~ | Transmission FRONT |
| 03904 1292 | 38212-Z5007 | 57 X 123 X 11 X 21 | UD BUS EN210,211,250,252 | 94/6~ | Wheel Hub REAR OUTER |
| 03904 6440 | 38212-Z5007 | 57 X 123 X 11 X 21 | UD BUS JM250,252 | 95/3~ | Wheel Hub REAR OUTER |
| 03904 7716 | 38212-Z5007 | 57 X 123 X 11 X 21 | UD BUS RM211,250,252,2B1,RN2 10,252 | 95/3~ | Wheel Hub REAR OUTER |
| 03904 6330 | 38212-00Z01 | 74 X 156 X 14 X 22 | UD BUS RA530,531,550,552 | 95/1~ | Wheel Hub REAR OUTER |
| 03904 4174 | 38212-00Z01 | 74 X 156 X 14 X 22 | UD BUS RP210,211,250,252 | 95/1~ | Wheel Hub REAR OUTER |
| 03904 5472 | 38212-00Z01 | 74 X 156 X 14 X 22 | UD BUS UA452,460,4E0,521 EXCEPT NON STEP BUS | 94/7~ | Wheel Hub REAR OUTER |
| 03904 4614 | 38212-00Z01 | 74 X 156 X 14 X 22 | UD BUS RD620,630,RG550,620 | 95/1~ | Wheel Hub REAR OUTER |
| 03904 5098 | 32219-Z5003 | 32 X 45 X 8 | UD BUS RM90,80,RP80 | 75/~91/ | Transmission FRONT |
| 03904 7100 | 32219-Z5005 | 42 X 60 X 8 | UD BUS RM81 TMH780,MLS60 | 84/11~90/ | Transmission FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 4669 | 32219-Z5003 | 32 X 45 X 8 | UD BUS RB80 EXCEPT GRERC | 88/7~92/ | Transmission FRONT |
| 03904 2282 | 32136-Z5003 | 65 X 78 X 9 | UD BUS RB80 MLS6 | 88/7~92/ | Transmission REAR |
| 03904 3635 | 32219-Z5003 | 32 X 45 X 8 | UD BUS JM210,250,252,JP211,250, 252 MHS5 | 86/10~ | Transmission FRONT |
| 03904 6616 | 32219-90014 | 48 X 65 X 9 | UD BUS U(A)20,30,31,36,RA50,51, 60 | 76/3~85/ | Transmission FRONT |
| 03904 5813 | 32219-90014 | 48 X 65 X 9 | UD BUS UA440,510,520,RA520,R D620 APS5 | 89/1~96/ | Transmission FRONT |
| 03904 2469 | 32219-90002 | 42 X 65 X 9 | UD BUS RA50 | 73/~76/2 | Transmission FRONT |
| 03904 4570 | 32219-90002 | 42 X 65 X 9 | UD BUS U(A)20,30 TMH410 | 73/~76/2 | Transmission FRONT |
| 03904 4713 | 32219-90018 | 56 X 72 X 9 | UD BUS RA46,52,53 | 84/3~94/ | Transmission FRONT |
| 03904 6671 | 32219-90018 | 56 X 72 X 9 | UD BUS U(A)32,33,50 | 84/3~90/ | Transmission FRONT |
| 03904 3250 | 32219-90018 | 56 X 72 X 9 | UD BUS UA440,510,520,RA520,53 0,RD620 MPS5,MTS6 | 89/1~96/ | Transmission FRONT |
| 03904 6594 | 32219-Z5003 | 32 X 45 X 8 | UD BUS RM81 TMH700,760,MHS50 | 84/11~90/ | Transmission FRONT |
| 03904 5021 | 13207-97001 | | UD TRUCK TRACTOR ENGINE PE6#,PF6# | 79/~01/ | Crank Shaft VALVE STEM SEAL |
| 03904 5846 | 12279-96007 | 138 X 162 X 14 | UD TRUCK TRACTOR ENGINE PF6# | 89/~93/9 | Crank Shaft REAR |
| 03904 3184 | 13207-97000 | | UD TRUCK TRACTOR ENGINE RE8,RE10(IN.) | 83/~95/ | Crank Shaft VALVE STEM SEAL |
| 03904 6297 | 12260-97002 | 132 X 150 X 14 | UD TRUCK TRACTOR ENGINE RE10 E/# 000552~ | 85/~86/1 | Crank Shaft REAR |
| 03904 3239 | 12270-96003 | 138 X 162 X 14 X 18 | UD TRUCK TRACTOR ENGINE PF6# | 93/10~97/ 9 | Crank Shaft FRONT |
| 03904 4548 | 12270-96005 | 138 X 173 X 17 | UD TRUCK TRACTOR ENGINE PF6# | 97/10~02/ | Crank Shaft REAR |
| 03904 4977 | 12270-97002 | 126 X 150 X 14 X 18 | UD TRUCK TRACTOR ENGINE NF6TA | 94/~01/ | Crank Shaft REAR |
| 03904 2403 | 12270-97005 | 133 X 168 X 17.5 | UD TRUCK TRACTOR ENGINE RG8 WITH PTO | 02/4~ | Crank Shaft REAR |
| 03904 6803 | 12270-97005 | 133 X 168 X 17.5 | UD TRUCK TRACTOR ENGINE PU6 | 01/3~ | Crank Shaft REAR |
| 03904 1314 | 12270-97007 | 133 X 157 X 18 X 22 | UD TRUCK TRACTOR ENGINE RE8,RF8,RF10 | 93/8~94/ | Crank Shaft REAR |
| 03904 2942 | 12270-97009 | 133 X 168 X 17 | UD TRUCK TRACTOR ENGINE RF8,RF10 | 95/~ | Crank Shaft REAR |
| 03904 6902 | 12279-97006 | 133 X 157 X 14 | UD TRUCK TRACTOR ENGINE RE10 E/# | 86/~90/ | Crank Shaft REAR |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | | 020162~ | | |
| 03904 7551 | 12279-95500 | 126 X 150 X 13 | UD TRUCK TRACTOR ENGINE NF6TA | 88/~93/ | Crank Shaft REAR |
| 03904 2359 | 12279-96001 | 126 X 195 X 15 | UD TRUCK TRACTOR ENGINE PD6,PE6 WITH REAR PTO | 70/~90/ | Crank Shaft REAR |
| 03904 5945 | 12279-Z6000 | 112 X 147 X 17 | UD TRUCK TRACTOR ENGINE MD92TB | 99/~ | Crank Shaft REAR |
| 03904 7034 | 13207-97000 | | UD TRUCK TRACTOR ENGINE NF6TA,RH8,RH10 | 89/~01/ | Crank Shaft VALVE STEM SEAL |
| 03904 5956 | 13207-97000 | | UD TRUCK TRACTOR ENGINE GE13# | 98/~ | Crank Shaft VALVE STEM SEAL |
| 03904 7452 | 13207-97000 | | UD TRUCK TRACTOR ENGINE RD8,RD10(IN.) | 72/~86/ | Crank Shaft VALVE STEM SEAL |
| 03904 1545 | 13207-97000 | | UD TRUCK TRACTOR ENGINE RF8,RF10,RG8(IN.) | 86/~00/ | Crank Shaft VALVE STEM SEAL |
| 03904 4966 | 13207-97001 | | UD TRUCK TRACTOR ENGINE PU6 | 01/~ | Crank Shaft VALVE STEM SEAL |
| 03904 4405 | 13207-97001 | | UD TRUCK TRACTOR ENGINE RD8,RD10(EX.) | 72/~86/ | Crank Shaft VALVE STEM SEAL |
| 03904 1490 | 13207-97001 | | UD TRUCK TRACTOR ENGINE RE8,RE10(EX.) | 83/~95/ | Crank Shaft VALVE STEM SEAL |
| 03904 4262 | 13207-97001 | | UD TRUCK TRACTOR ENGINE RF8,RF10,RG8(EX.) | 86/~00/ | Crank Shaft VALVE STEM SEAL |
| 03904 3888 | 13207-Z5500 | | UD TRUCK TRACTOR ENGINE MD92TB | 98/~ | Crank Shaft VALVE STEM SEAL |
| 03904 7903 | 12270-97009 | 133 X 168 X 17 | UD TRUCK TRACTOR ENGINE RG8,RH8,RH10,GE13# | 92/~ | Crank Shaft REAR |
| 03904 2150 | 12278-97002 | 109.5 X 150 X 17 | UD TRUCK TRACTOR ENGINE RE10,RF8,RF10,RG8,RH8 ,RH10 | 92/~ | Crank Shaft FRONT |
| 03904 3481 | 12278-90010 | 70 X 88 X 9 | UD TRUCK TRACTOR ENGINE RE8,RE10 | 83/~85/ | Crank Shaft FRONT |
| 03904 4746 | 12278-90006 | 62 X 85 X 13.5 | UD TRUCK TRACTOR ENGINE ND6,PD6 | 70/~79/ | Crank Shaft FRONT |
| 03904 6462 | 12278-90006 | 62 X 85 X 13.5 | UD TRUCK TRACTOR ENGINE PE6# | 79/~90/ | Crank Shaft FRONT |
| 03904 3470 | 12278-97000 | 70 X 88 X 8 | UD TRUCK TRACTOR ENGINE RE8 E/# 030001~ | 85/93/ | Crank Shaft FRONT |
| 03904 5505 | 12278-97000 | 70 X 88 X 8 | UD TRUCK TRACTOR ENGINE RE10..E/# 020001~ | 85/~90/ | Crank Shaft FRONT |
| 03904 7386 | 12278-97000 | 70 X 88 X 8 | UD TRUCK TRACTOR ENGINE RF8,RF10 | 86/~92/ | Crank Shaft FRONT |

# 5. Seals product list

## 5.4 NISSAN DIESEL / UD

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03904 6891 | 12277-Z0000 | 85 X 110 X 13 | UD TRUCK TRACTOR ENGINE PF6# | 93/~02/ | Crank Shaft FRONT |
| 03904 1127 | 12277-Z0000 | 85 X 110 X 13 | UD TRUCK TRACTOR ENGINE PU6 | 01/3~ | Crank Shaft FRONT |
| 03904 3745 | 12278-00Z00 | 95 X 136 X 17 | UD TRUCK TRACTOR ENGINE GE13# | 99/~ | Crank Shaft FRONT |
| 03904 7001 | 12279-97006 | 133 X 157 X 14 | UD TRUCK TRACTOR ENGINE RE8,RF8,RF10 | 85/~93/7 | Crank Shaft REAR |
| 03904 6011 | 12278-96001 | 62 X 85 X 12 | UD TRUCK TRACTOR ENGINE PF6# | 89/~92/ | Crank Shaft FRONT |
| 03904 1919 | 12278-90010 | 70 X 88 X 9 | UD TRUCK TRACTOR ENGINE RD8,RD10 | 72/~86/ | Crank Shaft FRONT |
| 03904 2865 | 12278-Z6000 | 88 X 123 X 16 | UD TRUCK TRACTOR ENGINE MD92TB | 98/~ | Crank Shaft FRONT |
| 03904 1787 | 12278-90013 | 68.7 X 90.5 X 7.5 | UD TRUCK TRACTOR ENGINE RD8 | 72/~83/ | Crank Shaft FRONT (OUTSIDE) |
| 03904 8134 | 12278-90013 | 68.7 X 90.5 X 7.5 | UD TRUCK TRACTOR ENGINE RD10 E/#~031348 | 79/~85/ | Crank Shaft FRONT (OUTSIDE) |
| 03904 5351 | 12278-90013 | 68.7 X 90.5 X 7.5 | UD TRUCK TRACTOR ENGINE RE8 E/#~009971 | 83/~85/ | Crank Shaft FRONT (OUTSIDE) |
| 03904 7562 | 12278-90013 | 68.7 X 90.5 X 7.5 | UD TRUCK TRACTOR ENGINE RE10 E/#~001851 | 83/~85/ | Crank Shaft FRONT (OUTSIDE) |
| 03904 5197 | 12279-96006 | 126 X 150 X 14 | UD TRUCK TRACTOR ENGINE PD6 | 70/~79/ | Crank Shaft REAR |
| 03904 5043 | 12279-96006 | 126 X 150 X 14 | UD TRUCK TRACTOR ENGINE PE6# | 79/~90/ | Crank Shaft REAR |
| 03904 3140 | 12279-96006 | 126 X 150 X 14 | UD TRUCK TRACTOR ENGINE RD8,RD10 | 72/~86/ | Crank Shaft REAR |
| 03904 5406 | 12279-96006 | 126 X 150 X 14 | UD TRUCK TRACTOR ENGINE RE8,RE10 | 83/~85/ | Crank Shaft REAR |
| 03904 1798 | 12279-95000 | 120 X 140 X 13 | UD TRUCK TRACTOR ENGINE ND6 | 70/~79/ | Crank Shaft REAR |
| 03904 6913 | 12278-95500 | 62 X 85 X 12 | UD TRUCK TRACTOR ENGINE NF6TA | 89/~01/ | Crank Shaft FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1199 | MD050606 | 44 x 60 x 7 | AIRTREK CU2W(4G63),CU4W(4G64) | 01/6~ | Engine CRANK SHAFT FRONT |
| 03905 1130 | MD755904 | 41 x 61 x 9 x 13.5 | AIRTREK CU2WLYXFZ(4WD) | 02/6~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 8636 | MD758763 | 41 x 61 x 11.5 x 16 | AIRTREK CU2W,4W 4WD EXC.CU2WLYXFZ | 01/6~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 5684 | MD707575 | 42 x 60 x 9 | AIRTREK CU2W,4W | 01/6~ | Mission & Differential (A/T) CONVERTER OIL PUMP |
| 03905 8135 | MB393929 | 35 x 65 x 12 | AIRTREK CU2W,4W 4WD | 01/6~ | Mission & Differential (A/T) REAR DIFF. PINION |
| 03905 2357 | MD707184 | 35 x 56 x 9 x 12 | AIRTREK CU2W,4W 4WD | 01/6~ | Mission & Differential (A/T) REAR DIFF. SIDE |
| 03905 3800 | MN101885 | | AIRTREK CU2W,4W | 01/6~ | Power Steering SEAL KIT |
| 03905 8933 | MD755904 | 41 x 61 x 9 x 13.5 | AIRTREK CU2W,4W 2WD | 01/6~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 4772 | MD095355 | 20 x 30 x 7 | AIRTREK CU2W(4G63),CU4W(4G64) | 01/6~ | Engine OIL PUMP |
| 03905 6314 | MD069950 | 25 x 35 x 6 | AIRTREK CU2W(4G63),CU4W(4G64) | 01/6~ | Engine BALANCER SHAFT |
| 03905 9005 | MD184303 | | AIRTREK 4G63(EXC. TURBO) IN. & EX. | 01/6~ | Engine VALVE STEM SEAL |
| 03905 4307 | MD184303 | | AIRTREK 4G64(SOHC) IN. & EX. | 02/12~ | Engine VALVE STEM SEAL |
| 03905 5669 | MD306079 | | AIRTREK 4G63(TURBO) IN. | 02/6~ | Engine VALVE STEM SEAL |
| 03905 2216 | MD306079 | | AIRTREK 4G64(DOHC) IN. | 01/6~ | Engine VALVE STEM SEAL |
| 03905 5441 | MD307343 | | AIRTREK 4G63(TURBO) EX. | 02/6~ | Engine VALVE STEM SEAL |
| 03905 8309 | MD307343 | | AIRTREK 4G64(DOHC) EX. | 01/6~ | Engine VALVE STEM SEAL |
| 03905 4478 | MD153103 | 35 x 50 x 8 | AIRTREK CU2W(4G63),CU4W(4G64) | 01/6~ | Engine CAM SHAFT |
| 03905 3341 | MD359158 | 85 x 103 x 7.5 | AIRTREK CU2W(4G63),CU4W(4G64) | 01/6~ | Engine CRANK SHAFT REAR |
| 03905 1166 | ME202850 | 50 x 74 x 11 | CANTER (1T~1.5T) 4M40 FB501,50A,511,51A,70A, FD501,50A,70A | 96/11~ | Engine CRANK SHAFT FRONT |
| 03905 4508 | MH034213 | 52 x 84 x 14 | CANTER (1T~1.5T) FB51A..A1A46,47,B8# | 99/3~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7925 | MH034213 | 52 x 84 x 14 | CANTER (1T~1.5T) FB511,70A B8# | 93/10~ | Final Drive PINION |
| 03905 2585 | MH034213 | 52 x 84 x 14 | CANTER (1T~1.5T) FC563 | 96/11~99/ | Final Drive PINION |
| 03905 1724 | MH034213 | 52 x 84 x 14 | CANTER (1T~1.5T) FD378 | 92/9~93/ | Final Drive PINION |
| 03905 8009 | MH034213 | 52 x 84 x 14 | CANTER (1T~1.5T) FD501,50A,70A B2# | 93/10~ | Final Drive PINION |
| 03905 2876 | MB664285 | 44 x 72 x 12 | CANTER (1T~1.5T) FD# | 92/9~97/11 | Final Drive PINION (FRONT DIFF.) |
| 03905 8432 | MB160578 | 42 x 65 x 12 | CANTER (1T~1.5T) FD# | 97/11~ | Final Drive PINION (FRONT DIFF.) |
| 03905 8222 | MD008762 | 35 x 50 x 8 | CANTER (1T~1.5T) 4G63,4G64 FA5#,FB500,510,FC563 | 96/11~ | Engine CAM SHAFT |
| 03905 8696 | MD095355 | 20 x 30 x 7 | CANTER (1T~1.5T) 4G63,4G64 FA5#,FB500,510,FC563 | 96/11~ | Engine OIL PUMP |
| 03905 2435 | MD008882 | 44 x 60 x 7 | CANTER (1T~1.5T) 4G63,4G64 FA5#,FB500,510,FC563 | 96/11~ | Engine CRANK SHAFT FRONT |
| 03905 7718 | 31311-06101 | 48 x 70 x 12 | CANTER (1T~1.5T) 4DR51 FB100,120,300 | 80/11~89/ | Engine CRANK SHAFT FRONT |
| 03905 1289 | ME241213 | | CANTER (1T~1.5T) 4M40 IN. & EX. | 93/10~ | Engine VALVE STEM SEAL |
| 03905 3776 | ME200028 | 52 x 74 x 11 x 19 | CANTER (1T~1.5T) 4M40 FB501,50A,511,51A,70A, FD501,50A,70A | 93/10~96/10 | Engine CRANK SHAFT FRONT |
| 03905 6230 | MB160949 | 45 x 72 x 12 x 19.5 | CANTER (1T~1.5T) FB511,70A EXC. B8# | 93/10~ | Final Drive PINION |
| 03905 8681 | MD359158 | 85 x 103 x 7.5 | CANTER (1T~1.5T) 4G63,4G64 FA5#,FB500,510,FC563 | 96/11~ | Engine CRANK SHAFT REAR |
| 03905 6683 | ME001196 | 96 x 113 x 16 | CANTER (1T~1.5T) 4DR51 | 80/11~86/1 | Engine CRANK SHAFT REAR |
| 03905 5480 | ME001293 | 90 x 113 x 15 | CANTER (1T~1.5T) 4DR51 | 86/1~89/ | Engine CRANK SHAFT REAR |
| 03905 6695 | ME001293 | 90 x 113 x 15 | CANTER (1T~1.5T) 4DR7 | 89/10~93/ | Engine CRANK SHAFT REAR |
| 03905 7661 | ME200012 | 92 x 114 x 8 x 17 | CANTER (1T~1.5T) 4M40 | 93/10~96/2 | Engine CRANK SHAFT REAR |
| 03905 4970 | ME202115 | 90 x 114 x 10.5 x 17 | CANTER (1T~1.5T) 4M40 | 96/3~96/10 | Engine CRANK SHAFT REAR |
| 03905 2951 | ME202851 | 94.5 x 114 x 12 | CANTER (1T~1.5T) 4M40 | 96/11~99/5 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3668 | ME203250 | 90.5 x 114 x 12 | CANTER (1T~1.5T) 4M40 | 99/6~ | Engine CRANK SHAFT REAR |
| 03905 5393 | MD184303 | | CANTER (1T~1.5T) 4G63,4G64 IN. & EX. | 96/11~ | Engine VALVE STEM SEAL |
| 03905 2204 | ME241213 | | CANTER (1T~1.5T) 4DR51,4DR7 IN. & EX. | 80/11~93/ | Engine VALVE STEM SEAL |
| 03905 7289 | ME001509 | 48 x 70 x 8 | CANTER (1T~1.5T) 4DR7 FB308,328,FD378 | 89/10~93/ | Engine CRANK SHAFT FRONT |
| 03905 8369 | MH034067 | 32 x 45 x 8 | CANTER (1T~1.5T) FA#,FB#,FD# | 96/11~99/ | Transmission FRONT |
| 03905 3101 | MB025291 | 52 x 73 x 10 | CANTER (1T~1.5T) FA# | 96/11~99/ | Wheel Hub FRONT |
| 03905 7811 | MB025291 | 52 x 73 x 10 | CANTER (1T~1.5T) FB#...EXC. FB51AA1A46,47 | 80/11~ | Wheel Hub FRONT |
| 03905 4031 | MT119305 | 68 x 90 x 12 | CANTER (1T~1.5T) FB51AA1A46,47 | 99/3~02/ | Wheel Hub FRONT |
| 03905 3197 | MT119305 | 68 x 90 x 12 | CANTER (1T~1.5T) FC563 | 96/11~99/ | Wheel Hub FRONT |
| 03905 5414 | MH034185 | 64 x 84 x 8 x 12 | CANTER (1T~1.5T) FD# | 92/9~ | Wheel Hub FRONT |
| 03905 7529 | MB161153 | 74 x 100 x 10 | CANTER (1T~1.5T) FA# | 96/11~99/ | Wheel Hub REAR INNER |
| 03905 2879 | MB161153 | 74 x 100 x 10 | CANTER (1T~1.5T) FB#...EXC. FB51AA1A46,47 | 80/11~ | Wheel Hub REAR INNER |
| 03905 7412 | MB161153 | 74 x 100 x 10 | CANTER (1T~1.5T) FD# | 92/9~ | Wheel Hub REAR INNER |
| 03905 1022 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (1T~1.5T) FB51AA1A46,47 | 99/3~02/ | Wheel Hub REAR INNER |
| 03905 7313 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (1T~1.5T) FC563 | 96/11~99/ | Wheel Hub REAR INNER |
| 03905 9032 | MB161139 | 74.4 x 93.5 x 6.8 | CANTER (1T~1.5T) FB100,120 | 80/11~85/ | Wheel Hub REAR OUTER |
| 03905 8540 | MH034213 | 52 x 84 x 14 | CANTER (1T~1.5T) FB100,300A#,308A# | 80/11~93/ | Final Drive PINION |
| 03905 6533 | MB308934 | 46 x 95 x 10 x 14 | CANTER (1T~1.5T) FD# | 92/9~ | Wheel Hub REAR OUTER |
| 03905 6458 | MB160949 | 45 x 72 x 12 x 19.5 | CANTER (1T~1.5T) FD501,50A,70A B1# | 93/10~ | Final Drive PINION |
| 03905 4763 | MH034147 | 40 x 58 x 8 | CANTER (1T~1.5T) FC563 | 96/11~99/ | Transmission FRONT |
| 03905 2936 | MH034177 | 48 x 65 x 9 | CANTER (1T~1.5T) FA# | 96/11~99/ | Transmission REAR EXTENTION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4313 | MH034177 | 48 x 65 x 9 | CANTER (1T~1.5T) FB1#,3# | 80/11~93/ | Transmission REAR EXTENTION |
| 03905 5900 | MH034177 | 48 x 65 x 9 | CANTER (1T~1.5T) FB5#...4G63 | 99/3~ | Transmission REAR EXTENTION |
| 03905 7955 | MH034181 | 50 x 65 x 9 | CANTER (1T~1.5T) FB5#...4M40 | 93/10~ | Transmission REAR EXTENTION |
| 03905 5534 | MH034181 | 50 x 65 x 9 | CANTER (1T~1.5T) FC563 | 96/11~99/ | Transmission REAR EXTENTION |
| 03905 1046 | MB664285 | 44 x 72 x 12 | CANTER (1T~1.5T) FB120,300B#,308B# | 80/11~93/ | Final Drive PINION |
| 03905 6863 | MB160949 | 45 x 72 x 12 x 19.5 | CANTER (1T~1.5T) FA# | 96/11~99/ | Final Drive PINION |
| 03905 5405 | MB160949 | 45 x 72 x 12 x 19.5 | CANTER (1T~1.5T) FB500,501,50A,510,700 | 93/10~ | Final Drive PINION |
| 03905 1979 | MB160949 | 45 x 72 x 12 x 19.5 | CANTER (1T~1.5T) FB51A EXC. A1A46,47,B8# | 99/3~ | Final Drive PINION |
| 03905 1508 | MB308933 | 46 x 102 x 10 x 16 | CANTER (1T~1.5T) FB51AA1A46,47 | 99/3~02/ | Wheel Hub REAR OUTER |
| 03905 5213 | MB308934 | 46 x 95 x 10 x 14 | CANTER (1T~1.5T) FA# | 96/11~99/ | Wheel Hub REAR OUTER |
| 03905 2291 | MB308934 | 46 x 95 x 10 x 14 | CANTER (1T~1.5T) FB#...EXC.FB100,120,51 AA1A46,47 | 80/11~ | Wheel Hub REAR OUTER |
| 03905 7973 | MB420112 | 36 x 50 x 8 | CANTER (2T~) FG325,327,335,337,435,4 37,537,538,638 | 85/12~99/ | Wheel Hub FRONT AXLE SHAFT |
| 03905 2414 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE83D EN#,GN# | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 6494 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE82C,82D,82E,83C,88E | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 3410 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE7## | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 4778 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE63E EXCEPT CY6#,CY7#,EY7#,GY6# | 99/3~02/ | Wheel Hub REAR WHEEL INNER |
| 03905 6116 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE63D EXCEPT CY7#,EY7#,GY7# | 99/3~02/ | Wheel Hub REAR WHEEL INNER |
| 03905 4352 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE62E,63C,69E | 99/3~02/ | Wheel Hub REAR WHEEL INNER |
| 03905 4064 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE632,636,637,638,639,64 2,648,649,662,667,668,669 | 93/10~99/ | Wheel Hub REAR WHEEL INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7532 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE5## | 93/10~02/ | Wheel Hub REAR WHEEL INNER |
| 03905 1544 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE3##,4## | 85/9~93/ | Wheel Hub REAR WHEEL INNER |
| 03905 4016 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE1##,2## | 78/11~85/ | Wheel Hub REAR WHEEL INNER |
| 03905 1409 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE53E BX6#,CX6# | 00/6~02/ | Wheel Hub FRONT |
| 03905 6965 | MB420112 | 36 x 50 x 8 | CANTER (2T~) FG53E,63E | 99/3~02/ | Wheel Hub FRONT AXLE SHAFT |
| 03905 7514 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FG ALL | 85/12~ | Wheel Hub REAR WHEEL INNER |
| 03905 6647 | MB420155 | 72 x 96 x 8 x 12 | CANTER (2T~) FG73E,83E | 02/5~ | Wheel Hub FRONT |
| 03905 6062 | MB420155 | 72 x 96 x 8 x 12 | CANTER (2T~) FG53E,63E | 99/3~02/ | Wheel Hub FRONT |
| 03905 4199 | MB420155 | 72 x 96 x 8 x 12 | CANTER (2T~) FG325,335,337,435,437,537,538,638 | 85,12~99/ | Wheel Hub FRONT |
| 03905 7823 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FF658,659,63D,63E,83D,83E | 96/11~ | Wheel Hub FRONT |
| 03905 1211 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE83E EXCEPT C4#,C6#,CX6#,EV6 | 02/5~ | Wheel Hub FRONT |
| 03905 6599 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE83D | 02/5~ | Wheel Hub FRONT |
| 03905 3797 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE73E BY6#,CY6#,EY6# | 02/5~ | Wheel Hub FRONT |
| 03905 6203 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE69E EV31 | 99/3~02/ | Wheel Hub FRONT |
| 03905 5729 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE63E CX3#,CY6#,CY7#,EY6#, EY7#,GY6# | 99/3~02/ | Wheel Hub FRONT |
| 03905 1244 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE63D CY7#,EV3#,EX3#,EY7#,E3#,GX3#,GY7 | 99/3~02/ | Wheel Hub FRONT |
| 03905 1175 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE63C EV355 | 99/3~02/ | Wheel Hub FRONT |
| 03905 4634 | MB420112 | 36 x 50 x 8 | CANTER (2T~) FG73E,83E | 02/5~ | Wheel Hub FRONT AXLE SHAFT |
| 03905 6545 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE63D EXCEPT CY7#,EY7#,GY7# | 99/3~02/ | Wheel Hub REAR WHEEL OUTER |
| 03905 5327 | MH034175 | 130 x 146 x 14 | CANTER (2T~) FE83D JZ7 | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 1847 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE1##,2## | 78/11~85/ | Wheel Hub REAR WHEEL OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3569 | MB308966 | 56 x 114 x 10 | CANTER (2T~) FE63E CY6#,CY7#,EY6#,EY7#, GY6# | 99/3~02/ | Wheel Hub REAR WHEEL OUTER |
| 03905 9014 | MB308966 | 56 x 114 x 10 | CANTER (2T~) FE3D CY7#,EY7#,GY7# | 99/3~02/ | Wheel Hub REAR WHEEL OUTER |
| 03905 7670 | MB308966 | 56 x 114 x 10 | CANTER (2T~) FE652,658,659 | 95/3~99/ | Wheel Hub REAR WHEEL OUTER |
| 03905 2276 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FG ALL | 85/12~ | Wheel Hub REAR WHEEL OUTER |
| 03905 4040 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FF ALL | 96/11~ | Wheel Hub REAR WHEEL OUTER |
| 03905 3065 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE83E C4#,C6#,CX3#,CX6#,EN# ,GN# | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 3605 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE83D EN#,GN# | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 2774 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE82C,82D,82E,83C,88E | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 5378 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FE83E C4#,C6#,CX3#,CX6#,EN# ,GN# | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 8903 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE63E EXCEPT CY6#,CY7#,EY6#,EY7#, GY6# | 99/3~02/ | Wheel Hub REAR WHEEL OUTER |
| 03905 5372 | MB161152 | 70 x 112 x 10 x 18.5 | CANTER (2T~) FF ALL | 96/11~ | Wheel Hub REAR WHEEL INNER |
| 03905 4001 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE62E,63C,69E | 99/3~02/ | Wheel Hub REAR WHEEL OUTER |
| 03905 6191 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE632,636,637,638,639,64 2,648,649,662,667,668,669 | 93/10~99/ | Wheel Hub REAR WHEEL OUTER |
| 03905 2237 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE63E C4#,C6#,CX6#,EV1# | 99/3~02/ | Wheel Hub FRONT |
| 03905 1268 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE5## | 93/10~02/ | Wheel Hub REAR WHEEL OUTER |
| 03905 1568 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE3##,4## | 85/9~93/ | Wheel Hub REAR WHEEL OUTER |
| 03905 4823 | MB308965 | 85 x 127 x 13 | CANTER (2T~) FE83E CY#,EY#,GY# | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 2912 | MB308965 | 85 x 127 x 13 | CANTER (2T~) FE83D CY7#,EY7#,GY7# | 02/5~ | Wheel Hub REAR WHEEL INNER |
| 03905 5867 | MB308965 | 85 x 127 x 13 | CANTER (2T~) FE63E CY6#,CY7#,EY6#,EY7#, GY6# | 99/3~02/ | Wheel Hub REAR WHEEL INNER |
| 03905 6944 | MB308965 | 85 x 127 x 13 | CANTER (2T~) FE63D CY7#,EY7#,GY7# | 99/3~02/ | Wheel Hub REAR WHEEL INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1862 | MB308965 | 85 x 127 x 13 | CANTER (2T~) FE652,658,659 | 95/3~99/ | Wheel Hub REAR WHEEL INNER |
| 03905 2750 | MB308966 | 56 x 114 x 10 | CANTER (2T~) FE83D CY7#,EY7#,GY7# | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 8741 | MB308933 | 46 x 102 x 10 x 16 | CANTER (2T~) FE7## | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 1235 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE512,517,518,532,533,536,537,538 | 93/10~99/ | Wheel Hub FRONT |
| 03905 5600 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE507,508,527,528 | 93/10~99/ | Wheel Hub FRONT |
| 03905 7490 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE516 BT# | 93/10~99/ | Wheel Hub FRONT |
| 03905 2261 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE50C,50E,52C,52E | 99/3~02/ | Wheel Hub FRONT |
| 03905 5918 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE53E CIM# | 99/3~02/ | Wheel Hub FRONT |
| 03905 6464 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE111 EXCEPT B,E | 78/11~85/ | Wheel Hub FRONT |
| 03905 4721 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE114 EXCEPT B,BG,E,EW | 82/11~85/ | Wheel Hub FRONT |
| 03905 6344 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE131,134 | 81/3~85/ | Wheel Hub FRONT |
| 03905 4091 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE211,214 CZZ,EZZ(S) | 79/4~85/ | Wheel Hub FRONT |
| 03905 6440 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE311,315,317 DUMP(BD#,BN#) | 85/9~91/4 | Wheel Hub FRONT |
| 03905 9053 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE662,668,669 E3#,EV3# | 96/11~99/ | Wheel Hub FRONT |
| 03905 8729 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE337 EXCEPT EGE#,EHE# | 87/9~91/4 | Wheel Hub FRONT |
| 03905 5837 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE337 EGE#,EHE# | 89/10~91/4 | Wheel Hub FRONT |
| 03905 1310 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE355,431,434,435,437,437,439 | 85/9~93/ | Wheel Hub FRONT |
| 03905 4940 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE334,335 EXCEPT EHE# | 85/9~91/4 | Wheel Hub FRONT |
| 03905 7235 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE542,548,562,566,567,568,636,637,667 | 95/3~99/ | Wheel Hub FRONT |
| 03905 6899 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE516 EXCEPT BT# | 93/10~99/ | Wheel Hub FRONT |
| 03905 1091 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE632 C4#,C6#,G1#,G4#,G6# | 97/10~99/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5582 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE638 EXCEPT E3#,EN4#,EV3#,F3#,G3# | 93/10~99/ | Wheel Hub FRONT |
| 03905 2759 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE639 EXCEPT E3#,EV3# | 93/10~99/ | Wheel Hub FRONT |
| 03905 7802 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE648 C6A,E6A,E6VM,G6A | 96/11~99/ | Wheel Hub FRONT |
| 03905 1790 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE662 E1#,E4#,E6#,EV1#,EV4#, EV6# | 97/10~99/ | Wheel Hub FRONT |
| 03905 7628 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE668,669 EV1#,EV4#,EV6# | 96/11~99/ | Wheel Hub FRONT |
| 03905 1214 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE51C,51E,53C,59E,62E | 99/3~02/ | Wheel Hub FRONT |
| 03905 5459 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE53E EXCEPT CIM#,BX62#,CX62# | 99/3~02/ | Wheel Hub FRONT |
| 03905 6008 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE63C EXCEPT EV355 | 99/3~02/ | Wheel Hub FRONT |
| 03905 4892 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE63D EV1#,EV4#,EV6#,E6#,G1 #,G4#,G6# | 99/3~02/ | Wheel Hub FRONT |
| 03905 5861 | MB308966 | 56 x 114 x 10 | CANTER (2T~) FE83E CY#,EY#,GY# | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 6470 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE444,445,447,449,465,46 7 | 85/9~93, | Wheel Hub FRONT |
| 03905 6554 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE70C,70E,71C,71E,72C, 72E,73C,79E | 02/5~ | Wheel Hub FRONT |
| 03905 3368 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE82C,82D,82E,83C,88E | 02/5~ | Wheel Hub FRONT |
| 03905 5954 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE73E B1#,B3#,B4#,B6#,BX#,E N# | 02/5~ | Wheel Hub FRONT |
| 03905 3977 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE83E C4#,C6#,CX6#,EV6 | 02/5~ | Wheel Hub FRONT |
| 03905 8186 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FG507,508 | 96/10~99/ | Wheel Hub FRONT |
| 03905 7397 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FG50E,52E,62E,68E | 99/3~02/ | Wheel Hub FRONT |
| 03905 1103 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FG70E,72E,82E,88E | 02/5~ | Wheel Hub FRONT |
| 03905 7295 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE69E EV11 | 99/3~02/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6704 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE231,234 | 80/12~85/ | Wheel Hub FRONT |
| 03905 2819 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE648 ALL | 93/10~96/ 11 | Wheel Hub FRONT |
| 03905 6536 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE632 EN4#,G3# | 97/10~99/ | Wheel Hub FRONT |
| 03905 8444 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE638 E#,EN4#,EV3#,F3#,G3# | 93/10~99/ | Wheel Hub FRONT |
| 03905 7988 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE639 E3#,EV3# | 83/10~99/ | Wheel Hub FRONT |
| 03905 1511 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE642 | 97/10~99/ | Wheel Hub FRONT |
| 03905 3134 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE334,335 EHE# | 85/9~91/4 | Wheel Hub FRONT |
| 03905 2978 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE648 C3#,E3#,G3# | 96/11~99/ | Wheel Hub FRONT |
| 03905 4793 | MT119305 | 68 x 90 x 12 | CANTER (2T~) FE307,311,315,317,331,33 5,337 | 91/4~93/ | Wheel Hub FRONT |
| 03905 5447 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE211,214 EXCEPT CZZ,EZZ(S) | 79/4~85/ | Wheel Hub FRONT |
| 03905 4346 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE300,301,305,320,321,32 5,425 | 85/9~93/ | Wheel Hub FRONT |
| 03905 6170 | MB025295 | 72 x 94 x 10 | CANTER (2T~) FE649,652,658,659 | 93/10~99/ | Wheel Hub FRONT |
| 03905 7874 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE100,101,120,121,124,22 1,224 | 78/11~85/ | Wheel Hub FRONT |
| 03905 6788 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE307,331 | 89/10~91/ 4 | Wheel Hub FRONT |
| 03905 2705 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE114 B,BG,E,EW | 82/11~85/ | Wheel Hub FRONT |
| 03905 7985 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE111 B,E | 82/10~85/ | Wheel Hub FRONT |
| 03905 5693 | MT327029 | 56 x 81 x 8 | CANTER (2T~) FE311,315,317 CARGO(BG#,BH#) | 85/9~91/4 | Wheel Hub FRONT |
| 03905 5660 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FE6##...EXCEPT 63ECY6B2,EV6B2,EY6B 2 | 99/3~02/ | Transmission REAR |
| 03905 1463 | MH034193 | 57 x 124 x 14.5 x 27 | CANTER (2T~) FE83D JZ7 | 02/5~ | Wheel Hub REAR WHEEL OUTER |
| 03905 4121 | ME240328 | 42 x 66 x 11.5 x 18.5 | CANTER (2T~) 4M40 FE63D,82D,83D,FF63D,8 3D | 99/3~ | Engine TIMING GEAR CASE |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4244 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FE50E,51E,52E,53E,59E,62E,63D,63E,69E | 99/3~02/ | Final Drive PINION |
| 03905 4460 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FE70D,E,71E,72D,E,73D,E,78E,82D,E,83D,E,88E | 02/5~ | Final Drive PINION |
| 03905 2375 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FG538,638 | 93/10~99/ | Final Drive PINION |
| 03905 6596 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FG53E,63E,73E,83E | 99/3~ | Final Drive PINION |
| 03905 6686 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FF6##,8## | 96/11~ | Final Drive PINION |
| 03905 3584 | 31311-06101 | 48 x 70 x 12 | CANTER (2T~) 4DR5 FE100,120,300,320 | 78/11~89/ | Engine TIMING GEAR CASE |
| 03905 3620 | ME024156 | 55 x 78 x 12 | CANTER (2T~) 4D3#...FE1##,2##,3##,4##,FG3##,4## | 78/11~89/9 | Engine TIMING GEAR CASE |
| 03905 5114 | ME013384 | 55 x 78 x 8 | CANTER (2T~) 4D3#...FE1##,2##,3##,4##,FG3##,4## | 89/10~93/ | Engine TIMING GEAR CASE |
| 03905 1376 | ME017208 | 57 x 78 x 10 x 16.5 | CANTER (2T~) 4D3#...FE5#6,5#7,5#8,6#6,6#7,6#8,6#9 | 93/10~99/ | Engine TIMING GEAR CASE |
| 03905 4055 | ME017208 | 57 x 78 x 10 x 16.5 | CANTER (2T~) 4D3#...FG5#7,5#8,638 | 93/10~99/ | Engine TIMING GEAR CASE |
| 03905 6758 | ME017208 | 57 x 78 x 10 x 16.5 | CANTER (2T~) 4D33 FE5#C,63C,7#C,8#C | 99/3~ | Engine TIMING GEAR CASE |
| 03905 2660 | ME240328 | 42 x 66 x 11.5 x 18.5 | CANTER (2T~) 4M51 FE5#2,6#2 | 97/10~99/ | Engine TIMING GEAR CASE |
| 03905 4295 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FE632,638,639,642,648,649,652,658,659,662,668,669 | 93/10~99/ | Final Drive PINION |
| 03905 8816 | ME240328 | 42 x 66 x 11.5 x 18.5 | CANTER (2T~) 4M51 FG5#E,6#E,7#E,8#E,FF63E,83E | 93/3~ | Engine TIMING GEAR CASE |
| 03905 6014 | ME011754 | 100 x 120 x 16 | CANTER (2T~) 4D3# | 78/11~85/8 | Engine CRANK SHAFT REAR |
| 03905 4412 | MD008762 | 35 x 50 x 8 | CANTER (2T~) 4G64 FE533 | 99/3~02/ | Engine CAM SHAFT |
| 03905 7499 | MD095355 | 20 x 30 x 7 | CANTER (2T~) 4G64 FE533 | 99/3~02/ | Engine OIL PUMP |
| 03905 8831 | MD008882 | 44 x 60 x 7 | CANTER (2T~) 4G64 FE533 | 99/3~02/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8876 | ME001196 | 96 x 113 x 16 | CANTER (2T~) 4DR5 | 78/11~86/9 | Engine CRANK SHAFT REAR |
| 03905 8789 | ME001293 | 90 x 113 x 15 | CANTER (2T~) 4DR5 | 86/10~93/ | Engine CRANK SHAFT REAR |
| 03905 1469 | ME011867 | 100 x 124 x 15 | CANTER (2T~) 4D3# | 85/9~93/8 | Engine CRANK SHAFT REAR |
| 03905 7142 | ME240010 | 101 x 123 x 13.5 | CANTER (2T~) 4M50,4M51 | 97/10~ | Engine CRANK SHAFT REAR |
| 03905 6419 | MD359158 | 85 x 103 x 7.5 | CANTER (2T~) 4G64 | 99/3~02/ | Engine CRANK SHAFT REAR |
| 03905 1247 | ME241213 | | CANTER (2T~) 4DR5 | 78/11~93/ | Engine VALVE STEM SEAL |
| 03905 3308 | ME241213 | | CANTER (2T~) 4M50,4M51 | 97/10~ | Engine VALVE STEM SEAL |
| 03905 2489 | ME215092 | | CANTER (2T~) 4D3# | 78/11~ | Engine VALVE STEM SEAL |
| 03905 1832 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FE8## | 02/5~ | Transmission REAR |
| 03905 2417 | ME240328 | 42 x 66 x 11.5 x 18.5 | CANTER (2T~) 4M51 FE5#E,6#E,7#E,8#E | 93/3~ | Engine TIMING GEAR CASE |
| 03905 2516 | MH034147 | 40 x 58 x 8 | CANTER (2T~) FG5##,6##,7##,8## | 93/10~ | Transmission FRONT |
| 03905 3338 | ME240010 | 101 x 123 x 13.5 | CANTER (2T~) 4D3# | 93/9~ | Engine CRANK SHAFT REAR |
| 03905 3512 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FE508,512,518,528,532,538,542,548,562,568 | 93/10~99/ | Final Drive PINION |
| 03905 4376 | ME620713 | 34 x 50 x 7 | CANTER (2T~) FE1##,2##,3##...EXCEPT 100,120,300,320 | 78/11~93/ | Transmission FRONT |
| 03905 3773 | ME620713 | 34 x 50 x 7 | CANTER (2T~) FE4## | 85/9~93/ | Transmission FRONT |
| 03905 8294 | MH034147 | 40 x 58 x 8 | CANTER (2T~) FE5##,6##,7##,8## | 93/10~ | Transmission FRONT |
| 03905 4598 | MH034147 | 40 x 58 x 8 | CANTER (2T~) FF6##,8## | 96/11~ | Transmission FRONT |
| 03905 8180 | MH034067 | 32 x 45 x 8 | CANTER (2T~) FE100,120,300,320 | 78/11~89/ | Transmission FRONT |
| 03905 2048 | MH034177 | 48 x 65 x 9 | CANTER (2T~) FE1##,2##,3##,4## | 78/11~93/ | Transmission REAR |
| 03905 7094 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FE5##...EXCEPT 537,538,568B6B#,562C6BK | 93/10~99/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2060 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FE6##...EXCEPT 638,668EV6B,648,659C6B,E6B | 93/10~99/ | Transmission REAR |
| 03905 4367 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FE5##...EXCEPT 53EBX6B#,B6B#,CX6BK1 | 99/3~02/ | Transmission REAR |
| 03905 4748 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FE70C,70E,71C,71E,72C,72E,73C,73E,78E | 02/5~ | Transmission REAR |
| 03905 1964 | MH034181 | 50 x 65 x 9 | CANTER (2T~) FF6##,8## | 96/11~ | Transmission REAR |
| 03905 1739 | MH034207 | 50 x 68 x 9 | CANTER (2T~) FE537,538,568B6B#,562C6BK | 93/10~99/ | Transmission REAR |
| 03905 3356 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FG3##,4## | 85/12~99/ | Final Drive PINION |
| 03905 6650 | MH034205 | 56 x 99 x 10 x 34 | CANTER (2T~) FE439,449 | 89/11~93/ | Final Drive PINION |
| 03905 3905 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FG50E,52E,62E,68E,70E,72E,82E,88E | 99/3~ | Final Drive PINION |
| 03905 1661 | ME620713 | 34 x 50 x 7 | CANTER (2T~) FG325,327,335,337,437 | 85/9~93/ | Transmission FRONT |
| 03905 1073 | MH034207 | 50 x 68 x 9 | CANTER (2T~) FE638,668EV6B,648,659C6B,E6B | 93/10~99/ | Transmission REAR |
| 03905 3671 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FG507,508,537 | 93/10~99/ | Final Drive PINION |
| 03905 8006 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FE70C,71C,72C,73C,82C,83C | 02/5~ | Final Drive PINION |
| 03905 8147 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FE50C,51C,52C,53C,63C | 99/3~02/ | Final Drive PINION |
| 03905 2159 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FE1##,2##,3## | 78/11~93/ | Final Drive PINION |
| 03905 1313 | MH034207 | 50 x 68 x 9 | CANTER (2T~) FE53EBX6#,B6B#,CX6BK1 | 99/3~02/ | Transmission REAR |
| 03905 1613 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FE507,516,517,527,533,536,537,566,567 | 93/10~99/ | Final Drive PINION |
| 03905 7805 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FE4##...EXCEPT 439,449 | 85/9~93/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1931 | MH034207 | 50 x 68 x 9 | CANTER (2T~) FE63CY6B2,EV6B2,EV6 B2,EY6B2 | 99/3~02/ | Transmission REAR |
| 03905 6521 | MH034213 | 52 x 84 x 14 | CANTER (2T~) FE636,637,667 | 93/10~99/ | Final Drive PINION |
| 03905 8072 | MH034249 | 40 x 65 x 9 | CANTER (2T~) FE700,72D,73D | 02/5~ | Transmission REAR |
| 03905 4514 | MD153103 | 35 x 50 x 8 | CARISMA DA2A 4G93 | 96/6~98/ | Engine CAM SHAFT |
| 03905 4415 | MB303875 | 52 x 72 x 8 x 11 | CARISMA DA2A | 96/6~98/ | Wheel Hub FRONT OUTER |
| 03905 7304 | MB573309 | 54 x 82 x 8 x 11 | CARISMA DA2A | 96/6~98/ | Wheel Hub FRONT INNER |
| 03905 1901 | MD359158 | 85 x 103 x 7.5 | CARISMA DA2A 4G93 | 96/6~98/ | Engine CRANK SHAFT REAR |
| 03905 7772 | MD707575 | 42 x 60 x 9 | CARISMA DA2A | 96/6~98/ | Mission & Differential (M/T) CONVERTER OIL PUMP |
| 03905 5498 | MD755904 | 41 x 61 x 9 x 13.5 | CARISMA DA2A | 96/6~98/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 8132 | MD184303 | | CARISMA 4G93 IN. & EX. | 96/6~98/ | Engine VALVE STEM SEAL |
| 03905 6320 | MD168055 | 37 x 50 x 6 | CARISMA DA2A 4G93 | 96/6~98/ | Engine CRANK SHAFT FRONT |
| 03905 1571 | MD307343 | | CHALLENGER 6G74 EX. | 97/8~02/ | Engine VALVE STEM SEAL |
| 03905 1001 | MD306079 | | CHALLENGER 6G74 IN. | 97/8~02/ | Engine VALVE STEM SEAL |
| 03905 6938 | MD050606 | 44 x 60 x 7 | CHALLENGER 4D56 | 96/5~97/ | Engine CRANK SHAFT FRONT |
| 03905 4658 | ME202115 | 90 x 114 x 10.5 x 17 | CHALLENGER 4M40 | 96/5~96/1 10 | Engine CRANK SHAFT REAR |
| 03905 3818 | MD069948 | 17 x 28 x 7 | CHALLENGER 4D56 | 96/5~97/ | Engine BALANCER SHAFT (RH) |
| 03905 1586 | MD069950 | 25 x 35 x 6 | CHALLENGER 4D56 | 96/5~97/ | Engine BALANCER SHAFT (LH) |
| 03905 1997 | MD152603 | 30 x 42 x 8 x 8.4 | CHALLENGER 6G74 K99 | 97/8~02/ | Engine CAM SHAFT |
| 03905 1388 | ME241213 | | CHALLENGER 4M40 IN. & EX. | 96/5~99/ | Engine VALVE STEM SEAL |
| 03905 2618 | MD307342 | | CHALLENGER 6G72 EX. | 96/5~98/ | Engine VALVE STEM SEAL |
| 03905 3656 | MD184303 | | CHALLENGER 6G72 IN. | 96/5~98/ | Engine VALVE STEM SEAL |
| 03905 4736 | ME202851 | 94.5 x 114 x 12 | CHALLENGER 4M40 | 96/11~99/ | Engine CRANK SHAFT REAR |
| 03905 3899 | MD153103 | 35 x 50 x 8 | CHALLENGER 6G72 K96 | 96/5~98/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4565 | MR350599 | 45 x 68.2 x 7 x 8 | CHALLENGER K99 | 97/8~02/ | Mission & Differential (A/T) CASE ADAPTER |
| 03905 4469 | MD120699 | 91 x 111 x 9 | CHALLENGER 6G72,6G74 | 96/5~02/ | Engine CRANK SHAFT REAR |
| 03905 5744 | MD069947 | 80 x 96 x 9 | CHALLENGER 4D56 | 96/5~97/ | Engine CRANK SHAFT REAR |
| 03905 2354 | ME202850 | 50 x 74 x 11 | CHALLENGER 4M40 K97 | 96/11~99/ | Engine TIMING GEAR CASE |
| 03905 2837 | ME200028 | 52 x 74 x 11 x 19 | CHALLENGER 4M40 K97 | 96/5~96/10 | Engine TIMING GEAR CASE |
| 03905 1853 | MD197467 | | CHALLENGER 4D56 IN. & EX. | 96/5~97/ | Engine VALVE STEM SEAL |
| 03905 3500 | MB936826 | 30 x 45 x 6.5 | CHALLENGER K97 | 96/5~99/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 1385 | MB664285 | 44 x 72 x 12 | CHALLENGER K9# | 96/5~02/ | Drive Pinion FRONT |
| 03905 4088 | MB160949 | 45 x 72 x 12 x 19.5 | CHALLENGER K9# | 96/5~02/ | Drive Pinion REAR |
| 03905 4904 | MD168055 | 37 x 50 x 6 | CHALLENGER 6G72,6G74 | 96/5~02/ | Engine CRANK SHAFT FRONT |
| 03905 4034 | MB526395 | 57 x 75 x 7.5 x 11.5 | CHALLENGER K9# | 96/5~02/ | Wheel Hub FRONT |
| 03905 4100 | MB837719 | 37 x 62 x 12.5 | CHALLENGER K9# | 96/5~02/ | Wheel Hub REAR INNER |
| 03905 3050 | MR145792 | 45 x 68.2 x 8.5 | CHALLENGER K9#...ATM | 96/5~02/ | Mission & Differential (A/T) TRANSFER INPUT |
| 03905 4601 | MH034067 | 32 x 45 x 8 | CHALLENGER K94 | 96/5~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 5282 | MD153103 | 35 x 50 x 8 | CHALLENGER 4D56 K94 | 96/5~97/ | Engine CAM SHAFT |
| 03905 3260 | MR350599 | 45 x 68.2 x 7 x 8 | CHALLENGER K96,97 | 96/5~99/ | Mission & Differential (A/T) EXTENTION HPUSING |
| 03905 4883 | MR145502 | 45 x 68.2 x 15 | CHALLENGER K9#...MTM | 96/5~99/ | Mission & Differential (A/T) TRANSFER INPUT |
| 03905 2129 | MD712012 | 36 x 52 x 10 x 11 | CHALLENGER K9# | 96/5~02/ | Mission & Differential (A/T) TRANSFER FRONT OUTPUT |
| 03905 2948 | MD731708 | 39.6 x 52 x 10 x 11 | CHALLENGER K94 | 96/5~97/ | Mission & Differential (A/T) TRANSFER REAR OUTPUT |
| 03905 8057 | MB919210 | 42.8 x 55 x 10 x 11 | CHALLENGER K96,97,99 | 96/5~02/ | Mission & Differential (A/T) TRANSFER REAR OUTPUT |
| 03905 7316 | MR151061 | | CHALLENGER K9# | 96/5~02/ | Power Steering SEAL KIT |
| 03905 7097 | MR151065 | | CHALLENGER K9# | 96/5~02/ | Power Steering SECTOR SHAFT SEAL KIT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6995 | MB664612 | 50 x 75 x 9 | CHALLENGER K9# | 96/5~02/ | Wheel Hub REAR PUTER |
| 03905 7154 | MD069947 | 80 x 96 x 9 | CHARIOT / SPACE WAGON 4G63 | 91/3~92/5 | Engine CRANK SHAFT REAR |
| 03905 7721 | MD168057 | 20 x 30 x 7 x 7.5 | CHARIOT / SPACE WAGON G62B,G63B,4G63 | 85/5~92/5 | Engine OIL PUMP |
| 03905 3659 | MD120699 | 91 x 111 x 9 | CHARIOT / SPACE WAGON 6G72 | 99/10~00/2 | Engine CRANK SHAFT REAR |
| 03905 2450 | MD000508 | | CHARIOT / SPACE WAGON G32B,G37B,G62B,G67B, 4D56,4D68 | 83/1~97/ | Engine VALVE STEM SEAL |
| 03905 8738 | MB176746 | 50 x 66.5 x 13 x 16 | CHARIOT / SPACE WAGON DO2WD,3W,5W,9W | 83/1~91/ | Wheel Hub FRONT INNER |
| 03905 8687 | MD372251 | 91 x 111 x 7.5 | CHARIOT / SPACE WAGON 6G72 | 00/3~ | Engine CRANK SHAFT REAR |
| 03905 2255 | MD016549 | 72 x 96 x 9 | CHARIOT / SPACE WAGON G32B,G37B | 83/1~91/ | Engine CRANK SHAFT REAR |
| 03905 5825 | MD153103 | 35 x 50 x 8 | CHARIOT / SPACE WAGON 4G64(N33W,44W,84W,94W) | 93/3~ | Engine CAM SHAFT |
| 03905 4517 | MD152603 | 30 x 42 x 8 x 8.4 | CHARIOT / SPACE WAGON 6G72(N86W,96W) | 99/10~ | Engine CAM SHAFT |
| 03905 4274 | MD151463 | 28 x 40 x 8 | CHARIOT / SPACE WAGON G7B | 84/6~91/ | Engine BALANCER SHAFT |
| 03905 5966 | MD069950 | 25 x 35 x 6 | CHARIOT / SPACE WAGON G62B,G63B,4G63,4G64,4D56,4D68 | 83/1~ | Engine BALANCER SHAFT |
| 03905 1403 | MD184303 | | CHARIOT / SPACE WAGON 4G63,4G64 | 92/6~97/ | Engine VALVE STEM SEAL |
| 03905 4754 | MD069948 | 17 x 28 x 7 | CHARIOT / SPACE WAGON G62B,G63B,4D56 | 83/1~85/4 | Engine OIL PUMP |
| 03905 7475 | MD307343 | | CHARIOT / SPACE WAGON 4G64 | 97/8~ | Engine VALVE STEM SEAL |
| 03905 1055 | MD095355 | 20 x 30 x 7 | CHARIOT / SPACE WAGON 4D56 | 85/5~91/ | Engine OIL PUMP |
| 03905 1478 | MD095355 | 20 x 30 x 7 | CHARIOT / SPACE WAGON 4G63,4G64,4D63,4D68 | 92/6~ | Engine OIL PUMP |
| 03905 6071 | MD050606 | 44 x 60 x 7 | CHARIOT / SPACE WAGON G32B,G37B,G62B,G67B, 4D56,4D68 | 83/1~ | Engine CRANK SHAFT FRONT |
| 03905 5540 | MD050606 | 44 x 60 x 7 | CHARIOT / SPACE WAGON 4G63 | 91/3~92/5 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2465 | MD174462 | 44 x 60 x 7 | CHARIOT / SPACE WAGON 4G63,4G64 | 92/6~ | Engine CRANK SHAFT FRONT |
| 03905 3128 | MD120700 | 37 x 50 x 6 | CHARIOT / SPACE WAGON 6G72 | 99/10~ | Engine CRANK SHAFT FRONT |
| 03905 8957 | MD069947 | 80 x 96 x 9 | CHARIOT / SPACE WAGON G62B,G63B,4D56 | 83/1~91/ | Engine CRANK SHAFT REAR |
| 03905 3191 | MD150161 | 85 x 103 x 8 | CHARIOT / SPACE WAGON 4G63 | 92/6~97/ | Engine CRANK SHAFT REAR |
| 03905 2555 | MD359158 | 85 x 103 x 7.5 | CHARIOT / SPACE WAGON 4G64,4D63 | 92/6~ | Engine CRANK SHAFT REAR |
| 03905 6431 | MD069948 | 17 x 28 x 7 | CHARIOT / SPACE WAGON G32B,G37B | 83/1~91/ | Engine OIL PUMP |
| 03905 7124 | MD707184 | 35 x 56 x 9 x 12 | CHARIOT / SPACE WAGON DO2W,3W,5W,8W,9W | 83/1~91/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE (L&R) |
| 03905 7541 | MB176746 | 50 x 66.5 x 13 x 16 | CHARIOT / SPACE WAGON DO8W EXCEPT LBU# | 84/6~91/ | Wheel Hub FRONT INNER |
| 03905 3917 | MB303867 | 50 x 82 x 8 x 11 | CHARIOT / SPACE WAGON DO8W LBU# | 84/10~88/ | Wheel Hub FRONT INNER |
| 03905 7148 | MB573309 | 54 x 82 x 8 x 11 | CHARIOT / SPACE WAGON N33W,38W,43W,48W | 91/3~97/ | Wheel Hub FRONT INNER |
| 03905 2186 | MB176746 | 50 x 66.5 x 13 x 16 | CHARIOT / SPACE WAGON DO2WD,3W,5W,9W | 83/1~91/ | Wheel Hub FRONT OUTER |
| 03905 8888 | MB176746 | 50 x 66.5 x 13 x 16 | CHARIOT / SPACE WAGON DO8W EXCEPT LBU# | 84/6~91/ | Wheel Hub FRONT OUTER |
| 03905 7547 | MB303875 | 52 x 72 x 8 x 11 | CHARIOT / SPACE WAGON DO8W LBU# | 84/10~88/ | Wheel Hub FRONT OUTER |
| 03905 8912 | MB303875 | 52 x 72 x 8 x 11 | CHARIOT / SPACE WAGON N33W,38W,43W,48W | 91/3~97/ | Wheel Hub FRONT OUTER |
| 03905 1763 | MA125844 | 38 x 52 x 6 | CHARIOT / SPACE WAGON DO2W,3W,5W,9W | 83/1~91/ | Wheel Hub REAR |
| 03905 5255 | MB393807 | 36 x 64 x 11 x 19 | CHARIOT / SPACE WAGON DO8W | 86/1~91/ | Wheel Hub REAR |
| 03905 7367 | MD000508 | | CHARIOT / SPACE WAGON 4G63 | 91/3~92/5 | Engine VALVE STEM SEAL |
| 03905 6356 | MD741818 | 25 x 35 x 6 | CHARIOT / SPACE WAGON N33W,38W,43W,48W | 91/3~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 1562 | MD153103 | 35 x 50 x 8 | CHARIOT / SPACE WAGON 4G63(N33W,43W),4D68( N38W,48W) | 91/3~97/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1565 | MD707184 | 35 x 56 x 9 x 12 | CHARIOT / SPACE WAGON N33W,38W | 91/3~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE (L&R) |
| 03905 4997 | MD707184 | 35 x 56 x 9 x 12 | CHARIOT / SPACE WAGON N43W,44W,48W | 91/3~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE (RH) |
| 03905 1961 | MD719710 | 35 x 54 x 10 x 7 | CHARIOT / SPACE WAGON N43W,44W,48W | 91/3~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE (LH) |
| 03905 2201 | MD755904 | 41 x 61 x 9 x 13.5 | CHARIOT / SPACE WAGON N84W,86W | 97/8~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE (L&R) |
| 03905 4937 | MD758763 | 41 x 61 x 11.5 x 16 | CHARIOT / SPACE WAGON N94W,96W | 97/8~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE (L&R) |
| 03905 6989 | MD153103 | 35 x 50 x 8 | CHARIOT / SPACE WAGON G32B(DO2W),G62B(DO3W) | 83/1~86/ | Engine CAM SHAFT |
| 03905 6023 | MD153103 | 35 x 50 x 8 | CHARIOT / SPACE WAGON G37B(DO5W),G63B(DO8W),4D56(DO9W) | 84/6~91/ | Engine CAM SHAFT |
| 03905 5603 | MD307342 | | CHARIOT / SPACE WAGON 6G72 EX. | 99/10~ | Engine VALVE STEM SEAL |
| 03905 9029 | MD306079 | | CHARIOT / SPACE WAGON 6G72 IN. | 99/10~ | Engine VALVE STEM SEAL |
| 03905 6500 | MD069950 | 25 x 35 x 6 | CHARIOT / SPACE WAGON DO2W,3W,5W,8W,9W | 83/1~91/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 3074 | MD707575 | 42 x 60 x 9 | COLT Z25A,27A | 02/11~ | Mission & Differential (A/T) CONVERTER HOUSING |
| 03905 8627 | MR567613 | 46 x 60 x 8.5 | COLT Z26A,28A(4WD) | 02/11~ | Mission & Differential (A/T) REAR DIFF. PINION |
| 03905 2120 | MD153103 | 35 x 50 x 8 | COLT Z25A,26A,27A,28A | 02/11~ | Engine CAM SHAFT |
| 03905 8897 | MD377999 | 34 x 46 x 7 | COLT Z25A,26A,27A,28A | 02/11~ | Engine CRANK SHAFT FRONT |
| 03905 7952 | MD372250 | 72 x 96 x 7.5 | COLT Z25A,26A,27A,28A | 02/11~ | Engine CRANK SHAFT REAR |
| 03905 3737 | MD302172 | | COLT Z25A,26A,27A,28A INTAKE | 02/11~ | Engine VALVE STEM SEAL |
| 03905 5024 | MD307341 | | COLT Z25A,26A,27A,28A EXHAUST | 02/11~ | Engine VALVE STEM SEAL |
| 03905 2693 | MR196784 | 33 x 60 x 15 | COLT Z26A,28A(4WD) | 02/11~ | Wheel Hub REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1133 | MD755904 | 41 x 61 x 9 x 13.5 | COLT Z25A,26A,27A,28A | 02/11~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 5420 | MD153103 | 35 x 50 x 8 | DELICA / L300 4G33,G33B(1400) LO31P,36P,P01V | 79/5~94/ | Engine CAM SHAFT |
| 03905 1889 | MB092145 | 42 x 65 x 12 | DELICA / L301 P05W 4F A/T | 86/4~99/ | Final Drive REAR DRIVE PINION |
| 03905 8354 | MB160578 | 42 x 65 x 12 | DELICA / L302 PA3V | 94/3~99/ | Final Drive REAR DRIVE PINION |
| 03905 4331 | MB160949 | 45 x 72 x 12 x 19.5 | DELICA / L303 LO35G,37G,38G,39G | 82/10~94/ | Final Drive REAR DRIVE PINION |
| 03905 6098 | MB160949 | 45 x 72 x 12 x 19.5 | DELICA / L304 P04W,23#,24W,25#,35W, 45W | 86/4~99/ | Final Drive REAR DRIVE PINION |
| 03905 1346 | MB160949 | 45 x 72 x 12 x 19.5 | DELICA / L305 P12V | 86/8~90/7 | Final Drive REAR DRIVE PINION |
| 03905 2621 | MB160949 | 45 x 72 x 12 x 19.5 | DELICA / L306 P15W | 90/8~99/ | Final Drive REAR DRIVE PINION |
| 03905 2636 | MB160949 | 45 x 72 x 12 x 19.5 | DELICA / L307 P05W 5F M/T | 86/4~99/ | Final Drive REAR DRIVE PINION |
| 03905 4214 | MD723202 | 30 x 45 x 6 | DELICA / L308 PA3V,5V,PB5V,PC4W,P D5V | 94/3~ | Transmission FRONT |
| 03905 4535 | MR151977 | | DELICA / L309 PA#,PB#,PC#,PD#,PE#,P F# | 94/3~ | Power Steering SEAL KIT |
| 03905 7790 | MB092145 | 42 x 65 x 12 | DELICA / L310 P01V,02V,03W,05V,15V | 86/4~99/ | Final Drive REAR DRIVE PINION |
| 03905 4727 | MD153103 | 35 x 50 x 8 | DELICA / L311 4G32,G32B(1600) LO32P,33P,34P,63P,P02V ,12V | 79/5~94/ | Engine CAM SHAFT |
| 03905 1040 | MD153103 | 35 x 50 x 8 | DELICA / L312 4G92(1600) P02T,P06V | 94/3~99/ | Engine CAM SHAFT |
| 03905 3089 | MD153103 | 35 x 50 x 8 | DELICA / L313 G62B(1800) LO35# | 79/5~86/ | Engine CAM SHAFT |
| 03905 2207 | MD153103 | 35 x 50 x 8 | DELICA / L314 G63B(2000) LO37G,P03#,P13V,23# | 83/11~94/ | Engine CAM SHAFT |
| 03905 6998 | MD153103 | 35 x 50 x 8 | DELICA / L315 4G63(2000) P07V,13T,17T,27V,PA3V | 94/3~99/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4319 | MD153103 | 35 x 50 x 8 | DELICA / L316 4G64(2400) P04W,P24W,PA4W,PB4 W,PC4W,PD4W | 89/8~ | Engine CAM SHAFT |
| 03905 6473 | MB160949 | 45 x 72 x 12 x 19.5 | DELICA / L317 PA4W,5V.W,PB#,PC#,PD #,PE8W,PF# | 94/3~ | Final Drive REAR DRIVE PINION |
| 03905 8525 | MB160578 | 42 x 65 x 12 | DELICA / L318 P2#,35W,45V(4WD) | 86/4~99/ | Final Drive FRONT DRIVE PINION |
| 03905 8771 | MB936826 | 30 x 45 x 6.5 | DELICA / L319 PA5W,PB5W,PC5W,PD8 W,PE8W,PF8W | 94/3~ | Transmission FRONT |
| 03905 4025 | MD701430 | 32 x 48 x 10 | DELICA / L320 LO31P | 79/6~82/ | Transmission REAR |
| 03905 6152 | MD701430 | 32 x 48 x 10 | DELICA / L321 LO36P,PO1V | 82/10~88/ 7 | Transmission REAR |
| 03905 7301 | MD703743 | 36 x 52 x 10 | DELICA / L322 P0#,P1#,2#,3#,4#...EXCE PT P01V | 86/4~99/ | Transmission REAR |
| 03905 7769 | MB526395 | 57 x 75 x 7.5 x 11.5 | DELICA / L323 P2#,3#,4#(4WD) | 86/4~99/ | Wheel Hub FRONT |
| 03905 5507 | MB919210 | 42.8 x 55 x 10 x 11 | DELICA / L324 PA5W,PB5W,PC5W | 94/3~ | Transmission REAR |
| 03905 4280 | MB092145 | 42 x 65 x 12 | DELICA / L325 P15W | 86/8~90/7 | Final Drive REAR DRIVE PINION |
| 03905 2654 | MD609235 | 45 x 68.2 x 7 x 8 | DELICA / L326 PD4W,5V,6W,8W,PE8W, PF6W,8W | 94/3~ | Transmission (A/T) EXTENTION HOUSING |
| 03905 3119 | MB092145 | 42 x 65 x 12 | DELICA / L327 P12V | 90/8~93/ | Final Drive REAR DRIVE PINION |
| 03905 4931 | MB160578 | 42 x 65 x 12 | DELICA / L328 PD4W,6V,6W,PF6W(4W D) | 94/3~ | Final Drive FRONT DRIVE PINION |
| 03905 1076 | MB160578 | 42 x 65 x 12 | DELICA / L329 PD8W,PE8W,PF8W(4WD ) AT | 94/3~97/5 | Final Drive FRONT DRIVE PINION |
| 03905 1970 | MB664285 | 44 x 72 x 12 | DELICA / L330 PD8W,PE8W,PF8W(4WD ) MT | 94/3~97/5 | Final Drive FRONT DRIVE PINION |
| 03905 8426 | MB664285 | 44 x 72 x 12 | DELICA / L331 PD8W,PE8W,PF8W(4WD ) ALL | 97/6~ | Final Drive FRONT DRIVE PINION |
| 03905 7325 | MB092145 | 42 x 65 x 12 | DELICA / L332 2WD ALL | 79/6~86/3 | Final Drive REAR DRIVE PINION |
| 03905 3548 | MB092145 | 42 x 65 x 12 | DELICA / L333 LO36P,39P,63P,69P | 86/4~94/ | Final Drive REAR DRIVE PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5312 | MD153103 | 35 x 50 x 8 | DELICA / L334 4D56(2500) LO39#,69P,P05#,15#,25#, 35W,45V | 86/4~99/ | Engine CAM SHAFT |
| 03905 6572 | MD951482 | 40 x 57.2 x 13 | DELICA / L335 PA3V,4W,5V.W,PB4W,5 V.W,6W,PC4W,5W | 94/3~ | Transmission (A/T) EXTENTION HOUSING |
| 03905 7436 | MD000508 | | DELICA / L336 G63B,4G64 EX. | 92/10~94/ | Engine VALVE STEM SEAL |
| 03905 8126 | MD153103 | 35 x 50 x 8 | DELICA / L337 6G72(3000) PB6W,PD6W,PF6W | 94/3~ | Engine CAM SHAFT |
| 03905 9002 | MD120699 | 91 x 111 x 9 | DELICA / L338 6G72 | 94/3~00/2 | Engine CRANK SHAFT REAR |
| 03905 3278 | MD372251 | 91 x 111 x 7.5 | DELICA / L339 6G72 | 00/3~ | Engine CRANK SHAFT REAR |
| 03905 1673 | ME200012 | 92 x 114 x 8 x 17 | DELICA / L340 4M40 | 94/3~96/2 | Engine CRANK SHAFT REAR |
| 03905 3845 | ME202115 | 90 x 114 x 10.5 x 17 | DELICA / L341 4M40 | 96/3~96/1 0 | Engine CRANK SHAFT REAR |
| 03905 6017 | ME202851 | 94.5 x 114 x 12 | DELICA / L342 4M40 | 96/11~99/ 5 | Engine CRANK SHAFT REAR |
| 03905 2906 | MD150161 | 85 x 103 x 8 | DELICA / L343 G63B,4G63,4G64,4G92 | 92/5~95/2 | Engine CRANK SHAFT REAR |
| 03905 3449 | MD000508 | | DELICA / L344 G32B,33B,62B,63B,4G64, 4G92,4D55,56 IN. & EX. | 79/5~92/9 | Engine VALVE STEM SEAL |
| 03905 2051 | MD069947 | 80 x 96 x 9 | DELICA / L345 4D55,4D56 | 82/10~ | Engine CRANK SHAFT REAR |
| 03905 1250 | MD197467 | | DELICA / L346 G33B,4G92 IN. & EX. | 92/10~94/ | Engine VALVE STEM SEAL |
| 03905 1748 | MD197467 | | DELICA / L347 G63B,4G64 IN. | 92/10~94/ 3 | Engine VALVE STEM SEAL |
| 03905 5927 | MD197467 | | DELICA / L348 4D56 IN. & EX. | 92/10~ | Engine VALVE STEM SEAL |
| 03905 5513 | MD184303 | | DELICA / L349 4G92,4G63,4G64 IN. & EX. | 94/4~ | Engine VALVE STEM SEAL |
| 03905 7868 | MD184303 | | DELICA / L350 6G72 IN. | 94/3~ | Engine VALVE STEM SEAL |
| 03905 4646 | MD307342 | | DELICA / L351 6G72 EX. | 94/3~ | Engine VALVE STEM SEAL |
| 03905 4118 | ME241213 | | DELICA / L352 4M40 IN. & EX. | 94/3~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5849 | ME203250 | 90.5 x 114 x 12 | DELICA / L353 4M40 | 99/6~ | Engine CRANK SHAFT REAR |
| 03905 1424 | MD168057 | 20 x 30 x 7 x 7.5 | DELICA / L354 G62B,G63B,4G64 | 85/5~94/ | Engine OIL PUMP |
| 03905 7382 | MD703743 | 36 x 52 x 10 | DELICA / L355 LO3#...EXCEPT LO31P,36P,LO6# | 79/6~94/ | Transmission REAR |
| 03905 8711 | MD153103 | 35 x 50 x 8 | DELICA / L356 4D56(2500) PA5#,PB5#,PC5W,PD5V | 94/3~ | Engine CAM SHAFT |
| 03905 6194 | MD151463 | 28 x 40 x 8 | DELICA / L357 4G3,G3 LO33PW,63PW | 79/5~86/ | Engine BALANCER SHAFT |
| 03905 7604 | MD069950 | 25 x 35 x 6 | DELICA / L358 G62B,G63B,4G63,4G64 | 79/5~ | Engine BALANCER SHAFT |
| 03905 5477 | MD069950 | 25 x 35 x 6 | DELICA / L359 4D55,4D56 | 82/10~ | Engine BALANCER SHAFT(LH) |
| 03905 8666 | MD069948 | 17 x 28 x 7 | DELICA / L360 4D55,4D56 | 82/10~ | Engine BALANCER SHAFT(RH) |
| 03905 5132 | MD359158 | 85 x 103 x 7.5 | DELICA / L361 4G63,4G64 | 95/3~ | Engine CRANK SHAFT REAR |
| 03905 7970 | MD069948 | 17 x 28 x 7 | DELICA / L362 G62B,G63B | 79/6~85/4 | Engine OIL PUMP |
| 03905 4361 | MD153103 | 35 x 50 x 8 | DELICA / L363 4D55(2300) LO38#,68P | 82/10~86/ | Engine CAM SHAFT |
| 03905 7616 | MD095355 | 20 x 30 x 7 | DELICA / L364 4G63,4G64 | 94/3~ | Engine OIL PUMP |
| 03905 1274 | ME200028 | 52 x 74 x 11 x 19 | DELICA / L365 4M40 PD8W,PE8W,PF8W | 94/3~96/10 | Engine TIMING GEAR CASE |
| 03905 7202 | ME202850 | 50 x 74 x 11 | DELICA / L366 4M40 PD8W,PE8W,PF8W | 96/11~ | Engine TIMING GEAR CASE |
| 03905 7256 | MD050606 | 44 x 60 x 7 | DELICA / L367 G32B,G33B,G62B,G63B, 4G63,4G64 | 79/5~ | Engine CRANK SHAFT FRONT |
| 03905 2036 | MD168055 | 37 x 50 x 6 | DELICA / L368 4G92,6G72 | 94/3~ | Engine CRANK SHAFT FRONT |
| 03905 5651 | MD016549 | 72 x 96 x 9 | DELICA / L369 G32B,G33B | 79/5~94/ | Engine CRANK SHAFT REAR |
| 03905 5135 | MD069947 | 80 x 96 x 9 | DELICA / L370 G62B,G63B,4G64 | 79/5~92/4 | Engine CRANK SHAFT REAR |
| 03905 7421 | MD069948 | 17 x 28 x 7 | DELICA / L371 G32B,G33B | 79/5~94/ | Engine OIL PUMP |
| 03905 2150 | MB001314 | 45 x 58 x 9 | DELICA / L372 PO1V HI ROOF | 90/5~92/7 | Wheel Hub REAR OUTER |
| 03905 5231 | MB092437 | 50 x 65 x 10 | DELICA / L373 P13T,15T,25T WITHOUT ABS | 94/3~99/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8489 | MB837719 | 37 x 62 x 12.5 | DELICA / L374 P13T,15T | 86/8~99/ | Wheel Hub REAR INNER |
| 03905 2753 | MB837719 | 37 x 62 x 12.5 | DELICA / L375 P2#,3#,4#(4WD) | 86/4~99/ | Wheel Hub REAR INNER |
| 03905 3230 | MB837719 | 37 x 62 x 12.5 | DELICA / L376 PA3V WITH ABS | 94/3~99/ | Wheel Hub REAR INNER |
| 03905 4232 | MB837719 | 37 x 62 x 12.5 | DELICA / L377 PA4W,5V.W,PB4W,5V.W ,6W,PC4W,5W | 94/3~ | Wheel Hub REAR INNER |
| 03905 2543 | MB837719 | 37 x 62 x 12.5 | DELICA / L378 PO4W,5V,6W,8W,PE8W, PF6W,8W | 94/3~ | Wheel Hub REAR INNER |
| 03905 2066 | MB092712 | 58 x 75 x 9 | DELICA / L379 P02T,05T W TIRE | 86/4~99/ | Wheel Hub REAR INNER |
| 03905 6962 | MB001314 | 45 x 58 x 9 | DELICA / L380 LO38PV.W,39P(ST),69P( ST) | 82/10~94/ | Wheel Hub REAR OUTER |
| 03905 8492 | MB092712 | 58 x 75 x 9 | DELICA / L381 LO63P,68P,69P TRUCK W TIRE | 82/10~94/ | Wheel Hub REAR INNER |
| 03905 2117 | MD703743 | 36 x 52 x 10 | DELICA / L382 PA3V,5V,PB5V,PC4W | 94/3~ | Transmission REAR |
| 03905 8285 | MB001314 | 45 x 58 x 9 | DELICA / L383 P06V,07V,12V,13V,15V. W,17V | 86/8~99/ | Wheel Hub REAR OUTER |
| 03905 5909 | MD723202 | 30 x 45 x 6 | DELICA / L384 P0#,P1#,P2#,3#,4#...EXC EPT P01V | 86/4~99/ | Transmission FRONT |
| 03905 3311 | MB092713 | 30 x 37 x 3.5 x 6.5 | DELICA / L385 LO31P,34P,36P,38P,39P TRUCK W TIRE | 79/6~94/ | Wheel Hub REAR OUTER |
| 03905 3455 | MB092713 | 30 x 37 x 3.5 x 6.5 | DELICA / L386 LO63P,68P,69[ TRUCK W TIRE | 82/10~94/ | Wheel Hub REAR OUTER |
| 03905 5831 | MB092713 | 30 x 37 x 3.5 x 6.5 | DELICA / L387 P02T,05T W TIRE | 86/4~99/ | Wheel Hub REAR OUTER |
| 03905 7268 | MB092437 | 50 x 65 x 10 | DELICA / L388 LO35G,37G,38G,39G 4WD | 82/10~94/ | Wheel Hub REAR OUTER |
| 03905 7742 | MB001314 | 45 x 58 x 9 | DELICA / L389 LO36P,63P TRUCK S TIRE | 79/6~94/ | Wheel Hub REAR OUTER |
| 03905 2525 | MA181498 | 51 x 65 x 9 | DELICA / L390 PO1V ALL | 92/8~93/ | Wheel Hub REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1610 | MB526395 | 57 x 75 x 7.5 x 11.5 | DELICA / L391 LO3#...4WD | 82/10~94/ | Wheel Hub FRONT |
| 03905 5294 | MT141132 | 50 x 65 x 9 | DELICA / L392 2WD ALL | 79/6~ | Wheel Hub FRONT |
| 03905 8192 | MB922062 | 63 x 81 x 7.5 x 11.5 | DELICA / L393 PD#,PE#,PF#(4WD) | 94/3~ | Wheel Hub FRONT |
| 03905 1694 | MA181498 | 51 x 65 x 9 | DELICA / L394 LO31P,36P VAN | 79/6~86/ | Wheel Hub REAR |
| 03905 3182 | MA181498 | 51 x 65 x 9 | DELICA / L395 LO32P,33P,35P ALL | 79/6~86/ | Wheel Hub REAR |
| 03905 6401 | MA181498 | 51 x 65 x 9 | DELICA / L396 LO63P,68P VAN,WAGON | 82/10~94/ | Wheel Hub REAR |
| 03905 8987 | MB837719 | 37 x 62 x 12.5 | DELICA / L397 LO35G,37G,38G,39G 4WD | 82/10~94/ | Wheel Hub REAR INNER |
| 03905 6710 | MA181498 | 51 x 65 x 9 | DELICA / L398 PO1V STD ROOF | 90/8~92/7 | Wheel Hub REAR |
| 03905 6416 | MB001314 | 45 x 58 x 9 | DELICA / L399 PA3V WITHOUT ABS | 94/3~99/ | Wheel Hub REAR OUTER |
| 03905 1730 | MB664588 | 35 x 58 x 8.5 | DELICA / L400 LO31P,36P,38P,39P TRUCK S TIRE | 79/6~94/ | Wheel Hub REAR INNER |
| 03905 7553 | MB664588 | 35 x 58 x 8.5 | DELICA / L401 LO63P,68P,69P TRUCK S TIRE | 82/10~94/ | Wheel Hub REAR INNER |
| 03905 2534 | MB664588 | 35 x 58 x 8.5 | DELICA / L402 PO1V HI ROOF | 90/5~92/7 | Wheel Hub REAR INNER |
| 03905 5225 | MB664588 | 35 x 58 x 8.5 | DELICA / L403 PO2T(ST),02V,03V.W,04 W,05T(ST),05V.W | 86/4~99/ | Wheel Hub REAR INNER |
| 03905 1712 | MB664588 | 35 x 58 x 8.5 | DELICA / L404 PO6V,07V,12V,13V,15V. W,17V | 86/8~99/ | Wheel Hub REAR INNER |
| 03905 4922 | MB664588 | 35 x 58 x 8.5 | DELICA / L405 PA3V WITHOUT ABS | 94/3~99/ | Wheel Hub REAR INNER |
| 03905 4814 | MB092712 | 58 x 75 x 9 | DELICA / L406 LO31P,34P,36P,38P,39P TRUCK W TIRE | 79/6~94/ | Wheel Hub REAR INNER |
| 03905 2558 | MA181498 | 51 x 65 x 9 | DELICA / L407 PO1V ALL | 86/4~90/7 | Wheel Hub REAR |
| 03905 4490 | MD069950 | 25 x 35 x 6 | DELICA / L408 LO36P,P01V | 82/10~88/ 7 | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7220 | MB001314 | 45 x 58 x 9 | DELICA / L409 PO2T(ST),02V,03V.W,04 W,05T(ST),05V.W | 86/4~99/ | Wheel Hub REAR OUTER |
| 03905 3608 | MD723202 | 30 x 45 x 6 | DELICA / L410 LO3#...EXCEPT LO31P,36P,LO6# | 79/6~94/ | Transmission FRONT |
| 03905 1499 | MB092437 | 50 x 65 x 10 | DELICA / L411 PA5V,PB5V,PD5V WITHOUT ABS | 94/3~99/ | Wheel Hub REAR OUTER |
| 03905 8312 | MB092437 | 50 x 65 x 10 | DELICA / L412 PA4W,5W,PB5W,6W,PC5 W WITHOUT ABS | 94/3~97/5 | Wheel Hub REAR OUTER |
| 03905 1598 | MB664612 | 50 x 75 x 9 | DELICA / L413 P13T,15T,25T WITH ABS | 94/3~99/ | Wheel Hub REAR OUTER |
| 03905 4733 | MB664612 | 50 x 75 x 9 | DELICA / L414 PA3V,5V,PB5V,PD5V WITH ABS | 94/3~99/ | Wheel Hub REAR OUTER |
| 03905 2855 | MB664612 | 50 x 75 x 9 | DELICA / L415 PA4W,5W,PB4W,5W,6W, PC5W WITH ABS | 94/3~ | Wheel Hub REAR OUTER |
| 03905 4886 | MB664612 | 50 x 75 x 9 | DELICA / L416 PD4W,6W,8W,PE8W,PF6 W,8W | 94/3~ | Wheel Hub REAR OUTER |
| 03905 7775 | MD069950 | 25 x 35 x 6 | DELICA / L417 LO31P | 79/6~82/ | Transmission FRONT |
| 03905 5552 | MB092437 | 50 x 65 x 10 | DELICA / L418 P23V.W,24W,25V.W,27V ,35W,45W | 86/4~99/ | Wheel Hub REAR OUTER |
| 03905 8213 | MB393929 | 35 x 65 x 12 | DIAMANTE / SIGMA F25A,27A,41A,46A,47A(4 WD) | 90/2~02/ | Mission & Differential (M/T) REAR DIFF. PINION |
| 03905 7694 | MD069950 | 25 x 35 x 6 | DIAMANTE / SIGMA F1#...MT | 90/2~91/8 | Mission & Differential (M/T) INPUT SHAFT |
| 03905 6107 | MD758763 | 41 x 61 x 11.5 x 16 | DIAMANTE / SIGMA F14A TRHA# | 96/12~97/ | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |
| 03905 8414 | MD153103 | 35 x 50 x 8 | DIAMANTE / SIGMA 6A12 F12A | 92/10~95/ | Engine CAM SHAFT |
| 03905 5360 | MD755904 | 41 x 61 x 9 x 13.5 | DIAMANTE / SIGMA F14A EXC. TRHA# | 96/12~97/ | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |
| 03905 6122 | MD755904 | 41 x 61 x 9 x 13.5 | DIAMANTE / SIGMA F41A | 94/11~96/ 11 | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1652 | MD755904 | 41 x 61 x 9 x 13.5 | DIAMANTE / SIGMA F31A,34A,36A,36W,46A, 47A | 94/11~ | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |
| 03905 8558 | MD719710 | 35 x 54 x 10 x 17 | DIAMANTE / SIGMA F15A,17A,25A,27A | 90/2~94/ | Mission & Differential (M/T) FRONT DIFF. CASE(LH) |
| 03905 6308 | MD742053 | 37 x 56 x 9 x 12.5 | DIAMANTE / SIGMA F13A,F07W | 91/10~96/ | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |
| 03905 8594 | MD742053 | 37 x 56 x 9 x 12.5 | DIAMANTE / SIGMA 15A,17A | 91/10~94/ | Mission & Differential (M/T) FRONT DIFF. CASE(RH) |
| 03905 1745 | MD707184 | 35 x 56 x 9 x 12 | DIAMANTE / SIGMA F25A,27A | 90/2~94/ | Mission & Differential (M/T) FRONT DIFF. CASE(RH) |
| 03905 2810 | MD707184 | 35 x 56 x 9 x 12 | DIAMANTE / SIGMA F13A,15A,17A | 90/2~91/9 | Mission & Differential (M/T) FRONT DIFF. CASE(RH) |
| 03905 5588 | MD741818 | 25 x 35 x 6 | DIAMANTE / SIGMA F1#...MT | 91/8~95/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 3098 | MD758763 | 41 x 61 x 11.5 x 16 | DIAMANTE / SIGMA F14A | 99/9~02/ | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |
| 03905 7211 | MD101915 | 91 x 111 x 9 | DIAMANTE / SIGMA 6G71 | 90/2~92/ | Engine CRANK SHAFT REAR |
| 03905 2807 | MD307343 | | DIAMANTE / SIGMA 6G73 DOHC EX. | 94/11~02/ | Engine VALVE STEM SEAL |
| 03905 7934 | MD307342 | | DIAMANTE / SIGMA 6G73 SOHC EX. | 94/11~02/ | Engine VALVE STEM SEAL |
| 03905 3359 | MD184303 | | DIAMANTE / SIGMA 6A12,6A13 IN. | 92/10~ | Engine VALVE STEM SEAL |
| 03905 2096 | MD184303 | | DIAMANTE / SIGMA 6G73 SOHC IN. | 94/11~02/ | Engine VALVE STEM SEAL |
| 03905 2213 | MD306079 | | DIAMANTE / SIGMA 6G72 IN. | 94/11~02/ | Engine VALVE STEM SEAL |
| 03905 4688 | MD306079 | | DIAMANTE / SIGMA 6G73 DOHC IN. | 94/11~02/ | Engine VALVE STEM SEAL |
| 03905 2918 | MD306079 | | DIAMANTE / SIGMA 6G73,6G72 IN. & EX. | 90/2~95/ | Engine VALVE STEM SEAL |
| 03905 6902 | MD000508 | | DIAMANTE / SIGMA 6G71 IN. & EX. | 90/2~92/ | Engine VALVE STEM SEAL |
| 03905 7946 | MD359158 | 85 x 103 x 7.5 | DIAMANTE / SIGMA 6A13 | 02/10~ | Engine CRANK SHAFT REAR |
| 03905 8048 | MD150161 | 85 x 103 x 8 | DIAMANTE / SIGMA 6A12 | 92/10~95/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7466 | MD707184 | 35 x 56 x 9 x 12 | DIAMANTE / SIGMA F25A,27A,41A,46A,47A(4 WD) | 90/2~02/ | Mission & Differential (M/T) REAR DIFF. SIDE |
| 03905 7055 | MD120699 | 91 x 111 x 9 | DIAMANTE / SIGMA 6G73,6G72 | 92/10~00/ 3 | Engine CRANK SHAFT REAR |
| 03905 7724 | MD153103 | 35 x 50 x 8 | DIAMANTE / SIGMA 6G71 F11A | 90/2~92/9 | Engine CAM SHAFT |
| 03905 7133 | MD168055 | 37 x 50 x 6 | DIAMANTE / SIGMA 6G71,6G72,6G73,6A12,6 A13 | 90/2~ | Engine CAM SHAFT |
| 03905 6548 | MD307343 | | DIAMANTE / SIGMA 6G72 EX. | 94/11~02/ | Engine VALVE STEM SEAL |
| 03905 6896 | MD152603 | 30 x 42 x 8 x 8.4 | DIAMANTE / SIGMA 6G72 F36A(EXC. TYGH),46A,47A | 94/11~02/ | Engine CAM SHAFT |
| 03905 1676 | MD302338 | | DIAMANTE / SIGMA 6A12,6A13 EX. | 92/10~ | Engine VALVE STEM SEAL |
| 03905 4421 | MD152603 | 30 x 42 x 8 x 8.4 | DIAMANTE / SIGMA 6G72 F17A,27A | 90/2~95/ | Engine CAM SHAFT |
| 03905 5423 | MD152603 | 30 x 42 x 8 x 8.4 | DIAMANTE / SIGMA 6G73 F31A,41A(DOHC) | 94/11~02/ | Engine CAM SHAFT |
| 03905 2498 | MD152603 | 30 x 42 x 8 x 8.4 | DIAMANTE / SIGMA 6G73 F13A,15A,25A | 90/2~95/ | Engine CAM SHAFT |
| 03905 7787 | MD153103 | 35 x 50 x 8 | DIAMANTE / SIGMA 6G72 F36A TYGH | 94/11~02/ | Engine CAM SHAFT |
| 03905 6083 | MD153103 | 35 x 50 x 8 | DIAMANTE / SIGMA 6G73 F31A,41A(SOHC) | 94/11~02/ | Engine CAM SHAFT |
| 03905 6590 | MD153103 | 35 x 50 x 8 | DIAMANTE / SIGMA 6A13 F34A | 02/10~ | Engine CAM SHAFT |
| 03905 6293 | MD372251 | 91 x 111 x 7.5 | DIAMANTE / SIGMA 6G73,6G72 | 00/3~02/ | Engine CRANK SHAFT REAR |
| 03905 1301 | MB573309 | 54 x 82 x 8 x 11 | DIAMANTE / SIGMA F13A | 90/2~92/9 | Wheel Hub FRONT INNER |
| 03905 3386 | MD707184 | 35 x 56 x 9 x 12 | DIAMANTE / SIGMA F11A,12A | 90/2~94/ | Mission & Differential (M/T) FRONT DIFF. CASE(L&R) |
| 03905 2504 | MB573309 | 54 x 82 x 8 x 11 | DIAMANTE / SIGMA F11A,F12A | 90/2~95/ | Wheel Hub FRONT INNER |
| 03905 3731 | MB573309 | 54 x 82 x 8 x 11 | DIAMANTE / SIGMA F13A TNHM,TRHM | 92/10~95/ | Wheel Hub FRONT INNER |
| 03905 1742 | MB633432 | 60 x 86 x 7 x 12 | DIAMANTE / SIGMA F13A TRHM1 | 92/10~95/ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8993 | MB633432 | 60 x 86 x 7 x 12 | DIAMANTE / SIGMA F15A,17A,27A | 90/2~95/ | Wheel Hub FRONT INNER |
| 03905 2993 | MB633432 | 60 x 86 x 7 x 12 | DIAMANTE / SIGMA F07W,F36W | 92/12~98/ | Wheel Hub FRONT INNER |
| 03905 5183 | MB303875 | 52 x 72 x 8 x 11 | DIAMANTE / SIGMA F13A | 90/2~92/9 | Wheel Hub FRONT OUTER |
| 03905 5165 | MB303875 | 52 x 72 x 8 x 11 | DIAMANTE / SIGMA F13A TNHM,TRHM | 92/10~95/ | Wheel Hub FRONT OUTER |
| 03905 7331 | MB633434 | 57 x 76 x 6.8 x 9.5 | DIAMANTE / SIGMA F13A TRHM1 | 92/10~95/ | Wheel Hub FRONT OUTER |
| 03905 4334 | MB633434 | 57 x 76 x 6.8 x 9.5 | DIAMANTE / SIGMA F15A,17A,27A | 90/2~95/ | Wheel Hub FRONT OUTER |
| 03905 7751 | MB633434 | 57 x 76 x 6.8 x 9.5 | DIAMANTE / SIGMA F07W,F36W | 92/12~98/ | Wheel Hub FRONT OUTER |
| 03905 8504 | MB303875 | 52 x 72 x 8 x 11 | DIAMANTE / SIGMA F11A,F12A | 90/2~95/ | Wheel Hub FRONT OUTER |
| 03905 5843 | MB393807 | 36 x 64 x 11 x 19 | DIAMANTE / SIGMA A25A,F27A(4WD) | 90/2~95/ | Wheel Hub REAR |
| 03905 3722 | MD755904 | 41 x 61 x 9 x 13.5 | DION CR5W,6W,9W 2WD | 99/12~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 1223 | MD050606 | 44 x 60 x 7 | DION 4G63 | 99/12~ | Engine CRANK SHAFT FRONT |
| 03905 8861 | MD168055 | 37 x 50 x 6 | DION 4G93,94 | 00/7~ | Engine CRANK SHAFT FRONT |
| 03905 5216 | MD069950 | 25 x 35 x 6 | DION 4G63 | 99/12~ | Engine BLANCER SHAFT |
| 03905 3872 | MD095355 | 20 x 30 x 7 | DION 4G63 | 99/12~ | Engine OIL PUMP |
| 03905 2666 | MD153103 | 35 x 50 x 8 | DION CR9W 4G63 | 99/12~ | Engine CAM SHAFT |
| 03905 8078 | MD153103 | 35 x 50 x 8 | DION CR5W 4G63 | 02/4~ | Engine CAM SHAFT |
| 03905 1475 | MD758763 | 41 x 61 x 11.5 x 16 | DION CR5W,6W 4WD | 00/7~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 3572 | MD359158 | 85 x 103 x 7.5 | DION 4G63,93,94 | 99/12~ | Engine CRANK SHAFT FRONT |
| 03905 7340 | MD153103 | 35 x 50 x 8 | DION CR6W 4G94 | 00/7~ | Engine CAM SHAFT |
| 03905 5429 | MD707575 | 42 x 60 x 9 | DION CR5W,6W,9W | 99/12~ | Mission & Differential (A/T) CONVERTER OIL PUMP |
| 03905 2453 | MD306079 | | DION 4G63 IN. | 99/12~ | Engine VALVE STEM SEAL |
| 03905 8486 | MD307343 | | DION 4G63 EX. | 99/12~ | Engine VALVE STEM SEAL |
| 03905 8873 | MD184303 | | DION 4G93,94 | 00/7~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8543 | MD707184 | 35 x 56 x 9 x 12 | DION CR5W,6W 4WD | 00/7~ | Mission & Differential (A/T) REAR DIFF. SIDE |
| 03905 4871 | MD069950 | 25 x 35 x 6 | ECLIPSE D22A,27A,32A,38A 4G63 | 89/9~97/ | Engine BRANCER SHAFT |
| 03905 3239 | MD707184 | 35 x 56 x 9 x 12 | ECLIPSE D22A | 89/9~94/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 1466 | MD742053 | 37 x 56 x 9 x 12.5 | ECLIPSE D32A,38A | 95/6~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 7172 | MD742053 | 37 x 56 x 9 x 12.5 | ECLIPSE D32A,38A | 95/6~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 3515 | MD707575 | 42 x 60 x 9 | ECLIPSE D22A,27A,32A,38A | 89/9~97/ | Mission & Differential (M/T&A/T) CONVERTER OIL PUMP |
| 03905 4082 | MD741818 | 25 x 35 x 6 | ECLIPSE D22A,27A,32A | 91/8~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 2972 | MD095355 | 20 x 30 x 7 | ECLIPSE D22A,27A,32A,38A 4G63 | 89/9~97/ | Engine OIL PUMP |
| 03905 2018 | MD719710 | 35 x 54 x 10 x 17 | ECLIPSE D27A | 89/9~93/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 4388 | MD050606 | 44 x 60 x 7 | ECLIPSE D22A,27A,32A,38A 4G63 | 89/9~97/ | Engine CRANK SHAFT FRONT |
| 03905 8468 | MD069947 | 80 x 96 x 9 | ECLIPSE D22A,27A 4G63 | 89/9~92/6 | Engine CRANK SHAFT REAR |
| 03905 1025 | MD359158 | 85 x 103 x 7.5 | ECLIPSE D22A,27A 4G63 | 92/7~95/ | Engine CRANK SHAFT REAR |
| 03905 5525 | MD359158 | 85 x 103 x 7.5 | ECLIPSE D32A,38A 4G63 | 95/6~97/ | Engine CRANK SHAFT REAR |
| 03905 6803 | MD307343 | | ECLIPSE 4G63 IN. & EX. | 89/9~97/ | Engine VALVE STEM SEAL |
| 03905 5939 | MD153103 | 35 x 50 x 8 | ECLIPSE D22A,27A,32A,38A 4G63 | 89/9~97/ | Engine CAM SHAFT |
| 03905 2699 | MB303875 | 52 x 72 x 8 x 11 | ECLIPSE D22A,27A | 89/9~95/ | Wheel Hub FRONT OUTER |
| 03905 7217 | MB573309 | 54 x 82 x 8 x 11 | ECLIPSE D22A,27A | 89/9~95/ | Wheel Hub FRONT INNER |
| 03905 1910 | MD707184 | 35 x 56 x 9 x 12 | ECLIPSE D22A,27A | 89/9~95/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 8618 | MD069950 | 25 x 35 x 6 | ECLIPSE D22A,27A | 89/9~91/8 | Mission & Differential (M/T) INPUT SHAFT |
| 03905 3995 | MD707575 | 42 x 60 x 9 | EK-WAGON, EK-SPORTS H81W | 01/10~ | Mission & Differential (A/T) OIL PUMP BODY |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4436 | MV026391 | 35 x 46 x 8 | EK-WAGON, EK-SPORTS H81W WITHOUT ABS | 01/10~ | Wheel Hub REAR |
| 03905 2432 | MD707184 | 35 x 56 x 9 x 12 | EK-WAGON, EK-SPORTS H81W | 01/10~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 1034 | MB092620 | 35 x 55 x 11 | EK-WAGON, EK-SPORTS H81W 4WD | 01/10~ | Mission & Differential (A/T) REAR DIFF. PINION |
| 03905 6791 | MD162689 | 35 x 47 x 8.5 | EK-WAGON, EK-SPORTS 3G83 H81W | 01/10~ | Engine CAM SHAFT |
| 03905 4544 | MD069948 | 17 x 28 x 7 | EK-WAGON, EK-SPORTS 3G83 H81W | 01/10~ | Engine OIL PUMP |
| 03905 7049 | MD115245 | 31 x 45 x 7 | EK-WAGON, EK-SPORTS 3G83 H81W | 01/10~ | Engine CRANK SHAFT FRONT |
| 03905 7199 | MD321819 | 60 x 75 x 8 | EK-WAGON, EK-SPORTS 3G83 H81W | 01/10~ | Engine CRANK SHAFT REAR |
| 03905 3545 | MD179175 | | EK-WAGON, EK-SPORTS 3G83 H81W | 01/10~ | Engine VALVE STEM SEAL |
| 03905 1895 | MB936241 | 33 x 50 x 13 | EK-WAGON, EK-SPORTS H81W WITH ABS | 01/10~ | Wheel Hub REAR |
| 03905 1760 | MD302338 | | FTO 6A12 EX. | 94/10~00/ | Engine VALVE STEM SEAL |
| 03905 5012 | MD008762 | 35 x 50 x 8 | FTO DE2A 4G93 | 94/10~00/ | Engine CAM SHAFT |
| 03905 6224 | MD008762 | 35 x 50 x 8 | FTO DE3A 6A12 | 94/10~00/ | Engine CAM SHAFT |
| 03905 5906 | MD168055 | 37 x 50 x 6 | FTO 4G93,6A12 | 94/10~00/ | Engine CRANK SHAFT FRONT |
| 03905 9026 | MD150161 | 85 x 103 x 8 | FTO 4G93,6A12 | 94/10~95/ 2 | Engine CRANK SHAFT REAR |
| 03905 8267 | MD359158 | 85 x 103 x 7.5 | FTO 4G93,6A12 | 95/3~00/ | Engine CRANK SHAFT REAR |
| 03905 8315 | MD184303 | | FTO 6A12 IN. | 94/10~00/ | Engine VALVE STEM SEAL |
| 03905 4856 | MR198955 | | FTO DE3A HRG#,HNG#,HNF#,HRF# ,HNX#,HY# | 94/10~00/ | Power Steering SEAL KIT |
| 03905 1256 | MB573309 | 54 x 82 x 8 x 11 | FTO DE2A,DE3A | 94/10~00/ | Wheel Hub FRONT INNER |
| 03905 6566 | MD184303 | | FTO 4G93 IN. & EX. | 94/10~00/ | Engine VALVE STEM SEAL |
| 03905 5714 | MB303875 | 52 x 72 x 8 x 11 | FTO DE2A,DE3A | 94/10~00/ | Wheel Hub FRONT OUTER |
| 03905 3662 | MN184008 | | FTO DE3A HNH#,HRH# | 97/2~00/ | Power Steering SEAL KIT |
| 03905 5048 | MD741818 | 25 x 35 x 6 | FTO DE2A,DE3A | 94/10~00/ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7631 | MD755904 | 41 x 61 x 9 x 13.5 | FTO DE2A,DE3A | 94/10~00/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(L&R) |
| 03905 8231 | MD707575 | 42 x 60 x 9 | FTO DE2A,DE3A | 94/10~00/ | Mission & Differential (A/T) CONVERTER OIL PUMP |
| 03905 2522 | MB103090R | | FTO DE2A | 94/10~97/ 1 | Power Steering SEAL KIT |
| 03905 7577 | MB103090R | | FTO DE3A HNH#,HRH# | 94/10~97/ 1 | Power Steering SEAL KIT |
| 03905 4781 | MN184008 | | FTO DE2A | 97/2~00/ | Power Steering SEAL KIT |
| 03905 6326 | MH034036 | 55 x 72 x 9 | FUSO BUS MJ, MK, ME MK115 | 76/~84/ | Transmission REAR |
| 03905 6611 | MH034146 | 50 x 68 x 9 | FUSO BUS MJ, MK, ME MJ2#,6# | 93/7~ | Transmission FRONT |
| 03905 8360 | MH034146 | 50 x 68 x 9 | FUSO BUS MJ, MK, ME MK2#,6# | 93/7~ | Transmission FRONT |
| 03905 4439 | MH034146 | 50 x 68 x 9 | FUSO BUS MJ, MK, ME MK117 FF,JF,JR,JUF,JUR | 87/10~93/ | Transmission FRONT |
| 03905 7706 | MH034146 | 50 x 68 x 9 | FUSO BUS MJ, MK, ME MK516 | 88/1~93/ | Transmission FRONT |
| 03905 4106 | MH034146 | 50 x 68 x 9 | FUSO BUS MJ, MK, ME MK517 JF,JR | 87/10~93/ | Transmission FRONT |
| 03905 6920 | MH034148 | 58 x 75 x 9 | FUSO BUS MJ, MK, ME MK102,116,117,126 | 79/2~93/ | Transmission REAR |
| 03905 1526 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MK618 FM,FME,FP,JF,JM,JME,JP,JR,JUR,FY,JY | 93/7~95/ | Final Drive PINION |
| 03905 3989 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME ME17D | 02/3~ | Transmission FRONT |
| 03905 7061 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME MJ117,527 | 87/10~93/ | Transmission FRONT |
| 03905 1775 | MH034146 | 50 x 68 x 9 | FUSO BUS MJ, MK, ME MK525,526,595 | 87/10~96/ | Transmission FRONT |
| 03905 1934 | MH034148 | 58 x 75 x 9 | FUSO BUS MJ, MK, ME MK115 | 84/~87/ | Transmission REAR |
| 03905 1502 | MH034148 | 58 x 75 x 9 | FUSO BUS MJ, MK, ME MK2#,5#,6# | 84/5~ | Transmission REAR |
| 03905 5822 | MH034035 | 60 x 82 x 13.5 x 20 | FUSO BUS MJ, MK, ME MK# | 74/~75/2 | Final Drive PINION |
| 03905 6980 | MH034048 | 60 x 103 x 13.5 x 20 | FUSO BUS MJ, MK, ME MK# | 75/3~77/ | Final Drive PINION |
| 03905 6188 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MK218,219 EXC. JD | 93/7~99/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6263 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MK619 FM,FME,FUF,JF,JM,JME, JR,JUR,FF,FP,JP,FY,JY | 95/4~99/ | Final Drive PINION |
| 03905 3959 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MK23H FM,FME,JM,JME | 99/5~ | Final Drive PINION |
| 03905 5345 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME MK527 | 87/10~96/ | Transmission FRONT |
| 03905 4652 | MH034175 | 130 x 146 x 14 | FUSO BUS MJ, MK, ME MK2# | 93/7~ | Wheel Hub REAR INNER |
| 03905 3929 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MK25H FM,FME,FY,JM,JME,JV | 99/5~ | Final Drive PINION |
| 03905 3131 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MK1#,5# | 77/~96/ | Final Drive PINION |
| 03905 7151 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO BUS MJ, MK, ME MJ117,527 | 87/10~93/ | Wheel Hub REAR OUTER |
| 03905 1445 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MK618,619 FD,FH,JD,JH | 93/7~99/ | Final Drive PINION |
| 03905 2747 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MK218,219 JD | 93/7~99/ | Final Drive PINION |
| 03905 6542 | MH034091 | 102 x 116 x 14 | FUSO BUS MJ, MK, ME MJ#,MK# | 79/9~ | Wheel Hub FRONT |
| 03905 8564 | MB025295 | 72 x 94 x 10 | FUSO BUS MJ, MK, ME ME17D | 02/3~ | Wheel Hub FRONT |
| 03905 6182 | MH034092 | 130 x 150 x 14 | FUSO BUS MJ, MK, ME MJ117,527 | 87/10~93/ | Wheel Hub REAR INNER |
| 03905 4142 | MH034092 | 130 x 150 x 14 | FUSO BUS MJ, MK, ME MK1# | 79/9~93/ | Wheel Hub REAR INNER |
| 03905 6908 | MH034092 | 130 x 150 x 14 | FUSO BUS MJ, MK, ME MK5# | 84/5~94/11 | Wheel Hub REAR INNER |
| 03905 8465 | MH034175 | 130 x 146 x 14 | FUSO BUS MJ, MK, ME MJ2#,6# | 93/7~ | Wheel Hub REAR INNER |
| 03905 8552 | MH034175 | 130 x 146 x 14 | FUSO BUS MJ, MK, ME MK526,527 | 94/12~96/ | Wheel Hub REAR INNER |
| 03905 5243 | MH034175 | 130 x 146 x 14 | FUSO BUS MJ, MK, ME MK6# | 93/7~ | Wheel Hub REAR INNER |
| 03905 8237 | MH034006 | 65 x 120.5 x 10 | FUSO BUS MJ, MK, ME MK116,126,516 | 79/9~86/6 | Wheel Hub REAR OUTER |
| 03905 3830 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME MK517 FD,FG,FH,JD,JG,JH | 87/10~93/ | Transmission FRONT |
| 03905 8495 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO BUS MJ, MK, ME MK1# | 86/7~93/ | Wheel Hub REAR OUTER |
| 03905 1217 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO BUS MJ, MK, ME MK5# | 86/7~96/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6305 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO BUS MJ, MK, ME MJ2#,6# | 93/7~ | Wheel Hub REAR OUTER |
| 03905 6467 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO BUS MJ, MK, ME MK2#,6# | 93/7~ | Wheel Hub REAR OUTER |
| 03905 5060 | MB308966 | 56 x 114 x 10 | FUSO BUS MJ, MK, ME ME17D | 02/3~ | Wheel Hub REAR OUTER |
| 03905 9011 | ME620713 | 34 x 50 x 7 | FUSO BUS MJ, MK, ME MK115 | 79/~84/ | Transmission FRONT |
| 03905 7241 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME MK102,116,126,515,516 | 79/12~87/ 12 | Transmission FRONT |
| 03905 8435 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME MK115 | 84/~87/ | Transmission FRONT |
| 03905 2573 | MH034147 | 40 x 58 x 8 | FUSO BUS MJ, MK, ME MK117 FD,FG,FK,JD,JG,JK | 87/10~93/ | Transmission FRONT |
| 03905 5381 | MB308965 | 85 x 127 x 13 | FUSO BUS MJ, MK, ME ME17D | 02/3~ | Wheel Hub REAR INNER |
| 03905 7592 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MJ, MK, ME 6D15 MK516,526,616,626 | 90/4~95/ | Engine CRANK SHAFT REAR |
| 03905 3683 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS MJ, MK, ME MJ117,527 | 87/10~93/ | Final Drive PINION |
| 03905 2090 | ME241213 | | FUSO BUS MJ, MK, ME 6D1#,6M6#,4M50 | 95/4~ | Engine VALVE STEM SEAL |
| 03905 2081 | ME215092 | | FUSO BUS MJ, MK, ME 6D1# | 74/~95/4 | Engine VALVE STEM SEAL |
| 03905 8075 | ME240010 | 101 x 123 x 13.5 | FUSO BUS MJ, MK, ME 4M50 ME17D | 02/3~ | Engine CRANK SHAFT REAR |
| 03905 1115 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MJ, MK, ME 6M61 MK23H,25H,27H,MJ23H, 25H,26H,27H | 99/5~ | Engine CRANK SHAFT REAR |
| 03905 5735 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MJ, MK, ME 6D17 MK218,219,618,619,628,6 29,MJ218,219,628,629 | 93/7~99/ | Engine CRANK SHAFT REAR |
| 03905 5222 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MJ, MK, ME 6D16 MK117,517,527,612,622, MJ117,217,527 | 87/10~99/ | Engine CRANK SHAFT REAR |
| 03905 6044 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MJ, MK, ME 6D14 MK525,595 | 87/10~90/ | Engine CRANK SHAFT REAR |
| 03905 2471 | ME030856 | 107 x 140 x 180 x 17.5 | FUSO BUS MJ, MK, ME 6D15 MK116,126,516 | 84/5~87/1 0 | Engine CRANK SHAFT REAR |
| 03905 5549 | ME030856 | 107 x 140 x 180 x 17.5 | FUSO BUS MJ, MK, ME 6D14 MK115,515 | 84/5~87/1 0 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6866 | ME031584 | 105 x 125 x 11 | FUSO BUS MJ, MK, ME 6D14 MK115 | 74/~84/5 | Engine CRANK SHAFT REAR |
| 03905 6200 | ME031584 | 105 x 125 x 11 | FUSO BUS MJ, MK, ME 6D10 MK103 | 74/~84/5 | Engine CRANK SHAFT REAR |
| 03905 1679 | ME031548 | 100 x 125 x 12.5 | FUSO BUS MJ, MK, ME 6D15 MK116 | 74/~84/ | Engine CRANK SHAFT REAR |
| 03905 2615 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MJ2#,6# | 87/10~ | Final Drive PINION |
| 03905 5882 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MK612,616,622,626,628,629 | 93/7~99/ | Final Drive PINION |
| 03905 6086 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MJ, MK, ME 6M60 MK25F,26F | 99/5~ | Engine CRANK SHAFT REAR |
| 03905 8585 | ME031548 | 100 x 125 x 12.5 | FUSO BUS MJ, MK, ME 6DS7 MK102 | 74/~84/ | Engine CRANK SHAFT REAR |
| 03905 3083 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MK23H FF,FVF,HNVF,HVF,JF,JR | 99/5~ | Final Drive PINION |
| 03905 4610 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MK25H FD,FF,JD,JF,JNVF,JR,JVF | 99/5~ | Final Drive PINION |
| 03905 4409 | MH034172 | 65 x 113 x 10 x 30 | FUSO BUS MJ, MK, ME MK25F,26F,27H | 99/5~ | Final Drive PINION |
| 03905 2243 | MH034205 | 56 x 99 x 10 x 34 | FUSO BUS MJ, MK, ME ME17D | 02/3~ | Final Drive PINION |
| 03905 2162 | ME034156 | 55 x 78 x 12 | FUSO BUS MJ, MK, ME 6DS7 MK102 | 74/~84/ | Engine CRANK SHAFT FRONT |
| 03905 8165 | ME031543 | 72 x 94 x 12 | FUSO BUS MJ, MK, ME 6D1#...MK#,MJ# | 74/~88/8 | Engine CRANK SHAFT FRONT |
| 03905 1427 | ME071269 | 76 x 94 x 12 | FUSO BUS MJ, MK, ME 6D1#...MK#,MJ# | 88/9~95/ | Engine CRANK SHAFT FRONT |
| 03905 5153 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO BUS MJ, MK, ME 6D1#...MK#,MJ# | 95/4~ | Engine CRANK SHAFT FRONT |
| 03905 3335 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO BUS MJ, MK, ME 6M60 MK25F,26F | 99/5~ | Engine CRANK SHAFT FRONT |
| 03905 2348 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO BUS MJ, MK, ME 6M61 MK23H,25H,27H,MJ23H,25H,26H,27H | 99/5~ | Engine CRANK SHAFT FRONT |
| 03905 2642 | ME240328 | 42 x 66 x 11.5 x 18.5 | FUSO BUS MJ, MK, ME 4M50 ME17D | 02/3~ | Engine CRANK SHAFT FRONT |
| 03905 3401 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 8M21 MS822,MU612 | 95/3~97/8 | Engine CRANK SHAFT REAR |
| 03905 5858 | ME031543 | 72 x 94 x 12 | FUSO BUS MM, MP, MR, MS, MU 6D1#...MM# | 74/~88/8 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7862 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO BUS MM, MP, MR, MS, MU 6D24 MP##7 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 3473 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 6D24 MP##7 | 95/3~97/8 | Engine CRANK SHAFT REAR |
| 03905 1109 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO BUS MM, MP, MR, MS, MU 8DC9 MS815 | 95/3~00/ | Engine CRANK SHAFT REAR |
| 03905 2861 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO BUS MM, MP, MR, MS, MU 8DC11 MS819,829,85K | 95/3~ | Engine CRANK SHAFT REAR |
| 03905 6887 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO BUS MM, MP, MR, MS, MU 8M21 MS822,85M,86M,MU612 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 3599 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 6D22 MP518,618,628 | 80/1~96/ | Engine CRANK SHAFT REAR |
| 03905 2273 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO BUS MM, MP, MR, MS, MU 6M70 MP33J,35J,37J | 00/4~ | Engine CRANK SHAFT REAR |
| 03905 8654 | ME215092 | | FUSO BUS MM, MP, MR, MS, MU 6D1# | 74/~95/ | Engine VALVE STEM SEAL |
| 03905 8129 | ME241213 | | FUSO BUS MM, MP, MR, MS, MU 6D16,6D17 | 95/4~99/ | Engine VALVE STEM SEAL |
| 03905 6569 | ME241213 | | FUSO BUS MM, MP, MR, MS, MU 6M60,6M61 | 99/5~ | Engine VALVE STEM SEAL |
| 03905 5300 | ME061574 | | FUSO BUS MM, MP, MR, MS, MU 8DC#,6D2#,8M20 | 79/~ | Engine VALVE STEM SEAL |
| 03905 3380 | ME180113 | | FUSO BUS MM, MP, MR, MS, MU 6M70 | 00/4~ | Engine VALVE STEM SEAL |
| 03905 5150 | ME071269 | 76 x 94 x 12 | FUSO BUS MM, MP, MR, MS, MU 6D1#...MM# | 88/9~95/ | Engine CRANK SHAFT FRONT |
| 03905 7517 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 8M20 MS821 | 92/8~95/ | Engine CRANK SHAFT REAR |
| 03905 4250 | ME061853 | 95 x 120 x 13 | FUSO BUS MM, MP, MR, MS, MU 6D2#...MP# | 76/~85/ | Engine CRANK SHAFT FRONT |
| 03905 2321 | ME180113 | | FUSO BUS MM, MP, MR, MS, MU 8M20,8M21 | 92/8~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7364 | ME030856 | 107 x 140 x 180 x 17.5 | FUSO BUS MM, MP, MR, MS, MU 6D14,6D15 MM515,116 | 84/~87/10 | Engine CRANK SHAFT REAR |
| 03905 4184 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO BUS MM, MP, MR, MS, MU 6M60,6M61 MM85F,86F,33H,35H | 99/5~ | Engine CRANK SHAFT FRONT |
| 03905 4115 | 31107-06301 | 85 x 110 x 13 | FUSO BUS MM, MP, MR, MS, MU 8DC#...MS# | 75/~83/ | Engine CRANK SHAFT FRONT |
| 03905 8399 | ME061853 | 95 x 120 x 13 | FUSO BUS MM, MP, MR, MS, MU 8DC#...MS#,MU# | 83/~85/ | Engine CRANK SHAFT FRONT |
| 03905 1142 | MH034036 | 55 x 72 x 9 | FUSO BUS MM, MP, MR, MS, MU MM515 | 76/~84/ | Transmission REAR |
| 03905 8702 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO BUS MM, MP, MR, MS, MU 8DC#...MS#,MU# | 85/~ | Engine CRANK SHAFT FRONT |
| 03905 6491 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO BUS MM, MP, MR, MS, MU MP627,628,747,37J | 91/12~ | Final Drive PINION |
| 03905 5318 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO BUS MM, MP, MR, MS, MU 6M70 MP33J,35J,37J | 00/4~ | Engine CRANK SHAFT FRONT |
| 03905 6125 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO BUS MM, MP, MR, MS, MU 6D2#...MP# | 85/~ | Engine CRANK SHAFT FRONT |
| 03905 4454 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO BUS MM, MP, MR, MS, MU 8M21 MS822,85M,86M,MU612 | 95/3~ | Engine CRANK SHAFT FRONT |
| 03905 5786 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 8DC11 MS729 | 88/7~94/ | Engine CRANK SHAFT REAR |
| 03905 3263 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MM, MP, MR, MS, MU 6D1#...MM# | 87/10~99/ | Engine CRANK SHAFT REAR |
| 03905 8405 | MH034155 | 75 x 100 x 13 | FUSO BUS MM, MP, MR, MS, MU MS8# | 92/8~ | Transmission REAR |
| 03905 4325 | ME034976 | 108 x 140 x 180 x 17 | FUSO BUS MM, MP, MR, MS, MU 6M60,6M61 MM85F,86F,33H,35H | 99/5~ | Engine CRANK SHAFT REAR |
| 03905 7373 | 31112-05701 | 130 x 160 x 14 | FUSO BUS MM, MP, MR, MS, MU 8DC#,,,MS# | 75/~80/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5102 | 31112-05701 | 130 x 160 x 14 | FUSO BUS MM, MP, MR, MS, MU 6D2#...MP# | 76/~80/ | Engine CRANK SHAFT REAR |
| 03905 7976 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 8DC8 MS613,713 | 80/1~90/ | Engine CRANK SHAFT REAR |
| 03905 2549 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 8DC9 MS615,715,725,815 | 80/1~95/2 | Engine CRANK SHAFT REAR |
| 03905 9050 | 31212-33300 | 135 x 155.5 x 15 | FUSO BUS MM, MP, MR, MS, MU 8DC10 MS716,726,826 | 90/4~95/ | Engine CRANK SHAFT REAR |
| 03905 8327 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO BUS MM, MP, MR, MS, MU 8M20 MS821 | 92/8~95/ | Engine CRANK SHAFT FRONT |
| 03905 7469 | MC807438 | 154 x 172 x 14 | FUSO BUS MM, MP, MR, MS, MU MP#,MS#,MM# | 84/8~ | Wheel Hub REAR INNER |
| 03905 4685 | MH034148 | 58 x 75 x 9 | FUSO BUS MM, MP, MR, MS, MU MM# | 84/~ | Transmission REAR |
| 03905 8480 | MH034147 | 40 x 58 x 8 | FUSO BUS MM, MP, MR, MS, MU MM116,516 | 80/1~87/ | Transmission FRONT |
| 03905 7574 | MH034147 | 40 x 58 x 8 | FUSO BUS MM, MP, MR, MS, MU MM515 | 84/~87/ | Transmission FRONT |
| 03905 5309 | ME620713 | 34 x 50 x 7 | FUSO BUS MM, MP, MR, MS, MU MM515 | 79/~84/ | Transmission FRONT |
| 03905 7919 | MC835508 | 76 x 157 x 164 x 15 | FUSO BUS MM, MP, MR, MS, MU MP627,628,747,37J | 91/12~ | Wheel Hub REAR OUTER |
| 03905 2177 | MH034134 | 60 x 72 x 12 | FUSO BUS MM, MP, MR, MS, MU MP#,MS#,MM#,MU# | 80/1~ | Wheel Hub REAR OUTER |
| 03905 5267 | MH034136 | 130 x 150 x 12 | FUSO BUS MM, MP, MR, MS, MU MU# | 89/12~ | Wheel Hub REAR INNER(REARWARD) |
| 03905 5753 | 44514-51681 | 45 x 60 x 9 | FUSO BUS MM, MP, MR, MS, MU MP107,117,MS513 | 77/~79/9 | Transmission FRONT |
| 03905 7262 | MC807438 | 154 x 172 x 14 | FUSO BUS MM, MP, MR, MS, MU MU# | 84/12~ | Wheel Hub REAR INNER(FORWARD) |
| 03905 5888 | MH034151 | 52 x 65 x 9 | FUSO BUS MM, MP, MR, MS, MU MP118,218,517,518,618 | 76/~79/9 | Transmission FRONT |
| 03905 6392 | MH034082 | 155 x 180 x 17 | FUSO BUS MM, MP, MR, MS, MU MM#,MP#,MR#,MS# | 80/1~84/8 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1871 | MH034180 | 139 x 158 x 11 | FUSO BUS MM, MP, MR, MS, MU MS826,829,86M HIGH DECKER | 92/8~ | Wheel Hub FRONT |
| 03905 3734 | MH034136 | 130 x 150 x 12 | FUSO BUS MM, MP, MR, MS, MU MS826,829,86M STANDARD DECKER | 92/8~ | Wheel Hub FRONT |
| 03905 8339 | MH034136 | 130 x 150 x 12 | FUSO BUS MM, MP, MR, MS, MU MS821,822 | 92/8~00/ | Wheel Hub FRONT |
| 03905 2399 | MH034136 | 130 x 150 x 12 | FUSO BUS MM, MP, MR, MS, MU MS7#,815,819,85K,85M | 90/1~ | Wheel Hub FRONT |
| 03905 6185 | MH034136 | 130 x 150 x 12 | FUSO BUS MM, MP, MR, MS, MU MM#,MP#,MU# | 90/1~ | Wheel Hub FRONT |
| 03905 3743 | MH034092 | 130 x 150 x 14 | FUSO BUS MM, MP, MR, MS, MU MM#,MP#,MR#,MS#,MU # | 80/1~89/12 | Wheel Hub FRONT |
| 03905 6764 | MH034092 | 130 x 150 x 14 | FUSO BUS MM, MP, MR, MS, MU MU# | 84/12~89/12 | Wheel Hub REAR INNER(REARWARD) |
| 03905 1937 | MH034153 | 70 x 92 x 12 | FUSO BUS MM, MP, MR, MS, MU MS715 | 82/12~90/4 | Transmission REAR |
| 03905 7487 | MC827475 | 70 x 142 x 12 x 36 | FUSO BUS MM, MP, MR, MS, MU MU# | 90/3~ | Final Drive PINION |
| 03905 3950 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO BUS MM, MP, MR, MS, MU MU# | 84/12~90/2 | Final Drive PINION |
| 03905 8198 | MH034178 | 70 x 122 x 12 x 30 | FUSO BUS MM, MP, MR, MS, MU MS815,826 | 92/8~95/ | Final Drive PINION |
| 03905 7145 | MH034178 | 70 x 122 x 12 x 30 | FUSO BUS MM, MP, MR, MS, MU MS5#,6#,7# | 76/10~ | Final Drive PINION |
| 03905 8276 | MH034178 | 70 x 122 x 12 x 30 | FUSO BUS MM, MP, MR, MS, MU MP#...EXC. 627,628,747,37J | 76/10~ | Final Drive PINION |
| 03905 4304 | MH034178 | 70 x 122 x 12 x 30 | FUSO BUS MM, MP, MR, MS, MU MM# | 76/10~ | Final Drive PINION |
| 03905 3440 | 03434-07051 | 70 x 92 x 13.5 x 20.5 | FUSO BUS MM, MP, MR, MS, MU MP#,MS# | 76/~76/9 | Final Drive PINION |
| 03905 3284 | MH034146 | 50 x 68 x 9 | FUSO BUS MM, MP, MR, MS, MU MM# | 87/10~ | Transmission FRONT |
| 03905 1718 | MH034155 | 75 x 100 x 13 | FUSO BUS MM, MP, MR, MS, MU MS729 | 88/7~94/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1700 | MC827475 | 70 x 142 x 12 x 36 | FUSO BUS MM, MP, MR, MS, MU MS819,821,822,829,85K,85M,86M | 92/8~ | Final Drive PINION |
| 03905 2141 | MH034153 | 70 x 92 x 12 | FUSO BUS MM, MP, MR, MS, MU MS513,613,615,713,716,725,725,726 | 75/~94/ | Transmission REAR |
| 03905 4181 | MH034153 | 70 x 92 x 12 | FUSO BUS MM, MP, MR, MS, MU MP# | 76/~ | Transmission REAR |
| 03905 1337 | MH034148 | 58 x 75 x 9 | FUSO BUS MM, MP, MR, MS, MU MM116,117,5#(EXC.515) | 80/1~84/ | Transmission REAR |
| 03905 9041 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO BUS MM, MP, MR, MS, MU 6D16,6D17 MM812,822,219,319,619,719 | 95/4~99/ | Engine CRANK SHAFT FRONT |
| 03905 8942 | MH034151 | 52 x 65 x 9 | FUSO BUS MM, MP, MR, MS, MU MU# | 84/12~ | Transmission FRONT |
| 03905 4976 | MH034151 | 52 x 65 x 9 | FUSO BUS MM, MP, MR, MS, MU MS# | 80/1~ | Transmission FRONT |
| 03905 5777 | MH034151 | 52 x 65 x 9 | FUSO BUS MM, MP, MR, MS, MU MP# | 79/10~ | Transmission FRONT |
| 03905 3644 | MH034155 | 75 x 100 x 13 | FUSO BUS MM, MP, MR, MS, MU MU# | 84/12~ | Transmission REAR |
| 03905 4058 | MH034155 | 75 x 100 x 13 | FUSO BUS MM, MP, MR, MS, MU MS715 | 90/4~94/ | Transmission REAR |
| 03905 1688 | MB161152 | 70 x 112 x 10 x 18.5 | FUSO BUS ROSA BE, BH, BG, BK BE#,BH#,BG# | 79/3~ | Wheel Hub REAR INNER |
| 03905 7430 | MH034181 | 50 x 65 x 9 | FUSO BUS ROSA BE, BH, BG, BK BE4##,6## | 95/4~ | Transmission REAR |
| 03905 5768 | MH034177 | 48 x 65 x 9 | FUSO BUS ROSA BE, BH, BG, BK BE2##,4##,BH2## | 79/3~95/3 | Transmission REAR |
| 03905 4898 | MH034147 | 40 x 58 x 8 | FUSO BUS ROSA BE, BH, BG, BK BE6##,BG6## | 97/8~ | Transmission FRONT |
| 03905 1430 | MH034147 | 40 x 58 x 8 | FUSO BUS ROSA BE, BH, BG, BK BE438,439,449,459 | 89/10~97/ | Transmission FRONT |
| 03905 7646 | MH034147 | 40 x 58 x 8 | FUSO BUS ROSA BE, BH, BG, BK BE436,BG438 | 95/4~97/ | Transmission FRONT |
| 03905 2873 | MH034147 | 40 x 58 x 8 | FUSO BUS ROSA BE, BH, BG, BK BK215F | 81/2~86/ | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3371 | ME620713 | 34 x 50 x 7 | FUSO BUS ROSA BE, BH, BG, BK BE434,435,436,437,BG437 | 86/1~95/3 | Transmission FRONT |
| 03905 3629 | ME620713 | 34 x 50 x 7 | FUSO BUS ROSA BE, BH, BG, BK BE201D,211D,BH212F,214F | 79/3~86/ | Transmission FRONT |
| 03905 3164 | MH034006 | 65 x 120.5 x 10 | FUSO BUS ROSA BE, BH, BG, BK BK215F | 81/2~86/ | Wheel Hub REAR OUTER |
| 03905 7163 | MB308933 | 46 x 102 x 10 x 16 | FUSO BUS ROSA BE, BH, BG, BK BE#,BG# | 86/1~ | Wheel Hub REAR OUTER |
| 03905 1715 | MT327029 | 56 x 81 x 8 | FUSO BUS ROSA BE, BH, BG, BK BE435E#(SHORT BODY) | 86/1~91/9 | Wheel Hub FRONT |
| 03905 5609 | MH034092 | 130 x 150 x 14 | FUSO BUS ROSA BE, BH, BG, BK BK215F | 81/2~86/ | Wheel Hub REAR INNER |
| 03905 8621 | MH034213 | 52 x 84 x 14 | FUSO BUS ROSA BE, BH, BG, BK BE438,632,642 ATM | 95/4~99/ | Final Drive PINION |
| 03905 1907 | MB420112 | 36 x 50 x 8 | FUSO BUS ROSA BE, BH, BG, BK BG437,438 | 89/10~97/ | Wheel Hub FRONT AXLE SHAFT |
| 03905 5456 | MB420155 | 72 x 96 x 8 x 12 | FUSO BUS ROSA BE, BH, BG, BK BG437,438 | 89/10~97/ | Wheel Hub FRONT |
| 03905 8372 | MH034091 | 102 x 116 x 14 | FUSO BUS ROSA BE, BH, BG, BK BK215F | 81/2~86/ | Wheel Hub FRONT |
| 03905 4223 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BG642,64E | 97/8~ | Wheel Hub FRONT |
| 03905 7991 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BE63C,63E,64D,64E,66D | 99/4~ | Wheel Hub FRONT |
| 03905 4310 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BE632,636,642,644,654 | 97/8~99/ | Wheel Hub FRONT |
| 03905 8999 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BE435# | 91/10~95/ | Wheel Hub FRONT |
| 03905 2168 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BE434,437,439,449,459 | 86/1~97/ | Wheel Hub FRONT |
| 03905 3863 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BE435F#(LONG BODY) | 86/1~91/9 | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1880 | MT119305 | 68 x 90 x 12 | FUSO BUS ROSA BE, BH, BG, BK BE211D,BH212F,214F | 79/3~86/ | Wheel Hub FRONT |
| 03905 7007 | MB161134 | 74.4 x 99.5 x 7.7 | FUSO BUS ROSA BE, BH, BG, BK BE201D,211D,BH212F,214F | 79/3~86/ | Wheel Hub REAR OUTER |
| 03905 3476 | ME017208 | 57 x 78 x 10 x 16.5 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BE4## | 93/10~97/ | Engine CRANK SHAFT FRONT |
| 03905 5465 | ME241213 | | FUSO BUS ROSA BE, BH, BG, BK 4M5# | 97/8~ | Engine VALVE STEM SEAL |
| 03905 4592 | ME215092 | | FUSO BUS ROSA BE, BH, BG, BK 4D3# | 79/3~ | Engine VALVE STEM SEAL |
| 03905 4235 | ME031548 | 100 x 125 x 12.5 | FUSO BUS ROSA BE, BH, BG, BK 6D14 BK215F | 81/2~86/ | Engine CRANK SHAFT REAR |
| 03905 8300 | ME001196 | 96 x 113 x 16 | FUSO BUS ROSA BE, BH, BG, BK 6DR5 BH212F | 79/3~86/ | Engine CRANK SHAFT REAR |
| 03905 5042 | ME140010 | 101 x 123 x 13.5 | FUSO BUS ROSA BE, BH, BG, BK 4D3#,4M5#...BE6## | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 1709 | ME140010 | 101 x 123 x 13.5 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BE4## | 93/9~97/ | Engine CRANK SHAFT REAR |
| 03905 4958 | ME011867 | 100 x 124 x 15 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BE4## | 86/1~93/8 | Engine CRANK SHAFT REAR |
| 03905 7913 | ME011754 | 100 x 120 x 16 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BF201D,211D,BH214F | 79/3~86/ | Engine CRANK SHAFT REAR |
| 03905 8894 | ME031543 | 72 x 94 x 12 | FUSO BUS ROSA BE, BH, BG, BK 6D14 BK215F | 81/2~86/ | Engine CRANK SHAFT FRONT |
| 03905 5840 | 31311-06101 | 48 x 70 x 12 | FUSO BUS ROSA BE, BH, BG, BK 6DR5 BH212F | 79/3~86/ | Engine CRANK SHAFT FRONT |
| 03905 6167 | MH034148 | 58 x 75 x 9 | FUSO BUS ROSA BE, BH, BG, BK BK215F | 81/2~86/ | Transmission REAR |
| 03905 6677 | ME017208 | 57 x 78 x 10 x 16.5 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BE636,63C | 97/8~ | Engine CRANK SHAFT FRONT |
| 03905 2627 | MH034213 | 52 x 84 x 14 | FUSO BUS ROSA BE, BH, BG, BK BE2##,434,435,436,437,BG437 | 79/3~97/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8750 | ME013384 | 55 x 78 x 8 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BE4## | 89/10~93/ 10 | Engine CRANK SHAFT FRONT |
| 03905 8501 | ME024156 | 55 x 78 x 12 | FUSO BUS ROSA BE, BH, BG, BK 4D3#...BE2##,BE4##,BH2 14F | 79/3~89/9 | Engine CRANK SHAFT FRONT |
| 03905 6638 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO BUS ROSA BE, BH, BG, BK BK215F | 81/2~86/ | Final Drive PINION |
| 03905 1883 | MH034205 | 56 x 99 x 10 x 34 | FUSO BUS ROSA BE, BH, BG, BK BE644,654,63E,64D,64E,6 6D | 97/8~ | Final Drive PINION |
| 03905 8918 | MH034205 | 56 x 99 x 10 x 34 | FUSO BUS ROSA BE, BH, BG, BK BE439,449,459,BG438 | 95/4~97/ | Final Drive PINION |
| 03905 3155 | MH034205 | 56 x 99 x 10 x 34 | FUSO BUS ROSA BE, BH, BG, BK BE438,632,642 MTM | 95/4~99/ | Final Drive PINION |
| 03905 2396 | MH034205 | 56 x 99 x 10 x 34 | FUSO BUS ROSA BE, BH, BG, BK BE439,449,459,BG438 | 95/4~97/ | Final Drive PINION |
| 03905 2423 | MH034205 | 56 x 99 x 10 x 34 | FUSO BUS ROSA BE, BH, BG, BK BE438 MTM | 95/4~97/ | Final Drive PINION |
| 03905 7445 | MH034213 | 52 x 84 x 14 | FUSO BUS ROSA BE, BH, BG, BK BE636,63C,BG642,64E | 97/8~ | Final Drive PINION |
| 03905 7484 | MH034213 | 52 x 84 x 14 | FUSO BUS ROSA BE, BH, BG, BK BE439,449,459 | 89/10~95/ 3 | Final Drive PINION |
| 03905 6161 | MT327029 | 56 x 81 x 8 | FUSO BUS ROSA BE, BH, BG, BK BE201D | 79/3~86/ | Wheel Hub FRONT |
| 03905 2456 | ME240328 | 42 x 66 x 11.5 x 18.5 | FUSO BUS ROSA BE, BH, BG, BK 4M5#...BE632,642,644,65 4,63E,64D,E,66D | 97/8~ | Engine CRANK SHAFT FRONT |
| 03905 3956 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP54L | 00/2~ | Wheel Hub REAR INNER |
| 03905 4619 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP418 DRS3A,B,C,D,E,F | 83/6~95/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 9056 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP415 DR#(EXC. DRS2A,DRS2B#,DRS2C, 90.10~99.) | 83/6~99/ | Wheel Hub REAR OUTER |
| 03905 8849 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP410,411,416,419,440,441,449 | 83/6~97/ | Wheel Hub REAR OUTER |
| 03905 8555 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP2##,3##...TRACTOR | 74/~83/ | Wheel Hub REAR OUTER |
| 03905 6722 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP103,113,119 | 74/~79/ | Wheel Hub REAR OUTER |
| 03905 8069 | MH034134 | 60 x 72 x 12 | FUSO TRUCK / TRACTOR FP FP50K EXC. NX41 | 00/2~ | Wheel Hub REAR OUTER |
| 03905 3428 | MH034134 | 60 x 72 x 12 | FUSO TRUCK / TRACTOR FP FP515 EXC. DK#,DR# EXC. NX41 | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 5027 | MH034134 | 60 x 72 x 12 | FUSO TRUCK / TRACTOR FP FP418 EXC.DRS3A,DRS3B,DRS3D,DRS3E,DRS3C,DRS3F | 83/6~95/ | Wheel Hub REAR OUTER |
| 03905 3194 | MH034134 | 60 x 72 x 12 | FUSO TRUCK / TRACTOR FP FP415 EXC. DR# | 89/11~99/ | Wheel Hub REAR OUTER |
| 03905 3926 | MH034134 | 60 x 72 x 12 | FUSO TRUCK / TRACTOR FP FP413 | 83/6~89/ | Wheel Hub REAR OUTER |
| 03905 3911 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP50J DR3#,DR4#,GR4# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 8240 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP54M DR3#,GR3# | 00/2~ | Wheel Hub REAR INNER |
| 03905 3944 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP515 NX41 | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 2045 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP54J DR5# | 00/2~ | Wheel Hub REAR INNER |
| 03905 6209 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP50M DR3#,GR3# | 00/2~ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6608 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP50L | 00/2~ | Wheel Hub REAR INNER |
| 03905 3221 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP50J DR5# | 00/2~ | Wheel Hub REAR INNER |
| 03905 7115 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP515 DK#,DR# | 96/4~00/ | Wheel Hub REAR INNER |
| 03905 6509 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP512,514,542,543,544,545 | 96/7~00/ | Wheel Hub REAR INNER |
| 03905 5708 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP445 DRS2A,DRS2B,DRS2C | 85/9~97/ | Wheel Hub REAR INNER |
| 03905 4991 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP424,442,444,446 | 91/9~96/ | Wheel Hub REAR INNER |
| 03905 7058 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP415 DRS2A,DRS2B#,DRS2C | 90/10~99/ | Wheel Hub REAR INNER |
| 03905 2756 | MH034084 | 160 x 182 x 17 | FUSO TRUCK / TRACTOR FP FP412,414 | 89/3~95/ | Wheel Hub REAR INNER |
| 03905 4700 | MH034134 | 60 x 72 x 12 | FUSO TRUCK / TRACTOR FP FP101,102,112,117,217,218 | 74/~88/ | Wheel Hub REAR OUTER |
| 03905 2105 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8M21 FP412,442,512,542,50M,54M | 95/2~ | Engine TIMING GEAR CASE |
| 03905 1298 | 31107-06301 | 85 x 110 x 13 | FUSO TRUCK / TRACTOR FP 8DC# | 74/~83/ | Engine TIMING GEAR CASE |
| 03905 3008 | ME061853 | 95 x 120 x 13 | FUSO TRUCK / TRACTOR FP 8DC8 FP413 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 1601 | ME061853 | 95 x 120 x 13 | FUSO TRUCK / TRACTOR FP 8DC9 FP415 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 4706 | ME061853 | 95 x 120 x 13 | FUSO TRUCK / TRACTOR FP 6DC2#...FP418 | 79/~85/8 | Engine TIMING GEAR CASE |
| 03905 6323 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8DC8 FP413 | 85/9~89/ | Engine TIMING GEAR CASE |
| 03905 5852 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8DC9 FP415,445,515,545 | 85/9~00/ | Engine TIMING GEAR CASE |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5537 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8DC10 FP416,446 | 90/10~96/ | Engine TIMING GEAR CASE |
| 03905 5249 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8DC11 FP419,449,519,549,50K | 85/9~ | Engine TIMING GEAR CASE |
| 03905 1061 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 10DC11 FP414 | 89/3~95/ | Engine TIMING GEAR CASE |
| 03905 7109 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 6D22 FP418 | 85/9~95/ | Engine TIMING GEAR CASE |
| 03905 5897 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP445 EXC. DRS2A,DRS2B,DRS2C | 85/9~97/ | Wheel Hub REAR OUTER |
| 03905 7358 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8M20 FP411,441,511,541 | 91/9~00/ | Engine TIMING GEAR CASE |
| 03905 1319 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP510,511,519,540,541,549 | 96/7~00/ | Wheel Hub REAR OUTER |
| 03905 4703 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 8M22 FP543,50L,54L | 96/7~ | Engine TIMING GEAR CASE |
| 03905 2780 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 10M20 FP424,444,514,544 | 94/12~00/ | Engine TIMING GEAR CASE |
| 03905 3107 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 6M70 FP50J,54J,55J,50K(NX41) | 00/2~ | Engine TIMING GEAR CASE |
| 03905 4094 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK / TRACTOR FP 8DC#,6D2# | 74/~79/ | Engine CRANK SHAFT REAR |
| 03905 1088 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK / TRACTOR FP 8DC#,10DC11,6D22 | 79/10~95/4 | Engine CRANK SHAFT REAR |
| 03905 1781 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK / TRACTOR FP 6D40,8M20,21,22,10M20 | 91/9~97/8 | Engine CRANK SHAFT REAR |
| 03905 4853 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK / TRACTOR FP 8DC# | 95/4~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8471 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK / TRACTOR FP 6D40,8M20,21,22,10M20, 6M70 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 4559 | ME061574 | | FUSO TRUCK / TRACTOR FP 8DC#,10DC11,6D2# | 79/10~ | Engine VALVE STEM SEAL |
| 03905 2792 | ME120154 | | FUSO TRUCK / TRACTOR FP 6D40,8M20,21,22,10M20, 6M70 | 91/9~ | Engine VALVE STEM SEAL |
| 03905 6233 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP50M DR1#,DR2# | 00/2~ | Wheel Hub REAR INNER |
| 03905 1943 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK / TRACTOR FP 6D40 FP410,440,510,540 | 90/8~00/ | Engine TIMING GEAR CASE |
| 03905 1481 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP415 DR#(EXC.DRC,DRF,DRS C,DRSF,DRS7C,DRS7F) | 89/10~99/ | Wheel Hub FRONT |
| 03905 2390 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP54M DR1#,DR2#,GR2# | 00/2~ | Wheel Hub REAR INNER |
| 03905 2996 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP410 DRS1C,DRS1T,DRS3C,G RS1C,GRS3C | 90/8~96/ | Wheel Hub FRONT |
| 03905 3497 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP449 DRA,DRB,DRD,DRE | 89/10~97/ | Wheel Hub FRONT |
| 03905 8087 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP446 DRB | 91/9~96/ | Wheel Hub FRONT |
| 03905 5579 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP445 DRS2A,DRS2B | 90/10~97/ | Wheel Hub FRONT |
| 03905 3329 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP445 DRSA,DRSB,DRSD,DRS E,DRS7A,DRS7B# | 89/10~97/ | Wheel Hub FRONT |
| 03905 3578 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP442 DRB | 95/2~97/ | Wheel Hub FRONT |
| 03905 3557 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP441 DRB,DRCB | 91/9~97/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5198 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP440 DRS3B | 91/10~97/ | Wheel Hub FRONT |
| 03905 6002 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP419 DRA#,DRB#,DRD#,DRE # | 89/10~97/ | Wheel Hub FRONT |
| 03905 6875 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP412 DRS,DRF | 95/2~96/ | Wheel Hub FRONT |
| 03905 3746 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP416 DRA,DRB | 90/10~95/ | Wheel Hub FRONT |
| 03905 2372 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP414 DRB,DRE | 89/3~90/10 | Wheel Hub FRONT |
| 03905 2306 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP415 EXC. DR# | 89/11~99/ | Wheel Hub FRONT |
| 03905 2981 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP414 DRB,DRE | 90/10~95/ | Wheel Hub FRONT |
| 03905 3923 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP414 DRA,DRD | 89/11~95/ | Wheel Hub FRONT |
| 03905 1682 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP411 DRA,DRB,DRCA,DRCB, DRD,DRE | 91/9~96/ | Wheel Hub FRONT |
| 03905 3266 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP449 DRA,DRB,DRD,DRE | 85/9~89/10 | Wheel Hub FRONT |
| 03905 3881 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP445 DRSA,DRSB,DRSD,DRSE,DRS7A,DRS7B# | 85/9~89/10 | Wheel Hub FRONT |
| 03905 5972 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP419 DRA#,DRB#,DRD#,DRE # | 85/9~89/10 | Wheel Hub FRONT |
| 03905 8966 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP418 EXC. DRS3C#,DRS3F | 83/6~89/10 | Wheel Hub FRONT |
| 03905 2651 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP415 DR#(EXC.DRC,DRF,DRSC,DRSF,DRS7S,DRS7F | 83/6~89/10 | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3443 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP414 DRA,DRD | 89/3~89/10 | Wheel Hub FRONT |
| 03905 5885 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP TRACTOR ALL | 74/~85/8 | Wheel Hub FRONT |
| 03905 7178 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP418 EXC. DRS3C#,DRS3F | 89/10~95/ | Wheel Hub FRONT |
| 03905 7181 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP445 DRSC,DRS2C,DRS7C | 85/9~97/ | Wheel Hub FRONT |
| 03905 6755 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP50J,50L,54J,54L,55J | 00/2~ | Final Drive PINION |
| 03905 5306 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP50K | 00/2~ | Wheel Hub REAR INNER |
| 03905 4076 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP50J DR3#,DR4#,GR4# | 00/2~ | Wheel Hub REAR INNER |
| 03905 6374 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP515 EXC. DK#,DR# | 96/4~00/ | Wheel Hub REAR INNER |
| 03905 2633 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP510,511,519,540,541,549 | 96/7~00/ | Wheel Hub REAR INNER |
| 03905 6563 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP445 EXC. DRS2A,DRS2B,DRS2C | 85/9~97/ | Wheel Hub REAR INNER |
| 03905 5492 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP415 DRS2A,DRS2B#,DRS2C(90.10~99.) | 83/6~99/ | Wheel Hub REAR INNER |
| 03905 8843 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP410,411,413,416,418,419,440,441,449 | 83/9~97/ | Wheel Hub REAR INNER |
| 03905 7082 | MH034082 | 155 x 180 x 17 | FUSO TRUCK / TRACTOR FP FP2##,3## | 74/~83/ | Wheel Hub REAR INNER |
| 03905 9023 | MH034180 | 139 x 158 x 11 | FUSO TRUCK / TRACTOR FP FP5## | 96/4~ | Wheel Hub FRONT |
| 03905 8423 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP411 DRC,DRCC,DRF | 91/9~96/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8303 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP446 DRC | 91/9~96/ | Wheel Hub FRONT |
| 03905 4718 | MC807438 | 154 x 172 x 14 | FUSO TRUCK / TRACTOR FP FP54J DR3#,DR4#,GR4# | 00/2~ | Wheel Hub REAR INNER |
| 03905 3767 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP444 | 85/2~97/ | Wheel Hub FRONT |
| 03905 1049 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP442 DRC | 95/2~97/ | Wheel Hub FRONT |
| 03905 6482 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP441 DRCB02,DRCC | 91/9~97/ | Wheel Hub FRONT |
| 03905 6992 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP440 DRS1#,DRS3C | 91/10~97/ | Wheel Hub FRONT |
| 03905 4925 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP424 | 94/12~97/ | Wheel Hub FRONT |
| 03905 4967 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP419 DRC#,DRF#,DRT | 83/6~97/ | Wheel Hub FRONT |
| 03905 8051 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP418 DRS3C#,DRS3F | 83/6~95/ | Wheel Hub FRONT |
| 03905 3125 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP416 DRC | 90/10~95/ | Wheel Hub FRONT |
| 03905 6854 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP415 DRC,DRF,DRSC,DRSF,DRS7C,DRS7F | 83/6~99/ | Wheel Hub FRONT |
| 03905 1118 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP415 DRA02 | 88/9~90 | Wheel Hub FRONT |
| 03905 7691 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP414 DRC,DRF | 89/3~95/ | Wheel Hub FRONT |
| 03905 7025 | MH034089 | 134 x 152 x 11 | FUSO TRUCK / TRACTOR FP FP449 DRC,DRE | 85/9~97/ | Wheel Hub FRONT |
| 03905 6809 | ME677501 | 55 x 75 x 8 | FUSO TRUCK / TRACTOR FP FP543 | 00/2~ | Transmission FRONT |
| 03905 7079 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP50K EXC. NX41 | 00/2~ | Transmission FRONT |
| 03905 1184 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP418 DRS3D,DRS3E,DRS3F | 83/6~88/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4373 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP416 | 90/10~95/ | Transmission REAR |
| 03905 6635 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP415 DRD,DRE,DRF,DRS(EX C.DRS7D,E,F) | 83/6~96/ | Transmission REAR |
| 03905 8264 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP411,412,414,419 EXC.DRD,DRE,DRF | 85/9~96/ | Transmission REAR |
| 03905 7046 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP515 EXC. DKR#,DR2#,NX41 | 96/7~00/ | Transmission REAR |
| 03905 4430 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP418 EXC. DRS3D,DRS3E,DRS3F | 83/6~93/ | Transmission REAR |
| 03905 2492 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP418 DRS3A,DRS3B,DRS3C | 83/6~84/8 | Transmission REAR |
| 03905 6836 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP415 FD,HT,J,L,N,T | 89/11~96/ | Transmission REAR |
| 03905 4673 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP415 DRA,DRB,DRC | 83/6~88/ | Transmission REAR |
| 03905 5846 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP424 M130S7 T/M | 95/2~96/ | Transmission REAR |
| 03905 6461 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP# | 74/~83/ | Transmission REAR |
| 03905 8189 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP441,442,444,445,446,44 9 | 85/9~97/ | Transmission REAR |
| 03905 3173 | MH034146 | 50 x 68 x 9 | FUSO TRUCK / TRACTOR FP FP424 | 94/12~97/ | Transmission FRONT |
| 03905 8978 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP50M,54M DR2#,3#,GR2#,3# | 00/2~ | Transmission FRONT |
| 03905 7271 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP50K NX41 | 00/2~ | Transmission FRONT |
| 03905 6260 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP50J,50L,54J,54L,55J | 00/2~ | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8090 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP515 DR# | 96/7~00/ | Transmission FRONT |
| 03905 1892 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP510,511,512,514,540,541,542,544,545 | 96/7~00/ | Transmission FRONT |
| 03905 5717 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP419 DRD,DRDQ,DRE,DRF | 90/10~91/8 | Transmission FRONT |
| 03905 5621 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP415 DR# | 90/10~99/ | Transmission FRONT |
| 03905 1031 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP414,445 | 90/10~96/ | Transmission FRONT |
| 03905 2606 | MH034233 | 57 x 70 x 9 | FUSO TRUCK / TRACTOR FP FP410,411,412,440,441,442,444 | 90/8~96/ | Transmission FRONT |
| 03905 2234 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP50M,54M DR3#,GR3C | 00/2~ | Final Drive PINION |
| 03905 7184 | MH034153 | 70 x 92 x 12 | FUSO TRUCK / TRACTOR FP FP413 | 83/6~89/ | Transmission REAR |
| 03905 4370 | MH034234 | 83 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP50J,54J DR3#,DR4#,GR4# | 00/2~ | Transmission REAR |
| 03905 3887 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP2#...TRUCK | 75/~88/ | Final Drive PINION |
| 03905 6248 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP103,113,119 DR,DRA,DRC | 76/10~79/ | Final Drive PINION |
| 03905 2786 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK / TRACTOR FP FP313,315 DUMP,MIXER | 79/12~83/ | Final Drive PINION |
| 03905 1538 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK / TRACTOR FP FP102,112 DRDRA,DRC | 76/10~79/ | Final Drive PINION |
| 03905 5186 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK / TRACTOR FP FP1#...DUMP,MIXER | 76/10~79/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1379 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK / TRACTOR FP FP418 H,HT,J,L,N,R,T | 83/6~93/ | Final Drive PINION |
| 03905 8795 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK / TRACTOR FP FP318 CARGO,TANK LORRY | 79/10~83/ | Final Drive PINION |
| 03905 5576 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK / TRACTOR FP FP1#...CARGO,FP217 T | 76/10~79/ | Final Drive PINION |
| 03905 3653 | 03434-07051 | 70 x 92 x 13.5 x 20.5 | FUSO TRUCK / TRACTOR FP FP1# | 74/~76/9 | Final Drive PINION |
| 03905 4502 | MH034245 | 115 x 145 x 13 | FUSO TRUCK / TRACTOR FP FP50J,54J DR5#,GR5# | 00/2~ | Transmission REAR |
| 03905 8030 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP418 DRS3A,DRS3B,DRS3C | 84/9~90/ | Transmission REAR |
| 03905 6338 | ME515135 | 105 x 130 x 13 | FUSO TRUCK / TRACTOR FP FP514 DRE,DRF | 96/7~00/ | Transmission REAR |
| 03905 4418 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP515 EXC. DR# | 96/4~00/ | Transmission FRONT |
| 03905 5075 | MH034234 | 83 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP50L,54L,55J | 00/2~ | Transmission REAR |
| 03905 6728 | MH034234 | 83 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP515 NX41 | 96/7~00/ | Transmission REAR |
| 03905 1064 | MH034234 | 83 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP410,440,510,540 | 90/8~00/ | Transmission REAR |
| 03905 7967 | MH034157 | 80 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP512 DRE,DRF | 96/7~00/ | Transmission REAR |
| 03905 3764 | MH034157 | 80 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP424 M130S0 T/M | 95/2~96/ | Transmission REAR |
| 03905 5501 | MH034157 | 80 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP415 DRS7D,DRS7E,DRS7F | 90/10~95/ | Transmission REAR |
| 03905 8792 | MH034157 | 80 x 105 x 13 | FUSO TRUCK / TRACTOR FP FP411,412,414,419 DRD,DRE,DRF | 90/10~96/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1631 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP50K,50M,54M | 00/2~ | Transmission REAR |
| 03905 1070 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP515 DKR#,DR2# | 96/7~00/ | Transmission REAR |
| 03905 6179 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP512,514 EXC. DRE,DRF | 96/7~00/ | Transmission REAR |
| 03905 4805 | MH034155 | 75 x 100 x 13 | FUSO TRUCK / TRACTOR FP FP511,519,541,542,544,545,549 | 96/7~00/ | Transmission REAR |
| 03905 8174 | ME515135 | 105 x 130 x 13 | FUSO TRUCK / TRACTOR FP FP543 | 96/7~00/ | Transmission REAR |
| 03905 8441 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP415 DRS7A,B,C,D,E,F,DRS2 A,B,C | 90/10~95/ | Final Drive PINION |
| 03905 3527 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP50M,54M DR1# | 00/2~ | Transmission FRONT |
| 03905 1382 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP413,415,419,445,449 | 83/6~90/2 | Final Drive PINION |
| 03905 8258 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP418 FDQ,FM,DRS#,GRS#,JCX | 83/6~90/2 | Final Drive PINION |
| 03905 1373 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP415 | 90/2~90/10 | Final Drive PINION |
| 03905 2093 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP415 EXC. DRS7A,B,C,D,E,F,DRS2 A,B,C | 90/10~99/ | Final Drive PINION |
| 03905 7229 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP418 FD,RDS#,GRS# | 90/2~93/ | Final Drive PINION |
| 03905 3062 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP419 DRA,DRB,DRC,DRD,DRE,DRF | 90/2~90/10 | Final Drive PINION |
| 03905 7016 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP445,449 | 90/2~90/10 | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6254 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP515 FX,HX,JX,LX,NX,TX | 96/4~00/ | Final Drive PINION |
| 03905 4676 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP50K EXC. NX41 | 00/2~ | Final Drive PINION |
| 03905 5699 | MH034092 | 130 x 150 x 14 | FUSO TRUCK / TRACTOR FP FP TRUCK ALL | 74/~89/10 | Wheel Hub FRONT |
| 03905 4157 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP410,440 | 90/8~95/2 | Final Drive PINION |
| 03905 1967 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP218 ERS | 83/2~88/ | Final Drive PINION |
| 03905 3317 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP419 DRA,DRB,DRC,DRD,DRE,DRF | 90/10~96/ | Final Drive PINION |
| 03905 3179 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP445 | 90/10~95/4 | Final Drive PINION |
| 03905 6452 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP449 | 90/10~96/ | Final Drive PINION |
| 03905 6626 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP511,519,541,549 | 96/7~00/ | Final Drive PINION |
| 03905 4820 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP50M,54M DR1#,DR2#,GR2# | 00/2~ | Final Drive PINION |
| 03905 3803 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP412,424,442,444 | 95/2~97/ | Final Drive PINION |
| 03905 2486 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP410,440 | 95/2~97/ | Final Drive PINION |
| 03905 2804 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP445 | 95/5~97/ | Final Drive PINION |
| 03905 1811 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP510,512,514,540,542,453,544,545 | 96/7~00/ | Final Drive PINION |
| 03905 3467 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP515 DKR,DR2,NX41 | 96/7~00/ | Final Drive PINION |
| 03905 4880 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP215 DRS | 76/10~79/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2438 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP411,414,416,441,446 | 89/3~96/ | Final Drive PINION |
| 03905 5069 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP50J DR5# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 6428 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP519,549 | 96/7~00/ | Transmission FRONT |
| 03905 4139 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP419 EXC.DRD,DRDQ,DRE,DRF | 85/9~96/ | Transmission FRONT |
| 03905 8450 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP415 EXC. DR# | 90/10~99/ | Transmission FRONT |
| 03905 2741 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP414,415,445 | 83/6~90/10 | Transmission FRONT |
| 03905 3779 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP413,416,418,446,449 | 83/6~96/ | Transmission FRONT |
| 03905 8291 | MH034151 | 52 x 65 x 9 | FUSO TRUCK / TRACTOR FP FP1##,2##,3## | 79/10~83/ | Transmission FRONT |
| 03905 2702 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK / TRACTOR FP FP# | 74/~79/ | Transmission FRONT |
| 03905 3908 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP54M DR3#,GR3# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 7010 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP54L | 00/2~ | Wheel Hub REAR OUTER |
| 03905 1844 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP54J DR5# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 4163 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK / TRACTOR FP FP313,315 DRA | 79/12~83/ | Final Drive PINION |
| 03905 4301 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP50L | 00/2~ | Wheel Hub REAR OUTER |
| 03905 1604 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK / TRACTOR FP FP50K NX41 | 00/2~ | Final Drive PINION |
| 03905 6395 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP515 DK#,DR# | 96/4~00/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7898 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP512,514,542,543,544,545 | 96/7~00/ | Wheel Hub REAR OUTER |
| 03905 7778 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP445 DRS2A,DRS2B,DRS2C | 85/9~97/ | Wheel Hub REAR OUTER |
| 03905 3344 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP424,442,444,446 | 94/12~97/ | Wheel Hub REAR OUTER |
| 03905 2678 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP415 DRS2A,DRS2B#,DRS2C | 90/10~99/ | Wheel Hub REAR OUTER |
| 03905 8786 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP412,414 | 89/3~96/ | Wheel Hub REAR OUTER |
| 03905 2885 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP54M DR1#,DR2#,GR2# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 2726 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP54J DR3#,DR4#,GR4# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 1664 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP50M DR1#,DR2# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 3302 | MH034135 | 65 x 77 x 12 | FUSO TRUCK / TRACTOR FP FP50K NX41 | 00/2~ | Wheel Hub REAR OUTER |
| 03905 4316 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP410 DRS1A,DRS1B,DRS3B | 90/8~96/ | Wheel Hub FRONT |
| 03905 2000 | MH034133 | 70 x 82 x 12.5 | FUSO TRUCK / TRACTOR FP FP50M DR3#,GR3# | 00/2~ | Wheel Hub REAR OUTER |
| 03905 1490 | MH034136 | 130 x 150 x 12 | FUSO TRUCK / TRACTOR FP FP412 DRB,DRBQ,DRE | 95/2~96/ | Wheel Hub FRONT |
| 03905 1331 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK74H G2#,H2#,J2# | 02/2~ | Final Drive PINION |
| 03905 6488 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK64F HZ2#,JZ2#,KZ2#,LZ2#,MZ2E | 99/1~ | Final Drive PINION |
| 03905 6713 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK61H D2D,D3#,EX2#,EY3#,EZ3,GX2,GY3#,GZ3# | 99/1~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6653 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK61F GY2,GZ2,HY2#,HZ#,H2#,JY2 | 99/1~ | Final Drive PINION |
| 03905 3461 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK728 CD3,C3,C3J | 98/3~99/ | Final Drive PINION |
| 03905 8249 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK629 D3#,EY3#,EZ3#,GY3,GZ3#,HY3#,HZ3# | 96/11~99/ | Final Drive PINION |
| 03905 5237 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK628 DD3,D3,EZ3,GZ3,HZ3,JZ3,KZ3#,LZ3# | 96/11~99/ | Final Drive PINION |
| 03905 2915 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK622 GZ#,G5#,HZ#,H5# | 96/11~99/ | Final Drive PINION |
| 03905 3788 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK619 D3#,EZ3#,GZ3#,HZ3#,JZ3# | 94/12~99/ | Final Drive PINION |
| 03905 8039 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK618 D#,EZ#,GZ#,HZ#,JZ#,KZ# | 92/6~99/ | Final Drive PINION |
| 03905 1517 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK612 GZ5#,G#,HZ5#,H6# | 94/12~99/ | Final Drive PINION |
| 03905 8396 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FL417,638,639,63H | 87/12~ | Final Drive PINION |
| 03905 3866 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FH21H C2D34,C2M,D2,E2,G2# | 99/3~ | Final Drive PINION |
| 03905 3998 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK612 G6#,H6#,J6# | 94/12~99/ | Final Drive PINION |
| 03905 6977 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FH217,227,21G | 95/10~ | Final Drive PINION |
| 03905 7277 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK74H GZ3#,HZ3#,JZ3#,KZ3# | 02/2~ | Final Drive PINION |
| 03905 4640 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK71H C2M,D2,E2,G2,#,H2# | 99/1~ | Final Drive PINION |
| 03905 3095 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK64H H2#,H3#,J2#,J3#,K2#,K3#,L2#,L3 | 99/1~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2528 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK64F HZ1,H1#,JZ1#,J1#,KZ1#, K1#,LZ1#,L1# | 99/1~ | Final Drive PINION |
| 03905 4268 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK61H E2#,E3,G2#,G3#,H2#,E3 W#,G2W,G3W | 99/1~ | Final Drive PINION |
| 03905 1484 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK61F G1#,H1#,J1# | 99/1~ | Final Drive PINION |
| 03905 1280 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK728 C3M,D3,E3,G3#,H3# | 98/3~99/ | Final Drive PINION |
| 03905 3590 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK629 E3#,G3#,H3#,J3# | 96/11~99/ | Final Drive PINION |
| 03905 8855 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK628 EY3,E3#,GY3,G3#,HY3, H3# | 96/11~99/ | Final Drive PINION |
| 03905 4760 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK622 G6#,H6#,J6# | 96/11~99/ | Final Drive PINION |
| 03905 3017 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK619 E3#,G3#,H3# | 94/12~99/ | Final Drive PINION |
| 03905 6575 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK618 E#,G#,H#(EXC.EZ,GZ,H Z) | 92/6~99/ | Final Drive PINION |
| 03905 8279 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK617 E#,G#,H#,D3#,E3#,G3#,H 3# | 92/6~99/ | Final Drive PINION |
| 03905 5096 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FH218,228 EXC. C,CD,CDN,CJ,CN | 95/10~99/ | Final Drive PINION |
| 03905 7457 | ME017208 | 57 x 78 x 10 x 16.5 | FUSO TRUCK FK, FH, FL 4D34T FK603 | 95/11~99/ | Engine CRANK SHAFT FRONT |
| 03905 5168 | ME241213 | | FUSO TRUCK FK, FH, FL 6M60,6M61,4M50 | 99/1~ | Engine VALVE STEM SEAL |
| 03905 5993 | ME215092 | | FUSO TRUCK FK, FH, FL 4D34T | 95/11~99/ | Engine VALVE STEM SEAL |
| 03905 5000 | ME215092 | | FUSO TRUCK FK, FH, FL 6D10,14,15,16,17 | 76/4~99/ | Engine VALVE STEM SEAL |
| 03905 1037 | ME240010 | 101 x 123 x 13.5 | FUSO TRUCK FK, FH, FL 4M50 FK71D | 99/7~ | Engine CRANK SHAFT REAR |
| 03905 1205 | ME240010 | 101 x 123 x 13.5 | FUSO TRUCK FK, FH, FL 4D34T FK603 | 95/11~99/ | Engine CRANK SHAFT REAR |
| 03905 6629 | ME011867 | 100 x 124 x 15 | FUSO TRUCK FK, FH, FL 6D31 FK330 | 88/10~96/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8105 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FK, FH, FL 6M60,6M61 | 99/1~ | Engine CRANK SHAFT REAR |
| 03905 8060 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FK, FH, FL 6D14,15,16,17 MIXER(CM,DM) | 89/2~99/ | Engine CRANK SHAFT REAR |
| 03905 4385 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FK, FH, FL 6D14,15,16,17 EXCEPT MIXER (CM,DM) | 87/7~99/ | Engine CRANK SHAFT REAR |
| 03905 6806 | ME030856 | 107 x 140 x 180 x 17.5 | FUSO TRUCK FK, FH, FL 6D14,15 EXCEPT MIXER (CM,CD) | 84/2~87/6 | Engine CRANK SHAFT REAR |
| 03905 5915 | ME031584 | 105 x 125 x 11 | FUSO TRUCK FK, FH, FL 6D10,14,15,16 MIXER (CM,DM) | 76/4~89/1 | Engine CRANK SHAFT REAR |
| 03905 6743 | ME031548 | 100 x 125 x 12.5 | FUSO TRUCK FK, FH, FL 6D10,14,15 EXCEPT MIXER (CM,DM) | 76/4~84/1 | Engine CRANK SHAFT REAR |
| 03905 1532 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK64H HZ3#,JZ3#,KZ3#,LZ3#,MZ3E | 99/1~ | Final Drive PINION |
| 03905 2888 | ME240328 | 42 x 66 x 11.5 x 18.5 | FUSO TRUCK FK, FH, FL 4M50 FK71D | 99/7~ | Engine CRANK SHAFT FRONT |
| 03905 6242 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK71H EX. C2M,D2,E2,G2#,H2# | 99/1~ | Final Drive PINION |
| 03905 4190 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO TRUCK FK, FH, FL 6M60,6M61 | 99/1~ | Engine CRANK SHAFT FRONT |
| 03905 1778 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO TRUCK FK, FH, FL 6D16,17 | 95/1~99/ | Engine CRANK SHAFT FRONT |
| 03905 7481 | ME071269 | 76 x 94 x 12 | FUSO TRUCK FK, FH, FL 6D14,15,16,17 | 88/9~94/12 | Engine CRANK SHAFT FRONT |
| 03905 5555 | ME031543 | 72 x 94 x 12 | FUSO TRUCK FK, FH, FL 6D10,14,15,16 | 76/4~88/8 | Engine CRANK SHAFT FRONT |
| 03905 8027 | ME013384 | 55 x 78 x 8 | FUSO TRUCK FK, FH, FL 6D31 FK330 | 90/1~95/ | Engine CRANK SHAFT FRONT |
| 03905 1988 | ME024156 | 55 x 78 x 12 | FUSO TRUCK FK, FH, FL 6D31 FK330 | 88/10~90/1 | Engine CRANK SHAFT FRONT |
| 03905 8066 | ME024156 | 55 x 78 x 12 | FUSO TRUCK FK, FH, FL 6DS7 FK102 | 76/4~84/ | Engine CRANK SHAFT FRONT |
| 03905 1625 | MH034205 | 56 x 99 x 10 x 34 | FUSO TRUCK FK, FH, FL FK603 | 95/11~99/ | Final Drive PINION |
| 03905 7508 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FL618,628,61H | 92/10~ | Final Drive PINION |
| 03905 4238 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FH21H CD2,C2J | 99/3~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7682 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FH218,228 C,CD,CDN,CJ,CN | 95/10~99/ | Final Drive PINION |
| 03905 6518 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK616,662,666,672 | 92/6~99/ | Final Drive PINION |
| 03905 8015 | ME031548 | 100 x 125 x 12.5 | FUSO TRUCK FK, FH, FL 6DS7 FK102 | 76/4~84/ | Engine CRANK SHAFT REAR |
| 03905 4532 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FK, FH, FL FK7## | 98/3~ | Wheel Hub REAR INNER |
| 03905 1589 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK515 EXC.FSQA,HKSA,HSQA, HUSA,JKSA,JSQA)) | 83/12~96/ | Transmission FRONT |
| 03905 6047 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK417 EXC.EFW,FFW,FZFWA, HZFWA | 87/9~96/ | Transmission FRONT |
| 03905 2195 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK416 EXC.M6S6 T/M | 84/2~96/ | Transmission FRONT |
| 03905 5801 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK415 EXC.ESA,HKSA,HUSA,J KSA,JUSA,KKSA)) | 84/2~96/ | Transmission FRONT |
| 03905 2264 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK1##,2##,3## | 79/8~95/ | Transmission FRONT |
| 03905 6011 | ME620713 | 34 x 50 x 7 | FUSO TRUCK FK, FH, FL FK1## | 76/4~79/8 | Transmission FRONT |
| 03905 1253 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FK, FH, FL FL6## | 92/10~ | Wheel Hub REAR OUTER |
| 03905 2540 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FK, FH, FL FH2## | 95/10~ | Wheel Hub REAR OUTER |
| 03905 2909 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FK, FH, FL FK6##,7## | 94/12~ | Wheel Hub REAR OUTER |
| 03905 3965 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO TRUCK FK, FH, FL FL417 | 87/12~95/ | Wheel Hub REAR OUTER |
| 03905 7511 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO TRUCK FK, FH, FL FK3##,4##,5## | 85/6~96/ | Wheel Hub REAR OUTER |
| 03905 8678 | MH034006 | 65 x 120.5 x 10 | FUSO TRUCK FK, FH, FL FK1##,2##,3##,4##,5## | 76/4~85/5 | Wheel Hub REAR OUTER |
| 03905 3701 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FK, FH, FL FL628 | 98/6~99/ | Wheel Hub REAR INNER |
| 03905 4166 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK516 EXC.M6S6 T/M | 83/12~96/ | Transmission FRONT |
| 03905 1529 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FK, FH, FL FK1##,2##,3##,4##,5## | 76/4~94/1 1 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8003 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FK, FH, FL FK1##,2##,3##,4##,5## | 76/4~96/ | Wheel Hub FRONT |
| 03905 5141 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FK, FH, FL FK6##...EXC. FK61F,H#Z#,64F,H#Z# | 92/6~ | Wheel Hub FRONT |
| 03905 3044 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FK, FH, FL FK7##...EXC. FK71H#Z#,74H#Z# | 98/3~ | Wheel Hub FRONT |
| 03905 3026 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FK, FH, FL FH2## | 95/10~ | Wheel Hub FRONT |
| 03905 4205 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FK, FH, FL FK61F,H#Z#,64F,H#Z#,71H#Z#,74H#Z# | 99/1~ | Wheel Hub FRONT |
| 03905 8597 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FK, FH, FL FL638,639,61H,63H | 96/11~ | Wheel Hub REAR INNER |
| 03905 1148 | MC891701 | 106 x 122 x 10 | FUSO TRUCK FK, FH, FL FL638,639,63H | 96/11~ | Wheel Hub FRONT |
| 03905 7586 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FK, FH, FL FH2## | 95/10~ | Wheel Hub REAR INNER |
| 03905 4694 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FK, FH, FL FK622,628,629 #Z# | 96/11~98/5 | Wheel Hub REAR INNER |
| 03905 1400 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FK, FH, FL FL417,618 | 87/12~97/ | Wheel Hub REAR INNER |
| 03905 3458 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FK, FH, FL FK617 D,DD,DG | 92/6~99/ | Final Drive PINION |
| 03905 6311 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FK, FH, FL FK3##,4##,5## | 94/12~96/ | Wheel Hub REAR INNER |
| 03905 4085 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK61G,71D,G | 99/1~ | Final Drive PINION |
| 03905 6269 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FK, FH, FL FK6##...EXC.FK622,628,629#Z#(96.11~98.5) | 92/6~ | Wheel Hub REAR INNER |
| 03905 4400 | MH034089 | 134 x 152 x 11 | FUSO TRUCK FK, FH, FL FL417,618,628,61H | 87/12~ | Wheel Hub FRONT |
| 03905 8606 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FK, FH, FL FK612,616,622,61F,64F M050S6,M060S6 T/M | 92/6~ | Transmission REAR |
| 03905 3635 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FK, FH, FL FL628 | 96/11~98/5 | Wheel Hub REAR INNER |
| 03905 9044 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK425,427,435,445,467,517,545,567 | 84/2~96/ | Transmission FRONT |
| 03905 5747 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK615,627,667,668,678,727 | 92/6~99/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6842 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FK, FH, FL FK1##,2##,3##,4##,5## | 77/9~96/ | Final Drive PINION |
| 03905 3176 | MH034048 | 60 x 103 x 13.5 x 20 | FUSO TRUCK FK, FH, FL FK1### | 76/4~77/8 | Final Drive PINION |
| 03905 1454 | MH034181 | 50 x 65 x 9 | FUSO TRUCK FK, FH, FL FK603,71D | 95/11~ | Transmission REAR |
| 03905 1550 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FK, FH, FL FH2## | 95/10~ | Transmission REAR |
| 03905 4046 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FK, FH, FL FK61G,H,64H,71G,H,74H | 99/1~ | Transmission REAR |
| 03905 2279 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FK, FH, FL FK615,617,618,619,627,628,629,667,668,678,727,728 | 92/6~99/ | Transmission REAR |
| 03905 4253 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FK, FH, FL FK1##,2##,3##,4##,5## | 79/8~96/ | Transmission REAR |
| 03905 7877 | MH034036 | 55 x 72 x 9 | FUSO TRUCK FK, FH, FL FK1### | 76/4~79/8 | Transmission REAR |
| 03905 2240 | MH034122 | 43 x 58 x 8 | FUSO TRUCK FK, FH, FL FL417 EFWA,EZFWA,FFWA,FZFWA | 90/3~93/ | Transmission FRONT |
| 03905 6941 | MH034122 | 43 x 58 x 8 | FUSO TRUCK FK, FH, FL FK417 EFW,FFW,FZFWA,HZFWA | 87/9~93/ | Transmission FRONT |
| 03905 2624 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FL6## | 92/10~ | Transmission FRONT |
| 03905 4787 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK415 FSA,FSQA,HAS,HSQA,JSA,JSQA)) | 87/10~93/ | Transmission FRONT |
| 03905 2669 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK603,615,627,727,710 | 92/6~ | Transmission FRONT |
| 03905 2078 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FK617#3# | 94/12~96/12 | Transmission FRONT |
| 03905 6926 | MH034173 | 64 x 78 x 9 | FUSO TRUCK FK, FH, FL FK612,616,622,662,666,672,61F,64F M070S6 T/M | 92/6~ | Transmission REAR |
| 03905 5810 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FH218,228,21G,21H | 95/10~ | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1541 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FL417 EXC.EFWA,EZFWA,FZFWA | 87/12~95/ | Transmission FRONT |
| 03905 1295 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK415 ESA,HKSA,HUSA,JKSA, JUSA,KKSA)) | 85/6~93/ | Transmission FRONT |
| 03905 1322 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FK, FH, FL FH217,227 | 95/10~99/ | Transmission FRONT |
| 03905 8936 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK416 M6S6 T/M | 85/6~93/ | Transmission FRONT |
| 03905 8519 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK515 FSQA,HKSA,HSQA,HUSA,JKSA,JSQA)) | 85/6~93/ | Transmission FRONT |
| 03905 4484 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK516 M6S6 T/M | 85/6~93/ | Transmission FRONT |
| 03905 5387 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK418,518,612,616,618,619,622,628,629,66#,67#,728 | 91/5~99/ | Transmission FRONT |
| 03905 3602 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK617 EXC.#3# | 92/6~95/4 | Transmission FRONT |
| 03905 8225 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FK, FH, FL FK61F,G,H,64F,H,71G,H, 74H | 99/1~ | Transmission FRONT |
| 03905 5177 | ME031543 | 72 x 94 x 12 | FUSO TRUCK FM 6D11,14,15 FM1##,2##,3##,515 | 74/~88/8 | Engine CRANK SHAFT FRONT |
| 03905 3623 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FM FM652 | 94/12~96/ | Final Drive PINION |
| 03905 8960 | ME031584 | 105 x 125 x 11 | FUSO TRUCK FM 6D14,16 FM515,51(MIXER) | 84/2~89/1 | Engine CRANK SHAFT REAR |
| 03905 1976 | ME071269 | 76 x 94 x 12 | FUSO TRUCK FM 6D15,17 FM616,618,656 | 92/7~95/ | Engine CRANK SHAFT FRONT |
| 03905 3419 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FM FM6##...EXC. FM652 | 86/9~ | Final Drive PINION |
| 03905 5828 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO TRUCK FM 6D16,17 FM612,619,628,629,652,658 | 94/12~99/ | Engine CRANK SHAFT FRONT |
| 03905 1928 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO TRUCK FM 6M60,61 FM62F,H | 99/4~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6818 | ME031584 | 105 x 125 x 11 | FUSO TRUCK FM 5D11,14 FM104,205 | 84/~77/10 | Engine CRANK SHAFT REAR |
| 03905 4835 | ME071269 | 76 x 94 x 12 | FUSO TRUCK FM 6D15,16 FM516,517 | 88/9~93/ | Engine CRANK SHAFT FRONT |
| 03905 4208 | ME031548 | 100 x 125 x 12.5 | FUSO TRUCK FM 6D14,15 FM215,315,316 | 77/11~84/ | Engine CRANK SHAFT REAR |
| 03905 3962 | ME030856 | 107 x 140 x 180 x 17.5 | FUSO TRUCK FM 6D14,16 FM515,517(EXCEPT MIXER) | 84/2~87/6 | Engine CRANK SHAFT REAR |
| 03905 6914 | ME030856 | 107 x 140 x 180 x 17.5 | FUSO TRUCK FM 6D15 FM516 | 86/9~87/6 | Engine CRANK SHAFT REAR |
| 03905 5636 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FM 6D16 FM517(MIXER) | 89/2~93/ | Engine CRANK SHAFT REAR |
| 03905 5252 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FM 6D15,16,17 FM6## | 92/7~99/ | Engine CRANK SHAFT REAR |
| 03905 3224 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FM FM215,315,316,515,516,517 | 76/10~93/ | Final Drive PINION |
| 03905 2579 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FM FM62F,62H | 99/4~ | Wheel Hub FRONT |
| 03905 6602 | ME215092 | | FUSO TRUCK FM 6D11,14,15,16,17 | 74/~99/ | Engine VALVE STEM SEAL |
| 03905 4913 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FM 6M60,61 FM62F,H | 99/4~ | Engine CRANK SHAFT REAR |
| 03905 3086 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FM 6D14,15 FM515,516,517(EXCEPT MIXER) | 87/7~93/ | Engine CRANK SHAFT REAR |
| 03905 1193 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FM FM516 F,H,J,L,M,S | 86/9~90/ | Transmission FRONT |
| 03905 8615 | ME241213 | | FUSO TRUCK FM 6D15,16 | 99/4~ | Engine VALVE STEM SEAL |
| 03905 8378 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FM FM628,652,656,658 | 94/12~99/ | Wheel Hub FRONT |
| 03905 7040 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FM FM1##,2##,3##,5## | 74/~93/ | Wheel Hub FRONT |
| 03905 5432 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FM FM612,616,618,619,629 | 92/7~99/ | Wheel Hub FRONT |
| 03905 1556 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FM FM622 HZ5#,JZ5#,LZ5#,MZ5#,SZ5# | 96/11~99/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8915 | MH034082 | 155 x 180 x 17 | FUSO TRUCK FM FM1##,2##,3## | 74/~84/ | Wheel Hub REAR INNER |
| 03905 1523 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FM FM1##,2##,3##,5##,6## | 74/~ | Wheel Hub REAR OUTER |
| 03905 5663 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FM FM5##,6## | 84/2~ | Wheel Hub REAR INNER |
| 03905 1820 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FM FM315,316,515 | 80/3~88/ | Transmission FRONT |
| 03905 9035 | 03434-07051 | 70 x 92 x 13.5 x 20.5 | FUSO TRUCK FM FM104,215 | 74/~76/9 | Final Drive PINION |
| 03905 5264 | MH034147 | 40 x 58 x 8 | FUSO TRUCK FM FM517 EXC. HF,JF | 87/12~93/ | Transmission FRONT |
| 03905 8252 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FM FM516 FS2#,HS2#,JS2#,LS2#,MS 2#,SS2# | 86/9~93/ | Transmission FRONT |
| 03905 3290 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FM FM6## | 92/7~ | Transmission FRONT |
| 03905 8330 | MH034122 | 43 x 58 x 8 | FUSO TRUCK FM FM517 HF,JF | 90/3~93/ | Transmission FRONT |
| 03905 1112 | MH034036 | 55 x 72 x 9 | FUSO TRUCK FM FM104,215 | 74/~80/ | Transmission REAR |
| 03905 6257 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FM FM315,316,515,516,517 | 80/3~ | Transmission REAR |
| 03905 1286 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FM FM612,616,618,619,622,6 29,652,656,62H | 92/7~ | Transmission REAR |
| 03905 6644 | MH034173 | 64 x 78 x 9 | FUSO TRUCK FM FM62F | 99/4~ | Transmission REAR |
| 03905 8669 | ME620713 | 34 x 50 x 7 | FUSO TRUCK FM FM104,215 | 74/~80/ | Transmission FRONT |
| 03905 8645 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FM FM622 F5,H5,J5,L5,M5,S5 | 96/11~99/ | Wheel Hub FRONT |
| 03905 2072 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FN, FQ 6D22 FN428 | 83/6~85/8 | Engine CRANK SHAFT FRONT |
| 03905 2765 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FN, FQ FN428,622 | 83/6~99/ | Transmission REAR |
| 03905 2531 | MC095475 | 154 x 185 x 19 | FUSO TRUCK FN, FQ FN622,FQ61F | 96/11~ | Rear Suspesion TRUNNION |
| 03905 7388 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK FN, FQ FN427,428 | 83/6~96/ | Rear Suspesion TRUNNION |
| 03905 8828 | ME241213 | | FUSO TRUCK FN, FQ 6D16,6M60 | 96/11~ | Engine VALVE STEM SEAL |
| 03905 3596 | ME061574 | | FUSO TRUCK FN, FQ 6D22,6D24 | 83/6~96/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8345 | ME034976 | 108 x 140 x 180 x 17 | FUSO TRUCK FN, FQ 6D16,6M60 | 96/11~ | Engine CRANK SHAFT REAR |
| 03905 7037 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FN, FQ 6D22,6D24 | 83/6~96/ | Engine CRANK SHAFT REAR |
| 03905 1238 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO TRUCK FN, FQ 6M60 FN61F,FQ61F | 99/4~ | Engine CRANK SHAFT FRONT |
| 03905 7844 | ME074755 | 75 x 100 x 14.5 x 19.5 | FUSO TRUCK FN, FQ 6D16 FN612,622 | 96/11~99/ | Engine CRANK SHAFT FRONT |
| 03905 1691 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FN, FQ 6D22 FN428 | 85/9~95/ | Engine CRANK SHAFT FRONT |
| 03905 4808 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FN, FQ FN427,428,612,622,61F,FQ61F | 91/8~ | Final Drive PINION |
| 03905 5417 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FN, FQ FN428 | 83/6~91/8 | Final Drive PINION |
| 03905 2387 | MH034173 | 64 x 78 x 9 | FUSO TRUCK FN, FQ FN61F,FQ61F | 99/4~ | Transmission REAR |
| 03905 3914 | MH034006 | 65 x 120.5 x 10 | FUSO TRUCK FN, FQ FN418 | 83/6~84/8 | Wheel Hub REAR OUTER (F & R) |
| 03905 3842 | MH034146 | 50 x 68 x 9 | FUSO TRUCK FN, FQ FN612,622,61F,FQ61F | 96/11~ | Transmission FRONT |
| 03905 7535 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FN, FQ FN427,428 | 83/6~96/ | Transmission FRONT |
| 03905 8102 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FN, FQ FN612,61F | 96/11~ | Wheel Hub REAR OUTER (F) |
| 03905 7886 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FN, FQ 6D24 FN427 | 95/4~96/ | Engine CRANK SHAFT FRONT |
| 03905 5396 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO TRUCK FN, FQ FN428 | 84/9~93/5 | Wheel Hub REAR OUTER (F & R) |
| 03905 4679 | MH034148 | 58 x 75 x 9 | FUSO TRUCK FN, FQ FN612 | 96/11~99/ | Transmission REAR |
| 03905 4028 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FN, FQ FN427,428,612,622,61F,FQ61F | 93/5~ | Wheel Hub REAR INNER (F & R) |
| 03905 5354 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FN, FQ FN428 | 83/6~93/5 | Wheel Hub REAR INNER (F & R) |
| 03905 6299 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FN, FQ FN622,FQ61F | 96/11~ | Wheel Hub FRONT |
| 03905 3896 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FN, FQ FN612,61F | 96/11~ | Wheel Hub FRONT |
| 03905 2135 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FN, FQ FN427,428 | 89/11~96/ | Wheel Hub FRONT |
| 03905 5006 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FN, FQ FN428 | 83/6~89/10 | Wheel Hub FRONT |
| 03905 6410 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FN, FQ FN427 | 95/4~96/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4742 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FN, FQ FN427,428,622,FQ61F | 93/5~ | Wheel Hub REAR OUTER (F & R) |
| 03905 4298 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FR 8DC9 FR415 | 86/11~99/ | Engine TIMING GEAR CASE |
| 03905 5750 | MH034072 | 70 x 92 x 14 | FUSO TRUCK FR FR# | 86/11~ | Transmission REAR |
| 03905 7379 | ME120154 | | FUSO TRUCK FR 8M21 | 00/3~ | Engine VALVE STEM SEAL |
| 03905 4751 | ME061574 | | FUSO TRUCK FR 8DC9,8DC11 | 86/11~00/ | Engine VALVE STEM SEAL |
| 03905 4712 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FR 8M21 | 00/3~ | Engine CRANK SHAFT REAR |
| 03905 2684 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FR 8DC9,8DC11 | 97/8~00/ | Engine CRANK SHAFT REAR |
| 03905 2324 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FR 8DC9,8DC11 | 86/11~97/ 8 | Engine CRANK SHAFT REAR |
| 03905 4457 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FR 8M21 FR50M | 00/3~ | Engine TIMING GEAR CASE |
| 03905 1703 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FR 8DC11 FR529 | 97/3~00/ | Engine TIMING GEAR CASE |
| 03905 1646 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FR FR50M | 00/3~ | Transmission FRONT |
| 03905 7433 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FR FR415,529 | 86/11~00/ | Transmission FRONT |
| 03905 8123 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FR FR# | 86/11~ | Wheel Hub REAR OUTER |
| 03905 1535 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FR FR# | 86/11~ | Wheel Hub REAR INNER |
| 03905 6530 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FR FR50M EXC. JXJ168 | 00/3~ | Wheel Hub FRONT |
| 03905 3251 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FR FR529 | 97/3~00/ | Wheel Hub FRONT |
| 03905 8054 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FR FR50M JXJ168 | 00/3~ | Wheel Hub FRONT |
| 03905 5759 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FR FR415 | 86/11~99/ | Wheel Hub FRONT |
| 03905 7796 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS519 VX#,VY#,VZ# | 96/4~00/ | Transmission REAR |
| 03905 3212 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FS FS50KVZA66 | 00/2~ | Final Drive PINION |
| 03905 5258 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FS FS50M,54K | 00/2~ | Final Drive PINION |
| 03905 2267 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FS FS5#...EXC. FS525 | 96/4~00/ | Final Drive PINION |
| 03905 7964 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FS FS4#...EXC. FS425 | 91/9~96/ | Final Drive PINION |
| 03905 1229 | MC827472 | 60 x 103 x 10 x 33.5 | FUSO TRUCK FS FS4#...EXC. FS425 | 83/6~91/8 | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1574 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FS FS50J,54J,55J | 00/2~ | Final Drive PINION |
| 03905 7544 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS50J,54J,55J | 00/2~ | Transmission REAR |
| 03905 1808 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 6D22 FS418,478 | 85/8~96/ | Engine TIMING GEAR CASE |
| 03905 3704 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS511 VZ,VZQ5A | 96/4~00/ | Transmission REAR |
| 03905 1208 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS510,517,540,570 | 96/4~00/ | Transmission REAR |
| 03905 3755 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS419 T,TZ,U | 94/11~96/ | Transmission REAR |
| 03905 7283 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS50M VX1,VY1,VZ1,VZ2# | 00/2~ | Transmission REAR |
| 03905 3470 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 8M21 FS512,50M | 96/4~ | Engine TIMING GEAR CASE |
| 03905 6668 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS418 US2 | 91/9~95/ | Transmission REAR |
| 03905 2657 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FS 8M20,8M21 | 93/5~97/8 | Engine CRANK SHAFT REAR |
| 03905 1616 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FS 6D24,6D40 | 95/4~97/8 | Engine CRANK SHAFT REAR |
| 03905 3524 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FS 6D22 | 83/6~96/ | Engine CRANK SHAFT REAR |
| 03905 4382 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FS 8DC10 | 89/11~96/ | Engine CRANK SHAFT REAR |
| 03905 3452 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 8DC10 FS416 | 89/11~96/ | Engine TIMING GEAR CASE |
| 03905 3209 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 6M70 FS50J,54J,55J | 00/2~ | Engine TIMING GEAR CASE |
| 03905 5159 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FS 8DC9,6D22 FS415,418 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 1178 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 8M20 FS411,511 | 93/5~00/ | Engine TIMING GEAR CASE |
| 03905 4811 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 6D40 FS410,510,540,570 | 93/5~00/ | Engine TIMING GEAR CASE |
| 03905 5690 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 6D24 FS417,477,517 | 95/4~00/ | Engine TIMING GEAR CASE |
| 03905 3488 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS418 US2 | 91/9~95/ | Transmission FRONT |
| 03905 4541 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 8DC11 FS419,519,50K,54K | 94/11~ | Engine TIMING GEAR CASE |
| 03905 4433 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FS 8DC9 FS415,425,515,525 | 85/8~0// | Engine TIMING GEAR CASE |
| 03905 8063 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FS 8DC9 | 83/6~95/4 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8288 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS416 U,UQ,T | 91/9~95/ | Transmission FRONT |
| 03905 2789 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS510,511,512,517,540,570 | 96/4~00/ | Transmission FRONT |
| 03905 3296 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS50M EXC. RYK1,RY1,TZK1,TZ1 | 00/2~ | Transmission FRONT |
| 03905 4613 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS50J,54J,55J | 00/2~ | Transmission FRONT |
| 03905 2039 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS519 VX#,VY#,VZ# | 96/4~00/ | Transmission FRONT |
| 03905 5573 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FS 8DC9 | 95/4~00/ | Engine CRANK SHAFT REAR |
| 03905 7448 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FS FS418 EXC. US2(89.11-) | 83/6~93/ | Transmission REAR |
| 03905 8765 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FS FS425,525 | 89/11~00/ | Final Drive PINION |
| 03905 7322 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FS FS515,525 | 96/4~00/ | Transmission REAR |
| 03905 1940 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS410,411,417,477,478 | 91/9~96/ | Transmission FRONT |
| 03905 7205 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS50M RYK1,RY1,TZK1,TZ1 | 00/2~ | Transmission FRONT |
| 03905 8510 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS50K,54K | 00/2~ | Transmission FRONT |
| 03905 1859 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS519 RY(K),TZ(K) | 96/4~00/ | Transmission FRONT |
| 03905 8927 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS515,525 | 96/4~00/ | Transmission FRONT |
| 03905 3035 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS419 N,R,RZ | 94/11~96/ | Transmission FRONT |
| 03905 7658 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FS FS419 T,TZ,U | 94/11~96/ | Transmission FRONT |
| 03905 4979 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS511 EXC. VZ,VZQ5A | 96/4~00/ | Transmission REAR |
| 03905 1505 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS411 TC(Q),UC(Q),TZC(Q) | 93/5~96/ | Transmission REAR |
| 03905 4994 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS410,417,477,478 | 91/9~96/ | Transmission REAR |
| 03905 7376 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS54K | 00/2~ | Transmission REAR |
| 03905 6005 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS50M EXC. VX1,VY1,VZ1,VZ2# | 00/2~ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1124 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS50K UZS,VX | 00/2~03/3 | Transmission REAR |
| 03905 8033 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FS FS415,425 | 83/6~99/ | Transmission REAR |
| 03905 4538 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS512 | 96/4~00/ | Transmission REAR |
| 03905 2108 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FS FS416 U,UQ,T | 91/9~95/ | Transmission REAR |
| 03905 8735 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS419 N,R,RZ | 94/11~96/ | Transmission REAR |
| 03905 6386 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS418 U32 | 89/11~91/ 8 | Transmission REAR |
| 03905 4148 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS416 U,UQ | 89/11~91/ 8 | Transmission REAR |
| 03905 2366 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS416 N,NQ,R,RQ | 89/11~95/ | Transmission REAR |
| 03905 8477 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS411 NC(Q),RC(Q),RZC(Q) | 93/5~96/ | Transmission REAR |
| 03905 2315 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FS FS50K VZA66 | 00/2~ | Transmission REAR |
| 03905 5798 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FS FS519 RY(K),TZ(K) | 96/4~00/ | Transmission REAR |
| 03905 6506 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS410 TZS1,TZS1Q | 94/11~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 3077 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS511,512,540,570 | 96/4~98/4 | Wheel Hub REAR INNER (F & R) |
| 03905 5315 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FS FS50KVZA66 | 00/2~ | Wheel Hub FRONT (REARWARD) |
| 03905 4442 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS410 TZS1,TZS1Q | 94/11~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 8336 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS411 RZ#,TZ# | 94/11~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 3227 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS419 RZ,TZ | 94/11~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 3326 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS425 | 89/11~89/ 12 | Wheel Hub FRONT (REARWARD) |
| 03905 8159 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS3# | 79/8~83/ | Wheel Hub REAR INNER (F & R) |
| 03905 7859 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS419 N,R,T,U | 95/4~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 7370 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS411 RZ#,TZ# | 94/11~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 8417 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS419 RZ,TZ | 94/11~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 7139 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS415,416,418,478 | 83/6~93/5 | Wheel Hub REAR INNER (F & R) |
| 03905 2546 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS510 VY#,VZ# | 96/4~98/4 | Wheel Hub REAR INNER (F & R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8351 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS517 VY#,VZ# | 96/4~98/4 | Wheel Hub REAR INNER (F & R) |
| 03905 5792 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS519 RY#,TZ#,VY#,VZ# | 96/4~98/4 | Wheel Hub REAR INNER (F & R) |
| 03905 4877 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS5#...EXC. FS525,FS50KVZA66 | 96/4~ | Wheel Hub FRONT (REARWARD) |
| 03905 6371 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FS FS425 | 89/12~99/ | Wheel Hub FRONT (FORWARD) |
| 03905 1946 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FS FS50K UZS,VX | 00/2~ | Final Drive PINION |
| 03905 1163 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FS 8DC11 | 94/11~ | Engine CRANK SHAFT REAR |
| 03905 3188 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS3# | 79/8~83/ | Wheel Hub FRONT (FORWARD) |
| 03905 8429 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS4#...EXC. FS425 | 83/6~96/ | Wheel Hub FRONT (FORWARD) |
| 03905 6026 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS418 EXC. U62(91.9-) | 83/6~93/ | Transmission FRONT |
| 03905 3902 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FS FS425,525 | 89/12~00/ | Wheel Hub FRONT (REARWARD) |
| 03905 7232 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FS FS425 | 89/11~89/ 12 | Wheel Hub FRONT (FORWARD) |
| 03905 6905 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS411 ALL | 93/5~94/1 1 | Wheel Hub FRONT (REARWARD) |
| 03905 6317 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FS FS525 | 98/4~00/ | Wheel Hub FRONT (FORWARD) |
| 03905 1841 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FS FS50KVZA66 | 00/2~ | Wheel Hub FRONT (FORWARD) |
| 03905 7745 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS3# | 79/8~83/ | Wheel Hub FRONT (REARWARD) |
| 03905 1985 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS410 TS1,US1 | 94/11~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 3170 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS411 NC#,RC#MTC#,UC# | 94/11~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 3281 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS415,416,417,418,477,47 8 | 83/6~96/ | Wheel Hub FRONT (REARWARD) |
| 03905 8642 | MH034086 | 125 x 150 x 14 | FUSO TRUCK FS FS5#...EXC. FS525,FS50KVZA66 | 96/4~ | Wheel Hub FRONT (FORWARD) |
| 03905 6749 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FS FS50KVZA66 | 00/2~ | Wheel Hub REAR OUTER(F & R) |
| 03905 6680 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FS 6D24,6D40 | 97/8~00/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4895 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FS 8M20,8M21 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 8780 | MH034091 | 102 x 116 x 14 | FUSO TRUCK FS FS410 ALL | 93/5~94/11 | Wheel Hub FRONT (REARWARD) |
| 03905 2681 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS410 ALL | 93/5~94/11 | Wheel Hub REAR INNER (F & R) |
| 03905 2648 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FS 6M70 | 00/2~ | Engine CRANK SHAFT REAR |
| 03905 3968 | ME061574 | | FUSO TRUCK FS 8DC#,6DC2# | 83/6~ | Engine VALVE STEM SEAL |
| 03905 2030 | ME120154 | | FUSO TRUCK FS 8M2#,6D40,6M70 | 93/5~ | Engine VALVE STEM SEAL |
| 03905 3695 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS416 U,UQ | 89/11~91/8 | Transmission FRONT |
| 03905 4448 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS415,425 | 83/6~99/ | Transmission FRONT |
| 03905 3827 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FS FS425,525 | 89/11~00/ | Wheel Hub REAR OUTER(F & R) |
| 03905 7703 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FS FS5#...EXC. FS525,FS50KVZA66 | 96/4~ | Wheel Hub REAR OUTER(F & R) |
| 03905 8963 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FS FS4#...EXC. FS425 | 93/5~96/ | Wheel Hub REAR OUTER(F & R) |
| 03905 6137 | MH034110 | 45 x 53 x 6.5 x 8 | FUSO TRUCK FS FS415,416,418,478 | 85/9~93/5 | Wheel Hub REAR OUTER(F & R) |
| 03905 2183 | MH034006 | 65 x 120.5 x 10 | FUSO TRUCK FS FS415,418 | 83/6~85/8 | Wheel Hub REAR OUTER(F & R) |
| 03905 6731 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS510,517 EXC.VY#,VZ#(96.4~98.4) | 96/4~00/ | Wheel Hub REAR INNER (F & R) |
| 03905 2393 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS411 NC#,RC#,TC#,UC# | 94/11~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 1343 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS411 ALL | 93/5~94/11 | Wheel Hub REAR INNER (F & R) |
| 03905 2330 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS419 N,R,T,U | 95/4~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 6560 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FS FS416 N,NQ,R,RQ | 89/11~95/ | Transmission FRONT |
| 03905 4832 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS410 TS1,US1 | 94/11~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 5057 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS415,416,417,418,477,478 | 93/5~96/ | Wheel Hub REAR INNER (F & R) |
| 03905 2840 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS511,512,540,570 | 98/4~00/ | Wheel Hub REAR INNER (F & R) |
| 03905 2459 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS515 | 96/4~00/ | Wheel Hub REAR INNER (F & R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5036 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS519 EXC.RY#,TZ#,VY#,VZ#( 96.4~98.4) | 96/4~00/ | Wheel Hub REAR INNER (F & R) |
| 03905 2897 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS50J,50M,54J,54K,55J | 00/2~ | Wheel Hub REAR INNER (F & R) |
| 03905 3869 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FS FS50K UZS,VX | 00/2~ | Wheel Hub REAR INNER (F & R) |
| 03905 7166 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FS FS425,525 | 89/11~00/ | Wheel Hub REAR INNER (F & R) |
| 03905 3407 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FS FS50KVZA66 | 00/2~ | Wheel Hub REAR INNER (F & R) |
| 03905 6155 | MH034006 | 65 x 120.5 x 10 | FUSO TRUCK FS FS3# | 79/8~83/ | Wheel Hub REAR OUTER(F & R) |
| 03905 5642 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT517 VX2#,WY2# | 96/4~00/ | Transmission FRONT |
| 03905 6140 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT517 LXT#,NXT#,NYT#,RXT# ,RYT#,WY1#,TY# | 96/4~00/ | Transmission FRONT |
| 03905 3038 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT417 VZS2,WZS2,TS2,VS2 | 94/11~96/ | Transmission FRONT |
| 03905 3713 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT510,520,527 | 96/4~00/ | Transmission FRONT |
| 03905 1802 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT50J LXT2,NYT2#,RYT2,VX1 #,2#,3,WY2#,WZ2 | 00/1~ | Transmission FRONT |
| 03905 8834 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT418 TS2,VS2 | 89/11~95/ | Transmission FRONT |
| 03905 7784 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT54J EXC. NYT1 | 03/3~ | Transmission FRONT |
| 03905 7835 | ME655359 | 97 x 110 x 4.5 | FUSO TRUCK FT FT4##,5## | 83/6~ | Transmission MAIN SHAFT |
| 03905 1925 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT515 TYP2,WYP2 | 96/7~00/ | Transmission FRONT |
| 03905 7031 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT415 NPS7,TPS2,TPS7,VPS2,V PS7 | 90/9~96/ | Transmission FRONT |
| 03905 5234 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FT FT410,416 | 89/11~96/ | Transmission FRONT |
| 03905 5204 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT54J NYT1 | 03/3~ | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6065 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT50J LXT1#,NXT1,NYT#,RXG 1,RXT1,RYT1 | 00/1~ | Transmission FRONT |
| 03905 3983 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT413 | 83/6~93/ | Transmission FRONT |
| 03905 2252 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT515 LXT#,NYT#,RYT# | 96/4~00/ | Transmission FRONT |
| 03905 2603 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT1# | 74/~79/ | Transmission REAR |
| 03905 4526 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT415 NPS#,TPS#,VPS# | 83/6~96/ | Transmission REAR |
| 03905 2609 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT418 EXCEPT TS2,VS2(89.11-) | 83/6~95/ | Transmission FRONT |
| 03905 5804 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT417 EXC. VZS2,WZS2,TS2,VS2 | 94/11~96/ | Transmission FRONT |
| 03905 6851 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT415 EXC. NPS7,TPS2,7,VPS2,7(90.9 -) | 83/6~96/ | Transmission FRONT |
| 03905 1487 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT50K | 00/1~ | Transmission FRONT |
| 03905 2783 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT50J LXT1#,NXT1#,NYT#,RX G1,RXT1,RYT1 | 00/1~ | Transmission REAR |
| 03905 7238 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT517 LXT2#,NYT2#,RYT2#,T Y1#,2#,WY1#,WX1# | 96/4~00/ | Transmission REAR |
| 03905 8243 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT50J LXT2,NYF2,NYT2#,RYT 2 | 00/1~ | Transmission REAR |
| 03905 2189 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FT FT50J NYT1#,2,RYT1,2,TY#,W Y#,WZ#(22T,25T) | 00/1~ | Wheel Hub FRONT (F & R) |
| 03905 4550 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FT FT313,315,318 | 89/10~83/ | Transmission FRONT |
| 03905 2495 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT418 TS2,VS2 | 88/9~89/1 0 | Transmission REAR |
| 03905 1097 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT417 LTS2,NS1,2,TS1,VS1 | 95/4~96/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4631 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT417 VZS1,WZS1,NZTS2,RZS 1,2 | 94/11~96/ | Transmission REAR |
| 03905 4109 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT415 V | 88/9~89/1 0 | Transmission REAR |
| 03905 7808 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT50J NYT1 | 03/3~ | Transmission REAR |
| 03905 7403 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT50K LXT,NYTS,RYTS,NYF | 00/1~ | Transmission REAR |
| 03905 3692 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT313,318 | 79/10~83/ | Transmission REAR |
| 03905 2249 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT517 LXT1#,NXT1#,NYT1#,R XT1#,RYT1# | 96/4~00/ | Transmission REAR |
| 03905 2138 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT515 EXC. TYP2,WYP2 | 96/4~00/ | Transmission REAR |
| 03905 7895 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT418 EXC. #S4#,#S3#,VS7 | 83/6~95/ | Transmission REAR |
| 03905 5471 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT418 TS2,VS2 | 83/6~88/8 | Transmission REAR |
| 03905 1157 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT417 NZTS1,KTS1,LTS1,RGS1 ,RTS1 | 94/11~96/ | Transmission REAR |
| 03905 2336 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT415 T,L,LT,N,RT | 83/6~96/ | Transmission REAR |
| 03905 9017 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT415 V | 83/6~88/8 | Transmission REAR |
| 03905 7472 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT413 | 83/7~ | Transmission REAR |
| 03905 5483 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FT FT315 T,V,SP | 79/10~83/ | Transmission REAR |
| 03905 6797 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT315 SPM | 79/10~83/ | Transmission REAR |
| 03905 1451 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FT FT510 NY#,TY#,WY#(22T) | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 6272 | MH034082 | 155 x 180 x 17 | FUSO TRUCK FT FT1#,3# | 74/~83/ | Wheel Hub REAR INNER |
| 03905 4343 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT119 L,N,S,U,RG | 76/~79/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5585 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT113 EXCEPT S,U,N,RP | 74/~79/ | Wheel Hub REAR OUTER |
| 03905 7265 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT102,103,112,117 | 74/~79/ | Wheel Hub REAR OUTER |
| 03905 3794 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FT FT5# | 96/4~ | Wheel Hub REAR INNER |
| 03905 7415 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FT FT4# | 83/6~99/ | Wheel Hub REAR INNER |
| 03905 2381 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FT FT50K NY#,RY#,WZ#(22T,25T) | 00/1~ | Wheel Hub FRONT (F & R) |
| 03905 2843 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FT FT520,527 | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 1271 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT413 | 83/6~94/ | Wheel Hub REAR OUTER |
| 03905 6878 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FT FT515 NY#,RY#,TY#,WY#(22T) | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 3953 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT415 L,LT,N,NFX,RT,T,V | 93/5~99/ | Wheel Hub REAR OUTER |
| 03905 4643 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FT FT50K LX#,VX#(20T) | 00/1~ | Wheel Hub FRONT (F & R) |
| 03905 1010 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FT FT50J LX1#,2,NXT1,RX#,VX#( 20T) | 00/1~ | Wheel Hub FRONT (F & R) |
| 03905 4112 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FT FT517 LX1#,2#,NXT1#,RX#,VX 1#,2#(20T) | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 1607 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FT FT515 LX#(20T) | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 8507 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FT FT510 VX#(20T) | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 1865 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FT FT4# | 89/11~99/ | Wheel Hub FRONT (F & R) |
| 03905 1649 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FT FT# | 74/~89/10 ~ | Wheel Hub FRONT (F & R) |
| 03905 6830 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT50K VXS,WZS | 00/1~ | Transmission REAR |
| 03905 3707 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT418 NS2 | 89/11~95/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7841 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FT FT517 NYT1#,2#,RYT1#,2#,TY1#,2#,WY1#,2#(22T) | 96/4~00/ | Wheel Hub FRONT (F & R) |
| 03905 1394 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT315 | 79/10~83/ | Wheel Hub REAR OUTER |
| 03905 8348 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT50J LXT2,VX#,NYT2,RYT2, TY#,WY#,WZ# | 00/1~ | Wheel Hub REAR OUTER |
| 03905 7064 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT517 LXT2,VX2#,NYT2#,RYT2#,TY2#,WY2# | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 8168 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT515 TY#,WY# | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 8921 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT510,520,527 | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 8846 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT418 #S3(V),#S30#,#S4(V),#S7 | 85/9~89/10 | Wheel Hub REAR OUTER |
| 03905 6290 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT417 #S2 | 94/11~ | Wheel Hub REAR OUTER |
| 03905 2762 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT416 | 89/11~95/ | Wheel Hub REAR OUTER |
| 03905 7637 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT415 NP#,TP#,VP# | 93/5~96/ | Wheel Hub REAR OUTER |
| 03905 4709 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT313,318 | 79/10~83/ | Wheel Hub REAR OUTER |
| 03905 2831 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT410 | 89/11~97/ | Wheel Hub REAR OUTER |
| 03905 6860 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK FT FT112,113,117,119 | 74/~79/ | Transmission FRONT |
| 03905 6077 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT119 HD,HM,RP | 76/~79/ | Wheel Hub REAR OUTER |
| 03905 2447 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT113 S,U,N,RP | 74/~79/ | Wheel Hub REAR OUTER |
| 03905 2591 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FU50K | 00/1~ | Wheel Hub REAR OUTER |
| 03905 5342 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT50J LXT1#,NXT1,RX#,NYT1#,RYT1 | 00/1~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8273 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT517 LXT1#,NXT1#,RX#,VX1 #,NYT1#MRYT1#,TY1#, WY1# | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 6050 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT515 LX#,NY#,RY# | 96/4~00/ | Wheel Hub REAR OUTER |
| 03905 7793 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT418 ALL | 89/11~93/ | Wheel Hub REAR OUTER |
| 03905 5087 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT418 #S,#S01,#S2,#S2V,#S6 | 83/6~89/1 0 | Wheel Hub REAR OUTER |
| 03905 8111 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FT FT417 #S1 | 94/11~96/ | Wheel Hub REAR OUTER |
| 03905 8036 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FT FT415 ALL | 83/6~93/5 | Wheel Hub REAR OUTER |
| 03905 1340 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT417 NZS2,NZTS2,RZS2,LTS2, NS2 | 94/11~96/ | Final Drive PINION |
| 03905 5351 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT515 LXT#,NYT#,RYT# | 96/4~00/ | Final Drive PINION |
| 03905 3875 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FT FT517 VX2(A),WY2(A) | 96/4~00/ | Final Drive PINION |
| 03905 5891 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FT FT510,520,527 | 96/4~00/ | Final Drive PINION |
| 03905 1655 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FT FT410 TS1,VS1 | 95/4~96/ | Final Drive PINION |
| 03905 2639 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FT FT410 VZS1,WZS1,TPS3,NPS3, VPS3 | 94/11~96/ | Final Drive PINION |
| 03905 3404 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT54J NYT2,NYT2X | 03/3~ | Final Drive PINION |
| 03905 3611 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT50J LXT2,NYT2,RYT2,NYT2 (X) | 00/1~ | Final Drive PINION |
| 03905 2384 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT517 LXT2(A),NYT2(A),RYT2 (A),TY2(A) | 96/4~00/ | Final Drive PINION |
| 03905 7226 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FT FT54J NYT2V,VX1#,2#,WZ2# | 03/3~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8474 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT418 TS2,VS2 | 89/11~95/ | Final Drive PINION |
| 03905 7406 | 31107-06301 | 85 x 110 x 13 | FUSO TRUCK FT 8DC# | 74/~83/ | Engine TIMING GEAR CASE |
| 03905 5627 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT416 | 89/11~95/ | Final Drive PINION |
| 03905 5930 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT415 NPS7,TPS2,TPS7,VPS2,VPS7 | 90/9~96/ | Final Drive PINION |
| 03905 7214 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT410 TS1,TS2,VS1,VS2 | 89/11~95/ | Final Drive PINION |
| 03905 2714 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT54J NYT1 | 03/3~ | Final Drive PINION |
| 03905 6332 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT50K | 00/1~ | Final Drive PINION |
| 03905 1922 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT50J LXT1(A),NXT1,NYT1(A),RXG1,RXT1,RYT1 | 00/1~ | Final Drive PINION |
| 03905 6800 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT517 RYT1(A),TY1(A),VX1(A),WY1(A) | 96/4~00/ | Final Drive PINION |
| 03905 6350 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT517 LXT1(A),NXT1(A),NYT1(A),RXT1(A) | 96/4~00/ | Final Drive PINION |
| 03905 5291 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FT FT515 TYP2,WYP2 | 96/7~00/ | Final Drive PINION |
| 03905 5468 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK FT 6D20 | 76/~79/ | Engine CRANK SHAFT REAR |
| 03905 3314 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT54J NYT2,NYT2X | 03/3~ | Transmission REAR |
| 03905 5591 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FT FT418 TS3#,4#,VS3#,4#,7 | 83/6~89/10 | Transmission REAR |
| 03905 2597 | ME120154 | | FUSO TRUCK FT 6D40,6M70 | 89/11~ | Engine VALVE STEM SEAL |
| 03905 2957 | ME061574 | | FUSO TRUCK FT 8DC#,6D2# | 79/10~ | Engine VALVE STEM SEAL |
| 03905 8012 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FT 6M70 | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 1259 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FT 6D24,40 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 6095 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FT 8DC# | 95/4~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2552 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FT 6D40 | 89/11~97/8 | Engine CRANK SHAFT REAR |
| 03905 1349 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FT FT50J VX1#,2#,3,WY2#,WZ2#, WZ3(V),TYP4,WYP4 | 00/1~ | Final Drive PINION |
| 03905 8549 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FT 8DC# | 79/10~95/4 | Engine CRANK SHAFT REAR |
| 03905 2246 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FT 8DC8,9 FT413,415 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 1226 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK FT 8DC# | 74/~79/ | Engine CRANK SHAFT REAR |
| 03905 5705 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 6M70 FT50J | 00/1~ | Engine TIMING GEAR CASE |
| 03905 1439 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 6D40 FT410,510,520 | 89/11~00/ | Engine TIMING GEAR CASE |
| 03905 8117 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 6D24 FT417,517,527 | 94/11~00/ | Engine TIMING GEAR CASE |
| 03905 7496 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 6D22 FT418 | 85/9~93/ | Engine TIMING GEAR CASE |
| 03905 2153 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 8DC11 FT50K | | Engine TIMING GEAR CASE |
| 03905 2966 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 8DC10 FT416 | 89/11~95/ | Engine TIMING GEAR CASE |
| 03905 3185 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FT 6D20,22 FT418 | 79/10~85/8 | Engine TIMING GEAR CASE |
| 03905 8852 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FT 6D2# | 79/10~97/8 | Engine CRANK SHAFT REAR |
| 03905 6032 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT54J NYT2V,VX1#,2#,WZ2# | 03/3~ | Transmission REAR |
| 03905 6365 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FT FT418 LT,LS,NTS | 83/6~88/8 | Final Drive PINION |
| 03905 8324 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FT FT413 KT | 88/9~89/10 | Final Drive PINION |
| 03905 1139 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FT FT413 .LT,RT | 83/6~93/ | Final Drive PINION |
| 03905 8024 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FT FT112 L | 76/10~79/ | Final Drive PINION |
| 03905 5990 | 03434-07051 | 70 x 92 x 13.5 x 20.5 | FUSO TRUCK FT FT# | 74/~76/9 | Final Drive PINION |
| 03905 5504 | MH034119 | 84 x 110 x 13 | FUSO TRUCK FT FT4#,5# | 94/11~ | Propeller Shaft CENTER BEARING |
| 03905 7310 | MC833624 | 80 x 100 x 13 | FUSO TRUCK FT FT4#,5# | 89/11~ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6455 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FT FT418 KTS,KTS6,LTS,LTS6,RTS6,NTS6,RGS6 | 85/9~95/ | Final Drive PINION |
| 03905 7766 | 03437-07052 | 70 x 90 x 10 | FUSO TRUCK FT FT1# | 74/~78/5 | Propeller Shaft CENTER BEARING |
| 03905 3143 | MH034065 | 70 x 100 x 13 | FUSO TRUCK FT FT4#,5# | 89/11~ | Propeller Shaft CENTER BEARING |
| 03905 8954 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT50J NYT2V,VX1#,2#,3,WY2#,WZ2#,3#,TYP4,WYP4 | 00/1~ | Transmission REAR |
| 03905 9020 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT517 VX2#,WY2# | 96/4~00/ | Transmission REAR |
| 03905 7781 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT510,520,527 | 96/4~00/ | Transmission REAR |
| 03905 4802 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT418 TS2,VS2 | 89/11~95/ | Transmission REAR |
| 03905 5321 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT418 LTS2,NS2,NS6,TS6,VS6 | 90/2~95/ | Final Drive PINION |
| 03905 8393 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT410,416 | 89/11~96/ | Transmission REAR |
| 03905 3884 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FT 8DC8,9 FT413,415,515 | 85/9~00/ | Engine TIMING GEAR CASE |
| 03905 7733 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FT FT417 VZS2,WZS2,TS2,VS2 | 94/11~96/ | Transmission REAR |
| 03905 1829 | MH034065 | 70 x 100 x 13 | FUSO TRUCK FT FT4# | 83/7~89/10 | Propeller Shaft CENTER BEARING |
| 03905 4178 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT418 KTS,LTS,NS,TS,TS2V,TS4(V),VS,VS2V,VS4(V) | 83/6~85/8 | Final Drive PINION |
| 03905 4127 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT417 KTS1,LTS1,NS1,RGS1,RTS1,TS1,VS1 | 95/4~96/ | Final Drive PINION |
| 03905 1823 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT417 NZS1,NZTS1,RZS1,VZS1,WZS1 | 94/11~96/ | Final Drive PINION |
| 03905 8708 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT415 L,LT,N,RT | 93/5~96/ | Final Drive PINION |
| 03905 7937 | MH034065 | 70 x 100 x 13 | FUSO TRUCK FT FT1#,3# | 78/6~83/ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4271 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FT FT112 EXCEPT L | 76/10~79/ | Final Drive PINION |
| 03905 4625 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT413 L,N | 90/2~93/5 | Final Drive PINION |
| 03905 5081 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT418 LTS2,NS2,NS6,TS6,VS6 | 85/9~90/2 | Final Drive PINION |
| 03905 1817 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT418 TS2V,TS3V,TS4(V),VS2 V,VS3V,VS4MVS4S | 85/9~88/8 | Final Drive PINION |
| 03905 1028 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT415 NPS7,TPS2,TPS7,VPS2,V PS7 | 90/2~90/8 | Final Drive PINION |
| 03905 6737 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT418 KTS2,NS2,TS2,VS2 | 83/6~85/8 | Final Drive PINION |
| 03905 3431 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT415 ALL | 83/6~90/2 | Final Drive PINION |
| 03905 2690 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FT FT313,318 ALL | 79/10~83/ | Final Drive PINION |
| 03905 8624 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT413 KT | 83/6~88/8 | Final Drive PINION |
| 03905 7853 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT413 L,N | 83/6~90/2 | Final Drive PINION |
| 03905 4844 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT315 ALL | 79/10~83/ | Final Drive PINION |
| 03905 5330 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT119 HD,HM,RP | 76/10~79/ | Final Drive PINION |
| 03905 4481 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT113 S,U,N,RP | 76/10~79/ | Final Drive PINION |
| 03905 2852 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FT FT117 ALL | 76/10~79/ | Final Drive PINION |
| 03905 7883 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FT FT418 KTS2,NS,TS2,TS3,VS,VS 2,VS3,VS7 | 85/9~89/1 0 | Final Drive PINION |
| 03905 6956 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FT FT119 L,N,S,U | 76/10~79/ | Final Drive PINION |
| 03905 4757 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU419 S,SQ,T,TQ,U,UQ | 89/11~96/ | Transmission REAR |
| 03905 5174 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU419 SZ,YZ | 94/11~96/ | Transmission REAR |
| 03905 1670 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU440,470 | 91/9~97/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1262 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU477,478 SS2,TS2,US2 | 83/6~97/ | Transmission REAR |
| 03905 3023 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FU 6D40,8M20,21 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 8138 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU510,512,540,549 | 96/4~00/ | Transmission REAR |
| 03905 3698 | ME061574 | | FUSO TRUCK FU 8DC#,6D2# | 79/10~ | Engine VALVE STEM SEAL |
| 03905 6128 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU511 XEC.NY | 96/4~00/ | Transmission REAR |
| 03905 6656 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU418 S2,TS2,US2 | 89/11~95/ | Transmission REAR |
| 03905 6974 | ME120154 | | FUSO TRUCK FU 6D40,8M20,21,6M70 | 91/9~ | Engine VALVE STEM SEAL |
| 03905 1577 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FU 6M70 | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 4283 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU417...SZS2,YZS2,SS2, TS2,US2 | 94/11~96/ | Transmission REAR |
| 03905 2768 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU416 S,SQ,T,TQ,U,UQ | 89/11~95/ | Transmission REAR |
| 03905 6761 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU411 EXC. MZC,NC(94.11-) | 91/9~96/ | Transmission REAR |
| 03905 8381 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU410 EXC. NS2,PS2(91.9~95.4) | 89/11~96/ | Transmission REAR |
| 03905 2921 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU54J NY2,NY2X,TZT2A | 03/3~ | Transmission REAR |
| 03905 4928 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU50M NYF1,NY1,2,PYF1,PY1 | 00/1~ | Transmission REAR |
| 03905 2933 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU50K SX,SY,TX,TY,TZS,JXD, NX,NY,PX,PY | 00/1~ | Transmission REAR |
| 03905 5279 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FU 6D24 EXC. FU517 JXM1,JXMA1A | 97/8~00/ | Engine CRANK SHAFT REAR |
| 03905 4175 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 6D22 FU418,478 | 85/9~96/ | Engine TIMING GEAR CASE |
| 03905 8783 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU50J JXD1,NX1,NY2,PX1,PY2 ,TZT2A | 00/1~03/3 | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2582 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU577 LXT2,NYT2,PX1,PY2,UX 1 | 96/4~00/ | Transmission REAR |
| 03905 2987 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU54J UZ239 | 00/1~03/3 | Transmission REAR |
| 03905 3854 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FU 8DC9 FU515,JXM,JXMA | 96/4~97/4 | Engine CRANK SHAFT REAR |
| 03905 4019 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU50M EXC. NYF1,NY1,PYF1,PY1 | 00/1~ | Transmission FRONT |
| 03905 7613 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU519 NY,PY | 96/4~00/ | Transmission REAR |
| 03905 5960 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 8DC9 FU415,515 | 85/9~00/ | Engine TIMING GEAR CASE |
| 03905 7826 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 8DC10 FU416 | 89/11~96/ | Engine TIMING GEAR CASE |
| 03905 5297 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 8DC11 FU419,519,549,50K | 85/9~ | Engine TIMING GEAR CASE |
| 03905 8777 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 6D24 FU417,477,517,577 | 94/11~00/ | Engine TIMING GEAR CASE |
| 03905 5288 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 8M20 FU411,511 | 91/9~00/ | Engine TIMING GEAR CASE |
| 03905 7922 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 8M21 FU512,50M,54M | 96/4~ | Engine TIMING GEAR CASE |
| 03905 2270 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 6M70 FU50J,54J,55J | 00/1~ | Engine TIMING GEAR CASE |
| 03905 7355 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK FU 8DC# | 74/~79/ | Engine CRANK SHAFT REAR |
| 03905 5633 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 6D40 FU410,440,470,510,540 | 89/11~00/ | Engine TIMING GEAR CASE |
| 03905 4766 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FU 8DC8,9,10 | 79/10~96/ | Engine CRANK SHAFT REAR |
| 03905 4010 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FU 8DC11 FU50K JXM | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 2999 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FU 8DC11 FU419 EXC. MZ,PZ,SZ,YZ(94.11-) | 85/9~95/4 | Engine CRANK SHAFT REAR |
| 03905 5765 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FU 6D22,24 | 83/6~97/8 | Engine CRANK SHAFT REAR |
| 03905 7334 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FU 6D24 FU517 JXM1,JXM1A | 96/4~98/4 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4472 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FU 6D40 | 89/11~97/8 | Engine CRANK SHAFT REAR |
| 03905 5156 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FU 8DC9 EXC. FU515 JXM,JXMA | 96/4~00/ | Engine CRANK SHAFT REAR |
| 03905 3167 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FU 8DC11 FU419 | 95/4~99/ | Engine CRANK SHAFT REAR |
| 03905 7814 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FU 8DC11 FU419 MZ,PZ,SZ,YZ | 94/11~99/ | Engine CRANK SHAFT REAR |
| 03905 2219 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FU 8DC11 FU519,549 | 96/4~00/ | Engine CRANK SHAFT REAR |
| 03905 4349 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FU 8DC11 FU50K EXC. JXM | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 8870 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FU 8DC9 FU515 JXM,JXMA | 97/5~00/ | Engine CRANK SHAFT REAR |
| 03905 2672 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK FU 6D20 | 76/~79/ | Engine CRANK SHAFT REAR |
| 03905 1835 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FU 8DC8 FU413 | 85/9~94/ | Engine TIMING GEAR CASE |
| 03905 7928 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 JDS1,LTS,LTS2,NS,PS | 85/9~89/3 | Transmission REAR |
| 03905 5528 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 NS2,PS2,SS,SS6,TS,TS6, US,US6 | 85/9~89/3 | Transmission REAR |
| 03905 8162 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 SS2#,TS2,US2# | 85/9~88/8 | Transmission REAR |
| 03905 8084 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 JDS1,LTS,NS,PS,SS,SS2 V,TS,US,US2V | 83/6~85/8 | Transmission REAR |
| 03905 4169 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 LTS2,NS2,PS2,SS2,TS2,U S2 | 83/6~85/8 | Transmission REAR |
| 03905 2990 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU417 LTS1 | 95/4~96/ | Transmission REAR |
| 03905 3521 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU415 EXC.S,SQ,T,TQ,U,UQ(88 .9~89.10) | 83/6~96/ | Transmission REAR |
| 03905 5687 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU413 | 83/7~94/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1472 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU313,315,318,353,358 | 79/10~83/ | Transmission REAR |
| 03905 2708 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU177,119 | 76/~79/ | Transmission REAR |
| 03905 6584 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU54M,55J | 00/1~ | Transmission FRONT |
| 03905 4103 | ME655359 | 97 x 110 x 4.5 | FUSO TRUCK FU FU4##,5## | 83/9~ | Transmission MAIN SHAFT |
| 03905 2102 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 SS6,TS6,US6 | 89/3~95/ | Transmission REAR |
| 03905 5531 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU54J EXC.TZT1A | 00/1~ | Transmission FRONT |
| 03905 5864 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU413,415,416,440,470,477,478 | 94/11~97/ | Wheel Hub FRONT |
| 03905 7169 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU50J EXC.JXD1,LXT1,NXT1,PX1,TZT1A | 00/1~ | Transmission FRONT |
| 03905 8216 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU577 UY2# | 96/4~00/ | Transmission FRONT |
| 03905 8672 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU519 SY,TX#,TY#,TZ#,UZ# | 96/4~00/ | Transmission FRONT |
| 03905 8747 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU517 SY2#,TX2#,TY2#,TZ2#,UZ2# | 96/4~00/ | Transmission FRONT |
| 03905 4817 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU510,511,512,540,549 | 96/4~00/ | Transmission FRONT |
| 03905 7319 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU440,470 | 91/9~97/ | Transmission FRONT |
| 03905 5180 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU419 S,SQ,T,TQ,U,UQ,SZ,YZ | 89/11~96/ | Transmission FRONT |
| 03905 2063 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU418,477,478 S2,TS2,US2 | 89/11~96/ | Transmission FRONT |
| 03905 6869 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU102,103,112,113(EXCEPT J,JD) | 74/~79/ | Transmission REAR |
| 03905 1181 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU415 S,SQ,T,TQ,U,UQ | 88/9~89/10 | Transmission REAR |
| 03905 4124 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU511 NY | 96/4~00/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3506 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU477 LTS2,NS1,2,PS1,2,SS1,TS 1,US1 | 95/4~96/ | Transmission REAR |
| 03905 3971 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU419 MZ,PZ | 94/11~96/ | Transmission REAR |
| 03905 5618 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU419 P,N | 85/9~96/ | Transmission REAR |
| 03905 6935 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU F4116FU419 S,SQ,T,TQ,U,UQ | 85/9~89/1 0 | Transmission REAR |
| 03905 5639 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU418,478 NS2,PS2 | 89/11~95/ | Transmission REAR |
| 03905 6587 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU418,478 SS2,3,TS2,3,7,US2,3,7 | 89/3~89/1 0 | Transmission REAR |
| 03905 8630 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU418,478 SS3,TS3#,7,US3#,7 | 85/9~89/3 | Transmission REAR |
| 03905 3053 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU418,478 SS2,TS2,US2 | 88/9~89/3 | Transmission REAR |
| 03905 6725 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU418,478 SS4#,TS4#,US4# | 83/6~88/8 | Transmission REAR |
| 03905 6950 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 LTS6,NS6,PS6 | 85/9~95/ | Transmission REAR |
| 03905 7949 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU416 N,NQ,P,PQ,NFX,PFX | 89/11~95/ | Transmission REAR |
| 03905 5675 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU418,478 NS2,PS2,SS,TS,US | 89/3~89/1 0 | Transmission REAR |
| 03905 5723 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU411 MZC,NC | 94/11~96/ | Transmission REAR |
| 03905 2864 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU410 NS2,PS2 | 91/9~95/ | Transmission REAR |
| 03905 3485 | 44514-46681 | 80 x 105 x 13 | FUSO TRUCK FU FU113 J,JD | 76/~79/ | Transmission REAR |
| 03905 6284 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU54J TZT1A | 03/3~ | Transmission REAR |
| 03905 6035 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU50K JXM,LXTS,NYTS | 00/1~ | Transmission REAR |
| 03905 4067 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU50J TZT1A,LXT1 | 00/1~ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8156 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU577 LXT1,NXT1 | 96/4~98/ | Transmission REAR |
| 03905 3809 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU517 TZT1A | 96/4~00/ | Transmission REAR |
| 03905 1874 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU515 | 96/4~00/ | Transmission REAR |
| 03905 7493 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FU FU477 LTS1,TGS1 | 95/4~96/ | Transmission REAR |
| 03905 2444 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU517 JXM1#,JX1#,NX1#,NY2, PX1#,PY2,TX1# | 96/4~00/ | Transmission REAR |
| 03905 8951 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FU FU417 MZS2,PZS2,NS1,2,PS1,2, SS1,TS1,US1 | 94/11~96/ | Transmission REAR |
| 03905 4220 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU54J,54M,55J | 00/1~ | Wheel Hub FRONT |
| 03905 8567 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU418,478 ALL | 89/11~96/ | Wheel Hub REAR OUTER (F) |
| 03905 4202 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU418,478 #S,#S2,#S6(T,T2,T6 ENGINE) | 85/9~89/11 | Wheel Hub REAR OUTER (F) |
| 03905 2945 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU418,478 DRUM BREAK | 83/6~85/8 | Wheel Hub REAR OUTER (F) |
| 03905 7091 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU417,477 #S1(T1 ENGINE) | 94/11~97/ | Wheel Hub REAR OUTER (F) |
| 03905 3416 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU415 CARGO | 89/11~97/ | Wheel Hub REAR OUTER (F) |
| 03905 6824 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU413 ALL | 89/11~94/ | Wheel Hub REAR OUTER (F) |
| 03905 3320 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU413 CARGO | 83/6~89/10 | Wheel Hub REAR OUTER (F) |
| 03905 7559 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU318,353,358 | 80/2~83/ | Wheel Hub REAR OUTER (F) |
| 03905 2033 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU313 EXC. J,JD,JM,JMA | 79/10~83/ | Wheel Hub REAR OUTER (F) |
| 03905 8867 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FU FU4## | 83/7~ | Wheel Hub REAR INNER (F & R) |
| 03905 4289 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU50K JX#,LX#,NX#,PX#,SX#,TX#(20T) | 00/1~ | Wheel Hub FRONT |
| 03905 1292 | MH034082 | 155 x 180 x 17 | FUSO TRUCK FU FU1## | 74/~79/ | Wheel Hub REAR INNER (F & R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2468 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU577 LX#(EXC.LXT2),NX#,PX #,UX# | 96/4~00/ | Wheel Hub REAR OUTER (F) |
| 03905 3158 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU50J,50K,50M NY#,PY#,SY#,TY#,TZ#, UZ#(22T,25T) | 00/1~ | Wheel Hub FRONT |
| 03905 4850 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU577 NY#,PY#,UY#(22T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 4193 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU517,519 NY#,PY#,SY#,TY#,TZ#, UZ#(22T,25T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 6770 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU515 NY#,PY#,SY#,TY#(22T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 7346 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU511,512,540,549 | 96/4~00/ | Wheel Hub FRONT |
| 03905 6485 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU510 TY#,TZ#,UZ#(22T,25T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 5147 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU419 YZ | 94/11~97/ | Wheel Hub FRONT |
| 03905 3836 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU417 YZS2 | 94/11~97/ | Wheel Hub FRONT |
| 03905 7034 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FU FU410,411 TZ#,UZ#,YZ# | 94/11~97/ | Wheel Hub FRONT |
| 03905 4172 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU416 | 89/11~96/ | Final Drive PINION |
| 03905 8675 | MH034082 | 155 x 180 x 17 | FUSO TRUCK FU FU3## | 79/10~83/ | Wheel Hub REAR INNER (F & R) |
| 03905 7655 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU418 DISC BREAK | 83/6~85/8 | Wheel Hub REAR OUTER (F) |
| 03905 4340 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK FU FU1##,3## | 74/~83/ | Rear Suspesion TRUNION |
| 03905 2309 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU50M,54J,55J | 00/1~ | Wheel Hub REAR OUTER (F) |
| 03905 1325 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU50K JXD | 00/1~ | Wheel Hub REAR OUTER (F) |
| 03905 5996 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU50J EXC. TZT1A | 00/1~ | Wheel Hub REAR OUTER (F) |
| 03905 3632 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU577 LXT2,NY#,PY#,UY# | 96/4~00/ | Wheel Hub REAR OUTER (F) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4052 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU517 JX#,TX2#,NY#,PY#,SY#, TY#,TZ#,UZ# | 96/4~00/ | Wheel Hub REAR OUTER (F) |
| 03905 7892 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU515 JX# | 96/4~00/ | Wheel Hub REAR OUTER (F) |
| 03905 4328 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU510,511,512,519,540,5 49 | 96/4~00/ | Wheel Hub REAR OUTER (F) |
| 03905 2825 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU478 #S4,#S7(T4,T7 ENGINE) | 85/9~89/1 0 | Wheel Hub REAR OUTER (F) |
| 03905 8906 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU477 #S2(T2 ENGINE) | 95/4~97/ | Wheel Hub REAR OUTER (F) |
| 03905 1496 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU515 EXC. JX# | 96/4~00/ | Wheel Hub REAR OUTER (F) |
| 03905 1580 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU418 #S1,#S3,#S4,#S7(T1,T3,T 4,T7 ENGINE) | 85/9~89/1 1 | Wheel Hub REAR OUTER (F) |
| 03905 6446 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU517 NX#,PX#,TX1#,TZ1A#,T ZT1A | 96/4~00/ | Wheel Hub REAR OUTER (F) |
| 03905 5003 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU417 #S2(T2 ENGINE) | 94/11~97/ | Wheel Hub REAR OUTER (F) |
| 03905 2084 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU416 | 89/11~96/ | Wheel Hub REAR OUTER (F) |
| 03905 2282 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU415 DUMP,MUXER | 89/11~97/ | Wheel Hub REAR OUTER (F) |
| 03905 6932 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU415 ALL | 83/7~89/1 0 | Wheel Hub REAR OUTER (F) |
| 03905 6221 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU413 DUMP,MIXER | 83/7~89/1 0 | Wheel Hub REAR OUTER (F) |
| 03905 1973 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU410,411 | 89/11~97/ | Wheel Hub REAR OUTER (F) |
| 03905 3203 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU315 | 79/10~83/ | Wheel Hub REAR OUTER (F) |
| 03905 6335 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU313 J,JD,JM,JMA | 79/10~83/ | Wheel Hub REAR OUTER (F) |
| 03905 8042 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU50K EXC. JXD | 00/1~ | Wheel Hub REAR OUTER (F) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8321 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FU FU50J TZT1A(T1 EHNGINE) | 00/1~ | Wheel Hub REAR OUTER (F) |
| 03905 3059 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU50J JX#,NX#,PX#,TX#(20T) | 00/1~ | Wheel Hub FRONT |
| 03905 1364 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FU FU419,440,470 | 85/9~99/ | Wheel Hub REAR OUTER (F) |
| 03905 2771 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU511 SY,TY,UZ# | 96/4~00/ | Final Drive PINION |
| 03905 6578 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU50M NYF1,NY1,2,PYF1,PY2 | 00/1~ | Final Drive PINION |
| 03905 7337 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU54J UZ239,NY2,NY2X,TZT2 A | 00/1~ | Final Drive PINION |
| 03905 5657 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU410 SS1,3,TS1,3,US1,3 | 95/4~96/ | Final Drive PINION |
| 03905 3383 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU410 SZ#,TZ#,UZ#,YZ# | 94/11~96/ | Final Drive PINION |
| 03905 7643 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU411 SC,TC,UC | 95/4~96/ | Final Drive PINION |
| 03905 7043 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU411 TZ#,UZ#,YZ# | 94/11~96/ | Final Drive PINION |
| 03905 7160 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU417 SZS2,YZS2,SS2,TS2,US2 | 94/11~96/ | Final Drive PINION |
| 03905 6623 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU419 SZ,YZ | 94/11~96/ | Final Drive PINION |
| 03905 4247 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU419 S,T,U | 95/4~96/ | Final Drive PINION |
| 03905 1733 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU440 | 95/4~96/ | Final Drive PINION |
| 03905 4934 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU50M TX#(20T) | 00/1~ | Wheel Hub FRONT |
| 03905 8891 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU510,512,540,549 | 96/4~00/ | Final Drive PINION |
| 03905 1361 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU577 LXT2,NYT2,PY2 | 96/4~00/ | Final Drive PINION |
| 03905 1190 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU517 SY2,TX2#,TY2#,TZ2#,UZ 2# | 96/4~00/ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1406 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU519 SY,TX#,TY#,TZ#,UZ# | 96/4~00/ | Final Drive PINION |
| 03905 5720 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU577 UY2 | 96/4~00/ | Final Drive PINION |
| 03905 4901 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU50J EXC. JXD1,NX1,NY2,2X,PX1, PY2,TZT1A,2A,LXT1 | 00/1~ | Final Drive PINION |
| 03905 7502 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU50M SY1,2,TX1,TY1,2,TZ1,UZ 1,2,3 | 00/1~ | Final Drive PINION |
| 03905 5816 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU54M,55J | 00/1~ | Final Drive PINION |
| 03905 4511 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU54J EXC.UZ239,NY2,NY2X, TZT1A,2A | 00/1~ | Final Drive PINION |
| 03905 8561 | 31107-06301 | 85 x 110 x 13 | FUSO TRUCK FU 8DC# | 74/~83/ | Engine TIMING GEAR CASE |
| 03905 5975 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FU 8DC8,9 FU413,415 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 4943 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FU 6D2# | 79/~83/ | Engine TIMING GEAR CASE |
| 03905 2687 | MH034201 | 84 x 162 x 12 x 41.5 | FUSO TRUCK FU FU477 SS2,TS2,US2 | 95/4~96/ | Final Drive PINION |
| 03905 3503 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU418,478 SS2,TS2,US2 | 89/11~95/ | Final Drive PINION |
| 03905 2600 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU577 LX#,NX#,PX#,UX#(20T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 6341 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU519 TX#(20T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 1127 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU517 NX#,PX#,TX1#,2#,JX#(20 T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 1136 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU515..NX#,LX#,PX#,SX #,TX#,JX#(20T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 7022 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU510 TX#(20T) | 96/4~00/ | Wheel Hub FRONT |
| 03905 6641 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU419 EXC. YZ(94.11~) | 85/9~99/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5879 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU417 EXC. YZS2 | 94/11~97/ | Wheel Hub FRONT |
| 03905 4379 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU140,411 EXC. TZ#,UZ#,YZ#(94.11~) | 89/11~97/ | Wheel Hub FRONT |
| 03905 5870 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU415 EXC. JD,JM(89.11-) | 83/6~90/2 | Final Drive PINION |
| 03905 7940 | MH034136 | 130 x 150 x 12 | FUSO TRUCK FU FU4## | 89/11~94/ 11 | Wheel Hub FRONT |
| 03905 7568 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU50K JXD | 00/1~ | Final Drive PINION |
| 03905 4262 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU417 MZS2,PZS2,NS2,PS2 | 94/11~96/ | Final Drive PINION |
| 03905 6632 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU50J JXD1,NX1,NY2,PX1,PY2 ,TZT2A | 00/1~ | Final Drive PINION |
| 03905 7958 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU419 N,S,SQ,T,TQ,U,UQ | 89/11~95/ 4 | Final Drive PINION |
| 03905 6302 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU419 N,P | 95/4~96/ | Final Drive PINION |
| 03905 4217 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU419 MZ,PZ | 94/11~96/ | Final Drive PINION |
| 03905 1559 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU440 | 93/5~95/4 | Final Drive PINION |
| 03905 4292 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU470 | 91/9~96/ | Final Drive PINION |
| 03905 8210 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU477 LYS2,NS2,PS2 | 95/4~96/ | Final Drive PINION |
| 03905 4595 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU511 NY | 96/4~00/ | Final Drive PINION |
| 03905 1916 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU515 JX# | 96/4~00/ | Final Drive PINION |
| 03905 4574 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU517 JX#,NY2#,PY2#,TZT2A | 96/4~00/ | Final Drive PINION |
| 03905 3791 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU519 NY,PY | 96/4~00/ | Final Drive PINION |
| 03905 1277 | ME061853 | 95 x 120 x 13 | FUSO TRUCK FU 6D22 FU418,478 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 1793 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU417 SZS2,YZS2,SS2,TS2,US2 | 94/11~96/ | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7103 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU413 | 83/6~90/2 | Final Drive PINION |
| 03905 4523 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FU FU117 ALL | 77/~79/ | Final Drive PINION |
| 03905 2258 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FU FU313 N,P,S,U | 79/10~83/ | Final Drive PINION |
| 03905 3047 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FU FU318,353,358 | 80/2~83/ | Final Drive PINION |
| 03905 5945 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU112 J,JD,JM | 76/10~79/ | Final Drive PINION |
| 03905 8219 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU113 J,JD,JM,N,P,R,S | 76/10~79/ | Final Drive PINION |
| 03905 5285 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU119 J,JD,JM | 76/10~79/ | Final Drive PINION |
| 03905 4916 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU418,478 EXC.SS2,TS2,US2 | 90/2~95/ | Final Drive PINION |
| 03905 6143 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU315 ALL | 79/10~83/ | Final Drive PINION |
| 03905 1412 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FU FU112 EXCEPT J,JD,JM | 76/10~79/ | Final Drive PINION |
| 03905 3392 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU54J TZT1A | 03/3~ | Transmission FRONT |
| 03905 2969 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU418,478 EXC.SS2,TS2,US2(89.11-) | 83/6~90/2 | Final Drive PINION |
| 03905 3323 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK FU FU41# | 83/7~99/ | Rear Suspesion TRUNION |
| 03905 4061 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU413 | 90/2~93/ | Final Drive PINION |
| 03905 6329 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU415 EXC.JD,JM | 90/2~96/ | Final Drive PINION |
| 03905 2312 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU F4197 LTS1,NS1,PS1,SS1,TS1,US1 | 95/4~96/ | Final Drive PINION |
| 03905 7244 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU F4106FU313 J,JD,JM | 79/10~83/ | Final Drive PINION |
| 03905 8096 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU54J EXC. UZ239,NY2,NY2X,TZT1A,2A | 00/1~ | Transmission REAR |
| 03905 2477 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU419 N,P,S,SQ,T,TQ,U,UQ | 85/9~89/10 | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6746 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU416 S,SQ,T,TQ,U,UQ | 89/11~95/ | Transmission FRONT |
| 03905 6527 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FU FU3## | 79/10~89/ 10 | Wheel Hub FRONT |
| 03905 2024 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU519 SY,TX#,TY#,TZ#,UZ# | 96/4~00/ | Transmission REAR |
| 03905 2411 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU577 UY2 | 96/4~00/ | Transmission REAR |
| 03905 3113 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU50J SY2,TX1,2,3,TY2,3,TZ2,3 ,UZ1,2,3,4 | 00/1~ | Transmission REAR |
| 03905 8462 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FU FU119 EXCEPT J,JD,JM | 76/10~79/ | Final Drive PINION |
| 03905 1766 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU50M SY1,2,TX1,,TY1,2,TZ1,U Z1,2,3 | 00/1~ | Transmission REAR |
| 03905 2720 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK FU FU113 EXCEPT J,JD,JM,N,P,R,S | 76/10~79/ | Final Drive PINION |
| 03905 5411 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU54M,55J | 00/1~ | Transmission REAR |
| 03905 1307 | 03437-07052 | 70 x 90 x 10 | FUSO TRUCK FU FU1# | 74/~78/5 | Propeller Shaft CENTER BEARING |
| 03905 1826 | MH034065 | 70 x 100 x 13 | FUSO TRUCK FU FU1#,3# | 78/6~83/ | Propeller Shaft CENTER BEARING |
| 03905 2900 | MH034065 | 70 x 100 x 13 | FUSO TRUCK FU FU4# | 83/7~89/1 0 | Propeller Shaft CENTER BEARING |
| 03905 5030 | MC833624 | 80 x 100 x 13 | FUSO TRUCK FU FU4#,5# | 89/11~ | Propeller Shaft CENTER BEARING |
| 03905 4322 | 03434-07051 | 70 x 92 x 13.5 x 20.5 | FUSO TRUCK FU FU# | 74/~76/9 | Final Drive PINION |
| 03905 8546 | MH034119 | 84 x 110 x 13 | FUSO TRUCK FU FU4#,5# | 94/11~ | Propeller Shaft CENTER BEARING |
| 03905 5606 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU50J NY2V,TX2X,TY2X,UZ2 X,UZ3X,UZ4V42 | 03/3~ | Transmission REAR |
| 03905 3464 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU50J JXD1,LXT1,NX1,PX1,TZ T1A | 00/1~ | Transmission FRONT |
| 03905 3005 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU410 NS2,PS2 | 91/9~95/4 | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6833 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU313,315,318,353,358 | 79/10~83/ | Transmission FRONT |
| 03905 5021 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU113 J,JD | 76/~79/ | Transmission FRONT |
| 03905 1640 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK FU FU117,199 | 76/~79/ | Transmission FRONT |
| 03905 3851 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK FU FU102,103,112,113(EXCEPT J,JD) | 74/~79/ | Transmission FRONT |
| 03905 2369 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FU FU517 SY2,TX2#,TY2#,TZ2#,UZ2# | 96/4~00/ | Transmission REAR |
| 03905 6227 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU413,415 | 83/7~97/ | Transmission FRONT |
| 03905 3353 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU50K | 00/1~ | Transmission FRONT |
| 03905 4133 | MC095475 | 154 x 185 x 19 | FUSO TRUCK FU FU50J,50K,50M | 00/1~ | Rear Suspesion TRUNION |
| 03905 4838 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU577 XEC. UY2# | 96/4~00/ | Transmission FRONT |
| 03905 8357 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU519 NY,PY | 96/4~00/ | Transmission FRONT |
| 03905 1421 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU477 LTS1,NS1,PS1,SS1,TGS1, TS1,US1 | 95/4~96/ | Final Drive PINION |
| 03905 6959 | MH034065 | 70 x 100 x 13 | FUSO TRUCK FU FU4#,5# | 89/11~ | Propeller Shaft CENTER BEARING |
| 03905 2042 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU411 | 91/9~99/ | Transmission FRONT |
| 03905 2894 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FU FU410 EXC. NS2,PS2(91.9~95.4) | 89/11~97/ | Transmission FRONT |
| 03905 8774 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU50M NYF1,NY1,PYF1,PY1 | 00/1~ | Transmission FRONT |
| 03905 8732 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU411 MZC,NC | 95/4~96/ | Final Drive PINION |
| 03905 5624 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU515 EXC. JX# | 96/4~00/ | Final Drive PINION |
| 03905 6239 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU577 LXT1,NXT1,PX1,UX1 | 96/4~00/ | Final Drive PINION |
| 03905 5117 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU50J TZT1A,LXT1 | 00/1~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7361 | MC095475 | 154 x 185 x 19 | FUSO TRUCK FU FU51# | 96/4~00/ | Rear Suspesion TRUNION |
| 03905 5009 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU416 N,NQ,P,PQ,NFX,PFX | 89/11~95/ | Transmission FRONT |
| 03905 2675 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU50K EXC. JXD | 00/1~ | Final Drive PINION |
| 03905 5333 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU54J TZT1A | 03/3~ | Final Drive PINION |
| 03905 2729 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FU FU517 NX1#,PX1#,TX1#,TZT1A | 96/4~00/ | Final Drive PINION |
| 03905 8120 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU411 SC#,TC#,UC# | 91/9~95/4 | Final Drive PINION |
| 03905 5678 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU417 MZS2,PZS2,LTS1,NS1,PS 1,SS1,TS1,US1 | 94/11~96/ | Transmission FRONT |
| 03905 1583 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU418,478 EXC.SS2,TS2,US2(89.11~ ) | 83/6~95/ | Transmission FRONT |
| 03905 7088 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU517 EXC. SY2#,TX2#,TY2#,TZ2#,U Z2# | 96/4~00/ | Transmission FRONT |
| 03905 4841 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU515 | 96/4~00/ | Transmission FRONT |
| 03905 6872 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU477 EXC. SS2,TS2,US2 | 95/4~96/ | Transmission FRONT |
| 03905 4616 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU415 JD,JM | 89/11~96/ | Final Drive PINION |
| 03905 8390 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FU FU410 NS2,PS2,SS1,2,TS1,2,US1 ,2 | 89/11~95/ 4 | Final Drive PINION |
| 03905 2057 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FU FU419 EXC.S,SQ,T,TQ,U,UQ,SZ ,YZ(89.11~) | 85/9~96/ | Transmission FRONT |
| 03905 4697 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 10M20 FW464 | 90/8~95/7 | Engine CRANK SHAFT REAR |
| 03905 6176 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FW, FX 8DC11 FW419 | 95/9~ | Engine CRANK SHAFT REAR |
| 03905 7193 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FW, FX 8DC9 FW455,LRS2 | 95/7~99/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 9008 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 8DC11 FW419 | 87/7~95/8 | Engine CRANK SHAFT REAR |
| 03905 7880 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 8DC111FW429,449,529 | 86/11~97/ 8 | Engine CRANK SHAFT REAR |
| 03905 8684 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 8M20 FW451 | 93/9~97/8 | Engine CRANK SHAFT REAR |
| 03905 7385 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FW, FX 8M22 FX50L | 00/7~ | Engine CRANK SHAFT REAR |
| 03905 6164 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 10M20 FW444 | 90/6~97/8 | Engine CRANK SHAFT REAR |
| 03905 8099 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FW, FX 8DC9 FW455,MS2 | 95/12~00/ | Engine CRANK SHAFT REAR |
| 03905 7052 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FW, FX 8DC11 FW529,NY62 | 97/3~00/3 | Engine CRANK SHAFT REAR |
| 03905 7394 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FW, FX 8M21 FW422,522,50M | 94/9~ | Engine CRANK SHAFT REAR |
| 03905 2405 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FW, FX 10M20 FW464 | 95/8~00/ | Engine CRANK SHAFT REAR |
| 03905 3491 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FW, FX 8DC11 FW429,529 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 6617 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FW, FX 8M21 FX50M | 00/6~ | Engine CRANK SHAFT REAR |
| 03905 3398 | ME152593 | 132 x 179.5 x 23 x 33 | FUSO TRUCK FW, FX 8DC11 FW449 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 5189 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 8DC9 FW455,LRS2 | 87/9~95/6 | Engine CRANK SHAFT REAR |
| 03905 2099 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FW, FX FX50M EXC. LR2,LR3,LR29# | 00/6~ | Transmission REAR |
| 03905 7715 | ME152593 | 132 x 179.5 x 23 x 33 | FUSO TRUCK FW, FX 10M20 FW444 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 8141 | ME061574 | | FUSO TRUCK FW, FX 8DC#,10M20 | 86/11~ | Engine VALVE STEM SEAL |
| 03905 2870 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FW, FX 8M20 FW451 | 97/8~00/ | Engine CRANK SHAFT REAR |
| 03905 5357 | MH034102 | 85 x 110 x 13 | FUSO TRUCK FW, FX FW455 | 87/9~91/9 | Transmission REAR |
| 03905 5054 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FX50M LR2#,LR3# | 00/6~ | Wheel Hub FRONT |
| 03905 4955 | ME120154 | | FUSO TRUCK FW, FX 8M2# | 93/9~ | Engine VALVE STEM SEAL |
| 03905 6698 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FW, FX FW50M | 00/3~ | Transmission FRONT |
| 03905 5129 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FW, FX FX50L,50M | 00/6~ | Transmission FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2300 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FW, FX FW419,445,449 | 87/7~ | Transmission REAR |
| 03905 5780 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FW, FX FW50M NZ185 | 03/3~ | Transmission REAR |
| 03905 7127 | MH034157 | 80 x 105 x 13 | FUSO TRUCK FW, FX FW444,451 | 90/6~ | Transmission REAR |
| 03905 3752 | MH034157 | 80 x 105 x 13 | FUSO TRUCK FW, FX FX50M LR2,LR3,LR29# | 00/10~ | Transmission REAR |
| 03905 8093 | MH034157 | 80 x 105 x 13 | FUSO TRUCK FW, FX FX50L | 00/7~ | Transmission REAR |
| 03905 3041 | MH034157 | 80 x 105 x 13 | FUSO TRUCK FW, FX FW455 | 91/10~00/ | Transmission REAR |
| 03905 6407 | MH034072 | 70 x 92 x 14 | FUSO TRUCK FW, FX FW50M EXC. NZ185 | 00/3~ | Transmission REAR |
| 03905 5711 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 8DC9 FW455,MS2 | 87/9~95/11 | Engine CRANK SHAFT REAR |
| 03905 5039 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FW, FX FW419,422,429,444,445,449,451,455 | 86/11~ | Final Drive PINION |
| 03905 7100 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FW, FX FW464 | 90/8~95/7 | Final Drive PINION |
| 03905 4571 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FW, FX FW522,529 | 97/3~01/ | Final Drive PINION |
| 03905 7409 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FW, FX FW50M,FX50M | 00/3~ | Final Drive PINION |
| 03905 1019 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK FW, FX FX50L MYP2,LR | 00/9~ | Final Drive PINION |
| 03905 2816 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FW, FX FW464 | 95/8~99/ | Final Drive PINION |
| 03905 3761 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK FW, FX FX50L LR1M | 00/7~ | Final Drive PINION |
| 03905 2480 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FW, FX FW4#,5#,FX5# | 86/11~ | Engine TIMING GEAR CASE |
| 03905 5336 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FW, FX 8DC9 FW445 | 87/3~95/ | Engine CRANK SHAFT REAR |
| 03905 4715 | MH034072 | 70 x 92 x 14 | FUSO TRUCK FW, FX FW429,529 | 86/11~01/ | Transmission REAR |
| 03905 7904 | MC823532 | 153 x 173 x 7.5 x 10.5 | FUSO TRUCK FW, FX FW419 | 87/7~ | Wheel Hub FRONT |
| 03905 1787 | MC823532 | 153 x 173 x 7.5 x 10.5 | FUSO TRUCK FW, FX FW455 MS2 | 87/9~00/ | Wheel Hub FRONT |
| 03905 5519 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FW, FX FW50M NZ# | 00/3~ | Wheel Hub FRONT |
| 03905 3533 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FW, FX FW529 NZ# | 97/3~01/ | Wheel Hub FRONT |
| 03905 7520 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FW, FX FW522 | 97/3~01/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7997 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FW, FX FW429 NZJ05,06,16,18 | 95/4~ | Wheel Hub FRONT |
| 03905 7748 | MC818294 | 180 x 210 x 16 | FUSO TRUCK FW, FX FW422 | 94/9~ | Wheel Hub FRONT |
| 03905 7817 | 06015-13400 | 184 x 215 x 18 | FUSO TRUCK FW, FX FW444,445,449 | 90/6~ | Wheel Hub FRONT |
| 03905 4463 | MC823532 | 153 x 173 x 7.5 x 10.5 | FUSO TRUCK FW, FX FX50M LR1#,LX1,MY# | 00/6~ | Wheel Hub FRONT |
| 03905 3824 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FW, FX FX50L LR1,LR2 | 00/7~ | Wheel Hub REAR INNER (F &R) |
| 03905 7004 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FW, FX FW455 | 91/10~00/ | Transmission FRONT |
| 03905 4445 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FW, FX FX50M LR2#,LR3# | 00/6~ | Wheel Hub REAR INNER (F &R) |
| 03905 8447 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FX50L LR1,LR2 | 00/7~ | Wheel Hub FRONT |
| 03905 6701 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW50M | 00/3~ | Wheel Hub FRONT |
| 03905 7343 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW529 NY# | 97/3~01/ | Wheel Hub FRONT |
| 03905 5270 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW464 | 90/8~00/ | Wheel Hub FRONT |
| 03905 4973 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW455 LR# | 87/9~00/ | Wheel Hub FRONT |
| 03905 7757 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW451 | 93/9~00/ | Wheel Hub FRONT |
| 03905 3815 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW429 EXC. NJ05,06,16,18 | 95/4~ | Wheel Hub FRONT |
| 03905 3563 | 03434-09300 | 150 x 174 x 14 | FUSO TRUCK FW, FX FW429 ALL | 86/11~95/ 3 | Wheel Hub FRONT |
| 03905 7622 | MC823532 | 153 x 173 x 7.5 x 10.5 | FUSO TRUCK FW, FX FX50L MYP2 | 00/7~ | Wheel Hub FRONT |
| 03905 7523 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FW, FX FW50L LR1 | 00/7~ | Wheel Hub REAR OUTER (F & R) |
| 03905 6752 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FW, FX FW529 | 97/3~01/ | Transmission FRONT |
| 03905 4889 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FW, FX FW455 | 87/9~91/9 | Transmission FRONT |
| 03905 4775 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FW, FX FW419,429,445,449 | 86/11~ | Transmission FRONT |
| 03905 8171 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK FW, FX FX50L,50M | 00/6~ | Rear Suspesion TRUNNION |
| 03905 2564 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK FW, FX FW4#,5# | 86/11~ | Rear Suspesion TRUNNION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1727 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FX50M LR1#,LX1,MY# | 00/6~ | Wheel Hub REAR OUTER (F & R) |
| 03905 7634 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FX50L MYP22 | 00/7~ | Wheel Hub REAR OUTER (F & R) |
| 03905 5612 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FW455 MS2 | 87/9~00/ | Wheel Hub REAR OUTER (F & R) |
| 03905 1334 | MC807438 | 154 x 172 x 14 | FUSO TRUCK FW, FX FW422,429,451,455(LR#), 464,522,529,50M | 86/11~ | Wheel Hub REAR INNER (F &R) |
| 03905 3347 | MT141132 | 50 x 65 x 9 | FUSO TRUCK FW, FX FW444,445,449 | 87/3~ | Wheel Hub REAR OUTER (F & R) |
| 03905 1094 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FW, FX FW444,451 | 90/6~ | Transmission FRONT |
| 03905 3770 | MH034135 | 65 x 77 x 12 | FUSO TRUCK FW, FX FW464 | 90/8~00/ | Wheel Hub REAR OUTER (F & R) |
| 03905 1355 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FW, FX FX50M LR2#,LR3# | 00/6~ | Wheel Hub REAR OUTER (F & R) |
| 03905 1172 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FW, FX FX50L LR2 | 00/7~ | Wheel Hub REAR OUTER (F & R) |
| 03905 4013 | MH034134 | 60 x 72 x 12 | FUSO TRUCK FW, FX FW422,429,451,455(LR#), 522,529,50M | 86/11~ | Wheel Hub REAR OUTER (F & R) |
| 03905 2738 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FX50M LR1#,LX1#,MY# | 00/8~ | Wheel Hub REAR INNER (F &R) |
| 03905 2942 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FX50L MYP2 | 00/7~ | Wheel Hub REAR INNER (F &R) |
| 03905 4406 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FW455 MS2 | 00/3~ | Wheel Hub REAR INNER (F &R) |
| 03905 8972 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FW419 | 87/7~ | Wheel Hub REAR INNER (F &R) |
| 03905 8402 | 16421-02101 | 184 x 210 x 15 | FUSO TRUCK FW, FX FW444,445,449 | 87/3~ | Wheel Hub REAR INNER (F &R) |
| 03905 6479 | MC807121 | 160 x 182 x 10 | FUSO TRUCK FW, FX FW419 | 87/7~ | Wheel Hub REAR OUTER (F & R) |
| 03905 5645 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FY FY50J RY2,TX1,TX157,TY2 | 00/1~ | Transmission FRONT |
| 03905 8000 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FY 8M21 FY50M | 00/1~ | Engine TIMING GEAR CASE |
| 03905 2288 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FY FY517 TY2 | 96/4~00/ | Transmission FRONT |
| 03905 8639 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FY FY54J | 00/1~ | Transmission REAR |
| 03905 4355 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FY FY5#...EXC. 50J | 96/4~ | Final Drive PINION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6911 | MH034172 | 65 x 113 x 10 x 30 | FUSO TRUCK FY FY50J NX1,RY2,TX1,TY2 | 00/1~ | Final Drive PINION |
| 03905 5594 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK FY FY50J TX157 | 00/1~03/ | Final Drive PINION |
| 03905 1121 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FY 8DC9 FY515 | 98/4~00/ | Engine TIMING GEAR CASE |
| 03905 3551 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FY 8DC11 FY519,50K | 96/4~ | Engine TIMING GEAR CASE |
| 03905 5210 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FY 6D24 FY517 | 96/4~00/ | Engine TIMING GEAR CASE |
| 03905 7175 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FY FY50J TX1,TX157,TY2 | 00/1~ | Transmission REAR |
| 03905 5438 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FY 6M70 FY50J,54J | 00/1~ | Engine TIMING GEAR CASE |
| 03905 3362 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FY FY519 TY | 96/4~00/ | Transmission REAR |
| 03905 3011 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK FY 6D24,6D40 | 96/4~97/8 | Engine CRANK SHAFT REAR |
| 03905 3890 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FY 6D24,6D40 | 97/8~00/ | Engine CRANK SHAFT REAR |
| 03905 5615 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FY 8DC9 | 98/4~00/ | Engine CRANK SHAFT REAR |
| 03905 7550 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FY 8DC11 FY519,JXM(FLYWHEEL PTO) | 96/4~00/ | Engine CRANK SHAFT REAR |
| 03905 5474 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FY 8DC11 FY50K | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 2378 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK FY 6M70,8M21 | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 4949 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK FY 8DC11 FY519,NY,NYK,RY,TY | 96/4~00/ | Engine CRANK SHAFT REAR |
| 03905 5807 | ME061574 | | FUSO TRUCK FY 8DC9,8DC11,6D24 | 96/4~ | Engine VALVE STEM SEAL |
| 03905 3494 | ME120154 | | FUSO TRUCK FY 6D40,6M70,8M21 | 96/4~ | Engine VALVE STEM SEAL |
| 03905 2114 | ME030124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK FY 6D40 FY510 | 96/4~00/ | Engine TIMING GEAR CASE |
| 03905 1052 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FY FY519 TY | 96/4~00/ | Transmission FRONT |
| 03905 6425 | MH034092 | 130 x 150 x 14 | FUSO TRUCK FY FY5# | 96/4~ | Wheel Hub REAR INNER |
| 03905 3056 | MH034175 | 130 x 146 x 14 | FUSO TRUCK FY FY5# | 98/4~ | Wheel Hub REAR INNER |
| 03905 1952 | MH034193 | 57 x 124 x 14.5 x 27 | FUSO TRUCK FY FY5# | 96/4~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2069 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FY FY515 | 98/4~00/ | Transmission FRONT |
| 03905 4145 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FY FY517 NX1,TX1 | 96/4~00/ | Transmission FRONT |
| 03905 8801 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FY FY519 JXM,NY,NYK,RY | 96/4~00/ | Transmission FRONT |
| 03905 5219 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FY FY50J NX1 | 00/1~ | Transmission FRONT |
| 03905 6413 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FY FY50K | 00/1~ | Transmission FRONT |
| 03905 8516 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FY FY50M TY1 | 00/1~ | Transmission REAR |
| 03905 8819 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FY FY510 | 96/4~00/ | Transmission FRONT |
| 03905 4739 | MH034180 | 139 x 158 x 11 | FUSO TRUCK FY FY5# | 96/4~ | Wheel Hub FRONT |
| 03905 5453 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FY FY50M NY132,TY1 | 00/1~ | Transmission FRONT |
| 03905 3530 | MH034233 | 57 x 70 x 9 | FUSO TRUCK FY FY54J | 00/1~ | Transmission FRONT |
| 03905 7697 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FY FY515 | 98/4~00/ | Transmission REAR |
| 03905 7856 | MH034153 | 70 x 92 x 12 | FUSO TRUCK FY FY50K | 00/1~ | Transmission REAR |
| 03905 1154 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FY FY517 NX1,TX1 | 96/4~00/ | Transmission REAR |
| 03905 6101 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FY FY519 JXM,NY,NYK,RY | 96/4~00/ | Transmission REAR |
| 03905 2960 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FY FY50J NX1,RY2 | 00/1~ | Transmission REAR |
| 03905 2588 | MH034155 | 75 x 100 x 13 | FUSO TRUCK FY FY50M NY1,NY132,RY1 | 00/1~ | Transmission REAR |
| 03905 5195 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FY FY510 | 96/4~00/ | Transmission REAR |
| 03905 6620 | MH034234 | 83 x 105 x 13 | FUSO TRUCK FY FY517 TY2 | 96/4~00/ | Transmission REAR |
| 03905 5981 | MH034151 | 52 x 65 x 9 | FUSO TRUCK FY FY50M NY1,RY1 | 00/1~ | Transmission FRONT |
| 03905 2426 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV414 JRK | 90/2~90/10 | Final Drive PINION REARWARD |
| 03905 6113 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK TRACTOR FV 8DC9 EXC. FV415,JRS2#(95.2-) | 83/6~96/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6557 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV410,411,413,416,419,439 | 90/2~99/ | Final Drive PINION REARWARD |
| 03905 4487 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8DC11 FV419,439,509,519,50K | 85/9~ | Engine TIMING GEAR CASE |
| 03905 3248 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 10DC11 FV414 | 89/3~96/ | Engine TIMING GEAR CASE |
| 03905 7253 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 6D22 FV418 | 85/9~90/ | Engine TIMING GEAR CASE |
| 03905 6767 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 6D40 FV410,500,510,540 | 94/11~00/ | Engine TIMING GEAR CASE |
| 03905 3275 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8M20 FV411,501,511 | 91/9~00/ | Engine TIMING GEAR CASE |
| 03905 8699 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8M21 FV412,502,512,50M | 94/11~ | Engine TIMING GEAR CASE |
| 03905 7832 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8M22 FV513,50L | 96/7~ | Engine TIMING GEAR CASE |
| 03905 3509 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 10M20 FV424,514 | 95/2~00/ | Engine TIMING GEAR CASE |
| 03905 4682 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 10M21 FV50N | 00/1~ | Engine TIMING GEAR CASE |
| 03905 1769 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 6M70 FV50J,54J | 00/1~ | Engine TIMING GEAR CASE |
| 03905 2147 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK TRACTOR FV 8DC# | 74/~79/ | Engine CRANK SHAFT REAR |
| 03905 2777 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8DC9 FV415,505,515 | 85/9~00/ | Engine TIMING GEAR CASE |
| 03905 6206 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK TRACTOR FV 8DC#,6D2# | 79/10~96/ | Engine CRANK SHAFT REAR |
| 03905 6503 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8DC8 FV413 | 85/9~95/ | Engine TIMING GEAR CASE |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7619 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK TRACTOR FV 8DC11 EXC. FV419,PZ,RZ,TZ(94.11-) | 85/9~95/4 | Engine CRANK SHAFT REAR |
| 03905 5570 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK TRACTOR FV 10DC11 | 89/3~97/8 | Engine CRANK SHAFT REAR |
| 03905 4397 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK TRACTOR FV 8M20,8M21,8M22 | 91/9~97/8 | Engine CRANK SHAFT REAR |
| 03905 3710 | 31212-33300 | 135 x 155.5 x 15 | FUSO TRUCK TRACTOR FV 6D40 | 94/11~97/ 8 | Engine CRANK SHAFT REAR |
| 03905 8900 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK TRACTOR FV 8DC9 FV415,JRS2# | 95/2~96/ | Engine CRANK SHAFT REAR |
| 03905 8990 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK TRACTOR FV 8DC11 EXC. FV419,PZ,RZ,TZ | 95/4~96/ | Engine CRANK SHAFT REAR |
| 03905 6845 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK TRACTOR FV 8DC11 FV419,PZ,RZ,TZ | 94/11~96/ | Engine CRANK SHAFT REAR |
| 03905 8633 | ME093335 | 132 x 171.5 x 13.5 x 22 | FUSO TRUCK TRACTOR FV 8DC9,11 T/M PTO | 96/4~ | Engine CRANK SHAFT REAR |
| 03905 3560 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK TRACTOR FV 8DC9,11 FLY WHEEL PTO | 96/4~ | Engine CRANK SHAFT REAR |
| 03905 3614 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK TRACTOR FV 8M20,8M21,8M22,10M20 ,10M21,6D40 | 97/8~ | Engine CRANK SHAFT REAR |
| 03905 5681 | ME152584 | 132 x 179.5 x 12.5 x 22 | FUSO TRUCK TRACTOR FV 6M70 | 00/1~ | Engine CRANK SHAFT REAR |
| 03905 8366 | ME061574 | | FUSO TRUCK TRACTOR FV 8DV#,6D2# | 79/10~ | Engine VALVE STEM SEAL |
| 03905 6917 | ME120154 | | FUSO TRUCK TRACTOR FV 8M20,21,22,10M20,21,6D 40,6M70 | 91/9~ | Engine VALVE STEM SEAL |
| 03905 4427 | 31112-05701 | 130 x 160 x 14 | FUSO TRUCK TRACTOR FV 6D2# | 76/~79/ | Engine CRANK SHAFT REAR |
| 03905 5783 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV424 | 95/2~97/ | Final Drive PINION REARWARD |
| 03905 4664 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV412 EXC. JRH,JRK,JRN | 94/11~96/ | Final Drive PINION REARWARD |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1079 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV50J JX# | 00/1~ | Wheel Hub FRONT |
| 03905 4475 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV415 EXC. JRS2H,JRS2K#,JRS2N | 90/2~96/ | Final Drive PINION REARWARD |
| 03905 6131 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV500,501,502,509,510,511,519 | 96/4~00/ | Final Drive PINION REARWARD |
| 03905 8882 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV505 JXD(A),JXM(A),MYD(A),MYM(A) | 98/4~00/ | Final Drive PINION REARWARD |
| 03905 2021 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV512 EXC. HRH,HRK | 96/4~99/ | Final Drive PINION REARWARD |
| 03905 1949 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV515 JX(A),JXD,JXM(A),MYA,MYD,MYM(A) | 96/4~00/ | Final Drive PINION REARWARD |
| 03905 2858 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV50J JXD#(EXC.JXD1LA,NA), JXM#,MYD#,MYM# | 00/1~ | Final Drive PINION REARWARD |
| 03905 2975 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV50K EXC. JXDLA,JXDNA | 00/1~ | Final Drive PINION REARWARD |
| 03905 7526 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV50L PYP2,PYP2M | 00/2~ | Final Drive PINION REARWARD |
| 03905 4988 | MC827475 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV54J UZ353 | 00/1~03/3 | Final Drive PINION REARWARD |
| 03905 1658 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV412 JRH,JRK,JRN | 95/2~96/ | Final Drive PINION REARWARD |
| 03905 6347 | ME060124 | 95 x 125 x 13.5 x 21.5 | FUSO TRUCK TRACTOR FV 8DC10 FV416 | 85/9~96/ | Engine TIMING GEAR CASE |
| 03905 2303 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV415 JRS2H,JRS2K#,JRS2N | 90/10~96/ | Final Drive PINION REARWARD |
| 03905 2054 | 12020-59600 | 70 x 142 x 12 x 36 | FUSO TRUCK TRACTOR FV FV4# | 83/7~90/2 | Final Drive PINION REARWARD |
| 03905 3413 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV512 HRH,HRK | 96/7~00/ | Final Drive PINION REARWARD |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4547 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV513,514,540 | 96/7~00/ | Final Drive PINION REARWARD |
| 03905 5348 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV515 HR2H,HR2K,HR2N | 96/4~00/ | Final Drive PINION REARWARD |
| 03905 2210 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV50J TZ3S,TZ4,UZ3#,UZ4# | 00/1~ | Final Drive PINION REARWARD |
| 03905 8207 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV50L HR1#,HR2# | 00/2~ | Final Drive PINION REARWARD |
| 03905 6059 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV50M,50N | 00/2~ | Final Drive PINION REARWARD |
| 03905 5324 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV54J EXC. UZ353 | 00/1~ | Final Drive PINION REARWARD |
| 03905 2015 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK TRACTOR FV FV505 JXA,JXA5E | 98/4~00/ | Final Drive PINION REARWARD |
| 03905 8270 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK TRACTOR FV FV50J JXD1LA,JXD1NA | 00/1~03/3 | Final Drive PINION REARWARD |
| 03905 7838 | MH034178 | 70 x 122 x 12 x 30 | FUSO TRUCK TRACTOR FV FV50K JXDLA,JXDNA | 00/1~03/3 | Final Drive PINION REARWARD |
| 03905 5924 | 31107-06301 | 85 x 110 x 13 | FUSO TRUCK TRACTOR FV 8DC# | 74/~83/ | Engine TIMING GEAR CASE |
| 03905 8081 | ME061853 | 95 x 120 x 13 | FUSO TRUCK TRACTOR FV 8DC8,9,10 FV413,415,416 | 83/6~85/8 | Engine TIMING GEAR CASE |
| 03905 8984 | ME061853 | 95 x 120 x 13 | FUSO TRUCK TRACTOR FV 6D2# | 79/~85/8 | Engine TIMING GEAR CASE |
| 03905 3206 | MH034131 | 80 x 162 x 12 x 41.5 | FUSO TRUCK TRACTOR FV FV414 JRK,JRKQ | 90/10~95/ | Final Drive PINION REARWARD |
| 03905 8411 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV415 HRS#,JDS,JDSQ,PPS,PPS M | 83/6~90/ | Transmission REAR |
| 03905 6785 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV415 JRS2# | 88/9~96/ | Transmission FRONT |
| 03905 7028 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV505 | 98/4~00/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3758 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV515 EXC. HR2H,HR2K,HR2N | 96/4~00/ | Transmission REAR |
| 03905 4286 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV50K HXMS,JXM,JXMA,MYM ,MYMA | 00/1~ | Transmission REAR |
| 03905 1085 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV215 | 80/3~83/ | Transmission REAR |
| 03905 7871 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV315 HR | 79/10~83/ | Transmission REAR |
| 03905 3122 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV413,418 | 83/6~95/ | Transmission REAR |
| 03905 5702 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV412 EXC. PPM,JRH,JRK,JRN | 95/2~96/ | Transmission REAR |
| 03905 4661 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV313,315,318 EXC. HR | 79/10~83/ | Transmission REAR |
| 03905 8837 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV416 | 83/6~95/ | Transmission REAR |
| 03905 8726 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV419 EXC. PPM,HRH,HRK#(90.9~91 .8) | 85/9~99/ | Transmission REAR |
| 03905 5672 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV439 | 91/9~94/ | Transmission REAR |
| 03905 6605 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV501,509 EXC. UZ5C | 98/4~00/ | Transmission REAR |
| 03905 1814 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV502 EXC. PYPM | 98/4~00/ | Transmission REAR |
| 03905 3233 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV512 EXC. HRH,HRK,PYPM | 96/7~00/ | Transmission REAR |
| 03905 2156 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV411 EXC. PPM,HRC#,HRH,HRK | 91/9~96/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6539 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV50L,50M,50N,54J | 00/1~ | Transmission FRONT |
| 03905 2723 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV512,513,514,515,540 HR# | 98/4~00/ | Wheel Hub FRONT |
| 03905 7583 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV419 PPM | 90/9~91/8 | Transmission FRONT |
| 03905 4586 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV419 HRH,HRK# | 90/10~91/ 8 | Transmission FRONT |
| 03905 7247 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV500,501,502,512,514,5 40 | 96/4~00/ | Transmission FRONT |
| 03905 3518 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV509 UZ5C | 98/4~00/ | Transmission FRONT |
| 03905 7001 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV515 HR2# | 96/7~00/ | Transmission FRONT |
| 03905 5384 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV415 JD,JDQ,JM,P,PQ,R,RQ,T, TQ | 83/6~96/ | Transmission REAR |
| 03905 2984 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV50J EXC.JXD#,JXM1 | 00/1~ | Transmission FRONT |
| 03905 1547 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV50K TZS,HXDS,JXD#,MYD | 00/1~ | Transmission REAR |
| 03905 8924 | ME677501 | 55 x 75 x 8 | FUSO TRUCK TRACTOR FV FV513 | 96/7~00/ | Transmission FRONT |
| 03905 7538 | ME655359 | 97 x 110 x 4.5 | FUSO TRUCK TRACTOR FV FV4#,5# | 83/6~ | Transmission MAIN SHAFT |
| 03905 2645 | 44514-46681 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV102,103,112,113 HRA | 74/~79/ | Transmission REAR |
| 03905 2630 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV102,103 EXC. Q,S | 74/~74/12 | Transmission REAR |
| 03905 7889 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV112 | 74/~79/ | Transmission REAR |
| 03905 3986 | MH034153 | 70 x 92 x 12 | FUSO TRUCK TRACTOR FV FV113 EXC. J,JD,JM,N,Q | 74/~79/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7685 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV519 UZA5C,UZ5C | 96/4~99/ | Transmission FRONT |
| 03905 1784 | MH034065 | 70 x 100 x 13 | FUSO TRUCK TRACTOR FV FV112,113,315 | 78/6~83/ | Propeller Shaft CENTER BEARING |
| 03905 2345 | MH034234 | 83 x 105 x 13 | FUSO TRUCK TRACTOR FV FV519 UZA5C,UZ5C | 96/4~99/ | Transmission REAR |
| 03905 4862 | MH034234 | 83 x 105 x 13 | FUSO TRUCK TRACTOR FV FV50J TZ3S,TZ4,UZ3#,UZ4# | 00/1~ | Transmission REAR |
| 03905 2006 | MH034234 | 83 x 105 x 13 | FUSO TRUCK TRACTOR FV FV54J EXC. UZS353 | 00/1~ | Transmission REAR |
| 03905 2507 | ME515135 | 105 x 130 x 12 | FUSO TRUCK TRACTOR FV FV513 | 96/7~00/ | Transmission REAR |
| 03905 8612 | ME515135 | 105 x 130 x 12 | FUSO TRUCK TRACTOR FV FV514 HRK,HRKQ,HRN | 96/7~00/ | Transmission REAR |
| 03905 5051 | MH034245 | 115 x 145 x 13 | FUSO TRUCK TRACTOR FV FV50L HRK#,HR1N# | 00/2~ | Transmission REAR |
| 03905 1595 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV519 EXC. UZA5C,UZ5C | 96/4~00/ | Transmission REAR |
| 03905 5654 | 03437-07052 | 70 x 90 x 10 | FUSO TRUCK TRACTOR FV FV102,103,112,113 | 74/~78/5 | Propeller Shaft CENTER BEARING |
| 03905 3482 | MH034234 | 83 x 105 x 13 | FUSO TRUCK TRACTOR FV FV410 | 94/11~97/ | Transmission REAR |
| 03905 1919 | MH034065 | 70 x 100 x 13 | FUSO TRUCK TRACTOR FV FV4# | 83/7~89/10 | Propeller Shaft CENTER BEARING |
| 03905 3935 | MH034065 | 70 x 100 x 13 | FUSO TRUCK TRACTOR FV FV4#,5# | 89/11~ | Propeller Shaft CENTER BEARING |
| 03905 1043 | MC833624 | 80 x 100 x 13 | FUSO TRUCK TRACTOR FV FV4#,5# | 89/11~ | Propeller Shaft CENTER BEARING |
| 03905 4391 | MH034119 | 84 x 110 x 13 | FUSO TRUCK TRACTOR FV FV4#,5# | 94/11~ | Propeller Shaft CENTER BEARING |
| 03905 3785 | 03434-07051 | 70 x 92 x 13.5 x 20.5 | FUSO TRUCK TRACTOR FV FV# | 74/~76/9 | Final Drive PINION REARWARD |
| 03905 3215 | 12020-39600 | 70 x 132 x 12 x 30 | FUSO TRUCK TRACTOR FV FV1#,2#,3# | 76/9~83/ | Final Drive PINION REARWARD |
| 03905 3446 | MH034245 | 115 x 145 x 13 | FUSO TRUCK TRACTOR FV FV50N | 00/1~ | Transmission REAR |
| 03905 8609 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV512 HRH,HRK,PYPM | 96/7~00/ | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3938 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV411 EXC. TZC21 | 91/9~99/ | Transmission FRONT |
| 03905 6986 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV50L PYP2 | 00/2~ | Transmission REAR |
| 03905 8690 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV411 PPM,HRC#,HRH,HRK | 91/9~96/ | Transmission REAR |
| 03905 7400 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV412 PPM,JRH,JRK,JRN | 95/2~96/ | Transmission REAR |
| 03905 5015 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV414,424 | 89/3~95/ | Transmission REAR |
| 03905 8531 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV415 JRS2# | 88/9~96/ | Transmission REAR |
| 03905 8456 | MH034234 | 83 x 105 x 13 | FUSO TRUCK TRACTOR FV FV501,509 UZ5C | 98/4~00/ | Transmission REAR |
| 03905 7418 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV502 PYPM | 98/4~00/ | Transmission REAR |
| 03905 1436 | MH034234 | 83 x 105 x 13 | FUSO TRUCK TRACTOR FV FV500,540 | 98/4~00/ | Transmission REAR |
| 03905 7463 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV514 HRKQ52,HRK52,HRN52 | 96/7~00/ | Transmission REAR |
| 03905 7121 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV515 HR2H,HR2K,HR2N | 96/7~00/ | Transmission REAR |
| 03905 6173 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV50L HR2H,HR2K,HR2N,PYP2 M | 00/2~ | Transmission REAR |
| 03905 7286 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV50M | 00/1~ | Transmission REAR |
| 03905 7250 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV54J UZ353 | 00/1~ | Transmission REAR |
| 03905 4799 | MH034102 | 85 x 110 x 13 | FUSO TRUCK TRACTOR FV FV415 JRS2H,JPS2K | 85/9~88/8 | Transmission REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2717 | MH034155 | 75 x 100 x 13 | FUSO TRUCK TRACTOR FV FV50J JXD#,JXM#,MYM#,MYD #,PY4,SY4 | 00/1~ | Transmission REAR |
| 03905 8651 | MH034157 | 80 x 105 x 13 | FUSO TRUCK TRACTOR FV FV419 PPM,HRH,HRK# | 90/9~91/8 | Transmission REAR |
| 03905 7571 | MH034082 | 155 x 180 x 17 | FUSO TRUCK TRACTOR FV FV1#,2#,3# | 74/~83/ | Wheel Hub REAR INNER (F & R) |
| 03905 7994 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV415 HRS7# | 90/10~95/ | Transmission FRONT |
| 03905 6437 | MH034180 | 139 x 158 x 11 | FUSO TRUCK TRACTOR FV FV510,511,512,515,519 MY#,PY#,SY#,TZ#,UZ# | 98/4~00/ | Wheel Hub FRONT |
| 03905 6266 | MH034180 | 139 x 158 x 11 | FUSO TRUCK TRACTOR FV FV50J,50K,50L,50M,54J MY#,PY#,SY#,TZ#,UZ# | 00/1~ | Wheel Hub FRONT |
| 03905 6020 | MH034089 | 134 x 152 x 11 | FUSO TRUCK TRACTOR FV FV412 EXCEPT JRN | 94/11~97/ | Wheel Hub FRONT |
| 03905 5819 | MH034089 | 134 x 152 x 11 | FUSO TRUCK TRACTOR FV FV415 JRS2N | 89/11~97/ | Wheel Hub FRONT |
| 03905 8582 | MH034089 | 134 x 152 x 11 | FUSO TRUCK TRACTOR FV FV424 JRS2N | 95/2~97/ | Wheel Hub FRONT |
| 03905 4604 | MH034180 | 139 x 158 x 11 | FUSO TRUCK TRACTOR FV FV500 | 98/4~00/ | Wheel Hub FRONT |
| 03905 5450 | 06015-13400 | 184 x 215 x 18 | FUSO TRUCK TRACTOR FV FV50M NW1,JP3W | 00/1~ | Wheel Hub FRONT |
| 03905 7505 | MH034180 | 139 x 158 x 11 | FUSO TRUCK TRACTOR FV FV419 TZ# | 89/11~99/ | Wheel Hub FRONT |
| 03905 3833 | MC807438 | 154 x 172 x 14 | FUSO TRUCK TRACTOR FV FV4# | 83/7~ | Wheel Hub REAR INNER (F & R) |
| 03905 8840 | MH034084 | 160 x 182 x 17 | FUSO TRUCK TRACTOR FV FV439 | 91/9~94/ | Wheel Hub REAR INNER (F & R) |
| 03905 3749 | 16421-02101 | 184 x 210 x 15 | FUSO TRUCK TRACTOR FV FV50M JR3W | 00/1~ | Wheel Hub REAR INNER (F & R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 8018 | MH034134 | 60 x 72 x 12 | FUSO TRUCK TRACTOR FV FV1#,2#,3# | 74/~83/ | Wheel Hub REAR OUTER (F & R) |
| 03905 7274 | MH034134 | 60 x 72 x 12 | FUSO TRUCK TRACTOR FV FV4#...EXC.412(JR#),414, 415(JRS2#),424,439 | 83/6~97/ | Wheel Hub REAR OUTER (F & R) |
| 03905 1592 | MH034134 | 60 x 72 x 12 | FUSO TRUCK TRACTOR FV FV5#...EXC.512,513,514, 515 HR# | 96/4~00/ | Wheel Hub REAR OUTER (F & R) |
| 03905 8762 | MH034089 | 134 x 152 x 11 | FUSO TRUCK TRACTOR FV FV439 | 91/9~94/ | Wheel Hub FRONT |
| 03905 8528 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV509 JX#,PX#,SX#,UX# | 98/4~00/ | Wheel Hub FRONT |
| 03905 5369 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV410 TS# | 94/11~97/ | Wheel Hub FRONT |
| 03905 5495 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV411 EXCEPT TZ# | 94/11~99/ | Wheel Hub FRONT |
| 03905 1805 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV412 EXCEPT TZ#,JRN | 94/11~97/ | Wheel Hub FRONT |
| 03905 4358 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV413,414,416 ALL | 89/11~96/ | Wheel Hub FRONT |
| 03905 2594 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV415 EXC. JRS2N | 89/11~97/ | Wheel Hub FRONT |
| 03905 5261 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV419 EXC. TZ# | 89/11~99/ | Wheel Hub FRONT |
| 03905 3542 | MH034180 | 139 x 158 x 11 | FUSO TRUCK TRACTOR FV FV501,502,505,509 MY#,PY#,SY#,TZ#,UZ# | 98/4~00/ | Wheel Hub FRONT |
| 03905 6275 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV501,502,505,507 JX# | 98/4~00/ | Wheel Hub FRONT |
| 03905 5813 | MH034135 | 65 x 77 x 12 | FUSO TRUCK TRACTOR FV FV512,513,514,515 HR# | 96/4~00/ | Wheel Hub REAR OUTER (F & R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2297 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV511,512,515 JX# | 98/4~00/ | Wheel Hub FRONT |
| 03905 7349 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV519 JX#,PX#,SX#,UX# | 98/4~00/ | Wheel Hub FRONT |
| 03905 5363 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV50K HX#,JX# | 00/1~ | Wheel Hub FRONT |
| 03905 5126 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV50L,50M,50N,54J HR# | 00/1~ | Wheel Hub FRONT |
| 03905 3974 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV50M JX#,PX#,SX#,UX# | 00/1~ | Wheel Hub FRONT |
| 03905 1016 | MH034180 | 139 x 158 x 11 | FUSO TRUCK TRACTOR FV FV410,411,412 TZ# | 94/11~99/ | Wheel Hub FRONT |
| 03905 4496 | MH034136 | 130 x 150 x 12 | FUSO TRUCK TRACTOR FV FV424 JRS2K# | 95/2~97/ | Wheel Hub FRONT |
| 03905 8579 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV505 | 98/4~00/ | Transmission FRONT |
| 03905 3437 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV102,103,112,113,315 HRA | 74/~83/ | Transmission FRONT |
| 03905 2903 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV103 Q,S | 74/1~74/12 | Transmission FRONT |
| 03905 2735 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV113 J,JD,JM,N,Q | 74/~79/ | Transmission FRONT |
| 03905 1100 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV214,215,313,315,318 | 76/~83/ | Transmission FRONT |
| 03905 7391 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV413,416,418,439 | 83/6~96/ | Transmission FRONT |
| 03905 2333 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV411 TZC21 | 94/11~97/ | Transmission FRONT |
| 03905 4160 | MH034134 | 60 x 72 x 12 | FUSO TRUCK TRACTOR FV FV5#...EXC.50L,50M,50N HR#,50M NW1,JR3W | 00/1~ | Wheel Hub REAR OUTER (F & R) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4259 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV419 EXC.PPM(90.0~91.8),HRH,HRK#(90.10~91.8) | 85/9~99/ | Transmission FRONT |
| 03905 7607 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK TRACTOR FV FV102,103(EXCEPT Q,S) | 74/1~74/12 | Transmission FRONT |
| 03905 3587 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV509 EXC. UZ5C | 98/4~00/ | Transmission FRONT |
| 03905 6659 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV515 EXC. HR2# | 96/4~00/ | Transmission FRONT |
| 03905 5090 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV519 EXC. UZA5C,UZ5C | 96/4~99/ | Transmission FRONT |
| 03905 7106 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV50J JXD1#,JXM1 | 00/1~ | Transmission FRONT |
| 03905 2822 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV50K | 00/1~ | Transmission FRONT |
| 03905 1955 | MH034233 | 57 x 70 x 9 | FUSO TRUCK TRACTOR FV FV410,412,414,424 | 89/3~97/ | Transmission FRONT |
| 03905 7589 | MH034151 | 52 x 65 x 9 | FUSO TRUCK TRACTOR FV FV415 EXC.JRS2#(88.9-),HRS7#(90.10-) | 83/6~97/ | Transmission FRONT |
| 03905 4493 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK TRACTOR FV FV50N,50M | 00/1~ | Rear Suspesion TRUNNION |
| 03905 6881 | MH034092 | 130 x 150 x 14 | FUSO TRUCK TRACTOR FV FV1#,2#,3#,4# | 74/~89/10 | Wheel Hub FRONT |
| 03905 8693 | MH034135 | 65 x 77 x 12 | FUSO TRUCK TRACTOR FV FV50L,50M,50N HR#,FV50M NW1 | 00/1~ | Wheel Hub REAR OUTER (F & R) |
| 03905 4043 | MT141132 | 50 x 65 x 9 | FUSO TRUCK TRACTOR FV FV50M JR3W | 00/1~ | Wheel Hub REAR OUTER (F & R) |
| 03905 8306 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK TRACTOR FV FV4# | 83/6~96/2 | Rear Suspesion TRUNNION |
| 03905 7664 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK TRACTOR FV FV512 HRH,HRK | 96/7~00/ | Rear Suspesion TRUNNION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1367 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK TRACTOR FV FV513,514 | 96/7~00/ | Rear Suspesion TRUNNION |
| 03905 4946 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK TRACTOR FV FV113 EXCEPT J,JD,JM,N,Q | 74/~79/ | Transmission FRONT |
| 03905 5942 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK TRACTOR FV FV50L HR1#,HR2# | 00/1~ | Rear Suspesion TRUNNION |
| 03905 6794 | 44514-51681 | 45 x 60 x 9 | FUSO TRUCK TRACTOR FV FV112,119 | 74/~79/ | Transmission FRONT |
| 03905 5741 | MC095475 | 154 x 185 x 19 | FUSO TRUCK TRACTOR FV FV410,411,412,419 | 96/3~99/ | Rear Suspesion TRUNNION |
| 03905 7130 | MC095475 | 154 x 185 x 19 | FUSO TRUCK TRACTOR FV FV500,501,502,505,509,510,511,519 | 96/4~00/ | Rear Suspesion TRUNNION |
| 03905 6218 | MC095475 | 154 x 185 x 19 | FUSO TRUCK TRACTOR FV FV512 EXC. HRH,HRK | 96/7~00/ | Rear Suspesion TRUNNION |
| 03905 2408 | MC095475 | 154 x 185 x 19 | FUSO TRUCK TRACTOR FV FV515 EXC. HR2# | 96/4~00/ | Rear Suspesion TRUNNION |
| 03905 4667 | MC095475 | 154 x 185 x 19 | FUSO TRUCK TRACTOR FV FV50J,50K | 00/1~ | Rear Suspesion TRUNNION |
| 03905 1637 | MC095475 | 154 x 185 x 19 | FUSO TRUCK TRACTOR FV FV50L PYP2# | 00/1~ | Rear Suspesion TRUNNION |
| 03905 5597 | MH034135 | 65 x 77 x 12 | FUSO TRUCK TRACTOR FV FV412(JR#),414,415(JRS2#),424,439 | 85/9~97/ | Wheel Hub REAR OUTER (F & R) |
| 03905 8723 | 12857-16700 | 165 x 195 x 19 | FUSO TRUCK TRACTOR FV FV515 HR2# | 96/4~00/ | Rear Suspesion TRUNNION |
| 03905 2663 | MD009038 | 17 x 28 x 7 | GALANT (FWD) G32,G37B,4G32,4G37 | 83/8~92/ | Engine OIL PUMP |
| 03905 5543 | MD008762 | 35 x 50 x 8 | GALANT (FWD) G62B,G63B E13,15 | 83/8~87/ | Engine CAM SHAFT |
| 03905 5339 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4G94 EA7A,EC7A | 00/5~ | Engine CAM SHAFT |
| 03905 1991 | MD151463 | 28 x 40 x 8 | GALANT (FWD) G32B,G37B,4G32,4G37 | 83/8~92/ | Engine BLANCER SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6080 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4D68 E57,77 | 92/2~96/ | Engine CAM SHAFT |
| 03905 8864 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4D65 E14,34 | 84/3~93/ | Engine CAM SHAFT |
| 03905 7679 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 6A13 EC5A | 96/8~02/ | Engine CAM SHAFT |
| 03905 6251 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 6A11,6A12 E53,54,64,84 | 92/2~96/ | Engine CAM SHAFT |
| 03905 3680 | MD050608 | 25 x 35 x 6 | GALANT (FWD) G62B,G63B,4G63,4G67,4G64,4D65,4D68 | 83/8~02/ | Engine BLANCER SHAFT |
| 03905 6119 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4G93 E52,72,EA1,EC1 | 92/2~00/ | Engine CAM SHAFT |
| 03905 6716 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 6G71 E17 | 86/10~90/ | Engine CAM SHAFT |
| 03905 7688 | MD009038 | 17 x 28 x 7 | GALANT (FWD) G62B,G63B,4D65 | 83/8~85/4 | Engine OIL PUMP |
| 03905 8756 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4G63,4G67 E33,35,38,39 | 87/9~92/ | Engine CAM SHAFT |
| 03905 5045 | MD008882 | 44 x 60 x 7 | GALANT (FWD) 4D65,4D68 | 84/3~96/ | Engine CRANK SHAFT FRONT |
| 03905 4868 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4G32,4G37 E31,32,37 | 87/8~92/ | Engine CAM SHAFT |
| 03905 8021 | MD008762 | 35 x 50 x 8 | GALANT (FWD) G32B,G37B E11,12 | 83/8~87/ | Engine CAM SHAFT |
| 03905 2891 | MR961021 | | GALANT (FWD) EA7,EC7 EXC. PRGC8,SRGC8 | 00/5~ | Power Steering SEAL KIT |
| 03905 7943 | MR961021 | | GALANT (FWD) EA1,EC1 | 97/7~00/ | Power Steering SEAL KIT |
| 03905 6773 | MB333879 | | GALANT (FWD) EA1,EC1 | 96/9~97/6 | Power Steering SEAL KIT |
| 03905 1391 | MR961024 | | GALANT (FWD) EA7,EC7 PRGC8,SRGC8 | 02/8~ | Power Steering SEAL KIT |
| 03905 1352 | MD008762 | 35 x 50 x 8 | GALANT (FWD) 4G64 EA3A,EC3A | 98/8~02/ | Engine CAM SHAFT |
| 03905 1994 | MD359158 | 85 x 103 x 7.5 | GALANT (FWD) 4D68 | 92/3~96/ | Engine CRANK SHAFT REAR |
| 03905 4730 | MR961024 | | GALANT (FWD) EA3,EC3,EC5 | 96/8~02/ | Power Steering SEAL KIT |
| 03905 7085 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E15 SNHG,SRHG | 84/5~84/9 | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7280 | MD307343 | | GALANT (FWD) 4G64 IN. | 98/8~99/7 | Engine VALVE STEM SEAL |
| 03905 7709 | MD184303 | | GALANT (FWD) 6A13 IN. | 96/8~02/ | Engine VALVE STEM SEAL |
| 03905 8759 | MD184303 | | GALANT (FWD) 4G93,4G94 IN. & EX. | 96/8~ | Engine VALVE STEM SEAL |
| 03905 7754 | MD307343 | | GALANT (FWD) 4G64 EX. | 98/8~02/ | Engine VALVE STEM SEAL |
| 03905 8717 | MD307343 | | GALANT (FWD) 4G63,4G67 | 87/8~92/ | Engine VALVE STEM SEAL |
| 03905 8948 | MD306079 | | GALANT (FWD) 4G64 IN. | 99/7~02/ | Engine VALVE STEM SEAL |
| 03905 3257 | MD008882 | 44 x 60 x 7 | GALANT (FWD) G32B,G37B,4G32,4G37 | 83/8~92/ | Engine CRANK SHAFT FRONT |
| 03905 2087 | MD359158 | 85 x 103 x 7.5 | GALANT (FWD) 4G64,4G93,4G94,6A13 | 96/8~ | Engine CRANK SHAFT REAR |
| 03905 1958 | MD168057 | 20 x 30 x 7 x 7.5 | GALANT (FWD) G62B,G63B | 85/5~87/ | Engine OIL PUMP |
| 03905 2462 | MD150161 | 85 x 103 x 8 | GALANT (FWD) 4G93,6A11,6A12 | 92/3~96/ | Engine CRANK SHAFT REAR |
| 03905 4151 | MD101915 | 91 x 111 x 9 | GALANT (FWD) 6G71 | 86/10~90/ | Engine CRANK SHAFT REAR |
| 03905 8657 | MD069947 | 80 x 96 x 9 | GALANT (FWD) G62B,G63B,4G63,4G67,4D65,4D68 | 83/8~96/ | Engine CRANK SHAFT REAR |
| 03905 1160 | MD016549 | 72 x 96 x 9 | GALANT (FWD) G32B,G37B,4G32,4G37 | 83/8~92/ | Engine CRANK SHAFT REAR |
| 03905 6383 | MD168055 | 37 x 50 x 6 | GALANT (FWD) 4G93,4G94,6A11,6A12,6A13 | 92/2~ | Engine CRANK SHAFT FRONT |
| 03905 2012 | MD168055 | 37 x 50 x 6 | GALANT (FWD) 6G71 | 86/10~90/ | Engine CRANK SHAFT FRONT |
| 03905 7850 | MD008882 | 44 x 60 x 7 | GALANT (FWD) G62B,G63B,4G63,4G64,4G67 | 83/8~02/ | Engine CRANK SHAFT FRONT |
| 03905 8297 | MD095355 | 20 x 30 x 7 | GALANT (FWD) 4G63,4G64,4G67 | 87/8~02/ | Engine OIL PUMP |
| 03905 8588 | MD095355 | 20 x 30 x 7 | GALANT (FWD) 4D65,4D68 | 85/5~96/ | Engine OIL PUMP |
| 03905 7427 | MD000508 | | GALANT (FWD) G32B,G37B,4G63,4G63,4G67,4D65,4D68 | 83/8~96/ | Engine VALVE STEM SEAL |
| 03905 6719 | MB303867 | 50 x 82 x 8 x 11 | GALANT (FWD) E15 REAR DISC BRAKE | 84/10~85/12 | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2732 | MB303875 | 52 x 72 x 8 x 11 | GALANT (FWD) E15 REAR DISC BRAKE | 84/10~85/ 12 | Wheel Hub FRONT OUTER |
| 03905 2561 | MB303875 | 52 x 72 x 8 x 11 | GALANT (FWD) E15 EXCEPT SNHG,SRHG | 84/7~84/9 | Wheel Hub FRONT OUTER |
| 03905 4007 | MB303875 | 52 x 72 x 8 x 11 | GALANT (FWD) E13 | 84/10~87/ | Wheel Hub FRONT OUTER |
| 03905 7727 | MB303866 | 50 x 72 x 8 x 11 | GALANT (FWD) E15 EXCEPT SNHG,SRHG | 84/5~84/7 | Wheel Hub FRONT OUTER |
| 03905 7292 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E15 REAR DRUM BRAKE | 84/10~85/ 12 | Wheel Hub FRONT OUTER |
| 03905 1721 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E15 | 83/8~84/4 | Wheel Hub FRONT OUTER |
| 03905 8153 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E13 | 83/8~84/9 | Wheel Hub FRONT OUTER |
| 03905 2801 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E11,12,14 | 83/8~87/ | Wheel Hub FRONT OUTER |
| 03905 1433 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E31,34 | 87/8~93/ | Wheel Hub FRONT INNER |
| 03905 8945 | MB303867 | 50 x 82 x 8 x 11 | GALANT (FWD) E15 ALL | 86/1~87/ | Wheel Hub FRONT INNER |
| 03905 4187 | MD050608 | 25 x 35 x 6 | GALANT (FWD) MT ALL | 83/8~91/8 | Mission & Differential (M/T) INPUT SHAFT |
| 03905 7961 | MB303867 | 50 x 82 x 8 x 11 | GALANT (FWD) E15 EXCEPT SNHG,SRHG | 84/5~84/9 | Wheel Hub FRONT INNER |
| 03905 1838 | MB303867 | 50 x 82 x 8 x 11 | GALANT (FWD) E13 | 84/10~87/ | Wheel Hub FRONT INNER |
| 03905 1418 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E15 REAR DRUM BRAKE | 84/10~85/ 12 | Wheel Hub FRONT INNER |
| 03905 5111 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E15 | 83/8~84/4 | Wheel Hub FRONT INNER |
| 03905 8522 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E13 | 83/8~84/9 | Wheel Hub FRONT INNER |
| 03905 2198 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E11,12,14 | 83/8~87/ | Wheel Hub FRONT INNER |
| 03905 1514 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E31,34 | 87/8~93/ | Wheel Hub FRONT OUTER |
| 03905 5120 | MD302338 | | GALANT (FWD) 6A13 EX. | 96/8~02/ | Engine VALVE STEM SEAL |
| 03905 3674 | MB573309 | 54 x 82 x 8 x 11 | GALANT (FWD) E32,33,35,37,38,39 | 87/9~92/ | Wheel Hub FRONT INNER |
| 03905 7820 | MD755904 | 41 x 61 x 9 x 13.5 | GALANT (FWD) EC1A(4WD) AT | 96/11~96/ 11 | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH&LH) |
| 03905 3071 | MB949358 | | GALANT (FWD) E54A #XM | 92/2~94/ | Power Steering SEAL KIT |
| 03905 4256 | MB941351 | | GALANT (FWD) E52A,53A,54A*,57A,72A, 74A,77A | 92/2~96/ | Power Steering SEAL KIT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5489 | MB815189 | | GALANT (FWD) E39A | 87/9~92/ | Power Steering SEAL KIT |
| 03905 5093 | MB815188 | | GALANT (FWD) E33A,35 EPS | 87/8~92/ | Power Steering SEAL KIT |
| 03905 1202 | MB682006R | | GALANT (FWD) E31A,32A,33A(EXC. EPS),34A,35A(EXC. EPS),37A,38A | 87/8~92/ | Power Steering SEAL KIT |
| 03905 6245 | MB393929 | 35 x 65 x 12 | GALANT (FWD) EC1A,3A,5A,7A | 96/8~ | Mission & Differential (M/T&A/T) REAR DRIVE PINION |
| 03905 3272 | MD707184 | 35 x 56 x 9 x 12 | GALANT (FWD) EC1A,3A,5A,7A | 96/8~ | Mission & Differential (M/T&A/T) REAR DIFF. SIDE |
| 03905 2711 | MD707575 | 42 x 60 x 9 | GALANT (FWD) E#,EA#,EC# | 83/8~ | Mission & Differential (M/T&A/T) CONVERTER OIL PUMP |
| 03905 1067 | MB303875 | 52 x 72 x 8 x 11 | GALANT (FWD) E15 ALL | 86/1~87/ | Wheel Hub FRONT OUTER |
| 03905 6056 | MD758763 | 41 x 61 x 11.5 x 16 | GALANT (FWD) EC1A(4WD) AT | 96/12~00/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH&LH) |
| 03905 3395 | MB303875 | 52 x 72 x 8 x 11 | GALANT (FWD) E32,33,35,37,38,39 | 87/9~92/ | Wheel Hub FRONT OUTER |
| 03905 6380 | MD755904 | 41 x 61 x 9 x 13.5 | GALANT (FWD) EC1A(4WD) MT | 96/11~00/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH&LH) |
| 03905 3992 | MD755904 | 41 x 61 x 9 x 13.5 | GALANT (FWD) EA1A,3A,7A(2WD) | 96/8~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH&LH) |
| 03905 5072 | MD719710 | 35 x 54 x 10 x 17 | GALANT (FWD) 4WD ALL | 88/2~96/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 6671 | MD707184 | 35 x 56 x 9 x 12 | GALANT (FWD) 2WD ALL | 83/8~96/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 1868 | MD707184 | 35 x 56 x 9 x 12 | GALANT (FWD) 2WD,4WD ALL | 83/8~96/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 7208 | MB936826 | 30 x 45 x 6.5 | GALANT (FWD) EC5A | 86/8~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 2795 | MD741818 | 25 x 35 x 6 | GALANT (FWD) EA1A,EC1A | 86/8~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 1328 | MD741818 | 25 x 35 x 6 | GALANT (FWD) MT ALL | 91/8~96/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 1877 | MR961024 | | GALANT (FWD) EA1 | 96/8~96/9 | Power Steering SEAL KIT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1697 | MD758763 | 41 x 61 x 11.5 x 16 | GALANT (FWD) EC3A,5A,7A(4WD) | 96/8~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH&LH) |
| 03905 3617 | MB176746 | 50 x 66.5 x 13 x 16 | GALANT (FWD) E15 SNHG,SRHG | 84/5~84/9 | Wheel Hub FRONT OUTER |
| 03905 8183 | MA181498 | 51 x 65 x 9 | GALANT (RWD) A16#,EXCEPT A164A,166 | 80/2~84/ | Wheel Hub REAR |
| 03905 6029 | MD703743 | 36 x 52 x 10 | GALANT (RWD) A161(PB),164(TURBO),167A,168V | 80/2~84/ | Transmission REAR |
| 03905 4553 | MD701430 | 32 x 48 x 10 | GALANT (RWD) A162(EXCEPTPB),162A,163A,164A,(WITHOUT TURBO) | 80/2~84/ | Transmission REAR |
| 03905 7982 | MD723202 | 30 x 45 x 6 | GALANT (RWD) A161(PB),163A,164A,167A,163V,168V | 80/2~84/ | Transmission FRONT |
| 03905 6074 | MD050608 | 25 x 35 x 6 | GALANT (RWD) A161A(EXCEPT PB),161V,162A | 80/2~84/ | Transmission FRONT |
| 03905 4691 | MD050608 | 25 x 35 x 6 | GALANT (RWD) A12#,13# | 76/4~80/ | Transmission FRONT |
| 03905 1634 | MB393929 | 35 x 65 x 12 | GALANT (RWD) A121A,122A,123A,131A,132A,133A | 76/4~80/ | Final Drive PINION |
| 03905 5855 | MB800115 | 41 x 55 x 9 | GALANT (RWD) A131A | 77/6~80/ | Wheel Hub REAR |
| 03905 3689 | MD701430 | 32 x 48 x 10 | GALANT (RWD) A161V,163V | 80/2~84/ | Transmission REAR |
| 03905 3242 | MA181498 | 51 x 65 x 9 | GALANT (RWD) A12#,13#...EXCEPT A131A | 76/4~80/ | Wheel Hub REAR |
| 03905 3146 | MB584745 | 45 x 62 x 6 | GALANT (RWD) A163A,164A,166A,167A | 80/2~83/ | Wheel Hub FRONT |
| 03905 1169 | MB584745 | 45 x 62 x 6 | GALANT (RWD) A1331(EXCEPT CNJ),135A | 77/11~80/ | Wheel Hub FRONT |
| 03905 2519 | MA125844 | 38 x 52 x 6 | GALANT (RWD) A161,162,161V,163V,168V | 80/2~84/ | Wheel Hub FRONT |
| 03905 4568 | MA125844 | 38 x 52 x 6 | GALANT (RWD) A12#,A131A,132A,133A(CNJ) | 76/4~80/ | Wheel Hub FRONT |
| 03905 4982 | MB092186 | 40 x 65 x 10 | GALANT (RWD) A164A,166A | 80/2~83/ | Wheel Hub REAR |
| 03905 1886 | MD008882 | 44 x 60 x 7 | GALANT (RWD) G3B,G6B,4D5 | 76/5~84/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7328 | MD000508 | | GALANT (RWD) G5B,G6B,4D5 | 76/5~84/ | Engine VALVE STEM SEAL |
| 03905 7478 | MD069947 | 80 x 96 x 9 | GALANT (RWD) G5B,G6B,4D5 | 80/5~84/ | Engine CRANK SHAFT REAR |
| 03905 2192 | MD020240 | 80 x 96 x 9 | GALANT (RWD) G5B | 76/4~80/ | Engine CRANK SHAFT REAR |
| 03905 4952 | MD701430 | 32 x 48 x 10 | GALANT (RWD) A12#,13# | 76/4~80/ | Transmission REAR |
| 03905 6377 | MD020308 | 48 x 68 x 11 | GALANT (RWD) G5B A122,123,132,133,135,166 | 76/4~81/ | Engine CRANK SHAFT FRONT |
| 03905 5999 | MB393929 | 35 x 65 x 12 | GALANT (RWD) A161A(EXCEPT PB),162A,163A | 80/2~84/ | Final Drive PINION |
| 03905 5732 | MD009038 | 17 x 28 x 7 | GALANT (RWD) G3B,G6B,4D5 | 76/5~84/ | Engine OIL PUMP |
| 03905 8459 | MD050608 | 25 x 35 x 6 | GALANT (RWD) G6B,4D5 | 80/2~84/ | Engine BALANCER SHAFT |
| 03905 5399 | MB092145 | 42 x 65 x 12 | GALANT (RWD) A121V,123V,135A | 77/11~80/ | Final Drive PINION |
| 03905 4790 | MD008762 | 35 x 50 x 8 | GALANT (RWD) 4D5 A167 | 80/2~83/ | Engine CAM SHAFT |
| 03905 8648 | MD008762 | 35 x 50 x 8 | GALANT (RWD) G6B A162,163,164,168 | 80/2~84/ | Engine CAM SHAFT |
| 03905 1757 | MD008762 | 35 x 50 x 8 | GALANT (RWD) G3B A121,131,161 | 76/4~84/ | Engine CAM SHAFT |
| 03905 6581 | MB092145 | 42 x 65 x 12 | GALANT (RWD) A161(PB),164A,166A,167 A,161V,163V,168V | 80/2~84/ | Final Drive PINION |
| 03905 2285 | MD151463 | 28 x 40 x 8 | GALANT (RWD) G3B | 76/4~84/ | Engine BALANCER SHAFT |
| 03905 3893 | MD016549 | 72 x 96 x 9 | GALANT (RWD) G3B | 76/5~84/ | Engine CRANK SHAFT REAR |
| 03905 2849 | MB569925 | 42 x 92 x 12.5 x 19.2 | GTO Z15A,16A 6F | 90/9~00/ | Mission & Differential (A/T) REAR DIFF. SIDE |
| 03905 2363 | MD152603 | 30 x 42 x 8 x 8.4 | GTO Z15A,16A(6G72) EXC.MJGF9 | 90/9~00/ | Engine CAM SHAFT |
| 03905 6497 | MD177097 | 30 x 42 x 8 | GTO Z15A,16A(6G72) MJGF9 | 92/10~97/ | Engine CAM SHAFT |
| 03905 4607 | MD120700 | 37 x 50 x 6 | GTO Z15A,16A(6G72) | 90/9~00/ | Engine CRANK SHAFT FRONT |
| 03905 8825 | MD120699 | 91 x 111 x 9 | GTO Z15A,16A(6G72) | 90/9~00/2 | Engine CRANK SHAFT REAR |
| 03905 3947 | MD306079 | | GTO 6G72 IN. | 90/9~00/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4826 | MD307343 | | GTO 6G72 EX. | 90/9~00/ | Engine VALVE STEM SEAL |
| 03905 5462 | MD707184 | 35 x 56 x 9 x 12 | GTO Z15A,16A ATM,5F | 90/9~00/ | Mission & Differential (A/T) REAR DIFF. SIDE |
| 03905 3839 | MD372251 | 91 x 111 x 7.5 | GTO Z15A,16A(6G72) | 00/3~00/ | Engine CRANK SHAFT REAR |
| 03905 3152 | MB393807 | 36 x 64 x 11 x 19 | GTO Z15A,16A | 90/9~00/ | Wheel Hub REAR |
| 03905 8483 | MB393929 | 35 x 65 x 12 | GTO Z15A,16A ATM,5F | 90/9~00/ | Mission & Differential (A/T) REAR DIFF. PINION |
| 03905 5228 | MD707575 | 42 x 60 x 9 | GTO Z15A,16A | 90/9~00/ | Mission & Differential (A/T) CONVERTER OIL PUMP |
| 03905 2144 | MB837029 | 37 x 58 x 10 x 13.3 | GTO Z15A,16A 6F | 90/9~00/ | Mission & Differential (A/T) FRONT DIFF. CASE(RH) |
| 03905 5789 | MD707184 | 35 x 56 x 9 x 12 | GTO Z15A,16A ATM,5F | 90/9~00/ | Mission & Differential (A/T) FRONT DIFF. CASE(RH) |
| 03905 1856 | MB837028 | 37 x 58 x 11.5 x 16 | GTO Z15A,16A 6F | 90/9~00/ | Mission & Differential (A/T) FRONT DIFF. CASE(LH) |
| 03905 2111 | MD719710 | 35 x 54 x 10 x 17 | GTO Z15A,16A ATM,5F | 90/9~00/ | Mission & Differential (A/T) FRONT DIFF. CASE(LH) |
| 03905 7649 | MD741818 | 25 x 35 x 6 | GTO Z15A,16A | 90/9~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 8660 | MB569924 | 42 x 72 x 12 x 15.5 | GTO Z15A,16A 6F | 90/9~00/ | Mission & Differential (A/T) REAR DIFF. PINION |
| 03905 6038 | MD008762 | 35 x 50 x 8 | LANCER (RWD) G3B 143,144,174 | 77/~87/ | Engine CAM SHAFT |
| 03905 3377 | MD008762 | 35 x 50 x 8 | LANCER (RWD) G6B A175 | 80/2~87/ | Engine CAM SHAFT |
| 03905 2342 | MD151463 | 28 x 40 x 8 | LANCER (RWD) G3B | 77/~87/ | Engine BALANCER SHAFT |
| 03905 7196 | MD050608 | 25 x 35 x 6 | LANCER (RWD) G6B | 81/~87/ | Engine BALANCER SHAFT |
| 03905 3116 | MD009038 | 17 x 28 x 7 | LANCER (RWD) G3B,G6B | 77/~87/ | Engine OIL PUMP |
| 03905 8822 | MD008882 | 44 x 60 x 7 | LANCER (RWD) G3B,G6B | 77/~87/ | Engine CRANK SHAFT FRONT |
| 03905 5912 | MA125844 | 38 x 52 x 6 | LANCER (RWD) A14#,17#...EXCEPT A175A NFU,NFG | 77/~87/ | Wheel Hub FRONT |
| 03905 1004 | MD008762 | 35 x 50 x 8 | LANCER (RWD) G19 A141,142,148,149,171,172 | 77/~87/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6278 | MD307343 | | LANCER (RWD) G1B | 77/~87/ | Engine VALVE STEM SEAL |
| 03905 2165 | MD030782 | 30 x 46 x 7 | LANCER (RWD) G1B | 77/~87/ | Engine CRANK SHAFT FRONT |
| 03905 6779 | MD000508 | | LANCER (RWD) G3B,G6B | 77/~87/ | Engine VALVE STEM SEAL |
| 03905 7640 | MD069947 | 80 x 96 x 9 | LANCER (RWD) G6B | 80/2~87/ | Engine CRANK SHAFT REAR |
| 03905 7799 | MA181498 | 51 x 65 x 9 | LANCER (RWD) A146A,174A(NU),175A | 79/4~87/ | Wheel Hub REAR |
| 03905 4769 | MD016549 | 72 x 96 x 9 | LANCER (RWD) G1B,G3B | 77/~87/ | Engine CRANK SHAFT REAR |
| 03905 8342 | MB584745 | 45 x 62 x 6 | LANCER (RWD) A174A NFU,NFG | 83/11~87/ | Wheel Hub FRONT |
| 03905 3626 | MB092145 | 42 x 65 x 12 | LANCER (RWD) A175A NTU,NTG,NFU,NFG | 81/11~87/ | Final Drive PINION |
| 03905 5105 | MB001115 | 41 x 55 x 9 | LANCER (RWD) A171A,172A,174A(EXCEPT NU) | 79/4~87/ | Wheel Hub REAR |
| 03905 7298 | MA181498 | 51 x 65 x 9 | LANCER (RWD) A141V,142V,148V,149V | 77/~85/ | Wheel Hub REAR |
| 03905 1151 | MD050608 | 25 x 35 x 6 | LANCER (RWD) A14#,17#...EXCEPT A175A NTU,NTG,NFU,NFG | 77/~87/ | Transmission FRONT |
| 03905 8975 | MD723202 | 30 x 45 x 6 | LANCER (RWD) A175A NTU,NTG,NFU,NFG | 81/11~87/ | Transmission FRONT |
| 03905 8384 | MD701430 | 32 x 48 x 10 | LANCER (RWD) A14#,17#...EXCEPT A175A NTU,NTG,NFU,NFG | 77/~87/ | Transmission REAR |
| 03905 4073 | MD703743 | 36 x 52 x 10 | LANCER (RWD) A175A NTU,NTG,NFU,NFG | 81/11~87/ | Transmission REAR |
| 03905 4403 | MB393929 | 35 x 65 x 12 | LANCER (RWD) A14#,17#...EXCEPT A175A NTU,NTG,NFU,NFG | 77/~87/ | Final Drive PINION |
| 03905 2027 | MB001115 | 41 x 55 x 9 | LANCER (RWD) A141A,142A,143A | 77/~80/ | Wheel Hub REAR |
| 03905 1232 | MD306079 | | LEGNUM 4G64 IN. | 99/7~02/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6041 | MD008762 | 35 x 50 x 8 | LEGNUM 4G94(EA7W,EC7W) | 00/5~02/ | Engine CAM SHAFT |
| 03905 5951 | MD095355 | 20 x 30 x 7 | LEGNUM 4G64(EA3W,EC3W) | 98/8~02/ | Engine OIL PUMP |
| 03905 4241 | MD050608 | 25 x 35 x 6 | LEGNUM 4G64(EA3W,EC3W) | 98/8~02/ | Engine BALANCER SHAFT |
| 03905 6776 | MD168055 | 37 x 50 x 6 | LEGNUM 4G93,6A12,6A13,4G94 | 96/6~02/ | Engine CRANK SHAFT FRONT |
| 03905 3677 | MD008882 | 44 x 60 x 7 | LEGNUM 4G64 | 98/8~02/ | Engine CRANK SHAFT FRONT |
| 03905 8753 | MD359158 | 85 x 103 x 7.5 | LEGNUM 4G93,4G64,6A12,6A13,4G94 | 96/6~02/ | Engine CRANK SHAFT REAR |
| 03905 5558 | MD184303 | | LEGNUM 4G93,4G94 IN. & EX. | 96/6~02/ | Engine VALVE STEM SEAL |
| 03905 5774 | MD184303 | | LEGNUM 6A12 IN. | 96/6~98/ | Engine VALVE STEM SEAL |
| 03905 6362 | MD008762 | 35 x 50 x 8 | LEGNUM 6A12(EA4W,EC4W),6A13(EA5W,EC5W) | 96/6~02/ | Engine CAM SHAFT |
| 03905 6134 | MD307343 | | LEGNUM 4G64 EX. | 98/8~02/ | Engine VALVE STEM SEAL |
| 03905 2420 | MD755904 | 41 x 61 x 9 x 13.5 | LEGNUM EC5W MT EXC.TURBO | 96/6~02/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 6053 | MD307343 | | LEGNUM 4G64 IN. | 98/8~99/7 | Engine VALVE STEM SEAL |
| 03905 3920 | MD707575 | 42 x 60 x 9 | LEGNUM EA#,EC# | 96/6~02/ | Mission & Differential (A/T) OIL PUMP BODY |
| 03905 7736 | MD758763 | 41 x 61 x 11.5 x 16 | LEGNUM EC5W AT LRGE,LRPE | 96/6~02/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 2174 | MD758763 | 41 x 61 x 11.5 x 16 | LEGNUM EC5W MT TURBO | 96/6~02/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 6104 | MD758763 | 41 x 61 x 11.5 x 16 | LEGNUM EC3W,7W | 98/8~02/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 7187 | MD755904 | 41 x 61 x 9 x 13.5 | LEGNUM EC5W AT EXC. LRGE,LRPE | 96/6~02/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 2882 | MD755904 | 41 x 61 x 9 x 13.5 | LEGNUM EC4W | 96/6~98/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 2963 | MD755904 | 41 x 61 x 9 x 13.5 | LEGNUM EC1W | 96/6~96/11 | Mission & Differential (M/T) FRONT DIFF. CASE |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5648 | MD755904 | 41 x 61 x 9 x 13.5 | LEGNUM EA1W,4W,5W,7W | 96/6~02/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 6839 | MB936826 | 30 x 45 x 6.5 | LEGNUM EC5W TURBO | 96/6~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 7556 | MD741818 | 25 x 35 x 6 | LEGNUM EA1W,4W,5W,EC1W,4W ,5W(EXC.TURBO) | 96/6~02/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 7601 | MD008762 | 35 x 50 x 8 | LEGNUM 4G93(EA1W,EC1W),4G6 4(EA3W,EC3W) | 96/6~02/ | Engine CAM SHAFT |
| 03905 2513 | MD302338 | | LEGNUM 6A12 EX. | 96/6~98/ | Engine VALVE STEM SEAL |
| 03905 2924 | MD758763 | 41 x 61 x 11.5 x 16 | LEGNUM EC1W | 96/12~00/ | Mission & Differential (M/T) FRONT DIFF. CASE |
| 03905 6389 | MD707184 | 35 x 56 x 9 x 12 | LEGNUM EC1W,3W,5W,7W | 96/6~02/ | Mission & Differential (M/T) REAR DIFF. SIDE |
| 03905 3020 | MD359158 | 85 x 103 x 7.5 | LIBERO 4G92,4G93 | 95/2~ | Engine CRANK SHAFT REAR |
| 03905 5138 | MD008762 | 35 x 50 x 8 | LIBERO 4G92(CB4W),4G93(CB5 W,CD5W) | 92/4~ | Engine CAM SHAFT |
| 03905 1460 | MD008762 | 35 x 50 x 8 | LIBERO 4D68(CB8#,CD8# | 92/4~ | Engine CAM SHAFT |
| 03905 5516 | MD095355 | 20 x 30 x 7 | LIBERO 4D68 | 92/4~ | Engine OIL PUMP |
| 03905 5201 | MD050608 | 25 x 35 x 6 | LIBERO 4D68 | 92/4~ | Engine BALANCER SHAFT |
| 03905 3812 | MD030782 | 30 x 46 x 7 | LIBERO 4G13,4G15 | 92/4~ | Engine CRANK SHAFT FRONT |
| 03905 8387 | MD008762 | 35 x 50 x 8 | LIBERO 4G13(CB1V),4G15(CB2#, CD2V) | 92/4~ | Engine CAM SHAFT |
| 03905 2576 | MD016549 | 72 x 96 x 9 | LIBERO 4G13,4G15 | 92/4~ | Engine CRANK SHAFT REAR |
| 03905 1145 | MD008882 | 44 x 60 x 7 | LIBERO 4D68 | 92/4~ | Engine CRANK SHAFT FRONT |
| 03905 6353 | MD359158 | 85 x 103 x 7.5 | LIBERO 4D68 | 92/4~ | Engine CRANK SHAFT REAR |
| 03905 7739 | MD307343 | | LIBERO 4G13,4G15 | 92/4~ | Engine VALVE STEM SEAL |
| 03905 4037 | MD184303 | | LIBERO 4G92,4G93 | 92/4~ | Engine VALVE STEM SEAL |
| 03905 4985 | MD000508 | | LIBERO 4D68 | 92/4~ | Engine VALVE STEM SEAL |
| 03905 6983 | MB573309 | 54 x 82 x 8 x 11 | LIBERO CD5W,8W | 92/4~00/ | Wheel Hub FRONT INNER |
| 03905 1736 | MD168055 | 37 x 50 x 6 | LIBERO 4G92,4G93 | 92/4~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2696 | MD707184 | 35 x 56 x 9 x 12 | LIBERO CB#,CD# | 92/4~ | Mission & Differential (A/T) FRONT DIFF. CASE(RH) |
| 03905 6197 | MB808443 | 54 x 76 x 8 x 11 | LIBERO CB1V,2V,2W,4W,5W,8V, 8W,CD2V,8V | 92/4~ | Wheel Hub FRONT INNER |
| 03905 2813 | MD150161 | 85 x 103 x 8 | LIBERO 4G93 | 92/4~95/2 | Engine CRANK SHAFT REAR |
| 03905 1799 | MB303875 | 52 x 72 x 8 x 11 | LIBERO CD5W,8W | 92/4~00/ | Wheel Hub FRONT OUTER |
| 03905 3581 | MA181498 | 51 x 65 x 9 | LIBERO CD#...WITHOUT ABS | 92/4~ | Wheel Hub REAR |
| 03905 5666 | MD741818 | 25 x 35 x 6 | LIBERO CB#,CD# | 92/4~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 3332 | MB808444 | 51.9 x 66 x 8 x 10 | LIBERO CB1V,2V,2W,4W,5W,8V, 8W,CD2V,8V | 92/4~ | Wheel Hub FRONT OUTER |
| 03905 2846 | MD707184 | 35 x 56 x 9 x 12 | LIBERO CB# | 92/4~ | Mission & Differential (A/T) FRONT DIFF. CASE(LH) |
| 03905 2834 | MR103090R | | LIBERO CB#,CD# | 92/5~96/11 | Power Steering SEAL KIT |
| 03905 6359 | MD719710 | 35 x 54 x 10 x 17 | LIBERO CD# | 92/4~ | Mission & Differential (A/T) FRONT DIFF. CASE(LH) |
| 03905 1622 | MB393929 | 35 x 65 x 12 | LIBERO CD# | 92/4~ | Mission & Differential (A/T) REAR DIFF. PINION |
| 03905 7460 | MD707575 | 42 x 60 x 9 | LIBERO CB#,CD# | 92/4~ | Mission & Differential (A/T) CONVERTER OIL PUMP |
| 03905 5564 | MB910971R | | LIBERO CB#,CD# | 92/4~92/5 | Power Steering SEAL KIT |
| 03905 8705 | MB886298 | 30 x 60 x 15 | LIBERO CD#...WITH ABS | 92/4~ | Wheel Hub REAR |
| 03905 8885 | MN184008 | | LIBERO CB#,CD# | 96/12~ | Power Steering SEAL KIT |
| 03905 3002 | MD008762 | 35 x 50 x 8 | MINI CAB 3G83 U41,42(DOHC) | 90/12~ | Engine CAM SHAFT |
| 03905 7454 | MD162689 | 35 x 47 x 8.5 | MINI CAB 4A30 U43,44(SOHC) | 93/12~99/ | Engine CAM SHAFT |
| 03905 4874 | MD162689 | 35 x 47 x 8.5 | MINI CAB 3G83 U61,62 | 98/11~ | Engine CAM SHAFT |
| 03905 6953 | MD707184 | 35 x 56 x 9 x 12 | MINI CAB U12,15,19,42,44(4WD) | 84/4~99/ | Final Drive FRONT DIFF. SIDE |
| 03905 2009 | MD162689 | 35 x 47 x 8.5 | MINI CAB 3G81,3G83 U14,15,18,19 | 90/9~91/ | Engine CAM SHAFT |
| 03905 3980 | MD008762 | 35 x 50 x 8 | MINI CAB G23B U11,12 | 84/4~87/5 | Engine CAM SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7019 | MD008762 | 35 x 50 x 8 | MINI CAB 4A30 U43,44(DOHC) | 93/12~99/ | Engine CAM SHAFT |
| 03905 5873 | MD008762 | 35 x 50 x 8 | MINI CAB 3G81,3G83 U14,15,18,19 | 87/6~90/9 | Engine CAM SHAFT |
| 03905 8261 | MD162689 | 35 x 47 x 8.5 | MINI CAB 3G83 U41,42(SOHC) | 90/12~99/ | Engine CAM SHAFT |
| 03905 6893 | MD009038 | 17 x 28 x 7 | MINI CAB 3G81,3G83 | 87/6~ | Engine OIL PUMP |
| 03905 6368 | MD168057 | 20 x 30 x 7 x 7.5 | MINI CAB 4A30 | 93/12~99/ | Engine OIL PUMP |
| 03905 2402 | MD030782 | 30 x 46 x 7 | MINI CAB G23B | 84/4~87/ | Engine CRANK SHAFT FRONT |
| 03905 2930 | MD115245 | 31 x 45 x 7 | MINI CAB 3G81,3G83,4A30 | 87/6~ | Engine CRANK SHAFT FRONT |
| 03905 6449 | MD329374 | 70 x 87 x 8.5 | MINI CAB 4A30 | 93/12~ | Engine CRANK SHAFT REAR |
| 03905 7136 | MD179175 | | MINI CAB 3G83,4A30 | 90/12~ | Engine VALVE STEM SEAL |
| 03905 2798 | MB092620 | 35 x 55 x 11 | MINI CAB U18,19,41,42,61,62 | 90/1~ | Final Drive PINION |
| 03905 3554 | MD016317 | 60 x 78 x 7.5 | MINI CAB 2G23,G23B | 77/3~87/ | Engine CRANK SHAFT REAR |
| 03905 5303 | MD307343 | | MINI CAB G23B,3G81,3G83 | 77/3~90/11 | Engine VALVE STEM SEAL |
| 03905 5486 | MD112895 | 60 x 75 x 8 | MINI CAB 3G81,3G83 | 87/6~95/10 | Engine CRANK SHAFT REAR |
| 03905 8195 | MB001115 | 41 x 55 x 9 | MINI CAB U11,14 FRONT DISC BRAKE | 84/4~89/12 | Wheel Hub REAR |
| 03905 7763 | MD321819 | 60 x 75 x 8 | MINI CAB 3G83 | 95/10~ | Engine CRANK SHAFT REAR |
| 03905 7700 | MB092620 | 35 x 55 x 11 | MINI CAB U14,15 WITHOUT SUPER CHARGER ETC. | 87/6~89/12 | Final Drive PINION |
| 03905 2867 | MB109453 | 45 x 60 x 7 x 10 | MINI CAB U12,15,19,42,44(4WD) | 84/4~99/ | Wheel Hub FRONT INNER |
| 03905 3641 | MB349099 | 46 x 61 x 7.3 x 10 | MINI CAB U12,15,19(4WD) | 84/4~91/ | Wheel Hub FRONT OUTER |
| 03905 3092 | MV026391 | 35 x 46 x 8 | MINI CAB U11,14 FRONT DRUM BRAKE | 84/4~89/12 | Wheel Hub REAR |
| 03905 2294 | MT131243 | 42 x 53 x 8 | MINI CAB U11,14,18,41,43(2WD) | 84/4~99/ | Wheel Hub FRONT |
| 03905 6782 | MB001115 | 41 x 55 x 9 | MINI CAB U12,15,18,19,41,42,43,44 | 84/4~99/ | Wheel Hub REAR |
| 03905 1685 | MB001115 | 41 x 55 x 9 | MINI CAB U61,62 WITHOUT ABS | 98/11~ | Wheel Hub REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1241 | MR399191 | 28 x 50 x 11 | MINI CAB U61,62 WITH ABS | 98/11~ | Wheel Hub REAR |
| 03905 6614 | MB393929 | 35 x 65 x 12 | MINI CAB U12(12V HLBJ,LBD) | 84/4~87/ | Final Drive PINION |
| 03905 7979 | MB109453 | 45 x 60 x 7 x 10 | MINI CAB U42,44(4WD) | 90/12~99/ | Wheel Hub FRONT OUTER |
| 03905 4583 | MB393929 | 35 x 65 x 12 | MINI CAB U14,15 SUPER CHARGER ETC. | 87/6~89/12 | Final Drive PINION |
| 03905 6923 | MN114457 | 22 x 32 x 5 | MINI CAB U1#,4#,6# | 84/4~ | Transmission (M/T) FRONT |
| 03905 5171 | MB290311 | 28 x 47 x 8 | MINI CAB U14 FRONT DRUM BRAKE | 87/6~89/12 | Final Drive PINION |
| 03905 6740 | MB290311 | 28 x 47 x 8 | MINI CAB U11,12(EXCEPT 12V HLBJ,LBD) | 84/4~87/ | Final Drive PINION |
| 03905 6593 | MD701430 | 32 x 48 x 10 | MINI CAB U4#...TURBO | 91/12~99/ | Transmission (M/T) REAR EXTENTION |
| 03905 6821 | MR983239 | 28 x 45 x 10 | MINI CAB U61 | 98/11~ | Transmission (M/T) REAR EXTENTION |
| 03905 2537 | MR983239 | 28 x 45 x 10 | MINI CAB U4#///EXCEPT TURBO | 90/12~99/ | Transmission (M/T) REAR EXTENTION |
| 03905 4277 | MR983239 | 28 x 45 x 10 | MINI CAB U1# | 84/4~91/ | Transmission (M/T) REAR EXTENTION |
| 03905 3566 | MD008762 | 35 x 50 x 8 | MINICA 2G23 A107 | 81/8~84/ | Engine CRANK SHAFT FRONT |
| 03905 7760 | MD008762 | 35 x 50 x 8 | MINICA 3G83(SONC) H22,27 | 90/1~90/8 | Engine CAM SHAFT |
| 03905 7157 | MD008762 | 35 x 50 x 8 | MINICA 3G83(DOHC) H22 | 90/1~93/ | Engine CAM SHAFT |
| 03905 8744 | MD008762 | 35 x 50 x 8 | MINICA 4A30(DOHC) H31,36 | 93/9~98/ | Engine CAM SHAFT |
| 03905 6146 | MD162689 | 35 x 47 x 8.5 | MINICA 3G83(SOHC) H22,27,32,37,42,47 | 90/9~ | Engine CAM SHAFT |
| 03905 4070 | MD009038 | 17 x 28 x 7 | MINICA 3G81,3G83 | 87/1~ | Engine OIL PUMP |
| 03905 6890 | MD168057 | 20 x 30 x 7 x 7.5 | MINICA 4A30 | 93/9~98/ | Engine OIL PUMP |
| 03905 5948 | MD008762 | 35 x 50 x 8 | MINICA G23B H11,12 | 84/1~86/ | Engine CAM SHAFT |
| 03905 5246 | MD030782 | 30 x 46 x 7 | MINICA G23B | 84/1~86/ | Engine CRANK SHAFT FRONT |
| 03905 2474 | MD115245 | 31 x 45 x 7 | MINICA 3G81,3G83,4A30 | 87/1~96/2 | Engine CRANK SHAFT FRONT |
| 03905 4589 | MD379845 | 31 x 45 x 7 | MINICA 3G83,4A30 | 96/2~ | Engine CRANK SHAFT FRONT |
| 03905 4364 | MD016317 | 60 x 78 x 7.5 | MINICA 2G23,G23B | 77/3~86/12 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7910 | MD112895 | 60 x 75 x 8 | MINICA 3G81,3G83 | 87/1~95/10 | Engine CRANK SHAFT REAR |
| 03905 1706 | MD321819 | 60 x 75 x 8 | MINICA 3G83,4A30 | 95/10~ | Engine CRANK SHAFT REAR |
| 03905 6692 | MD307343 | | MINICA G23B,3G81 H11,12,14,15 | 84/1~89/1 | Engine VALVE STEM SEAL |
| 03905 5390 | MB290311 | 28 x 47 x 8 | MINICA H26(4WD) | 90/1~90/ | Mission & Differential (A/T) DRIVE PINION |
| 03905 8363 | MD307343 | | MINICA 3G81,3G83 SOHC | 88/11~98/ | Engine VALVE STEM SEAL |
| 03905 8498 | MB092620 | 35 x 55 x 11 | MINICA H27,47(4WD) | 90/11~ | Mission & Differential (A/T) DRIVE PINION |
| 03905 8603 | MD179175 | | MINICA 3G83 | 98/10~ | Engine VALVE STEM SEAL |
| 03905 2828 | MR112693 | 45 x 60 x 7 x 10 | MINICA H22,27,3# | 90/1~98/ | Wheel Hub FRONT OUTER |
| 03905 5207 | MD008762 | 35 x 50 x 8 | MINICA 3G81 H14,15,21,26 | 87/1~90/ | Engine CAM SHAFT |
| 03905 2228 | MD179175 | | MINICA 4A30 | 93/9~98/ | Engine VALVE STEM SEAL |
| 03905 5771 | MB303297 | 43 x 58 x 6.5 x 9 | MINICA H1#,2#,3# | 84/1~98/ | Wheel Hub FRONT INNER |
| 03905 3941 | MB290311 | 28 x 47 x 8 | MINICA H12,15,26(4WD) | 84/1~89/ | Mission & Differential (A/T) DRIVE PINION |
| 03905 2231 | MB109453 | 45 x 60 x 7 x 10 | MINICA H1#,21,26 | 85/8~90/ | Wheel Hub FRONT OUTER |
| 03905 8591 | MV026391 | 35 x 46 x 8 | MINICA A107 | 81/8~84/ | Wheel Hub REAR |
| 03905 3287 | MV026391 | 35 x 46 x 8 | MINICA H12,15,26,27,37,47(4WD) | 84/1~ | Wheel Hub REAR |
| 03905 4265 | MB936241 | 33 x 50 x 13 | MINICA H47 ABS | 98/10~ | Wheel Hub REAR |
| 03905 5018 | MN114457 | 22 x 32 x 5 | MINICA A107 | 81/8~84/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 3422 | MN114457 | 22 x 32 x 5 | MINICA H1#,2#,3#,4# | 84/1~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 8996 | MR983239 | 28 x 45 x 10 | MINICA A107 | 81/8~84/ | Mission & Differential (M/T) REAR EXTENSION |
| 03905 3782 | MD707184 | 35 x 56 x 9 x 12 | MINICA H1#,2#,3#,4# | 84/1~ | Mission & Differential (A/T) DIFF. SIDE(L&R) |
| 03905 4865 | MB290311 | 28 x 47 x 8 | MINICA A107 | 81/8~84/ | Mission & Differential (A/T) DRIVE PINION |
| 03905 5063 | MB303884 | 41 x 56 x 7 x 11 | MINICA H1# | 84/1~85/7 | Wheel Hub FRONT OUTER |
| 03905 1397 | MD168055 | 37 x 50 x 6 | MIRAGE / LANCER (FWD) 6A10,11 CB6,CK6 | 91/12~00/ | Engine CRANK SHAFT FRONT |
| 03905 5099 | MD069947 | 80 x 96 x 9 | MIRAGE / LANCER (FWD) 4G61 | 87/3~92/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6158 | MD372250 | 72 x 96 x 7.5 | MIRAGE / LANCER (FWD) 4G13,4G15 | 00/3~ | Engine CRANK SHAFT REAR |
| 03905 8333 | MB303875 | 52 x 72 x 8 x 11 | MIRAGE / LANCER (FWD) CJ4A,(SIZE UP WHEEL),CK4A,CM5A | 95/10~00/ | Wheel Hub FRONT OUTER |
| 03905 4229 | MD016549 | 72 x 96 x 9 | MIRAGE / LANCER (FWD) 4G13,4G15 | 87/9~00/2 | Engine CRANK SHAFT REAR |
| 03905 6398 | MD168055 | 37 x 50 x 6 | MIRAGE / LANCER (FWD) 4G93 CB5,CD5,CK5,CM5,CQ5, CS5 | 91/8~ | Engine CRANK SHAFT FRONT |
| 03905 8108 | MD016549 | 72 x 96 x 9 | MIRAGE / LANCER (FWD) G1B,G3B,G13B,G15B | 78/3~92/ | Engine CRANK SHAFT REAR |
| 03905 5276 | MD008882 | 44 x 60 x 7 | MIRAGE / LANCER (FWD) 4G63 CD9,CE9,CN9,CP9,CT9 | 92/8~ | Engine CRANK SHAFT FRONT |
| 03905 1007 | MD008882 | 44 x 60 x 7 | MIRAGE / LANCER (FWD) 4D65,4D68 CB7,8,CD7,8,CK8,CM8 | 91/8~99/ | Engine CRANK SHAFT FRONT |
| 03905 6947 | MD008882 | 44 x 60 x 7 | MIRAGE / LANCER (FWD) 1800CC C14,34,64,74,37 | 83/10~92/ | Engine CRANK SHAFT FRONT |
| 03905 4907 | MD069947 | 80 x 96 x 9 | MIRAGE / LANCER (FWD) 4D65 | 79/3~92/ | Engine CRANK SHAFT REAR |
| 03905 1058 | MD008882 | 44 x 60 x 7 | MIRAGE / LANCER (FWD) 1600CC A153,157 | 78/2~85/ | Engine CRANK SHAFT FRONT |
| 03905 6404 | MD306078 | | MIRAGE / LANCER (FWD) 4G13 IN. | 95/8~00/ | Engine VALVE STEM SEAL |
| 03905 5108 | MD008882 | 44 x 60 x 7 | MIRAGE / LANCER (FWD) 1600CC C13,53,63,73,83 | 83/10~92/ | Engine CRANK SHAFT FRONT |
| 03905 6665 | MD150161 | 85 x 103 x 8 | MIRAGE / LANCER (FWD) 4G91,4G92,4G93,4G63,6 A10 | 91/8~95/ | Engine CRANK SHAFT REAR |
| 03905 5162 | MD359158 | 85 x 103 x 7.5 | MIRAGE / LANCER (FWD) 4G92,4G93,4G63,6A11 | 85/8~ | Engine CRANK SHAFT REAR |
| 03905 4211 | MD359158 | 85 x 103 x 7.5 | MIRAGE / LANCER (FWD) 4D68 | 92/10~ | Engine CRANK SHAFT REAR |
| 03905 6212 | MD307343 | | MIRAGE / LANCER (FWD) G1B,G13B,G15B IN. & EX. | 78/3~92/ | Engine VALVE STEM SEAL |
| 03905 3254 | MD307343 | | MIRAGE / LANCER (FWD) 4G13,4G15 IN. & EX. | 87/9~95/ | Engine VALVE STEM SEAL |
| 03905 1304 | MD307343 | | MIRAGE / LANCER (FWD) 4G63 IN. & EX. | 92/8~97/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7907 | MD184303 | | MIRAGE / LANCER (FWD) 4G91,92,93 IN. & EX. | 91/7~ | Engine VALVE STEM SEAL |
| 03905 4394 | MD307343 | | MIRAGE / LANCER (FWD) 4G13 EX. | 95/8~00/ | Engine VALVE STEM SEAL |
| 03905 1982 | MD307343 | | MIRAGE / LANCER (FWD) 4G63 IN. & EX. | 98/1~ | Engine VALVE STEM SEAL |
| 03905 3014 | MD307341 | | MIRAGE / LANCER (FWD) 4G15 EX. | 95/8~ | Engine VALVE STEM SEAL |
| 03905 8714 | MD307341 | | MIRAGE / LANCER (FWD) 4G13 EX. | 00/1~ | Engine VALVE STEM SEAL |
| 03905 3728 | MD302172 | | MIRAGE / LANCER (FWD) 4G15 IN. | 95/8~ | Engine VALVE STEM SEAL |
| 03905 2327 | MD302172 | | MIRAGE / LANCER (FWD) 4G13 IN. | 00/1~ | Engine VALVE STEM SEAL |
| 03905 3650 | MD000508 | | MIRAGE / LANCER (FWD) G3B,4D65,4D68 | 78/3~99/ | Engine VALVE STEM SEAL |
| 03905 3029 | MA125844 | 38 x 52 x 6 | MIRAGE / LANCER (FWD) A15# | 78/3~85/ | Wheel Hub REAR |
| 03905 8420 | MD755904 | 41 x 61 x 9 x 13.5 | MIRAGE / LANCER (FWD) CJ#,CK#,CL2A,CM2A,CM8A | 95/10~00/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 8858 | MD707184 | 35 x 56 x 9 x 12 | MIRAGE / LANCER (FWD) CA#,CB#,CC#,CD#,CE9A | 91/8~96/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 1442 | MD707184 | 35 x 56 x 9 x 12 | MIRAGE / LANCER (FWD) C1#,3#,5#,6#,7#,8# | 83/10~92/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 5426 | MD707184 | 35 x 56 x 9 x 12 | MIRAGE / LANCER (FWD) A15# | 78/3~85/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 3593 | MN132381 | 28 x 43 x 7 | MIRAGE / LANCER (FWD) CT9A(6F) | 01/2~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 6476 | MB936826 | 30 x 45 x 6.5 | MIRAGE / LANCER (FWD) CM5A,CN9A,CP9A,CT9A(5F) | 96/8~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 7118 | MD741818 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) CS2A,V | 00/5~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 8045 | MD741818 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) CA#MCB#,CC#,CD#,CE9A,CJ#,CK#,CM8A | 91/8~00/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 6524 | MD741818 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) C11V,12V,12W,14V,14W,32V,34W,37W | 91/8~92/ | Mission & Differential (M/T) INPUT SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7070 | MD050608 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) C1#,3#,5#,6#,7#,8# | 83/10~91/ 8 | Mission & Differential (M/T) INPUT SHAFT |
| 03905 8879 | MD050608 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) A15# | 78/3~85/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 1667 | MA181498 | 51 x 65 x 9 | MIRAGE / LANCER (FWD) C3#,7#,8# | 86/8~91/ | Wheel Hub REAR |
| 03905 2075 | MD755904 | 41 x 61 x 9 x 13.5 | MIRAGE / LANCER (FWD) CQ#,CS# | 98/11~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 2483 | MB584601 | 39 x 52 x 6 x 11.5 | MIRAGE / LANCER (FWD) C1#...EXCEPT VAN,WAGON | 83/10~88/ | Wheel Hub REAR |
| 03905 8930 | MB808444 | 51.9 x 66 x 8 x 10 | MIRAGE / LANCER (FWD) CK1A,2A,6A,8A,CL2A,C M2A,8A | 95/10~00/ | Wheel Hub FRONT OUTER |
| 03905 4424 | MB303875 | 52 x 72 x 8 x 11 | MIRAGE / LANCER (FWD) CC4A,CD5A,CD9A,CE9# | 91/8~96/ | Wheel Hub FRONT OUTER |
| 03905 5726 | MB808444 | 51.9 x 66 x 8 x 10 | MIRAGE / LANCER (FWD) CJ1A,2A,4A(EXC. SIZE UP WHEEL) | 95/10~00/ | Wheel Hub FRONT OUTER |
| 03905 3305 | MB176746 | 50 x 66.5 x 13 x 16 | MIRAGE / LANCER (FWD) C1#,3#,5#,6#,7#,8# | 83/10~92/ | Wheel Hub FRONT OUTER |
| 03905 3032 | MB176746 | 50 x 66.5 x 13 x 16 | MIRAGE / LANCER (FWD) A15# | 78/3~85/ | Wheel Hub FRONT OUTER |
| 03905 3878 | MB573309 | 54 x 82 x 8 x 11 | MIRAGE / LANCER (FWD) CJ4A(SIZE UP WHEEL),CK4A,CM5A | 95/10~00/ | Wheel Hub FRONT INNER |
| 03905 5408 | MB573309 | 54 x 82 x 8 x 11 | MIRAGE / LANCER (FWD) CC4A,CD5A,CD9A,CE9# | 91/8~96/ | Wheel Hub FRONT INNER |
| 03905 3725 | MB808443 | 54 x 76 x 8 x 11 | MIRAGE / LANCER (FWD) CK1A,2A,6A,8A,CL2A,C M2A,8A | 95/10~00/ | Wheel Hub FRONT INNER |
| 03905 2612 | MB808443 | 54 x 76 x 8 x 11 | MIRAGE / LANCER (FWD) CJ1A,2A,4A(EXC. SIZE UP WHEEL) | 95/10~00/ | Wheel Hub FRONT INNER |
| 03905 3236 | MB808443 | 54 x 76 x 8 x 11 | MIRAGE / LANCER (FWD) CA#,CB#,CC3A,CD3A,7 A,8A | 91/8~95/ | Wheel Hub FRONT INNER |
| 03905 3161 | MB176746 | 50 x 66.5 x 13 x 16 | MIRAGE / LANCER (FWD) C1#,3#,5#,6#,7#,8# | 83/10~92/ | Wheel Hub FRONT INNER |
| 03905 2501 | MB176746 | 50 x 66.5 x 13 x 16 | MIRAGE / LANCER (FWD) A15# | 78/3~85/ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3350 | MD168055 | 37 x 50 x 6 | MIRAGE / LANCER (FWD) 4G92 CA4,CB4,CC4,CJ4,CK4 | 91/8~00/ | Engine CRANK SHAFT FRONT |
| 03905 4961 | MA125844 | 38 x 52 x 6 | MIRAGE / LANCER (FWD) C11V,12V,12W,14V,14W | 85/1~92/ | Wheel Hub REAR |
| 03905 3806 | MB584601 | 39 x 52 x 6 x 11.5 | MIRAGE / LANCER (FWD) C5#,6# | 87/9~91/ | Wheel Hub REAR |
| 03905 4910 | MD009038 | 17 x 28 x 7 | MIRAGE / LANCER (FWD) 4D65 | 83/10~85/ 4 | Engine OIL PUMP |
| 03905 6857 | MD168055 | 37 x 50 x 6 | MIRAGE / LANCER (FWD) 4G91 CA3,CB3,CC3,CD3 | 91/8~95/ | Engine CRANK SHAFT FRONT |
| 03905 3365 | MD030782 | 30 x 46 x 7 | MIRAGE / LANCER (FWD) 4G13,4G15 CQ1,2,CS2 | 00/1~ | Engine CRANK SHAFT FRONT |
| 03905 5984 | MB808444 | 51.9 x 66 x 8 x 10 | MIRAGE / LANCER (FWD) CA#,CB#,CC3A,CD3A,7 A,8A | 91/8~95/ | Wheel Hub FRONT OUTER |
| 03905 5738 | MD758763 | 41 x 61 x 11.5 x 16 | MIRAGE / LANCER (FWD) CN9A,CP9A,CT9A | 96/8~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |
| 03905 5963 | MD030782 | 30 x 46 x 7 | MIRAGE / LANCER (FWD) 4G13,4G15 CA1,2,CB1,2,CJ1,2,CK1,2 ,CL2,CM2 | 91/8~00/ | Engine CRANK SHAFT FRONT |
| 03905 5876 | MD030782 | 30 x 46 x 7 | MIRAGE / LANCER (FWD) 1500CC C12,32,52,62,72,82 | 83/10~92/ | Engine CRANK SHAFT FRONT |
| 03905 3140 | MD030782 | 30 x 46 x 7 | MIRAGE / LANCER (FWD) 1300CC C11,51,61 | 83/10~92/ | Engine CRANK SHAFT FRONT |
| 03905 8150 | MD030782 | 30 x 46 x 7 | MIRAGE / LANCER (FWD) 1200CC,1400C A151,152,155,156 | 78/2~85/ | Engine CRANK SHAFT FRONT |
| 03905 7451 | MD095355 | 20 x 30 x 7 | MIRAGE / LANCER (FWD) 4D65,4D68 | 85/5~99/ | Engine OIL PUMP |
| 03905 1628 | MD009038 | 17 x 28 x 7 | MIRAGE / LANCER (FWD) G23B,G27B | 79/3~92/ | Engine OIL PUMP |
| 03905 4226 | MD050608 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) 4G63 CD9,CE9,CN9,CP9,CT9 | 92/8~ | Engine BALANCER SHAFT |
| 03905 3068 | MD050608 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) 4D68 CB8,CD8,CK8,CM8 | 92/10~99/ | Engine BALANCER SHAFT |
| 03905 8576 | MD050608 | 25 x 35 x 6 | MIRAGE / LANCER (FWD) 4D65 C14,34,64,74,CB7,CD7 | 83/10~92/ | Engine BALANCER SHAFT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 3299 | MD008762 | 35 x 50 x 8 | MIRAGE / LANCER (FWD) 4G#,4D#...C# | 83/10~ | Engine CAM SHAFT |
| 03905 1754 | MD707575 | 42 x 60 x 9 | MIRAGE / LANCER (FWD) A15#,C#,CA#,CB#,CC#,CD# | 78/3~95/ | Mission & Differential (M/T&A/T) CONVERTER OIL PUMP |
| 03905 8204 | MD707184 | 35 x 56 x 9 x 12 | MIRAGE / LANCER (FWD) CA#,CB# | 91/8~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 7424 | MD707184 | 35 x 56 x 9 x 12 | MIRAGE / LANCER (FWD) A15# | 78/3~85/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 7598 | MD719710 | 35 x 54 x 10 x 17 | MIRAGE / LANCER (FWD) C3#,7#,8# | 86/8~92/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 6929 | MD095355 | 20 x 30 x 7 | MIRAGE / LANCER (FWD) 4G61,4G63 | 87/9~ | Engine OIL PUMP |
| 03905 4655 | MD719710 | 35 x 54 x 10 x 17 | MIRAGE / LANCER (FWD) CC#,CD#,CE9A | 91/8~96/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 3539 | MD755904 | 41 x 61 x 9 x 13.5 | MIRAGE / LANCER (FWD) CJ#,CK#,CL2A,CM2A,CM8A | 95/10~00/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 3857 | MD707184 | 35 x 56 x 9 x 12 | MIRAGE / LANCER (FWD) C1#,5#,6# | 83/10~92/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 6068 | MD755904 | 41 x 61 x 9 x 13.5 | MIRAGE / LANCER (FWD) CQ#,CS# | 98/11~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 3080 | MD707575 | 42 x 60 x 9 | MIRAGE / LANCER (FWD) CJ#,CK#,CL2A,CM#,CQ#,CS# | 95/10~ | Mission & Differential (M/T&A/T) CONVERTER OIL PUMP |
| 03905 6236 | MB910971R | | MIRAGE / LANCER (FWD) CA#,CB#,CC#,CD# | 91/8~92/5 | Power Steering SEAL KIT |
| 03905 8537 | MR103090R | | MIRAGE / LANCER (FWD) CA#,CB#,CC#,CD# | 92/5~95/ | Power Steering SEAL KIT |
| 03905 8282 | MR103090R | | MIRAGE / LANCER (FWD) CJ#,CK#,CM# | 95/10~00/ | Power Steering SEAL KIT |
| 03905 4562 | MR961785 | | MIRAGE / LANCER (FWD) CQ#,CS# | 98/11~ | Power Steering SEAL KIT |
| 03905 8255 | MD008762 | 35 x 50 x 8 | MIRAGE / LANCER (FWD) G11B,12B,15B,32B,37B A15#,C11,12,13,32,37 | 78/3~92/ | Engine CAM SHAFT |
| 03905 4079 | MB636914 | | PAJERO L14# | 89/5~90/ | Power Steering SECTOR SHAFT KIT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4004 | MB160949 | 45 x 72 x 12 x 19.5 | PAJERO V14,V2#,V34,V4#,V55 | 90/10~99/ | Drive Pinion REAR |
| 03905 4670 | MB870190 | | PAJERO V14,V23,V24,V34,V43,V44 | 90/10~93/6 | Power Steering SECTOR SHAFT KIT |
| 03905 4451 | MB553346 | | PAJERO LO4# | 82/4~83/6 | Power Steering SECTOR SHAFT KIT |
| 03905 7730 | MN103373 | | PAJERO V6#,V7# | 99/6~ | Power Steering SEAL KIT |
| 03905 5066 | MR151065 | | PAJERO V2#,V4# | 93/7~99/ | Power Steering SECTOR SHAFT KIT |
| 03905 4745 | MD008762 | 35 x 50 x 8 | PAJERO G63B LO41,LO46 | 82/4~88/ | Engine CAM SHAFT |
| 03905 3374 | MR374193 | | PAJERO V2#,V4# | 93/7~99/ | Power Steering SEAL KIT |
| 03905 6815 | MB553255 | | PAJERO LO4#,L14# | 83/7~89/5 | Power Steering SECTOR SHAFT KIT |
| 03905 7067 | MB870189 | | PAJERO V14,V23,V24,V34,V43,V44 | 90/10~93/6 | Power Steering SEAL KIT |
| 03905 8318 | MB636913 | | PAJERO L14# | 89/5~90/ | Power Steering SEAL KIT |
| 03905 5375 | MB350847 | | PAJERO LO4#,L14# | 83/7~89/5 | Power Steering SEAL KIT |
| 03905 3848 | MB160949 | 45 x 72 x 12 x 19.5 | PAJERO V6#,V7# | 99/6~ | Drive Pinion REAR |
| 03905 5630 | MB664285 | 44 x 72 x 12 | PAJERO L141,L144,L146 | 88/9~90/ | Drive Pinion FRONT |
| 03905 5561 | MD008762 | 35 x 50 x 8 | PAJERO 4D55 LO43,LO48 | 82/4~86/ | Engine CAM SHAFT |
| 03905 6215 | MD168055 | 37 x 50 x 6 | PAJERO 6G72,6G74 | 88/9~ | Engine CRANK SHAFT FRONT |
| 03905 6515 | MB160949 | 45 x 72 x 12 x 19.5 | PAJERO LO4#,L14# | 82/4~90/ | Drive Pinion REAR |
| 03905 2318 | MB664285 | 44 x 72 x 12 | PAJERO V55,V63(MT),V68,V73(MT),V78 | 97/8~ | Drive Pinion FRONT |
| 03905 5522 | MB664285 | 44 x 72 x 12 | PAJERO V21(MT),V23(MT),V25,V26,V43(MT),V45,V46 | 90/10~99/ | Drive Pinion FRONT |
| 03905 6110 | MB553348 | | PAJERO LO4# | 82/4~83/6 | Power Steering SEAL KIT |
| 03905 8570 | MD009038 | 17 x 28 x 7 | PAJERO G63B CAB | 82/4~85/7 | Engine OIL PUMP |
| 03905 1448 | MD101915 | 91 x 111 x 9 | PAJERO 6G72 | 88/9~97/3 | Engine CRANK SHAFT REAR |
| 03905 5123 | MD069947 | 80 x 96 x 9 | PAJERO G63B,4D55,4D56 | 82/4~90/12 | Engine CRANK SHAFT REAR |
| 03905 1904 | MD197467 | | PAJERO 4D56,6G72 IN. & EX. | 92/10~99/ | Engine VALVE STEM SEAL |
| 03905 6092 | MB160578 | 42 x 65 x 12 | PAJERO V63(AT),V65,V73(AT),V75 | 99/6~ | Drive Pinion FRONT |
| 03905 3860 | ME202850 | 50 x 74 x 11 | PAJERO 4M41 V68,V78 | 99/6~ | Engine TIMING GEAR CASE |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6707 | ME202850 | 50 x 74 x 11 | PAJERO 4M40 V26,V46 | 96/10~99/ | Engine TIMING GEAR CASE |
| 03905 8438 | ME200028 | 52 x 74 x 11 x 19 | PAJERO 4M40 V26,V46 | 93/7~96/10 | Engine TIMING GEAR CASE |
| 03905 5834 | MD095355 | 20 x 30 x 7 | PAJERO 4G64 | 96/3~99/ | Engine OIL PUMP |
| 03905 3536 | MD168057 | 20 x 30 x 7 x 7.5 | PAJERO G63B ECI | 84/6~88/ | Engine OIL PUMP |
| 03905 8375 | MD008762 | 35 x 50 x 8 | PAJERO 4D56 LO44,LO49,L144,L149,V14,V24,V34,V44,V47 | 86/4~97/ | Engine CAM SHAFT |
| 03905 8408 | MD009038 | 17 x 28 x 7 | PAJERO 4D55,4D56 | 82/4~97/ | Engine BALANCER SHAFT(RH) |
| 03905 4154 | MD050608 | 25 x 35 x 6 | PAJERO 4G64 | 96/3~99/ | Engine BALANCER SHAFT(RH) |
| 03905 3575 | MD050608 | 25 x 35 x 6 | PAJERO G63B | 82/4~88/ | Engine BALANCER SHAFT(RH) |
| 03905 7352 | MD050608 | 25 x 35 x 6 | PAJERO 4D55,4D56 | 82/4~97/ | Engine BALANCER SHAFT(LH) |
| 03905 4529 | MD152603 | 30 x 42 x 8 x 8.4 | PAJERO 6G74 V25,V45,V65,V75 | 93/7~ | Engine CAM SHAFT |
| 03905 7013 | MD008762 | 35 x 50 x 8 | PAJERO 4G64 V21 | 96/3~99/ | Engine CAM SHAFT |
| 03905 3434 | MD008762 | 35 x 50 x 8 | PAJERO 6G74 V55 | 97/8~97/11 | Engine CAM SHAFT |
| 03905 3389 | MD008762 | 35 x 50 x 8 | PAJERO 6G72 L141,L146,V23,V43,V63,V73 | 88/9~ | Engine CAM SHAFT |
| 03905 4466 | MD008882 | 44 x 60 x 7 | PAJERO G63B,4D55,4D56,4G64 | 82/4~99/ | Engine CRANK SHAFT FRONT |
| 03905 4628 | MD184303 | | PAJERO 6G72 IN. | 00/6~ | Engine VALVE STEM SEAL |
| 03905 2339 | ME203250 | 90.5 x 114 x 12 | PAJERO 4M40,4M41 | 99/6~ | Engine CRANK SHAFT REAR |
| 03905 6422 | MD120699 | 91 x 111 x 9 | PAJERO 6G74 | 93/7~00/2 | Engine CRANK SHAFT REAR |
| 03905 6149 | MD372251 | 91 x 111 x 7.5 | PAJERO 6G72,6G74 | 00/2~ | Engine CRANK SHAFT REAR |
| 03905 5078 | MD359158 | 85 x 103 x 7.5 | PAJERO 4G64 | 96/3~99/ | Engine CRANK SHAFT REAR |
| 03905 2132 | ME200012 | 92 x 114 x 8 x 17 | PAJERO 4M40 | 93/7~96/2 | Engine CRANK SHAFT REAR |
| 03905 3104 | ME202115 | 90 x 114 x 10.5 x 17 | PAJERO 4M40 | 96/3~96/10 | Engine CRANK SHAFT REAR |
| 03905 4520 | ME202851 | 94.5 x 114 x 12 | PAJERO 4M40 | 96/11~99/5 | Engine CRANK SHAFT REAR |
| 03905 6512 | MB837719 | 37 x 62 x 12.5 | PAJERO LO4#,L14# | 82/4~90/ | Wheel Hub REAR INNER |
| 03905 8513 | MD184303 | | PAJERO 4G64 IN. & EX. | 96/3~99/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 6734 | MB837719 | 37 x 62 x 12.5 | PAJERO V14,V2#,V34,V4# | 90/10~99/ | Wheel Hub REAR INNER |
| 03905 1187 | MD307342 | | PAJERO 6G72 EX. | 00/6~ | Engine VALVE STEM SEAL |
| 03905 3293 | MD306079 | | PAJERO 6G74 IN. | 93/7~ | Engine VALVE STEM SEAL |
| 03905 4724 | MD307343 | | PAJERO 6G74 EX. | 93/7~ | Engine VALVE STEM SEAL |
| 03905 3110 | ME241213 | | PAJERO 4M40 IN. & EX. | 93/7~99/1 | Engine VALVE STEM SEAL |
| 03905 4637 | ME241213 | | PAJERO 4M40 IN. & EX. | 99/1~99/ | Engine VALVE STEM SEAL |
| 03905 2954 | ME203255 | | PAJERO 4M41 IN. & EX. | 99/6~ | Engine VALVE STEM SEAL |
| 03905 2567 | MD120699 | 91 x 111 x 9 | PAJERO 6G72 | 97/3~00/2 | Engine CRANK SHAFT REAR |
| 03905 7259 | MD000508 | | PAJERO G63B,4D55,4D56,6G72 IN. & EX. | 82/4~92/9 | Engine VALVE STEM SEAL |
| 03905 2927 | MB936826 | 30 x 45 x 6.5 | PAJERO V25,V26,V45,V46,V55,V 63,V73 | 93/7~ | Mission & Differential (M/T) MISSION INPUT |
| 03905 8228 | MB160578 | 42 x 65 x 12 | PAJERO LO4#,L149 | 82/4~90/ | Drive Pinion FRONT |
| 03905 7307 | MB919210 | 42.8 x 55 x 10 x 11 | PAJERO V25,V26,V45,V46,V55,V 6#,V7# | 93/7~ | Mission & Differential (A/T) TRANSFER REAR OUTPUT |
| 03905 2123 | MD731708 | 39.6 x 52 x 10 x 11 | PAJERO V14,V21,V23,V24,V34,V 43,V47 | 90/10~99/ | Mission & Differential (A/T) TRANSFER REAR OUTPUT |
| 03905 1013 | MD731708 | 39.6 x 52 x 10 x 11 | PAJERO LO4#,L14# | 82/4~90/ | Mission & Differential (A/T) TRANSFER REAR OUTPUT |
| 03905 5402 | MD712012 | 36 x 52 x 10 x 11 | PAJERO ALL MODEL | 82/4~ | Mission & Differential (A/T) TRANSFER FRONT OUTPUT |
| 03905 8939 | MR145792 | 45 x 68.2 x 8.5 | PAJERO LO4#,L14#,V2#,34,4#,55, 6#,7#...ATM | 82/4~ | Mission & Differential (A/T) TRANSFER INPUT |
| 03905 2180 | MR145502 | 45 x 68.2 x 15 | PAJERO LO4#,L14#,V14,2#,34,4#, 55,63,73 MTM | 82/4~ | Mission & Differential (A/T) TRANSFER INPUT |
| 03905 7676 | MB526395 | 57 x 75 x 7.5 x 11.5 | PAJERO LO4#,L14#,V14,V2#,V34, V4# | 82/4~99/ | Wheel Hub FRONT |
| 03905 1358 | MR350599 | 45 x 68.2 x 7 x 8 | PAJERO V21,V23,V24,V25,V26,V 34,V43,V45,V46,V47 | 90/10~99/ | Mission & Differential (A/T) EXTENTION HOUSING |
| 03905 6089 | MB160578 | 42 x 65 x 12 | PAJERO V14,V21(AT),V23(AT),V 24,V43(AT),V47 | 90/10~99/ | Drive Pinion FRONT |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1220 | MH034067 | 32 x 45 x 8 | PAJERO V23,V24,V43,V44,V47 | 90/10~99/ | Mission & Differential (M/T) MISSION INPUT |
| 03905 4049 | MH034067 | 32 x 45 x 8 | PAJERO L14# | 88/9~90/ | Mission & Differential (M/T) MISSION INPUT |
| 03905 8798 | MD723202 | 30 x 45 x 6 | PAJERO V21 | 96/3~99/ | Mission & Differential (M/T) MISSION INPUT |
| 03905 3200 | MD723202 | 30 x 45 x 6 | PAJERO V14,V34 | 90/10~93/ | Mission & Differential (M/T) MISSION INPUT |
| 03905 1493 | MD723202 | 30 x 45 x 6 | PAJERO LO4# | 82/4~90/ | Mission & Differential (M/T) MISSION INPUT |
| 03905 2222 | MB664612 | 50 x 75 x 9 | PAJERO V2#,V4# | 90/10~99/ | Wheel Hub REAR OUTER |
| 03905 4919 | MB092437 | 50 x 65 x 10 | PAJERO V14,V34 | 90/10~93/ | Wheel Hub REAR OUTER |
| 03905 6662 | MB092437 | 50 x 65 x 10 | PAJERO LO4#,L14# | 82/4~90/ | Wheel Hub REAR OUTER |
| 03905 4859 | MR350599 | 45 x 68.2 x 7 x 8 | PAJERO V55,V63,V65,V68,V73,V75,V78 | 97/8~ | Mission & Differential (A/T) CASE ADAPTER |
| 03905 1898 | MA181498 | 51 x 65 x 9 | PAJERO MINI, JR H51,53,56,57,58 WITHOUT ABS | 94/12~ | Wheel Hub REAR |
| 03905 4796 | MR983239 | 28 x 45 x 10 | PAJERO MINI, JR H51,53 | 94/12~ | Transmission (M/T) REAR EXTENTION |
| 03905 1619 | MB808444 | 51.9 x 66 x 8 x 10 | PAJERO MINI, JR H51,53,56,57,58 | 94/12~ | Wheel Hub FRONT OUTER |
| 03905 7439 | MD179175 | | PAJERO MINI, JR 4A30,4A31 | 94/12~ | Engine VALVE STEM SEAL |
| 03905 8909 | MN114457 | 22 x 32 x 5 | PAJERO MINI, JR H5# | 94/12~ | Transmission (M/T) FRONT |
| 03905 2744 | MB808443 | 54 x 76 x 8 x 11 | PAJERO MINI, JR H51,53,56,57,58 | 94/12~ | Wheel Hub FRONT INNER |
| 03905 3137 | MR983239 | 28 x 45 x 10 | PAJERO MINI, JR H56,58 WITHOUT TURBO | 94/12~ | Transmission (M/T) REAR EXTENTION |
| 03905 1553 | MD701430 | 32 x 48 x 10 | PAJERO MINI, JR H56,57,58 TURBO | 94/12~ | Transmission (M/T) REAR EXTENTION |
| 03905 5435 | MB092620 | 35 x 55 x 11 | PAJERO MINI, JR H56,57,58(4WD) | 94/12~ | Final Drive PINION(FRONT) |
| 03905 1520 | MD329374 | 70 x 87 x 8.5 | PAJERO MINI, JR 4A30,4A31 | 94/12~ | Engine CRANK SHAFT REAR |
| 03905 5795 | MD707184 | 35 x 56 x 9 x 12 | PAJERO MINI, JR H56,57,58(4WD) | 94/12~ | Final Drive DIFF. SIDE(FRONT) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2171 | MD162689 | 35 x 47 x 8.5 | PAJERO MINI, JR 4A30,4A31(SOHC) H51,53,56,57,58 | 94/12~ | Engine CAM SHAFT |
| 03905 4622 | MD008762 | 35 x 50 x 8 | PAJERO MINI, JR 4A30(DOHC) H51,53,56,58 | 94/12~ | Engine CAM SHAFT |
| 03905 7667 | MD168057 | 20 x 30 x 7 x 7.5 | PAJERO MINI, JR 4A30,4A31 | 94/12~ | Engine OIL PUMP |
| 03905 5894 | MD115245 | 31 x 45 x 7 | PAJERO MINI, JR 4A30,4A31 | 94/12~ | Engine CRANK SHAFT FRONT |
| 03905 1265 | MB393929 | 35 x 65 x 12 | PAJERO MINI, JR H51,53,56,57,58 | 94/12~ | Final Drive PINION(REAR) |
| 03905 4130 | MR196784 | 33 x 60 x 15 | PAJERO MINI, JR H51,53,56,57,58 WITH ABS | 94/12~ | Wheel Hub REAR |
| 03905 8114 | MD150161 | 85 x 103 x 8 | RVR N13W,23W 4G63 | 92/5~97/ | Engine CRANK SHAFT REAR |
| 03905 6689 | MD069947 | 80 x 96 x 9 | RVR N13W,23W 4G63 | 91/1~92/4 | Engine CRANK SHAFT REAR |
| 03905 1457 | MD008882 | 44 x 60 x 7 | RVR N28W 4D68 | 92/9~97/ | Engine CRANK SHAFT FRONT |
| 03905 1772 | MD008882 | 44 x 60 x 7 | RVR N13W,23W#,64WG,73WG,74WG 4G63,64 | 91/1~ | Engine CRANK SHAFT FRONT |
| 03905 6674 | MD168055 | 37 x 50 x 6 | RVR N11W,21W,61W,71W 4G93 | 91/5~ | Engine CRANK SHAFT FRONT |
| 03905 8144 | MD050608 | 25 x 35 x 6 | RVR N13W,23W#,64WG,73WG,74WG 4G63,64 | 91/1~ | Engine BALANCER SHAFT |
| 03905 5933 | MD150161 | 85 x 103 x 8 | RVR N11W,21W 4G93 | 91/5~97/ | Engine CRANK SHAFT REAR |
| 03905 6551 | MD050608 | 25 x 35 x 6 | RVR N28#...4D68 | 92/9~97/ | Engine BALANCER SHAFT |
| 03905 6812 | MD359158 | 85 x 103 x 7.5 | RVR N28W 4D68 | 92/8~97/ | Engine CRANK SHAFT REAR |
| 03905 2003 | MD359158 | 85 x 103 x 7.5 | RVR N61W,64WG,71W,73WG, 74WG 4G93,63,64 | 97/1~ | Engine CRANK SHAFT REAR |
| 03905 7931 | MD184303 | | RVR 4G93 | 91/5~ | Engine VALVE STEM SEAL |
| 03905 8810 | MD307343 | | RVR 4G63 | 91/1~97/ | Engine VALVE STEM SEAL |
| 03905 7595 | MD307343 | | RVR 4G63,64 IN. | 97/1~99/11 | Engine VALVE STEM SEAL |
| 03905 8600 | MD306079 | | RVR 4G63,64 IN. | 99/12~ | Engine VALVE STEM SEAL |
| 03905 1850 | MD095355 | 20 x 30 x 7 | RVR N28#...4D68 | 92/9~97/ | Engine OIL PUMP |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 4577 | MD197467 | | RVR 4D68 | 92/9~97/ | Engine VALVE STEM SEAL |
| 03905 4556 | MD758763 | 41 x 61 x 11.5 x 16 | RVR N71W,73WG,74WG | 97/11~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(L&R) |
| 03905 7847 | MD307343 | | RVR 4G63,64 EX. | 97/1~ | Engine VALVE STEM SEAL |
| 03905 3269 | MB633434 | 57 x 76 x 6.8 x 9.5 | RVR N21WG,23WG,28WG | 92/9~97/ | Wheel Hub FRONT OUTER |
| 03905 5567 | MB573309 | 54 x 82 x 8 x 11 | RVR N11W,13W,21W,23W,28 W | 91/1~97/ | Wheel Hub FRONT INNER |
| 03905 9038 | MB633432 | 60 x 86 x 7 x 12 | RVR N21W SNXE,SRXE | 94/9~96/4 | Wheel Hub FRONT INNER |
| 03905 7673 | MB633432 | 60 x 86 x 7 x 12 | RVR N21WG,23WG,28WG | 92/9~97/ | Wheel Hub FRONT INNER |
| 03905 3425 | MB393929 | 35 x 65 x 12 | RVR N21W#,23W#,28W#,71W, 73WG,74WG | 91/1~ | Mission & Differential (M/T&A/T) REAR DRIVE PINION |
| 03905 7712 | MB633434 | 57 x 76 x 6.8 x 9.5 | RVR N21W SNXE,SRXE | 94/9~96/4 | Wheel Hub FRONT OUTER |
| 03905 5987 | MD095355 | 20 x 30 x 7 | RVR N13W,23W#,64WG,73W G,74WG 4G63,64 | 91/1~ | Engine OIL PUMP |
| 03905 4337 | MD741818 | 25 x 35 x 6 | RVR N1#,2# | 91/1~97/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 6281 | MB936826 | 30 x 45 x 6.5 | RVR N73WG | 97/11~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 6296 | MD707184 | 35 x 56 x 9 x 12 | RVR N21W#,23W#,28W#,71W, 73WG,74WG | 91/1~ | Mission & Differential (M/T&A/T) REAR DIFF. SIDE |
| 03905 7916 | MB303875 | 52 x 72 x 8 x 11 | RVR N11W,13W,21W,23W,28 W | 91/1~97/ | Wheel Hub FRONT OUTER |
| 03905 5240 | MD008762 | 35 x 50 x 8 | RVR N1#,2#,6#,7# | 91/1~ | Engine CAM SHAFT |
| 03905 6827 | MD707184 | 35 x 56 x 9 x 12 | RVR N11W,13W | 91/1~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 6848 | MD707575 | 42 x 60 x 9 | RVR N1#,2#,6#,7# | 91/1~ | Mission & Differential (M/T&A/T) CONVERTER OIL PUMP |
| 03905 4847 | MD755904 | 41 x 61 x 9 x 13.5 | RVR N61W,64WG | 97/11~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(L&R) |
| 03905 4784 | MD707184 | 35 x 56 x 9 x 12 | RVR N11W,13W,21#,23#,28# | 91/1~ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(RH) |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 5546 | MD719710 | 35 x 54 x 10 x 17 | RVR N21#,23#,28# | 91/1~97/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(LH) |
| 03905 5921 | MD701430 | 32 x 48 x 10 | STARION A182 | 82/4~83/ | Transmission REAR |
| 03905 5444 | MB664285 | 44 x 72 x 12 | STARION A187 | 88/4~90/ | Final Drive PINION |
| 03905 1283 | MD020308 | 48 x 68 x 11 | STARION G54B A187 | 88/4~90/ | Engine CRANK SHAFT FRONT |
| 03905 2939 | MD008882 | 44 x 60 x 7 | STARION G63B | 82/4~88/ | Engine CRANK SHAFT FRONT |
| 03905 8768 | MD168057 | 20 x 30 x 7 x 7.5 | STARION G63B | 85/5~88/ | Engine OIL PUMP |
| 03905 5192 | MD009038 | 17 x 28 x 7 | STARION G63B | 82/4~85/4 | Engine OIL PUMP |
| 03905 1316 | MD050608 | 25 x 35 x 6 | STARION G63B | 82/4~88/ | Engine BALANCER SHAFT |
| 03905 1196 | MD008762 | 35 x 50 x 8 | STARION G63B A182,183,184 | 82/4~88/ | Engine CAM SHAFT |
| 03905 4829 | MD069947 | 80 x 96 x 9 | STARION G63B,G54B | 82/4~90/ | Engine CRANK SHAFT REAR |
| 03905 2360 | MB393929 | 35 x 65 x 12 | STARION A182 | 82/4~83/ | Final Drive PINION |
| 03905 9047 | MD703743 | 36 x 52 x 10 | STARION A183,184,187 | 82/4~90/ | Transmission REAR |
| 03905 1370 | MD723202 | 30 x 45 x 6 | STARION A18# | 82/4~90/ | Transmission FRONT |
| 03905 6434 | MB092186 | 40 x 65 x 10 | STARION A183,184,187 | 82/4~90/ | Wheel Hub REAR |
| 03905 3479 | MA181498 | 51 x 65 x 9 | STARION A182 | 82/4~83/ | Wheel Hub REAR |
| 03905 8177 | MB584745 | 45 x 62 x 6 | STARION A18# | 82/4~90/ | Wheel Hub FRONT |
| 03905 5756 | MB092145 | 42 x 65 x 12 | STARION A183,184 | 82/4~88/ | Final Drive PINION |
| 03905 5510 | MB160949 | 45 x 72 x 12 x 19.5 | STRADA K34T,K74T | 91/3~ | Drive Pinion REAR |
| 03905 7652 | MB351696 | | STRADA K34T | 91/3~97/ | Power Steering SEAL KIT |
| 03905 1415 | MR374193 | | STRADA K74T | 97/5~ | Power Steering SEAL KIT |
| 03905 5144 | MB553255 | | STRADA K34T | 91/3~97/ | Power Steering SECTOR SHAFT SEAL KIT |
| 03905 1082 | MR151065 | | STRADA K74T | 97/5~ | Power Steering SECTOR SHAFT SEAL KIT |
| 03905 4022 | MD008762 | 35 x 50 x 8 | STRADA 4D56 K34T,K74T | 91/3~ | Engine CAM SHAFT |
| 03905 1643 | MB160578 | 42 x 65 x 12 | STRADA K34T,K74T | 91/3~ | Drive Pinion FRONT |
| 03905 5366 | MD069947 | 80 x 96 x 9 | STRADA 4D56 | 91/3~ | Engine CRANK SHAFT REAR |
| 03905 5936 | MD050608 | 25 x 35 x 6 | STRADA 4D56 | 91/3~ | Engine BALANCER SHAFT(LH) |
| 03905 8663 | MD000508 | | STRADA 4D56 IN. & EX. | 91/3~92/9 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7190 | MD197467 | | STRADA 4D56 IN. & EX. | 92/1 | Engine VALVE STEM SEAL |
| 03905 2441 | MD009038 | 17 x 28 x 7 | STRADA 4D56 | 91/3~ | Engine BALANCER SHAFT(RH) |
| 03905 8807 | MB837719 | 37 x 62 x 12.5 | STRADA K34T,K74T | 91/3~ | Wheel Hub REAR INNER |
| 03905 6443 | MD731708 | 39.6 x 52 x 10 x 11 | STRADA K34T,K74T | 91/3~ | Mission & Differential (A/T) TRANSFER REAR OUTPUT |
| 03905 5957 | MD008882 | 44 x 60 x 7 | STRADA 4D56 | 91/3~ | Engine CRANK SHAFT FRONT |
| 03905 3149 | MB526395 | 57 x 75 x 7.5 x 11.5 | STRADA K34T,K74T | 91/3~ | Wheel Hub FRONT |
| 03905 7901 | MB092437 | 50 x 65 x 10 | STRADA K34T | 91/3~97/ | Wheel Hub REAR OUTER |
| 03905 5033 | MB664612 | 50 x 75 x 9 | STRADA K74T | 97/5~ | Wheel Hub REAR OUTER |
| 03905 8813 | MD723202 | 30 x 45 x 6 | STRADA K34T | 91/3~97/ | Mission & Differential (M/T) MISSION INPUT |
| 03905 3719 | MH034067 | 32 x 45 x 8 | STRADA K74T | 97/5~ | Mission & Differential (M/T) MISSION INPUT |
| 03905 1751 | MD609235 | 45 x 68.2 x 7 x 8 | STRADA K74T | 97/5~ | Mission & Differential (A/T) EXTENTION HOUSING |
| 03905 6968 | MR145502 | 45 x 68.2 x 15 | STRADA K34T,K74T MTM | 91/3~ | Mission & Differential (A/T) TRANSFER INPUT |
| 03905 5978 | MR145792 | 45 x 68.2 x 8.5 | STRADA K74T ATM | 97/5~ | Mission & Differential (A/T) TRANSFER INPUT |
| 03905 7829 | MD712012 | 36 x 52 x 10 x 11 | STRADA K34T,K74T | 91/3~ | Mission & Differential (A/T) TRANSFER FRONT OUTPUT |
| 03905 7442 | MD162689 | 35 x 47 x 8.5 | TOPPO BJ H41,46(4A30) SOHC | 98/10~02/ | Engine CAM SHAFT |
| 03905 8453 | MD321819 | 60 x 75 x 8 | TOPPO BJ 3G83 | 98/10~ | Engine CRANK SHAFT REAR |
| 03905 2225 | MD329374 | 70 x 87 x 8.5 | TOPPO BJ 4A30,4A31 | 98/10~ | Engine CRANK SHAFT REAR |
| 03905 5762 | MD379845 | 31 x 45 x 7 | TOPPO BJ 4G30,4G31,3G83 | 98/10~ | Engine CRANK SHAFT FRONT |
| 03905 8246 | MD343566 | 17 x 28 x 7 | TOPPO BJ 3G83 | 98/10~ | Engine OIL PUMP |
| 03905 8234 | MD168057 | 20 x 30 x 7 x 7.5 | TOPPO BJ 4A30,4A31 | 98/10~ | Engine OIL PUMP |
| 03905 8969 | MD133317 | 35 x 50 x 8 | TOPPO BJ H41,46(4A30) DOHC | 98/10~02/ | Engine CAM SHAFT |
| 03905 8981 | MD179175 | | TOPPO BJ 4A30,4A31,3G83 | 98/10~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 7865 | MD707184 | 35 x 56 x 9 x 12 | TOPPO BJ H4# | 98/10~ | Mission & Differential (A/T) FRONT DIFF. CASE |
| 03905 6884 | MN114457 | 22 x 32 x 5 | TOPPO BJ H4# | 98/10~ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 7073 | MB936241 | 33 x 50 x 13 | TOPPO BJ H47,48(4WD) WITH ABS | 98/10~ | Wheel Hub REAR |
| 03905 3740 | MV026391 | 35 x 46 x 8 | TOPPO BJ H47,48(4WD) WITHOUT ABS | 98/10~ | Wheel Hub REAR |
| 03905 3932 | MD162689 | 35 x 47 x 8.5 | TOPPO BJ H43,48(4A30) | 99/1~ | Engine CAM SHAFT |
| 03905 7610 | MD162689 | 35 x 47 x 8.5 | TOPPO BJ H42,47(3G83) | 98/10~ | Engine CAM SHAFT |
| 03905 3218 | MD179175 | | TOWN BOX 3G83,4A31 | 94/4~ | Engine VALVE STEM SEAL |
| 03905 3821 | MD009038 | 17 x 28 x 7 | TOWN BOX 3G83 | 99/4~ | Engine OIL PUMP |
| 03905 4097 | MD168057 | 20 x 30 x 7 x 7.5 | TOWN BOX 4A30,4A31 | 99/4~ | Engine OIL PUMP |
| 03905 3716 | MD358891 | | TOWN BOX 4A30 EX. | 99/4~ | Engine VALVE STEM SEAL |
| 03905 3638 | MD115245 | 31 x 45 x 7 | TOWN BOX 3G83,4A30,4A31 | 99/4~ | Engine CRANK SHAFT FRONT |
| 03905 3686 | MD179175 | | TOWN BOX 4A30 IN. | 99/4~ | Engine VALVE STEM SEAL |
| 03905 7562 | MD329374 | 70 x 87 x 8.5 | TOWN BOX 4A30,4A31 | 99/4~ | Engine CRANK SHAFT REAR |
| 03905 3647 | MR983239 | 28 x 45 x 10 | TOWN BOX U61 WITHOUT TURBO | 99/4~ | Transmission (M/T) REAR EXTENTION |
| 03905 7076 | MD008762 | 35 x 50 x 8 | TOWN BOX 4A30(TURBO) U63,64 | 99/4~ | Engine CAM SHAFT |
| 03905 8534 | MD321819 | 60 x 75 x 8 | TOWN BOX 3G83 | 99/4~ | Engine CRANK SHAFT REAR |
| 03905 4136 | MB092620 | 35 x 55 x 11 | TOWN BOX U61,62 WITHOUT TURBO | 99/4~ | Final Drive PINION |
| 03905 4196 | MD162689 | 35 x 47 x 8.5 | TOWN BOX 3G83 U61,62 | 99/4~ | Engine CAM SHAFT |
| 03905 7625 | MB393929 | 35 x 65 x 12 | TOWN BOX U63,64,65,66 | 99/4~ | Final Drive PINION |
| 03905 2429 | MB393929 | 35 x 65 x 12 | TOWN BOX U61,62 TURBO | 02/8~ | Final Drive PINION |
| 03905 4580 | MD701430 | 32 x 48 x 10 | TOWN BOX U61 TURBO,U63 | 99/4~ | Transmission (M/T) REAR EXTENTION |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 2351 | MN114457 | 22 x 32 x 5 | TOWN BOX U6# | 99/4~ | Transmission (M/T) FRONT |
| 03905 7112 | MR399191 | 28 x 50 x 11 | TOWN BOX U61,62,63,64,65,66 WITH ABS | 99/4~ | Wheel Hub REAR |
| 03905 2126 | MB001115 | 41 x 55 x 9 | TOWN BOX U61,62,63,64,65,66 WITHOUT ABS | 99/4~ | Wheel Hub REAR |
| 03905 8573 | MD162689 | 35 x 47 x 8.5 | TOWN BOX 4A31 U65,66 | 99/6~01/ | Engine CAM SHAFT |
| 03905 6971 | MD153103 | 35 x 50 x 8 | TREDIA / CORDIA G6B A213 | 82/3~87/ | Engine CAM SHAFT |
| 03905 2510 | MD069950 | 25 x 35 x 6 | TREDIA / CORDIA G6B | 82/3~87/ | Engine BALANCER SHAFT |
| 03905 4499 | MD069948 | 17 x 28 x 7 | TREDIA / CORDIA G6B | 82/3~85/4 | Engine OIL PUMP |
| 03905 5969 | MD168057 | 20 x 30 x 7 x 7.5 | TREDIA / CORDIA G6B | 85/5~87/ | Engine OIL PUMP |
| 03905 8720 | MD153104 | 30 x 46 x 7 | TREDIA / CORDIA G1B | 82/3~84/ | Engine CRANK SHAFT FRONT |
| 03905 3665 | MD050606 | 44 x 60 x 7 | TREDIA / CORDIA G3B,G6B | 82/3~87/ | Engine CRANK SHAFT FRONT |
| 03905 6287 | MD016549 | 72 x 96 x 9 | TREDIA / CORDIA G1B,G3B | 82/3~87/ | Engine CRANK SHAFT REAR |
| 03905 1913 | MD069947 | 80 x 96 x 9 | TREDIA / CORDIA G6B | 82/3~87/ | Engine CRANK SHAFT REAR |
| 03905 4964 | MD153103 | 35 x 50 x 8 | TREDIA / CORDIA G3B A212,215 | 82/3~87/ | Engine CAM SHAFT |
| 03905 7223 | MD000508 | | TREDIA / CORDIA G3B,G6B | 82/3~87/ | Engine VALVE STEM SEAL |
| 03905 5903 | MD151463 | 28 x 40 x 8 | TREDIA / CORDIA G3B | 84/9~87/ | Engine BALANCER SHAFT |
| 03905 7565 | MD307343 | | TREDIA / CORDIA G1B | 82/3~84/ | Engine VALVE STEM SEAL |
| 03905 3245 | MB176746 | 50 x 66.5 x 13 x 16 | TREDIA / CORDIA A215G BHZ,BHZ2 | 84/10~87/ | Wheel Hub FRONT OUTER |
| 03905 5273 | MD069948 | 17 x 28 x 7 | TREDIA / CORDIA G3B | 82/3~87/ | Engine OIL PUMP |
| 03905 8201 | MB176746 | 50 x 66.5 x 13 x 16 | TREDIA / CORDIA A211A,212A,213A,G,215 A | 82/3~87/ | Wheel Hub FRONT INNER |
| 03905 4649 | MD153103 | 35 x 50 x 8 | TREDIA / CORDIA G1B A211 | 82/3~84/ | Engine CAM SHAFT |
| 03905 4505 | MB176746 | 50 x 66.5 x 13 x 16 | TREDIA / CORDIA A215G BHZ,BHZ2 | 84/10~87/ | Wheel Hub FRONT INNER |
| 03905 5084 | MB176746 | 50 x 66.5 x 13 x 16 | TREDIA / CORDIA A211A,212A,213A,G,215 A | 82/3~87/ | Wheel Hub FRONT OUTER |

# 5. Seals product list

## 5.5 MITSUBISHI / FUSO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03905 1106 | MB303875 | 52 x 72 x 8 x 11 | TREDIA / CORDIA A215G BHZ3 | 85/10~87/ | Wheel Hub FRONT OUTER |
| 03905 8804 | MA125844 | 38 x 52 x 6 | TREDIA / CORDIA A21#...2WD | 82/3~87/ | Wheel Hub REAR |
| 03905 7580 | MB393807 | 36 x 64 x 11 x 19 | TREDIA / CORDIA A213G,215G(4WD) | 86/1~87/ | Wheel Hub REAR |
| 03905 1796 | MD069950 | 25 x 35 x 6 | TREDIA / CORDIA A21#...ALL | 82/3~87/ | Mission & Differential (M/T) INPUT SHAFT |
| 03905 5696 | MD707184 | 35 x 56 x 9 x 12 | TREDIA / CORDIA A21#...ALL | 82/3~87/ | Mission & Differential (M/T&A/T) FRONT DIFF. CASE(L&R) |
| 03905 2570 | MB303867 | 50 x 82 x 8 x 11 | TREDIA / CORDIA A215G BHZ3 | 85/10~87/ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 6197 | 0603 16 103 | 27 x 43 x 9 | ATENZA GGEP,GGES,GG3P,GG3S,GYEW,GY3W | 02/5~ | Mission & Differential INPUT SHAFT |
| 03906 8477 | F003 27 238A | 35 x 56 x 9 x 15 | ATENZA GGEP,GGES,GG3P,GG3S,GYEW,GY3W 2WD | 02/5~ | Mission & Differential FRONT DIFF. SIDE |
| 03906 8661 | FP20 27 238A | 47 x 61 x 10 | ATENZA GY3W 4WD | 02/5~ | Mission & Differential FRONT DIFF. SIDE (RH) |
| 03906 8749 | L807 10 155 | | ATENZA LF,L3 INTAKE | 02/5~ | Engine VALVE STEM SEAL |
| 03906 6901 | FP01 27 238 | 40 x 56 x 8 x 13 | ATENZA GY3W 4WD | 02/5~ | Mission & Differential FRONT DIFF. SIDE (LH) |
| 03906 4093 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | ATENZA GY3W 4WD | 02/5~ | Mission & Differential REAR DIFF. SIDE |
| 03906 3509 | LF01 10 155 | | ATENZA LF,L3 EXHAUST | 02/5~ | Engine VALVE STEM SEAL |
| 03906 3053 | LF01 10 602 | 37 x 50 x 8 | ATENZA L3(2300) GG3P,GY3W | 02/5~ | Engine TIMING GEAR COVER |
| 03906 1205 | LF01 10 602 | 37 x 50 x 8 | ATENZA LF(2000) GGEP,GGES,GYEW | 02/5~ | Engine TIMING GEAR COVER |
| 03906 2693 | M054 27 165 | 40 x 64 x 11 x 16 | ATENZA GY3W 4WD | 02/5~ | Mission & Differential REAR DIFF. PINION |
| 03906 3245 | F003 27 238A | 35 x 56 x 9 x 15 | AXELA BKEP(2000) | 03/10~ | Transmission & Differential DIFF. SIDE (LH & RH) |
| 03906 5301 | LF01 10 155 | | AXELA ZY INTAKE | 03/10~ | Engine VALVE STEM SEAL |
| 03906 2437 | BP05 11 312 | 83 x 100 x 9 | AXELA ZY BK5P(1500) | 03/10~ | Engine CRANK SHAFT REAR |
| 03906 8429 | LF01 10 602 | 37 x 50 x 8 | AXELA L3 BK3P(2300) | 03/10~ | Engine TIMING GEAR COVER |
| 03906 5613 | LF01 10 602 | 37 x 50 x 8 | AXELA LF BKEP(2000) | 03/10~ | Engine TIMING GEAR COVER |
| 03906 3445 | F003 27 238A | 35 x 56 x 9 x 15 | AXELA BK3P(2300) | 03/10~ | Transmission & Differential DIFF. SIDE (LH & RH) |
| 03906 3125 | F003 27 238A | 35 x 56 x 9 x 15 | AXELA BK5P(1500) | 03/10~ | Transmission & Differential DIFF. SIDE (LH & RH) |
| 03906 4445 | 0603 16 103 | 27 x 43 x 9 | AXELA BK3P(2300) | 03/10~ | Transmission & Differential INPUT SHAFT |
| 03906 5245 | 0613 16 103 | 24 x 40 x 8 | AXELA BK5P(1500) | 03/10~ | Transmission & Differential INPUT SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2925 | L807 10 155 | | AXELA LF,L3 INTAKE | 03/10~ | Engine VALVE STEM SEAL |
| 03906 8029 | LF01 10 1F5 | | AXELA ZY,LF,L3 EXHAUST | 03/10~ | Engine VALVE STEM SEAL |
| 03906 4621 | FS02 10 602 | 42.5 x 54.5 x 6 | AXELA ZY BK5P(1500) | 03/10~ | Engine TIMING GEAR COVER |
| 03906 4253 | F285 11 399A | 90 x 110 x 9 x 10 | BONGO SS,SE,SK 1800(F8) | 90/11~ | Engine CRANK SHAFT REAR |
| 03906 6917 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SK(VAN) ST/4WD/MT | 99/5~ | Differential PINION |
| 03906 7237 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS(VAN) WIDE LOW (DSL) | 90/1~95/ | Differential PINION |
| 03906 2029 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS,SE(WAGON,TRUCK) | 83/9~90/1 | Differential PINION |
| 03906 2389 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS(WAGON) EXCEPT LSD/AT | 90/1~95/ | Differential PINION |
| 03906 9181 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS(WAGON) MT (WITHOUT I/C) | 93/8~95/ | Differential PINION |
| 03906 2877 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SE(TRUCK) | 90/1~99/ | Differential PINION |
| 03906 3781 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS(VAN) | 95/9~99/ | Differential PINION |
| 03906 5405 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SK(VAN) ST/2WD,ST/4WD/AT,WT | 99/5~ | Differential PINION |
| 03906 7133 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SK(TRUCK) ST/2WD,WT | 99/5~ | Differential PINION |
| 03906 7485 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SS(VAN) 2WD(S TIRE) | 83/9~90/1 | Differential PINION |
| 03906 1941 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SS(VAN) 4WD(2200) | 87/9~95/ | Differential PINION |
| 03906 7181 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SS(VAN) EXCEPT WIDE LOW | 90/1~95/ | Differential PINION |
| 03906 1237 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SS(WAGON) LSD/AT | 90/1~95/ | Differential PINION |
| 03906 2661 | RF01 10 155 | | BONGO SS,SE,SK 2000DSL(RF),2200(R2) | 83/9~ | Engine VALVE STEM SEAL |
| 03906 5117 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SS(WAGON) | 95/9~98/ | Differential PINION |
| 03906 7117 | M005 27 165 | 40 x 64 x 12 x 17.5 | BONGO SS(VAN,TRUCK) 1400 MT | 83/9~86/ | Differential PINION |
| 03906 2333 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SK(TRUCK) ST/4WD | 99/5~ | Differential PINION |
| 03906 3253 | 0187 10 5078 | 40 x 55 x 8 | BONGO BA,SS,SE 1300,1400,1500 | 77/8~95/ | Engine TIMING GEAR COVER |
| 03906 7413 | 0221 10 6028 | 48 x 70 x 12 | BONGO BA 1600,1800 | 77/8~83/ | Engine TIMING GEAR COVER |
| 03906 5045 | F801 10 602 | 34 x 48 x 7 | BONGO SS,SE,SK 1800(F8),2000(FE) | 83/9~ | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2269 | F801 10 602 | 34 x 48 x 7 | BONGO SS,SE,SK 2000DSL(RF),2200DSL(R2) | 83/9~ | Engine TIMING GEAR COVER |
| 03906 7389 | SE08 10 602 | 50 x 70 x 11 | BONGO BA DIESEL | 79/10~ | Engine TIMING GEAR COVER |
| 03906 1309 | F801 10 602 | 34 x 48 x 7 | BONGO SS,SE,SK 1800(F8),2000(FE) | 83/9~ | Engine CAM SHAFT |
| 03906 4229 | B630 10 602 | 30 x 44 x 7 | BONGO SS,SE,SK 2000DSL(RF),2200DSL(R2) | 83/9~ | Engine CAM SHAFT |
| 03906 5333 | 0453 11 399 | 80 x 105 x 13 | BONGO BA 1600,1800 | 77/8~83/ | Engine CRANK SHAFT REAR |
| 03906 7325 | F801 11 399 | 90 x 110 x 9 | BONGO SS,SE,SK 2000DSL(RF),2200DSL(R2) | 83/9~ | Engine CRANK SHAFT REAR |
| 03906 5253 | FE5H 11 399A | 90 x 110 x 9 x 10.5 | BONGO SS,SE,SK 2000(FE) | 90/11~ | Engine CRANK SHAFT REAR |
| 03906 1389 | HE19 10 155 | | BONGO SS,SE 1800(F8),2000(FE) | 83/9~99/ | Engine VALVE STEM SEAL |
| 03906 5309 | B630 10 155 | | BONGO SK...(1800)F8 | 99/5~ | Engine VALVE STEM SEAL |
| 03906 4429 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO SS(WAGON) WITH INTER COOLER | 93/8~95/ | Differential PINION |
| 03906 2357 | 1391 26 157 | 29 x 36 x 8 | BONGO SS,SE W TIRE | 83/9~99/ | Wheel Hub REAR OUTER |
| 03906 6509 | S113 33 067 | 52 x 70 x 9 | BONGO SS,SE 2WD | 83/9~99/ | Wheel Hub FRONT |
| 03906 7341 | 9958 54 8659 | 48 x 65 x 9 | BONGO BA# | 77/8~83/ | Wheel Hub FRONT |
| 03906 8253 | F801 11 399 | 90 x 110 x 9 | BONGO SS,SE 1800(F8),2000(FE) | 83/9~90/11 | Engine CRANK SHAFT REAR |
| 03906 4541 | S113 33 067 | 52 x 70 x 9 | BONGO SK 2WD | 99/5~ | Wheel Hub FRONT |
| 03906 3229 | UC86 33 065A | 65 x 82 x 95 x 13.5 | BONGO SS,SE 4WD | 84/10~99/ | Wheel Hub FRONT INNER |
| 03906 5213 | UC86 33 067 | 60 x 75 x 86 x 12 | BONGO SS,SE 4WD | 84/10~99/ | Wheel Hub FRONT OUTER |
| 03906 9085 | 9958 55 5782 | 55 x 78 x 12 | BONGO BA# | 77/8~83/ | Wheel Hub REAR INNER |
| 03906 1197 | 9958 55 5782 | 55 x 78 x 12 | BONGO SS,SE 2WD(W TIRE) | 83/9~85/1 | Wheel Hub REAR INNER |
| 03906 7125 | S126 26 154 | 55 x 78 x 10 | BONGO SS,SE 2WD(W TIRE) | 85/2~99/ | Wheel Hub REAR INNER |
| 03906 6045 | S126 26 154 | 55 x 78 x 10 | BONGO SK W TIRE | 99/5~ | Wheel Hub REAR INNER |
| 03906 2789 | 1011 26 154 | 48 x 62 x 9 | BONGO SS,SE 2WD,4WD(S TIRE) | 83/9~99/ | Wheel Hub REAR INNER |
| 03906 7869 | S269 26 154 | 55 x 78 x 11 | BONGO SE TRUCK 4WD | 84/10~99/ | Wheel Hub REAR INNER |
| 03906 2373 | S41P 26 154 | 33 x 58 x 9 | BONGO SK S TIRE WITH ABS | 99/5~ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2845 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS(VAN) 4WD(1800) | 84/10~95/ | Differential PINION |
| 03906 8973 | 0603 16 103 | 27 x 43 x 9 | BONGO SS,SE,SK 4WD GAS | 95/9~ | Transmission FRONT COVER |
| 03906 1413 | SE08 11 399 | 101 x 125 x 13 | BONGO BA DIESEL | 79/10~83/ | Engine CRANK SHAFT REAR |
| 03906 1405 | 0223 27 018 | 40 x 64 x 12 | BONGO BA# | 77/8~83/ | Differential PINION |
| 03906 1517 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO SS,SE,SK 2WD GAS | 95/9~ | Transmission REAR |
| 03906 1829 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO SS,SE,SK 2WD DSL | 93/8~ | Transmission REAR |
| 03906 5645 | 0437 17 335A | 35 x 48 x 15 | BONGO SS,SE 2WD GAS | 93/8~95/9 | Transmission REAR |
| 03906 6253 | S41A 26 154 | 46 x 62 x 9 | BONGO SK S TIRE WITHOUT ABS | 99/5~ | Wheel Hub REAR INNER |
| 03906 7197 | H501 17 103 | 27 x 43 x 7 | BONGO SS,SE,SK 2WD GAS,DSL | 95/9~ | Transmission FRONT COVER |
| 03906 4125 | 1391 26 157 | 29 x 36 x 8 | BONGO BA# | 77/8~83/ | Wheel Hub REAR OUTER |
| 03906 4317 | 0603 16 103 | 27 x 43 x 9 | BONGO BA,SS,SE 1600,1800,2000,DSL | 77/8~95/9 | Transmission FRONT COVER |
| 03906 3981 | 0613 16 103 | 24 x 40 x 8 | BONGO BA,SS,SE 1300,1400,1500 | 77/8~95/ | Transmission FRONT COVER |
| 03906 3421 | S381 26 157A | 47 x 57.7 x 12.5 | BONGO SS,SE 4WD(S TIRE) | 87/7~99/ | Wheel Hub REAR OUTER |
| 03906 4677 | S231 26 157 | 47 x 57.6 x 78 x 12 | BONGO SS,SE 4WD(S TIRE) | 84/10~87/ 7 | Wheel Hub REAR OUTER |
| 03906 7725 | 1391 26 157 | 29 x 36 x 8 | BONGO SK W TIRE | 99/5~ | Wheel Hub REAR OUTER |
| 03906 3197 | M054 27 165 | 40 x 64 x 11 x 16 | BONGO SS(VAN) 2WD (W TIRE) | 83/9~90/1 | Differential PINION |
| 03906 2749 | 0437 17 335A | 35 x 48 x 15 | BONGO BA#,SS,SE 2WD | 77/8~93/8 | Transmission REAR |
| 03906 4389 | 0370 11 399 | 70 x 88 x 12 | BONGO BA,SS,SE 1300,1400,1500 | 77/8~95/ | Engine CRANK SHAFT REAR |
| 03906 7293 | M064 27 165 | 40 x 64 x 11 x 16 | BONGO BRAWNY SR WAGON(GASOLINE) | 90/3~95/ | Differential PINION |
| 03906 8621 | F801 10 602 | 34 x 48 x 7 | BONGO BRAWNY F8(1800 GAS.),FE(2000 GAS.) | 83/6~ | Engine CRANK SHAFT FRONT |
| 03906 1965 | B630 10 602 | 30 x 44 x 7 | BONGO BRAWNY RF(2000 DIE.)R2(2200 DIE.) | 83/6~ | Engine CAM SHAFT |
| 03906 1717 | F801 10 602 | 34 x 48 x 7 | BONGO BRAWNY F8(1800GAS.),FE(2000 GAS.) | 83/6~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 4261 | W001 27 165 | 50 x 75 x 12 x 17 | BONGO BRAWNY SK TRUCK/S TIRE/LONG BODY | 99/7~ | Differential PINION |
| 03906 5893 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO BRAWNY SK VAN,TRUCK(EXC. S TIRE/LONG BODY) | 99/7~ | Differential PINION |
| 03906 1669 | S483 26 154 | 65 x 90 x 13 | BONGO BRAWNY SR,SD W TIRE(4WD) | 87/9~99/ | Wheel Hub REAR INNER |
| 03906 4557 | 0437 17 335A | 35 x 48 x 15 | BONGO BRAWNY SR 2000 GAS. (WITHOUT EGI) | 93/9~95/ | Transmission REAR |
| 03906 3237 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO BRAWNY SR VAN# | 83/6~99/ | Differential PINION |
| 03906 1421 | VS01 10 602 | 53 x 70 x 11 | BONGO BRAWNY WL(2500 DIE.) | 97/4~ | Engine TIMING GEAR COVER(NO.1) |
| 03906 5357 | M064 27 165 | 40 x 64 x 11 x 16 | BONGO BRAWNY SR WAGON | 87/9~90/3 | Differential PINION |
| 03906 5853 | M005 27 165 | 40 x 64 x 12 x 17.5 | BONGO BRAWNY SR WAGON | 83/6~87/9 | Differential PINION |
| 03906 4829 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO BRAWNY SK | 99/7~ | Transmission REAR |
| 03906 2957 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO BRAWNY SR,SD | 95/8~99/ | Transmission REAR |
| 03906 1845 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO BRAWNY SR,SD 1800,2000(WITH EGI),DSL | 93/9~95/ | Transmission REAR |
| 03906 4845 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO BRAWNY SR WAGON(DIESEL) | 90/3~93/8 | Transmission REAR |
| 03906 6533 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO BRAWNY SR,SD VAN,TRUCK | 83/6~93/8 | Transmission REAR |
| 03906 6717 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO BRAWNY SR WAGON (DIESEL) | 90/3~95/ | Differential PINION |
| 03906 8821 | G601 11 399 | 90 x 110 x 9 x 12 | BONGO BRAWNY WL(2500 DIE.) | 97/4~99/ | Engine CRANK SHAFT REAR |
| 03906 3853 | WL01 10 155 | | BONGO BRAWNY WL | 97/4~ | Engine VALVE STEM SEAL |
| 03906 5421 | SE70 10 155 | | BONGO BRAWNY VS EXHAUST | 92/2~97/ | Engine VALVE STEM SEAL |
| 03906 2613 | SE01 10 155A | | BONGO BRAWNY VS INTAKE | 92/2~97/ | Engine VALVE STEM SEAL |
| 03906 1901 | RF01 10 155 | | BONGO BRAWNY RF,R2 | 83/6~ | Engine VALVE STEM SEAL |
| 03906 6989 | B630 10 155 | | BONGO BRAWNY FE | 95/8~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 9141 | B630 10 155 | | BONGO BRAWNY F8,FE WITH EGI | 93/8~95/ | Engine VALVE STEM SEAL |
| 03906 3261 | HE19 10 155 | | BONGO BRAWNY F8 | 95/8~99/ | Engine VALVE STEM SEAL |
| 03906 6301 | F801 10 602 | 34 x 48 x 7 | BONGO BRAWNY RF(2000 DIE.),R2(2200 DIE.) | 83/6~ | Engine CRANK SHAFT FRONT |
| 03906 3133 | HE19 10 155 | | BONGO BRAWNY F8,FE | 83/6~93/8 | Engine VALVE STEM SEAL |
| 03906 4565 | VS01 10 602 | 53 x 70 x 11 | BONGO BRAWNY VS(3000 DIE.) | 92/2~97/ | Engine TIMING GEAR COVER |
| 03906 4901 | SE08 11 399 | 101 x 125 x 13 | BONGO BRAWNY VS(3000 DIE.) | 92/2~97/ | Engine CRANK SHAFT REAR |
| 03906 1925 | F285 11 399A | 90 x 110 x 9 x 10 | BONGO BRAWNY WL(2500 DIE.) | 99/7~ | Engine CRANK SHAFT REAR |
| 03906 3285 | F285 11 399A | 90 x 110 x 9 x 10 | BONGO BRAWNY FE(2000 GAS.) | 90/11~ | Engine CRANK SHAFT REAR |
| 03906 1765 | FE5H 11 399A | 90 x 110 x 9 x 10.5 | BONGO BRAWNY F8(1800 GAS.) | 90/11~93/ | Engine CRANK SHAFT REAR |
| 03906 9189 | F801 11 399 | 90 x 110 x 9 | BONGO BRAWNY RF(2000 DIE.), R2(2200 DIE.) | 83/6~99/ | Engine CRANK SHAFT REAR |
| 03906 5005 | F801 11 399 | 90 x 110 x 9 | BONGO BRAWNY F8(1800 GAS.),FE(2000 GAS.) | 83/6~90/11 | Engine CRANK SHAFT REAR |
| 03906 2413 | WL01 10 602 | 60 x 76 x 7 | BONGO BRAWNY WL(2500 DIE.) | 97/4~ | Engine TIMING GEAR COVER(NO.2) |
| 03906 4709 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO BRAWNY SD W TIRE,S TIRE(STANDARD BODY) | 83/6~99/ | Differential PINION |
| 03906 3413 | HE19 10 155 | | BONGO BRAWNY F8,FE WITHOUT EGI | 93/8~95/ | Engine VALVE STEM SEAL |
| 03906 5933 | 0603 26 154 | 35 x 55 x 8 | BONGO BRAWNY SR S TIRE | 85/9~87/9 | Wheel Hub REAR INNER |
| 03906 4933 | S49S 26 154 | 36 x 61 x 9 | BONGO BRAWNY SK S TIRE WITHOUT ABS | 99/7~ | Wheel Hub REAR INNER |
| 03906 4293 | S46F 26 154 | 44 x 68 x 9 | BONGO BRAWNY SK S TIRE WITH ABS | 99/7~ | Wheel Hub REAR INNER |
| 03906 3221 | S483 26 154 | 65 x 90 x 13 | BONGO BRAWNY SK W TIRE | 99/7~ | Wheel Hub REAR INNER |
| 03906 2173 | S113 33 067 | 52 x 70 x 9 | BONGO BRAWNY SR,SD 2WD | 83/6~99/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7021 | S113 33 067 | 52 x 70 x 9 | BONGO BRAWNY SK 2WD | 99/7~ | Wheel Hub FRONT |
| 03906 6877 | UC86 33 065A | 65 x 82 x 95 x 13.5 | BONGO BRAWNY SR,SDSK 4WD | 85/8~ | Wheel Hub FRONT INNER |
| 03906 4781 | UC86 33 067 | 60 x 75 x 86 x 12 | BONGO BRAWNY SR,SDSK 4WD | 85/8~ | Wheel Hub FRONT OUTER |
| 03906 5149 | 0603 26 157 | 48 x 70 x 9 | BONGO BRAWNY SR S TIRE | 83/6~87/9 | Wheel Hub REAR OUTER |
| 03906 6013 | 9958 55 5729 | 55 x 72 x 9 | BONGO BRAWNY SD S TIRE(STANDART BODY) | 83/6~85/8 | Wheel Hub REAR INNER |
| 03906 3677 | U840 26 154 | 35 x 58 x 10 | BONGO BRAWNY SR S TIRE(EXCEPT 3000CC) | 87/9~95/8 | Wheel Hub REAR INNER |
| 03906 6237 | 0603 26 154 | 35 x 55 x 8 | BONGO BRAWNY SD S TIRE(STANDARD BODY) | 85/9~87/9 | Wheel Hub REAR INNER |
| 03906 2341 | 0437 17 335A | 35 x 48 x 15 | BONGO BRAWNY SR WAGON(GASOLINE) | 90/3~93/8 | Transmission REAR |
| 03906 2005 | U840 26 154 | 35 x 58 x 10 | BONGO BRAWNY SR S TIRE ALL | 95/8~99/ | Wheel Hub REAR INNER |
| 03906 7157 | W001 27 165 | 50 x 75 x 12 x 17 | BONGO BRAWNY SD S TIRE (LONG BODY) | 83/6~99/ | Differential PINION |
| 03906 7973 | 0604 26 154 | 58 x 80 x 9 | BONGO BRAWNY SD S TIRE(LONG BODY) | 83/12~97/ | Wheel Hub REAR INNER |
| 03906 4973 | 0604 26 154 | 58 x 80 x 9 | BONGO BRAWNY SR S TIRE(3000CC) | 92/2~95/8 | Wheel Hub REAR INNER |
| 03906 4301 | W001 33 065 | 65 x 90 x 13 | BONGO BRAWNY SR,SD W TIRE(2WD) | 83/6~88/1 | Wheel Hub REAR INNER |
| 03906 3013 | S483 26 154 | 65 x 90 x 13 | BONGO BRAWNY SR,SD W TIRE(2WD) | 88/1~99/ | Wheel Hub REAR INNER |
| 03906 4077 | 9958 55 5729 | 55 x 72 x 9 | BONGO BRAWNY SR S TIRE | 83/6~85/8 | Wheel Hub REAR INNER |
| 03906 8525 | H501 17 103 | 27 x 43 x 7 | BONGO BRAWNY SR,SD GASOLINE (WITH EGI) | 93/9~95/ | Transmission FRONT COVER |
| 03906 1533 | U840 26 154 | 35 x 58 x 10 | BONGO BRAWNY SD SR TIRE(STANDARD BODY) | 87/9~99/ | Wheel Hub REAR INNER |
| 03906 4037 | 0603 26 157 | 48 x 70 x 9 | BONGO BRAWNY SD S TIRE(STANDARD BODY) | 83/6~87/9 | Wheel Hub REAR OUTER |
| 03906 2261 | H501 17 103 | 27 x 43 x 7 | BONGO BRAWNY SR,SD DIESEL(3000) | 92/2~95/ | Transmission FRONT COVER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 1133 | 0603 16 103 | 27 x 43 x 9 | BONGO BRAWNY SR,SD DIESEL(2000,2200) | 83/6~95/ | Transmission FRONT COVER |
| 03906 7829 | 0603 16 103 | 27 x 43 x 9 | BONGO BRAWNY SR,SD GASOLINE (WITHOUT EGI) | 93/9~95/ | Transmission FRONT COVER |
| 03906 6333 | 0603 16 103 | 27 x 43 x 9 | BONGO BRAWNY SR,SD GASOLINE# | 83/6~93/8 | Transmission FRONT COVER |
| 03906 7893 | 1416 26 157 | 38 x 45 x 8 | BONGO BRAWNY SK W TIRE | 99/7~ | Wheel Hub REAR OUTER |
| 03906 8069 | 1416 26 157 | 38 x 45 x 8 | BONGO BRAWNY SR,SD W TIRE | 83/6~99/ | Wheel Hub REAR OUTER |
| 03906 8349 | 0604 26 184 | 42 x 65 x 9 | BONGO BRAWNY SD S TIRE(LONG BODY) | 83/6~95/8 | Wheel Hub REAR OUTER |
| 03906 5501 | UB40 26 157 | 48 x 70 x 10 | BONGO BRAWNY SK S TIRE | 99/7~ | Wheel Hub REAR OUTER |
| 03906 4997 | UB40 26 157 | 48 x 70 x 10 | BONGO BRAWNY SD S TIRE(ALL) | 95/8~97/ | Wheel Hub REAR OUTER |
| 03906 4189 | UB40 26 157 | 48 x 70 x 10 | BONGO BRAWNY SD S TIRE(STANDARD BODY) | 87/9~99/ | Wheel Hub REAR OUTER |
| 03906 7749 | H501 17 103 | 27 x 43 x 7 | BONGO BRAWNY SK | 99/7~ | Transmission FRONT COVER |
| 03906 5277 | 0604 26 184 | 42 x 65 x 9 | BONGO BRAWNY SR S TIRE(3000CC) | 92/2~99/ | Wheel Hub REAR OUTER |
| 03906 4005 | H501 17 103 | 27 x 43 x 7 | BONGO BRAWNY SR,SD | 95/8~99/ | Transmission FRONT COVER |
| 03906 3917 | 0437 17 335A | 35 x 48 x 15 | BONGO BRAWNY SR WAGON | 83/6~90/3 | Transmission REAR |
| 03906 3941 | UB40 26 157 | 48 x 70 x 10 | BONGO BRAWNY SR S TIRE(EXCEPT 3000CC) | 87/9~99/ | Wheel Hub REAR OUTER |
| 03906 7309 | KL02 10 155 | | BONGO FRIENDEE J5(2500 V6) SG5W | 95/6~ | Engine VALVE STEM SEAL |
| 03906 1213 | JE26 12 602A | 65 x 81 x 7 | BONGO FRIENDEE J5(2500 V6) SG5W | 95/6~ | Engine CAM SHAFT (LH) |
| 03906 3653 | JE26 12 601A | 38 x 52 x 7 | BONGO FRIENDEE J5(2500 V6) SG5W | 95/6~ | Engine CAM SHAFT (RH) |
| 03906 3181 | RF03 12 603A | 32 x 46 x 7 | BONGO FRIENDEE WL(2500 DSL) SGL3,SGLW,SGL5,SGLR | 95/6~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7405 | F285 11 399A | 90 x 110 x 9 x 10 | BONGO FRIENDEE FE(2000) SGEW,SGE3 | 95/6~ | Engine CRANK SHAFT REAR |
| 03906 7693 | JF01 11 312A | 75 x 93 x 9 | BONGO FRIENDEE J5(2500 V6) SG5W | 95/6~ | Engine CRANK SHAFT REAR |
| 03906 4869 | G601 11 399 | 90 x 110 x 9 x 12 | BONGO FRIENDEE WL(2500 DSL) SGL3,SGLW,SGL5,SGLR | 95/6~99/ | Engine CRANK SHAFT REAR |
| 03906 9197 | B630 10 155 | | BONGO FRIENDEE FE(2000) SGEW,SGE3 | 95/6~ | Engine VALVE STEM SEAL |
| 03906 8877 | WL01 10 155 | | BONGO FRIENDEE WL(2500 DSL) SGL3,SGLW,SGL5,SGLR | 95/6~ | Engine VALVE STEM SEAL |
| 03906 7013 | JE15 10 602A | 43 x 55 x 6 | BONGO FRIENDEE J5(2500 V6) SG5W | 95/6~ | Engine OIL PUMP |
| 03906 7997 | M504 17 335 | 42 x 65 x 11 | BONGO FRIENDEE SGL#...4WD | 95/6~99/ | Transmission (M/T) REAR |
| 03906 7589 | F285 11 399A | 90 x 110 x 9 x 10 | BONGO FRIENDEE WL(2500 DSL) SGL3,SGLW,SGL5,SGLR | 99/~ | Engine CRANK SHAFT REAR |
| 03906 6085 | H501 17 103 | 27 x 43 x 7 | BONGO FRIENDEE SGL# | 95/6~99/ | Transmission (M/T) FRONT |
| 03906 4149 | S10H 26 154 | 61 x 71 x 6 | BONGO FRIENDEE SG#...WITHOUT ABS | 95/6~ | Wheel Hub REAR INNER |
| 03906 8469 | R503 17 335 | 40 x 53 x 72 x 26 | BONGO FRIENDEE SGL#...4WD | 95/6~ | Transfer REAR |
| 03906 3525 | S10H 26 157 | 79 x 86 x 4 | BONGO FRIENDEE SG# | 95/6~ | Wheel Hub REAR OUTER |
| 03906 5157 | FE01 10 602 | 34 x 48 x 7 | BONGO FRIENDEE FE(2000) SGEW,SGE3 | 95/6~ | Engine OIL PUMP |
| 03906 8557 | M502 17 335A | 38 x 51 x 13 x 15 | BONGO FRIENDEE SGL#...2WD | 95/6~99/ | Transmission (M/T) REAR |
| 03906 5877 | R502 17 335 | 44 x 90 x 9 x 21 | BONGO FRIENDEE SGL#...4WD | 95/6~ | Transfer FRONT |
| 03906 4733 | R001 27 165 | 40 x 75 x 11 x 16.5 | BONGO FRIENDEE SG# | 95/6~ | Differential REAR DIFF. PINION |
| 03906 3373 | FE01 10 602 | 34 x 48 x 7 | BONGO FRIENDEE FE(2000) SGEW,SGE3 | 95/6~ | Engine TIMING COVER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 1245 | VS01 10 602 | 53 x 70 x 11 | BONGO FRIENDEE WL(2500 DSL) SGL3,SGLW,SGL5,SGLR | 95/6~ | Engine TIMING COVER NO.1 |
| 03906 7837 | WL01 10 602 | 60 x 76 x 7 | BONGO FRIENDEE WL(2500 DSL) SGL3,SGLW,SGL5,SGLR | 95/6~ | Engine TIMING COVER NO.2 |
| 03906 6581 | S09H 26 154 | 40 x 52 x 8 | BONGO FRIENDEE SG#...WITH ABS | 95/6~ | Wheel Hub REAR INNER |
| 03906 8261 | G304 33 065 | 56 x 68 x 5 x 11 | CAPELLA / TELATSR / 626 VAN, WAGON GV#,GW#...4WD | 90/8~02/ | Wheel Hub REAR |
| 03906 8845 | KL02 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON RF GWFW | 98/7~02/ | Engine VALVE STEM SEAL |
| 03906 5917 | G304 33 065 | 56 x 68 x 5 x 11 | CAPELLA / TELATSR / 626 VAN, WAGON GV#,GW# | 88/1~02/ | Wheel Hub FRONT |
| 03906 1157 | G717 26 154 | 47 x 64 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON GV#...2WD | 88/1~97/ | Wheel Hub REAR |
| 03906 6005 | BP01 10 602A | 30 x 44 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON KL | 97/10~02/ | Engine CAM SHAFT |
| 03906 1733 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | CAPELLA / TELATSR / 626 VAN, WAGON GV#,GW#...4WD | 90/8~02/ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 2629 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | CAPELLA / TELATSR / 626 VAN, WAGON GV#,GW#...4WD | 90/8~02/ | Transmission & Differential REAR DIFF. SIDE |
| 03906 6805 | B630 10 602 | 30 x 44 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON B6(1600) GV6V | 88/1~90/9 | Engine OIL PUMP |
| 03906 8797 | B3C7 10 602A | 36.5 x 50.5 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON B6(1600) GV6V | 90/9~99/ | Engine OIL PUMP |
| 03906 4325 | 0603 16 103 | 27 x 43 x 9 | CAPELLA / TELATSR / 626 VAN, WAGON GV#...2WD,4WD (DSL) | 88/1~97/ | Transmission & Differential INPUT SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2565 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON FE(2000) GVEW/R | 90/8~97/ | Engine OIL PUMP |
| 03906 2949 | KL02 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON FP,FS,KL EXHAUST | 97/10~02/ | Engine VALVE STEM SEAL |
| 03906 4837 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELATSR / 626 VAN, WAGON FP(1800) GW8W | 97/10~02/ | Engine OIL PUMP |
| 03906 4949 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELATSR / 626 VAN, WAGON FS(2000) GWEW/R | 97/10~02/ | Engine OIL PUMP |
| 03906 8861 | FS02 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELATSR / 626 VAN, WAGON KL(2500 V6) GW5R | 97/10~02/ | Engine OIL PUMP |
| 03906 5261 | F003 27 238A | 35 x 56 x 9 x 15 | CAPELLA / TELATSR / 626 VAN, WAGON GV#...2WD | 88/1~02/ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 6773 | B630 10 602 | 30 x 44 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON B6,RF | 88/1~02/ | Engine CAM SHAFT |
| 03906 8501 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON F8(1800) GV8W | 88/1~97/ | Engine OIL PUMP |
| 03906 3749 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON F8,FE,FP,FS | 88/1~02/ | Engine CAM SHAFT |
| 03906 3493 | B630 11 312 | 83 x 100 x 9 | CAPELLA / TELATSR / 626 VAN, WAGON B6 | 88/1~99/ | Engine CRANK SHAFT REAR |
| 03906 4397 | F801 11 399 | 90 x 110 x 9 | CAPELLA / TELATSR / 626 VAN, WAGON F8,FE,RF | 88/1~97/ | Engine CRANK SHAFT REAR |
| 03906 6933 | FS01 11 399 | 90 x 109 x 9 x 10.5 | CAPELLA / TELATSR / 626 VAN, WAGON FP,FS | 97/10~02/ | Engine CRANK SHAFT REAR |
| 03906 6149 | KL01 11 312 | 75 x 93 x 9 | CAPELLA / TELATSR / 626 VAN, WAGON KL | 97/10~02/ | Engine CRANK SHAFT REAR |
| 03906 4669 | B630 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON B6 | 88/1~99/ | Engine VALVE STEM SEAL |
| 03906 2653 | B630 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON F8 | 88/1~92/6 | Engine VALVE STEM SEAL |
| 03906 1757 | B660 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON F8 | 92/6~97/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 6109 | B660 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON FE | 90/8~97/ | Engine VALVE STEM SEAL |
| 03906 8669 | KL01 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON FP,FS,KL INTAKE | 97/10~02/ | Engine VALVE STEM SEAL |
| 03906 8837 | RF01 10 155 | | CAPELLA / TELATSR / 626 VAN, WAGON RF GVF# | 88/1~99/ | Engine VALVE STEM SEAL |
| 03906 6709 | RF2A 10 602 | 51.5 x 64 x 6 | CAPELLA / TELATSR / 626 VAN, WAGON RF(2000 DSL) GWFW | 98/7~02/ | Engine OIL PUMP |
| 03906 4485 | 0603 16 103 | 27 x 43 x 9 | CAPELLA / TELATSR / 626 VAN, WAGON GW# | 97/10~02/ | Transmission & Differential INPUT SHAFT |
| 03906 1501 | H501 17 103 | 27 x 43 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON GV#...4WD(GAS.) | 90/8~97/ | Transmission & Differential INPUT SHAFT |
| 03906 1461 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELATSR / 626 VAN, WAGON RF(2000 DSL) GVFW/R,GVFV | 89/5~99/ | Engine OIL PUMP |
| 03906 2917 | KL01 11 312 | 75 x 93 x 9 | CAPELLA / TELSTAR / 626 SEDAN K8,KF,KL | 91/1~94/ | Engine CRANK SHAFT REAR |
| 03906 6317 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELSTAR / 626 SEDAN FP(1800) CG2PP,GF8P | 94/7~02/ | Engine OIL PUMP |
| 03906 5389 | B630 10 602 | 30 x 44 x 7 | CAPELLA / TELSTAR / 626 SEDAN B6(1600) GD6P | 87/3~90/8 | Engine OIL PUMP |
| 03906 7421 | B3C7 10 602A | 36.5 x 50.5 x 7 | CAPELLA / TELSTAR / 626 SEDAN B6(1600) GD6P | 90/8~92/ | Engine OIL PUMP |
| 03906 8853 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN F6,F8,FE | 82/9~91/ | Engine CAM SHAFT |
| 03906 1557 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN FS | 91/1~ | Engine CAM SHAFT |
| 03906 8709 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN FP | 94/7~ | Engine CAM SHAFT |
| 03906 2501 | B630 10 602 | 30 x 44 x 7 | CAPELLA / TELSTAR / 626 SEDAN RF | 83/8~99/ | Engine CAM SHAFT |
| 03906 8205 | B630 10 602 | 30 x 44 x 7 | CAPELLA / TELSTAR / 626 SEDAN B6 | 87/3~92/ | Engine CAM SHAFT |
| 03906 1973 | B630 10 602 | 30 x 44 x 7 | CAPELLA / TELSTAR / 626 SEDAN K8,KF,KL | 91/10~95/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 4085 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELSTAR / 626 SEDAN FS(2000) GESRF,CG2SP/R,GFEP/R | 91/10~02/ | Engine OIL PUMP |
| 03906 4957 | B630 11 312 | 83 x 100 x 9 | CAPELLA / TELSTAR / 626 SEDAN B6 | 87/3~92/ | Engine CRANK SHAFT REAR |
| 03906 4021 | B660 10 155 | | CAPELLA / TELSTAR / 626 SEDAN FE | 87/3~91/ | Engine VALVE STEM SEAL |
| 03906 2485 | FS01 11 399 | 90 x 109 x 9 x 10.5 | CAPELLA / TELSTAR / 626 SEDAN FS,FP | 91/1~02/ | Engine CRANK SHAFT REAR |
| 03906 8341 | HE19 10 155 | | CAPELLA / TELSTAR / 626 SEDAN F6,F8,FE | 82/9~87/3 | Engine VALVE STEM SEAL |
| 03906 7813 | B630 10 155 | | CAPELLA / TELSTAR / 626 SEDAN F8,B6 | 87/3~91/ | Engine VALVE STEM SEAL |
| 03906 1285 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELSTAR / 626 SEDAN KB(1800) GE8PF | 91/10~95/ | Engine OIL PUMP |
| 03906 6421 | RF01 10 155 | | CAPELLA / TELSTAR / 626 SEDAN RF | 83/8~96/ | Engine VALVE STEM SEAL |
| 03906 9117 | KL02 10 155 | | CAPELLA / TELSTAR / 626 SEDAN K8,KF,KL,FS,FP EXHAUST | 91/1~ | Engine VALVE STEM SEAL |
| 03906 8885 | KL02 10 155 | | CAPELLA / TELSTAR / 626 SEDAN RF | 98/6~99/ | Engine VALVE STEM SEAL |
| 03906 8125 | F801 11 399 | 90 x 110 x 9 | CAPELLA / TELSTAR / 626 SEDAN F6,F8,FE,RF | 82/9~99/ | Engine CRANK SHAFT REAR |
| 03906 4173 | F003 27 238A | 35 x 56 x 9 x 15 | CAPELLA / TELSTAR / 626 SEDAN GC,GD,GE,CG,GF 2WD | 82/9~02/ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 8533 | KL01 10 155 | | CAPELLA / TELSTAR / 626 SEDAN K8,KF,KL,FS,FP INTAKE | 91/1~ | Engine VALVE STEM SEAL |
| 03906 5829 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELSTAR / 626 SEDAN KL(2500) GE5PF | 92/4~95/ | Engine OIL PUMP |
| 03906 3845 | RF2A 10 602 | 51.5 x 64 x 6 | CAPELLA / TELSTAR / 626 SEDAN RF(DSL) GFFP | 98/6~99/ | Engine OIL PUMP |
| 03906 1685 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN RF(DSL) GCFP,GEFPF | 83/8~96/ | Engine OIL PUMP |
| 03906 7469 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN FE(2000) GCEP,GDE# | 82/9~92/ | Engine OIL PUMP |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2813 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN F8(1800) GC8P,GD8# | 82/9~92/ | Engine OIL PUMP |
| 03906 3773 | F801 10 602 | 34 x 48 x 7 | CAPELLA / TELSTAR / 626 SEDAN F6(1600) GC6P | 82/9~87/ | Engine OIL PUMP |
| 03906 7941 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | CAPELLA / TELSTAR / 626 SEDAN GD,GE,CG,GF 4WD | 87/3~02/ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 6981 | H501 17 103 | 27 x 43 x 7 | CAPELLA / TELSTAR / 626 SEDAN GD,GE,CG 4WD | 89/4~95/ | Transmission & Differential INPUT SHAFT |
| 03906 1357 | 0603 16 103 | 27 x 43 x 9 | CAPELLA / TELSTAR / 626 SEDAN GF ALL | 97/6~02/ | Transmission & Differential INPUT SHAFT |
| 03906 4461 | 0603 16 103 | 27 x 43 x 9 | CAPELLA / TELSTAR / 626 SEDAN CG2SR(#102026) 4WD | 95/~97/ | Transmission & Differential INPUT SHAFT |
| 03906 2853 | GJ21 26 154 | 42 x 58 x 7 | CAPELLA / TELSTAR / 626 SEDAN GD DRUM BRAKE | 87/3~91/ | Wheel Hub REAR |
| 03906 6213 | FS01 10 602 | 42.5 x 54.5 x 6 | CAPELLA / TELSTAR / 626 SEDAN KF(2000) GEEPF | 91/10~95/ | Engine OIL PUMP |
| 03906 6261 | G304 33 065 | 56 x 68 x 5 x 11 | CAPELLA / TELSTAR / 626 SEDAN GD#,GE,CG,GF | 87/3~02/ | Wheel Hub FRONT |
| 03906 5573 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | CAPELLA / TELSTAR / 626 SEDAN GD,GE,CG,GF 4WD | 87/3~02/ | Transmission & Differential REAR DIFF. SIDE |
| 03906 6173 | G030 26 154A | 39 x 50.5 x 7 | CAPELLA / TELSTAR / 626 SEDAN GC | 82/9~87/ | Wheel Hub REAR |
| 03906 3165 | 0603 16 103 | 27 x 43 x 9 | CAPELLA / TELSTAR / 626 SEDAN GD,GE,CG 2WD | 89/4~97/ | Transmission & Differential INPUT SHAFT |
| 03906 2157 | GJ21 26 154 | 42 x 58 x 7 | CAPELLA / TELSTAR / 626 SEDAN GD DISC BRAKE (2WD.2WS) | 87/3~91/ | Wheel Hub REAR |
| 03906 8933 | G717 26 154 | 47 x 64 x 7 | CAPELLA / TELSTAR / 626 SEDAN GD DISC BRAKE (2WD.2WS) | 87/3~91/ | Wheel Hub REAR |
| 03906 5621 | G304 33 065 | 56 x 68 x 5 x 11 | CAPELLA / TELSTAR / 626 SEDAN GD,GE,CG,GF 4WD | 87/3~02/ | Wheel Hub REAR |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 6629 | G001 25 744A | 38 x 62 x 7 x 8 | CAPELLA / TELSTAR / 626 SEDAN GC | 82/9~87/ | Front Drive Shaft DUST SEAL INNER |
| 03906 6285 | G001 25 742A | 43 x 56 x 7 x 9 | CAPELLA / TELSTAR / 626 SEDAN GC | 82/9~87/ | Front Drive Shaft DUST SEAL OUTER |
| 03906 2053 | 0603 16 103 | 27 x 43 x 9 | CAPELLA / TELSTAR / 626 SEDAN GC,GD ALL | 82/9~89/4 | Transmission & Differential INPUT SHAFT |
| 03906 3269 | FS01 10 602 | 42.5 x 54.5 x 6 | CLEF KL(2500 V6) GE5PA | 92/5~94/ | Engine OIL PUMP |
| 03906 3989 | F003 27 238A | 35 x 56 x 9 x 15 | CLEF GE#...2WD | 92/5~94/ | Transmission & Differential DIFF. SIDE |
| 03906 8085 | KL01 10 155 | | CLEF KF,KL,FS INTAKE | 92/5~94/ | Engine VALVE STEM SEAL |
| 03906 4045 | FS01 11 399 | 90 x 109 x 9 x 10.5 | CLEF FS | 92/5~94/ | Engine CRANK SHAFT REAR |
| 03906 2101 | KL01 11 312 | 75 x 93 x 9 | CLEF KF,KL | 92/5~94/ | Engine CRANK SHAFT REAR |
| 03906 5373 | F801 10 602 | 34 x 48 x 7 | CLEF FS | 92/5~94/ | Engine CAM SHAFT |
| 03906 5541 | B630 10 602 | 30 x 44 x 7 | CLEF KF,KL | 92/5~94/ | Engine CAM SHAFT |
| 03906 2301 | KL02 10 155 | | CLEF KF,KL,FS EXHAUST | 92/5~94/ | Engine VALVE STEM SEAL |
| 03906 7165 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | CLEF GESRA 4WD | 92/5~94/ | Transmission & Differential DIFF. SIDE |
| 03906 8309 | H501 17 103 | 27 x 43 x 7 | CLEF GESRA 4WD | 92/5~94/ | Transmission & Differential INPUT SHAFT |
| 03906 5189 | 0603 16 103 | 27 x 43 x 9 | CLEF GE#...2WD | 92/5~94/ | Transmission & Differential INPUT SHAFT |
| 03906 4773 | G304 33 065 | 56 x 68 x 5 x 11 | CLEF GESRA 4WD | 92/5~94/ | Wheel Hub REAR |
| 03906 6429 | G304 33 065 | 56 x 68 x 5 x 11 | CLEF GE# | 92/5~94/ | Wheel Hub FRONT |
| 03906 3565 | FS01 10 602 | 42.5 x 54.5 x 6 | CLEF KF(2000 V6) GEEPA | 92/5~94/ | Engine OIL PUMP |
| 03906 6389 | FS01 10 602 | 42.5 x 54.5 x 6 | CLEF FS(2000) GESRA | 92/5~94/ | Engine OIL PUMP |
| 03906 1485 | F801 11 399 | 90 x 110 x 9 | COSMO HB GASOLINE | 83/9~90/ | Engine CRANK SHAFT REAR |
| 03906 3693 | M005 27 165 | 40 x 64 x 12 x 17.5 | COSMO HB | 81/8~90/ | Differential PINION |
| 03906 3501 | F003 27 238A | 35 x 56 x 9 x 15 | COSMO HB I.R.SUS. | 83/9~90/ | Differential PINION |
| 03906 2365 | 0221 10 602B | 48 x 70 x 12 | COSMO CD,HB GASOLINE | 75/10~83/ 8 | Engine TIMING GEAR COVER |
| 03906 3613 | F801 10 602 | 34 x 48 x 7 | COSMO HB GASOLINE | 83/9~90/ | Engine TIMING GEAR COVER |
| 03906 2421 | 0223 27 018 | 40 x 64 x 12 | COSMO CD | 75/10~81/ | Differential PINION |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 8589 | 0453 11 399 | 80 x 105 x 13 | COSMO CD,HB GASOLINE | 75/10~83/8 | Engine CRANK SHAFT REAR |
| 03906 1349 | 0603 16 103 | 27 x 43 x 9 | COSMO CD,HB | 75/10~90/ | Transmission FRONT COVER |
| 03906 8101 | SE08 11 399 | 101 x 125 x 13 | COSMO HB DIESEL | 81/8~90/ | Engine CRANK SHAFT REAR |
| 03906 7701 | SE08 10 602 | 50 x 70 x 11 | COSMO HB DIESEL | 81/8~90/ | Engine TIMING GEAR COVER |
| 03906 3805 | 0290 25 151 | 32 x 52 x 8 | COSMO CD | 75/10~81/ | Propeller Shaft CENTER BEARING |
| 03906 7429 | 0437 17 335A | 35 x 48 x 15 | COSMO HB ALL | 83/9~90/ | Transmission REAR |
| 03906 6437 | 0437 17 335A | 35 x 48 x 15 | COSMO CD | 75/10~81/ | Transmission REAR |
| 03906 2821 | 1011 26 154 | 48 x 62 x 9 | COSMO HB 5 LINK SUS. | 81/8~90/ | Wheel Hub REAR |
| 03906 8941 | 1011 26 154 | 48 x 62 x 9 | COSMO CD | 75/10~81/ | Wheel Hub REAR |
| 03906 3277 | H001 33 065A | 52 x 63 x 8 | COSMO HB | 81/8~90/ | Wheel Hub FRONT |
| 03906 4157 | 1312 33 065 | 40 x 54 x 6 | COSMO CD | 78/1~81/ | Wheel Hub FRONT |
| 03906 8325 | 9958 54 8629 | 48 x 62 x 9 | COSMO CD | 75/10~78/1 | Wheel Hub FRONT |
| 03906 6061 | HE19 10 155 | | COSMO CD,HB GASOLINE | 75/10~90/ | Engine VALVE STEM SEAL |
| 03906 4701 | 8599 17 335 | 35 x 48 x 10 | COSMO HB DIESEL | 81/8~83/8 | Transmission REAR |
| 03906 4533 | 0437 17 335A | 35 x 48 x 15 | COSMO HB GASOLINE | 81/8~83/8 | Transmission REAR |
| 03906 5981 | B630 10 602 | 30 x 44 x 7 | CRONOS K8,KF,KL,RF | 91/10~96/ | Engine CAM SHAFT |
| 03906 7301 | KL02 10 155 | | CRONOS K8,KF,KL,FS EXHAUST | 91/10~96/ | Engine VALVE STEM SEAL |
| 03906 8269 | KL01 10 155 | | CRONOS K8,KF,KL,FS INTAKE | 91/10~96/ | Engine VALVE STEM SEAL |
| 03906 3117 | F801 11 399 | 90 x 110 x 9 | CRONOS RF | 92/3~96/ | Engine CRANK SHAFT REAR |
| 03906 4493 | FS01 11 399 | 90 x 109 x 9 x 10.5 | CRONOS FS | 91/11~96/ | Engine CRANK SHAFT REAR |
| 03906 7061 | F801 10 602 | 34 x 48 x 7 | CRONOS FS | 91/11~96/ | Engine CAM SHAFT |
| 03906 3325 | RF01 10 155 | | CRONOS RF | 92/3~96/ | Engine VALVE STEM SEAL |
| 03906 5429 | F801 10 602 | 34 x 48 x 7 | CRONOS RF(2000 DSL) GEFP | 92/3~96/ | Engine OIL PUMP |
| 03906 1605 | FS01 10 602 | 42.5 x 54.5 x 6 | CRONOS KL(2500 V6) GE5P | 92/4~96/ | Engine OIL PUMP |
| 03906 4349 | G304 33 065 | 56 x 68 x 5 x 11 | CRONOS GESR 4WD | 91/11~96/ | Wheel Hub REAR |
| 03906 4141 | KL01 11 312 | 75 x 93 x 9 | CRONOS K8,KF,KL | 91/10~96/ | Engine CRANK SHAFT REAR |
| 03906 6397 | G304 33 065 | 56 x 68 x 5 x 11 | CRONOS GE8P,GEEP,GESR,GE5P,GEFP | 91/10~96/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7269 | FS01 10 602 | 42.5 x 54.5 x 6 | CRONOS FS(2000) GESR | 91/11~96/ | Engine OIL PUMP |
| 03906 6661 | 0603 16 103 | 27 x 43 x 9 | CRONOS GE#...2WD | 91/10~96/ | Transmission & Differential INPUT SHAFT |
| 03906 7989 | H501 17 103 | 27 x 43 x 7 | CRONOS GESR 4WD | 91/11~96/ | Transmission & Differential INPUT SHAFT |
| 03906 4309 | F003 27 238A | 35 x 56 x 9 x 15 | CRONOS GE#...2WD | 91/10~96/ | Transmission & Differential DIFF. SIDE |
| 03906 8981 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | CRONOS GESR 4WD | 91/11~96/ | Transmission & Differential DIFF. SIDE |
| 03906 8389 | FS01 10 602 | 42.5 x 54.5 x 6 | CRONOS K8(1800 V6) GE8P | 91/10~96/ | Engine OIL PUMP |
| 03906 6029 | FS01 10 602 | 42.5 x 54.5 x 6 | CRONOS KF(2000 V6) GEEP | 91/10~96/ | Engine OIL PUMP |
| 03906 8925 | B3C7 10 602A | 36.5 x 50.5 x 7 | DEMIO / FESTIVA MINIVAGON B3,B5 | 96/7~02/ | Engine OIL PUMP |
| 03906 3541 | LF01 10 155 | | DEMIO / FESTIVA MINIVAGON ZJ-VE,ZY-VE INTAKE | 02/6~ | Engine VALVE STEM SEAL |
| 03906 1885 | KL02 10 155 | | DEMIO / FESTIVA MINIVAGON B3,B5 | 96/7~02/ | Engine VALVE STEM SEAL |
| 03906 2645 | BP05 11 312 | 83 x 100 x 9 | DEMIO / FESTIVA MINIVAGON ZJ-VE,ZY-VE | 02/6~ | Engine CRANK SHAFT REAR |
| 03906 8653 | B630 11 312 | 83 x 100 x 9 | DEMIO / FESTIVA MINIVAGON B3,B5 | 96/7~02/ | Engine CRANK SHAFT REAR |
| 03906 2461 | FS01 10 602 | 42.5 x 54.5 x 6 | DEMIO / FESTIVA MINIVAGON ZY-VE DY5W | 02/6~ | Engine TIMING COVER |
| 03906 5053 | FS01 10 602 | 42.5 x 54.5 x 6 | DEMIO / FESTIVA MINIVAGON ZJ-VE DY3W | 02/6~ | Engine TIMING COVER |
| 03906 8629 | LF01 10 1F5 | | DEMIO / FESTIVA MINIVAGON ZJ-VE,ZY-VE EXHAUST | 02/6~ | Engine VALVE STEM SEAL |
| 03906 2237 | B630 10 602 | 30 x 44 x 7 | DEMIO / FESTIVA MINIVAGON B5 DW5W | 96/7~02/ | Engine CAM SHAFT |
| 03906 9149 | B630 10 602 | 30 x 44 x 7 | DEMIO / FESTIVA MINIVAGON B3 DW3W | 96/7~02/ | Engine CAM SHAFT |
| 03906 7541 | F003 27 238A | 35 x 56 x 9 x 15 | DEMIO / FESTIVA MINIVAGON DW3W,DW5W,DY3W,DY5W | 96/7~ | Mission & Differential (A/T) DIFF. SIDE (LH & RH) |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 8109 | F003 27 238A | 35 x 56 x 9 x 15 | DEMIO / FESTIVA MINIVAGON DW3W,DW5W,DY3W,DY5W | 96/7~ | Mission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03906 7965 | 0613 16 103 | 24 x 40 x 8 | DEMIO / FESTIVA MINIVAGON DW3W,DW5W,DY3W,DY5W | 96/7~ | Mission & Differential (M/T) INPUT SHAFT |
| 03906 6861 | B001 33 065A | 52 x 68 x 7 x 13 | DEMIO / FESTIVA MINIVAGON DW3W,DW5W | 96/7~02/ | Wheel Hub FRONT INNER |
| 03906 2253 | B092 33 067 | 52 x 63 x 8.5 | DEMIO / FESTIVA MINIVAGON DW3W,DW5W | 96/7~02/ | Wheel Hub FRONT OUTER |
| 03906 6997 | AJ03 10 602 | 47.5 x 63.5 x 8.7 | ESCAPE AJ(3000 V6) EPFWF | 00/12~ | Engine TIMING COVER |
| 03906 5509 | NA01 27 238 | 36 x 59 x 11 x 19 | ESCAPE EPEWF,EPFWF,EP3WF | 00/12~ | Differential REAR DIFF. SIDE |
| 03906 4549 | L807 10 155 | | ESCAPE 2300 EP3WF | 03/12~ | Engine VALVE STEM SEAL |
| 03906 1269 | AJ03 10 155 | | ESCAPE AJ(3000 V6) EPFWF | 00/12~ | Engine VALVE STEM SEAL |
| 03906 5109 | YF09 10 155 | | ESCAPE YF(2000) EPEWF | 00/12~03/ | Engine VALVE STEM SEAL |
| 03906 6445 | AJ03 11 312 | 92 x 107.7 x 9.5 | ESCAPE AJ(3000 V6) EPFWF | 00/12~ | Engine CRANK SHAFT REAR |
| 03906 3005 | YF09 11 399 | 88 x 108 x 10 | ESCAPE YF(2000) EPEWF | 00/12~03/ | Engine CRANK SHAFT REAR |
| 03906 6021 | LF01 10 602 | 37 x 50 x 8 | ESCAPE 2300 EP3WF | 03/12~ | Engine TIMING COVER |
| 03906 8357 | GY01 12 601 | 27 x 41 x 6 | ESCAPE AJ(3000 V6) EPFWF | 00/12~03/ | Engine CAM SHAFT REAR |
| 03906 3789 | YF09 10 602 | 42 x 53 x 7 | ESCAPE YF(2000) EPEWF | 00/12~03/ | Engine CAM SHAFT FRONT |
| 03906 8565 | YF10 10 602A | 35 x 50 x 7 | ESCAPE YF(2000) EPEWF | 00/12~03/ | Engine OIL PUMP |
| 03906 8701 | F003 27 238A | 35 x 56 x 9 x 15 | ESCAPE EP3WF | 03/12~ | Differential FRONT DIFF. SIDE (LH & RH) |
| 03906 3085 | FW90 27 238 | 57 x 70 x 8.7 | ESCAPE EPEWF,EPFWF | 00/12~ | Differential FRONT DIFF. SIDE (RH) |
| 03906 5661 | FW51 27 238 | 41 x 64 x 11 x 15.5 | ESCAPE EPEWF,EPFWF | 00/12~ | Differential FRONT DIFF. SIDE (LH) |
| 03906 2741 | F003 27 238A | 35 x 56 x 9 x 15 | EUNOS 100 BG5PE,BG8PE | 89/11~93/ | Transmission & Differential DIFF. SIDE |
| 03906 6341 | KL01 10 155 | | EUNOS 101 B5,BP INTAKE | 89/11~93/ | Engine VALVE STEM SEAL |
| 03906 3797 | B630 11 312 | 83 x 100 x 9 | EUNOS 102 B5,BP | 89/11~93/ | Engine CRANK SHAFT REAR |
| 03906 5749 | F801 10 602 | 34 x 48 x 7 | EUNOS 103 B5,BP | 89/11~93/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7365 | B3C7 10 602A | 36.5 x 50.5 x 7 | EUNOS 104 BP(1800) BG8PE | 90/8~93/ | Engine OIL PUMP |
| 03906 5037 | B3C7 10 602A | 36.5 x 50.5 x 7 | EUNOS 105 B5(1500) BG5PE | 90/8~93/ | Engine OIL PUMP |
| 03906 4357 | B630 10 602 | 30 x 44 x 7 | EUNOS 106 B5(1500) BG5PE | 89/11~90/ 8 | Engine OIL PUMP |
| 03906 7029 | KL02 10 155 | | EUNOS 107 B5,BP EXHAUST | 89/11~93/ | Engine VALVE STEM SEAL |
| 03906 2669 | 0603 16 103 | 27 x 43 x 9 | EUNOS 108 BG8PE | 89/11~93/ | Transmission & Differential INPUT SHAFT |
| 03906 4453 | 0613 16 103 | 24 x 40 x 8 | EUNOS 109 BG5PE | 89/11~93/ | Transmission & Differential INPUT SHAFT |
| 03906 7669 | G304 33 065 | 56 x 68 x 5 x 11 | EUNOS 110 BG5PE,BG8PE | 89/11~93/ | Wheel Hub FRONT |
| 03906 6525 | B630 10 602 | 30 x 44 x 7 | EUNOS 111 BP(1800) BG8PE | 89/11~90/ 8 | Engine OIL PUMP |
| 03906 7533 | F801 10 602 | 34 x 48 x 7 | EUNOS 300 F8(1800) MA8PE | 89/11~92/ | Engine OIL PUMP |
| 03906 1429 | F801 11 399 | 90 x 110 x 9 | EUNOS 301 F8,FE | 89/11~92/ | Engine CRANK SHAFT REAR |
| 03906 2021 | F801 10 602 | 34 x 48 x 7 | EUNOS 302 F8,FE | 89/11~92/ | Engine CAM SHAFT |
| 03906 3533 | B660 10 155 | | EUNOS 303 F8,FE | 89/11~92/ | Engine VALVE STEM SEAL |
| 03906 8373 | F801 10 602 | 34 x 48 x 7 | EUNOS 304 FE(2000) MAEPE | 89/11~92/ | Engine OIL PUMP |
| 03906 6741 | F003 27 238A | 35 x 56 x 9 x 15 | EUNOS 305 MA8PE,MAEPE | 89/11~92/ | Transmission & Differential DIFF. SIDE |
| 03906 3189 | 0603 16 103 | 27 x 43 x 9 | EUNOS 306 MA8PE,MAEPE | 89/11~92/ | Transmission & Differential INPUT SHAFT |
| 03906 7757 | G304 33 065 | 56 x 68 x 5 x 11 | EUNOS 307 MA8PE,MAEPE | 89/11~92/ | Wheel Hub FRONT |
| 03906 6941 | GJ21 26 154 | 42 x 58 x 7 | EUNOS 308 MA8PE,MAEPE | 89/11~92/ | Wheel Hub REAR |
| 03906 7501 | F003 27 238A | 35 x 56 x 9 x 15 | EUNOS 500 CA8P,CAPP,CAEP | 91/12~96/ | Transmission & Differential DIFF. SIDE |
| 03906 7949 | KL02 10 155 | | EUNOS 501 FP,K8,KL EXHAUST | 91/12~96/ | Engine VALVE STEM SEAL |
| 03906 2541 | 0603 16 103 | 27 x 43 x 9 | EUNOS 502 CA8P,CAPP,CAEP | 91/12~96/ | Transmission & Differential INPUT SHAFT |
| 03906 4381 | FS01 10 602 | 42.5 x 54.5 x 6 | EUNOS 503 FP(1800) CAPP | 94/2~96/ | Engine OIL PUMP |
| 03906 8869 | FS01 10 602 | 42.5 x 54.5 x 6 | EUNOS 504 KB(1800 V6) CA8P | 91/12~96/ | Engine OIL PUMP |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2981 | FS01 10 602 | 42.5 x 54.5 x 6 | EUNOS 505 KF(2000 V6) CAEP | 91/12~96/ | Engine OIL PUMP |
| 03906 5485 | F801 10 602 | 34 x 48 x 7 | EUNOS 506 FP | 94/2~96/ | Engine CAM SHAFT |
| 03906 3933 | B630 10 602 | 30 x 44 x 7 | EUNOS 507 K8,KF | 91/12~96/ | Engine CAM SHAFT |
| 03906 3293 | FS01 11 399 | 90 x 109 x 9 x 10.5 | EUNOS 508 FP | 94/2~96/ | Engine CRANK SHAFT REAR |
| 03906 7613 | KL01 11 312 | 75 x 93 x 9 | EUNOS 509 K8,KF | 91/12~96/ | Engine CRANK SHAFT REAR |
| 03906 5653 | KL01 10 155 | | EUNOS 510 FP,K8,KL INTAKE | 91/12~96/ | Engine VALVE STEM SEAL |
| 03906 3821 | G304 33 065 | 56 x 68 x 5 x 11 | EUNOS 511 CA8P,CAPP,CAEP | 91/12~96/ | Wheel Hub FRONT |
| 03906 8645 | KL02 10 155 | | EUNOS 800 KJ,KL EXHAUST | 93/9~97/ | Engine VALVE STEM SEAL |
| 03906 3301 | F003 27 238A | 35 x 56 x 9 x 15 | EUNOS 801 TA3#,TA5# | 93/9~97/ | Differential DIFF. SIDE |
| 03906 2085 | G304 33 065 | 56 x 68 x 5 x 11 | EUNOS 802 TA3#,TA5# | 93/9~97/ | Wheel Hub FRONT |
| 03906 1861 | KL01 10 155 | | EUNOS 803 KJ,KL INTAKE | 93/9~97/ | Engine VALVE STEM SEAL |
| 03906 3213 | KL01 11 312 | 75 x 93 x 9 | EUNOS 804 KJ,KL | 93/9~97/ | Engine CRANK SHAFT REAR |
| 03906 5861 | B630 10 602 | 30 x 44 x 7 | EUNOS 805 KJ,KL | 93/9~97/ | Engine CAM SHAFT |
| 03906 8637 | FS01 10 602 | 42.5 x 54.5 x 6 | EUNOS 806 KL(2500) TA5# | 93/9~97/ | Engine OIL PUMP |
| 03906 4277 | FS01 10 602 | 42.5 x 54.5 x 6 | EUNOS 807 KJ(2300) TA3# | 93/9~97/ | Engine OIL PUMP |
| 03906 2997 | Y702 10 602 | 18 x 32 x 6 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Y7(1700 DSL) BHA7P,7R | 94/3~99/ | Engine OIL PUMP (B) |
| 03906 1597 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF 2WD 1300CC,1500CC,1700CC | 89/1~94/ | Transmission & Differential INPUT SHAFT |
| 03906 3157 | F801 10 602 | 34 x 48 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE RF(2000 DSL) BJEP | 98/4~00/ | Engine OIL PUMP |
| 03906 8117 | B3C7 10 602A | 36.5 x 50.5 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B3 BG3P,3S,BJ3P | 90/9~ | Engine OIL PUMP |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 4181 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BHA 2WD 1300C,1500CC | 94/3~98/ | Transmission & Differential INPUT SHAFT |
| 03906 7173 | B3C7 10 602A | 36.5 x 50.5 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B5 BG5P,BHA5P,5S,BJ5P | 90/9~ | Engine OIL PUMP |
| 03906 1813 | F801 10 602 | 34 x 48 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE FS(2000GAS.) BJFP | 01/12~ | Engine OIL PUMP |
| 03906 4117 | B3C7 10 602A | 36.5 x 50.5 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B6 BG6P,6S,6R,6Z,BHA6R | 90/9~99/ | Engine OIL PUMP |
| 03906 7981 | B3C7 10 602A | 36.5 x 50.5 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BP BG8P,8S,SR,8Z,BHA8P,8S | 90/9~96/ | Engine OIL PUMP |
| 03906 7885 | Y701 10 602 | 40 x 52 x 6 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Y7(1700 DSL) BHA7P,7R | 94/3~99/ | Engine OIL PUMP (A) |
| 03906 6949 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B6(1600 GAS.)..BG6P,6S,6R,6Z | 89/1~90/9 | Engine OIL PUMP |
| 03906 3109 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B3,B5,BN,B6 OHC | 86/12~ | Engine CAM SHAFT |
| 03906 6453 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE PN,RF | 85/9~ | Engine CAM SHAFT |
| 03906 7789 | F801 10 602 | 34 x 48 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BP | 90/1~99/ | Engine CAM SHAFT |
| 03906 6909 | B3C7 10 602A | 36.5 x 50.5 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Z5(1500 GAS.) BHALP,LS | 94/3~96/ | Engine OIL PUMP |
| 03906 5461 | F003 27 238A | 35 x 56 x 9 x 15 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF,BG,BHA 2WD | 85/1~98/ | Transmission & Differential FRONT DIFF. SIDE |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 4629 | Y701 10 602 | 40 x 52 x 6 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Y7 | 94/3~99/ | Engine CAM SHAFT |
| 03906 1997 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF 4WD | 85/9~87/8 | Transmission & Differential INPUT SHAFT |
| 03906 6965 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF 2WD 1600CC (DOHC) | 85/9~89/ | Transmission & Differential INPUT SHAFT |
| 03906 5997 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF 2WD 1500CC (TURBO) | 85/1~87/ | Transmission & Differential INPUT SHAFT |
| 03906 8437 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ 2WD 1300CC,1500CC | 98/4~ | Transmission & Differential INPUT SHAFT |
| 03906 1229 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BG,BHA 2WD 1700CC,1800 | 90/1~98/ | Transmission & Differential INPUT SHAFT |
| 03906 5885 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ 2WD 2000CC | 98/4~ | Transmission & Differential INPUT SHAFT |
| 03906 2469 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ 4WD | 98/4~ | Transmission & Differential INPUT SHAFT |
| 03906 3957 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE PN(1700 DSL) BF7P,BG7P | 85/9~94/ | Engine OIL PUMP |
| 03906 4013 | F003 27 238A | 35 x 56 x 9 x 15 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BD#,BE# | 80/5~84/ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 8077 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BP(1800 GAS.) BG,8P,8S,8R,8Z | 89/6~90/9 | Engine OIL PUMP |
| 03906 5325 | F003 27 238A | 35 x 56 x 9 x 15 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ 2WD | 98/4~ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 6077 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF,BG,BHA 4WD | 85/10~98/ | Transmission & Differential FRONT DIFF. SIDE |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 8013 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ 4WD | 98/4~ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 8733 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF,BG,BHA 4WD | 85/10~98/ | Transmission & Differential REAR DIFF. SIDE |
| 03906 1637 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ 4WD | 98/4~ | Transmission & Differential REAR DIFF. SIDE |
| 03906 5093 | 0187 10 507B | 40 x 55 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE E3,E5(1300,1500 GAS.) BD#,BF3P,5P,5R | 80/5~87/ | Engine TIMING GEAR COVER |
| 03906 5589 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B3(1300 GAS.) BFTP,BG3P,3S | 86/12~90/ 9 | Engine OIL PUMP |
| 03906 2909 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B5(1500 GAS.) BFSP,SR,BG5P | 86/12~90/ 9 | Engine OIL PUMP |
| 03906 6053 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B6(1600 GAS.) BFMP,MR | 85/9~89/ | Engine OIL PUMP |
| 03906 4589 | H501 17 103 | 27 x 43 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF,BG,BHA 4WD | 87/8~98/ | Transmission & Differential INPUT SHAFT |
| 03906 6701 | B630 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B3,B5 | 86/12~89/ 1 | Engine VALVE STEM SEAL |
| 03906 5077 | RF01 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE RF | 98/4~00/ | Engine VALVE STEM SEAL |
| 03906 4885 | Z501 10 1F5 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Z5(EX.) | 94/3~ | Engine VALVE STEM SEAL |
| 03906 3597 | KL02 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B5,B6,BP,ZL,FS DOHC(EX.) | 93/7~ | Engine VALVE STEM SEAL |
| 03906 3045 | F801 10 602 | 34 x 48 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B5,B6,Z5,ZL,FS DOHC | 85/9~ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 8245 | B660 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B5,BP DOHC | 89/1~93/7 | Engine VALVE STEM SEAL |
| 03906 8613 | B660 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B3,B5,B6 OHC | 89/1~ | Engine VALVE STEM SEAL |
| 03906 6093 | B660 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B6 DOHC | 85/9~89/1 | Engine VALVE STEM SEAL |
| 03906 3813 | B001 33 065A | 52 x 68 x 7 x 13 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...2WD | 85/1~89/ | Wheel Hub FRONT INNER |
| 03906 2901 | B630 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B6 OHC | 86/12~89/ 1 | Engine VALVE STEM SEAL |
| 03906 1189 | Z501 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Z5(IN.) | 94/3~ | Engine VALVE STEM SEAL |
| 03906 8301 | HE19 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE E3,E5 | 80/5~87/ | Engine VALVE STEM SEAL |
| 03906 3645 | FS01 11 399 | 90 x 109 x 9 x 10.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE FS | 01/12~ | Engine CRANK SHAFT REAR |
| 03906 5949 | F801 11 399 | 90 x 110 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE RF | 98/4~00/ | Engine CRANK SHAFT REAR |
| 03906 6517 | Y701 11 312 | 87 x 100 x 8.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE Y7 | 94/3~ | Engine CRANK SHAFT REAR |
| 03906 1653 | B630 11 312 | 83 x 100 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE PN | 85/9~94/ | Engine CRANK SHAFT REAR |
| 03906 5565 | B630 11 312 | 83 x 100 x 9 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B3,B5,Z5,B6,BP | 86/12~ | Engine CRANK SHAFT REAR |
| 03906 9037 | 0370 11 399 | 70 x 88 x 12 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE E3,E5 | 80/5~87/ | Engine CRANK SHAFT REAR |
| 03906 7765 | ZL09 10 602 | 47 x 61 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE ZL VARIABLE VALVE TIMING | 98/4~ | Engine CAM SHAFT (?. 2) |
| 03906 7229 | B630 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE PN | 85/9~94/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 5181 | G304 33 065 | 56 x 68 x 5 x 11 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BG#...4WD | 89/1~94/ | Wheel Hub REAR OUTER |
| 03906 3461 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF 2WD 1600CC (OHC) | 86/12~89/ | Transmission & Differential INPUT SHAFT |
| 03906 5221 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF 2WD 1300CC,1500CC,1700CC | 85/1~89/ | Transmission & Differential INPUT SHAFT |
| 03906 8677 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BD#,BE# | 80/5~84/ | Transmission & Differential INPUT SHAFT |
| 03906 5173 | KL01 10 155 | | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE B5,B6,BP,ZL,FS DOHC(IN.) | 93/7~ | Engine VALVE STEM SEAL |
| 03906 6381 | G304 33 065 | 56 x 68 x 5 x 11 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BHA#...4WD | 94/3~98/ | Wheel Hub REAR OUTER |
| 03906 3973 | B001 33 065A | 52 x 68 x 7 x 13 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BD#,BE# | 80/5~84/ | Wheel Hub FRONT INNER |
| 03906 8173 | B210 33 067 | 51 x 63 x 9 x 12 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...4WD | 85/10~89/ | Wheel Hub REAR OUTER |
| 03906 7253 | B210 33 065 | 52 x 68 x 8 x 14 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...4WD | 85/10~89/ | Wheel Hub REAR INNER |
| 03906 5813 | B001 26 154B | 40 x 54 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...2WD | 85/1~89/ | Wheel Hub REAR |
| 03906 5533 | B210 33 067 | 51 x 63 x 9 x 12 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...4WD | 85/10~89/ | Wheel Hub FRONT OUTER |
| 03906 4341 | B092 33 067 | 52 x 63 x 8.5 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...2WD | 85/1~89/ | Wheel Hub FRONT OUTER |
| 03906 1613 | B001 33 067 | 52 x 63 x 6 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BD#,BE# | 80/5~84/ | Wheel Hub FRONT OUTER |
| 03906 7149 | B210 33 065 | 52 x 68 x 8 x 14 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BF#...4WD | 85/10~89/ | Wheel Hub FRONT INNER |
| 03906 5525 | G304 33 065 | 56 x 68 x 5 x 11 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ# | 98/4~ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2549 | G304 33 065 | 56 x 68 x 5 x 11 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BHA# | 94/3~98/ | Wheel Hub FRONT INNER |
| 03906 3893 | B001 26 154B | 40 x 54 x 7 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BD#,BE# | 80/5~84/ | Wheel Hub REAR |
| 03906 4757 | G304 33 065 | 56 x 68 x 5 x 11 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BG# | 89/1~94/ | Wheel Hub FRONT INNER |
| 03906 2725 | G304 33 065 | 56 x 68 x 5 x 11 | FAMILIA / 323 (FWD, 4WD) SEDAN, COUPE BJ#...4WD | 98/4~ | Wheel Hub REAR OUTER |
| 03906 4909 | B630 10 155 | | FAMILIA / 323 (FWD, 4WD) VAN, WAGON B6,PN | 85/11~94/ | Engine VALVE STEM SEAL |
| 03906 5237 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON PN(1700 DSL.) BF7V,BW7W | 85/11~94/ | Engine OIL PUMP |
| 03906 1565 | B3C7 10 602A | 36.5 x 50.5 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON B6(1600 GAS.) BF6M,BWMR | 90/9~94/ | Engine OIL PUMP |
| 03906 6069 | 0187 10 507B | 40 x 55 x 8 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON E3,E5(1300,1500 GAS.) BF3V,5V,BW3W,5W | 85/11~94/ | Engine TIMING GEAR COVER |
| 03906 7141 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON B6 | 87/3~94/ | Engine CAM SHAFT |
| 03906 7381 | 0370 11 399 | 70 x 88 x 12 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON E3,E5 | 85/11~94/ | Engine CRANK SHAFT REAR |
| 03906 4365 | HE19 10 155 | | FAMILIA / 323 (FWD, 4WD) VAN, WAGON E3,E5 | 85/11~94/ | Engine VALVE STEM SEAL |
| 03906 7509 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON B6(1600 GAS.) BF6M,BWMR | 87/3~90/9 | Engine OIL PUMP |
| 03906 4477 | B630 11 312 | 83 x 100 x 9 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON B6,PN | 85/11~94/ | Engine CRANK SHAFT REAR |
| 03906 1261 | B011 26 154B | 40 x 54 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BW3W,5W,7W(2WD,WAGON) | 89/10~94/ | Wheel Hub REAR |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 6821 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...4WD | 87/3~94/ | Transmission & Differential REAR DIFF. SIDE |
| 03906 3669 | B630 10 602 | 30 x 44 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON PN | 85/11~94/ | Engine CAM SHAFT |
| 03906 7493 | B001 33 065A | 52 x 68 x 7 x 13 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...2WD | 85/11~94/ | Wheel Hub FRONT INNER |
| 03906 3997 | B210 33 065 | 52 x 68 x 8 x 14 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...4WD | 87/3~94/ | Wheel Hub FRONT INNER |
| 03906 3469 | B092 33 067 | 52 x 63 x 8.5 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...2WD | 85/11~94/ | Wheel Hub FRONT OUTER |
| 03906 7853 | B011 26 154B | 40 x 54 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF5W (2WD,WAGON) | 85/11~87/ | Wheel Hub REAR |
| 03906 4133 | B216 26 154 | 48 x 65 x 8 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF3V,5V,7V(2WD,VAN) | 85/11~94/ | Wheel Hub REAR |
| 03906 3661 | B210 33 065 | 52 x 68 x 8 x 14 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BWMR,BF6M(4WD) | 87/3~94/ | Wheel Hub REAR INNER |
| 03906 7333 | B210 33 067 | 51 x 63 x 9 x 12 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BWMR,BF6M(4WD) | 87/3~94/ | Wheel Hub REAR OUTER |
| 03906 8061 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...2WD | 85/11~94/ | Transmission & Differential INPUT SHAFT |
| 03906 8093 | 0603 16 103 | 27 x 43 x 9 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BWMR(4WD) | 87/3~89/10 | Transmission & Differential INPUT SHAFT |
| 03906 8189 | H501 17 103 | 27 x 43 x 7 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BWMR,BF6M(4WD) | 89/10~94/ | Transmission & Differential INPUT SHAFT |
| 03906 5701 | F003 27 238A | 35 x 56 x 9 x 15 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...2WD | 85/11~94/ | Transmission & Differential FRONT DIFF. SIDE |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 1373 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...4WD | 87/3~94/ | Transmission & Differential FRONT DIFF. SIDE |
| 03906 5965 | B210 33 067 | 51 x 63 x 9 x 12 | FAMILIA / 323 (FWD, 4WD) VAN, WAGON BF#,BW#...4WD | 87/3~94/ | Wheel Hub FRONT OUTER |
| 03906 8221 | 0324 10 155 | | FAMILIA / 323 (RWD) TC | 76/12~79/ | Engine VALVE STEM SEAL |
| 03906 7461 | 0249 27 018A | 32 x 54 x 10 | FAMILIA / 323 (RWD) FA4 | 76/12~85/ | Differential PINION |
| 03906 7733 | 8173 10 155 | | FAMILIA / 323 (RWD) TC | 80/~81/ | Engine VALVE STEM SEAL |
| 03906 1917 | 0370 11 399 | 70 x 88 x 12 | FAMILIA / 323 (RWD) TC FA4 | 76/12~85/ | Engine CRANK SHAFT REAR |
| 03906 4765 | 0187 10 507B | 40 x 55 x 8 | FAMILIA / 323 (RWD) TC FA4 | 76/12~85/ | Engine TIMING GEAR COVER |
| 03906 3381 | 0613 16 103 | 24 x 40 x 8 | FAMILIA / 323 (RWD) FA4 | 76/12~85/ | Transmission FRONT |
| 03906 4333 | 0187 26 154 | 42 x 55 x 9 | FAMILIA / 323 (RWD) FA4 | 76/12~85/ | Wheel Hub REAR |
| 03906 4821 | 1312 33 065 | 40 x 54 x 6 | FAMILIA / 323 (RWD) FA4 | 76/12~85/ | Wheel Hub FRONT |
| 03906 7261 | HE19 10 155 | | FAMILIA / 323 (RWD) TC | 82/~85/ | Engine VALVE STEM SEAL |
| 03906 2973 | 0437 17 335A | 35 x 48 x 15 | FAMILIA / 323 (RWD) FA4 | 76/12~85/ | Transmission REAR |
| 03906 5029 | B630 10 602 | 30 x 44 x 7 | FESTIVA BJ(1300 DOHC) DAJPF | 86/10~90/ 8 | Engine OIL PUMP |
| 03906 5397 | B001 33 065A | 52 x 68 x 7 x 13 | FESTIVA DA#,D23PF,D25PF | 85/10~97/ | Wheel Hub FRONT INNER |
| 03906 5925 | B660 10 155 | | FESTIVA BJ | 86/10~97/ | Engine VALVE STEM SEAL |
| 03906 4693 | B630 10 155 | | FESTIVA B1,B3,B5 | 85/10~97/ | Engine VALVE STEM SEAL |
| 03906 2597 | B630 11 312 | 83 x 100 x 9 | FESTIVA B1,B3,B5,BJ | 85/10~97/ | Engine CRANK SHAFT REAR |
| 03906 1893 | F801 10 602 | 34 x 48 x 7 | FESTIVA BJ | 86/10~93/ | Engine CAM SHAFT |
| 03906 3733 | B630 10 602 | 30 x 44 x 7 | FESTIVA B1,B3,B5 | 85/10~97/ | Engine CAM SHAFT |
| 03906 6557 | B3C7 10 602A | 36.5 x 50.5 x 7 | FESTIVA B5(1500) D25PF | 92/11~97/ | Engine OIL PUMP |
| 03906 3725 | B3C7 10 602A | 36.5 x 50.5 x 7 | FESTIVA BJ(1300 DOHC) DAJPF | 90/8~93/ | Engine OIL PUMP |
| 03906 3621 | B3C7 10 602A | 36.5 x 50.5 x 7 | FESTIVA B1(1100) DA1PF | 90/8~97/ | Engine OIL PUMP |
| 03906 8333 | B630 10 602 | 30 x 44 x 7 | FESTIVA B3(1300) DA3PF,DA3VF,ADA242 | 85/10~90/ 8 | Engine OIL PUMP |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 6725 | B630 10 602 | 30 x 44 x 7 | FESTIVA B1(1100) DA1PF | 85/10~90/8 | Engine OIL PUMP |
| 03906 5317 | F003 27 238A | 35 x 56 x 9 x 15 | FESTIVA D25PF MT,AT | 92/11~97/ | Transmission & Differential DIFF. SIDE |
| 03906 4165 | F003 27 238A | 35 x 56 x 9 x 15 | FESTIVA DA#,D23PF AT | 85/10~97/ | Transmission & Differential DIFF. SIDE |
| 03906 3141 | B001 27 238 | 35 x 51 x 9 x 15 | FESTIVA DA#,D23PF MT | 85/10~97/ | Transmission & Differential DIFF. SIDE |
| 03906 7717 | 0613 16 103 | 24 x 40 x 8 | FESTIVA D25PF | 92/11~97/ | Transmission & Differential INPUT SHAFT |
| 03906 9069 | 0419 16 213 | 22 x 38 x 8 | FESTIVA DA#,D23PF | 85/10~97/ | Transmission & Differential INPUT SHAFT |
| 03906 7629 | G030 26 154A | 39 x 50.5 x 7 | FESTIVA DA# | 85/10~93/ | Wheel Hub REAR |
| 03906 8317 | B092 33 067 | 52 x 63 x 8.5 | FESTIVA DA#,D23PF,D25PF | 85/10~97/ | Wheel Hub FRONT OUTER |
| 03906 8037 | B3C7 10 602A | 36.5 x 50.5 x 7 | FESTIVA B3(1300) DA3PF,DA3VF,ADA242,D23 PF | 90/8~97/ | Engine OIL PUMP |
| 03906 2309 | G304 33 065 | 56 x 68 x 5 x 11 | IXION CP8WF | 99/4~ | Wheel Hub FRONT |
| 03906 7845 | G304 33 065 | 56 x 68 x 5 x 11 | IXION CP8WF 4WD | 99/4~ | Wheel Hub REAR |
| 03906 6309 | F003 27 238A | 35 x 56 x 9 x 15 | IXION CP8WF 2WD | 99/4~ | Mission & Differential FRONT DIFF. SIDE |
| 03906 5365 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | IXION CP8WF 4WD | 99/4~ | Mission & Differential FRONT DIFF. SIDE |
| 03906 7797 | F801 10 602 | 34 x 48 x 7 | IXION FP | 99/4~ | Engine CAM SHAFT |
| 03906 2557 | FS01 11 399 | 90 x 109 x 9 x 10.5 | IXION FP | 99/4~ | Engine CRANK SHAFT REAR |
| 03906 5453 | KL01 10 155 | | IXION FP INTAKE | 99/4~ | Engine VALVE STEM SEAL |
| 03906 9157 | KL02 10 155 | | IXION FP EXHAUST | 99/4~ | Engine VALVE STEM SEAL |
| 03906 9029 | FS01 10 602 | 42.5 x 54.5 x 6 | IXION FP(1800) CP8WF | 99/4~ | Engine OIL PUMP |
| 03906 6893 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | IXION CP8WF 4WD | 99/4~ | Mission & Differential REAR DIFF. SIDE |
| 03906 7053 | F801 10 602 | 34 x 48 x 7 | LANTIS BP | 93/6~97/ | Engine CAM SHAFT |
| 03906 3557 | KL01 10 155 | | LANTIS BP,KF INTAKE | 93/6~97/ | Engine VALVE STEM SEAL |
| 03906 8053 | KL01 11 312 | 75 x 93 x 9 | LANTIS KF | 93/6~97/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 4421 | B630 10 602 | 30 x 44 x 7 | LANTIS KF | 93/6~97/ | Engine CAM SHAFT |
| 03906 1453 | KL02 10 155 | | LANTIS BP,KE EXHAUST | 93/6~97/ | Engine VALVE STEM SEAL |
| 03906 9125 | FS01 10 602 | 42.5 x 54.5 x 6 | LANTIS KF(2000) CBAEP | 93/6~97/ | Engine OIL PUMP |
| 03906 4653 | B3C7 10 602A | 36.5 x 50.5 x 7 | LANTIS BP(1800) CBA8P | 93/6~97/ | Engine OIL PUMP |
| 03906 2149 | F003 27 238A | 35 x 56 x 9 x 15 | LANTIS CBA8P,CBAEP | 93/6~97/ | Transmission & Differential DIFF. SIDE (LH & RH) |
| 03906 3581 | 0603 16 103 | 27 x 43 x 9 | LANTIS CBA8P,CBAEP | 93/6~97/ | Transmission & Differential INPUT SHAFT |
| 03906 6845 | G304 33 065 | 56 x 68 x 5 x 11 | LANTIS CBA8P,CBAEP | 93/6~97/ | Wheel Hub FRONT |
| 03906 7037 | B630 11 312 | 83 x 100 x 9 | LANTIS BP | 93/6~97/ | Engine CRANK SHAFT REAR |
| 03906 1493 | JE26 12 602A | 65 x 81 x 7 | LUCE / 929 JE(3000 V6) HCSS | 86/9~91/ | Engine CAM SHAFT LH |
| 03906 8789 | F003 27 238A | 35 x 56 x 9 x 15 | LUCE / 930 HB I.R.SUS. | 81/8~86/ | Differential DIFF. SIDE |
| 03906 7437 | F003 27 238A | 35 x 56 x 9 x 15 | LUCE / 931 HC JF(2000CC WITHOUT TURBO) | 86/9~91/ | Differential DIFF. SIDE |
| 03906 1581 | R001 27 165 | 40 x 75 x 11 x 16.5 | LUCE / 932 HC JF(2000CC TURBO,3000CC) | 86/9~91/ | Differential DIFF. SIDE |
| 03906 3397 | F801 10 602 | 34 x 48 x 7 | LUCE / 933 FE(2000) HBEJ.P.S,HCEP | 83/9~91/ | Engine CAM SHAFT |
| 03906 3453 | R001 27 165 | 40 x 75 x 11 x 16.5 | LUCE / 934 HC 2000CC TURBO,3000CC,ROTARY | 86/9~91/ | Differential PINION |
| 03906 2429 | JF01 12 602A | 35 x 49.5 x 11 | LUCE / 935 JF(2000 V6) HCFS | 86/9~92/ | Engine CAM SHAFT |
| 03906 4061 | JE26 12 601A | 38 x 52 x 7 | LUCE / 936 JE(3000 V6) HCSS | 86/9~91/ | Engine CAM SHAFT RH |
| 03906 6829 | F801 10 602 | 34 x 48 x 7 | LUCE / 937 FE | 86/9~91/ | Engine OIL PUMP |
| 03906 7317 | JE15 10 602A | 43 x 55 x 6 | LUCE / 938 JF,JE | 86/9~92/ | Engine OIL PUMP |
| 03906 6117 | 0221 10 602B | 48 x 70 x 12 | LUCE / 939 LA,HB GASOLINE | 77/9~83/ | Engine TIMING GEAR COVER |
| 03906 5141 | F801 10 602 | 34 x 48 x 7 | LUCE / 940 HB GASOLINE | 83/9~86/ | Engine TIMING GEAR COVER |
| 03906 6781 | M005 27 165 | 40 x 64 x 12 x 17.5 | LUCE / 941 HB | 81/8~86/ | Differential PINION |
| 03906 6541 | SE08 10 602 | 50 x 70 x 11 | LUCE / 942 HB DIESEL | 81/8~83/ | Engine TIMING GEAR COVER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 5517 | M054 27 165 | 40 x 64 x 11 x 16 | LUCE / 943 HC 2000CC WITHOUT TURBO | 86/9~91/ | Differential PINION |
| 03906 2861 | 0453 11 399 | 80 x 105 x 13 | LUCE / 944 LA,HB GASOLINE | 77/9~83/ | Engine CRANK SHAFT REAR |
| 03906 5165 | SE08 10 602 | 50 x 70 x 11 | LUCE / 945 LA DIESEL | 80/8~82/ | Engine TIMING GEAR COVER |
| 03906 5773 | 0603 16 103 | 27 x 43 x 9 | LUCE / 946 HCEP FE ENGINE | 88/8~91/ | Transmission FRONT COVER |
| 03906 3029 | H001 33 065A | 52 x 63 x 8 | LUCE / 947 HB | 81/8~86/ | Wheel Hub FRONT |
| 03906 9133 | H501 17 103 | 27 x 43 x 7 | LUCE / 948 HCFS JF ENGINE | 88/8~91/ | Transmission FRONT COVER |
| 03906 8229 | H260 33 065 | 55 x 74 x 6 x 10 | LUCE / 949 HC | 86/9~91/ | Wheel Hub FRONT |
| 03906 7357 | 1011 26 154 | 48 x 62 x 9 | LUCE / 950 LA | 77/9~82/ | Wheel Hub REAR |
| 03906 7661 | 1011 26 154 | 48 x 62 x 9 | LUCE / 951 HB 5 LINK SUS. TAXI | 81/8~86/ | Wheel Hub REAR |
| 03906 6357 | 1011 26 154 | 48 x 62 x 9 | LUCE / 952 HCEP FE ENGINE | 86/9~91/ | Wheel Hub REAR |
| 03906 2125 | 0437 17 335A | 35 x 48 x 15 | LUCE / 953 LA,HB GASOLINE | 77/9~86/ | Transmission REAR |
| 03906 2165 | 0603 16 103 | 27 x 43 x 9 | LUCE / 954 LA,HB,HC ALL | 77/9~88/8 | Transmission FRONT COVER |
| 03906 3077 | 1312 33 065 | 40 x 54 x 6 | LUCE / 955 LA | 77/9~82/ | Wheel Hub FRONT |
| 03906 8917 | F801 11 399 | 90 x 110 x 9 | LUCE / 956 HB GASOLINE | 83/9~86/ | Engine CRANK SHAFT REAR |
| 03906 6589 | 0437 17 335A | 35 x 48 x 15 | LUCE / 957 HCEP FE ENGINE | 86/9~91/ | Transmission REAR |
| 03906 2869 | 8599 17 335 | 35 x 48 x 10 | LUCE / 958 LA,HB DIESEL | 80/8~83/8 | Transmission REAR |
| 03906 5709 | M502 17 335A | 38 x 51 x 13 x 15 | LUCE / 959 HC JF ENGINE | 86/9~88/8 | Transmission REAR |
| 03906 9229 | R501 17 335 | 38 x 51 x 60 x 23 | LUCE / 960 HC JF ENGINE | 88/8~91/ | Transmission REAR |
| 03906 6837 | 0290 25 151 | 32 x 52 x 8 | LUCE / 961 LA SEDAN,HARDTOP | 77/9~81/8 | Propeller Shaft CENTER BEARING |
| 03906 2013 | 0223 27 018 | 40 x 64 x 12 | LUCE / 962 LA | 77/9~81/8 | Differential PINION |
| 03906 5789 | 1011 26 154 | 48 x 62 x 9 | LUCE / 963 HCFS,HC3S JF,RE13B ENGINE | 86/9~91/ | Wheel Hub REAR |
| 03906 1125 | JF01 11 312A | 75 x 93 x 9 | LUCE / 964 HC JF | 86/9~92/ | Engine CRANK SHAFT REAR |
| 03906 1397 | 8173 10 155 | | LUCE / 965 LA | 77/9~80/ | Engine VALVE STEM SEAL |
| 03906 2205 | HE19 10 155 | | LUCE / 966 LA,HB | 81/~86/ | Engine VALVE STEM SEAL |
| 03906 4069 | HE19 10 155 | | LUCE / 967 FE | 86/9~91/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7397 | B630 10 155 | | LUCE / 968 JF | 86/9~92/ | Engine VALVE STEM SEAL |
| 03906 5901 | B660 10 155 | | LUCE / 969 JE | 86/9~91/ | Engine VALVE STEM SEAL |
| 03906 8949 | F801 11 399 | 90 x 110 x 9 | LUCE / 970 HC FE | 86/9~91/ | Engine CRANK SHAFT REAR |
| 03906 5797 | M005 27 165 | 40 x 64 x 12 x 17.5 | LUCE / 971 LA | 81/8~82/ | Differential PINION |
| 03906 7109 | G304 33 065 | 56 x 68 x 5 x 11 | MILLENIA TAFP,TA3#,TA5# | 97/7~00/6 | Wheel Hub FRONT |
| 03906 5285 | KL01 10 155 | | MILLENIA KF,KJ,KL INTAKE | 97/7~ | Engine VALVE STEM SEAL |
| 03906 6677 | B630 10 602 | 30 x 44 x 7 | MILLENIA KF,KJ,KL | 97/7~ | Engine CAM SHAFT |
| 03906 1293 | FS01 10 602 | 42.5 x 54.5 x 6 | MILLENIA KF(2000) TAFP | 98/6~ | Engine OIL PUMP |
| 03906 7917 | FS01 10 602 | 42.5 x 54.5 x 6 | MILLENIA KL(2500) TA5# | 97/7~ | Engine OIL PUMP |
| 03906 2397 | F003 27 238A | 35 x 56 x 9 x 15 | MILLENIA TAFP,TA3#,TA5# | 97/7~ | Differential DIFF. SIDE |
| 03906 6797 | KL02 10 155 | | MILLENIA KF,KJ,KL EXHAUST | 97/7~ | Engine VALVE STEM SEAL |
| 03906 8573 | FS01 10 602 | 42.5 x 54.5 x 6 | MILLENIA KJ(2300) TA3# | 97/7~ | Engine OIL PUMP |
| 03906 5957 | KL01 11 312 | 75 x 93 x 9 | MILLENIA KF,KJ,KL | 97/7~ | Engine CRANK SHAFT REAR |
| 03906 8813 | AJ03 10 602 | 47.5 x 63.5 x 8.7 | MPV GY(2500 V6) LW5W | 99/5~02/3 | Engine TIMING COVER |
| 03906 3629 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | MPV LW3W 4WD | 02/3~ | Final Drive REAR DIFF. SIDE |
| 03906 2701 | JE15 10 602A | 43 x 55 x 6 | MPV JE(3000 V6) LVEW | 89/11~99/5 | Engine OIL PUMP |
| 03906 2773 | FS01 10 602 | 42.5 x 54.5 x 6 | MPV FS(2000) LWEW | 99/5~02/4 | Engine OIL PUMP |
| 03906 1645 | JF01 12 602A | 35 x 49.5 x 11 | MPV JE(3000 V6) LVEW | 89/11~99/5 | Engine CAM SHAFT |
| 03906 1701 | FE01 10 602 | 34 x 48 x 7 | MPV FS(2000) LWEW | 99/5~02/4 | Engine CAM SHAFT |
| 03906 8453 | VS01 10 602 | 53 x 70 x 11 | MPV WL(2500 DSL) LVLR,LVLW | 95/10~99/5 | Engine TIMING COVER NO.1 |
| 03906 3173 | AJ03 11 312 | 92 x 107.7 x 9.5 | MPV GY,AJ | 99/5~ | Engine CRANK SHAFT REAR |
| 03906 6165 | JF01 10 602A | 46 x 60 x 7 | MPV G5(2500) LV5W | 94/12~99/5 | Engine TIMING COVER |
| 03906 5725 | F003 27 238A | 35 x 56 x 9 x 15 | MPV LWEW,LW5W | 99/5~02/3 | Final Drive FRONT DIFF. SIDE |
| 03906 3037 | AJ03 10 602 | 47.5 x 63.5 x 8.7 | MPV AJ(3000V6) LWFW | 02/3~ | Engine TIMING COVER |
| 03906 5413 | LF01 10 602 | 37 x 50 x 8 | MPV L3(2300) LW3W | 02/3~ | Engine TIMING COVER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 8893 | JF01 11 312A | 75 x 93 x 9 | MPV JE | 89/11~99/5 | Engine CRANK SHAFT REAR |
| 03906 8197 | G01 11 399 | 90 x 110 x 9 x 12 | MPV G5,WL | 94/12~99/5 | Engine CRANK SHAFT REAR |
| 03906 1909 | FS01 11 399 | 90 x 109 x 9 x 10.5 | MPV FS | 99/5~02/4 | Engine CRANK SHAFT REAR |
| 03906 2765 | WL01 10 602 | 60 x 76 x 7 | MPV WL(2500 DSL) LVLR,LVLW | 95/10~99/5 | Engine TIMING COVER NO.2 |
| 03906 7093 | 1011 26 154 | 48 x 62 x 9 | MPV LVEW ALL | 89/11~95/10 | Wheel Hub REAR INNER |
| 03906 9237 | WL01 10 155 | | MPV WL | 95/10~99/5 | Engine VALVE STEM SEAL |
| 03906 8365 | KL01 10 155 | | MPV FS INTAKE | 99/5~02/3 | Engine VALVE STEM SEAL |
| 03906 5061 | KL02 10 155 | | MPV FS EXHAUST | 99/5~02/3 | Engine VALVE STEM SEAL |
| 03906 9045 | B630 10 155 | | MPV G5 | 94/12~99/5 | Engine VALVE STEM SEAL |
| 03906 8997 | AJ03 10 155 | | MPV GY,AJ | 99/5~ | Engine VALVE STEM SEAL |
| 03906 9109 | L807 10 155 | | MPV L3 INTAKE | 02/3~ | Engine VALVE STEM SEAL |
| 03906 4269 | FP01 27 238 | 40 x 56 x 8 x 13 | MPV LWFW(3000) | 02/3~ | Final Drive FRONT DIFF. SIDE |
| 03906 8421 | G304 33 065 | 56 x 68 x 5 x 11 | MPV LWEW,LW5W | 99/5~02/3 | Wheel Hub FRONT |
| 03906 7677 | F003 27 238A | 35 x 56 x 9 x 15 | MPV LW3W(2300) | 02/3~ | Final Drive FRONT DIFF. SIDE |
| 03906 6373 | S09H 26 154 | 40 x 52 x 8 | MPV LVLR,LVLW,LVEW,LV5W WITH A.BREAK | 95/10~99/5 | Wheel Hub REAR INNER |
| 03906 1725 | S10H 26 154A | 61 x 71 x 6 | MPV LVLR,LVLW,LVEW,LV5W W/O A.BREAK | 95/10~99/5 | Wheel Hub REAR INNER |
| 03906 2589 | S381 26 157A | 47 x 57.7 x 12.5 | MPV LNEW DRUM BRAKE | 89/11~95/10 | Wheel Hub REAR OUTER |
| 03906 7453 | S10H 26 157 | 79 x 86 x 4 | MPV LVLR,LVLW,LVEW,LV5W | 95/10~99/5 | Wheel Hub REAR OUTER |
| 03906 1933 | R001 27 165 | 40 x 75 x 11 x 16.5 | MPV LVLR,LVLW,LVEW,LV5W | 89/11~99/5 | Final Drive REAR DIFF. PINION |
| 03906 1437 | M054 27 165 | 40 x 64 x 11 x 16 | MPV LW3W 4WD | 02/3~ | Final Drive REAR DIFF. PINION |
| 03906 7277 | B630 10 155 | | MPV JE INTAKE | 89/11~99/5 | Engine VALVE STEM SEAL |
| 03906 6157 | LF01 10 1F5 | | MPV L3 EXHAUST | 02/3~ | Engine VALVE STEM SEAL |
| 03906 1149 | HE19 10 155 | | MPV JE EXHAUST | 89/11~99/5 | Engine VALVE STEM SEAL |
| 03906 8965 | F801 10 602 | 34 x 48 x 7 | MS-6 FS | 91/11~94/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 5293 | RF01 10 155 | | MS-7 RF | 92/3~94/ | Engine VALVE STEM SEAL |
| 03906 6205 | G304 33 065 | 56 x 68 x 5 x 11 | MS-8 GE8P,GEEP,GESR,GEFP | 91/10~94/ | Wheel Hub FRONT |
| 03906 3861 | KL02 10 155 | | MS-9 K8,KF,FS EXHAUST | 91/10~94/ | Engine VALVE STEM SEAL |
| 03906 1837 | F801 10 602 | 34 x 48 x 7 | MS-10 RF(200 DSL) GEFP | 92/3~94/ | Engine OIL PUMP |
| 03906 7573 | KL01 10 155 | | MS-11 K8,KF,FS INTAKE | 91/10~94/ | Engine VALVE STEM SEAL |
| 03906 7621 | FS01 10 602 | 42.5 x 54.5 x 6 | MS-12 FS(2000) GESR | 91/11~94/ | Engine OIL PUMP |
| 03906 4853 | F801 11 399 | 90 x 110 x 9 | MS-13 RF | 92/3~94/ | Engine CRANK SHAFT REAR |
| 03906 8277 | KL01 11 312 | 75 x 93 x 9 | MS-14 K8,KF | 91/10~94/ | Engine CRANK SHAFT REAR |
| 03906 4413 | B630 10 602 | 30 x 44 x 7 | MS-15 K8,KF,RF | 91/10~94/ | Engine CAM SHAFT |
| 03906 4893 | FS01 10 602 | 42.5 x 54.5 x 6 | MS-16 KF(2000 V6) GEEP | 91/10~94/ | Engine OIL PUMP |
| 03906 8957 | FS01 10 602 | 42.5 x 54.5 x 6 | MS-17 KB(1800 V6) GE8P | 91/10~94/ | Engine OIL PUMP |
| 03906 5837 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | MS-18 GESR 4WD | 92/3~94/ | Transmission & Differential DIFF. SIDE |
| 03906 8605 | F003 27 238A | 35 x 56 x 9 x 15 | MS-19 GE#...2WD | 91/10~94/ | Transmission & Differential DIFF. SIDE |
| 03906 8413 | H501 17 103 | 27 x 43 x 7 | MS-20 GESR 4WD | 92/3~94/ | Transmission & Differential INPUT SHAFT |
| 03906 5085 | 0603 16 103 | 27 x 43 x 9 | MS-21 GE#...2WD | 91/10~94/ | Transmission & Differential INPUT SHAFT |
| 03906 3573 | G304 33 065 | 56 x 68 x 5 x 11 | MS-22 GESR 4WD | 92/3~94/ | Wheel Hub REAR |
| 03906 6853 | FS01 11 399 | 90 x 109 x 9 x 10.5 | MS-23 FS | 91/11~94/ | Engine CRANK SHAFT REAR |
| 03906 9021 | KL02 10 155 | | MS-8 KF,KL EXHAUST | 92/3~98/ | Engine VALVE STEM SEAL |
| 03906 9221 | F003 27 238A | 35 x 56 x 9 x 15 | MS-9 MBEP,MB5A,MB5P | 92/3~98/ | Transmission & Differential DIFF. SIDE |
| 03906 4213 | G304 33 065 | 56 x 68 x 5 x 11 | MS-10 MBEP,MB5A,MB5P | 92/3~98/ | Wheel Hub FRONT |
| 03906 8485 | 0603 16 103 | 27 x 43 x 9 | MS-11 MBEP,MB5A,MB5P | 92/3~98/ | Transmission & Differential INPUT SHAFT |
| 03906 2037 | FS01 10 602 | 42.5 x 54.5 x 6 | MS-12 KF(2000) MBEP | 92/3~98/ | Engine OIL PUMP |
| 03906 4941 | FS01 10 602 | 42.5 x 54.5 x 6 | MS-13 KL(2500) MB5A,MB5P | 92/3~98/ | Engine OIL PUMP |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7709 | B630 10 602 | 30 x 44 x 7 | MS-14 KF,KL | 92/3~98/ | Engine CAM SHAFT |
| 03906 7285 | KL01 11 312 | 75 x 93 x 9 | MS-15 KF,KL | 92/3~98/ | Engine CRANK SHAFT REAR |
| 03906 1253 | KL01 10 155 | | MS-16 KF,KL INTAKE | 92/3~98/ | Engine VALVE STEM SEAL |
| 03906 2781 | P043 27 238 | 38 x 58 x 9 x 14.5 | MS-9 HD5S,HDES | 91/10~96/ | Differential SIDE |
| 03906 1677 | JE15 10 602A | 43 x 55 x 6 | MS-10 JE(3000 V6) HDES | 91/10~96/ | Engine OIL PUMP |
| 03906 9061 | JE26 12 601A | 38 x 52 x 7 | MS-11 J5,JE | 91/10~96/ | Engine CAM SHAFT RH |
| 03906 8717 | JF01 11 312A | 75 x 93 x 9 | MS-12 J5,JE | 91/10~96/ | Engine CRANK SHAFT REAR |
| 03906 1949 | B660 10 155 | | MS-13 J5,JE | 91/10~96/ | Engine VALVE STEM SEAL |
| 03906 4645 | JE26 12 602A | 65 x 81 x 7 | MS-14 J5,JE | 91/10~96/ | Engine CAM SHAFT LH |
| 03906 1805 | R001 27 165 | 40 x 75 x 11 x 16.5 | MS-15 HD5S,HDES | 91/10~96/ | Differential PINION |
| 03906 2109 | JE15 10 602A | 43 x 55 x 6 | MS-16 J5(2500 V6) HD5S | 91/10~96/ | Engine OIL PUMP |
| 03906 6405 | KL01 10 155 | | MX-6 KF,KL INTAKE | 91/11~96/ | Engine VALVE STEM SEAL |
| 03906 5477 | G304 33 065 | 56 x 68 x 5 x 11 | MX-7 GEEB,GEES,GE5B,GE5S | 91/11~96/ | Wheel Hub FRONT |
| 03906 4405 | 0603 16 103 | 27 x 43 x 9 | MX-8 GEEB,GEES,GE5B,GE5S | 91/11~96/ | Transmission & Differential INPUT SHAFT |
| 03906 5869 | F003 27 238A | 35 x 56 x 9 x 15 | MX-9 GEEB,GEES,GE5B,GE5S | 91/11~96/ | Transmission & Differential DIFF. SIDE |
| 03906 3061 | FS01 10 602 | 42.5 x 54.5 x 6 | MX-10 KF(2000 V6) GEEB,GEES | 91/11~96/ | Engine OIL PUMP |
| 03906 1797 | FS01 10 602 | 42.5 x 54.5 x 6 | MX-11 KL(2500 V6) GE5B,GE5S | 91/11~96/ | Engine OIL PUMP |
| 03906 8149 | KL01 11 312 | 75 x 93 x 9 | MX-12 KF,KL | 91/11~96/ | Engine CRANK SHAFT REAR |
| 03906 6181 | KL02 10 155 | | MX-13 KF,KL EXHAUST | 91/11~96/ | Engine VALVE STEM SEAL |
| 03906 2349 | B630 10 602 | 30 x 44 x 7 | MX-14 KF,KL | 91/11~96/ | Engine CAM SHAFT |
| 03906 3877 | G304 33 065 | 56 x 68 x 5 x 11 | PERSONA MA8P,MAEP | 88/10~92/ | Wheel Hub FRONT |
| 03906 6637 | GJ21 26 154 | 42 x 58 x 7 | PERSONA MA8P,MAEP | 88/10~92/ | Wheel Hub REAR |
| 03906 7221 | 0603 16 103 | 27 x 43 x 9 | PERSONA MA8P,MAEP | 88/10~92/ | Transmission & Differential INPUT SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 3069 | F003 27 238A | 35 x 56 x 9 x 15 | PERSONA MA8P,MAEP | 88/10~92/ | Transmission & Differential DIFF. SIDE |
| 03906 5597 | F801 10 602 | 34 x 48 x 7 | PERSONA F8(1800) MA8P | 88/10~92/ | Engine OIL PUMP |
| 03906 6765 | F801 10 602 | 34 x 48 x 7 | PERSONA FE(2000) MAEP | 88/10~92/ | Engine OIL PUMP |
| 03906 2533 | F801 10 602 | 34 x 48 x 7 | PERSONA F8,FE | 88/10~92/ | Engine CAM SHAFT |
| 03906 3517 | F801 11 399 | 90 x 110 x 9 | PERSONA F8,FE | 88/10~92/ | Engine CRANK SHAFT REAR |
| 03906 5677 | B660 10 155 | | PERSONA F8,FE | 88/10~92/ | Engine VALVE STEM SEAL |
| 03906 5101 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | PREMACY CP8W 4WD | 99/4~ | Mission & Differential REAR DIFF. SIDE |
| 03906 4525 | KL01 10 155 | | PREMACY FS,FP INTAKE | 99/4~ | Engine VALVE STEM SEAL |
| 03906 2837 | FS01 11 399 | 90 x 109 x 9 x 10.5 | PREMACY FP,FS | 99/4~ | Engine CRANK SHAFT REAR |
| 03906 8133 | F801 10 602 | 34 x 48 x 7 | PREMACY FP,FS | 99/4~ | Engine CAM SHAFT |
| 03906 2709 | FS01 10 602 | 42.5 x 54.5 x 6 | PREMACY FP(1800) CP8W | 99/4~ | Engine OIL PUMP |
| 03906 9173 | T005 27 238A | 35 x 45 x 63.5 x 16.5 | PREMACY CP8W 4WD | 99/4~ | Mission & Differential FRONT DIFF. SIDE |
| 03906 1469 | F003 27 238A | 35 x 56 x 9 x 15 | PREMACY CP8W,CPEW 2WD | 99/4~ | Mission & Differential FRONT DIFF. SIDE |
| 03906 7189 | G304 33 065 | 56 x 68 x 5 x 11 | PREMACY CP8W 4WD | 99/4~ | Wheel Hub REAR |
| 03906 6141 | G304 33 065 | 56 x 68 x 5 x 11 | PREMACY CP8W,CPEW | 99/4~ | Wheel Hub FRONT |
| 03906 8549 | KL02 10 155 | | PREMACY FS,FP EXHAUST | 99/4~ | Engine VALVE STEM SEAL |
| 03906 1853 | FS01 10 602 | 42.5 x 54.5 x 6 | PREMACY FS(2000) CPEW | 01/7~ | Engine OIL PUMP |
| 03906 6269 | 0603 16 103 | 27 x 43 x 9 | PRESSO / AZ-3 ECPSA(1800CC) | 93/9~99/ | Transmission & Differential INPUT SHAFT |
| 03906 3101 | KL01 10 155 | | PRESSO / AZ-4 B5,K8 INTAKE | 91/6~99/ | Engine VALVE STEM SEAL |
| 03906 1709 | KL01 11 312 | 75 x 93 x 9 | PRESSO / AZ-5 K8 ECPSA | 93/9~99/ | Engine CRANK SHAFT REAR |
| 03906 7069 | B630 11 312 | 83 x 100 x 9 | PRESSO / AZ-6 B5 EC5SA | 91/6~99/ | Engine CRANK SHAFT REAR |
| 03906 4605 | BP01 10 602A | 30 x 44 x 7 | PRESSO / AZ-7 K8 ECPSA | 93/9~99/ | Engine CAM SHAFT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 1525 | F801 10 602 | 34 x 48 x 7 | PRESSO / AZ-8 B5 EC5SA | 91/6~99/ | Engine CAM SHAFT |
| 03906 8901 | FS01 10 602 | 42.5 x 54.5 x 6 | PRESSO / AZ-9 K8 ECPSA | 93/9~99/ | Engine OIL PUMP |
| 03906 9077 | F003 27 238A | 35 x 56 x 9 x 15 | PRESSO / AZ-10 EC# | 91/6~99/ | Transmission & Differential DIFF. SIDE (LH & RH) |
| 03906 3485 | 0613 16 103 | 24 x 40 x 8 | PRESSO / AZ-11 EC5SA(1500CC) | 91/6~99/ | Transmission & Differential INPUT SHAFT |
| 03906 2453 | KL02 10 155 | | PRESSO / AZ-12 B5,K8 EXHAUST | 91/6~99/ | Engine VALVE STEM SEAL |
| 03906 9205 | B3C7 10 602A | 36.5 x 50.5 x 7 | PRESSO / AZ-13 B5 EC5SA | 91/6~99/ | Engine OIL PUMP |
| 03906 1181 | G304 33 065 | 56 x 68 x 5 x 11 | PRESSO / AZ-14 EC# | 91/6~99/ | Wheel Hub FRONT |
| 03906 3317 | B630 10 155 | | PROCEED G5,G6 | 89/11~99/ | Engine VALVE STEM SEAL |
| 03906 2245 | G601 11 399 | 90 x 110 x 9 x 12 | PROCEED G5,G6,WL | 89/11~99/ | Engine CRANK SHAFT REAR |
| 03906 6613 | UC86 33 067 | 60 x 75 x 86 x 12 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Wheel Hub FRONT OUTER |
| 03906 5349 | UC86 33 065A | 65 x 82 x 95 x 13.5 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Wheel Hub FRONT INNER |
| 03906 1589 | H501 17 103 | 27 x 43 x 7 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Transmission FRONT |
| 03906 8397 | M504 17 335 | 42 x 65 x 11 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Transmission REAR |
| 03906 7645 | R001 27 165 | 40 x 75 x 11 x 16.5 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Differential PINION |
| 03906 1173 | JF01 10 602A | 46 x 60 x 7 | PROCEED G6(2600) UF66M,UV66R | 89/11~96/ | Engine TIMING COVER |
| 03906 5197 | JF01 10 602A | 46 x 60 x 7 | PROCEED G5(2500) UV56R | 96/2~99/ | Engine TIMING COVER |
| 03906 3685 | VS01 10 602 | 53 x 70 x 11 | PROCEED WL(2500 DSL) UVL6R | 96/2~99/ | Engine TIMING COVER ( NO.1) |
| 03906 6869 | WL01 10 602 | 60 x 76 x 7 | PROCEED WL(2500 DSL) UVL6R | 96/2~99/ | Engine TIMING COVER ( NO.2) |
| 03906 1165 | WL01 10 155 | | PROCEED WL | 96/3~99/ | Engine VALVE STEM SEAL |
| 03906 5765 | UB40 26 157 | 48 x 70 x 10 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Wheel Hub REAR OUTER |
| 03906 4741 | UB40 26 154 | 35 x 58 x 10 | PROCEED UF66M,UV66R,UV56R,UVL6R | 89/11~99/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 6245 | F003 27 238A | 35 x 56 x 9 x 15 | REVUE DB5PA(1500) | 90/9~ | Mission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03906 6461 | B001 33 065A | 52 x 68 x 7 x 13 | REVUE DB# | 90/9~ | Wheel Hub FRONT INNER |
| 03906 8213 | B092 33 067 | 52 x 63 x 8.5 | REVUE DB# | 90/9~ | Wheel Hub FRONT OUTER |
| 03906 2517 | 0419 16 213 | 22 x 38 x 8 | REVUE DB3PA(1300) | 90/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03906 4877 | B001 27 238 | 35 x 51 x 9 x 15 | REVUE DB3PA(1300) | 90/9~ | Mission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03906 9005 | F003 27 238A | 35 x 56 x 9 x 15 | REVUE DB# | 90/9~ | Mission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03906 3741 | B3C7 10 602A | 36.5 x 50.5 x 7 | REVUE DB# | 90/9~ | Engine OIL PUMP |
| 03906 5133 | B630 11 312 | 83 x 100 x 9 | REVUE DB# | 90/9~ | Engine CRANK SHAFT REAR |
| 03906 6957 | B630 10 155 | | REVUE DB# | 90/9~ | Engine VALVE STEM SEAL |
| 03906 6189 | B630 10 602 | 30 x 44 x 7 | REVUE DB# | 90/9~ | Engine CAM SHAFT |
| 03906 7741 | 0613 16 103 | 24 x 40 x 8 | REVUE DB5PA(1500) | 90/9~ | Mission & Differential (M/T) INPUT SHAFT |
| 03906 3765 | M054 27 165 | 40 x 64 x 11 x 16 | ROADSTER NB6C,NB8C | 97/12~ | Differential PINION |
| 03906 3589 | B3C7 10 602A | 36.5 x 50.5 x 7 | ROADSTER B6 NA6CE,NB6C | 90/8~ | Engine OIL PUMP |
| 03906 2637 | B630 10 602 | 30 x 44 x 7 | ROADSTER B6 NA6CE | 89/9~90/8 | Engine OIL PUMP |
| 03906 6885 | KL01 10 155 | | ROADSTER B6,BP INTAKE | 93/8~ | Engine VALVE STEM SEAL |
| 03906 1509 | T020 27 238 | 35 x 56 x 10 x 16.5 | ROADSTER NA6CE | 89/9~83/ | Differential SIDE |
| 03906 6477 | F003 27 238A | 35 x 56 x 9 x 15 | ROADSTER NB6C,NB8C | 97/12~ | Differential SIDE |
| 03906 8493 | F003 27 238A | 35 x 56 x 9 x 15 | ROADSTER NA8C | 93/8~ | Differential SIDE |
| 03906 2605 | ZL09 10 602 | 47 x 61 x 7 | ROADSTER BP | 97/12~ | Engine CAM SHAFT (NO.2) |
| 03906 2181 | KL02 10 155 | | ROADSTER B6,BP EXHAUST | 93/8~ | Engine VALVE STEM SEAL |
| 03906 7597 | BP05 11 312 | 83 x 100 x 9 | ROADSTER B6,BP | 93/8~ | Engine CRANK SHAFT REAR |
| 03906 5381 | B3C7 10 602A | 36.5 x 50.5 x 7 | ROADSTER BP NA8C,NB8C | 93/8~ | Engine OIL PUMP |
| 03906 6669 | B630 11 312 | 83 x 100 x 9 | ROADSTER B6 | 89/9~93/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 1957 | M507 17 335A | 35 x 48 x 18 x 23 | ROADSTER NA6CE,NA8C | 89/9~98/ | Transmission REAR EXTENSION |
| 03906 6493 | B660 10 155 | | ROADSTER B6 | 89/9~93/ | Engine VALVE STEM SEAL |
| 03906 2405 | F801 10 602 | 34 x 48 x 7 | ROADSTER BP | 93/8~ | Engine CAM SHAFT |
| 03906 3837 | G304 33 065 | 56 x 68 x 5 x 11 | ROADSTER NA6CE | 89/9~93/ | Wheel Hub REAR |
| 03906 5125 | G304 33 065 | 56 x 68 x 5 x 11 | ROADSTER NA8C | 93/8~98/ | Wheel Hub REAR |
| 03906 1773 | H501 17 103 | 27 x 43 x 7 | ROADSTER NA6CE,NA8C | 89/9~98/ | Transmission FRONT COVER |
| 03906 3349 | H501 17 103 | 27 x 43 x 7 | ROADSTER NB6C 5MT | 97/12~ | Transmission FRONT COVER |
| 03906 7373 | Y601 17 131 | 30 x 42 x 7 | ROADSTER NB8C 6MT | 97/12~ | Transmission FRONT COVER |
| 03906 3709 | M054 27 165 | 40 x 64 x 11 x 16 | ROADSTER NA8C | 93/8~98/ | Differential PINION |
| 03906 8293 | F801 10 602 | 34 x 48 x 7 | ROADSTER B6 | 89/9~ | Engine CAM SHAFT |
| 03906 3885 | T020 27 165 | 32 x 54 x 10 | ROADSTER NA6CE | 89/9~93/ | Differential PINION |
| 03906 5693 | M507 17 335A | 35 x 48 x 18 x 23 | ROADSTER NB6C,NB8C | 97/12~ | Transmission REAR EXTENSION |
| 03906 8509 | H501 17 103 | 27 x 43 x 7 | RX-8 SE3P 5 SPEED | 03/4~ | Transmission (M/T) FRONT COVER |
| 03906 8461 | Y601 17 131 | 30 x 42 x 7 | RX-9 SE3P 6 SPEED | 03/4~ | Transmission (M/T) FRONT COVER |
| 03906 3365 | RA02 27 165 | 40 x 75 x 10 x 16.5 | RX-10 SE3P 4.5 SPEED | 03/4~ | Differential PINION |
| 03906 9093 | RA03 27 165A | 40 x 75 x 10 x 16.5 | RX-11 SE3P 6 SPEED | 03/4~ | Differential PINION |
| 03906 2381 | P043 27 238A | 38 x 58 x 9 x 14.5 | RX-12 SE3P 6 SPEED | 03/4~ | Differential DIFF. SIDE |
| 03906 5717 | R004 27 238 | 38 x 58 x 9 x 14.5 | RX-13 SE3P 4.5 SPEED | 03/4~ | Differential DIFF. SIDE |
| 03906 6133 | R001 27 165 | 40 x 75 x 11 x 16.5 | SAVANNA / RX-7 FD3S | 91/10~ | Differential PINION |
| 03906 2525 | 0603 16 103 | 27 x 43 x 9 | SAVANNA / RX-8 SA22C | 78/3~85/ | Transmission FRONT COVER |
| 03906 9101 | R501 17 335A | 38 x 51 x 60 x 23 | SAVANNA / RX-9 FD3S | 91/10~ | Transmission REAR |
| 03906 2229 | M502 17 335A | 38 x 51 x 13 x 15 | SAVANNA / RX-10 FC3# | 85/10~91/ | Transmission REAR |
| 03906 5733 | 0437 17 335A | 35 x 48 x 15 | SAVANNA / RX-11 SA22C | 78/3~85/ | Transmission REAR |
| 03906 8405 | H501 17 103 | 27 x 43 x 7 | SAVANNA / RX-12 FD3S | 91/10~ | Transmission FRONT COVER |
| 03906 4597 | P016 27 165A | 48 x 78 x 14 x 19 | SAVANNA / RX-13 FC3# | 85/10~91/ | Differential PINION |
| 03906 4285 | 0603 16 103 | 27 x 43 x 9 | SAVANNA / RX-14 FC3#...C/# ~200000 | 85/10~89/ 1 | Transmission FRONT COVER |
| 03906 5445 | 0223 27 018 | 40 x 64 x 12 | SAVANNA / RX-15 SA22C C/#~199999 | 78/3~82/1 | Differential PINION |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 5629 | FB01 26 065A | 57.5 x 72 x 8 | SAVANNA / RX-16 FC3# | 85/10~91/ | Wheel Hub REAR |
| 03906 2621 | 1011 26 154 | 48 x 62 x 9 | SAVANNA / RX-17 SA22C C/# 300001~ | 83/10~85/ | Wheel Hub REAR |
| 03906 6749 | 0187 26 154 | 42 x 55 x 9 | SAVANNA / RX-18 SA22C C/#~299999 | 78/3~83/9 | Wheel Hub REAR |
| 03906 3965 | F801 33 065A | 52 x 63 x 8 | SAVANNA / RX-19 FC3# | 85/10~91/ | Wheel Hub FRONT |
| 03906 3477 | 1312 33 065 | 40 x 54 x 6 | SAVANNA / RX-20 SA22C | 78/3~85/ | Wheel Hub FRONT |
| 03906 5605 | M005 27 165 | 40 x 64 x 12 x 17.5 | SAVANNA / RX-21 SA22C C/# 200001~ | 82/2~85/ | Differential PINION |
| 03906 1117 | H501 17 103 | 27 x 43 x 7 | SAVANNA / RX-22 FC3#...C/# 200001~ | 89/1~91/ | Transmission FRONT COVER |
| 03906 8829 | JE26 12 601A | 38 x 52 x 7 | SENTIA J5,JE(DOHC) | 91/10~ | Engine CAM SHAFT RH |
| 03906 3637 | R004 27 238 | 38 x 58 x 9 x 14.5 | SENTIA HEEA,HEEP | 95/10~ | Differential SIDE |
| 03906 8237 | P043 27 238 | 38 x 58 x 9 x 14.5 | SENTIA HD5S,HDES | 91/3~96/ | Differential SIDE |
| 03906 6365 | RA02 27 165 | 40 x 75 x 10 x 16.5 | SENTIA HEEA,HEEP | 95/10~ | Differential PINION |
| 03906 4517 | R001 27 165 | 40 x 75 x 11 x 16.5 | SENTIA HD5S,HD5P,HDES,HDEP | 91/3~96/ | Differential PINION |
| 03906 2133 | JE15 10 602A | 43 x 55 x 6 | SENTIA J5(2500 V6) HD5S,HD5P | 91/3~96/ | Engine OIL PUMP |
| 03906 2093 | JE26 12 602A | 65 x 81 x 7 | SENTIA J5,JE(DOHC) | 91/10~ | Engine CAM SHAFT LH |
| 03906 8445 | JF01 12 602A | 35 x 49.5 x 11 | SENTIA JE(SOHC) | 95/10~ | Engine CAM SHAFT |
| 03906 1981 | JF01 11 312A | 75 x 93 x 9 | SENTIA J5,JE | 91/10~96/ | Engine CRANK SHAFT REAR |
| 03906 6549 | B660 10 155 | | SENTIA J5,JE HD# | 91/10~96/ | Engine VALVE STEM SEAL |
| 03906 4029 | KL02 10 155 | | SENTIA JE(DOHC) HE# | 95/10~ | Engine VALVE STEM SEAL |
| 03906 5557 | B630 10 155 | | SENTIA JE(SOHC) NO.1 HE# | 95/10~ | Engine VALVE STEM SEAL |
| 03906 8989 | HE19 10 155 | | SENTIA JE(SOHC) NO.2 HE# | 95/10~ | Engine VALVE STEM SEAL |
| 03906 4237 | JE15 10 602A | 43 x 55 x 6 | SENTIA JE(3000 V6) HDES,HDEP,HEEA,HEEP | 91/3~ | Engine OIL PUMP |
| 03906 6653 | W001 27 165 | 50 x 75 x 17 | T3000, T3500, BUS W VL | 81/10~89/1 | Differential PINION |
| 03906 6757 | W501 17 335A | 42 x 65 x 12 | T3000, T3500, BUS W VL | 81/10~ | Transmission REAR |
| 03906 4861 | W026 27 165 | 50 x 75 x 13 x 18.5 | T3000, T3500, BUS W VL | 89/1~ | Differential PINION |
| 03906 5685 | 0527 27 018 | 45 x 75 x 12 | T3000, T3500, BUS TA3H | 77/8~81/ | Differential PINION |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2285 | 1363 17 335 | 40 x 62 x 11 | T3000, T3500, BUS TA3H | 77/8~81/ | Transmission REAR |
| 03906 3829 | 0155 16 103 | 30 x 44 x 9 | T3000, T3500, BUS TA3H,W VL | 77/8~ | Transmission FRONT COVER |
| 03906 4509 | W025 26 157 | 43 x 50 x 9 | T3000, T3500, BUS W VL | 81/10~ | Wheel Hub REAR OUTER |
| 03906 7581 | W025 26 154 | 75 x 121 x 13 | T3000, T3500, BUS W VL | 81/10~ | Wheel Hub REAR INNER |
| 03906 4573 | 0557 26 154 | 75 x 121 x 13 x 23 | T3000, T3500, BUS TA3H S TIRE | 77/8~81/ | Wheel Hub REAR INNER |
| 03906 1741 | W001 33 065 | 65 x 90 x 13 | T3000, T3500, BUS W VL | 81/10~ | Wheel Hub FRONT |
| 03906 2733 | 0559 33 065 | 70 x 88 x 12 | T3000, T3500, BUS TA3H | 77/8~81/ | Wheel Hub FRONT |
| 03906 4469 | 0600 26 154 | 75 x 121 x 13 | T3000, T3500, BUS TA3H W TIRE | 77/8~81/ | Wheel Hub REAR INNER |
| 03906 7549 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN S TIRE 2T W TIRE 2500/2T | 87/2~89/1 | Differential PINION |
| 03906 7877 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN W TIRE (FULL WIDE LOW 3000),3500 | 89/4~90/7 | Differential PINION |
| 03906 6349 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN S TIRE 3000,3500 | 89/4~90/7 | Differential PINION |
| 03906 6101 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN W TIRE 3000,3500 | 87/2~89/1 | Differential PINION |
| 03906 7213 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN S TIRE 2T W TIRE 2500/2T | 89/1~89/4 | Differential PINION |
| 03906 5229 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3500 TURBO WIDE LOW | 84/1~89/4 | Differential PINION |
| 03906 7909 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3500 4WD | 84/1~89/4 | Differential PINION |
| 03906 5845 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN 1.5T WIDE LOW MT | 91/12~ | Differential PINION |
| 03906 4637 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN 1.5T | 90/7~91/12 | Differential PINION |
| 03906 6645 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN W TIRE FULL WIDE LOW (2500),WIDE LOW (1.5T) | 89/4~90/7 | Differential PINION |
| 03906 8157 | W025 26 157 | 43 x 50 x 9 | TITAN WG WIDE LOW(LSD+WIDE CABIN) (4600) | 91/12~95/ | Wheel Hub REAR OUTER |
| 03906 2477 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN W TIRE 3000,3500 | 87/2~89/1 | Differential PINION |
| 03906 7445 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN S TIRE 1.5T W TIRE (2500/1.5T),1.75T | 87/2~89/4 | Differential PINION |
| 03906 4109 | 0604 27 018 | 40 x 75 x 12 | TITAN EXR15 | 76/7~80/ | Differential PINION |
| 03906 4501 | 0527 27 018 | 45 x 75 x 12 | TITAN TA3H | 77/3~80/ | Differential PINION |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7085 | Z502 17 335 | 43 x 68 x 10 | TITAN WH 4600 | 00/4~ | Transmission REAR |
| 03906 2045 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN 250,030,003,500 | 80/10~84/1 | Differential PINION |
| 03906 6501 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN 2500,3000,3500 2WD,WITHOUT TORBO | 84/1~87/2 | Differential PINION |
| 03906 7605 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN S TIRE 2500 | 89/4~90/7 | Differential PINION |
| 03906 1693 | W029 26 157 | 49 x 56 x 9 | TITAN WH HIGH DECK WIDE CAB. 3.5T,4T,4.25T | 00/4~02/ | Wheel Hub REAR OUTER |
| 03906 5493 | W025 26 157 | 43 x 50 x 9 | TITAN WG H/DECK (WITHOUT TURBO) 2T,2.75T,3T,3.5T (4000) | 91/12~95/ | Wheel Hub REAR OUTER |
| 03906 6693 | 1363 17 335 | 40 x 62 x 11 | TITAN EXR15 | 76/7~80/ | Transmission REAR |
| 03906 8021 | S501 16 103 | 30 x 44 x 9 | TITAN WG,WH | 95/5~ | Transmission FRONT COVER |
| 03906 1629 | 0727 16 213 | 33 x 50 x 10 | TITAN WE,WG 3500 (TURBO),4100,4600 | 80/10~95/ | Transmission FRONT COVER |
| 03906 6325 | 0727 16 213 | 33 x 50 x 10 | TITAN TA2X# | 76/4~80/ | Transmission FRONT COVER |
| 03906 5757 | 0155 16 103 | 30 x 44 x 9 | TITAN WE,WG 2500,3000,3500 (W/D TURBO),4000 | 80/10~95/ | Transmission FRONT COVER |
| 03906 7925 | W025 26 157 | 43 x 50 x 9 | TITAN WH H/DECK (STD. CAB.),(WIDE CAB. 2T,3T) | 00/4~02/ | Wheel Hub REAR OUTER |
| 03906 4925 | W029 26 157 | 49 x 56 x 9 | TITAN WH HIGH DECK (FRONT DURM BRAKE) | 02/6~ | Wheel Hub REAR OUTER |
| 03906 7477 | W025 26 157 | 43 x 50 x 9 | TITAN WH FULL WIDE LOW (STD. CAB., WIDE CAB.) | 00/4~ | Wheel Hub REAR OUTER |
| 03906 8909 | W029 26 157 | 49 x 56 x 9 | TITAN WG HIGH DECK 3.5T(6 SPEED,LONG BODY),4T,4.25T | 95/5~00/ | Wheel Hub REAR OUTER |
| 03906 2829 | W029 26 157 | 49 x 56 x 9 | TITAN WG HIGH DECK 3.5T (4600),4T | 91/12~95/ | Wheel Hub REAR OUTER |
| 03906 4965 | W029 26 157 | 49 x 56 x 9 | TITAN WG HIGH DECK (TURBO) | 91/12~95/ | Wheel Hub REAR OUTER |
| 03906 3949 | W029 26 157 | 49 x 56 x 9 | TITAN WG H/DECK (WIDE CAB.) 3.5T ULTRA LONG,TURBO,4T | 89/5~91/12 | Wheel Hub REAR OUTER |
| 03906 5013 | W029 26 157 | 49 x 56 x 9 | TITAN WE 3500 TURBO,4100 | 80/10~89/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 3901 | W025 26 157 | 43 x 50 x 9 | TITAN WH H/DECK (FRONT DISC BRAKE) | 02/6~ | Wheel Hub REAR OUTER |
| 03906 6973 | 0155 16 103 | 30 x 44 x 9 | TITAN EXR15,TA3H# | 76/7~80/ | Transmission FRONT COVER |
| 03906 8741 | W025 26 157 | 43 x 50 x 9 | TITAN WE HIGH DECK(3000,3500 NT) | 80/10~89/ | Wheel Hub REAR OUTER |
| 03906 4813 | Z502 17 335 | 43 x 68 x 10 | TITAN WG 4600 | 98/~00/ | Transmission REAR |
| 03906 5469 | Z501 17 335 | 45 x 68 x 9 | TITAN WG 4600 | 92/1~96/ | Transmission REAR |
| 03906 2277 | Z501 17 335 | 45 x 68 x 9 | TITAN WH 3000,4000,4300 | 00/4~ | Transmission REAR |
| 03906 7637 | Z501 17 335 | 45 x 68 x 9 | TITAN WG 2500,3000,3500,4000,4300 | 89/5~00/ | Transmission REAR |
| 03906 1301 | Z501 17 335 | 45 x 68 x 9 | TITAN WE 3500 (TURBO,4WD),4100 | 80/10~89/ | Transmission REAR |
| 03906 4613 | W501 17 335A | 42 x 65 x 12 | TITAN WE 2500,3000,3500(WITHOUT TURBO) | 80/10~89/ | Transmission REAR |
| 03906 2445 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN W TIRE (WIDE LOW 2T,2.75T,3T) | 89/4~90/7 | Differential PINION |
| 03906 3309 | 1363 17 335 | 40 x 62 x 11 | TITAN TA3H# | 77/3~80/ | Transmission REAR |
| 03906 4197 | 1416 26 157 | KDS-3 x x | TITAN WH 2T,WIDE LOW | 00/4~ | Wheel Hub REAR OUTER |
| 03906 4917 | W025 26 157 | 43 x 50 x 9 | TITAN WG HIGH DECK (STD. CABIN) | 89/5~91/12 | Wheel Hub REAR OUTER |
| 03906 3149 | W025 26 157 | 43 x 50 x 9 | TITAN WG H/DECK (WIDE CAB.) EXC. 3.5T ULTRA LONG,TURBO,4 | 89/5~91/12 | Wheel Hub REAR OUTER |
| 03906 8685 | W025 26 157 | 43 x 50 x 9 | TITAN WG H/DECK 2T,2.75T,3T,3.5T (STD. CAB.,5 SPEED,STD. | 99/5~00/ | Wheel Hub REAR OUTER |
| 03906 1365 | W025 26 157 | 43 x 50 x 9 | TITAN WG WIDE LOW (2.75T~3.5T) | 95/5~00/ | Wheel Hub REAR OUTER |
| 03906 3605 | W025 26 157 | 43 x 50 x 9 | TITAN WG FULL WIDE LOW (2T),(WIDE CAB.) | 95/5~99/ | Wheel Hub REAR OUTER |
| 03906 2797 | W025 26 157 | 43 x 50 x 9 | TITAN WG FULL WIDE LOW (STD. CAB., WIDE CAB.) | 99/4~00/ | Wheel Hub REAR OUTER |
| 03906 7805 | 0727 17 335 | 50 x 72 x 12 | TITAN TA2X | 75/9~80/ | Transmission REAR |
| 03906 6485 | 1304 10 602A | 61 x 79.5 x 11 x 13.5 | TITAN TA2X# | 75/9~80/ | Engine TIMING GEAR COVER |
| 03906 4101 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 2.75T 3500 STD. BODY | 90/7~91/12 | Differential PINION |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 7781 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 3.5T 3500T STD. BODY | 90/7~91/12 | Differential PINION |
| 03906 4749 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 3.5T 4000 LONG BODY | 90/7~91/12 | Differential PINION |
| 03906 3869 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 4T (3500T STD. BODY),4000 | 90/7~91/12 | Differential PINION |
| 03906 5821 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 3.5T,4T 3500,(4000+STD. BODY) | 91/12~95/ | Differential PINION |
| 03906 4373 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 3.5T,4T (4600 HIGH DECK) | 91/12~95/ | Differential PINION |
| 03906 3405 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 3.5T HIGH DECK LONG BODY | 95/5~ | Differential PINION |
| 03906 9165 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 4T,4.25T | 95/5~ | Differential PINION |
| 03906 2677 | SE08 10 602 | 50 x 70 x 11 | TITAN EXR15,TA3H | 76/7~80/ | Engine TIMING GEAR COVER |
| 03906 6413 | SE08 10 602 | 50 x 70 x 11 | TITAN XA(2500) | 80/10~92/ | Engine TIMING GEAR COVER |
| 03906 8773 | SE08 10 602 | 50 x 70 x 11 | TITAN HA(3000) | 80/10~95/ | Engine TIMING GEAR COVER |
| 03906 2757 | YJ01 10 155 | | TITAN YJ(4300),YM(4600) IN. & EX. | 95/5~ | Engine VALVE STEM SEAL |
| 03906 2317 | VS01 10 602 | 53 x 70 x 11 | TITAN VS(3000) | 95/5~ | Engine TIMING GEAR COVER |
| 03906 2989 | W001 26 154 | 75 x 105 x 15 | TITAN EXC 2.75T~ | 71/~77/ | Wheel Hub FRONT |
| 03906 3205 | V101 10 602 | 60 x 79 x 11 | TITAN ZB(4100) | 80/10~87/ | Engine TIMING GEAR COVER |
| 03906 1317 | TF20 10 602 | 60 x 81 x 11 | TITAN TF(4000) | 89/5~ | Engine TIMING GEAR COVER |
| 03906 1541 | TF20 10 602 | 60 x 81 x 11 | TITAN TM(4600) | 92/1~95/ | Engine TIMING GEAR COVER |
| 03906 7773 | YJ01 10 602 | 109 x 137 x 13 | TITAN YJ(4300) | 95/5~ | Engine TIMING GEAR COVER |
| 03906 3093 | YJ01 10 602 | 109 x 137 x 13 | TITAN YM(4600) | 95/5~ | Engine TIMING GEAR COVER |
| 03906 5781 | 0636 11 399 | | TITAN EXR15 | 76/7~80/ | Engine CRANK SHAFT REAR |
| 03906 5341 | SE08 11 399 | 101 x 125 x 13 | TITAN TA3H | 77/3~80/ | Engine CRANK SHAFT REAR |
| 03906 9053 | SE08 11 399 | 101 x 125 x 13 | TITAN XA92500),HA(3000),SL(3500),ZB(4100) | 80/10~95/ | Engine CRANK SHAFT REAR |
| 03906 2581 | SE08 11 399 | 101 x 125 x 13 | TITAN VS(3000) | 95/5~ | Engine CRANK SHAFT REAR |
| 03906 3021 | 1304 11 399 | 132 x 158.8 x 12.4 | TITAN TA2X# | 75/9~80/ | Engine CRANK SHAFT REAR |
| 03906 3909 | TF20 11 399 | 105 x 125 x 13 | TITAN TF(4000),TM(4600) | 89/5~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2573 | SE08 10 602 | 50 x 70 x 11 | TITAN SL(3500) | 84/2~95/ | Engine TIMING GEAR COVER |
| 03906 2061 | Y001 27 165 | 62 x 104 x 12 x 20 | TITAN TA2X | 75/9~80/ | Differential PINION |
| 03906 6597 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN W TIRE H/D 3500T STD BODY | 89/4~90/7 | Differential PINION |
| 03906 2893 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 4000 2T,2.75T,3T,(3.5T STD BODY) | 89/4~90/7 | Differential PINION |
| 03906 1381 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 2T EXCEPT (TURBO H/D STD BODY) | 90/7~91/12 | Differential PINION |
| 03906 4437 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 2T EXCEPT (TURBO LONG BODY) | 90/7~91/12 | Differential PINION |
| 03906 1661 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 2.75T 3500 SHORT BODY | 90/7~91/12 | Differential PINION |
| 03906 4245 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 2.75T 4000 STD. BODY | 90/7~91/12 | Differential PINION |
| 03906 2933 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3T | 90/7~91/12 | Differential PINION |
| 03906 3549 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3.5T 4000 (SHORT BODY,STD BODY) | 90/7~91/12 | Differential PINION |
| 03906 5549 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 1.5T EXC. WIDE LOW/MT | 91/12~ | Differential PINION |
| 03906 7957 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 2T,2.75T,3T | 91/12~ | Differential PINION |
| 03906 7045 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3.5T,4T 4000 H/D SHORT BODY | 91/12~95/ | Differential PINION |
| 03906 8285 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 2T TURBO LONG BODY | 90/7~91/12 | Differential PINION |
| 03906 3701 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3.5T WIDE LOW,FULL WIDE LOW,(H/DECK SEMI LONG BODY | 95/5~ | Differential PINION |
| 03906 1477 | SE01 10 155 | | TITAN XA(2500),HA(3000),SL(3500),TF(4000) INTAKE | 80/10~95/ | Engine VALVE STEM SEAL |
| 03906 1821 | Y001 27 165 | 62 x 104 x 12 x 20 | TITAN 4100 | 84/1~87/2 | Differential PINION |
| 03906 8045 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 3500 HIGH DECK TURBO | 84/1~89/4 | Differential PINION |
| 03906 2077 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN W TIRE H/D 3500T LONG BODY | 89/4~90/7 | Differential PINION |
| 03906 8517 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 4000 4T,(3.5T LONG BODY) | 89/4~90/7 | Differential PINION |
| 03906 4205 | Y005 27 165 | 62 x 104 x 12 x 19 | TITAN 2T TURBO H/D STD BODY | 90/7~91/12 | Differential PINION |
| 03906 8805 | 0324 10 155 | | TITAN ZB(4100) INTAKE | 80/10~87/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2189 | YJ01 11 399 | 104 x 139 x 13 | TITAN YJ(4300),YM(4600) | 95/5~ | Engine CRANK SHAFT REAR |
| 03906 6293 | SE70 10 155 | | TITAN VS(3000),TF(4000) EXHAUST | 95/5~ | Engine VALVE STEM SEAL |
| 03906 6125 | SE70 10 155 | | TITAN XA(2500),HA(3000),SL(3500) ,TF(4000) EXHAUST | 88/~95/ | Engine VALVE STEM SEAL |
| 03906 8781 | 1416 26 157 | KDS-3 | TITAN WH S TIRE | 00/4~ | Wheel Hub REAR OUTER |
| 03906 8181 | SE01 10 155A | | TITAN VS(3000),TF(4000) INTAKE | 95/5~ | Engine VALVE STEM SEAL |
| 03906 6733 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN W TIRE (HIGH DECK 3000,3500NT) | 89/4~90/7 | Differential PINION |
| 03906 7205 | W026 27 165 | 50 x 75 x 13 x 18.5 | TITAN 3.5T,4T 4600 FULL WIDE LOW | 91/12~95/ | Differential PINION |
| 03906 6573 | 0604 26 184 | 42 x 65 x 9 | TITAN EVB12(TITAN L) | 71/~77/ | Wheel Hub REAR INNER |
| 03906 2717 | W029 33 065 | 65 x 100 x 12 | TITAN WE 3500(TURBO) 3.5T ULTRA LONG,4T | 86/3~89/ | Wheel Hub FRONT |
| 03906 3757 | 1416 26 157 | KDS-3 x x | TITAN WG FULL WIDE LOW(1.5T) | 95/5~99/ | Wheel Hub REAR OUTER |
| 03906 9213 | W029 33 065 | 65 x 100 x 12 | TITAN WG TURBO,3.5T(4600),4T | 91/12~95/ | Wheel Hub FRONT |
| 03906 8765 | W029 33 065 | 65 x 100 x 12 | TITAN WG HIGH DECK 3.5T(6 SPEED,LONG BODY),4T,4.25T | 95/5~00/ | Wheel Hub FRONT |
| 03906 7525 | W029 33 065 | 65 x 100 x 12 | TITAN WH DRUM BRAKE HIGH DECK(3.5T WIDE CAB.),4T,4.25T | 00/4~02/ | Wheel Hub FRONT |
| 03906 3717 | W029 33 065 | 65 x 100 x 12 | TITAN WH DRUM BRAKE | 02/6~ | Wheel Hub FRONT |
| 03906 7557 | W001 26 154 | 75 x 105 x 15 | TITAN WE S TIRE | 80/10~89/ | Wheel Hub REAR INNER |
| 03906 1325 | W782 33 154A | 28 x 55 x 9 | TITAN WE,WG 4WD | 85/9~00/ | Wheel Hub FRONT DRIVE SHAFT |
| 03906 7349 | W001 33 065 | 65 x 90 x 13 | TITAN WG 3.5T(6SPEED,STANDARD BODY) | 95/5~00/ | Wheel Hub FRONT |
| 03906 2141 | 0604 26 184 | 42 x 65 x 9 | TITAN EXR S TIRE | 76/7~80/ | Wheel Hub REAR INNER |
| 03906 2197 | 0557 26 154 | 75 x 121 x 13 x 23 | TITAN EVB,EXB,EXC,TA3H S TIRE | 71/~80/ | Wheel Hub REAR INNER |
| 03906 8597 | 0600 26 154 | 75 x 121 x 13 | TITAN EVB,EXB,EXC W TIRE | 71/~77/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 2885 | 0600 26 154 | 75 x 121 x 13 | TITAN TA3H#...W TIRE(EXCEPT WIDE LOW) | 77/5~80/ | Wheel Hub REAR INNER |
| 03906 1549 | 0600 26 154 | 75 x 121 x 13 | TITAN TA2X# | 76/4~80/ | Wheel Hub REAR INNER |
| 03906 4717 | W001 33 065 | 65 x 90 x 13 | TITAN EXR15 WIDE LOW | 76/7~80/ | Wheel Hub REAR INNER |
| 03906 4581 | W001 26 154 | 75 x 105 x 15 | TITAN TA3H WIDE LOW | 78/10~80/ | Wheel Hub REAR INNER |
| 03906 1445 | W782 33 065A | 75 x 105 x 10 x 14 | TITAN WE,WG 4WD | 85/9~00/ | Wheel Hub FRONT |
| 03906 3389 | W001 33 065 | 65 x 90 x 13 | TITAN WG S TIRE | 89/5~95/ | Wheel Hub FRONT |
| 03906 1781 | 0559 33 065 | 70 x 88 x 12 | TITAN EVB,EXB EXCEPT 3T~ | 71/~77/ | Wheel Hub FRONT |
| 03906 5269 | 0559 33 065 | 70 x 88 x 12 | TITAN EXC EXCEPT 2.75T~ | 71/~77/ | Wheel Hub FRONT |
| 03906 7653 | 0559 33 065 | 70 x 88 x 12 | TITAN EXR# | 76/7~80/ | Wheel Hub FRONT |
| 03906 6605 | 0559 33 065 | 70 x 88 x 12 | TITAN TA3H#...EXCEPT 3T~,MUXER | 77/5~80/ | Wheel Hub FRONT |
| 03906 2493 | W001 26 154 | 75 x 105 x 15 | TITAN EVB,EXB 3T~ | 71/~77/ | Wheel Hub FRONT |
| 03906 1749 | W001 26 154 | 75 x 105 x 15 | TITAN TA3H#...3T~,MIXER | 77/5~80/ | Wheel Hub FRONT |
| 03906 8381 | W001 33 065 | 65 x 90 x 13 | TITAN WE 2500,3000 | 80/10~89/ | Wheel Hub FRONT |
| 03906 5669 | W001 26 154 | 75 x 105 x 15 | TITAN TA2X# | 76/4~80/ | Wheel Hub FRONT |
| 03906 8541 | W001 33 065 | 65 x 90 x 13 | TITAN WE 3500(TURBO),EXCEPT 3.5T ULTRA LONG,4T | 86/3~89/ | Wheel Hub FRONT |
| 03906 7821 | W001 33 065 | 65 x 90 x 13 | TITAN WH DRUM BRAKE H/DECK(3T,3.5T,5T STD.CAB.),F/W.LOW | 00/4~02/ | Wheel Hub FRONT |
| 03906 2509 | W001 33 065 | 65 x 90 x 13 | TITAN WG WIDE LOW | 89/5~00/ | Wheel Hub FRONT |
| 03906 7565 | W001 33 065 | 65 x 90 x 13 | TITAN WG W TIRE EXCEPT TURBO 3.5T,3.5T ULTRA LONG,4T | 89/5~91/12 | Wheel Hub FRONT |
| 03906 5989 | W001 33 065 | 65 x 90 x 13 | TITAN WG W TIRE EXCEPT TURBO,3.5T (4600),4T | 91/12~95/ | Wheel Hub FRONT |
| 03906 6925 | W001 33 065 | 65 x 90 x 13 | TITAN WG DISC BRAKE | 95/5~00/ | Wheel Hub FRONT |
| 03906 6621 | W001 33 065 | 65 x 90 x 13 | TITAN WG STANDARD CAB,WIDE LOW,FULL WIDE LOW | 95/5~00/ | Wheel Hub FRONT |
| 03906 2685 | W001 33 065 | 65 x 90 x 13 | TITAN WG HIGH DECK 2.0T,2.75T,3.0T | 95/5~00/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 3925 | W029 33 065 | 65 x 100 x 12 | TITAN WG...TURBO,3.5T ULTRA LONG,4T | 89/5~91/12 | Wheel Hub FRONT |
| 03906 5637 | W001 33 065 | 65 x 90 x 13 | TITAN WE 3500(WITHOUT TURBO) | 80/10~89/ | Wheel Hub FRONT |
| 03906 7861 | 1358 26 157A | 60 x 130 x 11 | TITAN EXR15 WIDE LOW | 76/7~80/ | Wheel Hub REAR OUTER |
| 03906 6221 | 1304 26 154 | 90 x 135 x 15 | TITAN WE 3500 TURBO,4500 | 80/10~89/ | Wheel Hub REAR INNER |
| 03906 6229 | 1304 26 154 | 90 x 135 x 15 | TITAN WG H.DECK(WIDE CAB.) 3.5T ULTRA LONG,TURBO,4T | 89/5~91/12 | Wheel Hub REAR INNER |
| 03906 2965 | 1304 26 154 | 90 x 135 x 15 | TITAN WG HIGH DECK (TURBO) | 91/12~95/ | Wheel Hub REAR INNER |
| 03906 3333 | 1304 26 154 | 90 x 135 x 15 | TITAN WG HIGH DECK 3.5T (4600),4T | 91/12~95/ | Wheel Hub REAR INNER |
| 03906 7005 | 1304 26 154 | 90 x 135 x 15 | TITAN WG HIGH DECK 3.5T (6 SPEED,LONG BODY),4T,4.25T | 95/5~00/ | Wheel Hub REAR INNER |
| 03906 5581 | 1304 26 154 | 90 x 135 x 15 | TITAN WH HIGH DECK WIDE CAB. 3.5T,4T,4.25T | 00/4~02/ | Wheel Hub REAR INNER |
| 03906 4685 | 1304 26 154 | 90 x 135 x 15 | TITAN WH HIGH DECK (FRONT DRUM BRAKE) | 02/6~ | Wheel Hub REAR INNER |
| 03906 1877 | W025 26 154 | 75 x 121 x 13 | TITAN WH H/DECK (FRONT DISC BRAKE) | 02/6~ | Wheel Hub REAR INNER |
| 03906 6565 | 0604 26 154 | 58 x 80 x 9 | TITAN EXR S TIRE | 76/7~80/ | Wheel Hub REAR OUTER |
| 03906 6813 | 1416 26 157 | 38 x 45 x 8 | TITAN WG S TIRE | 89/5~00/ | Wheel Hub REAR OUTER |
| 03906 2805 | 1416 26 157 | 38 x 45 x 8 | TITAN TA3H#...WIDE LOW | 78/10~80/ | Wheel Hub REAR OUTER |
| 03906 4981 | 1416 26 157 | 38 x 45 x 8 | TITAN WE S TIRE | 80/10~89/ | Wheel Hub REAR OUTER |
| 03906 1277 | 1416 26 157 | 38 x 45 x 8 | TITAN WE 2500 | 80/10~89/ | Wheel Hub REAR OUTER |
| 03906 6685 | 1416 26 157 | 38 x 45 x 8 | TITAN WE WIDE LOW (3000,3500) | 80/10~89/ | Wheel Hub REAR OUTER |
| 03906 4989 | W001 26 154 | 75 x 105 x 15 | TITAN WE 2500 | 80/10~89/ | Wheel Hub REAR INNER |
| 03906 1573 | 1416 26 157 | 38 x 45 x 8 | TITAN WG WIDE LOW (1.5T~3T) | 89/5~95/ | Wheel Hub REAR OUTER |
| 03906 6277 | W001 33 065 | 65 x 90 x 13 | TITAN WH DISC BRAKE | 00/4~ | Wheel Hub FRONT |
| 03906 2941 | 0604 26 154 | 58 x 80 x 9 | TITAN EVB(TITAN L) | 71/~77/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 3429 | W001 26 154 | 75 x 105 x 15 | TITAN WG FULL WIDE LOW(1.5T) | 95/5~99/ | Wheel Hub REAR INNER |
| 03906 7077 | 1416 26 157 | KDS-3 | TITAN WG WIDE LOW(1.5T~2T) | 95/5~00/ | Wheel Hub REAR OUTER |
| 03906 4053 | W025 26 154 | 75 x 121 x 13 | TITAN WH H/DECK(STD. CAB.),(WIDE CAB. 2T,3T) | 00/4~02/ | Wheel Hub REAR INNER |
| 03906 9013 | W001 26 154 | 75 x 105 x 15 | TITAN WE WIDE LOW(3000,3500) | 80/10~89/ | Wheel Hub REAR INNER |
| 03906 4797 | W001 26 154 | 75 x 105 x 15 | TITAN WG S TIRE | 89/5~00/ | Wheel Hub REAR INNER |
| 03906 2117 | W001 26 154 | 75 x 105 x 15 | TITAN WG WIDE LOW(1.5T~2T) | 95/5~00/ | Wheel Hub REAR INNER |
| 03906 1141 | W001 26 154 | 75 x 105 x 15 | TITAN WH S TIRE | 00/4~ | Wheel Hub REAR INNER |
| 03906 4805 | W001 26 154 | 75 x 105 x 15 | TITAN WH 2T,WIDE LOW | 00/4~ | Wheel Hub REAR INNER |
| 03906 8141 | W025 26 154 | 75 x 121 x 13 | TITAN WE HIGH DECK(3000,3500NT) | 80/10~89/ | Wheel Hub REAR INNER |
| 03906 6469 | W025 26 154 | 75 x 121 x 13 | TITAN WG H/DECK(WIDE CAB.) EXC.3.5T ULTRA LONG,TURBO.4T | 89/5~91/12 | Wheel Hub REAR INNER |
| 03906 8725 | W025 26 154 | 75 x 121 x 13 | TITAN WG H/DECK(WITHOUT TURBO) 2T,2.75T,3T,3.5(4000) | 91/12~95/ | Wheel Hub REAR INNER |
| 03906 2325 | W025 26 154 | 75 x 121 x 13 | TITAN WG H/DECK 2T,2.75T,3T,3.5T(STD. CAB.,5 SPEED,STD. | 95/5~00/ | Wheel Hub REAR INNER |
| 03906 1221 | W025 26 154 | 75 x 121 x 13 | TITAN WH FULL WIDE LOW(STD. CAB,WIDE CAB.) | 00/4~ | Wheel Hub REAR INNER |
| 03906 2213 | W025 26 154 | 75 x 121 x 13 | TITAN WG WIDE LOW(LSD+WIDE CABIN) (4600) | 91/12~95/ | Wheel Hub REAR INNER |
| 03906 7517 | W025 26 154 | 75 x 121 x 13 | TITAN WG WIDE LOW (2.75T~3.5T) | 95/5~00/ | Wheel Hub REAR INNER |
| 03906 2069 | W025 26 154 | 75 x 121 x 13 | TITAN WG FULL WIDE LOW (2T),(WIDE CAB.) | 95/5~99/ | Wheel Hub REAR INNER |
| 03906 8757 | W025 26 154 | 75 x 121 x 13 | TITAN WG HIGH DECK(STD. CABIN) | 89/5~91/12 | Wheel Hub REAR INNER |
| 03906 7685 | W025 26 154 | 75 x 121 x 13 | TITAN WG FULL WIDE LOW(STD. CAB,WIDE CAB.) | 99/4~00/ | Wheel Hub REAR INNER |
| 03906 5805 | W001 26 154 | 75 x 105 x 15 | TITAN WG WIDE LOW(1.5T~3T) | 89/5~95/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 1621 | WL01 10 602 | 60 x 76 x 7 | TITAN DASH WL(2500 DSL.) | 00/10~ | Engine TIMING GEAR COVER (NO.2) |
| 03906 5941 | W001 27 165 | 50 x 75 x 12 x 17 | TITAN DASH SY 2WD/ST/1.5T | 00/10~ | Final Drive PINION |
| 03906 4661 | F801 10 602 | 34 x 48 x 7 | TITAN DASH FE(2000 GAS.) | 00/10~ | Engine TIMING GEAR COVER |
| 03906 1333 | WL02 10 155 | | TITAN DASH WL(2500 DSL.) | 00/10~ | Engine VALVE STEM SEAL |
| 03906 5069 | B630 10 155 | | TITAN DASH FE(2000 GAS.) | 00/10~ | Engine VALVE STEM SEAL |
| 03906 1869 | F285 11 399 | 90 x 110 x 9 x 10 | TITAN DASH WL(2500 DSL.) | 00/10~ | Engine CRANK SHAFT REAR |
| 03906 8165 | F801 10 602 | 34 x 48 x 7 | TITAN DASH FE(2000 GAS.) | 00/10~ | Engine OIL PUMP |
| 03906 3437 | R001 27 165 | 40 x 75 x 11 x 16.5 | TITAN DASH SY 2WD/ST/1.35T,2WD/WT,4WD | 00/10~ | Final Drive PINION |
| 03906 8693 | S113 33 067 | 52 x 70 x 9 | TITAN DASH SY 2WD | 00/10~ | Wheel Hub FRONT |
| 03906 6789 | F285 11 399 | 90 x 110 x 9 x 10 | TITAN DASH FE(2000 GAS.) | 00/10~ | Engine CRANK SHAFT REAR |
| 03906 7901 | M502 17 335A | 38 x 51 x 13 x 15 | TITAN DASH SY | 00/10~ | Transmission REAR |
| 03906 5909 | H501 17 103 | 27 x 43 x 7 | TITAN DASH SY | 00/10~ | Transmission FRONT COVER |
| 03906 4221 | 1416 26 157 | 38 x 45 x 8 | TITAN DASH SY DOUBLE TIRE | 00/10~ | Wheel Hub REAR OUTER |
| 03906 5973 | UB40 26 157 | 48 x 70 x 10 | TITAN DASH SY SINGLE TIRE | 00/10~ | Wheel Hub REAR OUTER |
| 03906 7245 | S483 26 154 | 65 x 90 x 13 | TITAN DASH SY DOUBLE TIRE | 00/10~ | Wheel Hub REAR INNER |
| 03906 5021 | S49S 26 154 | 36 x 61 x 9 | TITAN DASH SY SINGLE TIRE | 00/10~ | Wheel Hub REAR INNER |
| 03906 8005 | VS01 10 602 | 53 x 70 x 11 | TITAN DASH WL(2500 DSL.) | 00/10~ | Engine TIMING GEAR COVER (NO.1) |
| 03906 5205 | UC86 33 065A | 65 x 82 x 95 x 13.5 | TITAN DASH SY 4WD | 00/10~ | Wheel Hub FRONT INNER |
| 03906 5741 | UC86 33 067 | 60 x 75 x 86 x 12 | TITAN DASH SY 4WD | 00/10~ | Wheel Hub FRONT OUTER |
| 03906 2221 | AJ03 10 602 | 47.5 x 63.5 x 8.7 | TRIBUTE AJ(3000 V6) EPFW | 00/12~ | Engine TIMING COVER |
| 03906 3357 | L807 10 155 | | TRIBUTE L3(2300) EP3W | 03/12~ | Engine VALVE STEM SEAL |
| 03906 1789 | AJ03 10 155 | | TRIBUTE AJ(3000 V6) EPFW | 00/12~ | Engine VALVE STEM SEAL |
| 03906 8581 | YF09 10 155 | | TRIBUTE YF(2000) EPEW | 00/12~03/ | Engine VALVE STEM SEAL |
| 03906 6037 | AJ03 11 312 | 92 x 107.7 x 9.5 | TRIBUTE AJ(3000 V6) EPFW | 00/12~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.6 MAZDA

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03906 4789 | LF01 10 602 | 37 x 50 x 8 | TRIBUTE L3(2300) EP3W | 03/12~ | Engine TIMING COVER |
| 03906 1341 | YF10 10 602A | 35 x 50 x 7 | TRIBUTE YF(2000) EPEW | 00/12~03/ | Engine OIL PUMP |
| 03906 7933 | GY01 12 601 | 27 x 41 x 6 | TRIBUTE AJ(3000 V6) EPFW | 00/12~03/ | Engine CAM SHAFT REAR |
| 03906 2293 | YF09 10 602 | 42 x 53 x 7 | TRIBUTE YF(2000) EPEW | 00/12~03/ | Engine CAM SHAFT |
| 03906 5437 | NA01 27 238 | 36 x 59 x 11 x 19 | TRIBUTE EPEW,EPFW,EP3W | 00/12~ | Differential REAR DIFF. SIDE |
| 03906 7101 | F003 27 238A | 35 x 56 x 9 x 15 | TRIBUTE EP3W | 03/12~ | Differential FRONT DIFF. SIDE LH & RH |
| 03906 4725 | FW90 27 238 | 57 x 70 x 8.7 | TRIBUTE EPEW,EPFW | 00/12~ | Differential FRONT DIFF. SIDE RH |
| 03906 1989 | FW51 27 238 | 41 x 64 x 11 x 15.5 | TRIBUTE EPEW,EPFW | 00/12~ | Differential FRONT DIFF. SIDE LH |
| 03906 3341 | YF09 11 399 | 88 x 108 x 10 | TRIBUTE YF(2000) EPEW | 00/12~03/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1413 | 8-94239-173-0 | 28 x 40 x 8 | ASKA JJ#...4FC1 | 83/4~90/ | Engine OIL PUMP |
| 03907 2245 | 8-94235-369-0 | 95 x 118 x 10 | ASKA JJ# | 83/4~90/ | Engine CRANK SHAFT REAR |
| 03907 3749 | 8-94369-516-0 | 23 x 40 x 7.5 | ASKA JJ#...4ZB1,4ZC1 | 83/4~90/ | Engine OIL PUMP |
| 03907 2881 | 8-97033-673-0 | | ASKA JJ#...4FC1,4ZB1,4ZC1 | 83/4~90/ | Engine VALVE STEM SEAL |
| 03907 5633 | 8-94389-593-1 | 30 x 45 x 8 | ASKA JJ GASOLINE | 83/4~90/ | Engine CAM SHAFT |
| 03907 6389 | 8-97252-710-0 | 28 x 47 x 8 | ASKA JJ DIESEL | 83/4~90/ | Engine CAM SHAFT |
| 03907 7161 | 8-97072-405-0 | 35 x 55 x 15 | ASKA JJ# | 83/4~90/ | Transaxle Assy DRIVE SHAFT (L & R) |
| 03907 4965 | 8-94379-067-0 | 28 x 44 x 6 | ASKA JJ# | 83/4~90/ | Transaxle Assy INPUT SHAFT |
| 03907 4897 | 8-94254-381-1 | 40 x 52 x 62 x 12 | ASKA JJ# | 83/4~90/ | Wheel Hub REAR |
| 03907 5185 | 8-94254-353-0 | 57 x 72 x 7 | ASKA JJ# | 83/4~90/ | Wheel Hub FRONT |
| 03907 4721 | 8-97080-562-0 | 40 x 56 x 7 | ASKA JJ# | 83/4~90/ | Engine CRANK SHAFT FRONT |
| 03907 3641 | 9828-55110 | 55 x 72 x 9 x 15 | BUS RB145,1W,RH160,1W | 85/2~ | Transmission REAR COVER |
| 03907 3669 | 9828-55110 | 55 x 72 x 9 x 15 | BUS RJ170,172,RR170,172 | 80/10~83/11 | Transmission REAR COVER |
| 03907 2585 | 9828-55110 | 55 x 72 x 9 x 15 | BUS RL30#.32# | 75/~81/ | Transmission REAR COVER |
| 03907 1653 | 9828-55110 | 55 x 72 x 9 x 15 | BUS AM,AC140 5 SPEED T/M | 76/~89/ | Transmission REAR COVER |
| 03907 1449 | 9828-47101 | 47 x 65 x 9 | BUS AB115,2W,RB115,2W | 85/2~ | Transmission REAR COVER |
| 03907 1541 | 9828-55119 | 55 x 78 x 12 | BUS HT23#,2M,HU23#,2M EE DRIVE | 85/8~ | Transmission FRONT COVER |
| 03907 5313 | 9828-55113 | 55 x 72 x 9 | BUS HT23#,2M,HU23#,2M EXCEPT EE DRIVE | 85/8~ | Transmission FRONT COVER |
| 03907 1365 | 13719-1020 | | BUS W04C,H06C,H07C,H07D | 89/11~95/6 | Engine VALVE STEM SEAL |
| 03907 6077 | 9828-55113 | 55 x 72 x 9 | BUS RU1F,2F,3F | 90/7~ | Transmission FRONT COVER |
| 03907 5873 | 9828-55113 | 55 x 72 x 9 | BUS RT22#,RU22#,60#,63# | 82/10~90/ | Transmission FRONT COVER |
| 03907 2793 | 9828-55113 | 55 x 72 x 9 | BUS RC,RS,RV | 78/~84/ | Transmission FRONT COVER |
| 03907 4381 | 9828-60119 | 60 x 75 x 9 x 15 | BUS AC140 6 SPEED T/M | 83/8~89/ | Transmission REAR COVER |
| 03907 4057 | 9828-55113 | 55 x 72 x 9 | BUS HT27#,3K,HU27#,3K | 83/12~ | Transmission FRONT COVER |
| 03907 3825 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RJ170,171,RR170,171,172,191,192 | 83/12~90/ | Transmission REAR COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2665 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RH1J,RJ3H,1J,RR2H,3H,1J | 90/9~ | Transmission REAR COVER |
| 03907 4729 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RJ172 6 SPEED T/M | 83/12~90/ | Transmission REAR COVER |
| 03907 6565 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RT174,RU174,192,3H | 86/8~ | Transmission REAR COVER |
| 03907 3577 | 9828-60119 | 60 x 75 x 9 x 15 | BUS CH160,3H,1J | 87/12~ | Transmission REAR COVER |
| 03907 3505 | 9828-65108 | 65 x 95 x 14 x 22 | BUS RC,RE,RS | 69/~79/12 | Transmission REAR COVER |
| 03907 2189 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RC,RE | 80/1~84/ | Transmission REAR COVER |
| 03907 5677 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RS1#,3#...6 SPEED | 80/1~82/ | Transmission REAR COVER |
| 03907 6841 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RV7#,5#...6 SPEED | 78/5~82/ | Transmission REAR COVER |
| 03907 6721 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RU22#,RT22# | 82/10~90/ | Transmission REAR COVER |
| 03907 5805 | 9828-48120 | 48 x 60 x 9 | BUS RT174,RU174,192,3H,CH1J | 86/8~ | Transmission FRONT COVER |
| 03907 4657 | 13719-1360 | | BUS J05C,J08C | 95/7~98/1 | Engine VALVE STEM SEAL |
| 03907 3401 | 9828-57103 | 57 x 124 x 13 | BUS RH,RJ,RR,CH,HR | 84/~ | Wheel Hub REAR OUTER |
| 03907 5573 | 13719-1470 | | BUS J05C,J08C | 98/2~ | Engine VALVE STEM SEAL |
| 03907 6821 | 9828-66106 | 66 x 134 x 16 | BUS RK | 84/~90/ | Wheel Hub REAR OUTER |
| 03907 4489 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS HT#,HU# | 83/12~ | Transmission REAR COVER |
| 03907 6917 | 9828-85106 | 84 x 100 x 10 | BUS AB,AC,AM,RB | 76/~ | Wheel Hub FRONT |
| 03907 7129 | 9828-01137 | 101 x 114 x 10 | BUS RH,RJ,RL,RR,CH | 75/~ | Wheel Hub FRONT |
| 03907 1797 | 9828-01207 | 138 x 152 x 12 | BUS RC,RE,RK,RM,RS,RT,RU,RV,HR,HT,HU | 69/~ | Wheel Hub FRONT |
| 03907 6033 | 9828-01136 | 116 x 132 x 11 | BUS AC,AM | 76/~89/ | Wheel Hub REAR INNER |
| 03907 4609 | 9828-01204 | 145 x 164 x 14 | BUS RK | 84/~90/ | Wheel Hub REAR INNER |
| 03907 6601 | 9828-01203 | 127 x 147 x 11 | BUS RH,RJ,RR,CH,HR | 84/~ | Wheel Hub REAR INNER |
| 03907 5297 | 9828-01130 | 146 x 170 x 18 | BUS RC,RE,RS,RV | 69/~84/ | Wheel Hub REAR INNER |
| 03907 2289 | 9828-01193 | 154 x 175 x 13 | BUS RM,RT,RU,HT,HU | 82/~ | Wheel Hub REAR INNER |
| 03907 4693 | 9828-40101 | 40 x 50 x 6.5 | BUS AC,AM | 76/~89/ | Wheel Hub REAR OUTER |
| 03907 1973 | 9828-48112 | 48 x 109 x 13 | BUS AB,RB | 85/~ | Wheel Hub REAR OUTER |
| 03907 5073 | 9828-60108 | 60 x 74 x 7.5 | BUS RC,RE,RS,RV | 69/~84/ | Wheel Hub REAR OUTER |
| 03907 1173 | 9828-01149 | 120 x 140 x 12 | BUS RJ,RL,RR | 75/~83/ | Wheel Hub REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| | | | | | INNER |
| 03907 2669 | 9828-48120 | 48 x 60 x 9 | BUS RJ172 5 SPEED T/M | 83/12~90/ | Transmission FRONT COVER |
| 03907 6901 | 9828-01228 | 100 x 135 x 17 | BUS J05C,J08C | 95/7~ | Engine CRANK SHAFT REAR |
| 03907 5625 | 9828-76101 | 76 x 164 x 14 | BUS RM,RT,RU,HT,HU | 82/~ | Wheel Hub REAR OUTER |
| 03907 1737 | 9828-30101 | 30 x 42 x 8 | BUS AB115,RB115 | 85/2~90/ | Transmission FRONT COVER |
| 03907 2129 | 9828-37103 | 37 x 50 x 6 | BUS AC140,AM101 5 SPEED,RB14# | 80/1~89/ | Transmission FRONT COVER |
| 03907 2773 | 9828-37103 | 37 x 50 x 6 | BUS RJ170,172,RR170,172 | 80/10~83/11 | Transmission FRONT COVER |
| 03907 2381 | 9828-37103 | 37 x 50 x 6 | BUS RL301,321 | 80/1~81/ | Transmission FRONT COVER |
| 03907 6037 | 9828-43102 | 43 x 63 x 9 | BUS AC140 6 SPEED T/M | 83/8~89/ | Transmission FRONT COVER |
| 03907 2281 | 9828-43102 | 43 x 63 x 9 | BUS AB2W,RB1W,2W,CH#,RH# | 87/12~ | Transmission FRONT COVER |
| 03907 2161 | 9828-43102 | 43 x 63 x 9 | BUS RJ170,RR170 | 83/12~88/ | Transmission FRONT COVER |
| 03907 5029 | 9828-43102 | 43 x 63 x 9 | BUS RJ172,RR172 6 SPEED T/M | 83/12~90/ | Transmission FRONT COVER |
| 03907 2681 | 9828-48120 | 48 x 60 x 9 | BUS RJ171,3H,1J,RR171,191,192, 2H,3H,1J | 88/10~ | Transmission FRONT COVER |
| 03907 6641 | 9828-45104 | 45 x 55 x 7.5 | BUS RJ,RL,RR | 75/~83/ | Wheel Hub REAR OUTER |
| 03907 7257 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RJ#,RR# | 88/10~98/6 | Final Drive PINION |
| 03907 4949 | 9828-58105 | 58 x 75 x 9 | BUS EC100,EH100,300 RL,AM | 70/~77/ | Engine CRANK SHAFT FRONT |
| 03907 5401 | 9828-80117 | 80 x 136 x 9 x 25.5 | BUS HT#,HU#,RU1F,2F,3F,4F | 00/4~ | Final Drive PINION |
| 03907 5229 | 9828-80114 | 80 x 136 x 9 x 25 | BUS RU1F,2F,3F,4F | 98/10~00/3 | Final Drive PINION |
| 03907 5525 | 9828-65130 | 65 x 105 x 9 x 25 | BUS HR# | 01/11~ | Final Drive PINION |
| 03907 6341 | 9828-65127 | 65 x 114 x 9 x 25 | BUS HR# | 99/1~01/10 | Final Drive PINION |
| 03907 1897 | 9828-65127 | 65 x 114 x 9 x 25 | BUS RH#,RR#,CH# | 98/7~ | Final Drive PINION |
| 03907 6573 | 9828-80110 | 80 x 136 x 20 x 26 | BUS RU1F,2F,3F,4F | 90/7~98/9 | Final Drive PINION |
| 03907 1877 | 9828-80110 | 80 x 136 x 20 x 26 | BUS RU60#,63# | 85/9~90/ | Final Drive PINION |
| 03907 1849 | 9828-80115 | 80 x 124 x 19 x 25 | BUS HT#,HU# | 83/12~00/3 | Final Drive PINION |
| 03907 3685 | 9828-80115 | 80 x 124 x 19 x 25 | BUS RU60#,63# | 82/6~85/8 | Final Drive PINION |
| 03907 4341 | 9828-75111 | 75 x 100 x 13 x 18 | BUS RC,RE,RS,RV | 69/~84/ | Final Drive PINION |
| 03907 4065 | 9828-65116 | 65 x 88 x 12 x 19 | BUS EC100,EH100,300 RL,AM | 78/~83/ | Engine CRANK SHAFT FRONT |
| 03907 5421 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RH#,CH# | 87/12~98/6 | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5165 | 9828-80115 | 80 x 124 x 19 x 25 | BUS RU3H,1J | 90/6~ | Final Drive PINION |
| 03907 1569 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RJ17#,RR17#...REDUCTION RATIO 4.100 | 83/12~88/9 | Final Drive PINION |
| 03907 2205 | 9828-63104 | 63 x 100 x 12 | BUS RJ17#,RR17#...REDUCTION RATIO 5.142,5.571 | 83/12~88/9 | Final Drive PINION |
| 03907 1829 | 9828-63104 | 63 x 100 x 12 | BUS RJ#,RR# | 80/10~83/11 | Final Drive PINION |
| 03907 1817 | 9828-63104 | 63 x 100 x 12 | BUS RL | 75/4~81/ | Final Drive PINION |
| 03907 3645 | 9828-58109 | 58 x 102 x 8 x 22 | BUS AB,RB | 85/2~ | Final Drive PINION |
| 03907 5081 | 9828-52111 | 52 x 100 x 15 | BUS AC,AM | 76/~89/ | Final Drive PINION |
| 03907 6097 | 9828-75119 | 75 x 100 x 13 x 19 | BUS RU60#,63#,1F,2F,3F | 82/6~ | Transmission REAR COVER |
| 03907 1133 | 9828-75119 | 75 x 100 x 13 x 19 | BUS RV5#...5 SPEED T/M | 78/5~82/ | Transmission REAR COVER |
| 03907 1629 | 9828-75119 | 75 x 100 x 13 x 19 | BUS RS3#...5 SPEED T/M | 80/1~82/ | Transmission REAR COVER |
| 03907 6869 | 9828-01206 | 107 x 123 x 11 | BUS AB,RB | 85/~ | Wheel Hub REAR INNER |
| 03907 2549 | 9828-01226 | 125 x 177 x 17.5 | BUS F17D,F20C,F21C | 95/7~ | Engine CRANK SHAFT REAR |
| 03907 4845 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RT174,RU174,192 | 86/8~90/ | Final Drive PINION |
| 03907 2249 | 9828-01168 | 135 x 165 x 14 x 20.5 | BUS EF3#,5#,7# | 78/~90/ | Engine CRANK SHAFT REAR |
| 03907 3073 | 9828-01223 | 116 x 151 x 17 | BUS P11C,M10U,K13U | 95/4~ | Engine CRANK SHAFT REAR |
| 03907 3757 | 9828-01200 | 122 x 150 x 12 x 18 | BUS EM100 RT22#,RU22# | 82/10~90/ | Engine CRANK SHAFT REAR |
| 03907 4909 | 9828-80115 | 80 x 124 x 19 x 25 | BUS RT22#,RU22# | 82/10~89/ | Final Drive PINION |
| 03907 6877 | 9828-01168 | 135 x 165 x 14 x 20.5 | BUS F17#,F20C | 90/7~95/6 | Engine CRANK SHAFT REAR |
| 03907 2621 | 9828-65116 | 65 x 88 x 12 x 19 | BUS EH700 RL,RJ,RR | 80/~83/ | Engine CRANK SHAFT FRONT |
| 03907 5977 | 9828-01168 | 135 x 165 x 14 x 20.5 | BUS ER200,EB200,400 | 78/~84/ | Engine CRANK SHAFT REAR |
| 03907 2477 | 9828-01158 | 130 x 161 x 14 | BUS DK20 | 69/~78/ | Engine CRANK SHAFT REAR |
| 03907 2493 | 9828-00109 | 100 x 120 x 13 x 18 | BUS W04#.W06# | 83/~ | Engine CRANK SHAFT REAR |
| 03907 3349 | 9828-01167 | 106 x 126 x 12 | BUS H06#,H07# | 83/~ | Engine CRANK SHAFT REAR |
| 03907 5609 | 9828-01167 | 106 x 126 x 12 | BUS EH300,500,700 | 74/~83/ | Engine CRANK SHAFT REAR |
| 03907 6149 | 9828-00107 | 100 x 120 x 13 | BUS EC100,EH100 | 69/~83/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1369 | 9828-79103 | 79 x 114 x 17 | BUS J05C,J08C | 95/7~ | Engine CRANK SHAFT FRONT |
| 03907 3793 | 9828-96109 | 96 x 131 x 17.5 | BUS F17D,F20C,F21C | 85/7~ | Engine CRANK SHAFT FRONT |
| 03907 4545 | 9828-83103 | 83 x 118 x 18 | BUS M10U | 95/4~ | Engine CRANK SHAFT FRONT |
| 03907 6793 | 9828-75111 | 75 x 100 x 13 x 18 | BUS DK20 RC1#,3#,4# | 69/~78/ | Engine CRANK SHAFT FRONT |
| 03907 2841 | 9828-65116 | 65 x 88 x 12 x 19 | BUS H06#,H07#...RT174,RU174,192,3H,CH3H | 86/8~ | Engine CRANK SHAFT FRONT |
| 03907 5473 | 9828-01201 | 125 x 155 x 14 x 23 | BUS EK200 | 79/~ | Engine CRANK SHAFT REAR |
| 03907 3937 | 9828-65116 | 65 x 88 x 12 x 19 | BUS H06#,H07#...RJ#,RR# | 83/~ | Engine CRANK SHAFT FRONT |
| 03907 3153 | 9828-75145 | 75 x 114 x 17 | BUS K13U | 95/4~ | Engine CRANK SHAFT FRONT |
| 03907 4313 | 9828-58104 | 58 x 75 x 9 x 14.5 | BUS W04#,W06#...AB#,AC#,RH#,RB#,CH160 | 83/~ | Engine CRANK SHAFT FRONT |
| 03907 2241 | 9828-80102 | 80 x 105 x 13 | BUS ER200,EB200,400 RC301,321,RE# | 78/~84/ | Engine CRANK SHAFT FRONT |
| 03907 2953 | 9828-70102 | 70 x 95 x 13 | BUS EK200 RC7# | 79/~83/ | Engine CRANK SHAFT FRONT |
| 03907 1509 | 9828-70110 | 70 x 95 x 13 x 20 | BUS EK200 HT27#,HU27# | 84/~90/ | Engine CRANK SHAFT FRONT |
| 03907 1809 | 9828-96101 | 96 x 124 x 14 x 21 | BUS EF3#,5#,7#...RS#,RV#,RU60#,63# | 78/~90/ | Engine CRANK SHAFT FRONT |
| 03907 5109 | 9828-96101 | 96 x 124 x 14 x 21 | BUS F17#,F20C RU1F,2F,3F | 90/7~95/6 | Engine CRANK SHAFT FRONT |
| 03907 3605 | 9828-75140 | 75 x 100 x 13 x 20 | BUS EM100 RT22#,RU22# | 82/10~90/ | Engine CRANK SHAFT FRONT |
| 03907 6397 | 9828-75140 | 75 x 100 x 13 x 20 | BUS P11C | 99/6~ | Engine CRANK SHAFT FRONT |
| 03907 2049 | 1-09625-444-0 | 78 x 163 x 16 | BUS CRA,CSA,CQ,CH,CL,CJ,CP AIR BRAKE | 79/10~84/ | Wheel Hub REAR OUTER |
| 03907 6813 | 1-12569-009-0 | | BUS 8P#,10P#,12P# | 84/3~91/6 | Engine VALVE STEM SEAL |
| 03907 2929 | 1-09625-425-1 | 120 x 153 x 15 | BUS LV 8PC | 88/8~89/ | Engine CRANK SHAFT REAR |
| 03907 1297 | 1-09625-525-2 | 111 x 153 x 16.5 | BUS LV 8P#,10P#,12P# | 93/3~ | Engine CRANK SHAFT REAR |
| 03907 1421 | 1-09625-559-0 | 139-171-19 x x | BUS LV 8TD1 | 00/4~ | Engine CRANK SHAFT REAR |
| 03907 6817 | 5-12569-001-0 | | BUS 6BG1 | 84/3~90/6 | Engine VALVE STEM SEAL |
| 03907 1481 | 9-12569-058-0 | | BUS 6QA2,6QB2 | 84/3~95/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1601 | 1-09625-013-0 | | BUS 6RB2 | 84/3~95/ | Engine VALVE STEM SEAL |
| 03907 1169 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | BUS BA | 66/~79/ | Wheel Hub REAR INNER |
| 03907 4801 | 1-09625-444-0 | 78 x 163 x 16 | BUS LT AIR SUS. | 89/4~00/3 | Wheel Hub REAR OUTER |
| 03907 6913 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | BUS LT ALL | 00/4~ | Wheel Hub REAR INNER |
| 03907 4161 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | BUS LT AIR SUS. | 89/4~00/3 | Wheel Hub REAR INNER |
| 03907 6969 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | BUS LV | 84/3~ | Wheel Hub REAR INNER |
| 03907 3857 | 9-09924-393-0 | 123 x 184 x 15 x 28 | BUS CRA,CSA,CQ,CH,CL,CJ,CP AIR BRAKE | 79/10~84/ | Wheel Hub REAR INNER |
| 03907 4813 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | BUS CRA,CSA,CQ,CH,CL,CJ,CP OIL BRAKE | 76/~84/ | Wheel Hub REAR INNER |
| 03907 5381 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | BUS BU | 67/~79/ | Wheel Hub REAR INNER |
| 03907 2393 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | BUS CDM | 82/5~84/ | Wheel Hub REAR INNER |
| 03907 5797 | 9-09924-470-0 | 64 x 132.5 x 13 | BUS BA | 69/~79/ | Wheel Hub REAR OUTER |
| 03907 1713 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | BUS ECM,EDM | 78/11~84/ | Wheel Hub REAR INNER |
| 03907 4361 | 9-09924-470-0 | 64 x 132.5 x 13 | BUS ECM,EDM | 78/11~82/ | Wheel Hub REAR OUTER |
| 03907 4881 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS LT ALL | 95/7~ | Wheel Hub FRONT |
| 03907 1833 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS LT AIR SUS. | 89/4~95/ | Wheel Hub FRONT |
| 03907 3029 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS LV | 84/3~ | Wheel Hub FRONT |
| 03907 4941 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS CRA,CSA,CQ,CH,CL,CJ,CP | 76/~84/ | Wheel Hub FRONT |
| 03907 7229 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS BU | 73/7~79/ | Wheel Hub FRONT |
| 03907 7073 | 1-09625-129-0 | 85 x 128 x 11 x 21 | BUS LT LEAF SUS. | 84/3~95/ | Wheel Hub FRONT |
| 03907 3609 | 1-09625-129-0 | 85 x 128 x 11 x 21 | BUS ECM,EDM | 78/11~84/ | Wheel Hub FRONT |
| 03907 7185 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | BUS CDM | 82/5~84/ | Wheel Hub FRONT |
| 03907 6113 | 9-09924-407-0 | 76 x 115 x 13 x 21 | BUS BA | 66/~79/ | Wheel Hub FRONT |
| 03907 4025 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | BUS LT LEAF SUS. | 84/3~00/3 | Wheel Hub REAR INNER |
| 03907 3353 | 1-09625-502-0 | 40 x 55 x 9 | BUS ECM,EDM,CDM | 78/11~84/ | Transmission FRONT COVER |
| 03907 5009 | 1-12569-019-1 | | BUS 8TD1 | 00/4~ | Engine VALVE STEM SEAL |
| 03907 5169 | 8-94396-609-2 | | BUS 6HE1,6HH1 | 90/7~99/5 | Engine VALVE STEM SEAL |
| 03907 4937 | 8-97120-307-0 | | BUS 6HH1 | 99/6~ | Engine VALVE STEM SEAL |
| 03907 2457 | 1-09625-497-0 | 48 x 62 x 9 | BUS LV7# | 86/11~90/5 | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2449 | 1-09625-497-0 | 48 x 62 x 9 | BUS LV2#,3# | 84/3~89/10 | Transmission FRONT COVER |
| 03907 6809 | 1-09625-497-0 | 48 x 62 x 9 | BUS CQ,CH | 81/11~84/ | Transmission FRONT COVER |
| 03907 1613 | 1-09625-497-0 | 48 x 62 x 9 | BUS CRA,CSA | 80/~84/ | Transmission FRONT COVER |
| 03907 5193 | 1-09625-502-0 | 40 x 55 x 9 | BUS LT | 84/3~93/6 | Transmission FRONT COVER |
| 03907 6073 | 9-09924-351-0 | 86 x 130 x 15 | BUS BA | 66/~68/ | Wheel Hub REAR OUTER |
| 03907 2509 | 1-09625-502-0 | 40 x 55 x 9 | BUS CRA | 77/8~79/ | Transmission FRONT COVER |
| 03907 5881 | 1-12569-019-1 | | BUS 8P#,10P#,12P# | 91/6~ | Engine VALVE STEM SEAL |
| 03907 7269 | 1-09625-502-0 | 40 x 55 x 9 | BUS BA,BU45KYZ | 73/~79/ | Transmission FRONT COVER |
| 03907 4117 | 1-09625-444-0 | 78 x 163 x 16 | BUS LT ALL | 00/4~ | Wheel Hub REAR OUTER |
| 03907 6169 | 1-09625-444-0 | 78 x 163 x 16 | BUS LV | 84/3~ | Wheel Hub REAR OUTER |
| 03907 6697 | 1-09625-524-3 | 111 x 153 x 16.5 | BUS LV 8TD1 | 00/4~ | Engine CRANK SHAFT FRONT |
| 03907 4229 | 1-09625-379-0 | 74 x 142.9 x 17.5 | BUS CRA,CSA,CQ,CH,CL,CJ,CP OIL BRAKE | 79/10~84/ | Wheel Hub REAR OUTER |
| 03907 1969 | 9-09924-374-0 | 71 x 142 x 14 | BUS CRA | 76/~79/9 | Wheel Hub REAR OUTER |
| 03907 6533 | 9-09924-374-0 | 71 x 142 x 14 | BUS BU | 87/~79/ | Wheel Hub REAR OUTER |
| 03907 6121 | 1-09625-331-0 | 56 x 122 x 10.5 | BUS CDM | 82/5~84/ | Wheel Hub REAR OUTER |
| 03907 7149 | 9-09924-470-0 | 64 x 132.5 x 13 | BUS LT LEAF SUS. | 84/3~00/3 | Wheel Hub REAR OUTER |
| 03907 6593 | 1-09625-502-0 | 40 x 55 x 9 | BUS CP | 80/2~84/ | Transmission FRONT COVER |
| 03907 7093 | 1-09625-565-0 | 40 x 55 x 7 | BUS LT | 93/7~ | Transmission FRONT COVER |
| 03907 5685 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS BA | 77/6~79/ | Final Drive PINION |
| 03907 5441 | 1-09625-173-0 | 60 x 77 x 12 | BUS BA | 66/~77/5 | Final Drive PINION |
| 03907 5129 | 1-09625-515-0 | 67 x 90 x 12 | BUS LV MLH T/M | 86/4~99/ | Transmission REAR COVER |
| 03907 1453 | 1-09625-578-1 | 78 x 97 x 13 | BUS LV MAL,MAP T/M | 95/4~ | Transmission REAR COVER |
| 03907 1325 | 1-09625-579-1 | 74 x 97 x 13 | BUS LV MAF T/M | 86/4~95/ | Transmission REAR COVER |
| 03907 5569 | 1-09625-579-1 | 74 x 97 x 13 | BUS LV ALL | 84/3~86/3 | Transmission REAR COVER |
| 03907 6889 | 1-09625-579-1 | 74 x 97 x 13 | BUS CQ,CH MAB5 | 83/6~84/ | Transmission REAR COVER |
| 03907 1841 | 1-09625-207-0 | 73 x 96 x 12 | BUS CQ,CH MAB5 | 82/1~83/5 | Transmission REAR COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6057 | 1-09625-207-0 | 73 x 96 x 12 | BUS CQ,CH MAB6 | 82/1~84/ | Transmission REAR COVER |
| 03907 4525 | 1-09625-207-0 | 73 x 96 x 12 | BUS CP | 80/2~84/ | Transmission REAR COVER |
| 03907 2977 | 1-09625-207-0 | 73 x 96 x 12 | BUS CRA,CSA | 80/~84/ | Transmission REAR COVER |
| 03907 6273 | 1-09625-149-0 | 80 x 105 x 12 | BUS CRA | 77/8~79/ | Transmission REAR COVER |
| 03907 1249 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS EMC,EDM,CDM | 78/11~84/ | Final Drive PINION |
| 03907 6433 | 1-09625-063-0 | 68 x 90 x 12 | BUS CL,CJ | 80/2~84/ | Transmission REAR COVER |
| 03907 5913 | 1-09625-201-0 | 120 x 153 x 15 x 18 | BUS CRA,CSA | 77/8~84/ | Engine CRANK SHAFT REAR |
| 03907 6233 | 1-09625-063-0 | 68 x 90 x 12 | BUS BU EXCEPT 45KYZ | 69/~79/ | Transmission REAR COVER |
| 03907 3993 | 1-09625-505-0 | 60 x 77 x 12 | BUS LT | 90/3~ | Transmission REAR COVER |
| 03907 1905 | 1-09625-173-0 | 60 x 77 x 12 | BUS LT | 84/3~90/2 | Transmission REAR COVER |
| 03907 3085 | 1-09625-173-0 | 60 x 77 x 12 | BUS BA,ECM,EDM,CDM | 66/~84/ | Transmission REAR COVER |
| 03907 3985 | 1-09625-562-0 | 54 x 69 x 9 | BUS LV7# | 90/6~ | Transmission FRONT COVER |
| 03907 5369 | 1-09625-562-0 | 54 x 69 x 9 | BUS LV2#,3# | 89/11~ | Transmission FRONT COVER |
| 03907 5529 | 1-09625-507-1 | 120 x 153 x 17 | BUS LV 10PC,D | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03907 5457 | 1-09625-507-1 | 120 x 153 x 17 | BUS LV 8PC,10PC | 84/3~88/7 | Engine CRANK SHAFT REAR |
| 03907 3137 | 1-09625-439-1 | 105 x 135 x 15 | BUS LT 6B# | 84/3~90/6 | Engine CRANK SHAFT REAR |
| 03907 6701 | 1-09625-441-0 | 128 x 148 x 14 | BUS LV 6QA2,6QB2,6RB2 | 86/4~95/ | Engine CRANK SHAFT REAR |
| 03907 4157 | 9-09924-356-0 | 105 x 135 x 14 | BUS BA | 74/1~79/ | Engine CRANK SHAFT REAR |
| 03907 2765 | 1-09625-317-0 | 128 x 148 x 10 | BUS CQ,CH,CL,CJ,CP | 80/2~84/ | Engine CRANK SHAFT REAR |
| 03907 4373 | 1-09625-317-0 | 128 x 148 x 10 | BUS BU | 75/~79/ | Engine CRANK SHAFT REAR |
| 03907 5565 | 1-09625-149-0 | 80 x 105 x 12 | BUS BU45KYZ | 75/~79/ | Transmission REAR COVER |
| 03907 6449 | 1-09625-524-3 | 111 x 153 x 16.5 | BUS LV 8P#,10P#,12P# | 93/3~ | Engine CRANK SHAFT FRONT |
| 03907 5809 | 1-09625-317-0 | 128 x 148 x 10 | BUS LV 6QA2,6RB2 | 84/3~87/ | Engine CRANK SHAFT REAR |
| 03907 4853 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS LT LEAF SUS. | 84/3~00/3 | Final Drive PINION |
| 03907 5033 | 5-09625-052-0 | 100 x 135 x 15 | BUS ECM,EDM,CDM | 78/11~84/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5701 | 1-09625-424-0 | 120 x 153 x 13 x 15 | BUS LV 8PC | 88/8~89/ | Engine CRANK SHAFT FRONT |
| 03907 4077 | 1-09625-506-0 | 120 x 153 x 15 | BUS LV 10PC,D | 88/8~93/2 | Engine CRANK SHAFT FRONT |
| 03907 6977 | 1-09625-506-0 | 120 x 153 x 15 | BUS LV 8PC,10PC | 84/3~88/7 | Engine CRANK SHAFT FRONT |
| 03907 1793 | 1-09625-200-0 | 120 x 153 x 15 | BUS CRA,CSA | 77/8~84/ | Engine CRANK SHAFT FRONT |
| 03907 5545 | 1-09625-442-0 | 70 x 92 x 12 | BUS LV 6QA2,6QB2,6RB2 | 88/8~95/ | Engine CRANK SHAFT FRONT |
| 03907 5477 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS LV 6QA2,6RB2 | 84/3~88/7 | Engine CRANK SHAFT FRONT |
| 03907 3565 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS CQ,CH,CL,CJ,CP | 80/2~84/ | Engine CRANK SHAFT FRONT |
| 03907 4181 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS BU | 77/4~79/ | Engine CRANK SHAFT FRONT |
| 03907 5433 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS BA | 76/6~79/ | Engine CRANK SHAFT FRONT |
| 03907 7085 | 1-09625-128-0 | 70 x 92 x 12 | BUS BU | 67/~77/3 | Engine CRANK SHAFT FRONT |
| 03907 5353 | 1-09625-128-0 | 70 x 92 x 12 | BUS BA | 66/~76/5 | Engine CRANK SHAFT FRONT |
| 03907 3145 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LV7# | 84/4~ | Final Drive PINION |
| 03907 3149 | 1-09625-063-0 | 68 x 90 x 12 | BUS BU | 69/79/ | Final Drive PINION |
| 03907 5429 | 1-09625-063-0 | 68 x 90 x 12 | BUS CRA | 77/8~79/ | Final Drive PINION |
| 03907 5225 | 8-97602-378-0 | 104 x 137 x 13 | BUS LT 6HE1,6HH1 | 90/7~ | Engine CRANK SHAFT FRONT |
| 03907 1433 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LV2#,3#...15.5INCH,16.5INCH DIFF.. | 84/3~ | Final Drive PINION |
| 03907 5897 | 1-09625-063-0 | 68 x 90 x 12 | BUS CL,CJ,CP | 80/2~84/ | Final Drive PINION |
| 03907 6997 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LT AIR SUS. | 89/4~00/3 | Final Drive PINION |
| 03907 3485 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LT ALL | 00/4~ | Final Drive PINION |
| 03907 4237 | 1-09625-322-0 | 86 x 143 x 10 x 38 | BUS LV2#,3#...17.5INCH DIFF. | 92/6~99/ | Final Drive PINION |
| 03907 3853 | 8-97602-379-0 | 104 x 139 x 13 | BUS LT 6HE16HH1 | 90/7~ | Engine CRANK SHAFT REAR |
| 03907 5533 | 8-94373-765-0 | 60 x 82 x 12 | BUS ECM,EDM,CDM | 78/11~84/ | Engine CRANK SHAFT FRONT |
| 03907 1845 | 1-09625-319-0 | 60 x x 82 x 10 | BUS LT 6BG1 | 84/3~87/12 | Engine CRANK SHAFT FRONT |
| 03907 1373 | 1-09625-438-0 | 60 x 82 x 12 | BUS LT 6BG1 | 88/1~90/6 | Engine CRANK SHAFT FRONT |
| 03907 1917 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS CRA,CSA,CQ,CH | 80/~84/ | Final Drive PINION |
| 03907 4497 | 5-09625-052-0 | 100 x 135 x 15 | BUS JORNEY BL 4BA1,4BC1,2 | 79/~86/12 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2333 | 5-09625-052-0 | 100 x 135 x 15 | BUS JORNEY BE 4BB1,4BD1 | 73/~86/12 | Engine CRANK SHAFT REAR |
| 03907 3841 | 5-09625-052-0 | 100 x 135 x 15 | BUS JORNEY CCM,DBR 6BD1,6BB1 | 76/~83/ | Engine CRANK SHAFT REAR |
| 03907 6521 | 1-09625-320-0 | 100 x 135 x 10 | BUS JORNEY BL 4BC2 | 87/1~95/ | Engine CRANK SHAFT REAR |
| 03907 3673 | 1-09625-320-0 | 100 x 135 x 10 | BUS JORNEY BE 4BD1 | 87/1~95/ | Engine CRANK SHAFT REAR |
| 03907 1253 | 9-09624-356-0 | 105 x 135 x 14 | BUS JORNEY LR,MR 6BG1,6BD1 | 84/~87/10 | Engine CRANK SHAFT REAR |
| 03907 5461 | 1-09625-439-1 | 105 x 135 x 15 | BUS JORNEY LR,MR 6BG1,6BD1 | 87/11~95/ | Engine CRANK SHAFT REAR |
| 03907 2857 | 8-97602-379-0 | 104 x 139 x 13 | BUS JORNEY LR,MR,GR 6HE1,6HH1 | 90/7~ | Engine CRANK SHAFT REAR |
| 03907 1473 | 5-12569-001-0 | | BUS JORNEY 6BB1,6BD1,6BG1 | 76/~95/ | Engine VALVE STEM SEAL |
| 03907 6665 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS JORNEY CCM,DBR,LR,MR,GR | 84/~ | Final Drive PINION |
| 03907 2365 | 8-94396-609-2 | | BUS JORNEY 6HE1,6HH1 | 90/7~99/5 | Engine VALVE STEM SEAL |
| 03907 2217 | 5-12569-001-0 | | BUS JORNEY 4BA1,4BB1,4BC1,2,4BD1 | 73/~95/ | Engine VALVE STEM SEAL |
| 03907 3341 | 5-09625-036-0 | 82 x 105 x 13 | BUS JORNEY BL G201,C240 | 72/~79/ | Engine CRANK SHAFT REAR |
| 03907 4001 | 8-97602-378-0 | 104 x 137 x 13 | BUS JORNEY LR,MR,GR 6HE1,6HH1 | 90/7~ | Engine CRANK SHAFT FRONT |
| 03907 3357 | 1-09625-438-0 | 60 x 82 x 12 | BUS JORNEY LR,MR 6BG1,6BD1 | 87/11~95/ | Engine CRANK SHAFT FRONT |
| 03907 4349 | 9-09724-023-0 | 65 x 85 x 10 | BUS JORNEY BL RIGHT HANDLE | 80/~83/6 | Wheel Hub FRONT |
| 03907 6321 | 1-09625-319-0 | 60 x 82 x 10 | BUS JORNEY LR,MR 6BG1,6BD1 | 84/~87/10 | Engine CRANK SHAFT FRONT |
| 03907 7189 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | BUS JORNEY BE | 73/~95/ | Final Drive PINION |
| 03907 1909 | 8-97049-145-0 | 50 x 68 x 9 | BUS JORNEY BL G201,C240 | 72/~79/ | Engine CRANK SHAFT FRONT |
| 03907 4357 | 8-94373-765-0 | 60 x 82 x 12 | BUS JORNEY BL 4BA1,4BC1,2 | 77/9~90/ | Engine CRANK SHAFT FRONT |
| 03907 6737 | 8-94373-765-0 | 60 x 82 x 12 | BUS JORNEY BE 4BB1,4BD1 | 73/~95/ | Engine CRANK SHAFT FRONT |
| 03907 1485 | 8-94373-765-0 | 60 x 82 x 12 | BUS JORNEY CCM,DBR 6BD1,6BB1 | 76/~84/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1445 | 8-97120-307-0 | | BUS JORNEY 6HH1 | 99/6~ | Engine VALVE STEM SEAL |
| 03907 5981 | 8-94326-441-0 | 27 x 43 x 9 | BUS JORNEY BL,BE | 72/~90/7 | Transmission FRONT COVER |
| 03907 4753 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | BUS JORNEY BL35 | 80/2~83/ | Final Drive PINION |
| 03907 1301 | 8-94336-315-2 | 46 x 94.4 x 8 | BUS JORNEY BL,BE | 72/~90/7 | Wheel Hub REAR OUTER |
| 03907 6513 | 1-09625-513-0 | 65 x 84 x 9 | BUS JORNEY LR MLD6 T/M | 89/4~95/ | Transmission REAR COVER |
| 03907 2417 | 1-09625-505-0 | 60 x 77 x 12 | BUS JORNEY LR,MR,GR MBG#,MBJ# T/M | 90/3~ | Transmission REAR COVER |
| 03907 3469 | 1-09625-173-0 | 60 x 77 x 12 | BUS JORNEY LR,MR | 84/~90/2 | Transmission REAR COVER |
| 03907 7029 | 1-09625-173-0 | 60 x 77 x 12 | BUS JORNEY CCM,DBR | 76/~83/ | Transmission REAR COVER |
| 03907 6413 | 8-97074-651-0 | 45 x 65 x 10 | BUS JORNEY BL,BE | 72/~95/ | Transmission REAR COVER |
| 03907 5745 | 1-09625-498-0 | 40 x 56 x 6.5 | BUS JORNEY LR MLD6 T/M | 89/4~95/ | Transmission FRONT COVER |
| 03907 5849 | 1-09625-565-1 | 40 x 55 x 7 | BUS JORNEY MR,GR,LR MBG#,MBJ# T/M | 93/7~ | Transmission FRONT COVER |
| 03907 5945 | 1-09625-502-0 | 40 x 55 x 9 | BUS JORNEY MR,GR,LR MBG T/M | 84/~93/6 | Transmission FRONT COVER |
| 03907 4805 | 1-09625-502-0 | 40 x 55 x 9 | BUS JORNEY CCM,DBR | 76/~83/ | Transmission FRONT COVER |
| 03907 5905 | 8-94336-317-1 | 49 x 100 x 8 | BUS JORNEY BL,BE | 90/8~95/ | Wheel Hub REAR OUTER |
| 03907 3441 | 1-09625-331-0 | 56 x 122 x 10.5 | BUS JORNEY CCM,DBR,LR,MR,GR | 76/~ | Wheel Hub REAR OUTER |
| 03907 7245 | 9-09724-023-0 | 65 x 85 x 10 | BUS JORNEY BL36 RIGHT HANDLE | 83/7~86/12 | Wheel Hub FRONT |
| 03907 3493 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | BUS JORNEY CCM,DBR,LR,MR,GR | 76/~ | Wheel Hub REAR INNER |
| 03907 5197 | 8-94336-316-1 | 80 x 113 x 12 x 20 | BUS JORNEY BL,BE | 90/8~95/ | Wheel Hub REAR INNER |
| 03907 5413 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | BUS JORNEY BL,BE | 72/~90/7 | Wheel Hub REAR INNER |
| 03907 7125 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | BUS JORNEY LR,MR,GR | 84/~ | Wheel Hub FRONT |
| 03907 6505 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | BUS JORNEY CCM,DBR | 76/~83/ | Wheel Hub FRONT |
| 03907 2325 | 5-09625-029-0 | 70 x 90 x 10 | BUS JORNEY BE# | 80/~95/ | Wheel Hub FRONT |
| 03907 2537 | 8-94408-084-0 | 45 x 78 x 11 x 19 | BUS JORNEY BL EXCEPT BL35 | 72/~90/7 | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3973 | 5-09625-029-0 | 70 x 90 x 10 | BUS JORNEY BL46 | 83/7~90/ | Wheel Hub FRONT |
| 03907 6053 | 5-09625-029-0 | 70 x 90 x 10 | BUS JORNEY BL 36 LEFT HANDLE | 83/7~86/12 | Wheel Hub FRONT |
| 03907 3629 | 5-09625-029-0 | 70 x 90 x 10 | BUS JORNEY BL LEFT HANDLE | 80/~83/6 | Wheel Hub FRONT |
| 03907 6941 | 9-09724-023-0 | 65 x 85 x 10 | BUS JORNEY BL36,38 | 87/1~95/ | Wheel Hub FRONT |
| 03907 4125 | 8-97017-350-0 | 34 x 48 x 8 | BUS JORNEY BL,BE | 90/8~95/ | Transmission FRONT COVER |
| 03907 3041 | 5-09625-091-0 | 37 x 55 x 9.5 | ELF (1.5T) KA MSG T/M (EXCEPT FLAT LOW) | 77/~84/5 | Wheel Hub REAR INNER |
| 03907 2089 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (1.5T) NHR INDEPENDENT SUSPENSION | 90/6~ | Wheel Hub FRONT |
| 03907 6237 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (1.5T) NHS(4WD) | 91/7~ | Wheel Hub FRONT |
| 03907 4045 | 9-09724-023-0 | 65 x 85 x 10 | ELF (1.5T) WHR | 85/5~93/11 | Wheel Hub FRONT |
| 03907 4997 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (1.5T) VHR,WHR,WKR | 93/12~ | Wheel Hub FRONT |
| 03907 4005 | 8-94369-730-0 | 65 x 80 x 10.5 x 15.5 | ELF (1.5T) NHS(4WD) | 91/7~ | Wheel Hub KNUCKLE |
| 03907 1573 | 5-09625-092-0 | 39.5 x 60 x 10 | ELF (1.5T) KAD EXCEPT FLAT LOW | 75/~76/ | Wheel Hub REAR INNER |
| 03907 5317 | 5-09625-092-0 | 39.5 x 60 x 10 | ELF (1.5T) KA MSC T/M (EXCEPT FLAT LOW) | 77/~84/5 | Wheel Hub REAR INNER |
| 03907 1457 | 5-09625-092-0 | 39.5 x 60 x 10 | ELF (1.5T) NHR,NHS,WHR SINGLE TIRE | 84/6~ | Wheel Hub REAR INNER |
| 03907 1213 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (1.5T) KA FLAT LOW | 75/~84/5 | Wheel Hub REAR INNER |
| 03907 6485 | 8-94248-116-1 | 63 x 80 x 7.7 | ELF (1.5T) NHR EXCEPT INDEPENDENT SUSPENSION | 84/6~ | Wheel Hub FRONT |
| 03907 2101 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (1.5T) VHR | 96/11~ | Wheel Hub REAR INNER |
| 03907 2385 | 8-97049-145-0 | 50 x 68 x 9 | ELF (1.5T) NHR,WHR,NHS 4JA1,4JB1 | 84/6~ | Engine CRANK SHAFT FRONT |
| 03907 1469 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (1.5T) NHR,NHS,WHR DOUBLE TIRE | 84/6~ | Wheel Hub REAR INNER |
| 03907 4261 | 9-09924-303-0 | 50 x 65 x 9 | ELF (1.5T) KA | 75/~84/5 | Wheel Hub FRONT |
| 03907 3677 | 5-09625-070-0 | 19 x 32 x 8 | ELF (1.5T) NHR | 84/6~ | Steering WORM SHAFT |
| 03907 6153 | 8-94227-475-0 | 20 x 31 x 7 | ELF (1.5T) NHR,WHR,NHS 4JA1,4JB1,4JG2 | 84/6~ | Engine INJECTION PUMP |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6609 | 8-97080-562-0 | 40 x 56 x 7 | ELF (1.5T) NHR,WHR,NHS 4JA1,4JB1,4JG2 | 84/6~ | Engine CAM SHAFT |
| 03907 4445 | 9-09724-022-0 | 52 x 72 x 7.5 | ELF (1.5T) KA#...EXCEPT FLAT LOW | 75/~84/5 | Wheel Hub REAR OUTER |
| 03907 1953 | 8-97049-145-0 | 50 x 68 x 9 | ELF (1.5T) KA ALL | 75/~84/5 | Engine CRANK SHAFT FRONT |
| 03907 2561 | 5-09625-091-0 | 37 x 55 x 9.5 | ELF (1.5T) KAG EXCEPT FLAT LOW | 75/~76/ | Wheel Hub REAR INNER |
| 03907 1769 | 8-97071-560-1 | 50 x 68 x 11.5 | ELF (1.5T) NHR,WHR,NHS,VHR 4JG2 | 93/12~ | Engine CRANK SHAFT FRONT |
| 03907 2053 | 5-09625-036-0 | 82 x 105 x 13 | ELF (1.5T) KA ALL | 75/~84/5 | Engine CRANK SHAFT REAR |
| 03907 3377 | 8-94235-369-0 | 95 x 118 x 10 | ELF (1.5T) NHR,WHR,NHS 4JA1,4JB2 | 84/6~ | Engine CRANK SHAFT REAR |
| 03907 6757 | 8-97071-561-1 | 95 x 118 x 14 | ELF (1.5T) NHR,WHR,NHS,VHR 4JG2 | 93/12~ | Engine CRANK SHAFT REAR |
| 03907 6109 | 8-97120-307-0 | | ELF (1.5T) KA C190,C240 | 82/~84/5 | Engine VALVE STEM SEAL |
| 03907 3765 | 8-97120-307-0 | | ELF (1.5T) NHR,WHR,NHS,VHR 4JA1,4JB1,4JG2 | 84/6~ | Engine VALVE STEM SEAL |
| 03907 2057 | 9-09924-261-0 | 31.7 x 48 x 8 | ELF (1.5T) NHR | 84/6~ | Steering SECTOR SHAFT |
| 03907 4013 | 8-97352-745-0 | 40 x 56 x 6.5 | ELF (1.5T) VHR | 96/11~ | Engine |
| 03907 5157 | 8-97257-296-0 | 45 x 65 x 10 | ELF (1.5T) VHR ALL | 96/11~ | Transmission REAR COVER |
| 03907 2569 | 9-09924-451-0 | 30 x 42 x 8 | ELF (1.5T) WHR | 85/5~ | Steering SECTOR SHAFT |
| 03907 2225 | 8-94366-610-0 | 30 x 61 x 9 x 13.5 | ELF (1.5T) NHS(4WD) | 91/7~ | Wheel Hub AXLE SHAFT INNER |
| 03907 3893 | 9-09724-022-0 | 52 x 72 x 7.5 | ELF (1.5T) NHR,NHS,WHR SINGLE TIRE | 84/6~ | Wheel Hub REAR OUTER |
| 03907 6365 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (1.5T) NHR,NHS,VNR,WHR | 84/6~ | Final Drive PINION |
| 03907 5329 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (1.5T) KA52N | 75/~84/5 | Final Drive PINION |
| 03907 4917 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (1.5T) KA MSC T/M | 77/~84/5 | Final Drive PINION |
| 03907 6125 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (1.5T) KAD | 75/~76/ | Final Drive PINION |
| 03907 6401 | 9-09724-003-0 | 40 x 74 x 10 | ELF (1.5T) KA51N,KAD41NA | 75/~84/5 | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 7025 | 9-09724-003-0 | 40 x 74 x 10 | ELF (1.5T) KAG | 75/~76/ | Final Drive PINION |
| 03907 2353 | 9-09924-451-0 | 30 x 42 x 8 | ELF (1.5T) KA EXCEPT G41,D14NA | 75/~84/5 | Steering SECTOR SHAFT |
| 03907 6325 | 8-97257-296-0 | 45 x 65 x 10 | ELF (1.5T) NHR,WHR MSB T/M | 00/9~ | Transmission REAR COVER |
| 03907 3881 | 8-97074-651-0 | 45 x 65 x 10 | ELF (1.5T) VHR...ALL | 96/11~ | Transmission REAR COVER |
| 03907 5957 | 8-97074-651-0 | 45 x 65 x 10 | ELF (1.5T) WHR MSB T/M | 90/12~ | Transmission REAR COVER |
| 03907 3317 | 8-97074-651-0 | 45 x 65 x 10 | ELF (1.5T) NHR MSB T/M | 90/6~00/8 | Transmission REAR COVER |
| 03907 2981 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (1.5T) VHR | 96/11~ | Wheel Hub REAR OUTER |
| 03907 5241 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (1.5T) KA FLAT LOW | 75/~84/5 | Wheel Hub REAR OUTER |
| 03907 6981 | 9-09724-003-0 | 40 x 74 x 10 | ELF (1.5T) KA MSG T/M | 77/~84/5 | Final Drive PINION |
| 03907 4601 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (1.5T) NHR,NHS,WHR DOUBLE TIRE | 84/6~ | Wheel Hub REAR OUTER |
| 03907 2693 | 5-09625-017-0 | 40 x 68 x 11 | ELF (1.5T) WHR MSC T/M | 85/5~90/11 | Transmission REAR COVER |
| 03907 4621 | 8-94326-441-0 | 27 x 43 x 9 | ELF (1.5T) KA | 75/~84/5 | Transmission FRONT COVER |
| 03907 1277 | 8-94326-441-0 | 27 x 43 x 9 | ELF (1.5T) NHR,WHR | 84/6~ | Transmission FRONT COVER |
| 03907 3321 | 8-94326-441-0 | 27 x 43 x 9 | ELF (1.5T) VHR MSB T/M | 96/11~ | Transmission FRONT COVER |
| 03907 1633 | 8-97046-699-0 | 27 x 43 x 7 | ELF (1.5T) NHS | 91/7~ | Transmission FRONT COVER |
| 03907 3173 | 8-97017-350-0 | 34 x 48 x 8 | ELF (1.5T) VHR MXA T/M | 96/11~ | Transmission FRONT COVER |
| 03907 3125 | 8-94223-026-0 | 35 x 49.2 x 12.5 | ELF (1.5T) KA MSE,MSG T/M (EXCEPT FLAT LOW) | 75/~84/5 | Transmission REAR COVER |
| 03907 6013 | 5-09625-017-0 | 40 x 68 x 11 | ELF (1.5T) KA MSC T/M | 75/~84/5 | Transmission REAR COVER |
| 03907 6497 | 1-09625-502-0 | 40 x 55 x 9 | ELF (1.5T) KA MSE,MSG T/M (FLAT LOW) | 77/~84/5 | Transmission REAR COVER |
| 03907 1401 | 5-09625-017-0 | 40 x 68 x 11 | ELF (1.5T) NHR MSC T/M | 84/6~90/5 | Transmission REAR COVER |
| 03907 7201 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (2T) NKS(4WD) ALL | 87/9~95/11 | Wheel Hub REAR INNER |
| 03907 4225 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) NKR ALL | 84/6~89/5 | Wheel Hub REAR INNER |
| 03907 5181 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) NKR 4JB1,4BC2,4BE2,4BG1 | 89/6~93/3 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4737 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) NKR 4HF1(2T, FULL FLAT LOW) | 90/5~93/3 | Wheel Hub REAR INNER |
| 03907 1697 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) NKR WITHOUT LIMITED SLIP DIFF. | 93/4~ | Wheel Hub REAR INNER |
| 03907 3597 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) WKR,VKR ALL | 85/3~ | Wheel Hub REAR INNER |
| 03907 5665 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) NKS(4WD) WITHOUT LIMITED SLIP DIFF. | 95/11~ | Wheel Hub REAR INNER |
| 03907 2613 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (2T) NKR 4BG1 | 89/6~90/4 | Wheel Hub REAR INNER |
| 03907 4569 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (2T) NKS(4WD) LIMITED SLIP DIFF. | 95/11~ | Wheel Hub REAR INNER |
| 03907 6597 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (2T) NKR LIMITED SLIP DIFF. | 93/4~ | Wheel Hub REAR INNER |
| 03907 3033 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) KT ALL | 80/2~84/5 | Wheel Hub REAR OUTER |
| 03907 5069 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) TL ALL | 67/~84/5 | Wheel Hub REAR OUTER |
| 03907 2913 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) KT ALL | 80/2~84/5 | Wheel Hub REAR INNER |
| 03907 4069 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (2T) NKR 4HF1(EXCEPT 2T, FULL FLAT LOW) | 90/5~93/3 | Wheel Hub REAR INNER |
| 03907 6805 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (2T) NKR DISC BRAKE | 90/5~93/4 | Wheel Hub FRONT |
| 03907 1209 | 8-94336-317-1 | 49 x 100 x 8 | ELF (2T) NKR 4HF1(EXCEPT 2T,FULL FLAT LOW) | 90/5~93/3 | Wheel Hub REAR OUTER |
| 03907 3217 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) NKR ALL | 84/6~89/5 | Wheel Hub REAR OUTER |
| 03907 3885 | 9-09724-023-0 | 65 x 85 x 10 | ELF (2T) TL ALL | 67/~84/5 | Wheel Hub FRONT |
| 03907 4861 | 9-09724-023-0 | 65 x 85 x 10 | ELF (2T) WKR DRUM BRAKE | 85/3~93/11 | Wheel Hub FRONT |
| 03907 3281 | 5-09625-029-0 | 70 x 90 x 10 | ELF (2T) KT EXCEPT 2T | 80/2~84/5 | Wheel Hub FRONT |
| 03907 1313 | 9-09724-023-0 | 65 x 85 x 10 | ELF (2T) KT 2T | 80/2~84/5 | Wheel Hub FRONT |
| 03907 1205 | 8-94248-117-1 | 73 x 90 x 8 | ELF (2T) NKR EXCEPT INDEPENDENT SUSPENSION | 93/4~ | Wheel Hub FRONT |
| 03907 5973 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (2T) TL ALL | 67/~84/5 | Wheel Hub REAR INNER |
| 03907 6557 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (2T) NKR INDEPENDENT SUSPENSION | 93/4~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5465 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (2T) NKS(4WD) INDEPENDENT SUSPENSION | 95/11~ | Wheel Hub FRONT |
| 03907 4969 | 8-94440-904-0 | 102 x 120 x 20 | ELF (2T) NKS(4WD) ALL | 87/9~95/11 | Wheel Hub FRONT |
| 03907 6581 | 8-94440-904-0 | 102 x 120 x 20 | ELF (2T) NKS(4WD) EXCEPT INDEPENDENT SUSPENSION | 95/11~ | Wheel Hub FRONT |
| 03907 3289 | 8-94459-416-0 | 52 x 76 x 8.5 | ELF (2T) NKS(4WD) ALL | 87/9~95/11 | Wheel Hub FRONT AXLE SHAFT |
| 03907 5557 | 8-94459-416-0 | 52 x 76 x 8.5 | ELF (2T) NKS(4WD) EXCEPT INDEPENDENT SUSPENSION | 95/11~ | Wheel Hub FRONT AXLE SHAFT |
| 03907 5933 | 8-94248-117-1 | 73 x 90 x 8 | ELF (2T) NKR DRUM BRAKE | 84/6~93/4 | Wheel Hub FRONT |
| 03907 3753 | 8-97047-609-0 | 60 x 103 x 12 x 21 | ELF (2T) NKR diam. 320MM SIZE DIFF. | 95/3~ | Final Drive PINION (REAR) |
| 03907 5085 | 8-94373-765-0 | 60 x 82 x 12 | ELF (2T) KT ALL | 80/2~84/5 | Engine CRANK SHAFT FRONT |
| 03907 6717 | 8-94373-765-0 | 60 x 82 x 12 | ELF (2T) TL 4BA1,4BC1,4BC2 | 76/~84/5 | Engine CRANK SHAFT FRONT |
| 03907 1865 | 8-97049-145-0 | 50 x 68 x 9 | ELF (2T) WKR 4JB1 | 85/3~93/ | Engine CRANK SHAFT FRONT |
| 03907 2121 | 8-97049-145-0 | 50 x 68 x 9 | ELF (2T) NKR 4JB1 | 84/6~93/ | Engine CRANK SHAFT FRONT |
| 03907 1941 | 8-97049-145-0 | 50 x 68 x 9 | ELF (2T) TL G201,C240 | 76/~84/5 | Engine CRANK SHAFT FRONT |
| 03907 4925 | 8-97080-562-0 | 40 x 56 x 7 | ELF (2T) NKR,WKR 4JB1,4JG2 | 84/6~ | Engine CAM SHAFT |
| 03907 6897 | 8-94227-475-0 | 20 x 31 x 7 | ELF (2T) NKR,WKR 4JB1,4JG2 | 84/6~ | Engine INJECTION PUMP |
| 03907 3925 | 5-09625-070-0 | 19 x 32 x 8 | ELF (2T) NKR | 84/6~ | Steering WORM |
| 03907 1789 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) NKS(4WD) WITHOUT LIMITED SLIP DIFF. | 95/11~ | Wheel Hub REAR OUTER |
| 03907 5989 | 9-09924-261-0 | 31.7 x 48 x 8 | ELF (2T) TL | 82/~84/5 | Steering SECTOR SHAFT |
| 03907 2869 | 8-97071-560-1 | 50 x 68 x 11.5 | ELF (2T) NKR,WKR 4JG2 | 93/4~ | Engine CRANK SHAFT FRONT |
| 03907 1393 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (2T) VKR | 96/11~ | Final Drive PINION (REAR) |
| 03907 3465 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (2T) NKS | 87/9~ | Final Drive PINION (REAR) |
| 03907 2153 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (2T) NKR diam. 292MM SIZE DIFF. | 93/4~ | Final Drive PINION (REAR) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3617 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (2T) NKR 4BE1,4BE2,4BG1,4HF1 | 84/6~93/3 | Final Drive PINION (REAR) |
| 03907 1149 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (2T) KT EXCEPT 24NA,25NA | 80/2~84/5 | Final Drive PINION (REAR) |
| 03907 2229 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (2T) TL 44,54,64,45,55,65,75 | 76/~81/ | Final Drive PINION (REAR) |
| 03907 2169 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) WKR ALL | 85/3~ | Final Drive PINION (REAR) |
| 03907 4173 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) NKR diam. 244MM SIZE DIFF. | 93/4~ | Final Drive PINION (REAR) |
| 03907 2749 | 9-09924-261-0 | 31.7 x 48 x 8 | ELF (2T) NKR | 84/6~ | Steering SECTOR SHAFT |
| 03907 3833 | 1-09625-320-0 | 100 x 135 x 10 | ELF (2T) NKS 4BE1 | 87/9~93/ | Engine CRANK SHAFT REAR |
| 03907 5713 | 8-97210-702-0 | | ELF (2T) NKR,NKS,VKR 4HF1,4HG1,4HJ1,4HL1 | 02/5~ | Engine VALVE STEM SEAL |
| 03907 2209 | 8-94396-609-2 | | ELF (2T) NKR,NKS,VKR 4HF1,4HG1,4HJ1,4HL1 | 90/5~02/4 | Engine VALVE STEM SEAL |
| 03907 4209 | 5-12569-001-0 | | ELF (2T) NKR 4BA1,4BC1,4BC2,4BE1,4BE 2,4BG1 | 84/6~95/ | Engine VALVE STEM SEAL |
| 03907 5937 | 5-12569-001-0 | | ELF (2T) TL 4BA1,4BC1,4BC2 | 76/~84/5 | Engine VALVE STEM SEAL |
| 03907 4749 | 8-97120-307-0 | | ELF (2T) NKR,WKR 4JB1,4JG2 | 84/6~ | Engine VALVE STEM SEAL |
| 03907 6749 | 8-97120-307-0 | | ELF (2T) TL C240 | 82/~84/5 | Engine VALVE STEM SEAL |
| 03907 6481 | 8-97602-379-0 | 104 x 139 x 13 | ELF (2T) NKR,NKS,VKR 4HF1,4HG1,4HJ1,4HL1 | 02/6~ | Engine CRANK SHAFT REAR |
| 03907 2741 | 8-94370-637-0 | 104 x 139 x 13 | ELF (2T) NKR,NKS,VKR 4HF1,4HG1,4HJ1,4HL1 | 90/5~02/5 | Engine CRANK SHAFT REAR |
| 03907 5969 | 8-94373-765-0 | 60 x 82 x 12 | ELF (2T) NKR 4BA1,4BC1,4BC2,4BE1,4BE 2,4BG1 | 84/6~ | Engine CRANK SHAFT FRONT |
| 03907 3489 | 8-97071-561-1 | 95 x 118 x 14 | ELF (2T) NKR,WKR 4JG2 | 93/4~ | Engine CRANK SHAFT REAR |
| 03907 6265 | 8-94373-765-0 | 60 x 82 x 12 | ELF (2T) NKS 4BE1 | 87/9~93/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 7217 | 1-09625-320-0 | 100 x 135 x 10 | ELF (2T) NKR 4BA1,4BC1,4BC2,4BE1,4BE2,4BG1 | 84/6~93/3 | Engine CRANK SHAFT REAR |
| 03907 2029 | 8-94235-369-0 | 95 x 118 x 10 | ELF (2T) WKR 4JB1 | 85/3~93/ | Engine CRANK SHAFT REAR |
| 03907 1329 | 8-94235-369-0 | 95 x 118 x 10 | ELF (2T) NKR 4JB1 | 84/6~93/ | Engine CRANK SHAFT REAR |
| 03907 3549 | 5-09625-052-0 | 100 x 135 x 15 | ELF (2T) KT ALL | 80/2~84/5 | Engine CRANK SHAFT REAR |
| 03907 1785 | 5-09625-052-0 | 100 x 135 x 15 | ELF (2T) TL 4BA1,4BC1,4BC2 | 76/~84/5 | Engine CRANK SHAFT REAR |
| 03907 4169 | 5-09625-036-0 | 82 x 105 x 13 | ELF (2T) TL G201,C240 | 76/~84/5 | Engine CRANK SHAFT REAR |
| 03907 2785 | 8-97329-780-0 | 109 x 137 x 13 | ELF (2T) NKR,NKS,VKR 4HF1,4HG1,4HJ1,4HL1 | 02/6~ | Engine CRANK SHAFT FRONT |
| 03907 4685 | 8-94369-518-0 | 109 x 137 x 13 | ELF (2T) NKR,NKS,VKR 4HF1,4HG1,4HJ1,4HL1 | 90/5~02/5 | Engine CRANK SHAFT FRONT |
| 03907 6953 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) NKR ALL | 84/6~86/8 | Final Drive PINION (REAR) |
| 03907 7165 | 8-97072-823-1 | 100 x 135 x 17 | ELF (2T) NKR 4BE1,4BE2 | 93/4~ | Engine CRANK SHAFT REAR |
| 03907 3773 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) NKR ALL | 84/6~90/4 | Transmission FRONT COVER |
| 03907 3525 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) NKR 4JB1 | 90/5~93/3 | Final Drive PINION (REAR) |
| 03907 5125 | 8-97253-550-0 | 40 x 54 x 7 | ELF (2T) NKR MYY T/M | 02/5~ | Transmission FRONT COVER |
| 03907 4417 | 8-97017-350-0 | 34 x 48 x 8 | ELF (2T) NKS ALL | 90/5~02/5 | Transmission FRONT COVER |
| 03907 2429 | 8-97017-350-0 | 34 x 48 x 8 | ELF (2T) NKR MXA,MSA T/M | 93/4~02/4 | Transmission FRONT COVER |
| 03907 2461 | 8-97017-350-0 | 34 x 48 x 8 | ELF (2T) NKR 4BE1,4BE2,4HF | 90/5~93/3 | Transmission FRONT COVER |
| 03907 4781 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) VKR MSB T/M | 96/11~ | Transmission FRONT COVER |
| 03907 1113 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) NKS | 87/9~90/4 | Transmission FRONT COVER |
| 03907 2685 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) WKR | 85/3~ | Transmission FRONT COVER |
| 03907 3449 | 8-97253-550-0 | 40 x 54 x 7 | ELF (2T) VKR MXA T/M | 96/11~ | Transmission FRONT COVER |
| 03907 2557 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) NKR 4JB1 | 90/5~93/3 | Transmission FRONT COVER |
| 03907 1197 | 8-97074-651-0 | 45 x 65 x 10 | ELF (2T) TL MSB T/M | 67/~84/5 | Transmission REAR COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3633 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) TL,KT | 67/~84/5 | Transmission FRONT COVER |
| 03907 5613 | 8-94336-317-1 | 49 x 100 x 8 | ELF (2T) NKS(4WD) LIMITED SLIP DIFF. | 95/11~ | Wheel Hub REAR OUTER |
| 03907 5825 | 8-94336-317-1 | 49 x 100 x 8 | ELF (2T) NKS(4WD) ALL | 87/9~95/11 | Wheel Hub REAR OUTER |
| 03907 4429 | 8-94336-317-1 | 49 x 100 x 8 | ELF (2T) NKR LIMITED SLIP DIFF. | 93/4~ | Wheel Hub REAR OUTER |
| 03907 2801 | 5-09625-017-0 | 40 x 68 x 11 | ELF (2T) KT 24NA | 80/2~82/ | Transmission REAR COVER |
| 03907 3461 | 8-94336-317-1 | 49 x 100 x 8 | ELF (2T) NKR 4BG1 | 89/6~90/4 | Wheel Hub REAR OUTER |
| 03907 1461 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) WKR,VKR ALL | 85/3~ | Wheel Hub REAR OUTER |
| 03907 7053 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) NKR WITHOUT LIMITED SLIP DIFF. | 93/4~ | Wheel Hub REAR OUTER |
| 03907 1517 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) NKR 4HF1(2T, FULL FLAT LOW) | 90/5~93/3 | Wheel Hub REAR OUTER |
| 03907 4921 | 8-94326-441-0 | 27 x 43 x 9 | ELF (2T) NKR MSB T/M | 93/4~ | Transmission FRONT COVER |
| 03907 2213 | 8-97257-296-0 | 45 x 65 x 10 | ELF (2T) WKR MSB T/M | 00/9~ | Transmission REAR COVER |
| 03907 1873 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (2T) NKR 4JB1,4BC2,4BE1,4BG1 | 89/6~93/3 | Wheel Hub REAR OUTER |
| 03907 7001 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) KT 24NA,25NA | 80/2~84/5 | Final Drive PINION (REAR) |
| 03907 2341 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) TL..ALL | 82/~84/5 | Final Drive PINION (REAR) |
| 03907 5349 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) TL EXCEPT 44,54,64,45,55,65,75 | 76/~81/ | Final Drive PINION (REAR) |
| 03907 6393 | 8-94318-520-2 | 40 x 74 x 9.5 x 15 | ELF (2T) NKS INDEPENDENT SUSPENSION | 95/11~ | Final Drive PINION (FRONT) |
| 03907 2849 | 8-94318-915-0 | 45 x 78 x 11 x 18.5 | ELF (2T) NKS EXCEPT INDEPENDENT SUSPENSION | 95/11~ | Final Drive PINION (FRONT) |
| 03907 5449 | 8-94318-915-0 | 45 x 78 x 11 x 18.5 | ELF (2T) NKS..ALL | 87/9~95/11 | Final Drive PINION (FRONT) |
| 03907 5445 | 8-94481-424-0 | 50 x 70 x 10 | ELF (2T) NKS | 87/9~ | Transfer CASE |
| 03907 3717 | 8-97253-550-0 | 40 x 54 x 7 | ELF (2T) NKS ALL | 02/6~ | Transmission FRONT COVER |
| 03907 2321 | 8-97257-296-0 | 45 x 65 x 10 | ELF (2T) VKR | 00/9~ | Transmission REAR COVER |
| 03907 1273 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (2T) NKR 4BA1,4BC2,4JB1 | 86/9~90/4 | Final Drive PINION (REAR) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2033 | 8-97257-296-0 | 45 x 65 x 10 | ELF (2T) NKR MSB T/M | 02/5~ | Transmission REAR COVER |
| 03907 5145 | 8-97257-296-0 | 45 x 65 x 10 | ELF (2T) NKR MXA,MSB T/M | 00/9~02/4 | Transmission REAR COVER |
| 03907 2201 | 5-09625-017-0 | 40 x 68 x 11 | ELF (2T) NKR MSC T/M | 84/6~89/5 | Transmission REAR COVER |
| 03907 5057 | 5-09625-017-0 | 40 x 68 x 11 | ELF (2T) TL MSC T/M | 67/~77/8 | Transmission REAR COVER |
| 03907 7077 | 8-97074-651-0 | 45 x 65 x 10 | ELF (2T) VKR | 96/11~00/8 | Transmission REAR COVER |
| 03907 5417 | 8-97074-651-0 | 45 x 65 x 10 | ELF (2T) WKR MSB T/M | 90/12~00/8 | Transmission REAR COVER |
| 03907 3657 | 8-97074-651-0 | 45 x 65 x 10 | ELF (2T) NKR ALL | 89/6~00/9 | Transmission REAR COVER |
| 03907 7221 | 8-97074-651-0 | 45 x 65 x 10 | ELF (2T) NKR MSA,MSB T/M | 84/6~89/5 | Transmission REAR COVER |
| 03907 5097 | 8-97074-651-0 | 45 x 65 x 10 | ELF (2T) KT EXCEPT 24NA | 80/2~84/5 | Transmission REAR COVER |
| 03907 3873 | 8-97253-552-1 | 50 x 63.5 x 8.5 | ELF (2T) NKR MYY T/M | 02/5~ | Transmission REAR COVER |
| 03907 6537 | 5-09625-017-0 | 40 x 68 x 11 | ELF (2T) WKR MSC T/M | 85/3~90/11 | Transmission REAR COVER |
| 03907 2941 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (3T) NPS(4WD) LIMITED SLIP DIFF. | 02/10~ | Wheel Hub REAR INNER |
| 03907 4893 | 8-97017-350-0 | 34 x 48 x 8 | ELF (3T) NPR MSA,MXA T/M | 90/6~ | Transmission FRONT COVER |
| 03907 5093 | 8-94326-441-0 | 27 x 43 x 9 | ELF (3T) KS,NPR | 71/~90/5 | Transmission FRONT COVER |
| 03907 4293 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (3T) NPS(4WD) WITHOUT LIMITED SLIP DIFF. | 02/10~ | Wheel Hub REAR OUTER |
| 03907 5501 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (3T) NPR 2T,3T(WITHOUT LIMITED SLIP DIFF.) | 93/5~ | Wheel Hub REAR OUTER |
| 03907 2137 | 8-94336-315-2 | 46 x 94.4 x 8 | ELF (3T) NPR 4BC2,4BE1 | 84/6~93/4 | Wheel Hub REAR OUTER |
| 03907 5749 | 8-94336-317-1 | 49 x 100 x 8 | ELF (3T) NPS(4WD) LIMITED SLIP DIFF. | 02/10~ | Wheel Hub REAR OUTER |
| 03907 3613 | 8-94336-317-1 | 49 x 100 x 8 | ELF (3T) NPS(4WD) | 87/12~02/10 | Wheel Hub REAR OUTER |
| 03907 3333 | 8-94336-317-1 | 49 x 100 x 8 | ELF (3T) NPR 3.5T,4T+LIMITED SLIP DIFF. | 93/5~ | Wheel Hub REAR OUTER |
| 03907 1885 | 8-94336-317-1 | 49 x 100 x 8 | ELF (3T) NPR 4BD1,4BG1 | 84/6~93/4 | Wheel Hub REAR OUTER |
| 03907 2009 | 8-94336-317-1 | 49 x 100 x 8 | ELF (3T) KS | 71/~84/5 | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5953 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (3T) NPS(4WD) WITHOUT LIMITED SLIP DIFF. | 02/10~ | Wheel Hub REAR INNER |
| 03907 1377 | 9-09724-023-0 | 65 x 85 x 10 | ELF (3T) KS | 71/~80/1 | Wheel Hub FRONT |
| 03907 3921 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (3T) NPR 4BC2,4BE1 | 84/6~93/4 | Wheel Hub REAR INNER |
| 03907 4821 | 8-97253-550-0 | 40 x 54 x 7 | ELF (3T) NPR MYY,MZZ M/T | 02/5~03/2 | Transmission FRONT COVER |
| 03907 5833 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (3T) NPS(4WD) | 87/12~02/10 | Wheel Hub REAR INNER |
| 03907 2481 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (3T) NPR 3.5T,4T+LIMITED SLIP DIFF. | 93/5~ | Wheel Hub REAR INNER |
| 03907 2001 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (3T) NPR 4BD1,4BG1 | 84/6~93/4 | Wheel Hub REAR INNER |
| 03907 3585 | 8-94336-316-1 | 80 x 113 x 12 x 20 | ELF (3T) KS | 71/~84/5 | Wheel Hub REAR INNER |
| 03907 5693 | 8-94459-416-0 | 52 x 76 x 8.5 | ELF (3T) NPS(4WD) EXCEPT INDEPENDENT SUSPENSION | 02/10~ | Wheel Hub FRONT AXLE SHAFT |
| 03907 1989 | 8-94459-416-0 | 52 x 76 x 8.5 | ELF (3T) NPS(4WD) ALL | 87/12~02/10 | Wheel Hub FRONT AXLE SHAFT |
| 03907 2833 | 8-94440-904-0 | 102 x 120 x 20 | ELF (3T) NPS(4WD) EXCEPT INDEPENDENT SUSPENSION | 02/10~ | Wheel Hub FRONT |
| 03907 4145 | 8-94440-904-0 | 102 x 120 x 20 | ELF (3T) NPS(4WD) ALL | 87/12~02/10 | Wheel Hub FRONT |
| 03907 4873 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (3T) NPS(4WD) INDEPENDENT SUSPENSION | 02/10~ | Wheel Hub FRONT |
| 03907 1661 | 8-97211-082-0 | 65 x 93 x 8.5 x 18 | ELF (3T) NPR INDEPENDENT SUSPENSION | 99/12~ | Wheel Hub FRONT |
| 03907 1145 | 8-94248-117-1 | 73 x 90 x 8 | ELF (3T) NPR EXCEPT INDEPENDENT SUSPENSION | 99/12~ | Wheel Hub FRONT |
| 03907 6993 | 8-94248-117-1 | 73 x 90 x 8 | ELF (3T) NPR ALL | 84/6~99/12 | Wheel Hub FRONT |
| 03907 1117 | 5-09625-029-0 | 70 x 90 x 10 | ELF (3T) KS | 80/2~84/5 | Wheel Hub FRONT |
| 03907 6285 | 8-94336-314-1 | 77 x 102 x 9.5 x 21.5 | ELF (3T) NPR 2T,3T(WITHOUT LIMITED SLIP DIFF.) | 93/5~ | Wheel Hub REAR INNER |
| 03907 6141 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (3T) NPS(4WD) 2T,3T | 02/10~ | Final Drive PINION |
| 03907 3069 | 8-97210-702-0 | | ELF (3T) NPR,NPS 4HJ1,4HL1 | 99/8~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3537 | 8-97210-702-0 | | ELF (3T) NPR,NPS 4HF1,4HE1,4HG1,4HK1 | 99/8~ | Engine VALVE STEM SEAL |
| 03907 5861 | 8-94396-609-2 | | ELF (3T) NPR,NPS 4HF1,4HE1,4HG1,4HJ1,4HK 1 | 90/5~99/8 | Engine VALVE STEM SEAL |
| 03907 6217 | 5-12569-001-0 | | ELF (3T) NPR 4BE1,4BD1,4BG1 | 84/6~93/5 | Engine VALVE STEM SEAL |
| 03907 6209 | 5-12569-001-0 | | ELF (3T) KS | 71/~84/5 | Engine VALVE STEM SEAL |
| 03907 6205 | 8-97602-379-0 | 104 x 139 x 13 | ELF (3T) NPR,NPS 4HF1,4HE1,4HG1,4HJ1,4HK 1,4HL1 | 90/5~ | Engine CRANK SHAFT REAR |
| 03907 6525 | 1-09625-320-0 | 100 x 135 x 10 | ELF (3T) NPR 4BE1,4BD1,4BG1 | 84/6~93/5 | Engine CRANK SHAFT REAR |
| 03907 2897 | 5-09625-052-0 | 100 x 135 x 15 | ELF (3T) KS | 71/~84/5 | Engine CRANK SHAFT REAR |
| 03907 7057 | 8-97329-780-0 | 109 x 137 x 13 | ELF (3T) NPR,NPS 4HF1,4HE1,4HG1,4HJ1,4HK 1,4HL1 | 90/5~ | Engine CRANK SHAFT FRONT |
| 03907 4217 | 8-94373-765-0 | 60 x 82 x 12 | ELF (3T) NPR,NPS 4BE1,4BD1,4BG1 | 84/6~ | Engine CRANK SHAFT FRONT |
| 03907 2177 | 8-94373-765-0 | 60 x 82 x 12 | ELF (3T) KS | 71/~84/5 | Engine CRANK SHAFT FRONT |
| 03907 2313 | 8-97047-609-0 | 60 x 103 x 12 x 21 | ELF (3T) NPS(4WD) 3.5T | 02/10~ | Final Drive PINION |
| 03907 4325 | 1-09625-502-0 | 40 x 55 x 9 | ELF (3T) NPR MBL T/M | 93/5~93/6 | Transmission FRONT COVER |
| 03907 5485 | 8-94408-084-0 | 45 x 78 x 11 x 19 | ELF (3T) NPR..4BC2 | 84/6~88/ | Final Drive PINION |
| 03907 2073 | 1-09625-565-1 | 40 x 55 x 7 | ELF (3T) NPR MBL,MBL T/M | 93/7~ | Transmission FRONT COVER |
| 03907 3681 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (3T) NPS(4WD) ALL | 87/12~02/9 | Final Drive PINION |
| 03907 5605 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (3T) NPR EXCEPT 14INCH DIFF. | 93/6~ | Final Drive PINION |
| 03907 4205 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (3T) NPR 4BD1,4BE1,4BG1 | 84/6~93/5 | Final Drive PINION |
| 03907 5137 | 8-94408-083-0 | 58 x 103 x 12 x 19.5 | ELF (3T) KS | 71/~84/5 | Final Drive PINION |
| 03907 7113 | 8-97253-551-1 | 58 x 75 x 8.5 | ELF (3T) NPR MZZ M/T | 02/5~ | Transmission REAR COVER |
| 03907 6473 | 8-97253-552-1 | 50 x 63.5 x 8.5 | ELF (3T) NPR MYY M/T | 02/5~ | Transmission REAR COVER |
| 03907 6249 | 1-09625-505-0 | 60 x 77 x 12 | ELF (3T) NPR MBL,MBP T/M | 93/5~ | Transmission REAR COVER |
| 03907 2061 | 8-97257-296-0 | 45 x 65 x 10 | ELF (3T) NPR MXA T/M (DUAL MODE M/T) | 99/8~ | Transmission REAR COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2825 | 8-97074-651-0 | 45 x 65 x 10 | ELF (3T) KS | 71/~84/5 | Transmission REAR COVER |
| 03907 5389 | 8-97255-187-0 | 42 x 57 x 7 | ELF (3T) NPR MZZ M/T (SMOOTHER) | 03/3~ | Transmission FRONT COVER |
| 03907 1749 | 8-97253-550-0 | 40 x 54 x 7 | ELF (3T) NPR MYY,MZZ M/T(EXCEPT SMOOTHER) | 03/3~ | Transmission FRONT COVER |
| 03907 3421 | 8-97074-651-0 | 45 x 65 x 10 | ELF (3T) NPR MSA,MXA T/M | 84/6~99/7 | Transmission REAR COVER |
| 03907 5345 | 8-97047-609-0 | 60 x 103 x 12 x 21 | ELF (3T) NPR HEAVY DUTY 14INCH DIFF. | 93/5~ | Final Drive PINION |
| 03907 7121 | 8-97212-145-0 | 45 x 62 x 9 | ELF (3T) NPR MXA T/M (EXCEPT DUAL MODE M/T) | 99/8~ | Transmission REAR COVER |
| 03907 6181 | 8-97047-609-0 | 60 x 103 x 12 x 21 | ELF (4T) / FORWARD NQR | 95/12~ | Final Drive PINION |
| 03907 1665 | 8-97122-937-0 | 82 x 121 x 12 x 19 | ELF (4T) / FORWARD NQR | 95/12~ | Wheel Hub REAR INNER |
| 03907 7037 | 8-94336-317-1 | 49 x 100 x 8 | ELF (4T) / FORWARD NQR | 95/12~ | Wheel Hub REAR OUTER |
| 03907 1501 | 8-97017-350-0 | 34 x 48 x 8 | ELF (4T) / FORWARD NQR MXA T/M | 95/12~ | Transmission FRONT COVER |
| 03907 2269 | 8-97253-550-0 | 40 x 54 x 7 | ELF (4T) / FORWARD NQR MZZ T/M | 02/5~ | Transmission FRONT COVER |
| 03907 1281 | 8-97257-296-0 | 45 x 65 x 10 | ELF (4T) / FORWARD NQR MXA T/M | 00/9~ | Transmission REAR COVER |
| 03907 6509 | 8-94248-117-1 | 73 x 90 x 8 | ELF (4T) / FORWARD NQR | 95/12~ | Wheel Hub FRONT |
| 03907 4449 | 8-97253-551-1 | 58 x 75 x 8.5 | ELF (4T) / FORWARD NQR MZZ T/M | 02/5~ | Transmission REAR COVER |
| 03907 4733 | 1-09625-565-0 | 40 x 55 x 7 | ELF (4T) / FORWARD NQR MBP T/M | 95/12~ | Transmission FRONT COVER |
| 03907 3385 | 8-94369-518-0 | 109 x 137 x 13 | ELF (4T) / FORWARD NQR | 95/12~02/5 | Engine CRANK SHAFT FRONT |
| 03907 7145 | 8-97329-780-0 | 109 x 137 x 13 | ELF (4T) / FORWARD NQR | 02/6~ | Engine CRANK SHAFT FRONT |
| 03907 4073 | 8-94370-637-0 | 104 x 139 x 13 | ELF (4T) / FORWARD NQR | 95/12~02/5 | Engine CRANK SHAFT REAR |
| 03907 4377 | 8-97602-379-0 | 104 x 139 x 13 | ELF (4T) / FORWARD NQR | 02/6~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2497 | 8-94396-609-2 | | ELF (4T) / FORWARD NQR 4HE1,4HK1 | 95/12~ | Engine VALVE STEM SEAL |
| 03907 5301 | 8-97210-702-0 | | ELF (4T) / FORWARD NQR 4HJ1 | 99/5~ | Engine VALVE STEM SEAL |
| 03907 6801 | 1-09625-505-0 | 60 x 77 x 12 | ELF (4T) / FORWARD NQR MBR T/M | 95/12~ | Transmission REAR COVER |
| 03907 3065 | 8-97074-651-0 | 45 x 65 x 10 | ELF (4T) / FORWARD NQR MXA T/M | 95/12~00/8 | Transmission REAR COVER |
| 03907 3689 | 8-94326-441-0 | 27 x 43 x 9 | FARGO WFR,WFS,NFR,NFS | 81/1~96/ | Transmission FRONT COVER |
| 03907 5561 | 8-94340-317-0 | 38 x 49.2 x 9 | FARGO WFS,NFS | 83/11~96/ | Transfer CASE |
| 03907 2737 | 8-94422-387-0 | 38 x 49.5 x 8 x 12 | FARGO NFR,NFS | 88/9~96/ | Transmission REAR COVER |
| 03907 6569 | 8-94340-317-0 | 38 x 49.2 x 9 | FARGO WFR# | 88/11~96/ | Transmission REAR COVER |
| 03907 4433 | 8-94340-317-0 | 38 x 49.2 x 9 | FARGO WFR 4ZG1,4FC1 TURBO | 87/11~88/10 | Transmission REAR COVER |
| 03907 6905 | 8-97033-673-0 | | FARGO WFR,WFS,NFR,NFS | 89/11~96/ | Engine VALVE STEM SEAL |
| 03907 2069 | 8-94340-317-0 | 38 x 49.2 x 9 | FARGO WFR VAN 4FC1 TURBO | 85/12~87/10 | Transmission REAR COVER |
| 03907 6925 | 8-94223-026-0 | 35 x 49.2 x 12.5 | FARGO WFR 4ZC1,4FC1,WITHOUT TURBO | 87/11~88/10 | Transmission REAR COVER |
| 03907 3413 | 8-94224-173-0 | 48 x 62 x 7 x 9 | FARGO WFR EXCEPT 51FV,51FB | 81/1~82/4 | Wheel Hub FRONT |
| 03907 4701 | 8-94223-026-0 | 35 x 49.2 x 12.5 | FARGO WFR# | 81/1~85/11 | Transmission REAR COVER |
| 03907 3329 | 8-94121-539-0 | 40 x 74 x 10 x 19 | FARGO WFR,WFS | 83/2~90/11 | Final Drive PINION (REAR) |
| 03907 2409 | 8-94318-909-0 | 48 x 70 x 12 | FARGO WFR,WFS,NFR,NFS | 81/1~96/ | Wheel Hub REAR OUTER |
| 03907 3473 | 8-94318-910-0 | 33 x 55 x 9.5 | FARGO WFR,WFS,NFR,NFS | 81/1~96/ | Wheel Hub REAR INNER |
| 03907 4393 | 8-94240-603-0 | 48 x 64 x 14 | FARGO WFS,NFS(4WD) | 83/11~96/ | Wheel Hub FRONT KNUCKLE |
| 03907 5037 | 8-94258-825-2 | 57 x 79 x 21 | FARGO WFS,NFS(4WD) | 83/11~96/ | Wheel Hub FRONT |
| 03907 6309 | 8-94169-621-0 | 50 x 70 x 7 x 9.5 | FARGO WFR#,NFR | 82/5~96/ | Wheel Hub FRONT |
| 03907 4617 | 8-94169-621-0 | 50 x 70 x 7 x 9.5 | FARGO WFR 51FV,51FB | 82/1~82/4 | Wheel Hub FRONT |
| 03907 6269 | 8-94223-026-0 | 35 x 49.2 x 12.5 | FARGO WFR WAGON WITHOUT TURBO | 85/12~87/10 | Transmission REAR COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5889 | 8-94413-975-0 | 19 x 32 x 8.5 | FARGO WFR,WFS,NFR,NFS | 85/12~96/ | Steering WORM SHAFT |
| 03907 4441 | 8-94208-522-0 | | FARGO WFR,WFS ALL | 81/1~88/10 | Engine VALVE STEM SEAL |
| 03907 4765 | 8-97025-206-0 | 95 x 118 x 8.5 | FARGO WFR,NFR,NFS 4ZC1 | 88/11~96/ | Engine CRANK SHAFT REAR |
| 03907 3869 | 8-94235-369-0 | 95 x 118 x 10 | FARGO WFR,WFS,NFR,NFS 4FC1,4FG1 | 88/11~96/ | Engine CRANK SHAFT REAR |
| 03907 3081 | 8-94235-369-0 | 95 x 118 x 10 | FARGO WFR,WFS ALL | 81/1~88/10 | Engine CRANK SHAFT REAR |
| 03907 2505 | 8-97080-562-0 | 40 x 56 x 7 | FARGO WFR,WFS,NFR,NFS ALL | 8/1~96/ | Engine CRANK SHAFT FRONT |
| 03907 7021 | 8-94369-516-0 | 23 x 40 x 7.5 | FARGO WFR,NFR,NFS 4ZC1 | 85/12~96/ | Engine OIL PUMP |
| 03907 1813 | 8-94343-237-0 | 40 x 62 x 10 x 15.5 | FARGO WFS,NFS | 83/11~96/ | Transfer SIDE CASE |
| 03907 1725 | 8-97252-710-0 | 28 x 47 x 8 | FARGO WFR,WFS,NFR,NFS 4FC1,4FD1,4FG1 | 85/12~96/ | Engine CAM SHAFT |
| 03907 3701 | 9-09724-003-0 | 40 x 74 x 10 | FARGO WFR,WFS | 81/1~83/1 | Final Drive PINION (REAR) |
| 03907 4345 | 5-09625-034-0 | 17 x 30 x 7 | FARGO WFR,WFS | 81/1~85/11 | Steering WORM SHAFT |
| 03907 4841 | 9-09924-261-0 | 31.7 x 48 x 8 | FARGO WFR,WFS,NFR,NFS | 81/1~96/ | Steering SECTOR SHAFT |
| 03907 3865 | 8-97080-848-0 | 40 x 74 x 10 x 18.5 | FARGO WFR,WFS,NFR,NFS | 92/6~96/ | Final Drive PINION (REAR) |
| 03907 5293 | 8-97011-675-0 | 40 x 74 x 10 x 18.5 | FARGO NFR,NFS | 89/11~92/5 | Final Drive PINION (REAR) |
| 03907 6885 | 8-97011-675-0 | 40 x 74 x 10 x 18.5 | FARGO WFR,WFS | 90/12~92/5 | Final Drive PINION (REAR) |
| 03907 2777 | 8-94121-539-0 | 40 x 74 x 10 x 19 | FARGO NFR,NFS | 88/9~89/10 | Final Drive PINION (REAR) |
| 03907 1577 | 8-94389-593-1 | 30 x 45 x 8 | FARGO WFR,NFR,NFS 4ZC1 | 85/12~96/ | Engine CAM SHAFT |
| 03907 1597 | 8-94239-173-0 | 28 x 40 x 8 | FARGO WFR,WFS,NFR,NFS 4FC1,4FD1,4FG1 | 81/1~96/ | Engine OIL PUMP |
| 03907 3113 | 8-94227-475-0 | 20 x 31 x 7 | FARGO WFR,WFS 4FC1,4FD1,4FG1 | 85/12~96/ | Engine INJECTION PUMP |
| 03907 1557 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (4T~5T) FSD,FSR 15.5 INCH FINAL | 99/5~ | Wheel Hub REAR OUTER |
| 03907 6961 | 8-97255-187-0 | 42 x 57 x 7 | FORWARD (4T~5T) FRR,FRD,NRR MZZ T/M (SMOOTHER) | 02/1~ | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 7141 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (4T~5T) FRS,FSS EXCEPT LOW DECK (4WD) | 99/5~ | Wheel Hub REAR INNER |
| 03907 2361 | 9-09924-511-0 | 50 x 106 x 11 | FORWARD (4T~5T) TY,TR,SBR | 70/~75/ | Wheel Hub REAR OUTER |
| 03907 2921 | 1-09625-331-0 | 56 x 122 x 10.5 | FORWARD (4T~5T) SCR,SDR,FCR,FDR | 76/~84/ | Wheel Hub REAR OUTER |
| 03907 2293 | 1-09625-331-0 | 56 x 122 x 10.5 | FORWARD (4T~5T) FRR,FRD,NRR | 84/2~ | Wheel Hub REAR OUTER |
| 03907 3553 | 1-09625-331-0 | 56 x 122 x 10.5 | FORWARD (4T~5T) FSR,FSD ALL | 84/2~99/2 | Wheel Hub REAR OUTER |
| 03907 4101 | 1-09625-331-0 | 56 x 122 x 10.5 | FORWARD (4T~5T) FSR,FSD 14.5 INCH FINAL | 99/2~ | Wheel Hub REAR OUTER |
| 03907 3225 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (4T~5T) SCS,FRS,FSS ALL (4WD) | 80/5~99/5 | Wheel Hub REAR INNER |
| 03907 5021 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (4T~5T) SCS,FRS,FSS ALL (4WD) | 80/5~99/5 | Wheel Hub REAR OUTER |
| 03907 2065 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | FORWARD (4T~5T) FRS,FSS LOW DECK (4WD0 | 99/5~ | Wheel Hub REAR INNER |
| 03907 5853 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (4T~5T) FRS,FSS EXCEPT LOW DECK (4WD) | 99/5~ | Wheel Hub REAR OUTER |
| 03907 3785 | 1-09625-502-0 | 40 x 55 x 9 | FORWARD (4T~5T) SBR,SCR,SDR,FCR,FDR | 73/~84/ | Transmission FRONT COVER |
| 03907 1193 | 1-09625-502-0 | 40 x 55 x 9 | FORWARD (4T~5T) FRR,FRD,FSR,FSD MBG T/M | 84/2~93/12 | Transmission FRONT COVER |
| 03907 5333 | 1-09625-502-0 | 40 x 55 x 9 | FORWARD (4T~5T) FRR,NRR | 86/9~94/5 | Transmission FRONT COVER |
| 03907 6469 | 1-09625-502-0 | 40 x 55 x 9 | FORWARD (4T~5T) SCS,FRS,FSS | 84/5~93/6 | Transmission FRONT COVER |
| 03907 3589 | 1-09625-565-0 | 40 x 55 x 7 | FORWARD (4T~5T) FRR,FRD,FSR,FSD MBG,MBJ T/M | 94/1~ | Transmission FRONT COVER |
| 03907 6061 | 1-09625-565-0 | 40 x 55 x 7 | FORWARD (4T~5T) FSR MBJ T/M | 93/7~ | Transmission FRONT COVER |
| 03907 2725 | 1-09625-331-0 | 56 x 122 x 10.5 | FORWARD (4T~5T) FRS,FSS LOW DECK (4WD) | 99/5~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2997 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (4T~5T) SCS,FRS,FSS ALL (4WD) | 80/5~99/5 | Wheel Hub FRONT |
| 03907 7233 | 8-94396-609-2 | | FORWARD (4T~5T) 6HH1 | 90/4~99/2 | Engine VALVE STEM SEAL |
| 03907 3313 | 9-09924-438-0 | 65 x 102 x 8 x 15 | FORWARD (4T~5T) TY,TR | 70/~72/ | Wheel Hub FRONT |
| 03907 5453 | 8-94396-609-2 | | FORWARD (4T~5T) 6HE1,6HA1 | 90/4~ | Engine VALVE STEM SEAL |
| 03907 5829 | 9-09924-564-0 | 70 x 102 x 8.5 x 16 | FORWARD (4T~5T) SBR | 73/~75/ | Wheel Hub FRONT |
| 03907 2469 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | FORWARD (4T~5T) SBR | 76/~84/ | Wheel Hub FRONT |
| 03907 3581 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | FORWARD (4T~5T) SCR,SDR,FCR,FDR | 77/~84/ | Wheel Hub FRONT |
| 03907 4533 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | FORWARD (4T~5T) FRR,FRD,NRR | 84/2~ | Wheel Hub FRONT |
| 03907 1913 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (4T~5T) FSD,FSR 15.5 INCH FINAL | 99/5~ | Wheel Hub REAR INNER |
| 03907 6089 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | FORWARD (4T~5T) FSR,FSD EXCEPT HEAVY DUTY TYPE | 99/2~ | Wheel Hub FRONT |
| 03907 2729 | 8-97253-550-0 | 40 x 54 x 7 | FORWARD (4T~5T) FRR,FRD,NRR MZZ T/M (EXCEPT SMOOTHER) | 02/1~ | Transmission FRONT COVER |
| 03907 4993 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (4T~5T) FRS,FSS EXCEPT LOW DECK (4WD) | 99/5~ | Wheel Hub FRONT |
| 03907 6921 | 1-09625-628-0 | 106 x 122 x 10 | FORWARD (4T~5T) FRS,FSS LOW DECK (4WD) | 99/5~ | Wheel Hub FRONT |
| 03907 1533 | 1-09625-639-0 | 125 x 150 x 14 | FORWARD (4T~5T) FSD,FSR HEAVY DUTY TYPE | 99/2~ | Wheel Hub FRONT |
| 03907 3101 | 9-09924-437-0 | 90 x 127 x 12 x 36 | FORWARD (4T~5T) TY,TR,SBR | 70/~75/ | Wheel Hub REAR INNER |
| 03907 1441 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | FORWARD (4T~5T) SCR,SDR,FCR,FDR | 76/~84/ | Wheel Hub REAR INNER |
| 03907 1721 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | FORWARD (4T~5T) FRR,FDR,NRR | 84/2~ | Wheel Hub REAR INNER |
| 03907 1637 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | FORWARD (4T~5T) FSR,FSD ALL | 84/2~99/2 | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2925 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | FORWARD (4T~5T) FSR,FSD 14.5 INCH FINAL | 99/2~ | Wheel Hub REAR INNER |
| 03907 5377 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | FORWARD (4T~5T) FSR,FSD ALL | 84/2~99/2 | Wheel Hub FRONT |
| 03907 3021 | 1-09625-320-0 | 100 x 135 x 10 | FORWARD (4T~5T) 6BG1 WITH P.T.O | 85/7~86/8 | Engine CRANK SHAFT REAR |
| 03907 6329 | 8-97602-378-0 | 104 x 137 x 13 | FORWARD (4T~5T) FRR,FSR,FSD,NRR 6HE1,6HH1,6HK1,6HA1 | 90/4~ | Engine CRANK SHAFT FRONT |
| 03907 6373 | 1-09625-506-0 | 120 x 153 x 15 | FORWARD (4T~5T) FRR 6SA1 | 84/2~94/ | Engine CRANK SHAFT FRONT |
| 03907 5845 | 1-09625-498-0 | 40 x 56 x 6.5 | FORWARD (4T~5T) FRR,FRD,FSR,FSD MLD T/M | 84/2~93/12 | Transmission FRONT COVER |
| 03907 5577 | 5-09625-052-0 | 100 x 135 x 15 | FORWARD (4T~5T) TR | 70/~72/ | Engine CRANK SHAFT REAR |
| 03907 3309 | 1-09625-565-0 | 40 x 55 x 7 | FORWARD (4T~5T) FRR,NRR,FRS,FSS | 93/7~01/12 | Transmission FRONT COVER |
| 03907 3781 | 9-09924-356-0 | 105 x 135 x 14 | FORWARD (4T~5T) 6BD1 TURBO | 81/~84/ | Engine CRANK SHAFT REAR |
| 03907 3661 | 1-09625-438-0 | 60 x 82 x 12 | FORWARD (4T~5T) FSR,FRR,FSD,FRD,FRR,NRR 6BG1 | 87/11~94/ | Engine CRANK SHAFT FRONT |
| 03907 2489 | 1-09625-439-1 | 105 x 135 x 15 | FORWARD (4T~5T) 6BD1,6BG1 WITHOUT P.T.O | 87/10~94/ | Engine CRANK SHAFT REAR |
| 03907 4537 | 8-97329-780-0 | 109 x 137 x 13 | FORWARD (4T~5T) NRR,FRR 6HL1 | 99/2~ | Engine CRANK SHAFT FRONT |
| 03907 2865 | 1-09625-402-0 | 100 x 135 x 14 | FORWARD (4T~5T) 6BG1 WITH P.T.O | 86/9~90/ | Engine CRANK SHAFT REAR |
| 03907 3241 | 1-09625-443-0 | 120 x 150 x 15 | FORWARD (4T~5T) 6SA1 | 84/2~94/ | Engine CRANK SHAFT REAR |
| 03907 3397 | 8-94393-011-0 | 104 x 139 x 13 | FORWARD (4T~5T) 6HE1 | 90/4~92/1 | Engine CRANK SHAFT REAR |
| 03907 1853 | 8-97602-379-0 | 104 x 139 x 10 | FORWARD (4T~5T) 6HE1,6HH1,6HL1,6HA1 | 92/1~ | Engine CRANK SHAFT REAR |
| 03907 7237 | 5-12569-001-0 | | FORWARD (4T~5T) 6BB1,6BD1,6BG1 | 80/~94/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4269 | 1-12569-009-0 | | FORWARD (4T~5T) 6SA1 | 84/~94/ | Engine VALVE STEM SEAL |
| 03907 4353 | 8-97120-307-0 | | FORWARD (4T~5T) 6HL1,6HH1,6HK1 | 99/2~ | Engine VALVE STEM SEAL |
| 03907 1477 | 9-09924-356-0 | 105 x 135 x 14 | FORWARD (4T~5T) 6BD1,6BG1 WITHOUT P.T.O | 84/2~87/10 | Engine CRANK SHAFT REAR |
| 03907 4549 | 1-09625-505-0 | 60 x 77 x 12 | FORWARD (4T~5T) FRD,FSR,FSD MBG,MBJ T/M | 90/3~ | Transmission REAR COVER |
| 03907 4665 | 1-09625-497-0 | 48 x 62 x 9 | FORWARD (4T~5T) FRR,FRD,FSR,FSD MLD T/M | 94/1~ | Transmission FRONT COVER |
| 03907 5481 | 5-09625-052-0 | 100 x 135 x 15 | FORWARD (4T~5T) 6BB1,6BD1,6BF1 WITHOUT TURBO | 73/~84/ | Engine CRANK SHAFT REAR |
| 03907 1617 | 1-09625-173-0 | 60 x 77 x 12 | FORWARD (4T~5T) FRR,FRD,FSR,FSD,NRR MBG T/M | 84/2~90/2 | Transmission REAR COVER |
| 03907 1285 | 1-09625-319-0 | 60 x 82 x 10 | FORWARD (4T~5T) SCS,FRS,FSS 6BD1,6BG1 | 84/5~87/10 | Engine CRANK SHAFT FRONT |
| 03907 5025 | 1-09625-505-0 | 60 x 77 x 12 | FORWARD (4T~5T) FRR,FRS,FSS,NRR MBG,MBJ T/M | 90/3~ | Transmission REAR COVER |
| 03907 2149 | 1-09625-513-0 | 65 x 84 x 9 | FORWARD (4T~5T) FRR,FRD,FSR,FSD MLD T/M | 84/2~ | Transmission REAR COVER |
| 03907 3013 | 8-97253-551-1 | 58 x 75 x 8.5 | FORWARD (4T~5T) FRR,NRR,FRD MZZ T/M | 02/1~ | Transmission REAR COVER |
| 03907 6649 | 1-09625-173-0 | 60 x 77 x 12 | FORWARD (4T~5T) TY,TR,SBR | 70/~75/ | Final Drive PINION |
| 03907 5817 | 1-09625-319-0 | 60 x 82 x 10 | FORWARD (4T~5T) FSR,FRR,FSD,FRD,FRR,NRR 6BD1,6BG1 | 84/2~87/10 | Engine CRANK SHAFT FRONT |
| 03907 2993 | 1-09625-484-0 | 60 x 103 x 12 x 20 | FORWARD (4T~5T) FRR,FRD,FSR,FSD EXCEPT GEAR RATIO 41/6,40/13,39/11 | 84/2~ | Final Drive PINION |
| 03907 4869 | 1-09625-484-0 | 60 x 103 x 12 x 20 | FORWARD (4T~5T) NRR | 86/9~ | Final Drive PINION |
| 03907 6769 | 1-09625-484-0 | 60 x 103 x 12 x 20 | FORWARD (4T~5T) SCS,FRS,FSS | 84/2~ | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6345 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | FORWARD (4T~5T) FRR,FRD,FSR,FSD GEAR RATIO 41/6,40/13,39/11 | 84/2~ | Final Drive PINION |
| 03907 2705 | 8-94373-765-0 | 60 x 82 x 12 | FORWARD (4T~5T) TR | 70/~72/ | Engine CRANK SHAFT FRONT |
| 03907 3105 | 8-94373-765-0 | 60 x 82 x 12 | FORWARD (4T~5T) SBR,SCR,SDR,FCR,FDR 6BB1,6BD1 | 73/~84/ | Engine CRANK SHAFT FRONT |
| 03907 6133 | 1-09625-484-0 | 60 x 103 x 12 x 20 | FORWARD (4T~5T) SBR,SCR,SDR,FCR,FDR | 76/~84/ | Final Drive PINION |
| 03907 3709 | 1-09625-173-0 | 60 x 77 x 12 | FORWARD (4T~5T) TY,TR,SBR,SCR,SDR,FCR, FDR | 70/~84/ | Transmission REAR COVER |
| 03907 2541 | 9-09924-356-0 | 105 x 135 x 14 | FORWARD (6T~7T) JTR 6BD1,6BG1 WITHOUT P.T.O | 84/2~87/10 | Engine CRANK SHAFT REAR |
| 03907 5365 | 1-09625-439-1 | 105 x 135 x 15 | FORWARD (6T~7T) JTR 6BD1,6BG1 WITHOUT P.T.O | 87/11~95/ | Engine CRANK SHAFT REAR |
| 03907 1581 | 1-09625-443-0 | 120 x 150 x 15 | FORWARD (6T~7T) FTR 6SA1 | 84/2~95/ | Engine CRANK SHAFT REAR |
| 03907 4085 | 5-12569-001-0 | | FORWARD (6T~7T) 6B# | 80/~95/ | Engine VALVE STEM SEAL |
| 03907 3061 | 8-94393-011-0 | 104 x 139 x 13 | FORWARD (6T~7T) FTR 6HE1 | 90/4~92/1 | Engine CRANK SHAFT REAR |
| 03907 5045 | 1-12569-009-0 | | FORWARD (6T~7T) 6SA1 | 84/2~95/ | Engine VALVE STEM SEAL |
| 03907 1261 | 8-97120-307 | | FORWARD (6T~7T) 6HH1,6HK1,6HL1 | 99/5~ | Engine VALVE STEM SEAL |
| 03907 5245 | 8-94396-609 | | FORWARD (6T~7T) 6HH1 | 90/4~99/5 | Engine VALVE STEM SEAL |
| 03907 5717 | 8-97329-780-0 | 109 x 137 x 13 | FORWARD (6T~7T) FTR 6HL1 | 99/5~ | Engine CRANK SHAFT FRONT |
| 03907 6529 | 8-94396-609 | | FORWARD (6T~7T) 6HE1,6HA1 | 90/4~ | Engine VALVE STEM SEAL |
| 03907 6605 | 1-09625-173-0 | 60 x 77 x 12 | FORWARD (6T~7T) JBR,JCR,JDR | 76/~84/ | Transmission REAR COVER |
| 03907 6361 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (6T~7T) JBR,JCR,JDR | 76/~84/ | Wheel Hub REAR OUTER |
| 03907 3165 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (6T~7T) FTR 15.5 INCH FINAL | 84/2~99/6 | Wheel Hub REAR OUTER |
| 03907 5489 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (6T~7T) FTR ALL | 99/7~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5629 | 9-09924-470-0 | 64 x 132.5 x 13 | FORWARD (6T~7T) FTS (4WD) | 95/12~ | Wheel Hub REAR OUTER |
| 03907 4741 | 1-09625-331-0 | 56 x 122 x 10.5 | FORWARD (6T~7T) FTR 14.5 INCH FINAL | 86/3~99/6 | Wheel Hub REAR OUTER |
| 03907 1385 | 1-09625-502-0 | 40 x 55 x 9 | FORWARD (6T~7T) JBR,JCR,JDR | 76/~84/ | Transmission FRONT COVER |
| 03907 6929 | 1-09625-502-0 | 40 x 55 x 9 | FORWARD (6T~7T) FTR MBG T/M | 84/2~94/2 | Transmission FRONT COVER |
| 03907 6157 | 1-09625-565-0 | 40 x 55 x 7 | FORWARD (6T~7T) FTR,FTS MBG,MBJ T/M | 94/3~ | Transmission FRONT COVER |
| 03907 2873 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (6T~7T) FTS (4WD) | 95/12~ | Wheel Hub REAR INNER |
| 03907 2389 | 1-09625-497-0 | 48 x 62 x 9 | FORWARD (6T~7T) FTR,FTS MLD T/M | 92/7~ | Transmission FRONT COVER |
| 03907 2949 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (6T~7T) FTR ALL | 99/7~ | Wheel Hub REAR INNER |
| 03907 4021 | 1-09625-173-0 | 60 x 77 x 12 | FORWARD (6T~7T) FTR MBG T/M | 84/2~90/3 | Transmission REAR COVER |
| 03907 2633 | 1-09625-505-0 | 60 x 77 x 12 | FORWARD (6T~7T) FTR MBG,MBJ T/M | 90/4~ | Transmission REAR COVER |
| 03907 2165 | 1-09625-513-0 | 65 x 84 x 9 | FORWARD (6T~7T) FTR,FTS MLD T/M | 84/2~ | Transmission REAR COVER |
| 03907 1165 | 1-09625-173-0 | 60 x 77 x 12 | FORWARD (6T~7T) JBR | 76/~77/ | Final Drive PINION |
| 03907 4457 | 1-09625-484-0 | 60 x 103 x 12 x 20 | FORWARD (6T~7T) JCR,JDR 14.5 INCH FINAL | 76/~84/ | Final Drive PINION |
| 03907 4597 | 1-09625-484-0 | 60 x 103 x 12 x 20 | FORWARD (6T~7T) FTR 14.5 INCH FINAL | 84/2~99/6 | Final Drive PINION |
| 03907 3001 | 5-09625-052-0 | 100 x 135 x 15 | FORWARD (6T~7T) JBR,JCR,JDR WITHOUT TURBO | 76/~84/ | Engine CRANK SHAFT REAR |
| 03907 6957 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | FORWARD (6T~7T) JCR,JDR 15.5 INCH FINAL | 76/~84/ | Final Drive PINION |
| 03907 4037 | 9-09924-356-0 | 105 x 135 x 14 | FORWARD (6T~7T) JCR,JDR TURBO | 81/~84/ | Engine CRANK SHAFT REAR |
| 03907 1641 | 1-09625-498-0 | 40 x 56 x 6.5 | FORWARD (6T~7T) FTR MLD T/M | 84/2~92/6 | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4553 | 1-09625-129-0 | 85 x 128 x 11 x 21 | FORWARD (6T~7T) FTR | 84/2~91/10 | Wheel Hub FRONT |
| 03907 1493 | 8-97602-378-0 | 104 x 137 x 13 | FORWARD (6T~7T) FTR,FTS 6HE1,6HH1,6HK1,6HA1 | 90/4~ | Engine CRANK SHAFT FRONT |
| 03907 4277 | 1-09625-451-0 | 120 x 153 x 15 | FORWARD (6T~7T) FTR 6SA1 | 84/2~95/ | Engine CRANK SHAFT FRONT |
| 03907 5281 | 1-09625-438-0 | 60 x 82 x 12 | FORWARD (6T~7T) FTR 6BD1,6BG1 | 87/11~95/ | Engine CRANK SHAFT FRONT |
| 03907 3813 | 1-09625-319-0 | 60 x 82 x 10 | FORWARD (6T~7T) FTR 6BD1,6BG1 | 84/2~87/10 | Engine CRANK SHAFT FRONT |
| 03907 5189 | 8-94373-765-0 | 60 x 82 x 12 | FORWARD (6T~7T) JBR,JCR,JDR 6BB1,6BD1,6BF1 | 76/~84/ | Engine CRANK SHAFT FRONT |
| 03907 1429 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | FORWARD (6T~7T) FTS (4WD) | 95/12~ | Final Drive PINION |
| 03907 2745 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | FORWARD (6T~7T) FTR ALL | 99/7~ | Final Drive PINION |
| 03907 1929 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | FORWARD (6T~7T) FTR 15.5 INCH FINAL | 84/2~99/6 | Final Drive PINION |
| 03907 5217 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | FORWARD (6T~7T) FTR 14.5 INCH FINAL | 86/3~99/6 | Wheel Hub REAR INNER |
| 03907 3253 | 1-09625-129-0 | 85 x 128 x 11 x 21 | FORWARD (6T~7T) JCR,JDR | 79/~84/ | Wheel Hub FRONT |
| 03907 5793 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (6T~7T) FTS(4WD) | 95/12~ | Wheel Hub FRONT |
| 03907 2789 | 1-09625-041-0 | 120 x 140 x 10.5 | FORWARD (6T~7T) FTR | 91/11~ | Wheel Hub FRONT |
| 03907 4769 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (6T~7T) JBR,JCR,JDR | 76/~84/ | Wheel Hub REAR INNER |
| 03907 6849 | 8-97602-379-0 | 104 x 139 x 13 | FORWARD (6T~7T) FTR,FSR 6HE1,6HH1,6HK1,6HL1,6HA1 | 92/1~ | Engine CRANK SHAFT REAR |
| 03907 1225 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | FORWARD (6T~7T) FTR 15.5 INCH FINAL | 84/2~99/6 | Wheel Hub REAR INNER |
| 03907 3057 | 9-09924-407-0 | 76 x 115 x 13 x 21 | FORWARD (6T~7T) JBR,JCR | 76/~78/ | Wheel Hub FRONT |
| 03907 4661 | 8-94389-593-1 | 30 x 45 x 8 | GEMINI (FWD) JT 4XE1,4XF1 | 88/1~93/ | Engine CAM SHAFT |
| 03907 5205 | 8-94459-593-0 | 50 x 64 x 6.5 | GEMINI (FWD) JT150,600 TURBO,JT190 | 86/4~90/ | Wheel Hub FRONT OUTER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1985 | 8-94137-233-0 | 42 x 64 x 6 | GEMINI (FWD) JT150,600 WITHOUT TURBO | 85/3~90/ | Wheel Hub FRONT OUTER |
| 03907 4761 | 8-97025-798-1 | 50 x 68 x 6.5 | GEMINI (FWD) JT151,191,641,221 | 90/2~93/ | Wheel Hub FRONT INNER |
| 03907 2017 | 8-94108-663-0 | 50 x 64 x 6.5 | GEMINI (FWD) JT150,190,600 | 85/3~90/ | Wheel Hub FRONT INNER |
| 03907 2093 | 8-94144-614-0 | 38 x 52 x 7 x 12 | GEMINI (FWD) JT150,190,600 | 85/3~90/ | Wheel Hub REAR |
| 03907 4133 | 8-94475-250-0 | 42 x 60 x 6 | GEMINI (FWD) JT151(4XC1) | 90/2~93/ | Wheel Hub FRONT OUTER |
| 03907 2653 | 8-94110-559-0 | | GEMINI (FWD) JT 4XC1,4EC1,4XE1 | 85/3~87/12 | Engine VALVE STEM SEAL |
| 03907 6789 | 8-97072-405-0 | 35 x 55 x 15 | GEMINI (FWD) JT# | 85/3~93/ | Transaxle Assy DRIVE SHAFT (L & R) |
| 03907 4413 | 8-94324-158-0 | | GEMINI (FWD) JT 4XC1,4EE1,4XF1 | 90/2~93/ | Engine VALVE STEM SEAL |
| 03907 3725 | 8-94379-067-0 | 28 x 44 x 6 | GEMINI (FWD) JT# | 85/3~93/ | Transaxle Assy INPUT SHAFT |
| 03907 2413 | 8-94110-559-0 | | GEMINI (FWD) JT 4XC1,4EC1 | 88/1~90/1 | Engine VALVE STEM SEAL |
| 03907 2701 | 8-94464-555-0 | 50 x 60 x 6 | GEMINI (FWD) JT191(4XE1),221(4XF1),641 (4EE1) | 90/2~93/ | Wheel Hub FRONT OUTER |
| 03907 4189 | 8-94471-619-1 | 87 x 100 x 7.5 | GEMINI (FWD) JT 4EC1 | 85/7~90/ | Engine CRANK SHAFT REAR |
| 03907 2565 | 8-94327-063-1 | 87 x 100 x 8.5 | GEMINI (FWD) JT 4XE1,4XF1 | 90/2~ | Engine CRANK SHAFT REAR |
| 03907 5705 | 8-94129-884-0 | 87 x 100 x 8 | GEMINI (FWD) JT 4XC1,4XE1 | 85/3~90/ | Engine CRANK SHAFT REAR |
| 03907 4193 | 8-94468-654-1 | 40 x 52 x 6 | GEMINI (FWD) JT 4EC1,4EE1 | 85/7~93/ | Engine CRANK SHAFT FRONT |
| 03907 6293 | 8-94239-332-1 | 18 x 32 x 6 | GEMINI (FWD) JT 4EC1,4EE1 | 85/3~93/ | Engine OIL PUMP |
| 03907 6117 | 8-94334-860-0 | 32 x 44 x 6 | GEMINI (FWD) JT 4XC1,4XE1 | 85/3~93/ | Engine OIL PUMP |
| 03907 5637 | 8-94482-157-0 | 40 x 52 x 6 | GEMINI (FWD) JT 4XC1,4EC1,4EE1 | 85/3~93/ | Engine CAM SHAFT |
| 03907 5105 | 8-94324-158-0 | | GEMINI (FWD) JT 4XE1 | 88/1~93/ | Engine VALVE STEM SEAL |
| 03907 3705 | 8-94326-441-0 | 27 x 43 x 9 | GEMINI (RWD) PF# | 75/~87/ | Transmission FRONT COVER |
| 03907 5617 | 8-94216-107-0 | 38 x 52 x 14 | GEMINI (RWD) PF# | 75/~87/ | Wheel Hub FRONT |
| 03907 1345 | 8-97049-145-0 | 50 x 68 x 9 | GEMINI (RWD) PF50,PF60 G161Z,G180# | 75/~87/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4557 | 8-97080-562-0 | 40 x 56 x 7 | GEMINI (RWD) PF60 4FB1 | 79/11~87/ | Engine CRANK SHAFT FRONT |
| 03907 6629 | 5-09625-036-0 | 82 x 105 x 13 | GEMINI (RWD) PF50,PF60 G161Z,G180# | 75/~87/ | Engine CRANK SHAFT REAR |
| 03907 4473 | 8-94235-369-0 | 95 x 118 x 10 | GEMINI (RWD) PF60 | 79/11~87/ | Engine CRANK SHAFT REAR |
| 03907 6881 | 8-94208-522-0 | | GEMINI (RWD) PF50,PF60 G161Z,G180# | 75/~87/ | Engine VALVE STEM SEAL |
| 03907 6445 | 8-94239-173-0 | 28 x 40 x 8 | GEMINI (RWD) PF60 4FB1 | 79/11~87/ | Engine OIL PUMP |
| 03907 3637 | 8-94223-026-0 | 35 x 49.2 x 12.5 | GEMINI (RWD) PF# | 75/~87/ | Transmission REAR COVER |
| 03907 2445 | 8-97252-710-0 | 28 x 47 x 8 | GEMINI (RWD) PF60 4FB1 | 79/11~87/ | Engine CAM SHAFT |
| 03907 6709 | 8-11065-079-0 | 52 x 72 x 10 | GEMINI (RWD) PF# | 75/~87/ | Final Drive PINION |
| 03907 6637 | 8-94208-522-0 | | PIAZZA JR 4ZC1,G200(SOHC) | 81/5~90/ | Engine VALVE STEM SEAL |
| 03907 4309 | 8-94235-369-0 | 95 x 118 x 10 | PIAZZA JR 4ZC1 | 84/5~90/ | Engine CRANK SHAFT REAR |
| 03907 1605 | 8-94389-593-1 | 30 x 45 x 8 | PIAZZA JR 4ZC1 | 84/5~90/ | Engine CAM SHAFT |
| 03907 5681 | 5-09625-036-0 | 82 x 105 x 13 | PIAZZA JR G200 | 81/5~88/4 | Engine CRANK SHAFT REAR |
| 03907 2097 | 8-97080-562-0 | 40 x 56 x 7 | PIAZZA JR 4ZC1 | 84/5~90/ | Engine CRANK SHAFT FRONT |
| 03907 2761 | 8-94369-516-0 | 23 x 40 x 7.5 | PIAZZA JR 4ZC1 | 84/5~90/ | Engine OIL PUMP |
| 03907 5121 | 8-94121-539-0 | 40 x 74 x 10 x 19 | PIAZZA JR 5LINK SUS. | 88/5~90/ | Final Drive PINION |
| 03907 7209 | 8-11065-079-0 | 52 x 72 x 10 | PIAZZA JR EXCEPT 5LINK SUS. | 81/5~90/ | Final Drive PINION |
| 03907 3517 | 8-94340-317-0 | 38 x 49.2 x 9 | PIAZZA JR | 87/9~90/ | Transmission REAR COVER |
| 03907 2597 | 8-94223-026-0 | 35 x 49.2 x 12.5 | PIAZZA JR | 81/5~87/7 | Transmission REAR COVER |
| 03907 2861 | 8-94326-441-0 | 27 x 43 x 9 | PIAZZA JR | 81/5~90/ | Transmission FRONT COVER |
| 03907 1321 | 8-94450-127-0 | 45 x 62 x 9 | PIAZZA JR 5LINK SUS. | 88/5~90/ | Wheel Hub REAR |
| 03907 2533 | 8-94326-440-0 | 40 x 52 x 62 x 14.5 | PIAZZA JR | 81/5~90/ | Wheel Hub FRONT |
| 03907 4009 | 8-97049-145-0 | 50 x 68 x 9 | PIAZZA LR G200 | 81/5~88/4 | Engine CRANK SHAFT FRONT |
| 03907 5865 | 8-97046-705-2 | 38 x 49.2 x 8 x 12 | PICK UP / CHEV.LUV TFR,TFS | 91/5~ | Transmission REAR COVER |
| 03907 5725 | 8-97046-703-2 | 44 x 64 x 9 x 11.5 | PICK UP / CHEV.LUV TFS | 89/10~ | Transfer FLANGE |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6129 | 8-97080-562-0 | 40 x 56 x 7 | PICK UP / CHEV.LUV TFR,TFS 4JB1 | 89/10~ | Engine CAM SHAFT |
| 03907 2645 | 5-09625-022-0 | 42 x 55 x 9 | PICK UP / CHEV.LUV TFR,TFS C223 | 88/5~89/9 | Engine CAM SHAFT |
| 03907 4957 | 5-09625-022-0 | 42 x 55 x 9 | PICK UP / CHEV.LUV KB C190,C223 | 81/~88/ | Engine CAM SHAFT |
| 03907 6301 | 9-09924-261-0 | 31.7 x 48 x 8 | PICK UP / CHEV.LUV KB#,TFR,TFS | 81/~ | Steering SECTOR SHAFT |
| 03907 3049 | 8-94408-084-0 | 45 x 78 x 11 x 19 | PICK UP / CHEV.LUV TFR,TFS | 89/10~ | Final Drive PINION (REAR) |
| 03907 5593 | 9-09724-003-0 | 40 x 74 x 10 | PICK UP / CHEV.LUV KB#,TFR,TFS | 83/~89/9 | Final Drive PINION (REAR) |
| 03907 5149 | 9-09724-003-0 | 40 x 74 x 10 | PICK UP / CHEV.LUV KB# | 76/~82/ | Final Drive PINION (REAR) |
| 03907 5649 | 8-94318-520-0 | 40 x 74 x 9.5 x 15 | PICK UP / CHEV.LUV TFS | 89/10~ | Final Drive PINION (FRONT) |
| 03907 5305 | 8-94340-317-0 | 38 x 49.2 x 9 | PICK UP / CHEV.LUV TFS | 88/5~89/9 | Transfer CASE |
| 03907 6453 | 5-09625-002-1 | 35 x 65 x 13 | PICK UP / CHEV.LUV KB 4WD | 79/~88/ | Final Drive PINION (FRONT) |
| 03907 6085 | 5-09625-083-0 | 65 x 84 x 9 | PICK UP / CHEV.LUV TFR,TFS C223 | 88/5~89/9 | Engine CRANK SHAFT FRONT |
| 03907 3805 | 8-94343-237-0 | 40 x 62 x 10 x 15.5 | PICK UP / CHEV.LUV TFS | 88/8~89/9 | Transfer FLANGE |
| 03907 4177 | 5-09625-059-0 | 40 x 62 x 12 | PICK UP / CHEV.LUV TFS | 88/5~88/7 | Transfer FLANGE |
| 03907 6173 | 8-94224-173-0 | 48 x 62 x 7 x 9 | PICK UP / CHEV.LUV KB2#,3#...2WD | 76/~88/ | Wheel Hub FRONT |
| 03907 5013 | 8-94433-718-0 | 50 x 67 x 9 | PICK UP / CHEV.LUV TFR 2WD | 88/5~ | Wheel Hub FRONT |
| 03907 6465 | 8-94169-621-0 | 50 x 70 x 7 x 9.5 | PICK UP / CHEV.LUV KB4#,5#...4WD | 79/~81/ | Wheel Hub FRONT |
| 03907 2753 | 8-94227-048-1 | 54 x 70 x 7 x 9.5 | PICK UP / CHEV.LUV KB4#,5#...4WD | 82/~88/ | Wheel Hub FRONT |
| 03907 1889 | 5-09625-064-0 | 48 x 64 x 67 x 13 | PICK UP / CHEV.LUV KB4#,5#...4WD | 79/~81/2 | Wheel Hub FRONT KNUCKLE |
| 03907 3945 | 8-94407-725-0 | 53 x 69 x 10.5 x 15.5 | PICK UP / CHEV.LUV TFS 4WD | 88/5~ | Wheel Hub FRONT KNUCKLE |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 7169 | 5-09625-049-2 | 28 x 53 x 9.7 x 14.5 | PICK UP / CHEV.LUV TFS 4WD | 88/5~89/9 | Wheel Hub FRONT AXLE SHAFT |
| 03907 5273 | 5-09625-002-1 | 35 x 65 x 13 | PICK UP / CHEV.LUV TFS | 88/5~89/9 | Final Drive PINION (FRONT) |
| 03907 6733 | 5-09625-092-0 | 39.5 x 60 x 10 | PICK UP / CHEV.LUV TFR,TFS | 89/10~ | Wheel Hub REAR INNER |
| 03907 4593 | 8-94340-317-0 | 38 x 49.2 x 9 | PICK UP / CHEV.LUV KB 4WD | 79/~88/ | Transfer CASE |
| 03907 4093 | 8-94366-610-0 | 30 x 61 x 9 x 13.5 | PICK UP / CHEV.LUV TFS 4WD | 89/10~ | Wheel Hub FRONT AXLE SHAFT |
| 03907 6833 | 8-94340-317-0 | 38 x 49.2 x 9 | PICK UP / CHEV.LUV TFR,TFS | 88/5~91/4 | Transmission REAR COVER |
| 03907 2529 | 8-94223-026-0 | 35 x 49.2 x 12.5 | PICK UP / CHEV.LUV KB 2WD | 76/~88/ | Transmission REAR COVER |
| 03907 3025 | 8-97046-699-0 | 27 x 43 x 7 | PICK UP / CHEV.LUV TFR,TFS | 89/10~ | Transmission FRONT COVER |
| 03907 6001 | 8-94326-441-0 | 27 x 43 x 9 | PICK UP / CHEV.LUV KB,TFR,TFS | 76/~89/9 | Transmission FRONT COVER |
| 03907 6773 | 9-09724-022-0 | 52 x 72 x 7.5 | PICK UP / CHEV.LUV TFR,TFS | 89/10~ | Wheel Hub REAR OUTER |
| 03907 5373 | 8-94318-909-0 | 48 x 70 x 12 | PICK UP / CHEV.LUV TFR,TFS | 88/5~89/9 | Wheel Hub REAR OUTER |
| 03907 4697 | 8-94318-909-0 | 48 x 70 x 12 | PICK UP / CHEV.LUV KB# | 76/~88/ | Wheel Hub REAR OUTER |
| 03907 5837 | 8-97049-145-0 | 50 x 68 x 9 | PICK UP / CHEV.LUV KB G161,G180,G190 | 76/~80/ | Engine CRANK SHAFT FRONT |
| 03907 6909 | 5-09625-059-0 | 40 x 62 x 12 | PICK UP / CHEV.LUV KB 4WD | 79/~88/ | Transfer FLANGE |
| 03907 6425 | 5-09625-083-0 | 65 x 84 x 9 | PICK UP / CHEV.LUV KB C190,C223 | 81/~88/ | Engine CRANK SHAFT FRONT |
| 03907 5641 | 8-94318-910-0 | 33 x 55 x 9.5 | PICK UP / CHEV.LUV TFR,TFS | 885/~89/9 | Wheel Hub REAR INNER |
| 03907 2081 | 8-94318-910-0 | 33 x 55 x 9.5 | PICK UP / CHEV.LUV KB# | 76/~88/ | Wheel Hub REAR INNER |
| 03907 4529 | 8-97120-307-0 | | PICK UP / CHEV.LUV C190,C223,4JB1 | 81/~ | Engine VALVE STEM SEAL |
| 03907 5133 | 8-94208-522-0 | | PICK UP / CHEV.LUV G161,G180 | 76/~80/ | Engine VALVE STEM SEAL |
| 03907 5929 | 8-94235-369-0 | 95 x 118 x 10 | PICK UP / CHEV.LUV TFR,TFS 4JB1 | 89/10~ | Engine CRANK SHAFT REAR |
| 03907 2589 | 5-09625-036-0 | 82 x 105 x 13 | PICK UP / CHEV.LUV TFR,TFS C223 | 88/5~89/9 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6221 | 5-09625-036-0 | 82 x 105 x 13 | PICK UP / CHEV.LUV KB G161,G180,C190,C223 | 76/~88/ | Engine CRANK SHAFT REAR |
| 03907 4249 | 8-97049-145-0 | 50 x 68 x 9 | PICK UP / CHEV.LUV TFR,TFS 4JB1 | 89/10~ | Engine CRANK SHAFT FRONT |
| 03907 1777 | 8-97046-701-0 | 42 x 62 x 8 | PICK UP / CHEV.LUV TFS | 89/10~ | Transfer CASE |
| 03907 6489 | 8-94240-603-0 | 48 x 64 x 14 | PICK UP / CHEV.LUV KB4#,5#...4WD | 81/3~88/ | Wheel Hub FRONT KNUCKLE |
| 03907 1153 | 8-94407-711-0 | 59 x 75 x 10 | PICK UP / CHEV.LUV TFS 4WD | 88/5~ | Wheel Hub FRONT |
| 03907 1753 | 1-09625-578-1 | 78 x 97 x 13 | TRACTOR EXR,EXD,EXZ MAG,MAL T/M | 83/8~03/ | Transmission REAR COVER |
| 03907 5065 | 1-09625-041-0 | 120 x 140 x 10.5 | TRACTOR EXR,EXD,EXZ,EXY | 83/8~ | Wheel Hub FRONT |
| 03907 3545 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRACTOR EXR,EXD,EXZ,EXY | 83/8~ | Wheel Hub FRONT INNER |
| 03907 3913 | 1-09625-444-0 | 78 x 163 x 16 | TRACTOR EXR,EXD,EXZ,EXY | 83/8~ | Wheel Hub FRONT OUTER |
| 03907 4485 | 1-09625-497-0 | 48 x 62 x 9 | TRACTOR EXR,EXD,EXZ | 83/8~89/6 | Transmission FRONT COVER |
| 03907 1821 | 1-09625-562-0 | 54 x 69 x 9 | TRACTOR EXR,EXD,EXZ,EXY MAF,MAG,MAL,MJA,MJD, MJT | 89/7~ | Transmission FRONT COVER |
| 03907 3561 | 1-09625-624-0 | 60 x 75 x 9 | TRACTOR EXR,EXD,EXZ,EXY MJX16 T/M | 00/6~ | Transmission FRONT COVER |
| 03907 4233 | 1-09625-579-1 | 74 x 97 x 13 | TRACTOR EXR,EXD,EXZ MAB,MAF T/M | 83/8~94/ | Transmission REAR COVER |
| 03907 2405 | 1-09625-359-0 | 80 x 100 x 12 | TRACTOR EXR,EXD,EXZ,EXY MJA,MJD,MJT T/M | 92/10~94/6 | Transmission REAR COVER |
| 03907 4285 | 1-09625-616-0 | 86 x 150 x 10 x 40 | TRACTOR EXR,EXD 18.5INCH DIFF. (W6#) | 00/6~ | Final Drive PINION REARWARD |
| 03907 1861 | 1-09625-556-2 | 118 x 148 x 20 | TRACTOR 6WA1,6WF1,6WG1 | 95/9~ | Engine CRANK SHAFT FRONT |
| 03907 5597 | 1-12569-019-1 | | TRACTOR 6SD1 | 00/6~ | Engine VALVE STEM SEAL |
| 03907 2297 | 1-41349-180-0 | 82 x 140 x 19 | TRACTOR EXR,EXD, 19.5INCH DIFF. (W7#) | 00/6~03/ | Final Drive PINION REARWARD |
| 03907 6385 | 1-12569-019-1 | | TRACTOR 6TE1 | 00/12~ | Engine VALVE STEM SEAL |
| 03907 5821 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRACTOR EXR,EXD 18.5 INCH DIFF.(W3#,W4#) | 00/6~ | Final Drive PINION REARWARD |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4757 | 1-12569-019-1 | | TRACTOR 8TD1,10TD1 | 97/4~ | Engine VALVE STEM SEAL |
| 03907 3189 | 1-12569-019-1 | | TRACTOR 10P#,12P# | 92/10~ | Engine VALVE STEM SEAL |
| 03907 7045 | 1-09625-541-2 | 114 x 150 x 17 | TRACTOR 6SD1 | 00/6~ | Engine CRANK SHAFT REAR |
| 03907 4041 | 1-41219-029-0 | 82 x 140 x 19 | TRACTOR EXR,EXD 19.5INCH DIFF.(W5#,W6#) | 00/6~03/ | Final Drive PINION REARWARD |
| 03907 5385 | 1-12569-020-0 | | TRACTOR 6WA1,6WF1,6WG1 | 00/6~ | Engine VALVE STEM SEAL |
| 03907 5757 | 1-09625-577-1 | 80 x 100 x 13 | TRACTOR EXR,EXD,EXZ,EXY MJA,MJD,MJT T/M | 94/7~ | Transmission REAR COVER |
| 03907 2893 | 1-41219-029-0 | 82 x 140 x 19 | TRACTOR EXR,EXD 19.5 INCH DIFF. | 95/6~00/ | Final Drive PINION REARWARD |
| 03907 6145 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRACTOR EXZ,EXY 17.5 INCH DIFF. | 00/6~ | Final Drive PINION REARWARD |
| 03907 3265 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRACTOR EXZ,EXY 16.5 INCH DIFF. | 97/4~ | Final Drive PINION REARWARD |
| 03907 2181 | 1-12569-019-1 | | TRACTOR 6WA1,6WF1,6WG1 | 95/9~00/5 | Engine VALVE STEM SEAL |
| 03907 1245 | 1-41349-180-0 | 82 x 140 x 19 | TRACTOR EXR,EXD 19.5INCH DIFF. (W5#,W6#,W7#) | 03/7~ | Final Drive PINION REARWARD |
| 03907 5841 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRACTOR EXR,EXD 17.5 INCH DIFF. | 00/6~ | Final Drive PINION REARWARD |
| 03907 5361 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRACTOR EXR,EXD,EXZ 17.5 INCH,18.5INCH DIFF. | 95/6~00/ | Final Drive PINION REARWARD |
| 03907 2581 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRACTOR EXR,EXD,EXZ | 92/10~95/ | Final Drive PINION REARWARD |
| 03907 7177 | 1-09625-323-0 | 86 x 127 x 16 x 25 | TRACTOR EXZ | 92/10~ | Final Drive PINION FORWARD |
| 03907 2265 | 1-09625-625-0 | 104 x 126 x 13 | TRACTOR EXR,EXD,EXZ,EXY MJX16 T/M | 00/6~ | Transmission REAR COVER |
| 03907 7017 | 1-09625-540-3 | 114 x 153 x 17.5 | TRACTOR 6SD1 | 00/6~ | Engine CRANK SHAFT FRONT |
| 03907 6405 | 1-09625-559-0 | 139 x 171 x 19 | TRACTOR 6TE1 | 00/12~ | Engine CRANK SHAFT REAR |
| 03907 1417 | 1-09625-557-1 | 118 x 148 x 20 | TRACTOR 6WA1,6WF1,6WG1 | 95/9~ | Engine CRANK SHAFT REAR |
| 03907 6893 | 1-09625-525-2 | 111 x 153 x 16.5 | TRACTOR 10PD,12PD,10PE,12PE | 93/3~00/ | Engine CRANK SHAFT REAR |
| 03907 6585 | 1-09625-506-0 | 120 x 153 x 15 | TRACTOR 10PD.12PD | 92/10~93/2 | Engine CRANK SHAFT FRONT |
| 03907 5961 | 1-09625-524-3 | 111 x 153 x 16.5 | TRACTOR 10PD,12PD,10PE,12PE | 93/3~00/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1681 | 1-09625-524-3 | 111 x 153 x 16.5 | TRACTOR 8TD1,10TD1 | 97/4~ | Engine CRANK SHAFT FRONT |
| 03907 1565 | 1-09625-524-3 | 111 x 153 x 16.5 | TRACTOR 6TE1 | 00/12~ | Engine CRANK SHAFT FRONT |
| 03907 5729 | 1-09625-507-1 | 120 x 153 x 17 | TRACTOR 10PD,12PD | 92/10~93/2 | Engine CRANK SHAFT REAR |
| 03907 1997 | 1-09625-559-0 | 139 x 171 x 19 | TRACTOR 8TD1,10TD1 | 97/4~ | Engine CRANK SHAFT REAR |
| 03907 1805 | 8-94121-539-0 | 40 x 74 x 10 x 19 | TROOPER / BIG HORN UBS 4ZC1,C223 | 86/11~88/10 | Final Drive PINION (REAR) |
| 03907 6429 | 8-97080-562-0 | 40 x 56 x 7 | TROOPER / BIG HORN 4JB1 UBS55,4JG2 UBS69 | 87/8~98/ | Engine CAM SHAFT |
| 03907 4481 | 8-97049-145-0 | 50 x 68 x 9 | TROOPER / BIG HORN 4JB1,4JG2 | 83/8~93/7 | Engine CRANK SHAFT FRONT |
| 03907 1185 | 5-09625-083-0 | 65 x 84 x 9 | TROOPER / BIG HORN C223 | 81/9~88/10 | Engine CRANK SHAFT FRONT |
| 03907 1357 | 8-94369-516-0 | 23 x 40 x 7.5 | TROOPER / BIG HORN UBS 4ZC1,4ZE1 | 85/6~91/ | Engine OIL PUMP |
| 03907 1901 | 8-97252-710-0 | 28 x 47 x 8 | TROOPER / BIG HORN 4JX1 UBS73 | 98/2~ | Engine CAM SHAFT |
| 03907 3649 | 8-94389-593-1 | 30 x 45 x 8 | TROOPER / BIG HORN 6VD1 UBS25,6VE1 UBS26 | 91/12~ | Engine CAM SHAFT |
| 03907 6337 | 8-94389-593-1 | 30 x 45 x 8 | TROOPER / BIG HORN 4ZC1 UBS12,4ZE1 UBS17 | 86/11~91/11 | Engine CAM SHAFT |
| 03907 5537 | 5-09625-022-0 | 42 x 55 x 9 | TROOPER / BIG HORN C223 UBS52 | 81/9~88/10 | Engine CAM SHAFT |
| 03907 4649 | 8-94227-475-0 | 20 x 31 x 7 | TROOPER / BIG HORN UBS 4JB1,4JG2 | 87/8~97/ | Engine INJECTION PUMP |
| 03907 4777 | 8-97221-758-0 | 44 x 78 x 11 x 18 | TROOPER / BIG HORN UBS# | 98/2~ | Final Drive PINION (REAR) |
| 03907 1333 | 8-97179-937-0 | 48 x 80 x 7 x 20.5 | TROOPER / BIG HORN UBS# | 98/2~ | Final Drive PINION (REAR) |
| 03907 6985 | 8-97049-145-0 | 50 x 68 x 9 | TROOPER / BIG HORN G200 UBS13,4ZC1 | 83/6~86/10 | Engine CRANK SHAFT FRONT |
| 03907 6517 | 8-94408-084-0 | 45 x 78 x 11 x 19 | TROOPER / BIG HORN UBS 4JB1 | 87/8~88/10 | Final Drive PINION (REAR) |
| 03907 3769 | 5-09625-036-0 | 82 x 105 x 13 | TROOPER / BIG HORN C223 | 86/11~88/10 | Engine CRANK SHAFT REAR |
| 03907 3905 | 8-94121-539-0 | 40 x 74 x 10 x 19 | TROOPER / BIG HORN UBS# | 83/2~86/10 | Final Drive PINION (REAR) |
| 03907 4129 | 8-94408-084-0 | 45 x 78 x 11 x 19 | TROOPER / BIG HORN UBS# | 88/11~98/1 | Final Drive PINION (REAR) |
| 03907 5993 | 8-94235-369-0 | 95 x 118 x 10 | TROOPER / BIG HORN 4JG2 | 91/12~93/7 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2237 | 8-94324-158-1 | | TROOPER / BIG HORN 6VD1,6VE1 | 91/12~ | Engine VALVE STEM SEAL |
| 03907 1265 | 8-94428-466-0 | | TROOPER / BIG HORN 4ZC1,4ZE1 | 87/1~90/8 | Engine VALVE STEM SEAL |
| 03907 3365 | 8-94208-522-0 | | TROOPER / BIG HORN 4ZC1 | 86/11~86/12 | Engine VALVE STEM SEAL |
| 03907 4985 | 8-97120-307-0 | | TROOPER / BIG HORN C223,4JB1,4JG2 | 81/9~ | Engine VALVE STEM SEAL |
| 03907 5653 | 8-97071-561-1 | 95 x 118 x 14 | TROOPER / BIG HORN 4JX1 | 98/2~ | Engine CRANK SHAFT REAR |
| 03907 5277 | 8-97071-561-1 | 95 x 118 x 14 | TROOPER / BIG HORN 4JG2 | 93/8~98/ | Engine CRANK SHAFT REAR |
| 03907 4541 | 8-97071-560-1 | 50 x 68 x 11.5 | TROOPER / BIG HORN 4JG2 | 93/8~91/11 | Engine CRANK SHAFT FRONT |
| 03907 1933 | 8-97025-206-0 | 95 x 118 x 8.5 | TROOPER / BIG HORN 4ZE1 | 88/11~91/11 | Engine CRANK SHAFT REAR |
| 03907 7253 | 8-97049-145-0 | 50 x 68 x 9 | TROOPER / BIG HORN 4JX1 | 98/2~ | Engine CRANK SHAFT FRONT |
| 03907 3261 | 8-94235-369-0 | 95 x 118 x 10 | TROOPER / BIG HORN 4ZC1,4JB1 | 86/11~91/11 | Engine CRANK SHAFT REAR |
| 03907 1201 | 8-97033-673-0 | | TROOPER / BIG HORN 4ZE1 | 90/9~91/11 | Engine VALVE STEM SEAL |
| 03907 6617 | 5-09625-036-0 | 82 x 105 x 13 | TROOPER / BIG HORN C223,G200,4ZC1 | 81/9~86/10 | Engine CRANK SHAFT REAR |
| 03907 6837 | 9-09724-003-0 | 40 x 74 x 10 | TROOPER / BIG HORN UBS# | 81/9~83/1 | Final Drive PINION (REAR) |
| 03907 4053 | 8-97023-373-0 | 42 x 55 x 6 | TROOPER / BIG HORN 6VD1,6VE1 | 91/12~ | Engine CRANK SHAFT FRONT |
| 03907 2141 | 8-97080-562-0 | 40 x 56 x 7 | TROOPER / BIG HORN 4ZC1,4ZE1 | 86/11~91/11 | Engine CRANK SHAFT FRONT |
| 03907 5857 | 8-94381-233-0 | 95 x 118 x 11 | TROOPER / BIG HORN 6VD1,6VE1 | 91/12~ | Engine CRANK SHAFT REAR |
| 03907 1957 | 8-94318-520-2 | 40 x 74 x 9.5 x 15 | TROOPER / BIG HORN UBS ALL | 88/11~ | Final Drive PINION (FRONT) |
| 03907 1965 | 8-94441-817-1 | 48 x 70 x 13 x 19 | TROOPER / BIG HORN UBS ALL | 88/11~ | Wheel Hub REAR OUTER |
| 03907 3429 | 8-94441-817-1 | 48 x 70 x 13 x 19 | TROOPER / BIG HORN UBS 4JB1 | 87/8~88/10 | Wheel Hub REAR OUTER |
| 03907 1137 | 8-94318-909-0 | 48 x 70 x 12 | TROOPER / BIG HORN UBS 4ZC1,C223 | 86/11~88/10 | Wheel Hub REAR OUTER |
| 03907 5425 | 8-94318-909-0 | 48 x 70 x 12 | TROOPER / BIG HORN UBS ALL | 81/9~86/10 | Wheel Hub REAR OUTER |
| 03907 6049 | 8-94178-277-0 | 51 x 72 x 10 | TROOPER / BIG HORN UBS ALL | 88/11~02/ | Wheel Hub REAR INNER |
| 03907 3741 | 8-94178-277-0 | 51 x 72 x 10 | TROOPER / BIG HORN UBS 4JB1 | 87/8~88/10 | Wheel Hub REAR INNER |
| 03907 1237 | 8-94326-441-0 | 27 x 43 x 9 | TROOPER / BIG HORN UBS# | 81/9~87/7 | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1337 | 8-94318-910-0 | 33 x 55 x 9.5 | TROOPER / BIG HORN UBS ALL | 81/9~86/10 | Wheel Hub REAR INNER |
| 03907 1801 | 8-94318-910-0 | 33 x 55 x 9.5 | TROOPER / BIG HORN UBS 4ZC1,C223 | 86/11~88/10 | Wheel Hub REAR INNER |
| 03907 2517 | 8-94366-610-0 | 30 x 61 x 9 x 13.5 | TROOPER / BIG HORN UBS 4ZE1,4JB1 | 87/8~89/1 | Wheel Hub FRONT AXLE SHAFT INNER |
| 03907 3997 | 5-09625-049-2 | 28 x 53 x 9.7 x 14.5 | TROOPER / BIG HORN UBS 4ZC1,C223 | 86/11~88/10 | Wheel Hub FRONT AXLE SHAFT INNER |
| 03907 2829 | 8-97123-691-0 | 53 x 69 x 9.2 x 17.5 | TROOPER / BIG HORN UBS# | 95/2~ | Wheel Hub FRONT KNUCKLE |
| 03907 6245 | 8-94407-725-0 | 53 x 69 x 10.5 x 15.5 | TROOPER / BIG HORN UBS# | 86/11~95/1 | Wheel Hub FRONT KNUCKLE |
| 03907 2005 | 8-94240-603-0 | 48 x 65 x 14 | TROOPER / BIG HORN UBS# | 81/9~86/10 | Wheel Hub FRONT KNUCKLE |
| 03907 4589 | 8-97173-692-0 | | TROOPER / BIG HORN 4JX1 | 98/2~ | Engine VALVE STEM SEAL |
| 03907 4793 | 8-94227-048-1 | 54 x 70 x 7 x 9.5 | TROOPER / BIG HORN UBS# | 81/9~86/10 | Wheel Hub FRONT |
| 03907 4825 | 8-94407-711-0 | 59 x 75 x 10 | TROOPER / BIG HORN UBS# | 86/11~ | Wheel Hub FRONT |
| 03907 6937 | 8-97046-703-2 | 44 x 64 x 9 x 11.5 | TROOPER / BIG HORN UBS 4JB1,4ZE1 | 87/8~91/12 | Transfer SIDE CASE |
| 03907 7277 | 5-09625-002-1 | 35 x 65 x 13 | TROOPER / BIG HORN UBS 4ZC1,C223 | 86/11~88/10 | Final Drive PINION (FRONT) |
| 03907 1513 | 8-94366-610-0 | 30 x 61 x 9 x 13.5 | TROOPER / BIG HORN UBS ALL | 89/2~ | Wheel Hub FRONT AXLE SHAFT INNER |
| 03907 2285 | 8-97046-699-0 | 27 x 43 x 7 | TROOPER / BIG HORN UBS# | 87/8~98/1 | Transmission FRONT COVER |
| 03907 2113 | 5-09625-002-1 | 35 x 65 x 13 | TROOPER / BIG HORN UBS ALL | 81/9~86/10 | Final Drive PINION (FRONT) |
| 03907 6065 | 8-94318-520-2 | 40 x 74 x 9.5 x 15 | TROOPER / BIG HORN UBS 4JB1 | 87/8~88/10 | Final Drive PINION (FRONT) |
| 03907 4245 | 8-97129-041-0 | 42 x 62 x 8 | TROOPER / BIG HORN UBS# | 91/12~ | Transfer INPUT SHAFT |
| 03907 3733 | 5-09625-059-0 | 40 x 62 x 12 | TROOPER / BIG HORN UBS 4ZC1,C223 | 86/11~88/10 | Transfer SIDE CASE |
| 03907 2721 | 5-09625-059-0 | 40 x 62 x 12 | TROOPER / BIG HORN UBS ALL | 81/9~86/10 | Transfer SIDE CASE |
| 03907 3953 | 8-97046-707-2 | 40 x 58 x 9 | TROOPER / BIG HORN UBS MTM,ATM | 91/12~ | Transmission REAR COVER |
| 03907 2573 | 8-97165-084-0 | 32 x 53 x 7 | TROOPER / BIG HORN UBS# | 98/2~ | Transmission FRONT COVER |
| 03907 2425 | 8-94340-317-0 | 38 x 49.2 x 9 | TROOPER / BIG HORN UBS MTM | 87/8~91/4 | Transmission REAR COVER |
| 03907 1129 | 8-97129-040-0 | 41 x 62 x 12 | TROOPER / BIG HORN UBS# | 91/12~ | Transfer REAR OUTPUT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6441 | 8-97046-705-2 | 38 x 492 x 8 x 12 | TROOPER / BIG HORN UBS MTM | 91/5~91/11 | Transmission REAR COVER |
| 03907 2813 | 8-97129-040-0 | 41 x 62 x 12 | TROOPER / BIG HORN UBS# | 91/12~ | Transfer CASE FRONT |
| 03907 5405 | 8-94340-317-0 | 38 x 49.2 x 9 | TROOPER / BIG HORN UBS MTM ALL | 81/9~86/10 | Transfer CASE |
| 03907 1389 | 8-94340-317-0 | 38 x 49.2 x 9 | TROOPER / BIG HORN UBS MTM 4ZC1,C223 | 87/8~88/10 | Transfer CASE |
| 03907 1157 | 8-97046-701-2 | 42 x 62 x 8 | TROOPER / BIG HORN UBS MTM 4JB1 | 87/8~88/10 | Transfer CASE |
| 03907 2157 | 8-97046-701-2 | 42 x 62 x 8 | TROOPER / BIG HORN UBS ALL | 88/11~ | Transfer CASE |
| 03907 6333 | 9828-65111 | 65 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC303M,TC9# | 71/~79/8 | Transmission REAR COVER |
| 03907 6069 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN2P EA,EB,JA,JB | 92/5~ | Final Drive PINION |
| 03907 2641 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD) TC,FN,GN | 71/~ | Wheel Hub FRONT (FORWARD) |
| 03907 6645 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (2-2XD) TC3#...EXCEPT 303D,TC7#,9# | 71/~81/ | Final Drive PINION |
| 03907 5141 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2-2XD) TC303D,5# | 71/~81/ | Final Drive PINION |
| 03907 5801 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2-2XD) FN270AD,AM,FN63# | 81/5~83/ | Final Drive PINION |
| 03907 2805 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN27#...EXCEPT 270# | 81/5~89/ | Final Drive PINION |
| 03907 3569 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN28#...RT,RTN,TT,VTS | 82/7~89/ | Final Drive PINION |
| 03907 4745 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN60#,GN28# | 81/9~89/ | Final Drive PINION |
| 03907 3269 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN2K,GN1F,1P,2P | 89/12~95/3 | Final Drive PINION |
| 03907 3277 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN1K | 99/9~ | Transmission REAR COVER |
| 03907 4317 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN1P RT,RW,TT,VTS | 90/1~92/ | Final Drive PINION |
| 03907 4333 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN2P,GN2P HK06,07 T/M | 92/5~99/8 | Transmission REAR COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2473 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) EN270#,FN63# | 83/~89/ | Final Drive PINION |
| 03907 3929 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) FN28#...ST,UT,WTS | 82/7~89/ | Final Drive PINION |
| 03907 1609 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) FN1F,2F,1K | 90/1~92/4 | Final Drive PINION |
| 03907 4717 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) FN1P ST,SW,WTS,UT | 90/1~92/ | Final Drive PINION |
| 03907 3053 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (2-2XD) GN27# | 81/5~90/ | Final Drive PINION |
| 03907 5409 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (2-2XD) GN2K | 90/3~ | Final Drive PINION |
| 03907 1765 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2-2XD) FN1K,1V,2F,3F,4F | 92/5~ | Final Drive PINION |
| 03907 1925 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2-2XD) FN2P FA,FB,MA,MB | 92/5~ | Final Drive PINION |
| 03907 5869 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN1F | 92/5~95/3 | Final Drive PINION |
| 03907 4029 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) TC5# | 71/~81/ | Transmission REAR COVER |
| 03907 6553 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD) TC,FN,GN | 71/~ | Wheel Hub FRONT (REARWARD) |
| 03907 2369 | 9828-01130 | 146 x 170 x 18 | TRUCK (2-2XD) TC | 71/~81/ | Wheel Hub REAR INNER |
| 03907 4369 | 9828-01193 | 154 x 175 x 13 | TRUCK (2-2XD) FN,GN | 81/5~ | Wheel Hub REAR INNER |
| 03907 3425 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2-2XD) TC | 71/~81/ | Wheel Hub REAR OUTER |
| 03907 1341 | 9828-55113 | 55 x 72 x 9 | TRUCK (2-2XD) TC,FN,GN | 71/~ | Transmission FRONT COVER |
| 03907 5877 | 9828-65111 | 65 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC942 | 79/9~81/ | Transmission REAR COVER |
| 03907 1405 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC3#...EXCEPT 303M,TC7# | 71/~79/8 | Transmission REAR COVER |
| 03907 1757 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC3#,7#,922 | 79/9~81/ | Transmission REAR COVER |
| 03907 4273 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN2P,GN2P HK06,07 T/M | 99/9~ | Transmission REAR COVER |
| 03907 2809 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) FN28# | 82/7~83/11 | Transmission REAR COVER |
| 03907 6165 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2-2XD) FN2K,1F,GN2P | 95/4~ | Final Drive PINION |
| 03907 2501 | 9828-76101 | 76 x 164 x 14 | TRUCK (2-2XD) FN,GN | 81/5~ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4837 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN27#...7 SPEED T/M | 81/5~89/ | Transmission REAR COVER |
| 03907 2197 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN28# | 83/12~89/ | Transmission REAR COVER |
| 03907 1677 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN338,60#,63#,GN28# | 81/9~89/ | Transmission REAR COVER |
| 03907 3293 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN1F,1P,2K,GN1F,1P,2K | 89/10~ | Transmission REAR COVER |
| 03907 6005 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN1K,2F | 90/1~92/4 | Transmission REAR COVER |
| 03907 2689 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN2P,GN2P MJ06,07 T/M | 92/5~ | Transmission REAR COVER |
| 03907 7225 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN1K,1V,2F,3F | 92/5~99/8 | Transmission REAR COVER |
| 03907 4149 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) FN27#...6 SPEED T/M, GN27# | 81/5~89/ | Transmission REAR COVER |
| 03907 2525 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (2-2XD) SPG | 73/~78/ | Propeller Shaft CENTER BEARING (F) |
| 03907 4773 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) SRG SINGLE SPEED DIFF. | 75/~83/ | Final Drive PINION |
| 03907 1121 | 1-09625-359-0 | 80 x 100 x 12 | TRUCK (2-2XD) CXG MJA,MJB,MJC T/M | 83/8~94/6 | Transmission REAR COVER |
| 03907 2077 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (2-2XD) CXG,CYG MJA,MJB,MJC,MJD,MJT T/M | 94/7~ | Transmission REAR COVER |
| 03907 4981 | 1-09625-473-0 | 80 x 115 x 15 | TRUCK (2-2XD) CXG MAB10 T/M | 86/4~89/8 | Transmission REAR COVER |
| 03907 2781 | 1-09625-625-0 | 104 x 126 x 13 | TRUCK (2-2XD) CXG,CYG MJX12 T/M | 03/6~ | Transmission REAR COVER |
| 03907 7013 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (2-2XD) CXG,CYG MAG,MAH,MAL T/M | 83/8~ | Transmission REAR COVER |
| 03907 2441 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (2-2XD) SPG | 73/~78/ | Propeller Shaft CENTER BEARING |
| 03907 4889 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2-2XD) SRG,SSG571 | 80/1~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 7197 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2-2XD) CXG,CYG P60,90L PROPELLER SHAFT | 83/8~ | Propeller Shaft CENTER BEARING (F&R) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4109 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2-2XD) CXG,CYG P85,90 PROPELLER SHAFT | 83/8~00/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 4885 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2-2XD) CXG,CYG P105,115 PROPELLER SHAFT | 83/8~00/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 2125 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2-2XD) CXG,CYG P115 PROPELLER SHAFT | 00/4~ | Propeller Shaft CENTER BEARING (F) |
| 03907 5909 | 1-09625-622-0 | 86 x 106 x 14 | TRUCK (2-2XD) CXG,CYG P115 PROPELLER SHAFT | 00/4~ | Propeller Shaft CENTER BEARING |
| 03907 5673 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2-2XD) SSG 2 SPEED DIFF. | 80/1~83/ | Final Drive PINION |
| 03907 3849 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) SSG SINGLE SPEED DIFF. | 80/1~83/ | Final Drive PINION |
| 03907 5173 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY | 73/79/12 | Final Drive PINION |
| 03907 4165 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (2-2XD) SMG MAB5 T/M | 80/1~83/ | Wheel Hub REAR OUTER |
| 03907 6685 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2-2XD) CXG,CYG | 83/8~ | Wheel Hub FRONT (F&R) |
| 03907 7069 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY | 73/~79/ | Wheel Hub REAR INNER |
| 03907 5053 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2-2XD) SPG E120 (EXCEPT MIXER) | 73/~83/ | Engine CRANK SHAFT REAR |
| 03907 6777 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (2-2XD) SRG,SSG,SMG(EXCEPT MAB5 T/M) | 75/~83/ | Wheel Hub REAR INNER |
| 03907 1673 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) SMG EXCEPT TANK LORRY,CINTAINER | 80/1~83/ | Final Drive PINION |
| 03907 4681 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2-2XD) SMG MAB5 T/M | 80/1~83/ | Wheel Hub REAR INNER |
| 03907 2041 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2-2XD) CXG,CYG | 83/8~ | Wheel Hub REAR INNER |
| 03907 5997 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY | 73/~79/ | Wheel Hub REAR OUTER |
| 03907 6825 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2-2XD) SPG 540 TANK LORRY | 73/~79/ | Wheel Hub REAR INNER |
| 03907 5601 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (2-2XD) SPG 540 TANK LORRY | 73/~79/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3213 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (2-2XD) CXG MAB,MAF T/M | 83/8~94/ | Transmission REAR COVER |
| 03907 5437 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2-2XD) SRG,SSG,SMG(EXCEPT MAB5 T/M) | 80/1~83/ | Wheel Hub REAR OUTER |
| 03907 4113 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2-2XD) CXG,CYG | 83/8~ | Wheel Hub REAR OUTER |
| 03907 1181 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2-2XD) SPG,SRG | 73/~79/12 | Transmission FRONT COVER |
| 03907 1465 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2-2XD) SRG,SSG,SMG | 80/1~83/ | Transmission FRONT COVER |
| 03907 2233 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2-2XD) CXG | 83/8~89/8 | Transmission FRONT COVER |
| 03907 4453 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2-2XD) CXG,CYG | 89/9~ | Transmission FRONT COVER |
| 03907 3917 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2-2XD) SPG,SRG | 73/~79/12 | Transmission REAR COVER |
| 03907 1869 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (2-2XD) SRG,SSG,SMG | 80/1~83/ | Transmission REAR COVER |
| 03907 1981 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (2-2XD) SRG | 75/~79/12 | Wheel Hub REAR OUTER |
| 03907 4253 | 1-12569-009-0 | | TRUCK (2-2XD) 8P,10P,12P | 75,~91/6 | Engine VALVE STEM SEAL |
| 03907 6313 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (2-2XD) CXG,CYG 6SD1 | 94/12~ | Engine CRANK SHAFT FRONT |
| 03907 6201 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2-2XD) CXG 10P#,12P# | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03907 5709 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 8P# | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03907 1773 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2-2XD) CXG,CYG 8P#,10P#,12P# | 93/3~03/ | Engine CRANK SHAFT REAR |
| 03907 2917 | 1-09625-443-0 | 120 x 150 x 15 | TRUCK (2-2XD) CXG 6SD1 | 83/8~94/ | Engine CRANK SHAFT REAR |
| 03907 3017 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (2-2XD) CXG,CYG 6SD1 | 94/12~ | Engine CRANK SHAFT REAR |
| 03907 6081 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (2-2XD) CXG,CYG 6WA1,6WG1,6WF1 | 92/4~ | Engine CRANK SHAFT REAR |
| 03907 1837 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (2-2XD) SPG E120 (MIXER),CXG 6RB1 (MIXER) | 73/~92/ | Engine CRANK SHAFT REAR |
| 03907 3185 | 1-12569-013-0 | | TRUCK (2-2XD) 6R | 81/~92/ | Engine VALVE STEM SEAL |
| 03907 2085 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2-2XD) CXG 6RB1 (EXCEPT MIXER) | 83/8~86/3 | Engine CRANK SHAFT REAR |
| 03907 2337 | 1-12569-009-0 | | TRUCK (2-2XD) 6SD1 | 83/~94/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2545 | 1-12569-019-1 | | TRUCK (2-2XD) 6SD1 | 94/12 | Engine VALVE STEM SEAL |
| 03907 3433 | 1-12569-019-1 | | TRUCK (2-2XD) 8P,10P,12P | 91/7~ | Engine VALVE STEM SEAL |
| 03907 3501 | 1-12569-019-1 | | TRUCK (2-2XD) 6WA1,6WG1,6WF1 | 92/4~00/5 | Engine VALVE STEM SEAL |
| 03907 3497 | 1-12569-020-0 | | TRUCK (2-2XD) 6WG1,6WF1 | 00/6~ | Engine VALVE STEM SEAL |
| 03907 3237 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2-2XD) SPG,SRG,SSG,SMG | 73/~83/ | Wheel Hub FRONT (F&R) |
| 03907 6753 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (2-2XD) CXG 6RB1 (EXCEPT MIXER) | 86/4~92/ | Engine CRANK SHAFT REAR |
| 03907 2629 | 9-12569-072-0 | | TRUCK (2-2XD) E120 | 71/~83/ | Engine VALVE STEM SEAL |
| 03907 3481 | 1-09625-442-0 | 70 x 92 x 12 | TRUCK (2-2XD) CXG 6RB1 | 88/7~92/ | Engine CRANK SHAFT FRONT |
| 03907 2045 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2-2XD) SPG 540 TANK LORRY | 73/~79/12 | Final Drive PINION |
| 03907 1937 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2-2XD) SMG TANK LORRY,CONTAINER | 80/1~83/ | Final Drive PINION |
| 03907 5237 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2-2XD) CXG,CYG 16.5 INCH FINAL | 83/8~00/ | Final Drive PINION |
| 03907 5309 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2-2XD) CXG,CYG 17.5 INCH FINAL | 89/9~00/ | Final Drive PINION |
| 03907 2329 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2-2XD) CXG,CYG 18.5 INCH FINAL | 83/8~00/ | Final Drive PINION |
| 03907 1993 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2-2XD) CXG,CYG ALL | 00/4~ | Final Drive PINION |
| 03907 6725 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (2-2XD) SPG E120 | 73/~77/ | Engine CRANK SHAFT FRONT |
| 03907 2961 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2-2XD) CXG 8PC1,10PC1,12PC1 | 83/8~88/7 | Engine CRANK SHAFT REAR |
| 03907 6689 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2-2XD) CXG 6RB1 | 83/8~88/7 | Engine CRANK SHAFT FRONT |
| 03907 2485 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) CXG 17.5 INCH FINAL | 83/8~89/8 | Final Drive PINION |
| 03907 4605 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (2-2XD) SRG,SSG,SMG 8P,10P | 75/~83/ | Engine CRANK SHAFT FRONT |
| 03907 2433 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 6SD1,8PC1,10PC1,12PC1 | 83/8~88/7 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5789 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 10P#,12P# | 88/8~93/2 | Engine CRANK SHAFT FRONT |
| 03907 2273 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (2-2XD) CXG 8P# | 88/8~93/2 | Engine CRANK SHAFT FRONT |
| 03907 6945 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2-2XD) CXG,CYG 8P#,10P#,12P# | 93/3~03/ | Engine CRANK SHAFT FRONT |
| 03907 7273 | 1-09625-451-0 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 6SD1 | 88/8~94/ | Engine CRANK SHAFT FRONT |
| 03907 2769 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (2-2XD) CXG,CYG 6WA1,6WG1,6WF1 | 92/4~ | Engine CRANK SHAFT FRONT |
| 03907 6845 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2-2XD) SPG E120 | 77/~83/ | Engine CRANK SHAFT FRONT |
| 03907 3941 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (2-2XD) SPG,SSG,SMG 8P,10P,12P | 75/~83/ | Engine CRANK SHAFT REAR |
| 03907 7105 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (2XD-2, 2XD-4) SPM,TMK | 80/1~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 2845 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SSM,TMK | 71/~79/12 | Transmission REAR COVER |
| 03907 4513 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SRM,SSM,TMK | 80/1~83/ | Transmission REAR COVER |
| 03907 5657 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (2XD-2, 2XD-4) SPK,SMK,SQM,SMM,SHM, TMQ | 80/1~83/ | Transmission REAR COVER |
| 03907 3601 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (2XD-2, 2XD-4) CXM,CXK MAB,MAF T/M | 83/8~94/ | Transmission REAR COVER |
| 03907 1497 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL MAG,MAH,MAL,MAP T/M | 83/8~ | Transmission REAR COVER |
| 03907 6577 | 1-09625-359-0 | 80 x 100 x 12 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL MJ# T/M | 86/1~94/6 | Transmission REAR COVER |
| 03907 2037 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL MJA,MJD,MJT T/M | 94/7~ | Transmission REAR COVER |
| 03907 7109 | 1-09625-625-0 | 104 x 126 x 13 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL MJX12 T/M | 03/??? | Transmission REAR COVER |
| 03907 3949 | 9-12569-072-0 | | TRUCK (2XD-2, 2XD-4) E120 | 71/~83/ | Engine VALVE STEM SEAL |
| 03907 5357 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (2XD-2, 2XD-4) SPM,SPK | 71/~78/ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3777 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-2, 2XD-4) TMK,TMQ | 82/1~83/ | Transmission FRONT COVER |
| 03907 2025 | 1-12569-019-1 | | TRUCK (2XD-2, 2XD-4) 6TE1 | 00/12~ | Engine VALVE STEM SEAL |
| 03907 3745 | 1-12569-020-0 | | TRUCK (2XD-2, 2XD-4) 6WF1,6WG1 | 00/6~ | Engine VALVE STEM SEAL |
| 03907 1529 | 1-12569-019-1 | | TRUCK (2XD-2, 2XD-4) 6WA1,6WG1,6WF1 | 92/4~00/5 | Engine VALVE STEM SEAL |
| 03907 5985 | 1-12569-019-1 | | TRUCK (2XD-2, 2XD-4) 6SD1 | 94/10~ | Engine VALVE STEM SEAL |
| 03907 4585 | 1-12569-019-1 | | TRUCK (2XD-2, 2XD-4) 8PD1,10PD1,12PD1,8PE1,10 PE1 | 91/7~ | Engine VALVE STEM SEAL |
| 03907 4561 | 1-12569-009-0 | | TRUCK (2XD-2, 2XD-4) 6SD1 | 83/~94/ | Engine VALVE STEM SEAL |
| 03907 6781 | 1-12569-009-0 | | TRUCK (2XD-2, 2XD-4) 8P,10P,12P | 75/~91/6 | Engine VALVE STEM SEAL |
| 03907 2657 | 1-12569-013-0 | | TRUCK (2XD-2, 2XD-4) 6R | 81/~92/ | Engine VALVE STEM SEAL |
| 03907 4329 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (2XD-2, 2XD-4) SPM,SPK | 71/~78/ | Propeller Shaft CENTER BEARING (F) |
| 03907 3737 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-2, 2XD-4) SRK,SMK,SQM,SMM,SHM, TMQ,SMN | 80/1~83/ | Wheel Hub REAR OUTER (FORWARD) |
| 03907 6873 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2XD-2, 2XD-4) SRM,SPK,SQM,SSM,SSK | 80/1~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 5785 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SRM,SSM,TMK | 71/~83/ | Wheel Hub FRONT |
| 03907 3625 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-2, 2XD-4) SRK,SMK,SQM,SMM,SHM, TMQ,SMN | 80/1~83/ | Wheel Hub FRONT |
| 03907 7157 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL | 83/8~ | Wheel Hub FRONT |
| 03907 3697 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (2XD-2, 2XD-4) SPM,SRK,SRM,SSM,TMK | 71/~83/ | Wheel Hub REAR INNER (FORWARD) |
| 03907 3693 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (2XD-2, 2XD-4) SRK,SMK,SQM,SMM,SHM, TMQ,SMN | 80/1~83/ | Wheel Hub REAR INNER (FORWARD) |
| 03907 2377 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CYM,CYL | 83/8~ | Wheel Hub REAR INNER (FORWARD) |
| 03907 4817 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2XD-2, 2XD-4) SRK,SMK,SQM,SMM,SHM, TMQ,SMN | 80/1~83/ | Wheel Hub REAR INNER (REARWARD) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2877 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL | 89/7~ | Transmission FRONT COVER |
| 03907 3861 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SRM,SSM,TMK | 80/1~83/ | Wheel Hub REAR OUTER (FORWARD) |
| 03907 1269 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL | 83/8~89/6 | Transmission FRONT COVER |
| 03907 6933 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL | 83/8~ | Wheel Hub REAR OUTER (FORWARD) |
| 03907 1921 | 1-51389-005-0 | 155 x 185 x 13 | TRUCK (2XD-2, 2XD-4) SPM,SQM,SHM,SRM,SSM, SHK,SRK | 71/~83/ | Rear Suspesion TRUNNION SHAFT |
| 03907 6761 | 1-51389-005-0 | 155 x 185 x 13 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL | 83/8~ | Rear Suspesion TRUNNION SHAFT |
| 03907 5321 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SRM,SSM,TMK | 71/~79/12 | Transmission FRONT COVER |
| 03907 6677 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-2, 2XD-4) SPM,SRK | 80/1~83/ | Transmission FRONT COVER |
| 03907 5949 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-2, 2XD-4) TMK,TMQ | 80/5~81/12 | Transmission FRONT COVER |
| 03907 5017 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-2, 2XD-4) SRM,SPK,SSM,SQM,SMM, SHM | 80/1~83/ | Transmission FRONT COVER |
| 03907 7049 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL | 83/8~ | Wheel Hub REAR INNER (REARWARD) |
| 03907 4677 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SRM,SSM,TMK | 71/~79/12 | Wheel Hub REAR OUTER (FORWARD) |
| 03907 4961 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2XD-2, 2XD-4) SRM,SSM,SRK | 76/~83/ | Final Drive PINION |
| 03907 5049 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL 6SD1,8PC1,10PC1,12PC1 | 83/8~89/6 | Engine CRANK SHAFT FRONT |
| 03907 3509 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (2XD-2, 2XD-4) SRM,SRK,SSM 10P | 75/~83/ | Engine CRANK SHAFT FRONT |
| 03907 4581 | 1-09625-442-0 | 70 x 92 x 12 | TRUCK (2XD-2, 2XD-4) CXM 6RB1 | 89/7~92/ | Engine CRANK SHAFT FRONT |
| 03907 4725 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2XD-2, 2XD-4) SQM,SHM,SHK,TMQ,CXM 6R | 81/8~89/6 | Engine CRANK SHAFT FRONT |
| 03907 2797 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2XD-2, 2XD-4) SPM,SPK,TMK E120 | 77/~83/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4945 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (2XD-2, 2XD-4) SPM,SPK,TMK E120 | 71/~77/ | Engine CRANK SHAFT FRONT |
| 03907 2133 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2XD-2, 2XD-4) CXK,CXL | 89/7~ | Final Drive PINION |
| 03907 6989 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL | 83/8~ | Final Drive PINION |
| 03907 2821 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL 10PD1,12PD1 | 89/7~93/2 | Engine CRANK SHAFT FRONT |
| 03907 1161 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2XD-2, 2XD-4) SPM,SPK,TMK,SQM,SMM, SHM,SMK,TMQ | 80/1~83/ | Final Drive PINION |
| 03907 3761 | 1-09625-622-0 | 86 x 106 x 14 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL P115,P115L P/S | 99/11~ | Propeller Shaft CENTER BEARING |
| 03907 2349 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2XD-2, 2XD-4) SPM,SPK,TMK | 71/~79/12 | Final Drive PINION |
| 03907 3809 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL P115,P115L P/S | 99/11~ | Propeller Shaft CENTER BEARING (F) |
| 03907 4977 | 1-09625-621-0 | 81 x 103 x 16 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL P90 P/S | 99/11~ | Propeller Shaft CENTER BEARING |
| 03907 2933 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL P90 P/S | 99/11~ | Propeller Shaft CENTER BEARING (F) |
| 03907 3845 | 1-09625-559-0 | 139 x 171 x 19 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL 6TE1 | 0/12 | Engine CRANK SHAFT REAR |
| 03907 5917 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2XD-2, 2XD-4) SPM,SPK,SRM,SSM,TMK | 71/~83/ | Wheel Hub REAR INNER (REARWARD) |
| 03907 4833 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM P85,P90 P/S | 83/8~99/10 | Propeller Shaft CENTER BEARING (F&R) |
| 03907 2105 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL P60,P90L P/S | 83/8~ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 2193 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2XD-2, 2XD-4) CXK,CXL | 83/8~89/6 | Final Drive PINION |
| 03907 3257 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (2XD-2, 2XD-4) CXM 8PD1 | 89/7~93/2 | Engine CRANK SHAFT REAR |
| 03907 6421 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (2XD-2, 2XD-4) CXK,CXL,CXM,CYM,CYL 6SD1 | 94/10~ | Engine CRANK SHAFT REAR |
| 03907 5341 | 1-09625-443-0 | 120 x 150 x 15 | TRUCK (2XD-2, 2XD-4) CXM,CXK 6SD1 | 83/8~94/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6549 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CYM P105,P115 P/S | 86/1~99/10 | Propeller Shaft CENTER BEARING (F&R) |
| 03907 5769 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL 8PD1,10PD1,12PD1 | 93/3~94/ | Engine CRANK SHAFT FRONT |
| 03907 3305 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL 8PD1,10PD1,12PD1 | 93/3~94/ | Engine CRANK SHAFT REAR |
| 03907 3797 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL 10PD1,12PD1 | 89/7~93/2 | Engine CRANK SHAFT REAR |
| 03907 6041 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL 8PC1,10PC1,12PC1 | 83/8~89/6 | Engine CRANK SHAFT REAR |
| 03907 5521 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYM,CYL 6WA1,6WG1,6WF1 | 92/4~ | Engine CRANK SHAFT REAR |
| 03907 2905 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (2XD-2, 2XD-4) SRM,SRK,SSM,SSK 10P | 75/~83/ | Engine CRANK SHAFT REAR |
| 03907 3897 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (2XD-2, 2XD-4) CXM 6R (MIXER) | 83/8~89/6 | Engine CRANK SHAFT REAR |
| 03907 5113 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (2XD-2, 2XD-4) CXM 8PD1 | 89/7~93/2 | Engine CRANK SHAFT FRONT |
| 03907 1977 | 1-09625-451-0 | 120 x 153 x 15 | TRUCK (2XD-2, 2XD-4) CXM,CXK 6SD1 | 89/7~94/ | Engine CRANK SHAFT FRONT |
| 03907 3557 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2XD-2, 2XD-4) CXK,CXL,CXM,CYM,CYL 8PE1,10PE1,12PE1 | 94/10~ | Engine CRANK SHAFT REAR |
| 03907 3037 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (2XD-2, 2XD-4) CXM 6R (EXCEPT MIXER) | 86/1~92/ | Engine CRANK SHAFT REAR |
| 03907 2617 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (2XD-2, 2XD-4) CXK,CXL,CXM,CYM,CYL 6SD1 | 94/10~ | Engine CRANK SHAFT FRONT |
| 03907 6317 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-2, 2XD-4) CXM,CYM,CYL 6TE1 | 0/12 | Engine CRANK SHAFT FRONT |
| 03907 5765 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (2XD-2, 2XD-4) CXM,CXK,CXL,CYL 6WA1,6WG1,6WF1 | 92/4~ | Engine CRANK SHAFT FRONT |
| 03907 5077 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-2, 2XD-4) CXK,CXL,CXM,CYM,CYL 8PE1,10PE1,12PE1 | 94/10~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 7265 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-2, 2XD-4) SPM,SPK,TMK E120 | 71/~83/ | Engine CRANK SHAFT REAR |
| 03907 4337 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-2, 2XD-4) SQM,SHM,SHK,TMQ 6R | 81/6~83/ | Engine CRANK SHAFT REAR |
| 03907 5005 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-2, 2XD-4) CXM 6R(EXCEPT MIXER) | 83/8~85/12 | Engine CRANK SHAFT REAR |
| 03907 5209 | 9828-57103 | 57 x 124 x 13 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR OUTER |
| 03907 5621 | 9828-62104 | 62 x 76 x 9 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR OUTER |
| 03907 5513 | 9828-01189 | 159 x 182 x 18 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR INNER |
| 03907 4265 | 9828-76101 | 76 x 164 x 14 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR OUTER |
| 03907 1649 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR OUTER |
| 03907 3345 | 9828-62104 | 62 x 76 x 9 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR OUTER (F) |
| 03907 5285 | 9828-57103 | 57 x 124 x 13 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR OUTER (F) |
| 03907 3209 | 9828-76101 | 76 x 164 x 14 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR OUTER (F) |
| 03907 5941 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR OUTER (F) |
| 03907 2885 | 9828-01203 | 127 x 147 x 11 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR INNER |
| 03907 4573 | 9828-01193 | 154 x 175 x 13 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR INNER |
| 03907 4221 | 9828-01130 | 146 x 170 x 18 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR INNER |
| 03907 4241 | 9828-01189 | 159 x 182 x 18 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR INNER (F) |
| 03907 5669 | 9828-01193 | 154 x 175 x 13 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR INNER (F) |
| 03907 4297 | 9828-01130 | 146 x 170 x 18 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR INNER (F) |
| 03907 4673 | 9828-01207 | 138 x 152 x 12 | TRUCK (2XD-D) ZM,KK,FQ,FS,GK,WP | 71/~ | Wheel Hub FRONT |
| 03907 2969 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS60#,63#,66#... 9 SPEED T/M | 81/5~89/ | Transmission REAR COVER |
| 03907 1685 | 9828-55113 | 55 x 72 x 9 | TRUCK (2XD-D) ZM,FQ,FS,WP | 71/~ | Transmission FRONT COVER |
| 03907 3381 | 9828-01203 | 127 x 147 x 11 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR INNER (F) |
| 03907 4153 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (2XD-D) ZM | 71/~81/ | Final Drive PINION (REAR) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4705 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FQ1F | 90/2~95/4 | Transmission REAR COVER |
| 03907 1857 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) WP | 98/7~99/8 | Transmission REAR COVER |
| 03907 4017 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1F,3F,4F,1K,2P | 99/9~ | Transmission REAR COVER |
| 03907 2853 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ2P RFA#,TFA#,WFA# | 99/9~ | Transmission REAR COVER |
| 03907 1425 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ3F,4F,1K | 99/9~ | Transmission REAR COVER |
| 03907 4613 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (2XD-D) FQ | 00/3~ | Final Drive PINION (REAR) |
| 03907 7117 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) WP | 99/9~ | Transmission REAR COVER |
| 03907 5233 | 9828-90104 | 90 x 115 x 13 x 19 | TRUCK (2XD-D) ZM,KK,FQ,FS,GK | 71/~92/3 | Final Drive PINION (FRONT) |
| 03907 5177 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ1K | 98/2~99/8 | Transmission REAR COVER |
| 03907 3417 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (2XD-D) WP | 98/7~01/ | Final Drive PINION (FRONT) |
| 03907 6501 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ2P RFA#,TFA#,WFA# | 96/4~99/8 | Transmission REAR COVER |
| 03907 1741 | 9828-63104 | 63 x 100 x 12 | TRUCK (2XD-D) KK | 83/9~86/5 | Final Drive PINION (REAR) |
| 03907 3337 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-D) GK | 89/7~98/6 | Final Drive PINION (REAR) |
| 03907 7009 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-D) FQ | 90/2~00/2 | Final Drive PINION (REAR) |
| 03907 4565 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-D) KK | 86/6~89/ | Final Drive PINION (REAR) |
| 03907 4809 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-D) FS | 81/5~95/3 | Final Drive PINION (REAR) |
| 03907 6625 | 9828-70116 | 70 x 94.5 x 10 x 16.5 | TRUCK (2XD-D) WP | 98/7~01/ | Final Drive PINION (REAR) |
| 03907 6257 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2XD-D) FS | 95/4~ | Final Drive PINION (REAR) |
| 03907 6681 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (2XD-D) GK | 98/7~ | Final Drive PINION (REAR) |
| 03907 6229 | 9828-90115 | 90 x 125 x 10 x 17 | TRUCK (2XD-D) FQ,FS,GK | 92/4~ | Final Drive PINION (FRONT) |
| 03907 6009 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS60#,63#,66#...EXCEPT 9 SPEED T/M | 81/5~89/ | Transmission REAR COVER |
| 03907 1229 | 9828-50105 | 50 x 68 x 9 | TRUCK (2XD-D) KK,GK | 86/6~ | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1537 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) ZM,303D,M REAR AXLE RATIO 6.428 | 77/~81/ | Transmission REAR COVER |
| 03907 4201 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) ZM706D,M 1ST GEAR RATIO 6.028 | 79/~81/ | Transmission REAR COVER |
| 03907 7133 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) ZM745,765,785 | 79/~81/ | Transmission REAR COVER |
| 03907 7005 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) FS27# | 81/5~83/11 | Transmission REAR COVER |
| 03907 2261 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) KK,GK | 83/9~ | Transmission REAR COVER |
| 03907 6965 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) ZM303D,M REAR AXLE RATIO 6.833 | 77/~81/ | Transmission REAR COVER |
| 03907 3593 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) ZM706F,M 1ST GEAR RATIO 7.028 | 79/~81/ | Transmission REAR COVER |
| 03907 1657 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ2F,3F | 92/5~99/8 | Transmission REAR COVER |
| 03907 3229 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS27#,33#...EXCEPT 9 SPEED T/M | 83/12~89/ | Transmission REAR COVER |
| 03907 5089 | 9828-48120 | 48 x 60 x 9 | TRUCK (2XD-D) KK | 83/9~86/5 | Transmission FRONT COVER |
| 03907 5581 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS1F,2F,3F,1K,2K | 89/8~92/4 | Transmission REAR COVER |
| 03907 5325 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS2K | 92/5~ | Transmission REAR COVER |
| 03907 6693 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FQ2P REA#,TEA#,WEA# | 98/3~00/ | Transmission REAR COVER |
| 03907 3529 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS27#,33#...9 SPEED T/M | 83/12~89/ | Transmission REAR COVER |
| 03907 6357 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1V 10 SPEED T/M | 92/5~ | Transmission REAR COVER |
| 03907 3369 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1F,2F,3F,4F,1K | 92/5~99/8 | Transmission REAR COVER |
| 03907 5061 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1V EXCEPT 10 SPEED T/M | 92/5~ | Transmission REAR COVER |
| 03907 4213 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) ZM500D,540,560,580,940 | 77/~81/ | Transmission REAR COVER |
| 03907 1545 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2XD-D) SPZ,SRZ,SSZ | 73/~79/12 | Final Drive PINION (FORWARD) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4089 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-D) SVZ581 | 82/9~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 1233 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-D) CXZ,CYZ P85,P90 P/S | 83/8~99/12 | Propeller Shaft CENTER BEARING (F&R) |
| 03907 6661 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P90 P/S | 00/1~ | Propeller Shaft CENTER BEARING (F) |
| 03907 5161 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2XD-D) SRZ,SSZ581,641,701 | 80/1~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 6025 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P60,P90L P/S | 83/8~03/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 5253 | 1-09625-621-0 | 81 x 103 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P90 P/S | 00/1~ | Propeller Shaft CENTER BEARING |
| 03907 4385 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2XD-D) CXZ,CYZ P115 P/S | 83/8~99/12 | Propeller Shaft CENTER BEARING (F&R) |
| 03907 6305 | 1-09625-622-0 | 86 x 106 x 14 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P115,P115L P/S | 00/1~ | Propeller Shaft CENTER BEARING |
| 03907 2437 | 1-09625-119-0 | 80 x 127 x 16 x 24 | TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ,TMK-Z,TMQ-Z | 80/1~83/ | Final Drive PINION (FORWARD) |
| 03907 2889 | 1-09625-323-0 | 86 x 127 x 16 x 25 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 83/8~ | Final Drive PINION (FORWARD) |
| 03907 2661 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (2XD-D) SPZ,TMK-Z | 73/~78/ | Propeller Shaft CENTER BEARING |
| 03907 2317 | 1-09625-624-0 | 60 x 75 x 9 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJX16 | 03/5~ | Transmission FRONT COVER |
| 03907 6189 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ,TMK-Z,TMQ-Z | 73/~83/ | Final Drive PINION (REARWARD) |
| 03907 2309 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2XD-D) CXZ | 83/8~89/7 | Final Drive PINION (REARWARD) |
| 03907 6281 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P115,P115L P/S | 00/1~ | Propeller Shaft CENTER BEARING (F) |
| 03907 4105 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 89/8~03/ | Transmission FRONT COVER |
| 03907 5553 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-D) TMK-Z | 73/~80/3 | Transmission FRONT COVER |
| 03907 4033 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-D) SRZ,SSZ | 75/~79/12 | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3181 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 8PE1,10PE1,12PE1 | 94/10~ | Engine CRANK SHAFT REAR |
| 03907 3393 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2XD-D) CXZ,CYZ | 89/8~95/ | Final Drive PINION (REARWARD) |
| 03907 2713 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) TMK-Z | 80/4~83/ | Transmission FRONT COVER |
| 03907 3969 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) SRZ,SSZ | 80/1~83/ | Transmission FRONT COVER |
| 03907 2989 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (2XD-D) SPZ,SRZ,SSZ,TMK-Z,SQZ,TMQ-Z,SVZ | 80/1~83/ | Transmission REAR COVER |
| 03907 3789 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) CXZ | 83/8~89/7 | Transmission FRONT COVER |
| 03907 5721 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (2XD-D) SPZ,TMK-Z | 73/~78/ | Propeller Shaft CENTER BEARING (F) |
| 03907 4389 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MAL6,MAP6,MJT7,MJX12 | 03/5~ | Transmission FRONT COVER |
| 03907 5549 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ | 73/~79/12 | Transmission REAR COVER |
| 03907 2301 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (2XD-D) CXZ MAB,MAF T/M | 83/8~94/ | Transmission REAR COVER |
| 03907 3157 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MAG,MAH,MAL,MAP T/M | 83/8~ | Transmission REAR COVER |
| 03907 4689 | 1-09625-359-0 | 80 x 100 x 12 | TRUCK (2XD-D) CXZ MJA T/M | 86/1~94/ | Transmission REAR COVER |
| 03907 3729 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJA,MJD,MJT T/M | 94/7~ | Transmission REAR COVER |
| 03907 1945 | 1-09625-625-0 | 104 x 126 x 13 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJX12,16 | 0/3 | Transmission REAR COVER |
| 03907 7033 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) SQZ,TMQ-Z | 81/8~83/ | Transmission FRONT COVER |
| 03907 1893 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (2XD-D) SPZ E120(MIXER),CXZ 6R(MIXER) | 73/~89/ | Engine CRANK SHAFT REAR |
| 03907 1553 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (2XD-D) CXZ 8PD1 | 89/8~93/2 | Engine CRANK SHAFT REAR |
| 03907 4405 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6WA1,6WG1,6WF1 | 92/5~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6409 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6SD1 | 96/11~ | Engine CRANK SHAFT REAR |
| 03907 6253 | 1-09625-559-0 | 139 x 171 x 19 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6TE1,7TD1 | 00/1~ | Engine CRANK SHAFT REAR |
| 03907 4437 | 9-12569-072-0 | | TRUCK (2XD-D) E120 | 73/~83/ | Engine VALVE STEM SEAL |
| 03907 3653 | 1-12569-013-0 | | TRUCK (2XD-D) 6R | 81/~89/ | Engine VALVE STEM SEAL |
| 03907 2521 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2XD-D) CXZ 10PD1,12PD1 | 89/8~93/2 | Engine CRANK SHAFT REAR |
| 03907 4901 | 1-12569-019-1 | | TRUCK (2XD-D) 8P#,10P#,12P# | 91/7~ | Engine VALVE STEM SEAL |
| 03907 2973 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2XD-D) CXZ 8P,10P,12P | 83/8~89/7 | Engine CRANK SHAFT REAR |
| 03907 4409 | 1-12569-019-1 | | TRUCK (2XD-D) 6SD1 | 96/11~ | Engine VALVE STEM SEAL |
| 03907 6045 | 1-12569-019-1 | | TRUCK (2XD-D) 6WA1,6WG1 | 92/5~00/5 | Engine VALVE STEM SEAL |
| 03907 4141 | 1-12569-020-0 | | TRUCK (2XD-D) 6WF1,6WG1 | 00/6~ | Engine VALVE STEM SEAL |
| 03907 1729 | 1-12569-019-1 | | TRUCK (2XD-D) 6TE1,8TD1 | 00/1~ | Engine VALVE STEM SEAL |
| 03907 6021 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-D) SPZ | 73/~83/ | Transmission FRONT COVER |
| 03907 4633 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (2XD-D) SPZ,TMK-Z E120 | 73/~77/ | Engine CRANK SHAFT FRONT |
| 03907 3409 | 1-12569-009-0 | | TRUCK (2XD-D) 8P,10P,12P | 75/~91/6 | Engine VALVE STEM SEAL |
| 03907 3045 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (2XD-D) CXZ 8PD1 | 89/8~93/2 | Engine CRANK SHAFT FRONT |
| 03907 2605 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 16.5 INCH DIFF. | 95/5~ | Final Drive PINION (REARWARD) |
| 03907 3453 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2XD-D) SPZ,TMK-Z E120 | 77/~83/ | Engine CRANK SHAFT FRONT |
| 03907 3721 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (2XD-D) SRZ,SSZ,SVZ 10P,12P | 75/~83/ | Engine CRANK SHAFT FRONT |
| 03907 1349 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2XD-D) CXZ 8P,10P,12P | 83/8~89/7 | Engine CRANK SHAFT FRONT |
| 03907 2553 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2XD-D) XZ 10PD1,12PD1 | 89/8~93/2 | Engine CRANK SHAFT FRONT |
| 03907 2901 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ 8PD1,10PD1,12PD1 | 93/3~94/ | Engine CRANK SHAFT FRONT |
| 03907 3009 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ 8PD1,10PD1,12PD1 | 93/3~94/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2305 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6TE1,8TD1 | 00/1~ | Engine CRANK SHAFT FRONT |
| 03907 7041 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 17.5 INCH DIFF. | 94/9~ | Final Drive PINION (REARWARD) |
| 03907 5689 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6WA1,6WG1,6WF1 | 92/5~ | Engine CRANK SHAFT FRONT |
| 03907 1709 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6SD1 | 96/11~ | Engine CRANK SHAFT FRONT |
| 03907 4713 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-D) SPZ,TMK-Z E120(EXCEPT MIXER) | 73/~83/ | Engine CRANK SHAFT REAR |
| 03907 6973 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-D) SQZ TMQ-Z,CXZ 6R(EXCEPT MIXER) | 81/8~85/12 | Engine CRANK SHAFT REAR |
| 03907 1593 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (2XD-D) CXZ 6R (EXCEPT MIXER) | 86/1~89/ | Engine CRANK SHAFT REAR |
| 03907 1881 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (2XD-D) SRZ,SSZ,SVZ 10P,12P | 75/~83/ | Engine CRANK SHAFT REAR |
| 03907 5737 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 8PE1,10PE1,12PE1 | 94/10~ | Engine CRANK SHAFT FRONT |
| 03907 4669 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CYZ EXC. REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR INNER (F&R) |
| 03907 3117 | 1-51389-005-0 | 155 x 185 x 13 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 83/8~ | Rear Suspesion TRUNNION SHAFT |
| 03907 3541 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2XD-D) SQZ,CXZ 6R | 81/8~89/ | Engine CRANK SHAFT FRONT |
| 03907 1621 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 83/8~ | Wheel Hub FRONT |
| 03907 3373 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ | 73/~83/ | Wheel Hub REAR INNER (F&R) |
| 03907 2401 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CXZ ALL | 83/8~96/10 | Wheel Hub REAR INNER (F&R) |
| 03907 3109 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CXZ EXC. REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR INNER (F&R) |
| 03907 3837 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CYZ ALL | 94/9~96/10 | Wheel Hub REAR INNER (F&R) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2373 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ | 73/~83/ | Wheel Hub FRONT |
| 03907 7261 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CYZ,CYY 16.5,17.5 INCH FINAL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03907 4637 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (2XD-D) CXZ,CYZ REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR INNER (F&R) |
| 03907 5773 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (2XD-D) CXY ALL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03907 3665 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (2XD-D) CYZ,CYY 14.5 INCH FINAL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03907 1257 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CYZ EXC. REAR BRAKE WITH 150 MM | 96/11~99/ | Wheel Hub REAR OUTER (F&R) |
| 03907 4577 | 1-51389-005-0 | 155 x 185 x 13 x 16 | TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ | 73/~83/ | Rear Suspesion TRUNNION SHAFT |
| 03907 6261 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CXZ ALL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03907 6729 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ | 73/~79/12 | Wheel Hub REAR OUTER (F&R) |
| 03907 1505 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (2XD-D) CXY ALL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03907 2985 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (2XD-D) CYZ,CYY 14.5 INCH FINAL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03907 1317 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CYZ,CYY 16.5,17.5 INCH FINAL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03907 6093 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CYZ ALL | 94/9~96/10 | Wheel Hub REAR OUTER (F&R) |
| 03907 3197 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CXZ ALL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03907 1961 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CXZ EXC. REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR OUTER (F&R) |
| 03907 3325 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CXZ ALL | 83/8~96/10 | Wheel Hub REAR OUTER (F&R) |
| 03907 2345 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ | 80/1~83/ | Wheel Hub REAR OUTER (F&R) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3177 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (2XD-D) CXZ,CYZ REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR OUTER (F&R) |
| 03907 4989 | 9828-01130 | 146 x 170 x 18 | TRUCK (6T~8T) KB | 70/~81/ | Wheel Hub REAR INNER |
| 03907 4049 | 9828-90115 | 90 x 125 x 10 x 17 | TRUCK (6T~8T) FZ 1F,4F | 95/4~ | Final Drive PINION |
| 03907 6197 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (6T~8T) KB | 70/~81/ | Final Drive PINION |
| 03907 4865 | 9828-70110 | 70 x 95 x 13 x 20 | TRUCK (6T~8T) K13D | 90/1~95/1 | Engine CRANK SHAFT FRONT |
| 03907 4785 | 9828-70110 | 70 x 95 x 13 x 20 | TRUCK (6T~8T) EK100 | 83/~90/ | Engine CRANK SHAFT FRONT |
| 03907 3077 | 9828-96101 | 96 x 124 x 14 x 21 | TRUCK (6T~8T) EF750,F17D | 87/4~94/11 | Engine CRANK SHAFT FRONT |
| 03907 4829 | 9828-70102 | 70 x 95 x 13 | TRUCK (6T~8T) EK100 | 70/~83/ | Engine CRANK SHAFT FRONT |
| 03907 3405 | 9828-80102 | 80 x 105 x 13 | TRUCK (6T~8T) EB300 | 70/~81/ | Engine CRANK SHAFT FRONT |
| 03907 2709 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK (6T~8T) H06C,H07C,D | 83/7~94/ | Engine CRANK SHAFT FRONT |
| 03907 3909 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK (6T~8T) EH500,700 | 76/~83/ | Engine CRANK SHAFT FRONT |
| 03907 6185 | 9828-79103 | 79 x 114 x 17 | TRUCK (6T~8T) J08C | 94/9~ | Engine CRANK SHAFT FRONT |
| 03907 6177 | 9828-58105 | 58 x 75 x 9 | TRUCK (6T~8T) EH300 E/#~44626 | 74/~77/ | Engine CRANK SHAFT FRONT |
| 03907 6561 | 9828-75145 | 75 x 114 x 17 | TRUCK (6T~8T) K13D | 95/2~ | Engine CRANK SHAFT FRONT |
| 03907 6213 | 9828-90104 | 90 x 115 x 13 x 19 | TRUCK (6T~8T) FZ 27#,63#,1F | 83/11~95/3 | Final Drive PINION |
| 03907 1825 | 9828-01120 | 140 x 160 x 14 | TRUCK (6T~8T) KG,KR,FF,FG | 74/~83/11 | Wheel Hub REAR INNER |
| 03907 1309 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (6T~8T) FH 2K,2P | 95/4~ | Final Drive PINION |
| 03907 6381 | 9828-01137 | 101 x 114 x 10 | TRUCK (6T~8T) KR C/#~19999 | 74/~75/5 | Wheel Hub FRONT |
| 03907 3005 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (6T~8T) FH 220#,222BA-KA,222BF,270BD,272BA | 83/12~90/2 | Final Drive PINION |
| 03907 5393 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (6T~8T) FH 221#,222BA-AA,224BA,226BA,228#,229# | 83/12~90/2 | Final Drive PINION |
| 03907 7101 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (6T~8T) FF 2H,3H,1J | 89/8~99/ | Final Drive PINION |
| 03907 6797 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (6T~8T) FG 19#,1H,1J | 83/7~ | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4905 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (6T~8T) FG 18# | 80/7~83/ | Final Drive PINION |
| 03907 3965 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK (6T~8T) EH300 E/#44627~ | 78/~79/ | Engine CRANK SHAFT FRONT |
| 03907 3201 | 9828-01200 | 122 x 150 x 12 x 18 | TRUCK (6T~8T) EM100 | 83/12~90/ | Engine CRANK SHAFT REAR |
| 03907 4501 | 13719-1470 | | TRUCK (6T~8T) J08C | 98/1~ | Engine VALVE STEM SEAL |
| 03907 6353 | 13719-1360 | | TRUCK (6T~8T) H07C,D,J08C | 94/9~97/12 | Engine VALVE STEM SEAL |
| 03907 4185 | 13719-1350 | | TRUCK (6T~8T) H06C WITH TURBO (EX.) | 83/7~89/7 | Engine VALVE STEM SEAL |
| 03907 5697 | 13719-1020 | | TRUCK (6T~8T) H06C (IN. & EX.) | 89/8~94/ | Engine VALVE STEM SEAL |
| 03907 5101 | 13719-1020 | | TRUCK (6T~8T) H06C WITH TURBO (IN.) | 83/7~89/7 | Engine VALVE STEM SEAL |
| 03907 6101 | 13719-1020 | | TRUCK (6T~8T) H06C WITHOUT TURBO (IN. & EX.) | 83/7~89/7 | Engine VALVE STEM SEAL |
| 03907 4397 | 13719-1020 | | TRUCK (6T~8T) H07C,D | 83/7~94/8 | Engine VALVE STEM SEAL |
| 03907 6745 | 9828-01223 | 116 x 151 x 17 | TRUCK (6T~8T) K13D,P11C | 95/4~ | Engine CRANK SHAFT REAR |
| 03907 6713 | 9828-75140 | 75 x 100 x 13 x 20 | TRUCK (6T~8T) EM100 | 83/12~90/ | Engine CRANK SHAFT FRONT |
| 03907 3121 | 9828-01228 | 100 x 135 x 17 | TRUCK (6T~8T) J08C | 94/9~ | Engine CRANK SHAFT REAR |
| 03907 3389 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (6T~8T) FH 2K | 90/1~95/4 | Final Drive PINION |
| 03907 2957 | 9828-01201 | 125 x 155 x 14 x 23 | TRUCK (6T~8T) K13D EXCEPT FH2KGAM-BA | 90/1~95/4 | Engine CRANK SHAFT REAR |
| 03907 4081 | 9828-01201 | 125 x 155 x 14 x 23 | TRUCK (6T~8T) EK100 EXCEPT MIXER | 75/~90/ | Engine CRANK SHAFT REAR |
| 03907 3981 | 9828-01168 | 135 x 165 x 14 x 20.5 | TRUCK (6T~8T) EF750,F17D | 87/4~94/11 | Engine CRANK SHAFT REAR |
| 03907 3161 | 9828-01202 | 125 x 155 x 14 | TRUCK (6T~8T) K13D FH2KGAM-BA | 90/1~92/ | Engine CRANK SHAFT REAR |
| 03907 1561 | 9828-01202 | 125 x 155 x 14 | TRUCK (6T~8T) EB300,EK100 MIXER | 70/~87/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2593 | 9828-01167 | 106 x 126 x 12 | TRUCK (6T~8T) H06C,H07C,D | 83/7~94/ | Engine CRANK SHAFT REAR |
| 03907 7281 | 9828-01167 | 106 x 126 x 12 | TRUCK (6T~8T) EH300,500,700 | 74/~83/ | Engine CRANK SHAFT REAR |
| 03907 1217 | 9828-96109 | 96 x 131 x 17.5 | TRUCK (6T~8T) P11C | 00/3~ | Engine CRANK SHAFT FRONT |
| 03907 2117 | 9828-96109 | 96 x 131 x 17.5 | TRUCK (6T~8T) F17D | 94/12~02/ | Engine CRANK SHAFT FRONT |
| 03907 4365 | 9828-01226 | 125 x 177 x 17.5 | TRUCK (6T~8T) F17D | 94/12~02/ | Engine CRANK SHAFT REAR |
| 03907 4477 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (6T~8T) FE,FJ | 98/7~ | Final Drive PINION |
| 03907 2733 | 9828-48120 | 48 x 60 x 9 | TRUCK (6T~8T) FE 1J | 96/8~ | Transmission FRONT COVER |
| 03907 2173 | 9828-48120 | 48 x 60 x 9 | TRUCK (6T~8T) FG19#,FH22#,FF2H,1J | 80/~99/ | Transmission FRONT COVER |
| 03907 1693 | 9828-43102 | 43 x 63 x 9 | TRUCK (6T~8T) FF 17#,3H | 83/7~94/ | Transmission FRONT COVER |
| 03907 4137 | 9828-37103 | 37 x 50 x 6 | TRUCK (6T~8T) KR 6 SPEED,FF | 76/~83/6 | Transmission FRONT COVER |
| 03907 3301 | 9828-57103 | 57 x 124 x 13 | TRUCK (6T~8T) FE,FJ | 96/8~ | Wheel Hub REAR OUTER |
| 03907 6377 | 9828-76101 | 76 x 164 x 14 | TRUCK (6T~8T) CG,FH,FZ | 81/1~ | Wheel Hub REAR OUTER |
| 03907 2937 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (6T~8T) KB | 70/~81/ | Wheel Hub REAR OUTER |
| 03907 2465 | 9828-48120 | 48 x 60 x 9 | TRUCK (6T~8T) FJ | 99/3~ | Transmission FRONT COVER |
| 03907 6861 | 9828-52115 | 52 x 64 x 9 | TRUCK (6T~8T) KG,FF,FG | 80/~83/11 | Wheel Hub REAR OUTER |
| 03907 2697 | 9828-66106 | 66 x 134 x 16 | TRUCK (6T~8T) KG,FF,FG | 83/12~ | Wheel Hub REAR OUTER |
| 03907 1549 | 9828-52108 | 52 x 62 x 6 x 10 | TRUCK (6T~8T) KR301,321,361 | 74/~77/ | Wheel Hub REAR OUTER |
| 03907 3445 | 9828-01203 | 127 x 147 x 11 | TRUCK (6T~8T) FE,FJ | 96/8~ | Wheel Hub REAR INNER |
| 03907 3233 | 9828-01193 | 154 x 175 x 13 | TRUCK (6T~8T) CG,FH,FZ | 81/1~ | Wheel Hub REAR INNER |
| 03907 2221 | 9828-01204 | 145 x 164 x 14 | TRUCK (6T~8T) KG,FF,FG | 83/12~ | Wheel Hub REAR INNER |
| 03907 6029 | 9828-01189 | 159 x 182 x 18 | TRUCK (6T~8T) FZ | 83/12~ | Wheel Hub FRONT |
| 03907 5813 | 9828-01207 | 138 x 152 x 12 | TRUCK (6T~8T) CG,FE,FG,FH,FJ,KG | 80/~ | Wheel Hub FRONT |
| 03907 6657 | 9828-01207 | 138 x 152 x 12 | TRUCK (6T~8T) KB | 70/~81/ | Wheel Hub FRONT |
| 03907 5497 | 9828-01207 | 138 x 152 x 12 | TRUCK (6T~8T) KR C/#20000~ | 75/6~80/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3437 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (6T~8T) FE | 96/8~98/6 | Final Drive PINION |
| 03907 6865 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (6T~8T) FZ 1F | 93/6~99/8 | Transmission REAR COVER |
| 03907 1689 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (6T~8T) FF 17# | 83/7~89/ | Final Drive PINION |
| 03907 7153 | 9828-65108 | 65 x 95 x 14 x 22 | TRUCK (6T~8T) KR,FF | 74/~83/6 | Final Drive PINION |
| 03907 6545 | 9828-52115 | 52 x 64 x 9 | TRUCK (6T~8T) KR305,325,365 | 77/~80/ | Wheel Hub REAR OUTER |
| 03907 6369 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (6T~8T) FZ 1F,4F | 99/9~ | Transmission REAR COVER |
| 03907 4465 | 9828-50105 | 50 x 68 x 9 | TRUCK (6T~8T) KB EXCEPT 501 | 72/~81/ | Transmission FRONT COVER |
| 03907 1397 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (6T~8T) FH | 95/4~ | Transmission REAR COVER |
| 03907 1409 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (6T~8T) FZ 63#,1F | 87/4~92/12 | Transmission REAR COVER |
| 03907 2757 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (6T~8T) FH,FZ27# | 83/11~95/4 | Transmission REAR COVER |
| 03907 1949 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (6T~8T) FG | 80/7~ | Transmission REAR COVER |
| 03907 5661 | 9828-55110 | 55 x 72 x 9 x 15 | TRUCK (6T~8T) KR,FF | 74/~83/6 | Transmission REAR COVER |
| 03907 3801 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (6T~8T) KB 6 SPEED | 70/~81/ | Transmission REAR COVER |
| 03907 2601 | 9828-50105 | 50 x 68 x 9 | TRUCK (6T~8T) FG 1H,1J | 89/8~ | Transmission FRONT COVER |
| 03907 6105 | 9828-55113 | 55 x 72 x 9 | TRUCK (6T~8T) FZ | 83/11~ | Transmission FRONT COVER |
| 03907 2277 | 9828-55113 | 55 x 72 x 9 | TRUCK (6T~8T) KB 501 | 77/9~81/ | Transmission FRONT COVER |
| 03907 4641 | 9828-60119 | 60 x 75 x 9 x 15 | TRUCK (6T~8T) FF 17#,3H | 83/7~94/ | Transmission REAR COVER |
| 03907 4709 | 9828-63108 | 63 x 78 x 9 x 15 | TRUCK (6T~8T) FF 2H,1J | 89/8~99/ | Transmission REAR COVER |
| 03907 5893 | 9828-63108 | 63 x 78 x 9 x 15 | TRUCK (6T~8T) FE,FJ | 96/8~ | Transmission REAR COVER |
| 03907 5761 | 9828-65111 | 65 x 95 x 14 x 20.5 | TRUCK (6T~8T) KB 5 SPEED | 70/~79/ | Transmission REAR COVER |
| 03907 6493 | 9828-55113 | 55 x 72 x 9 | TRUCK (6T~8T) FH 27#,2K,2P | 81/6~ | Transmission FRONT COVER |
| 03907 2357 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (6T~8T) CVR | 83/9~89/10 | Transmission FRONT COVER |
| 03907 3273 | 1-09625-085-0 | 55 x 72 x 15 | TRUCK (6T~8T) TXD | 80/5~84/ | Propeller Shaft CENTER BEARING (F & R) |
| 03907 1525 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (6T~8T) TD,TP | 71/~79/12 | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4509 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (6T~8T) CVR MJT7 T/M | 03/6~ | Transmission REAR COVER |
| 03907 6589 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (6T~8T) CVR MAF5,MAF6 T/M | 83/9~95/ | Transmission REAR COVER |
| 03907 4973 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (6T~8T) TD,TP,SMR,SJR MAB T/M | 80/1~83/ | Transmission REAR COVER |
| 03907 6289 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (6T~8T) SMR MAB T/M | 78/4~79/12 | Transmission REAR COVER |
| 03907 3089 | 1-09625-063-0 | 68 x 90 x 12 | TRUCK (6T~8T) TXD,TD,TP,SLR MLE T/M | 71/~83/ | Transmission REAR COVER |
| 03907 1625 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (6T~8T) CVR | 89/11~ | Transmission FRONT COVER |
| 03907 4913 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) TD,TDJ,TDK,TP | 80/1~83/ | Propeller Shaft CENTER BEARING (F & R) |
| 03907 4857 | 1-09625-173-0 | 60 x 77 x 12 | TRUCK (6T~8T) TXD MG,MB T/M | 71/~84/ | Transmission REAR COVER |
| 03907 3093 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) SMR EXCEPT TURBO | 78/4~83/ | Propeller Shaft CENTER BEARING (F & R) |
| 03907 3821 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) SLR,SJR | 80/1~83/ | Propeller Shaft CENTER BEARING (F & R) |
| 03907 5265 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) CVR 6QA1 | 83/9~89/10 | Propeller Shaft CENTER BEARING (F & R) |
| 03907 1733 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (6T~8T) CVR 8PC1,8PD1,8PE1 | 83/9~03/ | Propeller Shaft CENTER BEARING (F & R) |
| 03907 6741 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (6T~8T) CVR 6SD1,6WF1 | 03/6~ | Propeller Shaft CENTER BEARING (F) |
| 03907 4505 | 1-09625-621-0 | 81 x 103 x 16 | TRUCK (6T~8T) CVR 6SD1,6WF1 | 03/6~ | Propeller Shaft CENTER BEARING |
| 03907 2397 | 1-09625-173-0 | 60 x 77 x 12 | TRUCK (6T~8T) TXD | 71/~77/ | Final Drive PINION |
| 03907 5213 | 1-09625-484-0 | 60 x 103 x 12 x 20 | TRUCK (6T~8T) TXD | 77/~84/ | Final Drive PINION |
| 03907 6137 | 1-09625-063-0 | 68 x 90 x 12 | TRUCK (6T~8T) TD,TP SINGLE SPEED | 71/~74/ | Final Drive PINION |
| 03907 4469 | 1-09625-063-0 | 68 x 90 x 12 | TRUCK (6T~8T) SLR SINGLE SPEED | 73/~83/ | Final Drive PINION |
| 03907 2609 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (6T~8T) SMR,SJR | 80/1~83/ | Transmission FRONT COVER |
| 03907 7097 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) TDJ | 80/1~84/ | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 6277 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (6T~8T) TD,TP EXCEPT TD-U,TD-P (2 SPEED) | 71/~79/12 | Wheel Hub REAR OUTER |
| 03907 7213 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) TP SINGLE SPEED | 72/~84/ | Final Drive PINION |
| 03907 1177 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (6T~8T) TD,TP | 71/~79/12 | Propeller Shaft CENTER BEARING(F) |
| 03907 4953 | 9-09924-407-0 | 76 x 115 x 13 x 21 | TRUCK (6T~8T) YXD | 71/~84/ | Wheel Hub FRONT |
| 03907 2673 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (6T~8T) TD,TP,SLR,SMR,SJR | 73/~84/ | Wheel Hub FRONT |
| 03907 2649 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (6T~8T) CVR | 83/9~ | Wheel Hub FRONT |
| 03907 2253 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (6T~8T) TXD | 71/~84/ | Wheel Hub REAR INNER |
| 03907 4257 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) TD,TP EXCEPT TD-U,TD-P (2 SPEED) | 71/~79/12 | Wheel Hub REAR INNER |
| 03907 7173 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) TDJ,TPJ78 | 80/1~84/ | Wheel Hub REAR INNER |
| 03907 4517 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) SLR,SMR(EXCEPT 360,361) | 73/~83/ | Wheel Hub REAR INNER |
| 03907 5261 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) SJR 461,531,601 | 81/8~83/ | Wheel Hub REAR INNER |
| 03907 4305 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (6T~8T) TD,TP TD-U,TD-P (2 SPEED) | 71/~79/12 | Wheel Hub REAR INNER |
| 03907 3533 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (6T~8T) TDK,TP,TDJ (EXCEPT 78) | 80/1~84/ | Wheel Hub REAR INNER |
| 03907 3521 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (6T~8T) SMR360,361,SJR361 | 78/4~83/ | Wheel Hub REAR INNER |
| 03907 5337 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (6T~8T) SMR450,520,600,670 | 78/3~79/12 | Wheel Hub REAR OUTER |
| 03907 1305 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (6T~8T) TXD | 71/~84/ | Wheel Hub REAR OUTER |
| 03907 6457 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (6T~8T) SMR | 78/4~79/12 | Transmission FRONT COVER |
| 03907 7181 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (6T~8T) SLR350,360,400,450,520,600 ,670,700 | 73/~79/12 | Wheel Hub REAR OUTER |
| 03907 3817 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) SMR EXCEPT 360,361 | 78/~83/ | Final Drive PINION |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3129 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) TD,TDJ | 80/1~84/ | Wheel Hub REAR OUTER |
| 03907 5505 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) SLR361,401,461,531 | 80/1~83/ | Wheel Hub REAR OUTER |
| 03907 3933 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) SMR401,461,531,601,671 | 80/1~83/ | Wheel Hub REAR OUTER |
| 03907 3977 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) SJR461,531,601 | 81/8~83/ | Wheel Hub REAR OUTER |
| 03907 5585 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (6T~8T) TD,TP TD-U,TD-P (2 SPEED) | 70/1~79/12 | Wheel Hub REAR OUTER |
| 03907 1293 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (6T~8T) SMR360 | 78/4~79/12 | Wheel Hub REAR OUTER |
| 03907 6461 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (6T~8T) SMR361,SJR361 | 80/1~83/ | Wheel Hub REAR OUTER |
| 03907 6349 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (6T~8T) CVR | 83/9~ | Wheel Hub REAR OUTER |
| 03907 1701 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (6T~8T) TXD | 73/~84/ | Transmission FRONT COVER |
| 03907 5645 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (6T~8T) TD,TDJ,TP | 80/1~84/ | Transmission FRONT COVER |
| 03907 3513 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (6T~8T) CVR | 83/9~ | Wheel Hub REAR INNER |
| 03907 5201 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (6T~8T) CVR 6QA1(EXCEPT FLYWHEEL PTO) | 86/4~89/10 | Engine CRANK SHAFT REAR |
| 03907 3169 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (6T~8T) CVR 6WF1 | 03/6~ | Engine CRANK SHAFT FRONT |
| 03907 2257 | 9-12365-040-0 | SPLIT SEAL x x | TRUCK (6T~8T) TXD DA120,640 | 71/~76/ | Engine CRANK SHAFT REAR |
| 03907 1717 | 9-09924-356-0 | 105 x 135 x 14 | TRUCK (6T~8T) TXD 120,640 | 76/~84/ | Engine CRANK SHAFT REAR |
| 03907 6477 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) TD,TP,SLR(EXCEPT MIXER) DH100 | 75/~84/ | Engine CRANK SHAFT REAR |
| 03907 3957 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) TDK E120 | 80/1~84/ | Engine CRANK SHAFT REAR |
| 03907 7205 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) TDJ,TPJ 6QA1 | 80/1~84/ | Engine CRANK SHAFT REAR |
| 03907 6017 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (6T~8T) CVR 6SD1 | 03/6~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 1353 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) CVR 6QA1(EXCEPT FLYWHEEL PTO) | 83/9~86/3 | Engine CRANK SHAFT REAR |
| 03907 1761 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (6T~8T) CVR 8PC1,8PD1 | 88/8~95/ | Engine CRANK SHAFT FRONT |
| 03907 3829 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (6T~8T) SLR DH100 (MIXER) | 76/~83/ | Engine CRANK SHAFT REAR |
| 03907 4301 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (6T~8T) CVR 6QA1 (MIXER) | 83/9~89/ | Engine CRANK SHAFT REAR |
| 03907 3221 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (6T~8T) SMR 8PB1 | 78/4~83/ | Engine CRANK SHAFT REAR |
| 03907 5289 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (6T~8T) CVR 8PC1 | 83/9~88/7 | Engine CRANK SHAFT REAR |
| 03907 5517 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (6T~8T) CVR 8PC1,8PD1 | 88/8~95/ | Engine CRANK SHAFT REAR |
| 03907 3889 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (6T~8T) CVR 8PE1 | 95/3~03/ | Engine CRANK SHAFT REAR |
| 03907 1745 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) SJR 6QA1(EXCEPT MIXER) | 81/8~83/ | Engine CRANK SHAFT REAR |
| 03907 3621 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (6T~8T) TD,TP,SLR DH100,D920 | 71/~77/ | Engine CRANK SHAFT FRONT |
| 03907 1585 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (6T~8T) CVR MAL5,MAL6,MAP6 T/M | 95/5~ | Transmission REAR COVER |
| 03907 1141 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) SJR461,531,601 | 81/8~83/ | Final Drive PINION |
| 03907 2513 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) CVR 16.5 INCH FINAL | 83/9~ | Final Drive PINION |
| 03907 2021 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (6T~8T) TD,TP 2 SPEED | 71/~84/ | Final Drive PINION |
| 03907 2453 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (6T~8T) SLR 2 SPEED | 73/~79/12 | Final Drive PINION |
| 03907 4653 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (6T~8T) TDK SINGLE SPEED | 80/1~84/ | Final Drive PINION |
| 03907 3457 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (6T~8T) CVR 6SD1 | 03/??? | Engine CRANK SHAFT FRONT |
| 03907 3193 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (6T~8T) TXD DA120,640 | 71/~84/ | Engine CRANK SHAFT FRONT |
| 03907 4929 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (6T~8T) CVR..8PE1 | 95/3~03/ | Engine CRANK SHAFT FRONT |
| 03907 6705 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (6T~8T) TD,TP,SLR DH100 | 77/~84/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 3713 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (6T~8T) TDK E120 | 80/1~84/ | Engine CRANK SHAFT FRONT |
| 03907 5885 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (6T~8T) TDJ,TPJ,SJR,CVR 6QA1 | 80/1~88/7 | Engine CRANK SHAFT FRONT |
| 03907 4629 | 1-09625-442-0 | 70 x 92 x 12 | TRUCK (6T~8T) CVR 6QA1 | 88/8~89/10 | Engine CRANK SHAFT FRONT |
| 03907 5901 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (6T~8T) SMR 8PB1 | 78/4~83/ | Engine CRANK SHAFT FRONT |
| 03907 6297 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (6T~8T) CVR 8PC1,8PD1 | 83/9~88/7 | Engine CRANK SHAFT FRONT |
| 03907 1589 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (6T~8T) CVR 17.5 INCH FINAL | 89/11~ | Final Drive PINION |
| 03907 3097 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (6T~8T) CVR 17.5 INCH FINAL | 83/9~89/10 | Final Drive PINION |
| 03907 5509 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (6T~8T) SMR360,361,SJR361 | 78/4~83/ | Final Drive PINION |
| 03907 2965 | 1-12569-009-0 | | TRUCK (6T~8T) DA120,640 | 71/~84/ | Engine VALVE STEM SEAL |
| 03907 5925 | 9-12569-072-0 | | TRUCK (6T~8T) E120 | 71/~83/ | Engine VALVE STEM SEAL |
| 03907 4289 | 9-12569-058-0 | | TRUCK (6T~8T) DA100,6QA1 | 75/~89/10 | Engine VALVE STEM SEAL |
| 03907 6225 | 1-12569-009-0 | | TRUCK (6T~8T) 8PC1,8PD1 | 83/9~91/6 | Engine VALVE STEM SEAL |
| 03907 4281 | 1-12569-019-1 | | TRUCK (6T~8T) 8PC1,8PD1,8PE1 | 91/7~03/ | Engine VALVE STEM SEAL |
| 03907 2637 | 1-12569-019-1 | | TRUCK (6T~8T) 6SD1 | 03/6~ | Engine VALVE STEM SEAL |
| 03907 2013 | 1-12569-020-0 | | TRUCK (6T~8T) 6WF1 | 03/6~ | Engine VALVE STEM SEAL |
| 03907 1437 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (6T~8T) CVR 6WF1 | 03/6~ | Engine CRANK SHAFT REAR |
| 03907 2817 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (8X4) P85,P90 P/S | 86/4~00/4 | Propeller Shaft CENTER BEARING (F&R) |
| 03907 3297 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (8X4) P90 P/S | 00/4~ | Propeller Shaft CENTER BEARING (F) |
| 03907 3285 | 1-09625-621-0 | 81 x 103 x 16 | TRUCK (8X4) P90 P/S | 00/4~ | Propeller Shaft CENTER BEARING |
| 03907 6857 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (8X4) P105,P115 P/S | 86/4~00/4 | Propeller Shaft CENTER BEARING (F&R) |
| 03907 6653 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (8X4) P115 P/S | 00/4~ | Propeller Shaft CENTER BEARING (F) |
| 03907 1221 | 1-09625-622-0 | 86 x 106 x 14 | TRUCK (8X4) P115 P/S | 00/4~ | Propeller Shaft CENTER BEARING |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 2145 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (8X4) P60,P90L P/S | 86/4~00/ | Propeller Shaft CENTER BEARING (F&R) |
| 03907 3133 | 1-09625-119-0 | 80 x 127 x 16 x 24 | TRUCK (8X4) CXH,CYH,CYJ G/RATIO 39/9,41/10,43/11,41/11 | 00/4~03/ | Final Drive PINION FORWARD |
| 03907 5781 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (8X4) CXH,CYH,CYJ | 89/9~ | Transmission FRONT COVER |
| 03907 4789 | 1-09625-119-0 | 80 x 127 x 16 x 24 | TRUCK (8X4) CXH,CYH,CYJ | 86/4~00/ | Final Drive PINION FORWARD |
| 03907 6829 | 1-09625-625-0 | 104 x 126 x 13 | TRUCK (8X4) MJX12 | 03/6~ | Transmission REAR COVER |
| 03907 2109 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (8X4) MJA,MJB,MJC,MJT T/M | 94/7~ | Transmission REAR COVER |
| 03907 6161 | 1-09625-359-0 | 80 x 100 x 12 | TRUCK (8X4) MJA,MJB,MJC T/M | 86/4~94/6 | Transmission REAR COVER |
| 03907 6417 | 1-09625-323-0 | 86 x 127 x 16 x 25 | TRUCK (8X4) CXH,CYH,CYJ EXC. G/RATIO 39/9,41/10,43/11,41/11 | 00/4~03/ | Final Drive PINION FORWARD |
| 03907 1125 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (8X4) MAF T/M | 86/4~94/ | Transmission REAR COVER |
| 03907 2421 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (8X4) CXH 16.5 INCH DIFF. | 86/4~94/ | Final Drive PINION REARWARD |
| 03907 4321 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (8X4) CXH | 86/4~89/8 | Transmission FRONT COVER |
| 03907 5777 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (8X4) 8PC1,8PD1 | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03907 5589 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (8X4) 8PD1,10PD1,12PD1,8PE1,10 PE1,12PE1 | 93/3~ | Engine CRANK SHAFT REAR |
| 03907 4877 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (8X4) MAG,MAH,MAL T/M | 86/4~ | Transmission REAR COVER |
| 03907 3249 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (8X4) 6SD1 | 86/4~88/7 | Engine CRANK SHAFT FRONT |
| 03907 7241 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (8X4) 8PC1 | 86/4~88/7 | Engine CRANK SHAFT REAR |
| 03907 1289 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (8X4) 6SD1 | 94/12~ | Engine CRANK SHAFT REAR |
| 03907 1381 | 1-09625-443-0 | 120 x 150 x 15 | TRUCK (8X4) 6SD1 | 86/4~94/ | Engine CRANK SHAFT REAR |
| 03907 4493 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (8X4) 6RB1 | 86/4~90/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5541 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (8X4) 6WA1,6WF1,6WG1 | 92/7~ | Engine CRANK SHAFT FRONT |
| 03907 1645 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (8X4) 8PD1,10PD1,12PD1,8PE1,10 PE1,12PE1 | 93/3~ | Engine CRANK SHAFT FRONT |
| 03907 5921 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (8X4) 8PC1,8PD1 | 86/12~93/2 | Engine CRANK SHAFT FRONT |
| 03907 3961 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (8X4) 10PC1,12PC1,10PD1,12PD1 | 86/4~93/2 | Engine CRANK SHAFT FRONT |
| 03907 3877 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (8X4) 8PC1 | 86/4~86/11 | Engine CRANK SHAFT FRONT |
| 03907 6785 | 1-09625-484-0 | 60 x 103 x 12 x 20 | TRUCK (8X4) CXH,CYH 14.5INCH DIFF .G/R 39/7,39/8,39/9,41/10 | 94/12~00/ | Final Drive PINION REARWARD |
| 03907 1241 | 1-09625-451-0 | 120 x 153 x 15 | TRUCK (8X4) 6SD1 | 88/8~94/ | Engine CRANK SHAFT FRONT |
| 03907 4425 | 1-09625-323-0 | 86 x 127 x 16 x 25 | TRUCK (8X4) CYH,CYJ ALL | 03/5~ | Final Drive PINION FORWARD |
| 03907 5041 | 1-09625-442-0 | 70 x 92 x 12 | TRUCK (8X4) 6RB1 | 88/8~90/ | Engine CRANK SHAFT FRONT |
| 03907 3141 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (8X4) 6RB1 | 86/4~88/7 | Engine CRANK SHAFT FRONT |
| 03907 5397 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (8X4) CYH,CYJ ALL | 03/5~ | Final Drive PINION REARWARD |
| 03907 4521 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (8X4) CXH,CYH,CYJ EXC. G/RATOI 39/9,41/10 | 00/4~03/ | Final Drive PINION REARWARD |
| 03907 1705 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (8X4) CXH,CYH 14.5INCH DIFF .G/R 43/11,41/11 | 94/12~00/ | Final Drive PINION REARWARD |
| 03907 4401 | 1-12569-019-1 | | TRUCK (8X4) 6SD1 | 94/12~ | Engine VALVE STEM SEAL |
| 03907 5221 | 1-09625-484-0 | 60 x 103 x 12 x 20 | TRUCK (8X4) CXH,CYH,CYJ G/RATIO 39/9,41/10 | 00/4~03/ | Final Drive PINION REARWARD |
| 03907 5269 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (8X4) 6WA1,6WF1,6WG1 | 92/7~ | Engine CRANK SHAFT REAR |
| 03907 6541 | 1-09625-484-0 | 60 x 103 x 12 x 20 | TRUCK (8X4) CXH 14.5 INCH DIFF. | 86/4~94/ | Final Drive PINION REARWARD |
| 03907 6633 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (8X4) 6SD1 | 94/12~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4625 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | TRUCK (8X4) CYH EXC. 25T HEAVY CHASSISRD2 | 94/12~00/4 | Wheel Hub FRONT REARWARD |
| 03907 4097 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (8X4) CYJ | 97/7~ | Wheel Hub REAR INNER (F&R) |
| 03907 2625 | 1-09625-331-0 | 56 x 122 x 10.5 | TRUCK (8X4) CXH | 83/8~ | Wheel Hub REAR OUTER (F&R) |
| 03907 6437 | 1-09625-331-0 | 56 x 122 x 10.5 | TRUCK (8X4) CYH EXC. (23/25T) LIGHT CHASSIS Y32 | 94/12~00/4 | Wheel Hub REAR OUTER (F&R) |
| 03907 6765 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CYH (23/25T) LIGHT CHASSIS Y32 | 95/9~00/4 | Wheel Hub FRONT REARWARD |
| 03907 7193 | 1-09625-331-0 | 56 x 122 x 10.5 | TRUCK (8X4) CYH EXC. 25T HEAVY CHASSIS RD2 | 94/12~00/4 | Wheel Hub REAR OUTER (F&R) |
| 03907 6193 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (8X4) CYH (23/25T) LIGHT CHASSIS Y32 | 95/9~00/4 | Wheel Hub REAR OUTER (F&R) |
| 03907 5257 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (8X4) CYH 25T HEAVY CHASSIS RD2 | 94/12~00/4 | Wheel Hub REAR OUTER (F&R) |
| 03907 4197 | 1-12569-013-0 | | TRUCK (8X4) 6RB1 | 86/4~90/ | Engine VALVE STEM SEAL |
| 03907 1669 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (8X4) CYJ | 97/7~ | Wheel Hub REAR OUTER (F&R) |
| 03907 2185 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (8X4) CYH ALL | 00/4~ | Wheel Hub REAR INNER (F&R) |
| 03907 7081 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | TRUCK (8X4) CYH EXC. (23/25T) LIGHT CHASSIS Y32 | 94/12~00/4 | Wheel Hub FRONT REARWARD |
| 03907 1489 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | TRUCK (8X4) CXH | 83/8~ | Wheel Hub FRONT REARWARD |
| 03907 1189 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (8X4) CYH EXC. (23/25T) LIGHT CHASSIS Y32 | 84/12~00/4 | Wheel Hub FRONT FORWARD |
| 03907 4645 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (8X4) CXH | 94/11~ | Wheel Hub FRONT FORWARD |
| 03907 2577 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CYJ | 97/7~ | Wheel Hub FRONT FORWARD |
| 03907 3989 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CYH ALL | 00/4~ | Wheel Hub FRONT FORWARD |
| 03907 6621 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CYH (23/25T) LIGHT CHASSIS Y32 | 95/9~00/4 | Wheel Hub FRONT FORWARD |
| 03907 2945 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CXH | 83/8~94/10 | Wheel Hub FRONT FORWARD |
| 03907 4933 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (8X4) CYH ALL | 00/4~ | Wheel Hub REAR OUTER (F&R) |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5753 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CYH ALL | 00/4~ | Wheel Hub FRONT REARWARD |
| 03907 7061 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (8X4) 10PC1,12PC1,10PD1,12PD1 | 86/4~93/2 | Engine CRANK SHAFT REAR |
| 03907 7089 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (8X4) CYH (23/25T) LIGHT CHASSIS Y32 | 95/9~00/4 | Wheel Hub REAR INNER (F&R) |
| 03907 4461 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | TRUCK (8X4) CYH EXC. 25T HEAVY CHASSIS RD2 | 94/12~00/4 | Wheel Hub REAR INNER (F&R) |
| 03907 4421 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | TRUCK (8X4) CYH EXC.(23/25T) LIGHT CHASSIS Y32 | 94/12~00/4 | Wheel Hub REAR INNER (F&R) |
| 03907 6241 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | TRUCK (8X4) CXH | 83/8~ | Wheel Hub REAR INNER (F&R) |
| 03907 3901 | 1-12569-009-0 | | TRUCK (8X4) 6SD1 | 86/4~94/ | Engine VALVE STEM SEAL |
| 03907 3205 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (8X4) CYH 25T HEAVY CHASSIS RD2 | 94/12~04/ | Wheel Hub FRONT REARWARD |
| 03907 1781 | 1-12569-009-0 | | TRUCK (8X4) 8P#,10P#,12P# | 86/4~91/6 | Engine VALVE STEM SEAL |
| 03907 2677 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (8X4) CYH 25T HEAVY CHASSIS RD2 | 94/12~00/4 | Wheel Hub REAR INNER (F&R) |
| 03907 5741 | 1-12569-019-1 | | TRUCK (8X4) 8P#,10P#,12P# | 91/7~ | Engine VALVE STEM SEAL |
| 03907 4061 | 1-12569-019-1 | | TRUCK (8X4) 6WA1,6WF1,6WG1 | 92/7~ | Engine VALVE STEM SEAL |
| 03907 2909 | 1-09625-129-0 | 85 x 128 x 11 x 21 | TRUCK (8X4) CYJ | 97/7~ | Wheel Hub FRONT REARWARD |
| 03907 2837 | 1-09625-119-0 | 80 x 127 x 16 x 24 | TRUCK (ALL WHEEL DRIVE) CVS NO SPIN DIFF. | 00/4~ | Final Drive PINION (REAR FORWARD) |
| 03907 5469 | 1-09625-119-0 | 80 x 127 x 16 x 24 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW | 87/5~00/4 | Final Drive PINION (REAR FORWARD) |
| 03907 7137 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW | 90/5~ | Transmission FRONT COVER |
| 03907 6853 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (ALL WHEEL DRIVE) CVS,CXW | 87/5~90/4 | Transmission FRONT COVER |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 4121 | 1-12569-019-1 | | TRUCK (ALL WHEEL DRIVE) 10P#,12P# | 91/7~ | Engine VALVE STEM SEAL |
| 03907 7065 | 1-42329-014-0 | 178 x 205 x 17 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW W8X,W8Y | 00/4~ | Wheel Hub FRONT |
| 03907 3245 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW | 87/5~ | Wheel Hub REAR INNER |
| 03907 2717 | 1-09625-309-0 | 150 x 180 x 14 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW W9L | 00/4~ | Wheel Hub FRONT |
| 03907 5493 | 1-09625-309-0 | 150 x 180 x 14 | TRUCK (ALL WHEEL DRIVE) CVS,CXW ALL | 87/5~00/4 | Wheel Hub FRONT |
| 03907 6949 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW | 87/5~ | Wheel Hub REAR OUTER |
| 03907 1521 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (ALL WHEEL DRIVE) 10P#,12P# | 93/3~ | Engine CRANK SHAFT FRONT |
| 03907 5153 | 1-12569-019-1 | | TRUCK (ALL WHEEL DRIVE) 8TD1 | 00/4~ | Engine VALVE STEM SEAL |
| 03907 5733 | 1-12569-009-0 | | TRUCK (ALL WHEEL DRIVE) 8PC1,10P# | 87/5~91/6 | Engine VALVE STEM SEAL |
| 03907 4797 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (ALL WHEEL DRIVE) 10P#,12P# | 93/3~ | Engine CRANK SHAFT REAR |
| 03907 6669 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (ALL WHEEL DRIVE) 8PC1 | 88/8~90/ | Engine CRANK SHAFT REAR |
| 03907 6613 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (ALL WHEEL DRIVE) 10PC1,10PD1 | 87/5~93/2 | Engine CRANK SHAFT REAR |
| 03907 6673 | 1-09625-559-0 | 139 x 171 x 19 | TRUCK (ALL WHEEL DRIVE) 8TD1 | 00/4~ | Engine CRANK SHAFT REAR |
| 03907 3361 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (ALL WHEEL DRIVE) 8TD1 | 00/4~ | Engine CRANK SHAFT FRONT |
| 03907 3573 | 1-09625-323-0 | 86 x 127 x 16 x 25 | TRUCK (ALL WHEEL DRIVE) CXW,CYW | 00/4~ | Final Drive PINION (REAR FORWARD) |
| 03907 3477 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (ALL WHEEL DRIVE) 8PC1 | 88/8~90/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.7 ISUZU

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03907 5249 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (ALL WHEEL DRIVE) 10PC1,10PD1 | 87/5~93/2 | Engine CRANK SHAFT FRONT |
| 03907 7249 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (ALL WHEEL DRIVE) 8PC1 | 87/5~88/7 | Engine CRANK SHAFT FRONT |
| 03907 5117 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW ALL | 00/4~ | Final Drive PINION (REAR REARWARD) |
| 03907 1361 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW 17.5 INCH DIFF. | 90/5~00/ | Final Drive PINION (REAR REARWARD) |
| 03907 5001 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW 17.5 INCH DIFF. | 87/5~90/4 | Final Drive PINION (REAR REARWARD) |
| 03907 5965 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (ALL WHEEL DRIVE) CVS,CXW,CYW 16.5 INCH DIFF. | 87/5~95/3 | Final Drive PINION (REAR REARWARD) |
| 03907 4849 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (ALL WHEEL DRIVE) 8PC1 | 87/5~88/7 | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6387 | 9828-55110 | 55 x 72 x 9 x 15 | BUS RB145,1W,RH160,1W | 85/2~ | Transmission REAR COVER |
| 03908 5683 | 9828-55110 | 55 x 72 x 9 x 15 | BUS RJ170,172,RR170,172 | 80/10~83/11 | Transmission REAR COVER |
| 03908 5035 | 9828-55110 | 55 x 72 x 9 x 15 | BUS RL30#.32# | 75/~81/ | Transmission REAR COVER |
| 03908 5011 | 9828-55110 | 55 x 72 x 9 x 15 | BUS AM,AC140 5 SPEED T/M | 76/~89/ | Transmission REAR COVER |
| 03908 6891 | 9828-47101 | 47 x 65 x 9 | BUS AB115,2W,RB115,2W | 85/2~ | Transmission REAR COVER |
| 03908 5635 | 9828-55119 | 55 x 78 x 12 | BUS HT23#,2M,HU23#,2M EE DRIVE | 85/8~ | Transmission FRONT COVER |
| 03908 3915 | 9828-55113 | 55 x 72 x 9 | BUS HT23#,2M,HU23#,2M EXCEPT EE DRIVE | 85/8~ | Transmission FRONT COVER |
| 03908 7379 | 13719-1020 | | BUS W04C,H06C,H07C,H07D | 89/11~95/6 | Engine VALVE STEM SEAL |
| 03908 2547 | 9828-55113 | 55 x 72 x 9 | BUS RU1F,2F,3F | 90/7~ | Transmission FRONT COVER |
| 03908 7867 | 9828-55113 | 55 x 72 x 9 | BUS RT22#,RU22#,60#,63# | 82/10~90/ | Transmission FRONT COVER |
| 03908 5155 | 9828-55113 | 55 x 72 x 9 | BUS RC,RS,RV | 78/~84/ | Transmission FRONT COVER |
| 03908 8379 | 9828-60119 | 60 x 75 x 9 x 15 | BUS AC140 6 SPEED T/M | 83/8~89/ | Transmission REAR COVER |
| 03908 5331 | 9828-55113 | 55 x 72 x 9 | BUS HT27#,3K,HU27#,3K | 83/12~ | Transmission FRONT COVER |
| 03908 7211 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RJ170,171,RR170,171,172 ,191,192 | 83/12~90/ | Transmission REAR COVER |
| 03908 6931 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RH1J,RJ3H,1J,RR2H,3H, 1J | 90/9~ | Transmission REAR COVER |
| 03908 5843 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RJ172 6 SPEED T/M | 83/12~90/ | Transmission REAR COVER |
| 03908 1523 | 9828-60119 | 60 x 75 x 9 x 15 | BUS RT174,RU174,192,3H | 86/8~ | Transmission REAR COVER |
| 03908 1507 | 9828-60119 | 60 x 75 x 9 x 15 | BUS CH160,3H,1J | 87/12~ | Transmission REAR COVER |
| 03908 6491 | 9828-65108 | 65 x 95 x 14 x 22 | BUS RC,RE,RS | 69/~79/12 | Transmission REAR COVER |
| 03908 2115 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RC,RE | 80/1~84/ | Transmission REAR COVER |
| 03908 3379 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RS1#,3#...6 SPEED | 80/1~82/ | Transmission REAR COVER |
| 03908 7075 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RV7#,5#...6 SPEED | 78/5~82/ | Transmission REAR COVER |
| 03908 4451 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS RU22#,RT22# | 82/10~90/ | Transmission REAR COVER |
| 03908 2971 | 9828-48120 | 48 x 60 x 9 | BUS RT174,RU174,192,3H,CH 1J | 86/8~ | Transmission FRONT COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6635 | 13719-1360 | | BUS J05C,J08C | 95/7~98/1 | Engine VALVE STEM SEAL |
| 03908 4107 | 9828-57103 | 57 x 124 x 13 | BUS RH,RJ,RR,CH,HR | 84/~ | Wheel Hub REAR OUTER |
| 03908 3851 | 13719-1470 | | BUS J05C,J08C | 98/2~ | Engine VALVE STEM SEAL |
| 03908 8243 | 9828-66106 | 66 x 134 x 16 | BUS RK | 84/~90/ | Wheel Hub REAR OUTER |
| 03908 4931 | 9828-70101 | 70 x 95 x 14 x 20.5 | BUS HT#,HU# | 83/12~ | Transmission REAR COVER |
| 03908 6971 | 9828-85106 | 84 x 100 x 10 | BUS AB,AC,AM,RB | 76/~ | Wheel Hub FRONT |
| 03908 5675 | 9828-01137 | 101 x 114 x 10 | BUS RH,RJ,RL,RR,CH | 75/~ | Wheel Hub FRONT |
| 03908 7387 | 9828-01207 | 138 x 152 x 12 | BUS RC,RE,RK,RM,RS,RT,RU,RV,HR,HT,HU | 69/~ | Wheel Hub FRONT |
| 03908 5747 | 9828-01136 | 116 x 132 x 11 | BUS AC,AM | 76/~89/ | Wheel Hub REAR INNER |
| 03908 7707 | 9828-01204 | 145 x 164 x 14 | BUS RK | 84/~90/ | Wheel Hub REAR INNER |
| 03908 3099 | 9828-01203 | 127 x 147 x 11 | BUS RH,RJ,RR,CH,HR | 84/~ | Wheel Hub REAR INNER |
| 03908 8171 | 9828-01130 | 146 x 170 x 18 | BUS RC,RE,RS,RV | 69/~84/ | Wheel Hub REAR INNER |
| 03908 3691 | 9828-01193 | 154 x 175 x 13 | BUS RM,RT,RU,HT,HU | 82/~ | Wheel Hub REAR INNER |
| 03908 8091 | 9828-40101 | 40 x 50 x 6.5 | BUS AC,AM | 76/~89/ | Wheel Hub REAR OUTER |
| 03908 2875 | 9828-48112 | 48 x 109 x 13 | BUS AB,RB | 85/~ | Wheel Hub REAR OUTER |
| 03908 8475 | 9828-60108 | 60 x 74 x 7.5 | BUS RC,RE,RS,RV | 69/~84/ | Wheel Hub REAR OUTER |
| 03908 3731 | 9828-01149 | 120 x 140 x 12 | BUS RJ,RL,RR | 75/~83/ | Wheel Hub REAR INNER |
| 03908 2587 | 9828-48120 | 48 x 60 x 9 | BUS RJ172 5 SPEED T/M | 83/12~90/ | Transmission FRONT COVER |
| 03908 5107 | 9828-01228 | 100 x 135 x 17 | BUS J05C,J08C | 95/7~ | Engine CRANK SHAFT REAR |
| 03908 1411 | 9828-76101 | 76 x 164 x 14 | BUS RM,RT,RU,HT,HU | 82/~ | Wheel Hub REAR OUTER |
| 03908 8155 | 9828-30101 | 30 x 42 x 8 | BUS AB115,RB115 | 85/2~90/ | Transmission FRONT COVER |
| 03908 4939 | 9828-37103 | 37 x 50 x 6 | BUS AC140,AM101 5 SPEED,RB14# | 80/1~89/ | Transmission FRONT COVER |
| 03908 6979 | 9828-37103 | 37 x 50 x 6 | BUS RJ170,172,RR170,172 | 80/10~83/11 | Transmission FRONT COVER |
| 03908 1619 | 9828-37103 | 37 x 50 x 6 | BUS RL301,321 | 80/1~81/ | Transmission FRONT COVER |
| 03908 5651 | 9828-43102 | 43 x 63 x 9 | BUS AC140 6 SPEED T/M | 83/8~89/ | Transmission FRONT COVER |
| 03908 2067 | 9828-43102 | 43 x 63 x 9 | BUS AB2W,RB1W,2W,CH#,RH# | 87/12~ | Transmission FRONT COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7683 | 9828-43102 | 43 x 63 x 9 | BUS RJ170,RR170 | 83/12~88/ | Transmission FRONT COVER |
| 03908 8371 | 9828-43102 | 43 x 63 x 9 | BUS RJ172,RR172 6 SPEED T/M | 83/12~90/ | Transmission FRONT COVER |
| 03908 6907 | 9828-48120 | 48 x 60 x 9 | BUS RJ171,3H,1J,RR171,191,192,2H,3H,1J | 88/10~ | Transmission FRONT COVER |
| 03908 7507 | 9828-45104 | 45 x 55 x 7.5 | BUS RJ,RL,RR | 75/~83/ | Wheel Hub REAR OUTER |
| 03908 8443 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RJ#,RR# | 88/10~98/6 | Final Drive PINION |
| 03908 6779 | 9828-58105 | 58 x 75 x 9 | BUS EC100,EH100,300 RL,AM | 70/~77/ | Engine CRANK SHAFT FRONT |
| 03908 3107 | 9828-80117 | 80 x 136 x 9 x 25.5 | BUS HT#,HU#,RU1F,2F,3F,4F | 00/4~ | Final Drive PINION |
| 03908 3019 | 9828-80114 | 80 x 136 x 9 x 25 | BUS RU1F,2F,3F,4F | 98/10~00/3 | Final Drive PINION |
| 03908 6715 | 9828-65130 | 65 x 105 x 9 x 25 | BUS HR# | 01/11~ | Final Drive PINION |
| 03908 6483 | 9828-65127 | 65 x 114 x 9 x 25 | BUS HR# | 99/1~01/10 | Final Drive PINION |
| 03908 2691 | 9828-65127 | 65 x 114 x 9 x 25 | BUS RH#,RR#,CH# | 98/7~ | Final Drive PINION |
| 03908 3843 | 9828-80110 | 80 x 136 x 20 x 26 | BUS RU1F,2F,3F,4F | 90/7~98/9 | Final Drive PINION |
| 03908 8427 | 9828-80110 | 80 x 136 x 20 x 26 | BUS RU60#,63# | 85/9~90/ | Final Drive PINION |
| 03908 8339 | 9828-80115 | 80 x 124 x 19 x 25 | BUS HT#,HU# | 83/12~00/3 | Final Drive PINION |
| 03908 6411 | 9828-80115 | 80 x 124 x 19 x 25 | BUS RU60#,63# | 82/6~85/8 | Final Drive PINION |
| 03908 1075 | 9828-75111 | 75 x 100 x 13 x 18 | BUS RC,RE,RS,RV | 69/~84/ | Final Drive PINION |
| 03908 1027 | 9828-65116 | 65 x 88 x 12 x 19 | BUS EC100,EH100,300 RL,AM | 78/~83/ | Engine CRANK SHAFT FRONT |
| 03908 4947 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RH#,CH# | 87/12~98/6 | Final Drive PINION |
| 03908 2283 | 9828-80115 | 80 x 124 x 19 x 25 | BUS RU3H,1J | 90/6~ | Final Drive PINION |
| 03908 7739 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RJ17#,RR17#...REDUCTION RATIO 4.100 | 83/12~88/9 | Final Drive PINION |
| 03908 7107 | 9828-63104 | 63 x 100 x 12 | BUS RJ17#,RR17#...REDUCTION RATIO 5.142,5.571 | 83/12~88/9 | Final Drive PINION |
| 03908 6803 | 9828-63104 | 63 x 100 x 12 | BUS RJ#,RR# | 80/10~83/11 | Final Drive PINION |
| 03908 4499 | 9828-63104 | 63 x 100 x 12 | BUS RL | 75/4~81/ | Final Drive PINION |
| 03908 4571 | 9828-58109 | 58 x 102 x 8 x 22 | BUS AB,RB | 85/2~ | Final Drive PINION |
| 03908 6435 | 9828-52111 | 52 x 100 x 15 | BUS AC,AM | 76/~89/ | Final Drive PINION |
| 03908 6603 | 9828-75119 | 75 x 100 x 13 x 19 | BUS RU60#,63#,1F,2F,3F | 82/6~ | Transmission REAR COVER |
| 03908 6683 | 9828-75119 | 75 x 100 x 13 x 19 | BUS RV5#...5 SPEED T/M | 78/5~82/ | Transmission REAR COVER |
| 03908 4883 | 9828-75119 | 75 x 100 x 13 x 19 | BUS RS3#...5 SPEED T/M | 80/1~82/ | Transmission REAR COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7171 | 9828-01206 | 107 x 123 x 11 | BUS AB,RB | 85/~ | Wheel Hub REAR INNER |
| 03908 4643 | 9828-01226 | 125 x 177 x 17.5 | BUS F17D,F20C,F21C | 95/7~ | Engine CRANK SHAFT REAR |
| 03908 7459 | 9828-65113 | 65 x 114 x 10 x 25.5 | BUS RT174,RU174,192 | 86/8~90/ | Final Drive PINION |
| 03908 4131 | 9828-01168 | 135 x 165 x 14 x 20.5 | BUS EF3#,5#,7# | 78/~90/ | Engine CRANK SHAFT REAR |
| 03908 1899 | 9828-01223 | 116 x 151 x 17 | BUS P11C,M10U,K13U | 95/4~ | Engine CRANK SHAFT REAR |
| 03908 4955 | 9828-01200 | 122 x 150 x 12 x 18 | BUS EM100 RT22#,RU22# | 82/10~90/ | Engine CRANK SHAFT REAR |
| 03908 8323 | 9828-80115 | 80 x 124 x 19 x 25 | BUS RT22#,RU22# | 82/10~89/ | Final Drive PINION |
| 03908 1691 | 9828-01168 | 135 x 165 x 14 x 20.5 | BUS F17#,F20C | 90/7~95/6 | Engine CRANK SHAFT REAR |
| 03908 5027 | 9828-65116 | 65 x 88 x 12 x 19 | BUS EH700 RL,RJ,RR | 80/~83/ | Engine CRANK SHAFT FRONT |
| 03908 3987 | 9828-01168 | 135 x 165 x 14 x 20.5 | BUS ER200,EB200,400 | 78/~84/ | Engine CRANK SHAFT REAR |
| 03908 7907 | 9828-01158 | 130 x 161 x 14 | BUS DK20 | 69/~78/ | Engine CRANK SHAFT REAR |
| 03908 2803 | 9828-00109 | 100 x 120 x 13 x 18 | BUS W04#.W06# | 83/~ | Engine CRANK SHAFT REAR |
| 03908 5587 | 9828-01167 | 106 x 126 x 12 | BUS H06#,H07# | 83/~ | Engine CRANK SHAFT REAR |
| 03908 7323 | 9828-01167 | 106 x 126 x 12 | BUS EH300,500,700 | 74/~83/ | Engine CRANK SHAFT REAR |
| 03908 1435 | 9828-00107 | 100 x 120 x 13 | BUS EC100,EH100 | 69/~83/ | Engine CRANK SHAFT REAR |
| 03908 8035 | 9828-79103 | 79 x 114 x 17 | BUS J05C,J08C | 95/7~ | Engine CRANK SHAFT FRONT |
| 03908 7395 | 9828-96109 | 96 x 131 x 17.5 | BUS F17D,F20C,F21C | 85/7~ | Engine CRANK SHAFT FRONT |
| 03908 3051 | 9828-83103 | 83 x 118 x 18 | BUS M10U | 95/4~ | Engine CRANK SHAFT FRONT |
| 03908 7811 | 9828-75111 | 75 x 100 x 13 x 18 | BUS DK20 RC1#,3#,4# | 69/~78/ | Engine CRANK SHAFT FRONT |
| 03908 7235 | 9828-65116 | 65 x 88 x 12 x 19 | BUS H06#,H07#...RT174,RU174,192,3H,CH3H | 86/8~ | Engine CRANK SHAFT FRONT |
| 03908 4331 | 9828-01201 | 125 x 155 x 14 x 23 | BUS EK200 | 79/~ | Engine CRANK SHAFT REAR |
| 03908 8131 | 9828-65116 | 65 x 88 x 12 x 19 | BUS H06#,H07#...RJ#,RR# | 83/~ | Engine CRANK SHAFT FRONT |
| 03908 3667 | 9828-75145 | 75 x 114 x 17 | BUS K13U | 95/4~ | Engine CRANK SHAFT FRONT |
| 03908 7435 | 9828-58104 | 58 x 75 x 9 x 14.5 | BUS W04#,W06#...AB#,AC#,RH#,RB#,CH160 | 83/~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3643 | 9828-80102 | 80 x 105 x 13 | BUS ER200,EB200,400 RC301,321,RE# | 78/~84/ | Engine CRANK SHAFT FRONT |
| 03908 7971 | 9828-70102 | 70 x 95 x 13 | BUS EK200 RC7# | 79/~83/ | Engine CRANK SHAFT FRONT |
| 03908 2651 | 9828-70110 | 70 x 95 x 13 x 20 | BUS EK200 HT27#,HU27# | 84/~90/ | Engine CRANK SHAFT FRONT |
| 03908 6859 | 9828-96101 | 96 x 124 x 14 x 21 | BUS EF3#,5#,7#...RS#,RV#,RU 60#,63# | 78/~90/ | Engine CRANK SHAFT FRONT |
| 03908 4835 | 9828-96101 | 96 x 124 x 14 x 21 | BUS F17#,F20C RU1F,2F,3F | 90/7~95/6 | Engine CRANK SHAFT FRONT |
| 03908 5995 | 9828-75140 | 75 x 100 x 13 x 20 | BUS EM100 RT22#,RU22# | 82/10~90/ | Engine CRANK SHAFT FRONT |
| 03908 6051 | 9828-75140 | 75 x 100 x 13 x 20 | BUS P11C | 99/6~ | Engine CRANK SHAFT FRONT |
| 03908 3611 | 1-09625-444-0 | 78 x 163 x 16 | BUS CRA,CSA,CQ,CH,CL,CJ, CP AIR BRAKE | 79/10~84/ | Wheel Hub REAR OUTER |
| 03908 6251 | 1-12569-009-0 | | BUS 8P#,10P#,12P# | 84/3~91/6 | Engine VALVE STEM SEAL |
| 03908 4787 | 1-09625-425-1 | 120 x 153 x 15 | BUS LV 8PC | 88/8~89/ | Engine CRANK SHAFT REAR |
| 03908 7715 | 1-09625-525-2 | 111 x 153 x 16.5 | BUS LV 8P#,10P#,12P# | 93/3~ | Engine CRANK SHAFT REAR |
| 03908 3707 | 1-09625-559-0 | 139-171-19 x x | BUS LV 8TD1 | 00/4~ | Engine CRANK SHAFT REAR |
| 03908 1723 | 5-12569-001-0 | | BUS 6BG1 | 84/3~90/6 | Engine VALVE STEM SEAL |
| 03908 2227 | 9-12569-058-0 | | BUS 6QA2,6QB2 | 84/3~95/ | Engine VALVE STEM SEAL |
| 03908 3011 | 1-09625-013-0 | | BUS 6RB2 | 84/3~95/ | Engine VALVE STEM SEAL |
| 03908 1267 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | BUS BA | 66/~79/ | Wheel Hub REAR INNER |
| 03908 6347 | 1-09625-444-0 | 78 x 163 x 16 | BUS LT AIR SUS. | 89/4~00/3 | Wheel Hub REAR OUTER |
| 03908 6851 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | BUS LT ALL | 00/4~ | Wheel Hub REAR INNER |
| 03908 3459 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | BUS LT AIR SUS. | 89/4~00/3 | Wheel Hub REAR INNER |
| 03908 1307 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | BUS LV | 84/3~ | Wheel Hub REAR INNER |
| 03908 6619 | 9-09924-393-0 | 123 x 184 x 15 x 28 | BUS CRA,CSA,CQ,CH,CL,CJ, CP AIR BRAKE | 79/10~84/ | Wheel Hub REAR INNER |
| 03908 4075 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | BUS CRA,CSA,CQ,CH,CL,CJ, CP OIL BRAKE | 76/~84/ | Wheel Hub REAR INNER |
| 03908 2723 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | BUS BU | 67/~79/ | Wheel Hub REAR INNER |
| 03908 1627 | 1-09625-569-0 | 95 x 132 x 12 x 21.5 | BUS CDM | 82/5~84/ | Wheel Hub REAR INNER |
| 03908 6459 | 9-09924-470-0 | 64 x 132.5 x 13 | BUS BA | 69/~79/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4803 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | BUS ECM,EDM | 78/11~84/ | Wheel Hub REAR INNER |
| 03908 6611 | 9-09924-470-0 | 64 x 132.5 x 13 | BUS ECM,EDM | 78/11~82/ | Wheel Hub REAR OUTER |
| 03908 7667 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS LT ALL | 95/7~ | Wheel Hub FRONT |
| 03908 2395 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS LT AIR SUS. | 89/4~95/ | Wheel Hub FRONT |
| 03908 8491 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS LV | 84/3~ | Wheel Hub FRONT |
| 03908 7011 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS CRA,CSA,CQ,CH,CL,CJ, CP | 76/~84/ | Wheel Hub FRONT |
| 03908 2259 | 1-09625-041-0 | 120 x 140 x 10.5 | BUS BU | 73/7~79/ | Wheel Hub FRONT |
| 03908 2819 | 1-09625-129-0 | 85 x 128 x 11 x 21 | BUS LT LEAF SUS. | 84/3~95/ | Wheel Hub FRONT |
| 03908 4739 | 1-09625-129-0 | 85 x 128 x 11 x 21 | BUS ECM,EDM | 78/11~84/ | Wheel Hub FRONT |
| 03908 3899 | 1-09625-568-0 | 75 x 112 x 10 x 17.5 | BUS CDM | 82/5~84/ | Wheel Hub FRONT |
| 03908 5499 | 9-09924-407-0 | 76 x 115 x 13 x 21 | BUS BA | 66/~79/ | Wheel Hub FRONT |
| 03908 2451 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | BUS LT LEAF SUS. | 84/3~00/3 | Wheel Hub REAR INNER |
| 03908 1419 | 1-09625-502-0 | 40 x 55 x 9 | BUS ECM,EDM,CDM | 78/11~84/ | Transmission FRONT COVER |
| 03908 3603 | 1-12569-019-1 | | BUS 8TD1 | 00/4~ | Engine VALVE STEM SEAL |
| 03908 1667 | 8-94396-609-2 | | BUS 6HE1,6HH1 | 90/7~99/5 | Engine VALVE STEM SEAL |
| 03908 5067 | 8-97120-307-0 | | BUS 6HH1 | 99/6~ | Engine VALVE STEM SEAL |
| 03908 3475 | 1-09625-497-0 | 48 x 62 x 9 | BUS LV7# | 86/11~90/5 | Transmission FRONT COVER |
| 03908 4147 | 1-09625-497-0 | 48 x 62 x 9 | BUS LV2#,3# | 84/3~89/10 | Transmission FRONT COVER |
| 03908 7227 | 1-09625-497-0 | 48 x 62 x 9 | BUS CQ,CH | 81/11~84/ | Transmission FRONT COVER |
| 03908 4587 | 1-09625-497-0 | 48 x 62 x 9 | BUS CRA,CSA | 80/~84/ | Transmission FRONT COVER |
| 03908 6555 | 1-09625-502-0 | 40 x 55 x 9 | BUS LT | 84/3~93/6 | Transmission FRONT COVER |
| 03908 6811 | 9-09924-351-0 | 86 x 130 x 15 | BUS BA | 66/~68/ | Wheel Hub REAR OUTER |
| 03908 1699 | 1-09625-502-0 | 40 x 55 x 9 | BUS CRA | 77/8~79/ | Transmission FRONT COVER |
| 03908 3635 | 1-12569-019-1 | | BUS 8P#,10P#,12P# | 91/6~ | Engine VALVE STEM SEAL |
| 03908 3123 | 1-09625-502-0 | 40 x 55 x 9 | BUS BA,BU45KYZ | 73/~79/ | Transmission FRONT COVER |
| 03908 2619 | 1-09625-444-0 | 78 x 163 x 16 | BUS LT ALL | 00/4~ | Wheel Hub REAR OUTER |
| 03908 3443 | 1-09625-444-0 | 78 x 163 x 16 | BUS LV | 84/3~ | Wheel Hub REAR OUTER |
| 03908 6443 | 1-09625-524-3 | 111 x 153 x 16.5 | BUS LV 8TD1 | 00/4~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7955 | 1-09625-379-0 | 74 x 142.9 x 17.5 | BUS CRA,CSA,CQ,CH,CL,CJ, CP OIL BRAKE | 79/10~84/ | Wheel Hub REAR OUTER |
| 03908 7611 | 9-09924-374-0 | 71 x 142 x 14 | BUS CRA | 76/~79/9 | Wheel Hub REAR OUTER |
| 03908 4691 | 9-09924-374-0 | 71 x 142 x 14 | BUS BU | 87/~79/ | Wheel Hub REAR OUTER |
| 03908 7475 | 1-09625-331-0 | 56 x 122 x 10.5 | BUS CDM | 82/5~84/ | Wheel Hub REAR OUTER |
| 03908 1019 | 9-09924-470-0 | 64 x 132.5 x 13 | BUS LT LEAF SUS. | 84/3~00/3 | Wheel Hub REAR OUTER |
| 03908 1931 | 1-09625-502-0 | 40 x 55 x 9 | BUS CP | 80/2~84/ | Transmission FRONT COVER |
| 03908 7483 | 1-09625-565-0 | 40 x 55 x 7 | BUS LT | 93/7~ | Transmission FRONT COVER |
| 03908 6827 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS BA | 77/6~79/ | Final Drive PINION |
| 03908 3939 | 1-09625-173-0 | 60 x 77 x 12 | BUS BA | 66/~77/5 | Final Drive PINION |
| 03908 5235 | 1-09625-515-0 | 67 x 90 x 12 | BUS LV MLH T/M | 86/4~99/ | Transmission REAR COVER |
| 03908 1755 | 1-09625-578-1 | 78 x 97 x 13 | BUS LV MAL,MAP T/M | 95/4~ | Transmission REAR COVER |
| 03908 4619 | 1-09625-579-1 | 74 x 97 x 13 | BUS LV MAF T/M | 86/4~95/ | Transmission REAR COVER |
| 03908 2571 | 1-09625-579-1 | 74 x 97 x 13 | BUS LV ALL | 84/3~86/3 | Transmission REAR COVER |
| 03908 2755 | 1-09625-579-1 | 74 x 97 x 13 | BUS CQ,CH MAB5 | 83/6~84/ | Transmission REAR COVER |
| 03908 4867 | 1-09625-207-0 | 73 x 96 x 12 | BUS CQ,CH MAB5 | 82/1~83/5 | Transmission REAR COVER |
| 03908 7835 | 1-09625-207-0 | 73 x 96 x 12 | BUS CQ,CH MAB6 | 82/1~84/ | Transmission REAR COVER |
| 03908 5003 | 1-09625-207-0 | 73 x 96 x 12 | BUS CP | 80/2~84/ | Transmission REAR COVER |
| 03908 5923 | 1-09625-207-0 | 73 x 96 x 12 | BUS CRA,CSA | 80/~84/ | Transmission REAR COVER |
| 03908 4019 | 1-09625-149-0 | 80 x 105 x 12 | BUS CRA | 77/8~79/ | Transmission REAR COVER |
| 03908 7035 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS EMC,EDM,CDM | 78/11~84/ | Final Drive PINION |
| 03908 4875 | 1-09625-063-0 | 68 x 90 x 12 | BUS CL,CJ | 80/2~84/ | Transmission REAR COVER |
| 03908 4779 | 1-09625-201-0 | 120 x 153 x 15 x 18 | BUS CRA,CSA | 77/8~84/ | Engine CRANK SHAFT REAR |
| 03908 1811 | 1-09625-063-0 | 68 x 90 x 12 | BUS BU EXCEPT 45KYZ | 69/~79/ | Transmission REAR COVER |
| 03908 8059 | 1-09625-505-0 | 60 x 77 x 12 | BUS LT | 90/3~ | Transmission REAR COVER |
| 03908 7627 | 1-09625-173-0 | 60 x 77 x 12 | BUS LT | 84/3~90/2 | Transmission REAR COVER |
| 03908 4307 | 1-09625-173-0 | 60 x 77 x 12 | BUS BA,ECM,EDM,CDM | 66/~84/ | Transmission REAR COVER |
| 03908 5099 | 1-09625-562-0 | 54 x 69 x 9 | BUS LV7# | 90/6~ | Transmission FRONT COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 1563 | 1-09625-562-0 | 54 x 69 x 9 | BUS LV2#,3# | 89/11~ | Transmission FRONT COVER |
| 03908 3171 | 1-09625-507-1 | 120 x 153 x 17 | BUS LV 10PC,D | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03908 2459 | 1-09625-507-1 | 120 x 153 x 17 | BUS LV 8PC,10PC | 84/3~88/7 | Engine CRANK SHAFT REAR |
| 03908 6939 | 1-09625-439-1 | 105 x 135 x 15 | BUS LT 6B# | 84/3~90/6 | Engine CRANK SHAFT REAR |
| 03908 6123 | 1-09625-441-0 | 128 x 148 x 14 | BUS LV 6QA2,6QB2,6RB2 | 86/4~95/ | Engine CRANK SHAFT REAR |
| 03908 5043 | 9-09924-356-0 | 105 x 135 x 14 | BUS BA | 74/1~79/ | Engine CRANK SHAFT REAR |
| 03908 4179 | 1-09625-317-0 | 128 x 148 x 10 | BUS CQ,CH,CL,CJ,CP | 80/2~84/ | Engine CRANK SHAFT REAR |
| 03908 7299 | 1-09625-317-0 | 128 x 148 x 10 | BUS BU | 75/~79/ | Engine CRANK SHAFT REAR |
| 03908 2251 | 1-09625-149-0 | 80 x 105 x 12 | BUS BU45KYZ | 75/~79/ | Transmission REAR COVER |
| 03908 6563 | 1-09625-524-3 | 111 x 153 x 16.5 | BUS LV 8P#,10P#,12P# | 93/3~ | Engine CRANK SHAFT FRONT |
| 03908 3363 | 1-09625-317-0 | 128 x 148 x 10 | BUS LV 6QA2,6RB2 | 84/3~87/ | Engine CRANK SHAFT REAR |
| 03908 8347 | 1-09625-484-0 | 60 x 103 x 12 x 20 | BUS LT LEAF SUS. | 84/3~00/3 | Final Drive PINION |
| 03908 6867 | 5-09625-052-0 | 100 x 135 x 15 | BUS ECM,EDM,CDM | 78/11~84/ | Engine CRANK SHAFT REAR |
| 03908 5443 | 1-09625-424-0 | 120 x 153 x 13 x 15 | BUS LV 8PC | 88/8~89/ | Engine CRANK SHAFT FRONT |
| 03908 3235 | 1-09625-506-0 | 120 x 153 x 15 | BUS LV 10PC,D | 88/8~93/2 | Engine CRANK SHAFT FRONT |
| 03908 5691 | 1-09625-506-0 | 120 x 153 x 15 | BUS LV 8PC,10PC | 84/3~88/7 | Engine CRANK SHAFT FRONT |
| 03908 5315 | 1-09625-200-0 | 120 x 153 x 15 | BUS CRA,CSA | 77/8~84/ | Engine CRANK SHAFT FRONT |
| 03908 4163 | 1-09625-442-0 | 70 x 92 x 12 | BUS LV 6QA2,6QB2,6RB2 | 88/8~95/ | Engine CRANK SHAFT FRONT |
| 03908 1499 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS LV 6QA2,6RB2 | 84/3~88/7 | Engine CRANK SHAFT FRONT |
| 03908 5171 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS CQ,CH,CL,CJ,CP | 80/2~84/ | Engine CRANK SHAFT FRONT |
| 03908 2843 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS BU | 77/4~79/ | Engine CRANK SHAFT FRONT |
| 03908 3115 | 1-09625-316-0 | 70 x 92 x 10 x 16 | BUS BA | 76/6~79/ | Engine CRANK SHAFT FRONT |
| 03908 7019 | 1-09625-128-0 | 70 x 92 x 12 | BUS BU | 67/~77/3 | Engine CRANK SHAFT FRONT |
| 03908 6067 | 1-09625-128-0 | 70 x 92 x 12 | BUS BA | 66/~76/5 | Engine CRANK SHAFT FRONT |
| 03908 3243 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LV7# | 84/4~ | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4811 | 1-09625-063-0 | 68 x 90 x 12 | BUS BU | 69/79/ | Final Drive PINION |
| 03908 6795 | 1-09625-063-0 | 68 x 90 x 12 | BUS CRA | 77/8~79/ | Final Drive PINION |
| 03908 7635 | 8-97602-378-0 | 104 x 137 x 13 | BUS LT 6HE1,6HH1 | 90/7~ | Engine CRANK SHAFT FRONT |
| 03908 1243 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LV2#,3#...15.5INCH,16.5INCH DIFF.. | 84/3~ | Final Drive PINION |
| 03908 7619 | 1-09625-063-0 | 68 x 90 x 12 | BUS CL,CJ,CP | 80/2~84/ | Final Drive PINION |
| 03908 1115 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LT AIR SUS. | 89/4~00/3 | Final Drive PINION |
| 03908 2859 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS LT ALL | 00/4~ | Final Drive PINION |
| 03908 7179 | 1-09625-322-0 | 86 x 143 x 10 x 38 | BUS LV2#,3#...17.5INCH DIFF. | 92/6~99/ | Final Drive PINION |
| 03908 6595 | 8-97602-379-0 | 104 x 139 x 13 | BUS LT 6HE16HH1 | 90/7~ | Engine CRANK SHAFT REAR |
| 03908 3515 | 8-94373-765-0 | 60 x 82 x 12 | BUS ECM,EDM,CDM | 78/11~84/ | Engine CRANK SHAFT FRONT |
| 03908 5819 | 1-09625-319-0 | 60 x x 82 x 10 | BUS LT 6BG1 | 84/3~87/12 | Engine CRANK SHAFT FRONT |
| 03908 7123 | 1-09625-438-0 | 60 x 82 x 12 | BUS LT 6BG1 | 88/1~90/6 | Engine CRANK SHAFT FRONT |
| 03908 5211 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | BUS CRA,CSA,CQ,CH | 80/~84/ | Final Drive PINION |
| 03908 3091 | 90311-95008 | 95 x 115 x 9.5 x 12 | RANGER (3.5T) FB4J EAA-XB J05C | 97/11~00/ | Engine CRANK SHAFT REAR |
| 03908 5019 | 9828-79103 | 79 x 114 x 17 | RANGER (3.5T) FB J05C | 95/2~97/11 | Engine CRANK SHAFT FRONT |
| 03908 7651 | 9828-47101 | 47 x 65 x 9 | RANGER (3.5T) FB | 84/6~95/1 | Transmission REAR COVER |
| 03908 5915 | 90311-48011 | 48 x 62 x 9 | RANGER (3.5T) FB | 95/2~00/ | Transmission REAR COVER |
| 03908 8355 | 9828-52111 | 52 x 100 x 15 | RANGER (3.5T) KM | 65/~86/ | Final Drive PINION |
| 03908 4859 | 9828-58109 | 58 x 102 x 8 x 22 | RANGER (3.5T) FB | 84/6~98/7 | Final Drive PINION |
| 03908 4659 | 90311-35023 | 35 x 48 x 6.5 | RANGER (3.5T) FB | 95/2~00/ | Transmission FRONT COVER |
| 03908 5267 | 9828-55105 | 55 x 72 x 9 | RANGER (3.5T) KM DM100,DQ100 | 71/~83/ | Engine CRANK SHAFT FRONT |
| 03908 3947 | 9828-30101 | 30 x 42 x 8 | RANGER (3.5T) FB | 84/6~90/4 | Transmission FRONT COVER |
| 03908 7787 | 9828-52112 | 52 x 70 x 9 | RANGER (3.5T) KM | 65/~86/ | Transmission REAR COVER |
| 03908 6739 | 9828-79103 | 79 x 114 x 17 | RANGER (3.5T) EXCEPT FB4J EAA-XB J05C | 97/11~00/ | Engine CRANK SHAFT FRONT |
| 03908 3195 | 90311-50013 | 50 x 72 x 9 x 14 | RANGER (3.5T) FB4J EAA-XB J05C | 97/11~00/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 1995 | 9828-90108 | 90 x 110 x 13 | RANGER (3.5T) KM DM100,DQ100 | 71/~83/ | Engine CRANK SHAFT REAR |
| 03908 8459 | 9828-00109 | 100 x 120 x 13 x 18 | RANGER (3.5T) KM,FB W04D | 83/~95/1 | Engine CRANK SHAFT REAR |
| 03908 7563 | 9828-01228 | 100 x 135 x 17 | RANGER (3.5T) EXCEPT FB4J EAA-XB J05C | 97/11~00/ | Engine CRANK SHAFT REAR |
| 03908 2595 | 13719-1020 | | RANGER (3.5T) W04D | 83/~95/ | Engine VALVE STEM SEAL |
| 03908 7139 | 13719-1360 | | RANGER (3.5T) J05C | 95/2~97/10 | Engine VALVE STEM SEAL |
| 03908 4203 | 13719-1360 | | RANGER (3.5T) EXCEPT FB4J EAA-XB J05C | 97/11~98/1 | Engine VALVE STEM SEAL |
| 03908 5611 | 13719-1470 | | RANGER (3.5T) EXCEPT FB4J EAA-XB J05C | 98/2~00/ | Engine VALVE STEM SEAL |
| 03908 2699 | 13719-1480 | | RANGER (3.5T) FB4J EAA-XB J05C | 97/11~00/ | Engine VALVE STEM SEAL |
| 03908 8219 | 9828-58113 | 58 x 102 x 7.8 x 21.8 | RANGER (3.5T) FB | 98/8~00/ | Final Drive PINION |
| 03908 6547 | 9828-43102 | 43 x 63 x 9 | RANGER (3.5T) FB | 90/6~95/1 | Transmission FRONT COVER |
| 03908 3955 | 9828-01228 | 100 x 135 x 17 | RANGER (3.5T) FB J05C | 95/2~97/11 | Engine CRANK SHAFT REAR |
| 03908 2443 | 9828-01203 | 127 x 147 x 11 | RANGER (3.5T) FB4J CAA-# | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 2355 | 9828-48112 | 48 x 109 x 13 | RANGER (3.5T) FB5B EAA EXCEPT -TD | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 6283 | 9828-58104 | 58 x 75 x 9 x 14.5 | RANGER (3.5T) KM,FB W04D | 83/~95/1 | Engine CRANK SHAFT FRONT |
| 03908 5987 | 9828-85106 | 84 x 100 x 10 | RANGER (3.5T) KM | 65/~86/ | Wheel Hub FRONT |
| 03908 2779 | 9828-01136 | 116 x 132 x 11 | RANGER (3.5T) KM | 65/~86/ | Wheel Hub REAR INNER |
| 03908 2715 | 9828-01203 | 127 x 147 x 11 | RANGER (3.5T) FB4J EAA EXCEPT -AA.-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 7771 | 9828-01203 | 127 x 147 x 11 | RANGER (3.5T) FB4J GAA EXCEPT -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 3835 | 9828-01203 | 127 x 147 x 11 | RANGER (3.5T) FB5B EAA-TD | 97/11~99/ | Wheel Hub REAR INNER |
| 03908 4403 | 9828-01203 | 127 x 147 x 11 | RANGER (3.5T) FB5B GAV-# | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 3131 | 9828-01206 | 107 x 123 x 11 | RANGER (3.5T) FB1#,2# | 84/7~95/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6787 | 9828-01206 | 107 x 123 x 11 | RANGER (3.5T) FB4J EAA -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 1955 | 9828-01206 | 107 x 123 x 11 | RANGER (3.5T) FB4J GAA -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 3971 | 9828-48112 | 48 x 109 x 13 | RANGER (3.5T) FB1#,2# | 84/7~95/ | Wheel Hub REAR OUTER |
| 03908 8043 | 9828-48112 | 48 x 109 x 13 | RANGER (3.5T) FB5B CAA-#,EAV-#,GAA-# | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 2139 | 9828-85106 | 84 x 100 x 10 | RANGER (3.5T) FB | 84/7~00/ | Wheel Hub FRONT |
| 03908 1659 | 9828-01206 | 107 x 123 x 11 | RANGER (3.5T) FB5B CAA-#,EAV-#,GAA-# | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 1035 | 9828-48112 | 48 x 109 x 13 | RANGER (3.5T) FB4J GAA -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 3739 | 9828-48112 | 48 x 109 x 13 | RANGER (3.5T) FB4J EAA -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 2315 | 9828-57103 | 57 x 124 x 13 | RANGER (3.5T) FB5B GAV-# | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 2419 | 9828-57103 | 57 x 124 x 13 | RANGER (3.5T) FB5B EAA -TD | 97/11~99/ | Wheel Hub REAR OUTER |
| 03908 3523 | 9828-57103 | 57 x 124 x 13 | RANGER (3.5T) FB4J GAA EXCEPT -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 2835 | 9828-57103 | 57 x 124 x 13 | RANGER (3.5T) FB4J EAA EXCEPT -AA,-BA,-RA,-SA | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 6219 | 9828-57103 | 57 x 124 x 13 | RANGER (3.5T) FB4J CAA-# | 95/5~99/ | Wheel Hub REAR OUTER |
| 03908 1859 | 9828-40101 | 40 x 50 x 6.5 | RANGER (3.5T) KM | 65/~86/ | Wheel Hub REAR OUTER |
| 03908 4443 | 9828-01206 | 107 x 123 x 11 | RANGER (3.5T) FB5B EAA EXCEPT -TD | 95/5~99/ | Wheel Hub REAR INNER |
| 03908 6819 | 9828-65113 | 65 x 114 x 10 x 25.5 | RANGER (4.5T~5T) FD#,GD#,KD | 83/12~98/6 | Final Drive PINION |
| 03908 3323 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) FC 17#,2J | 84/6~90/ | Transmission REAR COVER |
| 03908 1179 | 9828-63104 | 63 x 100 x 12 | RANGER (4.5T~5T) FC..11#,14# | 84/6~90/5 | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2947 | 9828-63104 | 63 x 100 x 12 | RANGER (4.5T~5T) FD,GD EC100,EH500,700 | 80/~83/11 | Final Drive PINION |
| 03908 7059 | 9828-63104 | 63 x 100 x 12 | RANGER (4.5T~5T) KL | 69/~80/ | Final Drive PINION |
| 03908 7043 | 9828-63108 | 63 x 78 x 9 x 15 | RANGER (4.5T~5T) GD 1J(NA,NG) | 94/10~98/9 | Transmission REAR COVER |
| 03908 4187 | 9828-63104 | 63 x 100 x 12 | RANGER (4.5T~5T) FT | 83/9~86/4 | Final Drive PINION |
| 03908 5867 | 9828-63108 | 63 x 78 x 9 x 15 | RANGER (4.5T~5T) FD 1H,1J(DUMP) | 89/10~94/ | Transmission REAR COVER |
| 03908 1971 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) GC | 02/9~ | Transmission REAR COVER |
| 03908 5803 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) GD 1J,7J | 98/10~ | Transmission REAR COVER |
| 03908 1539 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) FT 17#,3H,1J,7J | 83/9~ | Transmission REAR COVER |
| 03908 5971 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) FC 3W(#-LC) | 90/6~95/ | Transmission REAR COVER |
| 03908 7291 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) GD 1J(AA,AC,AG) | 94/10~98/9 | Transmission REAR COVER |
| 03908 7163 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) GD 16#,17#,2H,3H | 83/12~94/ | Transmission REAR COVER |
| 03908 7219 | 9828-65113 | 65 x 114 x 10 x 25.5 | RANGER (4.5T~5T) FC17# | 84/6~90/5 | Final Drive PINION |
| 03908 4035 | 9828-01167 | 106 x 126 x 12 | RANGER (4.5T~5T) H06C,H07C,D | 83/~ | Engine CRANK SHAFT REAR |
| 03908 1827 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) FC 1J,2J,3J,5J,6J,7J | 95/1~ | Transmission REAR COVER |
| 03908 7267 | 9828-58104 | 58 x 75 x 9 x 14.5 | RANGER (4.5T~5T) W04D,W06E | 83/~ | Engine CRANK SHAFT FRONT |
| 03908 2019 | 13719-1360 | | RANGER (4.5T~5T) J05C,J07C,J08C | 91/10~98/1 | Engine VALVE STEM SEAL |
| 03908 4299 | 13719-1020 | | RANGER (4.5T~5T) W04C | 00/10~ | Engine VALVE STEM SEAL |
| 03908 5387 | 13719-1020 | | RANGER (4.5T~5T) H06C,H07C,D,W04D,W06D,E | 83/6~95/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7315 | 9828-01228 | 100 x 135 x 17 | RANGER (4.5T~5T) J05C,J07C,J08C | 91/~ | Engine CRANK SHAFT REAR |
| 03908 4003 | 9828-00109 | 100 x 120 x 13 x 18 | RANGER (4.5T~5T) W04C,D,W06E | 83/~ | Engine CRANK SHAFT REAR |
| 03908 2995 | 9828-48120 | 48 x 60 x 9 | RANGER (4.5T~5T) FD 1H,2H,1J,2J,7J | 89/7~ | Transmission FRONT COVER |
| 03908 3355 | 9828-01167 | 106 x 126 x 12 | RANGER (4.5T~5T) EH300,EH500,EH700 | 74/~83/ | Engine CRANK SHAFT REAR |
| 03908 6267 | 9828-00107 | 100 x 120 x 13 | RANGER (4.5T~5T) EC100,EH100 | 69/~83/ | Engine CRANK SHAFT REAR |
| 03908 8275 | 9828-79103 | 79 x 114 x 17 | RANGER (4.5T~5T) J05C,J07C,J08C | 91/~ | Engine CRANK SHAFT FRONT |
| 03908 8291 | 9828-65113 | 65 x 114 x 10 x 25.5 | RANGER (4.5T~5T) FC# | 90/6~98/6 | Final Drive PINION |
| 03908 5795 | 9828-65116 | 65 x 88 x 12 x 19 | RANGER (4.5T~5T) H06C,H07C,D | 83/~ | Engine CRANK SHAFT FRONT |
| 03908 8299 | 9828-65116 | 65 x 88 x 12 x 19 | RANGER (4.5T~5T) EH500,EH700 | 80/~83/ | Engine CRANK SHAFT FRONT |
| 03908 5571 | 9828-65116 | 65 x 88 x 12 x 19 | RANGER (4.5T~5T) EC100,EH100,EH300 | 78/~83/ | Engine CRANK SHAFT FRONT |
| 03908 1651 | 9828-58105 | 58 x 75 x 9 | RANGER (4.5T~5T) EC100,EH100,EH300 | 69/~77/ | Engine CRANK SHAFT FRONT |
| 03908 2603 | 9828-65130 | 65 x 105 x 9 x 25 | RANGER (4.5T~5T) FC#,FD#,FT#,GC#,GD# | 01/11~ | Final Drive PINION |
| 03908 8083 | 9828-65127 | 65 x 114 x 9 x 25 | RANGER (4.5T~5T) FC#,FD#,FT#,GD# | 98/7~01/10 | Final Drive PINION |
| 03908 5283 | 9828-65113 | 65 x 114 x 10 x 25.5 | RANGER (4.5T~5T) FT | 86/6~98/6 | Final Drive PINION |
| 03908 5243 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) FD 17#,2H,3H,1J(EXCEPT DUMP),2J,7J | 83/12~ | Transmission REAR COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7099 | 9828-01134 | 140 x 160 x 12 | RANGER (4.5T~5T) FT1J EXCEPT EBA,ECA,GBA-A#,GBF-A#,GCA-A#,H# | 95/1~99/3 | Wheel Hub FRONT |
| 03908 3435 | 9828-57103 | 57 x 124 x 13 | RANGER (4.5T~5T) FC,FD,GC,GD,KD | 83/12~ | Wheel Hub REAR OUTER |
| 03908 1171 | 9828-45104 | 45 x 55 x 7.5 | RANGER (4.5T~5T) FD,GD | 80/~83/11 | Wheel Hub REAR OUTER |
| 03908 4723 | 9828-45104 | 45 x 55 x 7.5 | RANGER (4.5T~5T) KL | 69/~80/ | Wheel Hub REAR OUTER |
| 03908 3043 | 9828-01146 | 122 x 138 x 12 | RANGER (4.5T~5T) FT | 80/~95/ | Wheel Hub REAR INNER |
| 03908 3963 | 9828-01203 | 127 x 147 x 11 | RANGER (4.5T~5T) FC,FD,GC,GD,KD | 83/12~ | Wheel Hub REAR INNER |
| 03908 6699 | 9828-01149 | 120 x 140 x 12 | RANGER (4.5T~5T) FD,GD | 80/~83/11 | Wheel Hub REAR INNER |
| 03908 5459 | 9828-48103 | 48 x 58 x 7 | RANGER (4.5T~5T) FT 173A,175A | 80/12~83/ | Wheel Hub REAR OUTER |
| 03908 8179 | 9828-01134 | 140 x 160 x 12 | RANGER (4.5T~5T) FT1J ALL | 99/3~ | Wheel Hub FRONT |
| 03908 5163 | 9828-37103 | 37 x 50 x 6 | RANGER (4.5T~5T) FD,GD EC100,EH500,700 | 80/~83/11 | Transmission FRONT COVER |
| 03908 1843 | 9828-01134 | 140 x 160 x 12 | RANGER (4.5T~5T) FT3H EAL,GAL,GAF-ADA | 89/10~95/ | Wheel Hub FRONT |
| 03908 3931 | 9828-01192 | 116 x 132 x 12 | RANGER (4.5T~5T) FT1J EBA,ECA,GBA-A#,GBF-4#,GCA-A#,H# | 95/1~99/3 | Wheel Hub FRONT |
| 03908 1907 | 9828-01192 | 116 x 132 x 12 | RANGER (4.5T~5T) FT3H EXCEPT EAL,GAL,GAF-ADA | 89/10~95/ | Wheel Hub FRONT |
| 03908 2323 | 9828-01192 | 116 x 132 x 12 | RANGER (4.5T~5T) FT17# | 80/~90/ | Wheel Hub FRONT |
| 03908 5435 | 9828-01137 | 101 x 114 x 10 | RANGER (4.5T~5T) FC,FD,GC,GD,KD | 80/~ | Wheel Hub FRONT |
| 03908 7643 | 9828-01137 | 101 x 114 x 10 | RANGER (4.5T~5T) KL | 69/~80/ | Wheel Hub FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3907 | 13719-1470 | | RANGER (4.5T~5T) J05C,D,J07C,E,J08C | 98/2~ | Engine VALVE STEM SEAL |
| 03908 8523 | 9828-01149 | 120 x 140 x 12 | RANGER (4.5T~5T) KL | 69/~80/ | Wheel Hub REAR INNER |
| 03908 3203 | 9828-48120 | 48 x 60 x 9 | RANGER (4.5T~5T) FC 1J,3J,5J,6J,7J | 95/1~ | Transmission FRONT COVER |
| 03908 6275 | 9828-55110 | 55 x 72 x 9 x 15 | RANGER (4.5T~5T) FC 3W(EXCEPT #-LC) | 90/6~95/ | Transmission REAR COVER |
| 03908 4219 | 9828-55110 | 55 x 72 x 9 x 15 | RANGER (4.5T~5T) FC 14#,4J,1W,2W | 84/6~ | Transmission REAR COVER |
| 03908 8075 | 9828-55110 | 55 x 72 x 9 x 15 | RANGER (4.5T~5T) FD 16#,3W 5 SPEED | 83/12~94/ | Transmission REAR COVER |
| 03908 3715 | 9828-55110 | 55 x 72 x 9 x 15 | RANGER (4.5T~5T) FD,GD EC100,EH500,700 | 80/~83/11 | Transmission REAR COVER |
| 03908 5979 | 9828-55110 | 55 x 72 x 9 x 15 | RANGER (4.5T~5T) KD,KL | 75/~89/ | Transmission REAR COVER |
| 03908 1875 | 9828-52112 | 52 x 70 x 9 | RANGER (4.5T~5T) FC 11# | 84/6~90/ | Transmission REAR COVER |
| 03908 5811 | 9828-52112 | 52 x 70 x 9 | RANGER (4.5T~5T) KL | 69/~74/ | Transmission REAR COVER |
| 03908 7331 | 9828-57103 | 57 x 124 x 13 | RANGER (4.5T~5T) FT 173B,175B,3H,1J | 80/12~ | Wheel Hub REAR OUTER |
| 03908 8067 | 9828-48120 | 48 x 60 x 9 | RANGER (4.5T~5T) FT 1J | 97/10~ | Transmission FRONT COVER |
| 03908 4027 | 9828-60119 | 60 x 75 x 9 x 15 | RANGER (4.5T~5T) FD 16#,3W 6 SPEED | 83/12~95/ | Transmission REAR COVER |
| 03908 3259 | 9828-48120 | 48 x 60 x 9 | RANGER (4.5T~5T) GD 16#,2H,1J | 83/12~ | Transmission FRONT COVER |
| 03908 4251 | 9828-43102 | 43 x 63 x 9 | RANGER (4.5T~5T) KD | 86/4~89/ | Transmission FRONT COVER |
| 03908 5059 | 9828-43102 | 43 x 63 x 9 | RANGER (4.5T~5T) FC 14#,17#,3H,2J,4J,1W,2W, 3W | 84/6~ | Transmission FRONT COVER |
| 03908 1531 | 9828-43102 | 43 x 63 x 9 | RANGER (4.5T~5T) FT 17#,3H,1J | 83/9~97/9 | Transmission FRONT COVER |
| 03908 3923 | 9828-43102 | 43 x 63 x 9 | RANGER (4.5T~5T) GD 17#,3H | 83/12~94/ | Transmission FRONT COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6499 | 9828-43102 | 43 x 63 x 9 | RANGER (4.5T~5T) FD 16#,17#,3H,3W | 83/12~94/ | Transmission FRONT COVER |
| 03908 8051 | 9828-48120 | 48 x 60 x 9 | RANGER (4.5T~5T) GC | 02/9~ | Transmission FRONT COVER |
| 03908 2027 | 9828-65111 | 65 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC303M,TC9# | 71/~79/8 | Transmission REAR COVER |
| 03908 4355 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN2P EA,EB,JA,JB | 92/5~ | Final Drive PINION |
| 03908 5411 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD) TC,FN,GN | 71/~ | Wheel Hub FRONT (FORWARD) |
| 03908 8019 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (2-2XD) TC3#...EXCEPT 303D,TC7#,9# | 71/~81/ | Final Drive PINION |
| 03908 6243 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2-2XD) TC303D,5# | 71/~81/ | Final Drive PINION |
| 03908 2827 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2-2XD) FN270AD,AM,FN63# | 81/5~83/ | Final Drive PINION |
| 03908 8211 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN27#...EXCEPT 270# | 81/5~89/ | Final Drive PINION |
| 03908 5195 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN28#...RT,RTN,TT,VTS | 82/7~89/ | Final Drive PINION |
| 03908 1043 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN60#,GN28# | 81/9~89/ | Final Drive PINION |
| 03908 8419 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN2K,GN1F,1P,2P | 89/12~95/3 | Final Drive PINION |
| 03908 8011 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN1K | 99/9~ | Transmission REAR COVER |
| 03908 4459 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN1P RT,RW,TT,VTS | 90/1~92/ | Final Drive PINION |
| 03908 8259 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN2P,GN2P HK06,07 T/M | 92/5~99/8 | Transmission REAR COVER |
| 03908 3819 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) EN270#,FN63# | 83/~89/ | Final Drive PINION |
| 03908 5787 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) FN28#...ST,UT,WTS | 82/7~89/ | Final Drive PINION |
| 03908 6363 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) FN1F,2F,1K | 90/1~92/4 | Final Drive PINION |
| 03908 5603 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2-2XD) FN1P ST,SW,WTS,UT | 90/1~92/ | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4339 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (2-2XD) GN27# | 81/5~90/ | Final Drive PINION |
| 03908 3403 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (2-2XD) GN2K | 90/3~ | Final Drive PINION |
| 03908 2171 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2-2XD) FN1K,1V,2F,3F,4F | 92/5~ | Final Drive PINION |
| 03908 1219 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2-2XD) FN2P FA,FB,MA,MB | 92/5~ | Final Drive PINION |
| 03908 4243 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD) FN1F | 92/5~95/3 | Final Drive PINION |
| 03908 4891 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) TC5# | 71/~81/ | Transmission REAR COVER |
| 03908 1155 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD) TC,FN,GN | 71/~ | Wheel Hub FRONT (REARWARD) |
| 03908 6227 | 9828-01130 | 146 x 170 x 18 | TRUCK (2-2XD) TC | 71/~81/ | Wheel Hub REAR INNER |
| 03908 4899 | 9828-01193 | 154 x 175 x 13 | TRUCK (2-2XD) FN,GN | 81/5~ | Wheel Hub REAR INNER |
| 03908 7979 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2-2XD) TC | 71/~81/ | Wheel Hub REAR OUTER |
| 03908 7371 | 9828-55113 | 55 x 72 x 9 | TRUCK (2-2XD) TC,FN,GN | 71/~ | Transmission FRONT COVER |
| 03908 1795 | 9828-65111 | 65 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC942 | 79/9~81/ | Transmission REAR COVER |
| 03908 3779 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC3#...EXCEPT 303M,TC7# | 71/~79/8 | Transmission REAR COVER |
| 03908 4195 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) TC3#,7#,922 | 79/9~81/ | Transmission REAR COVER |
| 03908 5355 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN2P,GN2P HK06,07 T/M | 99/9~ | Transmission REAR COVER |
| 03908 4083 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) FN28# | 82/7~83/11 | Transmission REAR COVER |
| 03908 1603 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2-2XD) FN2K,1F,GN2P | 95/4~ | Final Drive PINION |
| 03908 2379 | 9828-76101 | 76 x 164 x 14 | TRUCK (2-2XD) FN,GN | 81/5~ | Wheel Hub REAR OUTER |
| 03908 6107 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN27#...7 SPEED T/M | 81/5~89/ | Transmission REAR COVER |
| 03908 6587 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN28# | 83/12~89/ | Transmission REAR COVER |
| 03908 2683 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN338,60#,63#,GN28# | 81/9~89/ | Transmission REAR COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2179 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN1F,1P,2K,GN1F,1P,2K | 89/10~ | Transmission REAR COVER |
| 03908 1835 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN1K,2F | 90/1~92/4 | Transmission REAR COVER |
| 03908 8107 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD) FN2P,GN2P MJ06,07 T/M | 92/5~ | Transmission REAR COVER |
| 03908 1851 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2-2XD) FN1K,1V,2F,3F | 92/5~99/8 | Transmission REAR COVER |
| 03908 3083 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2-2XD) FN27#...6 SPEED T/M, GN27# | 81/5~89/ | Transmission REAR COVER |
| 03908 1611 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (2-2XD) SPG | 73/~78/ | Propeller Shaft CENTER BEARING (F) |
| 03908 1587 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) SRG SINGLE SPEED DIFF. | 75/~83/ | Final Drive PINION |
| 03908 6091 | 1-09625-359-0 | 80 x 100 x 12 | TRUCK (2-2XD) CXG MJA,MJB,MJC T/M | 83/8~94/6 | Transmission REAR COVER |
| 03908 6883 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (2-2XD) CXG,CYG MJA,MJB,MJC,MJD,MJT T/M | 94/7~ | Transmission REAR COVER |
| 03908 1059 | 1-09625-473-0 | 80 x 115 x 15 | TRUCK (2-2XD) CXG MAB10 T/M | 86/4~89/8 | Transmission REAR COVER |
| 03908 7259 | 1-09625-625-0 | 104 x 126 x 13 | TRUCK (2-2XD) CXG,CYG MJX12 T/M | 03/6~ | Transmission REAR COVER |
| 03908 2883 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (2-2XD) CXG,CYG MAG,MAH,MAL T/M | 83/8~ | Transmission REAR COVER |
| 03908 3283 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (2-2XD) SPG | 73/~78/ | Propeller Shaft CENTER BEARING |
| 03908 7523 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2-2XD) SRG,SSG571 | 80/1~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03908 4603 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2-2XD) CXG,CYG P60,90L PROPELLER SHAFT | 83/8~ | Propeller Shaft CENTER BEARING (F&R) |
| 03908 1347 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2-2XD) CXG,CYG P85,90 PROPELLER SHAFT | 83/8~00/ | Propeller Shaft CENTER BEARING (F&R) |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 5139 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2-2XD) CXG,CYG P105,115 PROPELLER SHAFT | 83/8~00/ | Propeller Shaft CENTER BEARING (F&R) |
| 03908 1475 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2-2XD) CXG,CYG P115 PROPELLER SHAFT | 00/4~ | Propeller Shaft CENTER BEARING (F) |
| 03908 3787 | 1-09625-622-0 | 86 x 106 x 14 | TRUCK (2-2XD) CXG,CYG P115 PROPELLER SHAFT | 00/4~ | Propeller Shaft CENTER BEARING |
| 03908 1675 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2-2XD) SSG 2 SPEED DIFF. | 80/1~83/ | Final Drive PINION |
| 03908 2627 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) SSG SINGLE SPEED DIFF. | 80/1~83/ | Final Drive PINION |
| 03908 3659 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY | 73/79/12 | Final Drive PINION |
| 03908 7827 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (2-2XD) SMG MAB5 T/M | 80/1~83/ | Wheel Hub REAR OUTER |
| 03908 3811 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2-2XD) CXG,CYG | 83/8~ | Wheel Hub FRONT (F&R) |
| 03908 7283 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY | 73/~79/ | Wheel Hub REAR INNER |
| 03908 5419 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2-2XD) SPG E120 (EXCEPT MIXER) | 73/~83/ | Engine CRANK SHAFT REAR |
| 03908 8195 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (2-2XD) SRG,SSG,SMG(EXCEPT MAB5 T/M) | 75/~83/ | Wheel Hub REAR INNER |
| 03908 7723 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) SMG EXCEPT TANK LORRY,CINTAINER | 80/1~83/ | Final Drive PINION |
| 03908 2403 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2-2XD) SMG MAB5 T/M | 80/1~83/ | Wheel Hub REAR INNER |
| 03908 6027 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2-2XD) CXG,CYG | 83/8~ | Wheel Hub REAR INNER |
| 03908 6659 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY | 73/~79/ | Wheel Hub REAR OUTER |
| 03908 1011 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2-2XD) SPG 540 TANK LORRY | 73/~79/ | Wheel Hub REAR INNER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6291 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (2-2XD) SPG 540 TANK LORRY | 73/~79/ | Wheel Hub REAR OUTER |
| 03908 6307 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (2-2XD) CXG MAB,MAF T/M | 83/8~94/ | Transmission REAR COVER |
| 03908 7595 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2-2XD) SRG,SSG,SMG(EXCEPT MAB5 T/M) | 80/1~83/ | Wheel Hub REAR OUTER |
| 03908 7067 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2-2XD) CXG,CYG | 83/8~ | Wheel Hub REAR OUTER |
| 03908 5347 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2-2XD) SPG,SRG | 73/~79/12 | Transmission FRONT COVER |
| 03908 6875 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2-2XD) SRG,SSG,SMG | 80/1~83/ | Transmission FRONT COVER |
| 03908 8163 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2-2XD) CXG | 83/8~89/8 | Transmission FRONT COVER |
| 03908 5251 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2-2XD) CXG,CYG | 89/9~ | Transmission FRONT COVER |
| 03908 6995 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2-2XD) SPG,SRG | 73/~79/12 | Transmission REAR COVER |
| 03908 4011 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (2-2XD) SRG,SSG,SMG | 80/1~83/ | Transmission REAR COVER |
| 03908 2923 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (2-2XD) SRG | 75/~79/12 | Wheel Hub REAR OUTER |
| 03908 4531 | 1-12569-009-0 | | TRUCK (2-2XD) 8P,10P,12P | 75,~91/6 | Engine VALVE STEM SEAL |
| 03908 2667 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (2-2XD) CXG,CYG 6SD1 | 94/12~ | Engine CRANK SHAFT FRONT |
| 03908 4491 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2-2XD) CXG 10P#,12P# | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03908 3331 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 8P# | 88/8~93/2 | Engine CRANK SHAFT REAR |
| 03908 3995 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2-2XD) CXG,CYG 8P#,10P#,12P# | 93/3~03/ | Engine CRANK SHAFT REAR |
| 03908 1123 | 1-09625-443-0 | 120 x 150 x 15 | TRUCK (2-2XD) CXG 6SD1 | 83/8~94/ | Engine CRANK SHAFT REAR |
| 03908 3571 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (2-2XD) CXG,CYG 6SD1 | 94/12~ | Engine CRANK SHAFT REAR |
| 03908 4067 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (2-2XD) CXG,CYG 6WA1,6WG1,6WF1 | 92/4~ | Engine CRANK SHAFT REAR |
| 03908 1275 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (2-2XD) SPG E120 (MIXER),CXG 6RB1 (MIXER) | 73/~92/ | Engine CRANK SHAFT REAR |
| 03908 6155 | 1-12569-013-0 | | TRUCK (2-2XD) 6R | 81/~92/ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4275 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2-2XD) CXG 6RB1 (EXCEPT MIXER) | 83/8~86/3 | Engine CRANK SHAFT REAR |
| 03908 1891 | 1-12569-009-0 | | TRUCK (2-2XD) 6SD1 | 83/~94/ | Engine VALVE STEM SEAL |
| 03908 6059 | 1-12569-019-1 | | TRUCK (2-2XD) 6SD1 | 94/12 | Engine VALVE STEM SEAL |
| 03908 1203 | 1-12569-019-1 | | TRUCK (2-2XD) 8P,10P,12P | 91/7~ | Engine VALVE STEM SEAL |
| 03908 1579 | 1-12569-019-1 | | TRUCK (2-2XD) 6WA1,6WG1,6WF1 | 92/4~00/5 | Engine VALVE STEM SEAL |
| 03908 5523 | 1-12569-020-0 | | TRUCK (2-2XD) 6WG1,6WF1 | 00/6~ | Engine VALVE STEM SEAL |
| 03908 1747 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2-2XD) SPG,SRG,SSG,SMG | 73/~83/ | Wheel Hub FRONT (F&R) |
| 03908 3163 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (2-2XD) CXG 6RB1 (EXCEPT MIXER) | 86/4~92/ | Engine CRANK SHAFT REAR |
| 03908 5259 | 9-12569-072-0 | | TRUCK (2-2XD) E120 | 71/~83/ | Engine VALVE STEM SEAL |
| 03908 3387 | 1-09625-442-0 | 70 x 92 x 12 | TRUCK (2-2XD) CXG 6RB1 | 88/7~92/ | Engine CRANK SHAFT FRONT |
| 03908 1731 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2-2XD) SPG 540 TANK LORRY | 73/~79/12 | Final Drive PINION |
| 03908 1187 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2-2XD) SMG TANK LORRY,CONTAINER | 80/1~83/ | Final Drive PINION |
| 03908 3979 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2-2XD) CXG,CYG 16.5 INCH FINAL | 83/8~00/ | Final Drive PINION |
| 03908 5083 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2-2XD) CXG,CYG 17.5 INCH FINAL | 89/9~00/ | Final Drive PINION |
| 03908 3867 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2-2XD) CXG,CYG 18.5 INCH FINAL | 83/8~00/ | Final Drive PINION |
| 03908 6507 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2-2XD) CXG,CYG ALL | 00/4~ | Final Drive PINION |
| 03908 2963 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (2-2XD) SPG E120 | 73/~77/ | Engine CRANK SHAFT FRONT |
| 03908 1595 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2-2XD) CXG 8PC1,10PC1,12PC1 | 83/8~88/7 | Engine CRANK SHAFT REAR |
| 03908 8187 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2-2XD) CXG 6RB1 | 83/8~88/7 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3155 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2-2XD) CXG 17.5 INCH FINAL | 83/8~89/8 | Final Drive PINION |
| 03908 6419 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (2-2XD) SRG,SSG,SMG 8P,10P | 75/~83/ | Engine CRANK SHAFT FRONT |
| 03908 2891 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 6SD1,8PC1,10PC1,12PC1 | 83/8~88/7 | Engine CRANK SHAFT FRONT |
| 03908 5739 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 10P#,12P# | 88/8~93/2 | Engine CRANK SHAFT FRONT |
| 03908 4139 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (2-2XD) CXG 8P# | 88/8~93/2 | Engine CRANK SHAFT FRONT |
| 03908 5075 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2-2XD) CXG,CYG 8P#,10P#,12P# | 93/3~03/ | Engine CRANK SHAFT FRONT |
| 03908 7963 | 1-09625-451-0 | 120 x 153 x 15 | TRUCK (2-2XD) CXG 6SD1 | 88/8~94/ | Engine CRANK SHAFT FRONT |
| 03908 4971 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (2-2XD) CXG,CYG 6WA1,6WG1,6WF1 | 92/4~ | Engine CRANK SHAFT FRONT |
| 03908 1459 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2-2XD) SPG E120 | 77/~83/ | Engine CRANK SHAFT FRONT |
| 03908 4155 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (2-2XD) SPG,SSG,SMG 8P,10P,12P | 75/~83/ | Engine CRANK SHAFT REAR |
| 03908 8435 | 9828-90104 | 90 x 115 x 13 x 19 | TRUCK (2-2XD-D) FW27#,28#,60#,1F,2K | 83/11~94/6 | Final Drive PINION (FRONT) |
| 03908 2011 | 9828-76101 | 76 x 164 x 14 | TRUCK (2-2XD-D) FY | 88/9~ | Wheel Hub REAR OUTER (F) |
| 03908 6955 | 9828-45104 | 45 x 55 x 7.5 | TRUCK (2-2XD-D) FW | 81/6~83/11 | Wheel Hub REAR OUTER |
| 03908 3251 | 9828-57103 | 57 x 124 x 13 | TRUCK (2-2XD-D) FW | 83/12~ | Wheel Hub REAR OUTER |
| 03908 5931 | 9828-76101 | 76 x 164 x 14 | TRUCK (2-2XD-D) FY | 88/9~ | Wheel Hub REAR OUTER |
| 03908 5699 | 9828-55113 | 55 x 72 x 9 | TRUCK (2-2XD-D) FW,FY | 83/11~ | Transmission FRONT COVER |
| 03908 3227 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD-D) FW27#,28#,60#,1F,2K | 83/11~00/ | Transmission REAR COVER |
| 03908 5475 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2-2XD-D) FW1K,2P,2F,3F,4F | 92/4~99/8 | Transmission REAR COVER |
| 03908 5219 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW,FY | 81/6~ | Wheel Hub FRONT (FORWARD) |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4363 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2-2XD-D) FY | 99/9~ | Transmission REAR COVER |
| 03908 7251 | 9828-01193 | 154 x 175 x 13 | TRUCK (2-2XD-D) FY | 88/9~ | Wheel Hub REAR INNER |
| 03908 3491 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD-D) FW1K,2F,3F | 89/11~94/6 | Final Drive PINION (FRONT) |
| 03908 5323 | 9828-90115 | 90 x 125 x 10 x 17 | TRUCK (2-2XD-D) FW1F,2F,3F,4F,1K,2P | 94/7~ | Final Drive PINION (FRONT) |
| 03908 2523 | 9828-90115 | 90 x 125 x 10 x 17 | TRUCK (2-2XD-D) FY | 98/9~ | Final Drive PINION (FRONT) |
| 03908 6835 | 9828-63104 | 63 x 100 x 12 | TRUCK (2-2XD-D) FW27#,60# | 83/11~85/8 | Final Drive PINION (REAR) |
| 03908 8395 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2-2XD-D) FW27# | 85/9~90/ | Final Drive PINION (REAR) |
| 03908 2235 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2-2XD-D) FW28#,60#,1F,2F,3F,4F,1K,2K,2P | 85/9~98/6 | Final Drive PINION (REAR) |
| 03908 4395 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (2-2XD-D) FW1K,2P,4F | 98/7~ | Final Drive PINION (REAR) |
| 03908 3059 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2-2XD-D) FY | 98/9~ | Final Drive PINION (REAR) |
| 03908 4051 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2-2XD-D) FW1K,2P,3F,4F | 99/9~ | Transmission REAR COVER |
| 03908 7187 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW3F ALL | 98/4~ | Wheel Hub FRONT (REARWARD) |
| 03908 7467 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2-2XD-D) FW1K,2F | 89/11~92/3 | Transmission REAR COVER |
| 03908 2131 | 9828-01137 | 101 x 114 x 10 | TRUCK (2-2XD-D) FW1K,3F ALL | 90/1~94/12 | Wheel Hub FRONT (REARWARD) |
| 03908 6395 | 9828-01137 | 101 x 114 x 10 | TRUCK (2-2XD-D) FW1K EXCEPT YDA,XDA,ZD# | 94/12~98/5 | Wheel Hub FRONT (REARWARD) |
| 03908 5363 | 9828-01137 | 101 x 114 x 10 | TRUCK (2-2XD-D) FW1K AG#,WC# | 98/5~ | Wheel Hub FRONT (REARWARD) |
| 03908 3683 | 9828-01137 | 101 x 114 x 10 | TRUCK (2-2XD-D) FW2P | 96/12~98/3 | Wheel Hub FRONT (REARWARD) |
| 03908 5763 | 9828-01137 | 101 x 114 x 10 | TRUCK (2-2XD-D) FW3F EXCEPT #D | 96/12~98/3 | Wheel Hub FRONT (REARWARD) |
| 03908 2435 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW1K YDA,XDA,ZD# | 94/12~98/5 | Wheel Hub FRONT (REARWARD) |
| 03908 3531 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW1K EXCEPT AG#,WC# | 98/5~ | Wheel Hub FRONT (REARWARD) |
| 03908 6643 | 9828-57103 | 57 x 124 x 13 | TRUCK (2-2XD-D) FW | 83/12~ | Wheel Hub REAR OUTER (F) |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4371 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW3F #D | 94/12~98/3 | Wheel Hub FRONT (REARWARD) |
| 03908 2555 | 9828-45104 | 45 x 55 x 7.5 | TRUCK (2-2XD-D) FW | 81/6~83/11 | Wheel Hub REAR OUTER (F) |
| 03908 6723 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW4F | 94/12~ | Wheel Hub FRONT (REARWARD) |
| 03908 1099 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FY | 88/9~ | Wheel Hub FRONT (REARWARD) |
| 03908 6011 | 9828-01149 | 120 x 140 x 12 | TRUCK (2-2XD-D) FW | 81/6~83/11 | Wheel Hub REAR INNER (F) |
| 03908 4595 | 9828-01203 | 127 x 147 x 11 | TRUCK (2-2XD-D) FW | 83/12~ | Wheel Hub REAR INNER (F) |
| 03908 7499 | 9828-01193 | 154 x 175 x 13 | TRUCK (2-2XD-D) FY | 88/9~ | Wheel Hub REAR INNER (F) |
| 03908 8539 | 9828-01149 | 120 x 140 x 12 | TRUCK (2-2XD-D) FW | 81/6~83/11 | Wheel Hub REAR INNER |
| 03908 1363 | 9828-01203 | 127 x 147 x 11 | TRUCK (2-2XD-D) FW | 83/12~ | Wheel Hub REAR INNER |
| 03908 7571 | 9828-01137 | 101 x 114 x 10 | TRUCK (2-2XD-D) FW27#,28#,60#,1F,2F,2K | 81/6~ | Wheel Hub FRONT (REARWARD) |
| 03908 3875 | 9828-01207 | 138 x 152 x 12 | TRUCK (2-2XD-D) FW2P | 98/3~ | Wheel Hub FRONT (REARWARD) |
| 03908 1963 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2-2XD-D) FY | 98/9~99/8 | Transmission REAR COVER |
| 03908 3595 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2XD-4) FR1K#,FR2K# | 90/1~92/4 | Final Drive PINION |
| 03908 4467 | 9828-01207 | 138 x 152 x 12 | TRUCK (2XD-4) FR,FP | 81/5~ | Wheel Hub FRONT |
| 03908 4651 | 9828-01207 | 138 x 152 x 12 | TRUCK (2XD-4) KE | 71/~81/ | Wheel Hub FRONT |
| 03908 2939 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2XD-4) FR270B# | 81/~83/ | Final Drive PINION |
| 03908 1259 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-4) FR27#...EXCEPT 270B,FP27# | 81/~89/ | Final Drive PINION |
| 03908 7347 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-4) FR28#KP,LP,FP28#KP,LP | 81/~89/ | Final Drive PINION |
| 03908 7859 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-4) FR60#...EXCEPT 600BD,BM,FP60# | 81/~89/ | Final Drive PINION |
| 03908 3451 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-4) (FR1P,FP1P) KP,LP | 89/10~92/ | Final Drive PINION |
| 03908 6075 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2XD-4) FR270B#,FR33# | 83/~89/ | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7155 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2XD-4) FR28#PP,QP,FP28#PP,QP | 83/~89/ | Final Drive PINION |
| 03908 3803 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2XD-4) FR600BD,BM,FR63#,66# | 83/~89/ | Final Drive PINION |
| 03908 4227 | 9828-01130 | 146 x 170 x 18 | TRUCK (2XD-4) KF | 71/~81/ | Wheel Hub REAR INNER (F) |
| 03908 3179 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2XD-4) (FR1P,FP1P) PP,PV,PW,QP | 89/12~92/ | Final Drive PINION |
| 03908 7795 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-4) FR1F EXCEPT FK#,FP1F | 89/12~95/3 | Final Drive PINION |
| 03908 5939 | 9828-85110 | 85 x 146 x 10 x 26 | TRUCK (2XD-4) FR1FK#,FR2F#,FR3F#,FP 2F# | 92/5~95/3 | Final Drive PINION |
| 03908 4979 | 9828-85110 | 85 x 146 x 10 x 26 | TRUCK (2XD-4) (FR2P,FP2P) NA,NC,GA | 92/5~94/11 | Final Drive PINION |
| 03908 7203 | 9828-85110 | 85 x 146 x 10 x 26 | TRUCK (2XD-4) FR1K,FP1K | 92/5~94/11 | Final Drive PINION |
| 03908 8499 | 9828-85110 | 85 x 146 x 10 x 26 | TRUCK (2XD-4) FR2K KBD-BA,KBM-BE | 92/5~95/ | Final Drive PINION |
| 03908 1163 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2XD-4) FR2K EXCEPT KBD-BA,KBM-BE,FP2K | 95/8~00/ | Final Drive PINION |
| 03908 7443 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2XD-4) FR1F EXCEPT FK#, FP1F | 95/4~ | Final Drive PINION |
| 03908 4683 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2XD-4) (FR2P,FP2P) NA,NC,GA | 94/12~ | Final Drive PINION |
| 03908 2339 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2XD-4) FR1K,FP1K | 94/12~ | Final Drive PINION |
| 03908 6731 | 9828-85112 | 85 x 146 x 9 x 24 | TRUCK (2XD-4) FR1FK#,FR2F#,FR3F#,F R4F#,FP2F# | 95/4~ | Final Drive PINION |
| 03908 4411 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-4) (FR2P,FP2P) FA,KA,KC | 92/5~ | Final Drive PINION |
| 03908 6451 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2XD-4) FR28#PP,QP,FP28#PP,QP | 81/~83/ | Final Drive PINION |
| 03908 7195 | 9828-95112 | 95 x 156 x 17 x 23.5 | TRUCK (2XD-4) FR1FK#,FR2F#,FR3F# | 89/12~92/4 | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7411 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-4) FR2P NA,NC,GA | 92/5~99/8 | Transmission REAR COVER |
| 03908 1643 | 9828-95106 | 95 x 152 x 10 x 25 | TRUCK (2XD-4) KF301D,704D,5# | 71/~81/ | Final Drive PINION |
| 03908 8123 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (2XD-4) KF3#,7#...EXCEPT 301D,704D | 71/~81/ | Final Drive PINION |
| 03908 2611 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-4) FR1K,3F,4F,2P,FP2P | 99/9~ | Transmission REAR COVER |
| 03908 1195 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-4) FR2K EXCEPT KBD-BA,KBM-BE,FP2K | 92/5~95/7 | Final Drive PINION |
| 03908 6355 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-4) FP1K,2F | 92/5~ | Transmission REAR COVER |
| 03908 2467 | 9828-01193 | 154 x 175 x 13 | TRUCK (2XD-4) FR,FP | 81/5~ | Wheel Hub REAR INNER (F) |
| 03908 2059 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-4) FR2F,3F,4F,1K | 92/5~99/8 | Transmission REAR COVER |
| 03908 3339 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-4) FR1F DUMP MIXER | 92/5~ | Transmission REAR COVER |
| 03908 6467 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FP2P FA,KA,KC | 92/5~99/8 | Transmission REAR COVER |
| 03908 7275 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FP1F,1P,2K | 89/12~ | Transmission REAR COVER |
| 03908 3003 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FR2K | 92/5~00/ | Transmission REAR COVER |
| 03908 7843 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FR2P FA,FF,FN,KA,KC | 92/5~99/8 | Transmission REAR COVER |
| 03908 4731 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FR1F EXCEPT DUMP,MIXER | 92/5~ | Transmission REAR COVER |
| 03908 6747 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2XD-4) KF | 71/~81/ | Wheel Hub REAR OUTER (F) |
| 03908 7987 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-4) FP2P NA,NC | 92/5~99/8 | Transmission REAR COVER |
| 03908 4315 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FR1F,2F,3F,1P,1K,2K | 89/9~92/4 | Transmission REAR COVER |
| 03908 3499 | 9828-01207 | 138 x 152 x 12 | TRUCK (2XD-4) FR SELF STEERING | 89/9~ | Wheel Hub REAR INNER |
| 03908 4507 | 9828-01130 | 146 x 170 x 18 | TRUCK (2XD-4) KF | 71/~81/ | Wheel Hub REAR INNER |
| 03908 5595 | 9828-76101 | 76 x 164 x 14 | TRUCK (2XD-4) FR,FP | 81/5~ | Wheel Hub REAR OUTER (F) |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3147 | 9828-55113 | 55 x 72 x 9 | TRUCK (2XD-4) KF,FR,FP | 71/~ | Transmission FRONT COVER |
| 03908 2811 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-4) KF EXCEPT 500D,545,585,595 | 71/~81/ | Transmission REAR COVER |
| 03908 4267 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-4) FR27#,FP27# | 81/5~83/11 | Transmission REAR COVER |
| 03908 7003 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) KF 500D,545,585,595 | 76/~81/ | Transmission REAR COVER |
| 03908 5755 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FR27#,33#,FP27# | 83/12~90/ | Transmission REAR COVER |
| 03908 1299 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-4) FR28#,60#,63#,66#,FP28# ,60# | 81/5~89/ | Transmission REAR COVER |
| 03908 7403 | 9828-01193 | 154 x 175 x 13 | TRUCK (2XD-4) FR,FP | 81/5~ | Wheel Hub REAR INNER |
| 03908 1883 | 9828-57103 | 57 x 124 x 13 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR OUTER |
| 03908 3187 | 9828-62104 | 62 x 76 x 9 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR OUTER |
| 03908 5851 | 9828-01189 | 159 x 182 x 18 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR INNER |
| 03908 5467 | 9828-76101 | 76 x 164 x 14 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR OUTER |
| 03908 3307 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR OUTER |
| 03908 6691 | 9828-62104 | 62 x 76 x 9 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR OUTER (F) |
| 03908 1107 | 9828-57103 | 57 x 124 x 13 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR OUTER (F) |
| 03908 7675 | 9828-76101 | 76 x 164 x 14 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR OUTER (F) |
| 03908 5547 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR OUTER (F) |
| 03908 4059 | 9828-01203 | 127 x 147 x 11 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR INNER |
| 03908 4611 | 9828-01193 | 154 x 175 x 13 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR INNER |
| 03908 5539 | 9828-01130 | 146 x 170 x 18 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR INNER |
| 03908 3315 | 9828-01189 | 159 x 182 x 18 | TRUCK (2XD-D) WP | 98/7~ | Wheel Hub REAR INNER (F) |
| 03908 5451 | 9828-01193 | 154 x 175 x 13 | TRUCK (2XD-D) FS | 81/5~ | Wheel Hub REAR INNER (F) |
| 03908 2003 | 9828-01130 | 146 x 170 x 18 | TRUCK (2XD-D) ZM | 71/~81/ | Wheel Hub REAR INNER (F) |
| 03908 5875 | 9828-01207 | 138 x 152 x 12 | TRUCK (2XD-D) ZM,KK,FQ,FS,GK,WP | 71/~ | Wheel Hub FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2675 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS60#,63#,66#... 9 SPEED T/M | 81/5~89/ | Transmission REAR COVER |
| 03908 1915 | 9828-55113 | 55 x 72 x 9 | TRUCK (2XD-D) ZM,FQ,FS,WP | 71/~ | Transmission FRONT COVER |
| 03908 7339 | 9828-01203 | 127 x 147 x 11 | TRUCK (2XD-D) KK,FQ,GK | 83/12~ | Wheel Hub REAR INNER (F) |
| 03908 4995 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (2XD-D) ZM | 71/~81/ | Final Drive PINION (REAR) |
| 03908 3579 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FQ1F | 90/2~95/4 | Transmission REAR COVER |
| 03908 4483 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) WP | 98/7~99/8 | Transmission REAR COVER |
| 03908 3723 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1F,3F,4F,1K,2P | 99/9~ | Transmission REAR COVER |
| 03908 2787 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ2P RFA#,TFA#,WFA# | 99/9~ | Transmission REAR COVER |
| 03908 8387 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ3F,4F,1K | 99/9~ | Transmission REAR COVER |
| 03908 7939 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (2XD-D) FQ | 00/3~ | Final Drive PINION (REAR) |
| 03908 4379 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) WP | 99/9~ | Transmission REAR COVER |
| 03908 5771 | 9828-90104 | 90 x 115 x 13 x 19 | TRUCK (2XD-D) ZM,KK,FQ,FS,GK | 71/~92/3 | Final Drive PINION (FRONT) |
| 03908 5115 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ1K | 98/2~99/8 | Transmission REAR COVER |
| 03908 8003 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (2XD-D) WP | 98/7~01/ | Final Drive PINION (FRONT) |
| 03908 7851 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ2P RFA#,TFA#,WFA# | 96/4~99/8 | Transmission REAR COVER |
| 03908 6403 | 9828-63104 | 63 x 100 x 12 | TRUCK (2XD-D) KK | 83/9~86/5 | Final Drive PINION (REAR) |
| 03908 8411 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-D) GK | 89/7~98/6 | Final Drive PINION (REAR) |
| 03908 1979 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-D) FQ | 90/2~00/2 | Final Drive PINION (REAR) |
| 03908 3539 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (2XD-D) KK | 86/6~89/ | Final Drive PINION (REAR) |
| 03908 7931 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (2XD-D) FS | 81/5~95/3 | Final Drive PINION (REAR) |
| 03908 6323 | 9828-70116 | 70 x 94.5 x 10 x 16.5 | TRUCK (2XD-D) WP | 98/7~01/ | Final Drive PINION (REAR) |
| 03908 5723 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (2XD-D) FS | 95/4~ | Final Drive PINION (REAR) |
| 03908 7491 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (2XD-D) GK | 98/7~ | Final Drive PINION (REAR) |
| 03908 6019 | 9828-90115 | 90 x 125 x 10 x 17 | TRUCK (2XD-D) FQ,FS,GK | 92/4~ | Final Drive PINION (FRONT) |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4627 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS60#,63#,66#...EXCEPT 9 SPEED T/M | 81/5~89/ | Transmission REAR COVER |
| 03908 6571 | 9828-50105 | 50 x 68 x 9 | TRUCK (2XD-D) KK,GK | 86/6~ | Transmission FRONT COVER |
| 03908 6371 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) ZM,303D,M REAR AXLE RATIO 6.428 | 77/~81/ | Transmission REAR COVER |
| 03908 2563 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) ZM706D,M 1ST GEAR RATIO 6.028 | 79/~81/ | Transmission REAR COVER |
| 03908 5963 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) ZM745,765,785 | 79/~81/ | Transmission REAR COVER |
| 03908 6195 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) FS27# | 81/5~83/11 | Transmission REAR COVER |
| 03908 4915 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (2XD-D) KK,GK | 83/9~ | Transmission REAR COVER |
| 03908 7579 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) ZM303D,M REAR AXLE RATIO 6.833 | 77/~81/ | Transmission REAR COVER |
| 03908 6627 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) ZM706F,M 1ST GEAR RATIO 7.028 | 79/~81/ | Transmission REAR COVER |
| 03908 5899 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FQ2F,3F | 92/5~99/8 | Transmission REAR COVER |
| 03908 3547 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS27#,33#...EXCEPT 9 SPEED T/M | 83/12~89/ | Transmission REAR COVER |
| 03908 1339 | 9828-48120 | 48 x 60 x 9 | TRUCK (2XD-D) KK | 83/9~86/5 | Transmission FRONT COVER |
| 03908 2763 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS1F,2F,3F,1K,2K | 89/8~92/4 | Transmission REAR COVER |
| 03908 5491 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FS2K | 92/5~ | Transmission REAR COVER |
| 03908 6963 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) FQ2P REA#,TEA#,WEA# | 98/3~00/ | Transmission REAR COVER |
| 03908 5555 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS27#,33#...9 SPEED T/M | 83/12~89/ | Transmission REAR COVER |
| 03908 8251 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1V 10 SPEED T/M | 92/5~ | Transmission REAR COVER |
| 03908 5859 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1F,2F,3F,4F,1K | 92/5~99/8 | Transmission REAR COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 1939 | 9828-78102 | 78 x 100 x 14 x 20 | TRUCK (2XD-D) FS1V EXCEPT 10 SPEED T/M | 92/5~ | Transmission REAR COVER |
| 03908 4099 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (2XD-D) ZM500D,540,560,580,940 | 77/~81/ | Transmission REAR COVER |
| 03908 7891 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2XD-D) SPZ,SRZ,SSZ | 73/~79/12 | Final Drive PINION (FORWARD) |
| 03908 2035 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-D) SVZ581 | 82/9~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03908 1491 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-D) CXZ,CYZ P85,P90 P/S | 83/8~99/12 | Propeller Shaft CENTER BEARING (F&R) |
| 03908 2243 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P90 P/S | 00/1~ | Propeller Shaft CENTER BEARING (F) |
| 03908 6083 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2XD-D) SRZ,SSZ581,641,701 | 80/1~83/ | Propeller Shaft CENTER BEARING (F&R) |
| 03908 3411 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P60,P90L P/S | 83/8~03/ | Propeller Shaft CENTER BEARING (F&R) |
| 03908 3563 | 1-09625-621-0 | 81 x 103 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P90 P/S | 00/1~ | Propeller Shaft CENTER BEARING |
| 03908 5507 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2XD-D) CXZ,CYZ P115 P/S | 83/8~99/12 | Propeller Shaft CENTER BEARING (F&R) |
| 03908 4547 | 1-09625-622-0 | 86 x 106 x 14 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P115,P115L P/S | 00/1~ | Propeller Shaft CENTER BEARING |
| 03908 8531 | 1-09625-119-0 | 80 x 127 x 16 x 24 | TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ,TMK-Z,TMQ-Z | 80/1~83/ | Final Drive PINION (FORWARD) |
| 03908 8403 | 1-09625-323-0 | 86 x 127 x 16 x 25 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 83/8~ | Final Drive PINION (FORWARD) |
| 03908 1235 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (2XD-D) SPZ,TMK-Z | 73/~78/ | Propeller Shaft CENTER BEARING |
| 03908 4675 | 1-09625-624-0 | 60 x 75 x 9 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJX16 | 03/5~ | Transmission FRONT COVER |
| 03908 6211 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ,TMK-Z,TMQ-Z | 73/~83/ | Final Drive PINION (REARWARD) |
| 03908 8315 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (2XD-D) CXZ | 83/8~89/7 | Final Drive PINION (REARWARD) |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3555 | 1-09625-222-1 | 83 x 114 x 19 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P115,P115L P/S | 00/1~ | Propeller Shaft CENTER BEARING (F) |
| 03908 1051 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 89/8~03/ | Transmission FRONT COVER |
| 03908 4563 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-D) TMK-Z | 73/~80/3 | Transmission FRONT COVER |
| 03908 2507 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-D) SRZ,SSZ | 75/~79/12 | Transmission FRONT COVER |
| 03908 7051 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 8PE1,10PE1,12PE1 | 94/10~ | Engine CRANK SHAFT REAR |
| 03908 2043 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2XD-D) CXZ,CYZ | 89/8~95/ | Final Drive PINION (REARWARD) |
| 03908 2099 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) TMK-Z | 80/4~83/ | Transmission FRONT COVER |
| 03908 8363 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) SRZ,SSZ | 80/1~83/ | Transmission FRONT COVER |
| 03908 5091 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (2XD-D) SPZ,SRZ,SSZ,TMK-Z,SQZ,TMQ-Z,SVZ | 80/1~83/ | Transmission REAR COVER |
| 03908 2851 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) CXZ | 83/8~89/7 | Transmission FRONT COVER |
| 03908 8267 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (2XD-D) SPZ,TMK-Z | 73/~78/ | Propeller Shaft CENTER BEARING (F) |
| 03908 1067 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MAL6,MAP6,MJT7,MJX 12 | 03/5~ | Transmission FRONT COVER |
| 03908 7947 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ | 73/~79/12 | Transmission REAR COVER |
| 03908 1227 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (2XD-D) CXZ MAB,MAF T/M | 83/8~94/ | Transmission REAR COVER |
| 03908 1379 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MAG,MAH,MAL,MAP T/M | 83/8~ | Transmission REAR COVER |
| 03908 8467 | 1-09625-359-0 | 80 x 100 x 12 | TRUCK (2XD-D) CXZ MJA T/M | 86/1~94/ | Transmission REAR COVER |
| 03908 8203 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJA,MJD,MJT T/M | 94/7~ | Transmission REAR COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6843 | 1-09625-625-0 | 104 x 126 x 13 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJX12,16 | 0/3 | Transmission REAR COVER |
| 03908 2163 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (2XD-D) SQZ,TMQ-Z | 81/8~83/ | Transmission FRONT COVER |
| 03908 4635 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (2XD-D) SPZ E120(MIXER),CXZ 6R(MIXER) | 73/~89/ | Engine CRANK SHAFT REAR |
| 03908 4715 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (2XD-D) CXZ 8PD1 | 89/8~93/2 | Engine CRANK SHAFT REAR |
| 03908 6763 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6WA1,6WG1,6WF1 | 92/5~ | Engine CRANK SHAFT REAR |
| 03908 1331 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6SD1 | 96/11~ | Engine CRANK SHAFT REAR |
| 03908 7899 | 1-09625-559-0 | 139 x 171 x 19 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6TE1,7TD1 | 00/1~ | Engine CRANK SHAFT REAR |
| 03908 5667 | 9-12569-072-0 | | TRUCK (2XD-D) E120 | 73/~83/ | Engine VALVE STEM SEAL |
| 03908 7147 | 1-12569-013-0 | | TRUCK (2XD-D) 6R | 81/~89/ | Engine VALVE STEM SEAL |
| 03908 5707 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2XD-D) CXZ 10PD1,12PD1 | 89/8~93/2 | Engine CRANK SHAFT REAR |
| 03908 1371 | 1-12569-019-1 | | TRUCK (2XD-D) 8P#,10P#,12P# | 91/7~ | Engine VALVE STEM SEAL |
| 03908 4515 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (2XD-D) CXZ 8P,10P,12P | 83/8~89/7 | Engine CRANK SHAFT REAR |
| 03908 6235 | 1-12569-019-1 | | TRUCK (2XD-D) 6SD1 | 96/11~ | Engine VALVE STEM SEAL |
| 03908 2363 | 1-12569-019-1 | | TRUCK (2XD-D) 6WA1,6WG1 | 92/5~00/5 | Engine VALVE STEM SEAL |
| 03908 1555 | 1-12569-020-0 | | TRUCK (2XD-D) 6WF1,6WG1 | 00/6~ | Engine VALVE STEM SEAL |
| 03908 6523 | 1-12569-019-1 | | TRUCK (2XD-D) 6TE1,8TD1 | 00/1~ | Engine VALVE STEM SEAL |
| 03908 5299 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (2XD-D) SPZ | 73/~83/ | Transmission FRONT COVER |
| 03908 2707 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (2XD-D) SPZ,TMK-Z E120 | 73/~77/ | Engine CRANK SHAFT FRONT |
| 03908 2275 | 1-12569-009-0 | | TRUCK (2XD-D) 8P,10P,12P | 75/~91/6 | Engine VALVE STEM SEAL |
| 03908 1515 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (2XD-D) CXZ 8PD1 | 89/8~93/2 | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3795 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 16.5 INCH DIFF. | 95/5~ | Final Drive PINION (REARWARD) |
| 03908 8227 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2XD-D) SPZ,TMK-Z E120 | 77/~83/ | Engine CRANK SHAFT FRONT |
| 03908 1987 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (2XD-D) SRZ,SSZ,SVZ 10P,12P | 75/~83/ | Engine CRANK SHAFT FRONT |
| 03908 4419 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2XD-D) CXZ 8P,10P,12P | 83/8~89/7 | Engine CRANK SHAFT FRONT |
| 03908 6035 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (2XD-D) XZ 10PD1,12PD1 | 89/8~93/2 | Engine CRANK SHAFT FRONT |
| 03908 8147 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ 8PD1,10PD1,12PD1 | 93/3~94/ | Engine CRANK SHAFT FRONT |
| 03908 1571 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ 8PD1,10PD1,12PD1 | 93/3~94/ | Engine CRANK SHAFT REAR |
| 03908 4667 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6TE1,8TD1 | 00/1~ | Engine CRANK SHAFT FRONT |
| 03908 5955 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 17.5 INCH DIFF. | 94/9~ | Final Drive PINION (REARWARD) |
| 03908 2107 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6WA1,6WG1,6WF1 | 92/5~ | Engine CRANK SHAFT FRONT |
| 03908 2747 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6SD1 | 96/11~ | Engine CRANK SHAFT FRONT |
| 03908 3699 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-D) SPZ,TMK-Z E120(EXCEPT MIXER) | 73/~83/ | Engine CRANK SHAFT REAR |
| 03908 5123 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (2XD-D) SQZ TMQ-Z,CXZ 6R(EXCEPT MIXER) | 81/8~85/12 | Engine CRANK SHAFT REAR |
| 03908 4755 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (2XD-D) CXZ 6R (EXCEPT MIXER) | 86/1~89/ | Engine CRANK SHAFT REAR |
| 03908 3347 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (2XD-D) SRZ,SSZ,SVZ 10P,12P | 75/~83/ | Engine CRANK SHAFT REAR |
| 03908 5891 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 8PE1,10PE1,12PE1 | 94/10~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2731 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CYZ EXC. REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR INNER (F&R) |
| 03908 7755 | 1-51389-005-0 | 155 x 185 x 13 x 16 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 83/8~ | Rear Suspesion TRUNNION SHAFT |
| 03908 8507 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (2XD-D) SQZ,CXZ 6R | 81/8~89/ | Engine CRANK SHAFT FRONT |
| 03908 4115 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-D) CXZ,CYZ,CXY,CYY | 83/8~ | Wheel Hub FRONT |
| 03908 3763 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ | 73/~83/ | Wheel Hub REAR INNER (F&R) |
| 03908 1739 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CXZ ALL | 83/8~96/10 | Wheel Hub REAR INNER (F&R) |
| 03908 3675 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CXZ EXC. REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR INNER (F&R) |
| 03908 3859 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CYZ ALL | 94/9~96/10 | Wheel Hub REAR INNER (F&R) |
| 03908 7547 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ | 73/~83/ | Wheel Hub FRONT |
| 03908 6579 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CYZ,CYY 16.5,17.5 INCH FINAL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03908 2371 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (2XD-D) CXZ,CYZ REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR INNER (F&R) |
| 03908 2515 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (2XD-D) CXY ALL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03908 2083 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (2XD-D) CYZ,CYY 14.5 INCH FINAL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03908 1147 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CYZ EXC. REAR BRAKE WITH 150 MM | 96/11~99/ | Wheel Hub REAR OUTER (F&R) |
| 03908 1291 | 1-51389-005-0 | 155 x 185 x 13 x 16 | TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ | 73/~83/ | Rear Suspesion TRUNNION SHAFT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2387 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (2XD-D) CXZ ALL | 00/1~ | Wheel Hub REAR INNER (F&R) |
| 03908 4747 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ | 73/~79/12 | Wheel Hub REAR OUTER (F&R) |
| 03908 5427 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (2XD-D) CXY ALL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03908 1707 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (2XD-D) CYZ,CYY 14.5 INCH FINAL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03908 4387 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CYZ,CYY 16.5,17.5 INCH FINAL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03908 2635 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CYZ ALL | 94/9~96/10 | Wheel Hub REAR OUTER (F&R) |
| 03908 6899 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CXZ ALL | 00/1~ | Wheel Hub REAR OUTER (F&R) |
| 03908 4907 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CXZ EXC. REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR OUTER (F&R) |
| 03908 4323 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (2XD-D) CXZ ALL | 83/8~96/10 | Wheel Hub REAR OUTER (F&R) |
| 03908 3035 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ | 80/1~83/ | Wheel Hub REAR OUTER (F&R) |
| 03908 5147 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (2XD-D) CXZ,CYZ REAR BRAKE WITH 150MM | 96/11~99/ | Wheel Hub REAR OUTER (F&R) |
| 03908 6099 | 9828-01130 | 146 x 170 x 18 | TRUCK (6T~8T) KB | 70/~81/ | Wheel Hub REAR INNER |
| 03908 4923 | 9828-90115 | 90 x 125 x 10 x 17 | TRUCK (6T~8T) FZ 1F,4F | 95/4~ | Final Drive PINION |
| 03908 7875 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (6T~8T) KB | 70/~81/ | Final Drive PINION |
| 03908 4259 | 9828-70110 | 70 x 95 x 13 x 20 | TRUCK (6T~8T) K13D | 90/1~95/1 | Engine CRANK SHAFT FRONT |
| 03908 2411 | 9828-70110 | 70 x 95 x 13 x 20 | TRUCK (6T~8T) EK100 | 83/~90/ | Engine CRANK SHAFT FRONT |
| 03908 2123 | 9828-96101 | 96 x 124 x 14 x 21 | TRUCK (6T~8T) EF750,F17D | 87/4~94/11 | Engine CRANK SHAFT FRONT |
| 03908 2051 | 9828-70102 | 70 x 95 x 13 | TRUCK (6T~8T) EK100 | 70/~83/ | Engine CRANK SHAFT FRONT |
| 03908 6339 | 9828-80102 | 80 x 105 x 13 | TRUCK (6T~8T) EB300 | 70/~81/ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3219 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK (6T~8T) H06C,H07C,D | 83/7~94/ | Engine CRANK SHAFT FRONT |
| 03908 1091 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK (6T~8T) EH500,700 | 76/~83/ | Engine CRANK SHAFT FRONT |
| 03908 4699 | 9828-79103 | 79 x 114 x 17 | TRUCK (6T~8T) J08C | 94/9~ | Engine CRANK SHAFT FRONT |
| 03908 7451 | 9828-58105 | 58 x 75 x 9 | TRUCK (6T~8T) EH300 E/#~44626 | 74/~77/ | Engine CRANK SHAFT FRONT |
| 03908 7419 | 9828-75145 | 75 x 114 x 17 | TRUCK (6T~8T) K13D | 95/2~ | Engine CRANK SHAFT FRONT |
| 03908 2659 | 9828-90104 | 90 x 115 x 13 x 19 | TRUCK (6T~8T) FZ 27#,63#,1F | 83/11~95/3 | Final Drive PINION |
| 03908 2499 | 9828-01120 | 140 x 160 x 14 | TRUCK (6T~8T) KG,KR,FF,FG | 74/~83/11 | Wheel Hub REAR INNER |
| 03908 1283 | 9828-80114 | 80 x 136 x 9 x 25 | TRUCK (6T~8T) FH 2K,2P | 95/4~ | Final Drive PINION |
| 03908 1483 | 9828-01137 | 101 x 114 x 10 | TRUCK (6T~8T) KR C/#~19999 | 74/~75/5 | Wheel Hub FRONT |
| 03908 8483 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (6T~8T) FH 220#,222BA-KA,222BF,270BD,272BA | 83/12~90/2 | Final Drive PINION |
| 03908 5187 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (6T~8T) FH 221#,222BA-AA,224BA,226BA,228#,229# | 83/12~90/2 | Final Drive PINION |
| 03908 2075 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (6T~8T) FF 2H,3H,1J | 89/8~99/ | Final Drive PINION |
| 03908 7803 | 9828-80115 | 80 x 124 x 19 x 25 | TRUCK (6T~8T) FG 19#,1H,1J | 83/7~ | Final Drive PINION |
| 03908 2643 | 9828-75111 | 75 x 100 x 13 x 18 | TRUCK (6T~8T) FG 18# | 80/7~83/ | Final Drive PINION |
| 03908 7603 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK (6T~8T) EH300 E/#44627~ | 78/~79/ | Engine CRANK SHAFT FRONT |
| 03908 6531 | 9828-01200 | 122 x 150 x 12 x 18 | TRUCK (6T~8T) EM100 | 83/12~90/ | Engine CRANK SHAFT REAR |
| 03908 1467 | 13719-1470 | | TRUCK (6T~8T) J08C | 98/1~ | Engine VALVE STEM SEAL |
| 03908 3267 | 13719-1360 | | TRUCK (6T~8T) H07C,D,J08C | 94/9~97/12 | Engine VALVE STEM SEAL |
| 03908 6539 | 13719-1350 | | TRUCK (6T~8T) H06C WITH TURBO (EX.) | 83/7~89/7 | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2427 | 13719-1020 | | TRUCK (6T~8T) H06C (IN. & EX.) | 89/8~94/ | Engine VALVE STEM SEAL |
| 03908 5515 | 13719-1020 | | TRUCK (6T~8T) H06C WITH TURBO (IN.) | 83/7~89/7 | Engine VALVE STEM SEAL |
| 03908 2483 | 13719-1020 | | TRUCK (6T~8T) H06C WITHOUT TURBO (IN. & EX.) | 83/7~89/7 | Engine VALVE STEM SEAL |
| 03908 2475 | 13719-1020 | | TRUCK (6T~8T) H07C,D | 83/7~94/8 | Engine VALVE STEM SEAL |
| 03908 1083 | 9828-01223 | 116 x 151 x 17 | TRUCK (6T~8T) K13D,P11C | 95/4~ | Engine CRANK SHAFT REAR |
| 03908 2211 | 9828-75140 | 75 x 100 x 13 x 20 | TRUCK (6T~8T) EM100 | 83/12~90/ | Engine CRANK SHAFT FRONT |
| 03908 5731 | 9828-01228 | 100 x 135 x 17 | TRUCK (6T~8T) J08C | 94/9~ | Engine CRANK SHAFT REAR |
| 03908 3883 | 9828-80110 | 80 x 136 x 20 x 26 | TRUCK (6T~8T) FH 2K | 90/1~95/4 | Final Drive PINION |
| 03908 6203 | 9828-01201 | 125 x 155 x 14 x 23 | TRUCK (6T~8T) K13D EXCEPT FH2KGAM-BA | 90/1~95/4 | Engine CRANK SHAFT REAR |
| 03908 2579 | 9828-01201 | 125 x 155 x 14 x 23 | TRUCK (6T~8T) EK100 EXCEPT MIXER | 75/~90/ | Engine CRANK SHAFT REAR |
| 03908 2739 | 9828-01168 | 135 x 165 x 14 x 20.5 | TRUCK (6T~8T) EF750,F17D | 87/4~94/11 | Engine CRANK SHAFT REAR |
| 03908 4291 | 9828-01202 | 125 x 155 x 14 | TRUCK (6T~8T) K13D FH2KGAM-BA | 90/1~92/ | Engine CRANK SHAFT REAR |
| 03908 4771 | 9828-01202 | 125 x 155 x 14 | TRUCK (6T~8T) EB300,EK100 MIXER | 70/~87/ | Engine CRANK SHAFT REAR |
| 03908 4043 | 9828-01167 | 106 x 126 x 12 | TRUCK (6T~8T) H06C,H07C,D | 83/7~94/ | Engine CRANK SHAFT REAR |
| 03908 1635 | 9828-01167 | 106 x 126 x 12 | TRUCK (6T~8T) EH300,500,700 | 74/~83/ | Engine CRANK SHAFT REAR |
| 03908 5531 | 9828-96109 | 96 x 131 x 17.5 | TRUCK (6T~8T) P11C | 00/3~ | Engine CRANK SHAFT FRONT |
| 03908 3075 | 9828-96109 | 96 x 131 x 17.5 | TRUCK (6T~8T) F17D | 94/12~02/ | Engine CRANK SHAFT FRONT |
| 03908 1443 | 9828-01226 | 125 x 177 x 17.5 | TRUCK (6T~8T) F17D | 94/12~02/ | Engine CRANK SHAFT REAR |
| 03908 7883 | 9828-65127 | 65 x 114 x 9 x 25 | TRUCK (6T~8T) FE,FJ | 98/7~ | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 1403 | 9828-48120 | 48 x 60 x 9 | TRUCK (6T~8T) FE 1J | 96/8~ | Transmission FRONT COVER |
| 03908 7819 | 9828-48120 | 48 x 60 x 9 | TRUCK (6T~8T) FG19#,FH22#,FF2H,1J | 80/~99/ | Transmission FRONT COVER |
| 03908 7115 | 9828-43102 | 43 x 63 x 9 | TRUCK (6T~8T) FF 17#,3H | 83/7~94/ | Transmission FRONT COVER |
| 03908 5051 | 9828-37103 | 37 x 50 x 6 | TRUCK (6T~8T) KR 6 SPEED,FF | 76/~83/6 | Transmission FRONT COVER |
| 03908 2987 | 9828-57103 | 57 x 124 x 13 | TRUCK (6T~8T) FE,FJ | 96/8~ | Wheel Hub REAR OUTER |
| 03908 2203 | 9828-76101 | 76 x 164 x 14 | TRUCK (6T~8T) CG,FH,FZ | 81/1~ | Wheel Hub REAR OUTER |
| 03908 6379 | 9828-60108 | 60 x 74 x 7.5 | TRUCK (6T~8T) KB | 70/~81/ | Wheel Hub REAR OUTER |
| 03908 6179 | 9828-48120 | 48 x 60 x 9 | TRUCK (6T~8T) FJ | 99/3~ | Transmission FRONT COVER |
| 03908 5339 | 9828-52115 | 52 x 64 x 9 | TRUCK (6T~8T) KG,FF,FG | 80/~83/11 | Wheel Hub REAR OUTER |
| 03908 4555 | 9828-66106 | 66 x 134 x 16 | TRUCK (6T~8T) KG,FF,FG | 83/12~ | Wheel Hub REAR OUTER |
| 03908 5883 | 9828-52108 | 52 x 62 x 6 x 10 | TRUCK (6T~8T) KR301,321,361 | 74/~77/ | Wheel Hub REAR OUTER |
| 03908 5403 | 9828-01203 | 127 x 147 x 11 | TRUCK (6T~8T) FE,FJ | 96/8~ | Wheel Hub REAR INNER |
| 03908 1131 | 9828-01193 | 154 x 175 x 13 | TRUCK (6T~8T) CG,FH,FZ | 81/1~ | Wheel Hub REAR INNER |
| 03908 6947 | 9828-01204 | 145 x 164 x 14 | TRUCK (6T~8T) KG,FF,FG | 83/12~ | Wheel Hub REAR INNER |
| 03908 7027 | 9828-01189 | 159 x 182 x 18 | TRUCK (6T~8T) FZ | 83/12~ | Wheel Hub FRONT |
| 03908 3827 | 9828-01207 | 138 x 152 x 12 | TRUCK (6T~8T) CG,FE,FG,FH,FJ,KG | 80/~ | Wheel Hub FRONT |
| 03908 7691 | 9828-01207 | 138 x 152 x 12 | TRUCK (6T~8T) KB | 70/~81/ | Wheel Hub FRONT |
| 03908 4523 | 9828-01207 | 138 x 152 x 12 | TRUCK (6T~8T) KR C/#20000~ | 75/6~80/ | Wheel Hub FRONT |
| 03908 1427 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (6T~8T) FE | 96/8~98/6 | Final Drive PINION |
| 03908 6675 | 9828-78101 | 78 x 100 x 14 x 20 | TRUCK (6T~8T) FZ 1F | 93/6~99/8 | Transmission REAR COVER |
| 03908 3299 | 9828-65113 | 65 x 114 x 10 x 25.5 | TRUCK (6T~8T) FF 17# | 83/7~89/ | Final Drive PINION |
| 03908 4827 | 9828-65108 | 65 x 95 x 14 x 22 | TRUCK (6T~8T) KR,FF | 74/~83/6 | Final Drive PINION |
| 03908 3771 | 9828-52115 | 52 x 64 x 9 | TRUCK (6T~8T) KR305,325,365 | 77/~80/ | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 2491 | 9828-78104 | 78 x 100 x 14 x 20 | TRUCK (6T~8T) FZ 1F,4F | 99/9~ | Transmission REAR COVER |
| 03908 6475 | 9828-50105 | 50 x 68 x 9 | TRUCK (6T~8T) KB EXCEPT 501 | 72/~81/ | Transmission FRONT COVER |
| 03908 1803 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (6T~8T) FH | 95/4~ | Transmission REAR COVER |
| 03908 1395 | 9828-75119 | 75 x 100 x 13 x 19 | TRUCK (6T~8T) FZ 63#,1F | 87/4~92/12 | Transmission REAR COVER |
| 03908 4843 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (6T~8T) FH,FZ27# | 83/11~95/4 | Transmission REAR COVER |
| 03908 1819 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (6T~8T) FG | 80/7~ | Transmission REAR COVER |
| 03908 3483 | 9828-55110 | 55 x 72 x 9 x 15 | TRUCK (6T~8T) KR,FF | 74/~83/6 | Transmission REAR COVER |
| 03908 4211 | 9828-70101 | 70 x 95 x 14 x 20.5 | TRUCK (6T~8T) KB 6 SPEED | 70/~81/ | Transmission REAR COVER |
| 03908 3891 | 9828-50105 | 50 x 68 x 9 | TRUCK (6T~8T) FG 1H,1J | 89/8~ | Transmission FRONT COVER |
| 03908 6755 | 9828-55113 | 55 x 72 x 9 | TRUCK (6T~8T) FZ | 83/11~ | Transmission FRONT COVER |
| 03908 1715 | 9828-55113 | 55 x 72 x 9 | TRUCK (6T~8T) KB 501 | 77/9~81/ | Transmission FRONT COVER |
| 03908 7747 | 9828-60119 | 60 x 75 x 9 x 15 | TRUCK (6T~8T) FF 17#,3H | 83/7~94/ | Transmission REAR COVER |
| 03908 7515 | 9828-63108 | 63 x 78 x 9 x 15 | TRUCK (6T~8T) FF 2H,1J | 89/8~99/ | Transmission REAR COVER |
| 03908 3651 | 9828-63108 | 63 x 78 x 9 x 15 | TRUCK (6T~8T) FE,FJ | 96/8~ | Transmission REAR COVER |
| 03908 1451 | 9828-65111 | 65 x 95 x 14 x 20.5 | TRUCK (6T~8T) KB 5 SPEED | 70/~79/ | Transmission REAR COVER |
| 03908 5827 | 9828-55113 | 55 x 72 x 9 | TRUCK (6T~8T) FH 27#,2K,2P | 81/6~ | Transmission FRONT COVER |
| 03908 5483 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (6T~8T) CVR | 83/9~89/10 | Transmission FRONT COVER |
| 03908 2979 | 1-09625-085-0 | 55 x 72 x 15 | TRUCK (6T~8T) TXD | 80/5~84/ | Propeller Shaft CENTER BEARING (F & R) |
| 03908 5291 | 9-37529-013-0 | 65 x 110 x 47 | TRUCK (6T~8T) TD,TP | 71/~79/12 | Propeller Shaft CENTER BEARING |
| 03908 5275 | 1-09625-577-1 | 80 x 100 x 13 | TRUCK (6T~8T) CVR MJT7 T/M | 03/6~ | Transmission REAR COVER |
| 03908 7307 | 1-09625-579-1 | 74 x 97 x 13 | TRUCK (6T~8T) CVR MAF5,MAF6 T/M | 83/9~95/ | Transmission REAR COVER |
| 03908 5395 | 1-09625-207-0 | 73 x 96 x 12 | TRUCK (6T~8T) TD,TP,SMR,SJR MAB T/M | 80/1~83/ | Transmission REAR COVER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3291 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (6T~8T) SMR MAB T/M | 78/4~79/12 | Transmission REAR COVER |
| 03908 1251 | 1-09625-063-0 | 68 x 90 x 12 | TRUCK (6T~8T) TXD,TD,TP,SLR MLE T/M | 71/~83/ | Transmission REAR COVER |
| 03908 4763 | 1-09625-562-0 | 54 x 69 x 9 | TRUCK (6T~8T) CVR | 89/11~ | Transmission FRONT COVER |
| 03908 5835 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) TD,TDJ,TDK,TP | 80/1~83/ | Propeller Shaft CENTER BEARING (F & R) |
| 03908 7587 | 1-09625-173-0 | 60 x 77 x 12 | TRUCK (6T~8T) TXD MG,MB T/M | 71/~84/ | Transmission REAR COVER |
| 03908 7659 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) SMR EXCEPT TURBO | 78/4~83/ | Propeller Shaft CENTER BEARING (F & R) |
| 03908 7427 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) SLR,SJR | 80/1~83/ | Propeller Shaft CENTER BEARING (F & R) |
| 03908 8331 | 1-09625-130-0 | 65 x 90 x 16 | TRUCK (6T~8T) CVR 6QA1 | 83/9~89/10 | Propeller Shaft CENTER BEARING (F & R) |
| 03908 2307 | 1-09625-126-0 | 70 x 100 x 16 | TRUCK (6T~8T) CVR 8PC1,8PD1,8PE1 | 83/9~03/ | Propeller Shaft CENTER BEARING (F & R) |
| 03908 3619 | 1-09625-127-0 | 75 x 105 x 16 | TRUCK (6T~8T) CVR 6SD1,6WF1 | 03/6~ | Propeller Shaft CENTER BEARING (F) |
| 03908 7731 | 1-09625-621-0 | 81 x 103 x 16 | TRUCK (6T~8T) CVR 6SD1,6WF1 | 03/6~ | Propeller Shaft CENTER BEARING |
| 03908 3427 | 1-09625-173-0 | 60 x 77 x 12 | TRUCK (6T~8T) TXD | 71/~77/ | Final Drive PINION |
| 03908 7915 | 1-09625-484-0 | 60 x 103 x 12 x 20 | TRUCK (6T~8T) TXD | 77/~84/ | Final Drive PINION |
| 03908 6987 | 1-09625-063-0 | 68 x 90 x 12 | TRUCK (6T~8T) TD,TP SINGLE SPEED | 71/~74/ | Final Drive PINION |
| 03908 7779 | 1-09625-063-0 | 68 x 90 x 12 | TRUCK (6T~8T) SLR SINGLE SPEED | 73/~83/ | Final Drive PINION |
| 03908 7699 | 1-09625-497-0 | 48 x 62 x 9 | TRUCK (6T~8T) SMR,SJR | 80/1~83/ | Transmission FRONT COVER |
| 03908 5307 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) TDJ | 80/1~84/ | Final Drive PINION |
| 03908 1323 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (6T~8T) TD,TP EXCEPT TD-U,TD-P (2 SPEED) | 71/~79/12 | Wheel Hub REAR OUTER |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3419 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) TP SINGLE SPEED | 72/~84/ | Final Drive PINION |
| 03908 5779 | 9-37529-003-0 | 65 x 113 x 26 | TRUCK (6T~8T) TD,TP | 71/~79/12 | Propeller Shaft CENTER BEARING(F) |
| 03908 2331 | 9-09924-407-0 | 76 x 115 x 13 x 21 | TRUCK (6T~8T) YXD | 71/~84/ | Wheel Hub FRONT |
| 03908 4795 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (6T~8T) TD,TP,SLR,SMR,SJR | 73/~84/ | Wheel Hub FRONT |
| 03908 2267 | 1-09625-041-0 | 120 x 140 x 10.5 | TRUCK (6T~8T) CVR | 83/9~ | Wheel Hub FRONT |
| 03908 6171 | 9-09924-415-0 | 100 x 145 x 14.5 x 26 | TRUCK (6T~8T) TXD | 71/~84/ | Wheel Hub REAR INNER |
| 03908 6515 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) TD,TP EXCEPT TD-U,TD-P (2 SPEED) | 71/~79/12 | Wheel Hub REAR INNER |
| 03908 3755 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) TDJ,TPJ78 | 80/1~84/ | Wheel Hub REAR INNER |
| 03908 4707 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) SLR,SMR(EXCEPT 360,361) | 73/~83/ | Wheel Hub REAR INNER |
| 03908 2955 | 1-09625-351-0 | 115 x 156 x 15.5 x 31 | TRUCK (6T~8T) SJR 461,531,601 | 81/8~83/ | Wheel Hub REAR INNER |
| 03908 6259 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (6T~8T) TD,TP TD-U,TD-P (2 SPEED) | 71/~79/12 | Wheel Hub REAR INNER |
| 03908 2219 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (6T~8T) TDK,TP,TDJ (EXCEPT 78) | 80/1~84/ | Wheel Hub REAR INNER |
| 03908 6163 | 9-09924-393-0 | 123 x 184 x 15 x 28 | TRUCK (6T~8T) SMR360,361,SJR361 | 78/4~83/ | Wheel Hub REAR INNER |
| 03908 2155 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (6T~8T) SMR450,520,600,670 | 78/3~79/12 | Wheel Hub REAR OUTER |
| 03908 7243 | 9-09924-470-0 | 64 x 132.5 x 13 | TRUCK (6T~8T) TXD | 71/~84/ | Wheel Hub REAR OUTER |
| 03908 1387 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (6T~8T) SMR | 78/4~79/12 | Transmission FRONT COVER |
| 03908 3467 | 9-09924-374-0 | 71 x 142 x 14 | TRUCK (6T~8T) SLR350,360,400,450,520, 600,670,700 | 73/~79/12 | Wheel Hub REAR OUTER |
| 03908 8115 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) SMR EXCEPT 360,361 | 78/~83/ | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 5563 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) TD,TDJ | 80/1~84/ | Wheel Hub REAR OUTER |
| 03908 7363 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) SLR361,401,461,531 | 80/1~83/ | Wheel Hub REAR OUTER |
| 03908 3211 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) SMR401,461,531,601,671 | 80/1~83/ | Wheel Hub REAR OUTER |
| 03908 4851 | 1-09625-379-0 | 74 x 142.9 x 17.5 | TRUCK (6T~8T) SJR461,531,601 | 81/8~83/ | Wheel Hub REAR OUTER |
| 03908 8307 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (6T~8T) TD,TP TD-U,TD-P (2 SPEED) | 70/1~79/12 | Wheel Hub REAR OUTER |
| 03908 1211 | 9-09924-392-0 | 78 x 162 x 16 | TRUCK (6T~8T) SMR360 | 78/4~79/12 | Wheel Hub REAR OUTER |
| 03908 2195 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (6T~8T) SMR361,SJR361 | 80/1~83/ | Wheel Hub REAR OUTER |
| 03908 2531 | 1-09625-444-0 | 78 x 163 x 16 | TRUCK (6T~8T) CVR | 83/9~ | Wheel Hub REAR OUTER |
| 03908 7091 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (6T~8T) TXD | 73/~84/ | Transmission FRONT COVER |
| 03908 4963 | 1-09625-502-0 | 40 x 55 x 9 | TRUCK (6T~8T) TD,TDJ,TP | 80/1~84/ | Transmission FRONT COVER |
| 03908 5227 | 1-09625-350-0 | 117 x 174 x 15.5 x 28 | TRUCK (6T~8T) CVR | 83/9~ | Wheel Hub REAR INNER |
| 03908 6315 | 1-09625-441-0 | 128 x 148 x 14 | TRUCK (6T~8T) CVR 6QA1(EXCEPT FLYWHEEL PTO) | 86/4~89/10 | Engine CRANK SHAFT REAR |
| 03908 2187 | 1-09625-556-2 | 118 x 148 x 20 | TRUCK (6T~8T) CVR 6WF1 | 03/6~ | Engine CRANK SHAFT FRONT |
| 03908 6187 | 9-12365-040-0 | SPLIT SEAL x x | TRUCK (6T~8T) TXD DA120,640 | 71/~76/ | Engine CRANK SHAFT REAR |
| 03908 3371 | 9-09924-356-0 | 105 x 135 x 14 | TRUCK (6T~8T) TXD 120,640 | 76/~84/ | Engine CRANK SHAFT REAR |
| 03908 4427 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) TD,TP,SLR(EXCEPT MIXER) DH100 | 75/~84/ | Engine CRANK SHAFT REAR |
| 03908 7531 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) TDK E120 | 80/1~84/ | Engine CRANK SHAFT REAR |
| 03908 1315 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) TDJ,TPJ 6QA1 | 80/1~84/ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 3275 | 1-09625-541-2 | 114 x 150 x 17 | TRUCK (6T~8T) CVR 6SD1 | 03/6~ | Engine CRANK SHAFT REAR |
| 03908 6003 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) CVR 6QA1(EXCEPT FLYWHEEL PTO) | 83/9~86/3 | Engine CRANK SHAFT REAR |
| 03908 6299 | 1-09625-424-0 | 120 x 153 x 13 x 15 | TRUCK (6T~8T) CVR 8PC1,8PD1 | 88/8~95/ | Engine CRANK SHAFT FRONT |
| 03908 6771 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (6T~8T) SLR DH100 (MIXER) | 76/~83/ | Engine CRANK SHAFT REAR |
| 03908 5627 | 1-09625-504-0 | 125 x 155 x 10 | TRUCK (6T~8T) CVR 6QA1 (MIXER) | 83/9~89/ | Engine CRANK SHAFT REAR |
| 03908 5371 | 1-09625-201-0 | 120 x 153 x 15 x 18 | TRUCK (6T~8T) SMR 8PB1 | 78/4~83/ | Engine CRANK SHAFT REAR |
| 03908 2907 | 1-09625-507-1 | 120 x 153 x 17 | TRUCK (6T~8T) CVR 8PC1 | 83/9~88/7 | Engine CRANK SHAFT REAR |
| 03908 8235 | 1-09625-425-1 | 120 x 153 x 15 | TRUCK (6T~8T) CVR 8PC1,8PD1 | 88/8~95/ | Engine CRANK SHAFT REAR |
| 03908 2347 | 1-09625-525-2 | 111 x 153 x 16.5 | TRUCK (6T~8T) CVR 8PE1 | 95/3~03/ | Engine CRANK SHAFT REAR |
| 03908 2291 | 1-09625-317-0 | 128 x 148 x 10 | TRUCK (6T~8T) SJR 6QA1(EXCEPT MIXER) | 81/8~83/ | Engine CRANK SHAFT REAR |
| 03908 5643 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (6T~8T) TD,TP,SLR DH100,D920 | 71/~77/ | Engine CRANK SHAFT FRONT |
| 03908 7355 | 1-09625-578-1 | 78 x 97 x 13 | TRUCK (6T~8T) CVR MAL5,MAL6,MAP6 T/M | 95/5~ | Transmission REAR COVER |
| 03908 2915 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) SJR461,531,601 | 81/8~83/ | Final Drive PINION |
| 03908 6427 | 1-09625-017-0 | 68 x 124 x 11.5 x 27 | TRUCK (6T~8T) CVR 16.5 INCH FINAL | 83/9~ | Final Drive PINION |
| 03908 4283 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (6T~8T) TD,TP 2 SPEED | 71/~84/ | Final Drive PINION |
| 03908 8283 | 1-09625-149-0 | 80 x 105 x 12 | TRUCK (6T~8T) SLR 2 SPEED | 73/~79/12 | Final Drive PINION |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 6923 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (6T~8T) TDK SINGLE SPEED | 80/1~84/ | Final Drive PINION |
| 03908 3627 | 1-09625-540-3 | 114 x 153 x 17.5 | TRUCK (6T~8T) CVR 6SD1 | 03/??? | Engine CRANK SHAFT FRONT |
| 03908 4091 | 1-09625-128-0 | 70 x 92 x 12 | TRUCK (6T~8T) TXD DA120,640 | 71/~84/ | Engine CRANK SHAFT FRONT |
| 03908 1787 | 1-09625-524-3 | 111 x 153 x 16.5 | TRUCK (6T~8T) CVR..8PE1 | 95/3~03/ | Engine CRANK SHAFT FRONT |
| 03908 1923 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (6T~8T) TD,TP,SLR DH100 | 77/~84/ | Engine CRANK SHAFT FRONT |
| 03908 2771 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (6T~8T) TDK E120 | 80/1~84/ | Engine CRANK SHAFT FRONT |
| 03908 6331 | 1-09625-316-0 | 70 x 92 x 10 x 16 | TRUCK (6T~8T) TDJ,TPJ,SJR,CVR 6QA1 | 80/1~88/7 | Engine CRANK SHAFT FRONT |
| 03908 3395 | 1-09625-442-0 | 70 x 92 x 12 | TRUCK (6T~8T) CVR 6QA1 | 88/8~89/10 | Engine CRANK SHAFT FRONT |
| 03908 4171 | 1-09625-200-0 | 120 x 153 x 15 | TRUCK (6T~8T) SMR 8PB1 | 78/4~83/ | Engine CRANK SHAFT FRONT |
| 03908 8451 | 1-09625-506-0 | 120 x 153 x 15 | TRUCK (6T~8T) CVR 8PC1,8PD1 | 83/9~88/7 | Engine CRANK SHAFT FRONT |
| 03908 4819 | 1-09625-322-0 | 86 x 143 x 10 x 38 | TRUCK (6T~8T) CVR 17.5 INCH FINAL | 89/11~ | Final Drive PINION |
| 03908 1355 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (6T~8T) CVR 17.5 INCH FINAL | 83/9~89/10 | Final Drive PINION |
| 03908 2795 | 1-09625-030-0 | 80 x 143 x 10 x 37 | TRUCK (6T~8T) SMR360,361,SJR361 | 78/4~83/ | Final Drive PINION |
| 03908 4123 | 1-12569-009-0 | | TRUCK (6T~8T) DA120,640 | 71/~84/ | Engine VALVE STEM SEAL |
| 03908 3747 | 9-12569-072-0 | | TRUCK (6T~8T) E120 | 71/~83/ | Engine VALVE STEM SEAL |
| 03908 3027 | 9-12569-058-0 | | TRUCK (6T~8T) DA100,6QA1 | 75/~89/10 | Engine VALVE STEM SEAL |
| 03908 1867 | 1-12569-009-0 | | TRUCK (6T~8T) 8PC1,8PD1 | 83/9~91/6 | Engine VALVE STEM SEAL |
| 03908 5179 | 1-12569-019-1 | | TRUCK (6T~8T) 8PC1,8PD1,8PE1 | 91/7~03/ | Engine VALVE STEM SEAL |
| 03908 6707 | 1-12569-019-1 | | TRUCK (6T~8T) 6SD1 | 03/6~ | Engine VALVE STEM SEAL |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 7083 | 1-12569-020-0 | | TRUCK (6T~8T) 6WF1 | 03/6~ | Engine VALVE STEM SEAL |
| 03908 1683 | 1-09625-557-1 | 118 x 148 x 20 | TRUCK (6T~8T) CVR 6WF1 | 03/6~ | Engine CRANK SHAFT REAR |
| 03908 5947 | 9828-01201 | 125 x 155 x 14 x 23 | TRUCK ENGINE K13C,D EXCEPT MIXER | 89/11~95/3 | Crank Shaft REAR |
| 03908 2867 | 9828-01202 | 125 x 155 x 14 | TRUCK ENGINE EK100 MIXER | 75/~89/ | Crank Shaft REAR |
| 03908 4435 | 9828-01201 | 125 x 155 x 14 x 23 | TRUCK ENGINE EK100 EXCEPT MIXER | 75/~90/ | Crank Shaft REAR |
| 03908 6115 | 9828-01202 | 125 x 155 x 14 | TRUCK ENGINE K13D MIXER | 89/11~95/3 | Crank Shaft REAR |
| 03908 2299 | 9828-01158 | 130 x 161 x 14 | TRUCK ENGINE EF300 E/?.~30000 | | Crank Shaft REAR |
| 03908 2147 | 9828-01103 | 135 x 165 x 14 | TRUCK ENGINE EF300 E/?.30001~ | | Crank Shaft REAR |
| 03908 8027 | 9828-01103 | 135 x 165 x 14 | TRUCK ENGINE EF500,700 E/?.~30100 | ~81/ | Crank Shaft REAR |
| 03908 4475 | 9828-01168 | 135 x 165 x 14 x 20.5 | TRUCK ENGINE EF500,700 E/?.30101~ | 81/~82/ | Crank Shaft REAR |
| 03908 6667 | 9828-01168 | 135 x 165 x 14 x 20.5 | TRUCK ENGINE EF350,550,750 | 81/~90/ | Crank Shaft REAR |
| 03908 6043 | 9828-01168 | 135 x 165 x 14 x 20.5 | TRUCK ENGINE V22D | 90/10~95/ | Crank Shaft REAR |
| 03908 5907 | 9828-01223 | 116 x 151 x 17 | TRUCK ENGINE P11C | 94/12~ | Crank Shaft REAR |
| 03908 1139 | 9828-01200 | 122 x 150 x 12 x 18 | TRUCK ENGINE P09C,11C | 89/10~94/11 | Crank Shaft REAR |
| 03908 1771 | 9828-01228 | 100 x 135 x 17 | TRUCK ENGINE J08C | 94/9~ | Crank Shaft REAR |
| 03908 7923 | 9828-01226 | 125 x 177 x 17.5 | TRUCK ENGINE F17D,E,V,F20C,F21C | 94/12~ | Crank Shaft REAR |
| 03908 6915 | 9828-96109 | 96 x 131 x 17.5 | TRUCK ENGINE P11C | 00/3~ | Crank Shaft FRONT |
| 03908 3587 | 9828-01223 | 116 x 151 x 17 | TRUCK ENGINE K13C,D | 95/4~ | Crank Shaft REAR |
| 03908 5131 | 9828-01168 | 135 x 165 x 14 x 20.5 | TRUCK ENGINE F17C,D,E,F20C | 87/7~94/11 | Crank Shaft REAR |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 8099 | 9828-01200 | 122 x 150 x 12 x 18 | TRUCK ENGINE EP100,EM100 | 81/1~90/ | Crank Shaft REAR |
| 03908 4987 | 9828-70110 | 70 x 95 x 13 x 20 | TRUCK ENGINE K13D | 89/11~94/12 | Crank Shaft FRONT |
| 03908 3507 | 9828-96109 | 96 x 131 x 17.5 | TRUCK ENGINE K13C | 98/2~ | Crank Shaft FRONT |
| 03908 7995 | 9828-01167 | 106 x 126 x 12 | TRUCK ENGINE H06C,H07C,D | 83/7~94/ | Crank Shaft REAR |
| 03908 7555 | 9828-70102 | 70 x 95 x 13 | TRUCK ENGINE EK100 KF3#,ZM3#,TC3# | 71/~81/ | Crank Shaft FRONT |
| 03908 5579 | 9828-70110 | 70 x 95 x 13 x 20 | TRUCK ENGINE EK100 | 83/8~90/ | Crank Shaft FRONT |
| 03908 1779 | 9828-96101 | 96 x 124 x 14 x 21 | TRUCK ENGINE EF300,350,500 | 77/~81/ | Crank Shaft FRONT |
| 03908 6147 | 9828-96101 | 96 x 124 x 14 x 21 | TRUCK ENGINE EF550,750 | 81/5~90/ | Crank Shaft FRONT |
| 03908 2091 | 9828-96101 | 96 x 124 x 14 x 21 | TRUCK ENGINE F17C,D,E,F20C | 85/10~94/11 | Crank Shaft FRONT |
| 03908 8515 | 9828-96101 | 96 x 124 x 14 x 21 | TRUCK ENGINE V22D | 90/10~95/ | Crank Shaft FRONT |
| 03908 4347 | 9828-96109 | 96 x 131 x 17.5 | TRUCK ENGINE F17D,E,V,F20C,F21C | 94/12~ | Crank Shaft FRONT |
| 03908 5619 | 9828-75140 | 75 x 100 x 13 x 20 | TRUCK ENGINE K13C | 83/10~94/12 | Crank Shaft FRONT |
| 03908 7539 | 9828-75140 | 75 x 100 x 13 x 20 | TRUCK ENGINE P09C | 89/10~92/ | Crank Shaft FRONT |
| 03908 2931 | 9828-75140 | 75 x 100 x 13 x 20 | TRUCK ENGINE P11C | 92/4~00/2 | Crank Shaft FRONT |
| 03908 7763 | 9828-65116 | 65 x 88 x 12 x 19 | TRUCK ENGINE H06C,H07C,D | 83/7~94/ | Crank Shaft FRONT |
| 03908 7131 | 9828-79103 | 79 x 114 x 17 | TRUCK ENGINE J08C | 94/9~ | Crank Shaft FRONT |
| 03908 5715 | 9828-75145 | 75 x 114 x 17 | TRUCK ENGINE K13C,D | 95/1~98/1 | Crank Shaft FRONT |
| 03908 2539 | 9828-75145 | 75 x 114 x 17 | TRUCK ENGINE K13D | 98/2~ | Crank Shaft FRONT |
| 03908 8139 | 9828-75140 | 75 x 100 x 13 x 20 | TRUCK ENGINE EP100,EM100 | 82/7~90/ | Crank Shaft FRONT |

# 5. Seals product list

## 5.8 HINO

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03908 4539 | 9828-70102 | 70 x 95 x 13 | TRUCK ENGINE EK100 FR27#,FP27#,FS27#,FN27#,GN27# | 81/5~83/ | Crank Shaft FRONT |
| 03908 6139 | 13719-1080 | | TRUCK ENGINE K13D | 89/11~00/ | Valve Stem Seal |
| 03908 1947 | 13719-1540 | | TRUCK ENGINE P11C | 00/3~ | Valve Stem Seal |
| 03908 3067 | 13719-1500 | | TRUCK ENGINE F21C | 02/3~ | Valve Stem Seal |
| 03908 5379 | 13719-1030 | | TRUCK ENGINE EM100, EP100 | 83/12~90/ | Valve Stem Seal |
| 03908 1547 | 13719-1030 | | TRUCK ENGINE F20C, 21C | 89/11~00/2 | Valve Stem Seal |
| 03908 6651 | 13719-1080 | | TRUCK ENGINE K13C | 86/1~92/3 | Valve Stem Seal |
| 03908 2899 | 13719-1370 | | TRUCK ENGINE P09C, 11C | 89/10~00/2 | Valve Stem Seal |
| 03908 3139 | 13719-1470 | | TRUCK ENGINE J08C | 98/1~ | Valve Stem Seal |
| 03908 5659 | 13719-1360 | | TRUCK ENGINE J08C | 94/9~97/12 | Valve Stem Seal |
| 03908 4579 | 13719-1020 | | TRUCK ENGINE K13C | 92/4~ | Valve Stem Seal |
| 03908 4235 | 13719-1020 | | TRUCK ENGINE H06C, H07C, D | 83/7~94/10 | Valve Stem Seal |
| 03908 5203 | 13719-1080 | | TRUCK ENGINE V22D | 90/10~95/ | Valve Stem Seal |
| 03908 1763 | 13719-1080 | | TRUCK ENGINE F17C, D, E, V | 85/10~ | Valve Stem Seal |
| 03908 6131 | 13719-1080 | | TRUCK ENGINE EK100, EF550, 750 | 83/8~90/ | Valve Stem Seal |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1572 | 27371-80F00 | 35 x 64 x 10 x 14.5 | AERIO RA21S,RB21S,RC51S,RD51S-4WD | 01.1~ | Final Drive PINION |
| 03909 1872 | 09283-41001 | 41 x 53 x 6 | AERIO M15A,M18S | 01.1~ | Engine CRANK SHAFT FRONT |
| 03909 3042 | 27611-55G10 | 37.5 x 58 x 9 | AERIO RA21S,RB21S-M15A | 01.10~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 1907 | 27612-79C10 | 37.5 x 63 x 9 | AERIO RA21S,RB21S-M15A | 01.10~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2822 | 27441-60G10 | 34.5 x 58 x 9.5 x 13.5 | AERIO RB21S | 01.1~01.10 | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2737 | 27431-60G10 | 35 x 54 x 9.5 x 13.5 | AERIO RC51S,RD51S-M18A | 02.6~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2217 | 27431-60G10 | 35 x 54 x 9.5 x 13.5 | AERIO RB21S | 01.1~01.10 | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 3127 | 27432-70C00 | 38 x 54 x 8 | AERIO RA21S,RB21S,RC51S,RD51S-2WD,4WD | 01.1~ | Transmission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03909 2777 | 09283-25088 | 25 x 38 x 6 | AERIO RA21S,RB21S,RC51S,RD51S | 01.1~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2087 | 43431-60B20 | 49 x 62 x 8 x 11 | AERIO RA21S,RB21S,RC51S,RD51S-4WD | 01.1~ | Wheel Hub REAR (OUTER & INNER) |
| 03909 2417 | 27441-60G10 | 34.5 x 58 x 9.5 x 13.5 | AERIO RC51S,RD51S-M18A | 02.6~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2957 | 09283-83001 | 83 x 103 x 8 | AERIO M15A,M18S | 01.1~ | Engine CRANK SHAFT REAR |
| 03909 2167 | 27611-82301 | 35 x 55 x 8 | ALTO CL#,CN#,CR3-TURBO | 88.9~94. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |
| 03909 2212 | 09283-28022 | 28 x 47 x 7 | ALTO HA#,HB#,HC#,HD# (4WD) | 94.11~ | Final Drive PINION |
| 03909 1737 | 09283-28022 | 28 x 47 x 7 | ALTO CL#,CM#,CP#,CS# (4WD) | 88.9~94. | Final Drive PINION |
| 03909 2587 | 27611-71B70 | 30 x 52 x 8 | ALTO HA12S,V,22S-CVT | 98.4~00. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2267 | 27431-73H30 | 34.5 x 52 x 8 | ALTO H23S,V | 02.??? | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 1477 | 27431-73B20 | 35 x 52 x 8 | ALTO HA12V,12S,22S,23V,23S-2WD,4WD | 98.10~02.4 | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2962 | 27432-73H10 | 40 x 54 x 7 | ALTO HA12V,12S,22S,23V,23S-4WD | 98.8~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2312 | 27431-73H10 | 34.5 x 54 x 8.5 x 10 | ALTO HA12V,12S,22S,23V,23S-2WD | 98.8~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2512 | 27431-73B20 | 35 x 52 x 8 | ALTO HB#,HD#(4WD) | 94.11~98. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |
| 03909 1352 | 27611-71B70 | 30 x 52 x 8 | ALTO CL#,CN#,CR#...WITHOUT TURBO | 88.9~94. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |
| 03909 2707 | 27611-82301 | 35 x 55 x 8 | ALTO HA#,HC#...TURBO | 94.11~98. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |
| 03909 2632 | 27611-71B70 | 30 x 52 x 8 | ALTO HA#,HC#...WITHOUT TURBO | 94.11~98. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |
| 03909 3072 | 09283-32038 | 32 x 47 x 6 | ALTO F5A,B-CA#,CC#,CL#,CN#,CM#,CP# | 81.10~90. | Engine CAM SHAFT |
| 03909 2637 | 27431-73B20 | 35 x 52 x 8 | ALTO CM#,CP#,CS# (4WD) | 88.9~94. | Transmission & Differential (A/T) DIFF. SIDE (LH,RH) |
| 03909 3047 | 09283-60005 | 60 x 80 x 8 | ALTO K6A-HA21S,HB21S | 94.11~97. | Engine CRANK SHAFT REAR |
| 03909 2062 | 09283-40029 | 40 x 62 x 8 | ALTO HA12V,12S,22S,23V,23S-2WD:TURBO,4WD | 98.10~ | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2377 | 09283-20024 | 20 x 35 x 7 | ALTO CA71V,72V | 84.9~88. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2307 | 09283-79001 | 79 x 99 x 8 | ALTO K6A-HA21S,HB21S | 97.4~98. | Engine CRANK SHAFT REAR |
| 03909 1432 | 09283-32038 | 32 x 47 x 6 | ALTO F6A(2VALVE)-CL#,CN#,CM#,CP# | 90.3~94. | Engine CAM SHAFT |
| 03909 1582 | 09283-60005 | 60 x 80 x 8 | ALTO F5A,F6A | 81.10~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2067 | 09283-35040 | 35 x 47 x 6 | ALTO K6A-HA21S,22S,23S,V,HB21S | 94.11~ | Engine CRANK SHAFT FRONT |
| 03909 2007 | 09283-32038 | 32 x 47 x 6 | ALTO F5A,B,F6A-ALL | 81.10~ | Engine CRANK SHAFT FRONT |
| 03909 1342 | 09283-35040 | 35 x 47 x 6 | ALTO F6A(4 VALVE )-HA11S,12S,HB11S | 94.11~00. | Engine CAM SHAFT |
| 03909 1922 | 09283-35040 | 35 x 47 x 6 | ALTO F6A(4 VALVE )-CL#,CN#,CM#,CP# | 90.3~94. | Engine CAM SHAFT |
| 03909 2037 | 09283-32038 | 32 x 47 x 6 | ALTO F6A(2VALVE)-HA1#,HB11S,HC11V,HD11V | 94.11~00. | Engine CAM SHAFT |
| 03909 1397 | 09283-79001 | 79 x 99 x 8 | ALTO K6A-HA22S,23S,V | 98.8~ | Engine CRANK SHAFT REAR |
| 03909 2727 | 09283-44011 | 44 x 62 x 8 x 13.5 | ALTO HA11S,21S,HB11S,21S,HC11V ,HD11V | 94.11~98. | Wheel Hub FRONT |
| 03909 1707 | 24151-73B01 | 20 x 35 x 5.5 | ALTO CC#,CL#,CM#,CN#,CP#,CR#, CS# | 88.9~94. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2772 | 09283-20024 | 20 x 35 x 7 | ALTO SS30V,40V | 79.5~84. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 3237 | 43491-82H00 | 42 x 55 x 7 x 9 | ALTO HA23S,V | 01.??? | Wheel Hub REAR |
| 03909 2767 | 43491-70D01 | 42 x 55 x 7 | ALTO HA12S,V,22S,23S,V-4WD | 98.8~01.6 | Wheel Hub REAR |
| 03909 1487 | 09283-44009 | 44 x 62 x 8 x 14 | ALTO SS30V,40V | 79.5~84. | Wheel Hub FRONT |
| 03909 1357 | 24151-73B01 | 20 x 35 x 5.5 | ALTO HA12S,V,22S-2WD-4MT,5MT:EPI | 98.8~00. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2697 | 09283-42008 | 42 x 55 x 7 | ALTO CC71V,72V (4WD) | 84.11~88. | Wheel Hub REAR |
| 03909 1802 | 43491-70D01 | 42 x 55 x 7 | ALTO HB11S,21S,HD11V (4WD) | 94.11~98. | Wheel Hub REAR |
| 03909 2742 | 09283-44011 | 44 x 62 x 8 x 13.5 | ALTO CL22V,CM22V,CR22S,CS22S | 91.9~94. | Wheel Hub FRONT |
| 03909 3147 | 09283-44011 | 44 x 62 x 8 x 13.5 | ALTO CL21V,CM21V,CN21S,CP21S | 90.3~91. | Wheel Hub FRONT |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1462 | 09283-44011 | 44 x 62 x 8 x 13.5 | ALTO CL11V,CM11V,CN11S,CP11S | 88.9~90. | Wheel Hub FRONT |
| 03909 2147 | 09283-44011 | 44 x 62 x 8 x 13.5 | ALTO CA71V,72V,CC71V,72V | 84.9~88. | Wheel Hub FRONT |
| 03909 1532 | 09283-35037 | 35 x 62 x 9.5 | ALTO HA#,HC#...TURBO | 94.11~98. | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2552 | 24151-73B01 | 20 x 35 x 5.5 | ALTO HA11S,21S,HB11S,21S,HC11V ,HD11V | 94.11~98. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2802 | 43491-70D01 | 42 x 55 x 7 | ALTO CM22V,CS2S (4WD) | 91.9~94. | Wheel Hub REAR |
| 03909 2722 | 27431-73B20 | 35 x 52 x 8 | ALTO HA#,HC#...TURBO | 94.11~98. | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 2907 | 09283-35037 | 35 x 62 x 9.5 | ALTO CL#,CN#,CR#...TURBO | 88.9~94. | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 1552 | 09283-42008 | 42 x 55 x 7 | ALTO CM11V,21V,CP11S,21S (4WD) | 88.9~91. | Wheel Hub REAR |
| 03909 2422 | 09283-40028 | 40 x 58 x 10 | ALTO HA12V,12S,22S,23V,23S-2WD:TURBO,4WD | 98.8~ | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 1852 | 24151-73B01 | 20 x 35 x 5.5 | ALTO HA22S,23S,V-2WD | 00.11~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 1502 | 27431-73B20 | 35 x 52 x 8 | ALTO CL#,CN#,CR#...TURBO | 88.9~94. | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 2567 | 27431-73B20 | 35 x 52 x 8 | ALTO HB#,HD# (4WD0 | 94.11~98. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 2982 | 27431-73B20 | 35 x 52 x 8 | ALTO CM#,CP#,CS# (4WD) | 88.9~94. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 2542 | 27611-71B70 | 30 x 52 x 8 | ALTO HA12S,12V,22S,23S,V-2WD:W/O TURBO | 98.8~ | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 2997 | 27611-71B70 | 30 x 52 x 8 | ALTO HA#,HC#...2WD:W/O TURBO | 94.11~98. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1652 | 27611-71B70 | 30 x 52 x 8 | ALTO CL#,CN#,CR#...WITHOUT TURBO | 88.9~94. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 3217 | 27431-50A30 | 30 x 54 x 10 | ALTO CA71V,72V | 84.9~88. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 2797 | 27431-50A30 | 30 x 54 x 10 | ALTO SS40V | 81.10~84. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 1702 | 09283-35036 | 35 x 72 x 9.5 | ALTO SS30V | 79.5~82. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 2447 | 24151-60BD1 | 22 x 36 x 5.5 | ALTO HA22S,23S,V-4WD | 00.11~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2352 | 24151-60BD1 | 22 x 36 x 5.5 | ALTO HA12S,V,22S-2WD:TURBO,4WD | 98.8~00. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2327 | 27371-53F00 | 35 x 55 x 11 | CARRY / EVERY DD51T,DF51V (4WD0 | 97.4~98. | Differential SIDE FRONT |
| 03909 1367 | 09289-36002 | 36 x 72 x 7 x 9 | CARRY / EVERY LJ55-ST3#,DA81 | 79.4~89. | Engine CRANK SHAFT FRONT |
| 03909 1482 | 09283-35040 | 35 x 47 x 6 | CARRY / EVERY F6A(4VALVE)-DA,DB,DC,DD,DE,DF | 90.3~01. | Engine CAM SHAFT |
| 03909 2022 | 09283-32038 | 32 x 47 x 6 | CARRY / EVERY F6A(TURBO,2VALVE)-DA,DB,DE,DF | 90.3~01. | Engine CAM SHAFT |
| 03909 2332 | 09283-32038 | 32 x 47 x 6 | CARRY / EVERY F5A,F5B-ST40,41,DA41,71,DB41,71 | 80.10~90. | Engine CAM SHAFT |
| 03909 3122 | 27431-73B20 | 35 x 52 x 8 | CARRY / EVERY DF | 91.9~98. | Differential SIDE REAR |
| 03909 3007 | 27431-73B20 | 35 x 52 x 8 | CARRY / EVERY DE-AT-(RH & LH) | 91.9~98. | Differential SIDE REAR |
| 03909 2812 | 27431-73B20 | 35 x 52 x 8 | CARRY / EVERY DE-MT-RH & LH | 97.4~98. | Differential SIDE REAR |
| 03909 2882 | 27431-73B20 | 35 x 52 x 8 | CARRY / EVERY DE-MT-LEFT SIDE | 91.9~97. | Differential SIDE REAR |
| 03909 2617 | 09283-35037 | 35 x 62 x 9.5 | CARRY / EVERY DE-MT-RIGHT SIDE | 91.9~97. | Differential SIDE REAR |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2157 | 27371-53F00 | 35 x 55 x 11 | CARRY / EVERY DF51V(C/#500001~700000) | 91.9~93.10 | Differential PINION FRONT |
| 03909 2102 | 27371-53F00 | 35 x 55 x 11 | CARRY / EVERY DB52# (4WD) | 98.12~01. | Differential SIDE FRONT |
| 03909 3152 | 09283-32038 | 32 x 47 x 6 | CARRY / EVERY F5A,F5B-ST4#,DA41,71,DB41,71 | 80.10~90. | Engine CRANK SHAFT FRONT |
| 03909 3062 | 27283-79A00 | 27.5 x 2 x 11 | CARRY / EVERY DA#,DB# | 98.12~ | Differential PINION FRONT |
| 03909 1732 | 09283-28022 | 28 x 47 x 7 | CARRY / EVERY DA#,DB#,DC#,DD#,DE# | 85.3~98.11 | Differential PINION FRONT |
| 03909 2492 | 09283-28022 | 28 x 47 x 7 | CARRY / EVERY DF51V (C/#700001~) | 93.10~98. | Differential PINION FRONT |
| 03909 2532 | 27371-53F00 | 35 x 55 x 11 | CARRY / EVERY DA62#,63T-4WD | 01.9~ | Differential SIDE FRONT |
| 03909 2987 | 12311-67011 | 44 x 72 x 7 | CARRY / EVERY LJ55-ST3#,DA81 | 79.4~89. | Engine MIDDLE CRANK SEAL |
| 03909 2227 | 09283-35008 | 35 x 62 x 10 x 16 | CARRY / EVERY DA62V,W-PJ:AT,PX,PS,PZ | 02.11~ | Differential PINION REAR |
| 03909 1837 | 09283-44009 | 44 x 62 x 8 x 14 | CARRY / EVERY ST31 (4WD) | 81.9~82.10 | Wheel Hub FRONT |
| 03909 1767 | 09283-32038 | 32 x 47 x 6 | CARRY / EVERY F6A-DA51#,52#,DB51#,52# | 90.3~01. | Engine CRANK SHAFT FRONT |
| 03909 2702 | 09283-79001 | 79 x 99 x 8 | CARRY / EVERY K6A-DA62#,63T | 01.9~ | Engine CRANK SHAFT REAR |
| 03909 3017 | 09283-60005 | 60 x 80 x 8 | CARRY / EVERY F6A-DC51T,DD51T,DE51V,DF51V | 91.9~98. | Engine CRANK SHAFT REAR |
| 03909 2437 | 09283-60005 | 60 x 80 x 8 | CARRY / EVERY F6A-DA51#,52#,DB51#,52# | 90.3~01. | Engine CRANK SHAFT REAR |
| 03909 3027 | 09283-60005 | 60 x 80 x 8 | CARRY / EVERY F5A,F5B-ST4#,DA41,71,DB41,71 | 80.10~90. | Engine CRANK SHAFT REAR |
| 03909 1497 | 09283-35006 | 35 x 80 x 9 | CARRY / EVERY LJ55-ST3#,DA81 | 79.4~89. | Engine CRANK SHAFT REAR |
| 03909 1492 | 09283-35040 | 35 x 47 x 6 | CARRY / EVERY K6A-DA62#,63T | 01.9~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2897 | 09283-32038 | 32 x 47 x 6 | CARRY / EVERY F6A-DC51T,DD51T,DE51V,DF51V | 91.9~98. | Engine CRANK SHAFT FRONT |
| 03909 3087 | 09283-42008 | 42 x 55 x 7 | CARRY / EVERY DA41T,51T,71T,DB41T,51T,71T | 85.3~91. | Wheel Hub REAR |
| 03909 2902 | 09283-20028 | 20 x 47 x 8.5 | CARRY / EVERY ST3#,4# | 79.4~85. | TransTransmission (M/T) INPUT SHAFT |
| 03909 2922 | 09282-48006 | 48 x 62 x 9 | CARRY / EVERY DA63T | 02.5~ | Wheel Hub REAR |
| 03909 2442 | 09282-48006 | 48 x 62 x 9 | CARRY / EVERY DA62V,W | 01.8~ | Wheel Hub REAR |
| 03909 2842 | 09282-48006 | 48 x 62 x 9 | CARRY / EVERY DA52V,W,DB52V | 99.11~01. | Wheel Hub REAR |
| 03909 1892 | 09283-48007 | 48 x 62 x 9 | CARRY / EVERY DA52V,W,DB52V | 98.12~99.11 | Wheel Hub REAR |
| 03909 2002 | 43491-70D01 | 42 x 55 x 7 | CARRY / EVERY DA62T | 01.8~02. | Wheel Hub REAR |
| 03909 2732 | 09283-20028 | 20 x 47 x 8.5 | CARRY / EVERY DA#,DB# | 85.3~90.2 | TransTransmission (M/T) INPUT SHAFT |
| 03909 3092 | 43491-70D01 | 42 x 55 x 7 | CARRY / EVERY DC51T,DD51T | 91.9~98. | Wheel Hub REAR |
| 03909 2597 | 43491-50F00 | 50 x 68 x 7 x 10 | CARRY / EVERY DE51V,DF51V | 91.9~98. | Wheel Hub REAR |
| 03909 3157 | 09283-42008 | 42 x 55 x 7 | CARRY / EVERY ST3#,4# | 79.4~85. | Wheel Hub REAR |
| 03909 2607 | 09283-50005 | 50 x 65 x 7 x 10 | CARRY / EVERY DB41T,51T,71T,DD51T,DF51V (4WD) | 85.3~98. | Wheel Hub FRONT OUTER |
| 03909 3142 | 43491-50F00 | 50 x 68 x 7 x 10 | CARRY / EVERY DD51T,DF51V 94WD) | 91.9~98. | Wheel Hub FRONT INNER |
| 03909 3102 | 09283-40014 | 40 x 62 x 8 x 14 | CARRY / EVERY DB41T,51T,71T(4WD) | 85.3~91. | Wheel Hub FRONT INNER |
| 03909 1627 | 09283-40012 | 40 x 72 x 9 x 15 | CARRY / EVERY ST31 (4WD) | 82.11~85. | Wheel Hub FRONT |
| 03909 1647 | 09283-40012 | 40 x 72 x 9 x 15 | CARRY / EVERY ST41 (4WD) | 82.12~85. | Wheel Hub FRONT |
| 03909 3177 | 09283-35008 | 35 x 62 x 10 x 16 | CARRY / EVERY DA62#...TURBO,4V:PJ | 01.8~02.10 | Differential PINION REAR |
| 03909 2712 | 19283-28022 | 28 x 47 x 7 | CARRY / EVERY DA63T | 02.??? | Differential PINION REAR |
| 03909 1507 | 09283-35008 | 35 x 62 x 10 x 16 | CARRY / EVERY DA52#,DB#...TURBO | 98.12~01. | Differential PINION REAR |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 3037 | 43491-70D01 | 42 x 55 x 7 | CARRY / EVERY DA52T,DB52T | 98.12~01. | Wheel Hub REAR |
| 03909 3187 | 09283-35008 | 35 x 62 x 10 x 16 | CARRY / EVERY DA,DB-(MT.TURBO) | 90.3~91. | Differential PINION REAR |
| 03909 2017 | 24151-70D00 | 20 x 49 x 7.8 | CARRY / EVERY DA#,DB# | 90.3~91. | TransTransmission (M/T) INPUT SHAFT |
| 03909 3202 | 19283-28022 | 28 x 47 x 7 | CARRY / EVERY DA62V,W-PJ:MT,GA,PA,PC,PG | 02.11~ | Differential PINION REAR |
| 03909 2372 | 19283-28022 | 28 x 47 x 7 | CARRY / EVERY DA62#...4V (EXC. PJ) | 01.8~02.10 | Differential PINION REAR |
| 03909 1762 | 19283-28022 | 28 x 47 x 7 | CARRY / EVERY DA52#,DB52#...4V | 98.12~01. | Differential PINION REAR |
| 03909 2602 | 19283-28022 | 28 x 47 x 7 | CARRY / EVERY DC51T,DD51T | 91.9~98. | Differential PINION REAR |
| 03909 1437 | 09283-28010 | 28 x 47 x 10 | CARRY / EVERY DA,DB-(EXCEPT MT.TURBO) | 89.5~91. | Differential PINION REAR |
| 03909 2717 | 09283-28010 | 28 x 47 x 10 | CARRY / EVERY ST3#,4# | 79.4~85. | Differential PINION REAR |
| 03909 1632 | 24780-78A20 | 28.5 x 38 x 10 x 13 | CARRY / EVERY DA52#,62#,63T-2WD | 98.12~ | TransTransmission (M/T) EXTENSION CASE |
| 03909 1697 | 24780-79001 | 28 x 38 x 10 x 15 | CARRY / EVERY DA,DC (2WD) | 85.3~98. | TransTransmission (M/T) EXTENSION CASE |
| 03909 2877 | 24780-79001 | 28 x 38 x 10 x 15 | CARRY / EVERY ST30,40 (2WD) | 79.4~85. | TransTransmission (M/T) EXTENSION CASE |
| 03909 3137 | 24151-78A20 | 25 x 52 x 10 | CARRY / EVERY DA52#,62#,63T,DB52# | 98.12~ | TransTransmission (M/T) INPUT SHAFT |
| 03909 1902 | 24151-73B01 | 20 x 35 x 5.5 | CARRY / EVERY DE#,DF# | 91.9~98. | TransTransmission (M/T) INPUT SHAFT |
| 03909 1937 | 24151-70D00 | 20 x 49 x 7.8 | CARRY / EVERY DC#,DD# | 91.9~98. | TransTransmission (M/T) INPUT SHAFT |
| 03909 2592 | 09283-28010 | 28 x 47 x 10 | CARRY / EVERY DA,DB | 85.3~89.4 | Differential PINION REAR |
| 03909 2477 | 27611-82301 | 35 x 55 x 8 | CERVO CN21S,22S-TURBO | 90.7~95. | Transmission & Differential (A/T) DIFF.SIDE (LH,RH) |
| 03909 2402 | 27431-73B20 | 35 x 52 x 8 | CERVO CP21S,22S | 90.7~98. | Transmission & Differential (A/T) DIFF.SIDE (LH,RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1667 | 09283-28022 | 28 x 47 x 7 | CERVO CN#,CP# | 90.7~98. | Final Drive PINION |
| 03909 2487 | 09283-32038 | 32 x 47 x 6 | CERVO T5A-SS20C,40C | 77.10~88. | Engine CAM SHAFT |
| 03909 2952 | 09283-32038 | 32 x 47 x 6 | CERVO F5B-CG72V,CH72V | 88.1~90. | Engine CAM SHAFT |
| 03909 2207 | 09283-32038 | 32 x 47 x 6 | CERVO F6A(2 VALVE)-CN2#,CP2# | 90.7~98. | Engine CAM SHAFT |
| 03909 1847 | 09283-35040 | 35 x 47 x 6 | CERVO F6A(4 VALVE)-CN2#,CP2# | 90.7~98. | Engine CAM SHAFT |
| 03909 3257 | 09283-35040 | 35 x 47 x 6 | CERVO F6B(DOHC)-CN3#,CP3# | 90.7~97. | Engine CAM SHAFT |
| 03909 3232 | 09283-60005 | 60 x 80 x 8 | CERVO T5A,F5B,F6A,B | 77.10~98. | Engine CRANK SHAFT REAR |
| 03909 2407 | 27611-55A10 | 30 x 50 x 7.5 | CERVO CG72V | 88.1~90. | Transmission & Differential (A/T) DIFF.SIDE (LH,RH) |
| 03909 2857 | 09283-32038 | 32 x 47 x 6 | CERVO T5A,F5B,F6A,B | 77.10~98. | Engine CRANK SHAFT FRONT |
| 03909 2762 | 24151-73B01 | 20 x 35 x 5.5 | CERVO CH72V,CN#,CP# | 88.1~98. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2322 | 27431-50A30 | 30 x 54 x 10 | CERVO SS40C | 82.5~88. | Transmission & Differential (A/T) DIFF.SIDE (LH,RH) |
| 03909 2127 | 27611-71B70 | 30 x 52 x 8 | CERVO CN21S,22S-W/O TURBO | 90.7~98. | Transmission & Differential (A/T) DIFF.SIDE (LH,RH) |
| 03909 1727 | 09283-44009 | 44 x 62 x 8 x 14 | CERVO SS20C,40C | 77.10~88. | Wheel Hub FRONT |
| 03909 3247 | 09283-44011 | 44 x 62 x 8 x 13.5 | CERVO CG72V,CH72V | 88.1~90. | Wheel Hub FRONT |
| 03909 2627 | 09283-44011 | 44 x 62 x 8 x 13.5 | CERVO CN#,CP# | 90.7~98. | Wheel Hub FRONT |
| 03909 2642 | 09283-42008 | 42 x 55 x 7 | CERVO CH72V,CP21S,31S(4WD) | 88.1~91. | Wheel Hub REAR |
| 03909 1597 | 09283-20024 | 20 x 35 x 7 | CERVO SS20C,40C,CG72V | 77.10~90. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 1882 | 27431-50A30 | 30 x 54 x 10 | CERVO SS20C,40C,CG72V | 77.10~90. | Transmission & Differential (M/T) DIFF.SIDE (LH,RH) |
| 03909 1857 | 0923-35037 | 35 x 62 x 9.5 | CERVO CH72V | 88.1~90. | Transmission & Differential (M/T) DIFF.SIDE (LH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2452 | 0923-35037 | 35 x 62 x 9.5 | CERVO CN21S,22S-TURBO,CN31S,32S | 90.7~97. | Transmission & Differential (M/T) DIFF.SIDE (LH) |
| 03909 2917 | 09283-35036 | 35 x 72 x 9.5 | CERVO CH72V | 88.1~90. | Transmission & Differential (M/T) DIFF.SIDE (RH) |
| 03909 3262 | 27431-73B20 | 35 x 52 x 8 | CERVO CN21S,22S-TURBO,CN31S,32S | 90.7~97. | Transmission & Differential (M/T) DIFF.SIDE (RH) |
| 03909 2782 | 27431-73B20 | 35 x 52 x 8 | CERVO CP21S,22S,31S,32S | 90.7~98. | Transmission & Differential (M/T) DIFF.SIDE (LH,RH) |
| 03909 1557 | 27611-71B70 | 30 x 52 x 8 | CERVO CN21S,22S-W/O TURBO | 90.7~98. | Transmission & Differential (M/T) DIFF.SIDE (LH,RH) |
| 03909 1777 | 43491-70D01 | 42 x 55 x 7 | CERVO CP22S,CP32S (4WD) | 91.9~98. | Wheel Hub REAR |
| 03909 2347 | 27611-79C10 | 39.5 x 54 x 9 | CHEVROLET CRUIZE HR51S,HR81S | 01.10~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2482 | 09283-83001 | 83 x 103 x 8 | CHEVROLET CRUIZE HR51S,HR81S-M13A,M15A | 01.10~ | Engine CRANK SHAFT REAR |
| 03909 2682 | 43491-82H00 | 42 x 55 x 7 x 9 | CHEVROLET CRUIZE HR51S,HR81S-4WD | 01.10~ | Wheel Hub REAR |
| 03909 3112 | 09283-38023 | 38 x 55 x 9.5 | CHEVROLET CRUIZE HR51S,HR81S | 01.10~ | Final Drive PINION |
| 03909 1997 | 27612-79C10 | 37.5 x 63 x 9 | CHEVROLET CRUIZE HR51S,HR81S | 01.10~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 1442 | 09283-41001 | 41 x 53 x 6 | CHEVROLET CRUIZE HR51S,HR81S-M13A,M15A | 01.10~ | Engine CRANK SHAFT FRONT |
| 03909 1457 | 09283-32038 | 32 x 47 x 6 | CULTUS G15-AH64,AJ64,GA21,GB21,GC21, GD21 | 91.7~ | Engine CAM SHAFT |
| 03909 2887 | 09283-32038 | 32 x 47 x 6 | CULTUS G13-AA3#,53,AB3#,51,55,AF34,GA 11 | 86.6~ | Engine CAM SHAFT |
| 03909 1407 | 09283-32038 | 32 x 47 x 6 | CULTUS G10-AA4#,AB4# | 83.9~00. | Engine CAM SHAFT |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1372 | 27371-80F00 | 35 x 64 x 10 x 14.5 | CULTUS GB21,31,GD21,31-4WD | 95.1~ | Final Drive PINION |
| 03909 2572 | 27441-60G10 | 34.5 x 58 x 9.5 x 13.5 | CULTUS GA11,21,GB31,GC21,41,GD31 | 95.1~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2197 | 27431-60G10 | 35 x 54 x 9.5 x 13.5 | CULTUS GA11,21,GB31,GC21,41,GD31 | 95.1~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 1512 | 27611-82301 | 35 x 55 x 8 | CULTUS AA#,AB# | 83.9~00. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03909 2357 | 09283-32038 | 32 x 47 x 6 | CULTUS G16-AH14,AJ14,GB31,GD31 | 89.6~ | Engine CAM SHAFT |
| 03909 2747 | 27432-70C00 | 38 x 54 x 8 | CULTUS GB21,31,GC41,GD21,31 | 95.1~ | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 1982 | 27432-70C00 | 38 x 54 x 8 | CULTUS AF34,AH#,AJ# | 89.6~94. | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 1932 | 27431-73B20 | 35 x 52 x 8 | CULTUS GA11,21,GC21 | 95.1~ | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 1757 | 27611-72C00 | 35 x 56 x 9 | CULTUS AH14,64 | 89.6~94. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03909 1782 | 09283-32038 | 32 x 47 x 6 | CULTUS G10,G13,15,G16 | 83.9~ | Engine CRANK SHAFT FRONT |
| 03909 3222 | 09283-45011 | 45 x 63 x 7.5 | CULTUS J18A-GC41 | 96.2~ | Engine CRANK SHAFT FRONT |
| 03909 3002 | 09283-68001 | 68 x 86 x 8 | CULTUS G10,G13,G15,G16 | 83.9~ | Engine CRANK SHAFT REAR |
| 03909 1687 | 09283-98001 | 98 x 116 x 10 | CULTUS J18A-GC41 | 96.2~ | Engine CRANK SHAFT REAR |
| 03909 2257 | 43431-60B20 | 49 x 62 x 8 x 11 | CULTUS AA34,AB34,AF34-1300CC | 88.9~93.10 | Wheel Hub FRONT INNER |
| 03909 2832 | 27431-73B20 | 35 x 52 x 8 | CULTUS AA34,44,AB34,44 | 88.9~00. | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 2162 | 43431-60B20 | 49 x 62 x 8 x 11 | CULTUS AH64,AJ64-1500CC | 91.7~93.10 | Wheel Hub FRONT INNER |
| 03909 1517 | 43431-60B20 | 49 x 62 x 8 x 11 | CULTUS AH14,AJ14-1600CC | 89.6~93.10 | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1677 | 09283-35037 | 35 x 62 x 9.5 | CULTUS AA33,41,43,53,AB33,41,43,51,53 | 83.9~88. | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 2522 | 09283-44009 | 44 x 62 x 8 x 14 | CULTUS AA41,43,AB41,43-1000CC | 83.9~88. | Wheel Hub FRONT INNER |
| 03909 2077 | 43431-60B20 | 49 x 62 x 8 x 11 | CULTUS AA44,AB44-1000CC | 88.9~93.10 | Wheel Hub FRONT INNER |
| 03909 2467 | 43430-60810 | 48 x 62 x 16.5 | CULTUS AA34,44,AB34,44,AF34 | 93.11~00. | Wheel Hub FRONT INNER |
| 03909 3057 | 43430-60810 | 48 x 62 x 16.5 | CULTUS AH14,64,AJ14,64 | 93.11~94. | Wheel Hub FRONT INNER |
| 03909 2517 | 43431-60G00 | 49 x 65 x 8 x 36.5 | CULTUS GA11,21,GB21,31,GC21,41,GD21,31 | 95.1~ | Wheel Hub FRONT INNER |
| 03909 2892 | 09283-53001 | 53 x 68.2 x 7 | CULTUS AA43-TURBO | 86.6~88. | Wheel Hub FRONT OUTER |
| 03909 1622 | 09283-53001 | 53 x 68.2 x 7 | CULTUS AA33,53,AB33,51,55 | 84.6~88. | Wheel Hub FRONT OUTER |
| 03909 2927 | 09283-53001 | 53 x 68.2 x 7 | CULTUS AA44,AB34,44 | 88.9~00. | Wheel Hub FRONT OUTER |
| 03909 2182 | 09283-53001 | 53 x 68.2 x 7 | CULTUS AA34,AF34-EXCEPT TWIN CAM | 88.9~00. | Wheel Hub FRONT OUTER |
| 03909 1672 | 09283-53001 | 53 x 68.2 x 7 | CULTUS AH14,64,AJ14,64 | 89.6~94. | Wheel Hub FRONT OUTER |
| 03909 1977 | 09283-35037 | 35 x 62 x 9.5 | CULTUS AA3#,4#,53,AB3#,4#,5# | 83.9~00. | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 1522 | 09283-44009 | 44 x 62 x 8 x 14 | CULTUS AA33,53,AB33,51,55-1300CC | 84.6~88. | Wheel Hub FRONT INNER |
| 03909 3022 | 09283-56002 | 56 x 72.2 x 8 x 10 | CULTUS AA34,AF34-TWIN CAM | 88.9~00. | Wheel Hub FRONT OUTER |
| 03909 2277 | 27432-70C00 | 38 x 54 x 8 | CULTUS GB21,31,GC41,GD21,31 | 95.1~ | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2847 | 27432-70C00 | 38 x 54 x 8 | CULTUS AF34,AH#,AJ# | 89.6~94. | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 1897 | 09283-35037 | 35 x 62 x 9.5 | CULTUS GA11,21,GC21 | 95.1~ | Transmission & Differential (M/T) DIFF. SIDE (LH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2612 | 09283-25088 | 25 x 38 x 6 | CULTUS GB21,31,GD21,31-4WD,GC41 | 95.1~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 1862 | 43431-60B20 | 49 x 62 x 8 x 11 | CULTUS GB21,31,GD21,31-4WD | 95.1~ | Wheel Hub REAR INNER & OUTER |
| 03909 1412 | 09283-56002 | 56 x 72.2 x 8 x 10 | CULTUS GA11,21,GB21,31,GC21,41,GD21,31 | 95.1~ | Wheel Hub FRONT OUTER |
| 03909 1812 | 43431-60B20 | 49 x 62 x 8 x 11 | CULTUS AF34,AJ14,64-4WD | 89.11~93.10 | Wheel Hub REAR INNER & OUTER |
| 03909 2652 | 09283-25088 | 25 x 38 x 6 | CULTUS AF34,AH#,AJ# | 89.6~94. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2647 | 43430-60810 | 48 x 62 x 16.5 | CULTUS AF34,AJ14,64-4WD | 93.11~94. | Wheel Hub REAR INNER & OUTER |
| 03909 1422 | 24151-73B01 | 20 x 35 x 5.5 | CULTUS AA#,AB# | 83.9~00. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2342 | 24151-73B01 | 20 x 35 x 5.5 | CULTUS GA11,21,GC21-2WD | 95.1~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2977 | 09283-45011 | 45 x 63 x 7.5 | ESCUDO / VITARA JLX J20A-TA51W,52W,TD51W,52W | 96.10~00. | Engine CRANK SHAFT FRONT |
| 03909 2472 | 09283-28014 | 28 x 50 x 8 | ESCUDO / VITARA JLX TL52W,TX92W | 98.11~ | TransTransmission (M/T) INPUT SHAFT |
| 03909 1527 | 09282-25006 | 25 x 62 x 13 | ESCUDO / VITARA JLX MT# | 88.5~ | TransTransmission (M/T) REAR |
| 03909 2232 | 09283-40027 | 40 x 72 x 11 x 18.5 | ESCUDO / VITARA JLX ALL | 88.5~ | Differential PINION REAR |
| 03909 1887 | 09283-32038 | 32 x 47 x 6 | ESCUDO / VITARA JLX G16A-TA01#,02W,TD01W,02W | 88.5~01. | Engine CAM SHAFT |
| 03909 2412 | 09283-32038 | 32 x 47 x 6 | ESCUDO / VITARA JLX G16A-TA01#,02W,TD01W,02W | 88.5~01. | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2072 | 09283-45011 | 45 x 63 x 7.5 | ESCUDO / VITARA JLX H20A,H25A,H27A-TA11W,11W,61W,62W,TX92W | 94.11~ | Engine CRANK SHAFT FRONT |
| 03909 2117 | 09283-40027 | 40 x 72 x 11 x 18.5 | ESCUDO / VITARA JLX ALL | 88.5~ | Differential PINION FRONT |
| 03909 3207 | FS05 10 602A | 34 x 48 x 7 | ESCUDO / VITARA JLX RF-TA31W,TD31W,32W | 94.11~00. | Engine CRANK SHAFT FRONT |
| 03909 1587 | 09283-68001 | 68 x 86 x 8 | ESCUDO / VITARA JLX G16A-TA01#,02W,TD01W,02W | 88.5~01. | Engine CRANK SHAFT REAR |
| 03909 2792 | 09283-98002 | 98 x 116 x 10 | ESCUDO / VITARA JLX H20A,H25A,H27A-TA11W,11W,61W,62W,TX92W | 94.11~ | Engine CRANK SHAFT REAR |
| 03909 1637 | 09283-98002 | 98 x 116 x 10 | ESCUDO / VITARA JLX J20A-TA51W,52W,TD51W,52W | 96.10~00. | Engine CRANK SHAFT REAR |
| 03909 2497 | F801 11 399 | 90 x 110 x 9 | ESCUDO / VITARA JLX RF-TA31W,TD31W,32W | 94.11~00. | Engine CRANK SHAFT REAR |
| 03909 2752 | 09283-28014 | 28 x 50 x 8 | ESCUDO / VITARA JLX TD02W,11W,31W,32W,51W,52W,61W,62W | 94.11~ | TransTransmission (M/T) INPUT SHAFT |
| 03909 1787 | 09283-35008 | 35 x 62 x 10 x 16 | ESCUDO / VITARA JLX ALL | 88.5~ | Differential FRONT DIFF. SIDE |
| 03909 3252 | 09283-54001 | 54 x 69 x 7.5 x 9.5 | ESCUDO / VITARA JLX TA02W,52W,62W | 97.11~00.3 | Wheel Hub FRONT OUTER NO.1 |
| 03909 1917 | BP01 10 602A | 30 x 44 x 7 | ESCUDO / VITARA JLX RF-TA31W,TD31W,32W | 94.11~00. | Engine CAM SHAFT |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2282 | 09289-48004 | 48 x 70 x 9 x 17 | ESCUDO / VITARA JLX TA02W,52W,TD62W,TL52W,TX92W | 97.11~ | Wheel Hub FRONT INNER NO.1 |
| 03909 1797 | 09286-64001 | 64 x 82 x 10 | ESCUDO / VITARA JLX TA01#,11W,31W,51W | 88.5~97. | Wheel Hub FRONT INNER NO.2 |
| 03909 2582 | 09286-64001 | 64 x 82 x 10 | ESCUDO / VITARA JLX TD01W,02W,11W,31W,32W,51W,52W,61W | 90.8~00. | Wheel Hub FRONT INNER NO.2 |
| 03909 1957 | 09286-64001 | 64 x 82 x 10 | ESCUDO / VITARA JLX TA02W,52W,TD62W,TL52W,TX92W | 97.11~ | Wheel Hub FRONT INNER NO.2 |
| 03909 2052 | 09283-28014 | 28 x 50 x 8 | ESCUDO / VITARA JLX TA02W,11W,31W,51W,52W | 94.11~ | TransTransmission (M/T) INPUT SHAFT |
| 03909 2527 | 09283-54001 | 54 x 69 x 7.5 x 9.5 | ESCUDO / VITARA JLX TD01W,02W,11W,31W,32W,51W,52W,61W | 90.8~00. | Wheel Hub FRONT OUTER NO.1 |
| 03909 3197 | 09286-75001 | 75 x 89 x 7 | ESCUDO / VITARA JLX TA01#,11W,31W,51W | 88.5~97. | Wheel Hub FRONT OUTER NO.2 |
| 03909 2827 | 09286-75001 | 75 x 89 x 7 | ESCUDO / VITARA JLX TD01W,02W,11W,31W,32W,51W,52W,61W | 90.8~00. | Wheel Hub FRONT OUTER NO.2 |
| 03909 1662 | 09284-45001 | 45 x 59 x 8 | ESCUDO / VITARA JLX TA01#,11W,31W,51W | 88.5~97. | Wheel Hub REAR OUTER |
| 03909 2392 | 09283-25088 | 25 x 38 x 6 | ESCUDO / VITARA JLX TA01#,TD01W | 88.5~97. | TransTransmission (M/T) INPUT SHAFT |
| 03909 1712 | 09283-54001 | 54 x 69 x 7.5 x 9.5 | ESCUDO / VITARA JLX TA01#,11W,31W,51W | 88.5~97. | Wheel Hub FRONT OUTER NO.1 |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2137 | 09284-45001 | 45 x 59 x 8 | ESCUDO / VITARA JLX TD01W,11W,31W,51W,61W | 90.8~97. | Wheel Hub REAR OUTER |
| 03909 1722 | 09286-75001 | 75 x 89 x 7 | ESCUDO / VITARA JLX TA02W,52W,62W | 97.11~00.3 | Wheel Hub FRONT OUTER NO.2 |
| 03909 1842 | 43592-52D00 | 51 x 65 x 9 | ESCUDO / VITARA JLX TX92W | 00.12~ | Wheel Hub REAR INNER |
| 03909 1562 | 09289-48004 | 48 x 70 x 9 x 17 | ESCUDO / VITARA JLX TA01#,11W,31W,51W | 88.5~97. | Wheel Hub FRONT INNER NO.1 |
| 03909 2837 | 43592-65D00 | 51 x 71 x 9 | ESCUDO / VITARA JLX TA02W,52W,TD02W,32W,52W,62W,TL52W | 97.11~ | Wheel Hub REAR INNER |
| 03909 2042 | 09289-48004 | 48 x 70 x 9 x 17 | ESCUDO / VITARA JLX TD01W,02W,11W,31W,32W,51W,52W,61W | 90.8~00. | Wheel Hub FRONT INNER NO.1 |
| 03909 2387 | 09282-48003 | 48 x 62 x 9 | ESCUDO / VITARA JLX TD01W,11W,31W,51W,61W | 90.8~97. | Wheel Hub REAR INNER |
| 03909 1382 | 09282-48003 | 48 x 62 x 9 | ESCUDO / VITARA JLX TA01#,11W,31W,51W | 88.5~97. | Wheel Hub REAR INNER |
| 03909 1427 | 27431-50A30 | 30 x 54 x 10 | FRONTE CB71S,72S | 84.9~88. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 1822 | 09283-60005 | 60 x 80 x 8 | FRONTE F5A,B-SS40F,CB#,CD#,CN#,CP# | 79.5~90. | Engine CRANK SHAFT REAR |
| 03909 2172 | 09283-32038 | 32 x 47 x 6 | FRONTE F5A,B-SS40F,CB#,CD#,CN#,CP# | 79.5~90. | Engine CRANK SHAFT FRONT |
| 03909 2787 | 09283-32038 | 32 x 47 x 6 | FRONTE F5A,B-SS40F,CB#,CD#,CN#,CP# | 79.5~90. | Engine CAM SHAFT |
| 03909 1992 | 09283-28022 | 28 x 47 x 7 | FRONTE CP11S (4WD) | 88.9~90. | Final Drive PINION |
| 03909 1792 | 27611-71B70 | 30 x 52 x 8 | FRONTE CN11S | 88.9~90. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1417 | 09283-35036 | 35 x 72 x 9.5 | FRONTE SS30F,40F | 79.5~81.5 | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 1972 | 24151-73B01 | 20 x 35 x 5.5 | FRONTE CN11S,CD72S,CP11S | 88.9~90. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2692 | 09283-20024 | 20 x 35 x 7 | FRONTE SS30F,40F,CB71S,72S | 79.5~88. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 1447 | 09283-42008 | 42 x 55 x 7 | FRONTE CD72S,CP11S (4WD) | 86.7~90. | Wheel Hub REAR |
| 03909 1987 | 09283-44011 | 44 x 62 x 8 x 13.5 | FRONTE CN11S,CP11S | 88.9~90. | Wheel Hub FRONT |
| 03909 2222 | 09283-44011 | 44 x 62 x 8 x 13.5 | FRONTE CB71S,72S,CD72S | 84.9~88. | Wheel Hub FRONT |
| 03909 2187 | 09283-44009 | 44 x 62 x 8 x 14 | FRONTE SS30F,40F | 79.5~84. | Wheel Hub FRONT |
| 03909 3182 | 27431-73B20 | 35 x 52 x 8 | FRONTE CP11S (4WD) | 88.9~90. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 3077 | 27431-50A30 | 30 x 54 x 10 | FRONTE SS40F | 81.5~84. | Transmission & Differential (M/T) DIFF. SIDE (LH,RH) |
| 03909 2092 | 09283-40027 | 40 x 72 x 11 x 18.5 | JIMNY / SAMURAI JA11,12,22,51,JB23,31,32,33,43 | 84.10~ | Differential PINION REAR |
| 03909 3067 | 09283-35040 | 35 x 47 x 6 | JIMNY / SAMURAI K6A-JA22,JB23 | 95.11~ | Engine CRANK SHAFT FRONT |
| 03909 1912 | 09283-35008 | 35 x 62 x 10 x 16 | JIMNY / SAMURAI SJ30,40,JA71 | 81.5~90. | Differential PINION REAR |
| 03909 1692 | 09283-32038 | 32 x 47 x 6 | JIMNY / SAMURAI F5A,F6A-JA71,11,12 | 86.1~98. | Engine CRANK SHAFT FRONT |
| 03909 1602 | 09283-32038 | 32 x 47 x 6 | JIMNY / SAMURAI F10A-SJ40 | 82.6~86. | Engine CRANK SHAFT FRONT |
| 03909 3082 | 09289-36002 | 36 x 72 x 7 x 9 | JIMNY / SAMURAI LJ50-SJ30 | 81.5~88. | Engine CRANK SHAFT FRONT |
| 03909 2237 | 09283-41001 | 41 x 53 x 6 | JIMNY / SAMURAI M13A-JB43 | 00.4~ | Engine CRANK SHAFT FRONT |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2297 | 09283-32038 | 32 x 47 x 6 | JIMNY / SAMURAI F5A,F6A-JA71,11,12 | 86.1~98. | Engine CAM SHAFT |
| 03909 3097 | 12311-67011 | 44 x 72 x 7 | JIMNY / SAMURAI LJ50-SJ30 | 81.5~88. | Engine MIDDLE CRANK SEAL RETAINER |
| 03909 2112 | 09283-32038 | 32 x 47 x 6 | JIMNY / SAMURAI G13#...JA51,JB31,32,33 | 84.10~00. | Engine CAM SHAFT |
| 03909 3212 | 09283-35006 | 35 x 80 x 9 | JIMNY / SAMURAI LJ50-SJ30 | 81.5~88. | Engine CRANK SHAFT REAR |
| 03909 2507 | 09283-60005 | 60 x 80 x 8 | JIMNY / SAMURAI F5A,F6A,F10A-SJ40,JA71,11,12 | 82.8~98. | Engine CRANK SHAFT REAR |
| 03909 2202 | 09283-68001 | 68 x 86 x 8 | JIMNY / SAMURAI G13#...JA51,JB31,32,33 | 84.10~00. | Engine CRANK SHAFT REAR |
| 03909 1387 | 09283-83001 | 83 x 103 x 8 | JIMNY / SAMURAI M13A-JB43 | 00.4~ | Engine CRANK SHAFT REAR |
| 03909 2152 | 09283-79001 | 79 x 99 x 8 | JIMNY / SAMURAI K6A-JA22,JB23 | 95.11~ | Engine CRANK SHAFT REAR |
| 03909 2817 | 09283-26016 | 26 x 38 x 8 | JIMNY / SAMURAI SJ30,40 | 81.5~88. | Wheel Hub FRONT DRIVE SHAFT |
| 03909 3227 | 09283-32038 | 32 x 47 x 6 | JIMNY / SAMURAI G13#...JA51,JB31,32,33 | 84.10~00. | Engine CRANK SHAFT FRONT |
| 03909 2032 | 09283-40027 | 40 x 72 x 11 x 18.5 | JIMNY / SAMURAI JA51,JB31,43 | 84.10~ | Differential PINION FRONT |
| 03909 2862 | 09283-50002 | 50 x 68 x 7 x 10 | JIMNY / SAMURAI JA11,51,71 | 84.10~90. | Wheel Hub FRONT INNER |
| 03909 3172 | 09283-50002 | 50 x 68 x 7 x 10 | JIMNY / SAMURAI JB31 | 93.5~95. | Wheel Hub FRONT INNER |
| 03909 2367 | 43446-82CB0 | 44 x 54 x 7 | JIMNY / SAMURAI JA12,22 | 95.11~98. | Wheel Hub FRONT INNER |
| 03909 1927 | 43446-82CB0 | 44 x 54 x 7 | JIMNY / SAMURAI JB23,32,33,43 | 95.11~ | Wheel Hub FRONT INNER |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1612 | 09283-54001 | 54 x 69 x 7.5 x 9.5 | JIMNY / SAMURAI JB23,32,33,43 | 95.11~ | Wheel Hub FRONT OUTER |
| 03909 1547 | 09283-50002 | 50 x 68 x 7 x 10 | JIMNY / SAMURAI SJ30,40 | 83.7~88. | Wheel Hub FRONT INNER |
| 03909 2262 | 09283-26016 | 26 x 38 x 8 | JIMNY / SAMURAI JA11,12,22,51,71 | 84.10~98. | Wheel Hub FRONT DRIVE SHAFT |
| 03909 2577 | 09283-26016 | 26 x 38 x 8 | JIMNY / SAMURAI JB23,31,32,33,43 | 93.5~ | Wheel Hub FRONT DRIVE SHAFT |
| 03909 1362 | 24780-79001 | 28 x 38 x 10 x 15 | JIMNY / SAMURAI SJ30,40,JA11,12,71,JB23 | 81.5~ | TransTransmission REAR |
| 03909 2192 | 09283-54001 | 54 x 69 x 7.5 x 9.5 | JIMNY / SAMURAI JA12,22 | 95.11~98. | Wheel Hub FRONT OUTER |
| 03909 2047 | 24780-83010 | 32 x 42 x 10 x 12.5 | JIMNY / SAMURAI JA51,JB31,32,33,43 | 84.10~ | TransTransmission REAR |
| 03909 3032 | 09283-48007 | 48 x 62 x 9 | JIMNY / SAMURAI SJ30,40 | 81.5~88. | Wheel Hub REAR |
| 03909 1592 | 24151-78A20 | 25 x 52 x 10 | JIMNY / SAMURAI JB23 | 98.9~ | TransTransmission FRONT |
| 03909 1682 | 09283-28014 | 28 x 50 x 8 | JIMNY / SAMURAI JB33,43 | 97.12~ | TransTransmission FRONT |
| 03909 2317 | 09283-25088 | 25 x 38 x 6 | JIMNY / SAMURAI JA51,JB31,32 | 84.10~97. | TransTransmission FRONT |
| 03909 1772 | 24151-70D00 | 20 x 49 x 7.8 | JIMNY / SAMURAI JA11,12,22 | 90.3~98. | TransTransmission FRONT |
| 03909 2457 | 09283-20028 | 20 x 47 x 8.5 | JIMNY / SAMURAI SJ30,40,JA71 | 81.5~90. | TransTransmission FRONT |
| 03909 1617 | 09283-48007 | 48 x 62 x 9 | JIMNY / SAMURAI JB23,31,32,33,43 | 93.5~ | Wheel Hub REAR |
| 03909 2867 | 09283-48007 | 48 x 62 x 9 | JIMNY / SAMURAI JA11,12,22,51,71 | 84.10~90. | Wheel Hub REAR |
| 03909 2937 | 09283-35008 | 35 x 62 x 10 x 16 | JIMNY / SAMURAI SJ30,40,JA11,12,71,JB23,32,33 | 81.5~ | Differential PINION FRONT |
| 03909 2132 | 27432-73H10 | 40 x 54 x 7 | KEI HN11S,12S,21S,22S-4WD | 98.9~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2557 | 09283-79001 | 79 x 99 x 8 | KEI HN21S,22S-K6A | 98.9~ | Engine CRANK SHAFT REAR |
| 03909 1657 | 09283-60005 | 60 x 80 x 8 | KEI HN11S,12S-F6A | 98.9~ | Engine CRANK SHAFT REAR |
| 03909 2677 | 09283-35040 | 35 x 47 x 6 | KEI HN21S,22S-K6A | 98.9~ | Engine CRANK SHAFT FRONT |
| 03909 1467 | 09283-32038 | 32 x 47 x 6 | KEI HN11S,12S-F6A | 98.9~ | Engine CRANK SHAFT FRONT |
| 03909 2942 | 09283-32038 | 32 x 47 x 6 | KEI HN11S,12S-F6A | 98.9~ | Engine CAM SHAFT |
| 03909 2537 | 09283-28022 | 28 x 47 x 7 | KEI HN11S,12S,21S,22S-4WD | 98.9~ | Final Drive PINION |
| 03909 1827 | 27431-73H10 | 34.5 x 54 x 8.5 x 10 | KEI HN11S,12S,21S,22S-2WD | 98.9~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2362 | 27431-73H30 | 34.5 x 52 x 8 | KEI HN12S,22S | 01.11~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 1952 | 27431-73B20 | 35 x 52 x 8 | KEI HN11S,12S,21S,22S-2WD,4WD | 98.9~01.11 | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2622 | 09283-40028 | 40 x 58 x 10 | KEI HN11S,12S,21S,22S-2WD:TURBO,4WD | 98.9~ | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 3107 | 09283-40029 | 40 x 62 x 8 | KEI HN11S,12S,21S,22S-2WD:TURBO,4WD | 98.9~ | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2947 | 27611-71B70 | 30 x 52 x 8 | KEI HN11S,12S,21S,22S-2WD:4V | 98.9~ | Transmission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03909 1402 | 24151-60BD1 | 22 x 36 x 5.5 | KEI HN11S,12S,21S,22S-TURBO | 98.9~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2382 | 24151-73B01 | 20 x 35 x 5.5 | KEI HN11S,12S,21S,22S-4V | 98.9~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 1452 | 43491-70D01 | 42 x 55 x 7 | KEI HN11S,12S,21S,22S | 98.9~02.4 | Wheel Hub REAR |
| 03909 1537 | 43491-82H00 | 42 x 55 x 7 x 9 | KEI HN12S,22S | 02.5~ | Wheel Hub REAR |
| 03909 1607 | 09283-35040 | 35 x 47 x 6 | MR WAGON MF21S-K6A | 01.11~ | Engine CRANK SHAFT FRONT |
| 03909 1877 | 27431-73H10 | 34.5 x 54 x 8.5 x 10 | MR WAGON MF21S-2WD | 01.11~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2287 | 09283-79001 | 79 x 99 x 8 | MR WAGON MF21S-K6A | 01.11~ | Engine CRANK SHAFT REAR |
| 03909 2432 | 27432-73H10 | 40 x 54 x 7 | MR WAGON MF21S-4WD | 01.11~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2097 | 43491-70D01 | 42 x 55 x 7 | MR WAGON MF21S-4WD | 01.11~ | Wheel Hub REAR |
| 03909 3162 | 09283-28022 | 28 x 47 x 7 | MR WAGON MF21S-4WD | 01.11~ | Final Drive PINION |
| 03909 1472 | 27431-73H30 | 34.5 x 52 x 8 | MR WAGON MF21S-2WD,4WD | 01.11~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 1347 | 09283-41001 | 41 x 53 x 6 | SWIFT M13A-HT51S | 00.1~ | Engine CRANK SHAFT FRONT |
| 03909 2562 | 09283-83001 | 83 x 103 x 8 | SWIFT M13A-HT51S | 00.1~ | Engine CRANK SHAFT REAR |
| 03909 1962 | 09283-28022 | 28 x 47 x 7 | SWIFT HT51S-4WD | 00.1~ | Final Drive PINION |
| 03909 3192 | 27611-75F11 | 40 x 56 x 8 | SWIFT HT51S-4WD | 00.1~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2972 | 27611-82301 | 35 x 55 x 8 | SWIFT HT51S-2WD | 00.1~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 1542 | 27611-82301 | 35 x 55 x 8 | SWIFT HT51S-2WD,4WD | 00.1~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2462 | 43491-70D01 | 42 x 55 x 7 | SWIFT HT51S-4WD | 00.1~ | Wheel Hub REAR |
| 03909 3167 | 27611-79C10 | 39.5 x 54 x 9 | WAGON R MA34S | 00.12~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 1567 | 09283-35040 | 35 x 47 x 6 | WAGON R CT21S,CV21S,MC11S-F6A-4V | 93.9~00. | Engine CAM SHAFT |
| 03909 1832 | 09283-28022 | 28 x 47 x 7 | WAGON R MC11S,12S,21S,22S,MA63S,64S-4WD | 98.10~ | Final Drive PINION |
| 03909 2967 | 09283-28022 | 28 x 47 x 7 | WAGON R CV21S,CV51S (4WD) | 93.9~98. | Final Drive PINION |
| 03909 1947 | 09283-32038 | 32 x 47 x 6 | WAGON R CT21S,CV21S,MC11S,12S-F6A-TURBO | 93.9~ | Engine CAM SHAFT |
| 03909 1747 | 27611-71B70 | 30 x 52 x 8 | WAGON R MC11S,21S-CVT | 98.10~00. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 1967 | 27611-75F11 | 40 x 55 x 8 | WAGON R MB61S-AISIN | 97.1~99. | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2302 | 27432-73H10 | 40 x 54 x 7 | WAGON R MC11S,12S,21S,22S,MA63S,64S-4WD | 98.10~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 1742 | 27431-73H10 | 34.5 x 54 x 8.5 x 10 | WAGON R MC11S,12S,21S,22S,MA63S,64S-2WD | 98.10~ | Transmission & Differential (A/T) DIFF. SIDE (RH) |
| 03909 2177 | 09283-32038 | 32 x 47 x 6 | WAGON R CT21S,CV21S,MC11S,12S-F6A | 93.9~ | Engine CRANK SHAFT FRONT |
| 03909 1377 | 27611-82301 | 35 x 55 x 8 | WAGON R MB61S-AISIN | 97.1~99. | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 3117 | 09283-83001 | 83 x 103 x 8 | WAGON R MA34S-M13A | 00.12~ | Engine CRANK SHAFT REAR |
| 03909 2667 | 27431-73H30 | 34.5 x 52 x 8 | WAGON R MA64S-2WD,4WD | 00.12~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2057 | 27431-73H30 | 34.5 x 52 x 8 | WAGON R MC22S-2WD,4WD | 01.10~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 3242 | 27612-79C10 | 37.5 x 63 x 9 | WAGON R MA34S | 00.12~ | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 1642 | 09283-35040 | 35 x 47 x 6 | WAGON R CT51S,CV51S,MC21S,22S-K6A | 97.4~ | Engine CRANK SHAFT FRONT |
| 03909 2122 | 09283-35040 | 35 x 47 x 6 | WAGON R MA61S,63S,64S,MB61S-K10A | 97.1~ | Engine CRANK SHAFT FRONT |
| 03909 2547 | 09283-41001 | 41 x 53 x 6 | WAGON R MA34S-M13A | 00.12~ | Engine CRANK SHAFT FRONT |
| 03909 2912 | 09283-60005 | 60 x 80 x 8 | WAGON R CT21S,CV21S,MC11S,12S-F6A | 93.9~ | Engine CRANK SHAFT REAR |
| 03909 2662 | 09283-79001 | 79 x 99 x 8 | WAGON R MA61S,63S,64S,MB61S-K10A | 97.1~ | Engine CRANK SHAFT REAR |
| 03909 1392 | 27431-73B20 | 35 x 52 x 8 | WAGON R MA63S-2WD,4WD | 99.5~00. | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 3012 | 43491-70D01 | 42 x 55 x 7 | WAGON R CV21S,CV51S (4WD) | 93.9~98. | Wheel Hub REAR |
| 03909 1867 | 09283-79001 | 79 x 99 x 8 | WAGON R CT51S,CV51S,MC21S,22S-K6A | 97.4~ | Engine CRANK SHAFT REAR |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2657 | 27431-73B20 | 35 x 52 x 8 | WAGON R MB61S | 97.1~98.3 | Transmission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03909 2107 | 09283-44011 | 44 x 62 x 8 x 13.5 | WAGON R CT21S,CV21S,CT51S,CV51S | 93.9~98. | Wheel Hub FRONT |
| 03909 3132 | 43430-60810 | 48 x 62 x 16.5 | WAGON R MA61S,MB61S | 97.1~99. | Wheel Hub FRONT |
| 03909 2852 | 43491-70D01 | 42 x 55 x 7 | WAGON R MC11S,MC21S-4WD | 98.10~00. | Wheel Hub REAR |
| 03909 2427 | 43491-70D01 | 42 x 55 x 7 | WAGON R MB61S (4WD) | 97.1~99. | Wheel Hub REAR |
| 03909 1817 | 43491-70D01 | 42 x 55 x 7 | WAGON R MA63S-4WD | 99.5~00. | Wheel Hub REAR |
| 03909 1717 | 43491-82H00 | 42 x 55 x 7 x 9 | WAGON R MC22S-4WD | 02.5~ | Wheel Hub REAR |
| 03909 2082 | 43491-82H00 | 42 x 55 x 7 x 9 | WAGON R MA34S,64S-4WD | 00.12~ | Wheel Hub REAR |
| 03909 1752 | 24151-73B01 | 20 x 35 x 5.5 | WAGON R CT21S,CT51S | 93.9~98. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2672 | 24151-73B01 | 20 x 35 x 5.5 | WAGON R MC11S,12S,21S,22S-2WD-4V | 98.10~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2807 | 24151-73B01 | 20 x 35 x 5.5 | WAGON R MA61S | 97.1~98.3 | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 1942 | 24151-60BD1 | 22 x 36 x 5.5 | WAGON R MC11S,12S,21S,22S-4WD,TURBO | 98.10~ | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2292 | 24151-60BD1 | 22 x 36 x 5.5 | WAGON R MA61S | 98.3~99. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2757 | 24151-60BD1 | 22 x 36 x 5.5 | WAGON R MB61S | 97.1~99. | Transmission & Differential (M/T) INPUT SHAFT |
| 03909 2397 | 43491-70D01 | 42 x 55 x 7 | WAGON R MC12S,MC22S-4WD | 00.12~02.5 | Wheel Hub REAR |
| 03909 3052 | 09283-40029 | 40 x 62 x 8 | WAGON R MA61S,MB61S | 98.3~99. | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2252 | 27431-73B20 | 35 x 52 x 8 | WAGON R CV21S,CV51S (4WD) | 93.9~98. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03909 2687 | 27431-73B20 | 35 x 52 x 8 | WAGON R CT21S,51S-4AT-TURBO | 93.9~98. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |

# 5. Seals product list

## 5.9 SUZUKI

| SNT Part No. | OEM Part No. | Size | Body Model | Year/ Month | Part Description |
|---|---|---|---|---|---|
| 03909 2872 | 27611-82300 | 35 x 55 x 8 | WAGON R MA61S-AISIN | 97.1~ | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03909 2247 | 27611-82300 | 35 x 55 x 8 | WAGON R CT21S,51S-3AT-TURBO | 93.9~98. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03909 2502 | 27611-71B70 | 30 x 52 x 8 | WAGON R CT21S,51S-3AT-4V | 93.9~98. | Transmission & Differential (A/T) DIFF. SIDE (LH & RH) |
| 03909 2027 | 27611-71B70 | 30 x 52 x 8 | WAGON R CT21S,51S-2WD-4V | 93.9~98. | Transmission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03909 2932 | 09283-40028 | 40 x 58 x 10 | WAGON R MC11S,12S,21S,22S-2WD-TURBO,4WD | 98.10~ | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 1807 | 27611-71B70 | 30 x 52 x 8 | WAGON R MC11S,12S,21S,22S-2WD-4V | 98.10~ | Transmission & Differential (M/T) DIFF. SIDE (LH & RH) |
| 03909 2272 | 09283-40029 | 40 x 62 x 8 | WAGON R MC11S,12S,21S,22S-2WD-TURBO,4WD | 98.10~ | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2012 | 27431-73B20 | 35 x 52 x 8 | WAGON R MA61S | 97.1~98.3 | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 2142 | 27431-73B20 | 35 x 52 x 8 | WAGON R CT21S,51S-2WD-TURBO | 93.9~98. | Transmission & Differential (M/T) DIFF. SIDE (RH) |
| 03909 2242 | 09283-35037 | 35 x 62 x 9.5 | WAGON R MA61S | 97.1~98.3 | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 2992 | 09283-35037 | 35 x 62 x 9.5 | WAGON R CT21S,51S-2WD-TURBO | 93.9~98. | Transmission & Differential (M/T) DIFF. SIDE (LH) |
| 03909 1577 | 27431-73B20 | 35 x 52 x 8 | WAGON R MC11S,12S,21S,22S-2WD,4WD-3AT,4AT | 98.10~01.10 | Transmission & Differential (A/T) DIFF. SIDE (LH) |
| 03909 2337 | 09283-40028 | 40 x 58 x 10 | WAGON R MA61S,MB61S | 98.3~99. | Transmission & Differential (M/T) DIFF. SIDE (RH) |

# SERVICE **WORLDWIDE**

***For over 10 years, we have continuously strived to improve our business to efficiently meet every customer demand. Now, SNT is providing Worldwide Service that will help drive your business growth endlessly and sustainably.***

## SNT AUTOPART GROUP


***HEADQUARTERS***
***SNT AUTOPART ENTERPRISE, LLC.***
*Empire State Building*
*350 Fifth Avenue, 59th Floor*
*New York, NY 10118 U.S.A.*
*Telephone: (+1)917-979-6883*
*Fax: (+1)917-979-6884*
*E-mail: info@sntautopart.com*

***ASIA-PACIFIC OFFICE***
***SNT AUTOPART INTERTRADE Co., Ltd.***
*All Seasons Place*
*36th Floor, CRC Tower,*
*87/2 Wireless Road, Pathumwan,*
*Bangkok 10330 Thailand*
*Telephone: (+66)2-105-6155*
*Fax: (+66)2-105-6155 Ext.4*
*E-mail: info@sntautopart.com*

***FACTORY***
***SNT MACHINE LIMITED PARTNERSHIP***
*18/3 Rama II Road,*
*Samaedam, Bangkhuntien,*
*Bangkok 10150 Thailand*
*Telephone: (+66)2-897-0968*
*Fax: (+66)2-897-0968*
*E-mail: info@sntautopart.com*


www.sntautopart.com