

PICKUP



TRUCK



BUILT TOUGH



TRAILER



HEAVY-DUTY EQUIPMENT



Oil Seals

CATALOG



SNT AUTOPART GROUP
www.sntautopart.com



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

1. FOREWORD

Rubber parts are in our DNA. It's not marketing speak. SNT produce only the highest quality products. If you need something custom, our engineering and design team can help assist with your unique rubber part requirements with our warranty guarantee. **We are different and we want to show why that's good for you.**

We know that having the right part at the right time is crucial to your operation. Under the SNT brand, we carry more than 30,000 SKUs.

We believe the best method to get our products to the customer is through strategic alliances with our distribution partners. Our commitment to our distributors, and the ultimate user, is to constantly introduce new and innovative products at higher levels of quality with an emphasis on compressed lead times - products that will last longer and reduce overall maintenance costs. All of our employees have a "can do" attitude and take pride in helping customers. **You have a problem? We have a solution.** All we ask is the chance to prove ourselves; you won't be disappointed!

Content Remarks

All rubber parts in this catalogue are specially manufactured by SNT. The O.E.M. Part No., Interchange Part No., Auto maker name, and all other trademarks mentioned in this document are the property of their respective owners and are used for identification purposes only.



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

2. INTRODUCTION

SNT AUTOPART GROUP is a leading manufacturer of replacement parts. For over 30 years experience, SNT supplies the high quality rubber parts successfully. We win worldwide clients' trust based on **premium quality of products, excellent service and competitive price.**

Our top executive has more than 7 years of R&D experience at the top 3 automobile companies in the world, create a perfect knowledge of products. Moreover, SNT products are manufactured according to German standard (DIN) and ISO 9001 quality management system. So we guarantee to

“SNT products are the same characteristics of original spare parts with competitive price”

SNT AUTOPART GROUP is comprised of the following companies:

1. SNT AUTOPART ENTERPRISE, LLC. (New York, U.S.A.)
2. SNT AUTOPART INTERTRADE Co., Ltd. (Bangkok, Thailand)
3. SNT MACHINE Ltd., Part. (Bangkok, Thailand)



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

2.1 ISO 9001 CERTIFICATION

globalgroup
Management System Experts®

Certificate of Registration

This is to certify that the

QUALITY MANAGEMENT SYSTEM

of

S.N.T. MACHINE LTD., PART.

18/3 Soi Bangkradee19 Yeak6, RAMA II Road, Bangkhuntien, Bangkok, 10150, THAILAND

for

Design and Manufacture of Rubber Parts and Stamping Parts, Oil Seals, Rubber Bushings, Torque Rod Bushings, Engine Mounts for Automotives, Motorcycles and Industrial Machineries.

has been assessed and registered against the provisions of

ISO 9001:2008

International Standard

With

Registration Number:	44Q16937	Project:	11-16937-1-Q
Certification Date:	11 December 2015	Code:	DH 25.13
Recertification Due Date:	14 September 2018	Exclusions:	7.5.4, 7.5.2
Certification Approved By:		Alan Cherry	
		Chairman	

Registration is subject to the management system being continually maintained to the above standard under regular surveillance. Should surveillance not take place when required, registration shall be removed.

This certificate is the property of GlobalGROUP of Companies Limited
21 Lansdowne Crescent, Edinburgh, Midlothian, EH12 5EH, Scotland, United Kingdom


0039

Please validate the authenticity of the certificate at www.globalgroup.net


30002530


3. SNT WARRANTY

SNT, warrants that all products sold shall be free from defects in material and workmanship for period of one year from date of shipment. At our option, any products prove to be defective either in workmanship or material whereby it is not suitable under proper usage and service for the purpose for which designed shall be replaced free of charge including transportation charges, but not the cost of installation, providing that the products are not subject to negligence, accident, or damages beyond our control. We shall not be responsible for consequential damages.

4. MEMBERSHIPS

SNT AUTOPART GROUP is long standing members and supporter of the following associations.

- 1) THE FEDERATION OF THAI INDUSTRIES
- 2) THE THAI CHAMBER OF COMMERCE
- 3) THAILAND AUTOMOTIVE INSTITUTE
- 4) THAI AUTO PARTS MANUFACTURERS ASSOCIATION



THE FEDERATION OF THAI INDUSTRIES



5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5371	90311-89001	89 x 105 x 10	ALTEZZA 3SGE..SXE10	98/10~	Engine CRANK SHAFT REAR
03901 1037	90311-29001	30 x 42 x 7	ALTEZZA SXE10	98/10~	Transmission (M/T) FRONT COVER
03901 7325	90311-38032	38 x 58 x 11	ALTEZZA SXE10	98/10~	Transmission (M/T) EXTENSION HOUSING
03901 3109	90311-48013	48 x 73 x 7	ALTEZZA GXE10, SXE10	98/10~	Wheel Hub FRONT
03901 3527	90913-02115		ALTEZZA 3SGE (EX)	98/10~	Engine VALVE STEM SEAL
03901 5051	90913-02093		ALTEZZA 1GFE (IN & EX)	98/10~	Engine VALVE STEM SEAL
03901 7403	90311-75007	75 x 100 x 10	ALTEZZA 1GFE GXE10	98/10~	Engine CRANK SHAFT REAR
03901 4397	90311-42026	42 x 60 x 7	ALTEZZA 3SGE SXE10	98/10~	Engine CRANK SHAFT FRONT
03901 2789	90311-45015	45 x 62 x 9	ALTEZZA 1GFE GXE10	98/10~	Engine TIMING GEAR CASE
03901 2909	15165-70010	18 x 30 x 7	ALTEZZA 1GFE GXE10, 3SGE SXE10	98/10~	Engine OIL PUMP
03901 2539	90311-38032	38 x 58 x 11	ALTEZZA GXE10	98/10~	Transmission (A/T) EXTENSION HOUSING
03901 8247	90913-02114		ALTEZZA 3SGE (IN)	98/10~	Engine VALVE STEM SEAL
03901 2209	90311-38029	38 x 58 x 11	ALTEZZA SXE10	98/10~	Transmission (A/T) FRONT OIL PUMP
03901 4731	90311-46004	46 x 60 x 6.5	ALTEZZA 3SGE SXE10	98/10~	Engine CAM SHAFT
03901 3211	90311-40001	40 x 58 x 11	ALTEZZA SXE10	98/10~	Transmission (A/T) EXTENSION HOUSING
03901 7897	90311-38070	38 x 74 x 11 x 19	ALTEZZA GXE10, SXE10	98/10~	Final Drive PINION
03901 4165	90311-38071	38 x 63 x 10 x 16.5	ALTEZZA GXE10, SXE10	98/10~	Final Drive DIFF. SIDE
03901 2487	04445-53010		ALTEZZA GXE10, SXE10	98/10~	Steering (P/S) R&P GASKET KIT
03901 4021	90311-19002	19 x 32 x 7 x 8	ALTEZZA GXE10, SXE10	98/10~	Steering (P/S) CONTROL VALVE UPPER
03901 1685	90310-25027	25 x 38 x 7	ALTEZZA GXE10, SXE10	98/10~	Steering (P/S) CONTROL VALVE LOWER
03901 6929	90311-38020	38 x 55 x 8.5	ALTEZZA GXE10	98/10~	Transmission (A/T) FRONT OIL PUMP
03901 5575	90913-02106		ARISTO 1UZFE(EX.) UZS143	96/8~97	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5055	90311-43004	43 x 60 x 7	ARISTO 1UZFE UZS143	92/10~97	Engine OIL PUMP
03901 3117	90311-46001	46 x 63 x 6.5	ARISTO 2JZ#...JZS147,16#	91/10~	Engine CRANK SHAFT FRONT
03901 3361	90311-90006	90 x 110 x 9.5	ARISTO 2JZ#...JZS147,16#	91/10~	Engine CRANK SHAF REAR
03901 2737	90311-95006	95 x 113 x 10	ARISTO 1UZFE UZS143	92/10~97	Engine CRANK SHAF REAR
03901 7993	90913-02062		ARISTO 2JZ#...JZS147	92/10~97	Engine VALVE STEM SEAL
03901 6457	90913-02113		ARISTO 1UZFE(IN.) UZS143	96/8~97	Engine VALVE STEM SEAL
03901 3525	90311-38036	38 x 50 x 8	ARISTO 1UZFE UZS143	92/10~97	Engine CAM SHAFT
03901 3179	90913-02062		ARISTO 2JZ#(EX.) JZS16#	97/8~	Engine VALVE STEM SEAL
03901 3897	90311-50008	50 x 77.5 x 9 x 14	ARISTO JZS147	91/10~97	Wheel Hub FRONT
03901 8187	90913-02079		ARISTO 2JZ#(IN.) JZS16#	97/8~	Engine VALVE STEM SEAL
03901 6479	90311-42024	42 x 55 x 10	ARISTO JZS147, 16#, UZS143	91/10~	Transmission (A/T) EXTENTION HOUSING
03901 1741	90311-63001	63 x 90 x 7 x 10	ARISTO JZS147, UZS143	91/10~97	Wheel Hub REAR INNER
03901 6121	90311-40020	40.5 x 52.5 x 6.5	ARISTO 2JZ#...JZS147,16#	91/10~	Engine CAM SHAFT
03901 3745	90311-57001	57 x 81 x 8 x 11	ARISTO JZS147, UZS143	91/10~97	Wheel Hub REAR OUTER
03901 8253	90913-02079		ARISTO 1UZFE UZS143(IN.&EX.)	91/10~96/8	Engine VALVE STEM SEAL
03901 3577	90311-38029	38 x 55 x 7.5	ARISTO JZS147, 16#, UZS143	91/10~	Transmission (A/T) FRONT OIL PUMP
03901 7257	90311-47008	47 x 72 x 10 x 11	ARISTO JZS147, 16#, UZS143	91/10~	Final Drive DIFF. SIDE
03901 6361	04445-30150		ARISTO JZS147	91,10~92/10	Steering (P/S) R&P GASKET KIT
03901 7517	90311-50008	50 x 77.5 x 9 x 14	ARISTO JZS16#	97/8~	Wheel Hub FRONT
03901 4081	04445-30230		ARISTO JZS147	92/10~97/	Steering (P/S) R&P GASKET KIT
03901 1509	04445-30240		ARISTO UZS143	92/10~97/	Steering (P/S) R&P GASKET KIT
03901 7607	04445-30252		ARISTO JZS16#	97/8~	Steering (P/S) R&P GASKET KIT
03901 1499	90311-19002	19 x 32 x 7 x 8	ARISTO JZS147, 16#, UZS143	91/10~	Steering (P/S) CONTROL VALE UPPER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4489	90311-30016	30 x 42 x 7 x 8	ARISTO JZS147, 16#, UZS143	91/10~	Steering (P/S) CONTROL VALE LOWER
03901 4185	90311-44005	44 x 74 x 11 x 16	ARISTO JZS147, 16#, UZS143	91/10~	Final Drive PINION
03901 4173	90311-19010	19 x 32 x 6	AVALON MCX10	95/3~00/	Steering (P/S) CONTROL VALVE UPPER
03901 4983	90913-02101		AVALON 1MZFE(IN.)	95/3~00/	Engine VALVE STEM SEAL
03901 4209	90913-02111		AVALON 1MZFE(EX.)	95/3~00/	Engine VALVE STEM SEAL
03901 2945	90311-92008	92 x 110 x 9	AVALON 1MZFE MCX10	95/3~00/	Engine CRANK SHAFT REAR
03901 1767	90311-40022	40 x 55 x 6	AVALON 1MZFE MCX10	95/3~00/	Engine OIL PUMP
03901 7691	90311-26003	26 x 38 x 6.5	AVALON MCX10	95/3~00/	Steering (P/S) CONTROL VALVE LOWER
03901 3289	04445-07010		AVALON MCX10	95/3~00/	Steering (P/S) R&P GASKET KIT
03901 4159	90311-38020	38 x 55 x 8.5	AVALON MCX10	95/3~00/	Mission & Differential (A/T) FRONT OIL PUMP
03901 4189	90311-50011	50 x 80 x 16.5 x 23	AVALON MCX10	95/3~00/	Mission & Differential (A/T) DIFF. SIDE
03901 4909	90311-40010	40 x 56 x 9 x 15.5	AVALON MCX10	95/3~00/	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 6355	90311-38034	38 x 50 x 10.5	AVALON 1MZFE MCX10	95/3~00/	Engine CAM SHAFT
03901 4051	04445-52010		BB NCP35 (4WD)	00/1~	Steering (P/S) R&P GASKET KIT
03901 5755	90311-34017	34 x 63 x 9 x 16	BB NCP30	00/1~	Mission & Differential (A/T) TRANSAXLE CASE
03901 4591	90913-02093		BB 1NZFE,2NZFE (IN.& EX.)	00/1~	Engine VALVE STEM SEAL
03901 7819	90311-75016	75 x 107 x 8	BB 1NZFE,2NZFE NCP3#	00/1~	Engine CRANK SHAFT REAR
03901 6135	90311-25021	25.5 x 37.5 x 6	BB 1NZFE,2NZFE NCP3#	00/1~	Engine OIL PUMP
03901 6199	90311-42055	42 x 55 x 7	BB NCP35 (4WD)	00/1~	Wheel Hub REAR
03901 3895	90311-38020	38 x 55 x 8.5	BB NCP31,35	00/1~	Mission & Differential (A/T) FRONT OIL PUMP
03901 2319	90311-38075	38 x 55 x 7.8	BB NCP30	00/1~	Mission & Differential (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6973	90311-38075	38 x 55 x 7.8	BB NCP30	00/1~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 6943	90311-34022	34 x 56 x 9 x 15	BB NCP35 (4WD)	00/1~	Mission & Differential (A/T) TRANSAXLE (NO.2)
03901 2875	90311-34016	34 x 54 x 9 x 15.5	BB NCP30,31	00/1~	Mission & Differential (A/T) TRANSAXLE (NO.2)
03901 4167	90311-34022	34 x 56 x 9 x 15	BB NCP31	00/1~	Mission & Differential (A/T) TRANSAXLE (NO.1)
03901 1169	04445-52020		BB NCP30,31	00/1~	Steering (P/S) R&P GASKET KIT
03901 8205	90311-49002	50 x 64 x 8	BB NCP35 (4WD)	00/1~	Mission & Differential (A/T) TRANSAXLE (NO.1)
03901 4811	90311-42026	42 x 60 x 7	BLIZZARD L,2L#...LD10,2#	80/3~90/	Engine TIMING GEAR CASE
03901 2501	90311-85001	85 x 105 x 13	BLIZZARD L LD10	80/3~84/2	Engine CRANK SHAFT REAR
03901 1515	90311-85004	85 x 105 x 10	BLIZZARD L,2L#...LD10,2#	84/2~90/	Engine CRANK SHAFT REAR
03901 1267	90913-02036		BLIZZARD L LD10	80/3~81/7	Engine VALVE STEM SEAL
03901 7027	90913-02060		BLIZZARD L,2L#...LD10,2#	81/7~90/	Engine VALVE STEM SEAL
03901 5581	90311-42003	42 x 60 x 7	BLIZZARD L,2L#...LD10,2#	80/3~90/	Engine CAM SHAFT
03901 8055	90043-11166-000	50 x 62 x 9	BLIZZARD LD2#	84/5~90/	Wheel Hub REAR OUTER
03901 4115	90311-52059	52 x 65 x 9	BLIZZARD LD2#	84/5~90/	Wheel Hub REAR INNER
03901 1543	90043-11131-000	45 x 72 x 12 x 18	BLIZZARD LD10,2#	80/3~90/	Final Drive PINION (F&R)
03901 6527	90312-32002	32 x 40 x 5	BLIZZARD LD2#	84/5~90/	Steering (P/S) GEAR HOUSING
03901 7445	90043-11080-000	55 x 78 x 12	BLIZZARD LD10,2#	80/3~90/	Wheel Hub FRONT
03901 2317	90043-11081-000	32 x 48 x 8	BLIZZARD LD10	80/3~84/	Wheel Hub REAR INNER
03901 7121	90043-11082-000	50 x 72 x 9	BLIZZARD LD10	80/3~84/	Wheel Hub REAR OUTER
03901 6803	90043-11141-000	30 x 45 x 8	BLIZZARD LD10,2#	80/3~90/	Transmission FRONT COVER
03901 3359	04445-60020		BLIZZARD LD2#	84/5~90/	Steering (P/S) GEAR GASKET KIT
03901 4525	90043-11086-000	32 x 52 x 8	BLIZZARD LD10	80/3~84/	Final Drive FRONT DIFF. SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4135	90043-11117-000	19 x 32 x 8	BLIZZARD LD10,2#	80/3~90/	Steering (M/S) WORM GEAR
03901 3087	90043-11168-000	34 x 44 x 8	BLIZZARD LD2#	84/5~90/	Steering (M/S) SEKTOR SHAFT
03901 7177	90913-02079		BREVIS 1JZFSE, 2JZFSE (IN.)	01/5~	Engine VALVE STEM SEAL
03901 4279	90311-38029	38 x 55 x 7.5	BREVIS JCG1#	01/5~	Transmission (A/T) FRONT OIL PUMP
03901 2885	90913-02062		BREVIS 1JZFSE, 2JZFSE(EX.)	01/5~	Engine VALVE STEM SEAL
03901 2689	90311-90006	90 x 110 x 9.5	BREVIS 1JZFSE, 2JZFSE JCG1#	01/5~	Engine CRANK SHAFT REAR
03901 7837	90311-46001	46 x 63 x 6.5	BREVIS 1JZFSE, 2JZFSE JCG1#	01/5~	Engine CRANK SHAFT FRONT
03901 8227	90311-34027	34 x 56 x 6	BREVIS 1JZFSE, 2JZFSE JCG1#	01/5~	Engine CAM SHAFT
03901 2641	04445-51011		BREVIS JCG1#	01/5~	Steering (P/S) RACK&PINION KIT
03901 7031	90311-43001	43 x 70 x 9 x 15.5	BREVIS JCG11	01/5~	Final Drive DIFF. SIDE
03901 6159	90311-38071	38 x 63 x 10 x 16.5	BREVIS JCG10,15	01/5~	Final Drive DIFF. SIDE
03901 8229	90311-38070	38 x 74 x 11 x 19	BREVIS JCG1#	01/5~	Final Drive PINION
03901 2533	90311-40001	40 x 58 x 11	BREVIS JCG1#	01/5~	Transmission (A/T) REAR EXTENTION
03901 1749	90311-48013	48 x 73 x 7	BREVIS JCG10,11	01/5~	Wheel Hub FRONT
03901 4333	15165-70010	18 x 30 x 7	CALDINA 3SFE,4SFE ST19#,21#	92/11~	Engine OIL PUMP
03901 3039	90311-38044	38 x 50 x 6	CALDINA 2C#,3C#...CT19#,216	92/11~	Engine CAM SHAFT
03901 3509	90311-38036	38 x 50 x 8	CALDINA 3SFE,4SFE ST19#	92/11~97/8	Engine CAM SHAFT
03901 7111	90311-38067	38 x 50 x 8	CALDINA 3SFE ST198,21#	97/8~	Engine CAM SHAFT
03901 2597	90311-35041	35 x 60 x 11	CALDINA 3SGE ST215	97/8~	Engine CAM SHAFT (NO.1)
03901 2575	90311-46004	46 x 60 x 6.5	CALDINA 3SGE ST215	97/8~	Engine CAM SHAFT (NO.2)
03901 4987	90029-21022	22 x 34 x 6.5	CALDINA 2C CT19#	92/11~93/8	Engine OIL PUMP
03901 7157	90311-32020	32 x 46 x 6	CALDINA 7AFE AT191,211	96/1~	Engine OIL PUMP
03901 7497	90310-25004	25 x 38 x 7 x 8	CALDINA AT211,CT216,ST21#...TOY ODAKOKI G/B	97/8~	Steering (P/S) CONTROL VALVE LOWER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6213	90029-21020	20 x 32 x 5	CALDINA 5EFE ET196	92/11~	Engine OIL PUMP
03901 2921	90311-35013	35 x 49 x 6	CALDINA 3SGTE ST215	97/8~	Engine CAM SHAFT
03901 6651	90311-35013	35 x 49 x 6	CALDINA 3SGE ST195	95/2~97/8	Engine CAM SHAFT
03901 5509	90311-35013	35 x 49 x 6	CALDINA 5EFE ET196	92/11~	Engine CAM SHAFT
03901 6925	90311-35013	35 x 49 x 6	CALDINA 7AFE AT191,211	96/1~	Engine CAM SHAFT
03901 1619	90310-25004	25 x 38 x 7 x 8	CALDINA AT191,CT19#,ST19#...TOY ODAKOKI G/B	92/11~	Steering (P/S) CONTROL VALVE LOWER
03901 6847	90310-28003	28 x 41 x 6.5	CALDINA AT191,ET196,ST191 TOYOTA G/B	92/11~	Steering (P/S) CONTROL VALVE LOWER
03901 6103	15165-70010	18 x 30 x 7	CALDINA 3SG#...ST195,215	95/2~	Engine OIL PUMP
03901 3945	90311-89001	89 x 105 x 10	CALDINA 3SG#...ST195,215	95/2~	Engine CRANK SHAFT REAR
03901 4413	04445-20210		CALDINA ET196	96/1~	Steering (P/S) R&P GASKET KIT
03901 7783	90311-19002	19 x 32 x 7 x 8	CALDINA AT191,211,CT19#,216,ST19 #,21#	92/11~	Steering (P/S) CONTROL VALVE UPPER
03901 7805	90310-28003	28 x 41 x 6.5	CALDINA AT211,ST210 TOYOTA G/B	97/8~	Steering (P/S) CONTROL VALVE LOWER
03901 2261	90913-02062		CALDINA 5EFE (IN. & EX.)	92/11~	Engine VALVE STEM SEAL
03901 6971	04445-20240		CALDINA CT196,197	96/1~	Steering (P/S) R&P GASKET KIT
03901 6347	90311-44003	44 x 80 x 9 x 15.5	CALDINA ST195,198 4FC	92/11~	Mission & Differential (A/T) DIFF.SIDE
03901 3791	90913-02117		CALDINA 2C#,3C#	97/4~	Engine VALVE STEM SEAL
03901 7943	90913-02110		CALDINA 2C#	96/1~97/4	Engine VALVE STEM SEAL
03901 1699	90913-02056		CALDINA 2C	95/11~96/ 1	Engine VALVE STEM SEAL
03901 5191	90913-02094		CALDINA 2C	92/11~95/ 11	Engine VALVE STEM SEAL
03901 5327	90913-02079		CALDINA 3SFE,4SFE (IN.)	92/11~	Engine VALVE STEM SEAL
03901 8181	90913-02079		CALDINA 7AFE (IN.)	96/1~	Engine VALVE STEM SEAL
03901 7861	90311-90008	90 x 110 x 9.5 x 11.5	CALDINA 2C#,3C#...CT19#,216	96/1~	Engine CRANK SHAFT REAR
03901 7667	90913-02062		CALDINA 7AFE (EX.)	96/1~	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1113	90311-35013	35 x 49 x 6	CALDINA 5EFE ET196	92/11~96/4	Engine CRANK SHAFT FRONT
03901 2757	90311-85007	85 x 105 x 10	CALDINA 3SFE,4SFE ST19#,21#	92/11~	Engine CRANK SHAFT REAR
03901 2077	90311-90005	90 x 110 x 8.5 x 10	CALDINA 2C CT19#	92/11~96/1	Engine CRANK SHAFT REAR
03901 5401	90311-70007	70 x 92 x 8.5	CALDINA 7AFE AT191,211	96/1~	Engine CRANK SHAFT REAR
03901 6469	90311-80012	80 x 100 x 8.5	CALDINA 5EFE ET196	92/11~	Engine CRANK SHAFT REAR
03901 7933	90311-42035	42 x 60 x 7	CALDINA 3SGE ST19#,21#	96/9~	Engine CRANK SHAFT FRONT
03901 7297	90311-42026	42 x 60 x 7	CALDINA 3SGE ST195,215	96/9~	Engine CRANK SHAFT FRONT
03901 1467	90311-42026	42 x 60 x 7	CALDINA 3S#,4SFE ST19#	92/11~96/9	Engine CRANK SHAFT FRONT
03901 7895	90311-42026	42 x 60 x 7	CALDINA 2C3,3C#...CT19#,216	92/11~	Engine CRANK SHAFT FRONT
03901 7967	90311-35040	35 x 49 x 6	CALDINA 5EFE ET196	96/4~	Engine CRANK SHAFT FRONT
03901 5403	90913-02062		CALDINA 3SFE,4SFE (EX.)	92/11~	Engine VALVE STEM SEAL
03901 5417	90311-56015	56 x 75 x 7 x 12	CALDINA CT216,ST215 (4WD)	97/8~	Wheel Hub REAR INNER
03901 8003	90311-35033	35 x 55 x 9 x 15.5	CALDINA CT197 5F	00/2~	Mission & Differential (M/T) DIFF. SIDE
03901 4099	90311-35033	35 x 55 x 9 x 15.5	CALDINA CT190,196,197,ST190 5F	92/11~00/2	Mission & Differential (M/T) DIFF. SIDE
03901 7109	90311-49002	50 x 64 x 8	CALDINA ST215 5F (E,G)	97/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 3983	90311-35033	35 x 55 x 9 x 15.5	CALDINA CT197 5F	00/2~	Mission & Differential (M/T) TRANSAXLE CASE
03901 1237	90311-35033	35 x 55 x 9 x 15.5	CALDINA CT190,196,197,ST190 5F	92/11~00/2	Mission & Differential (M/T) TRANSAXLE CASE
03901 8127	90311-34016	34 x 54 x 9 x 15.5	CALDINA AT191,211,ET196 5F	92/11~	Mission & Differential (M/T) TRANSAXLE CASE
03901 7533	90311-50010	50 x 80 x 16.5 x 23	CALDINA ST215 5F GTT	97/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 1733	90311-44003	44 x 80 x 9 x 15.5	CALDINA CT198,199,ST195 5F	92/11~	Mission & Differential (M/T) TRANSMISSION CASE
03901 4253	90311-30006	30 x 42 x 7	CALDINA CT19#,ST190,195,215 5F	92/11~	Mission & Differential (M/T) INPUT SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2685	90311-35033	35 x 55 x 9 x 15.5	CALDINA ST215 5F (E,G)	97/8~	Mission & Differential (M/T) DIFF. SIDE
03901 7361	90311-52005	52 x 75 x 7.5 x 12	CALDINA ST195 (4WD)	92/11~97/8	Wheel Hub REAR OUTER
03901 2345	90311-34017	34 x 63 x 9 x 16	CALDINA AT191,211,ET196 5F	92/11~	Mission & Differential (M/T) TRANSMISSION CASE
03901 1657	90311-56007	56 x 75 x 6.5 x 11	CALDINA ST195 (4WD)	92/11~97/8	Wheel Hub REAR INNER
03901 1769	90311-52059	52 x 65 x 9	CALDINA CT198,199,ST198	92/11~	Wheel Hub REAR
03901 3573	90311-48001	48 x 62 x 9	CALDINA CT196,197,ET196	92/11~	Wheel Hub REAR
03901 2403	04422-20080	Kit	CALDINA AT191,CT190,ST19#...ABS	92/11~97/8	Wheel Hub FRONT
03901 2647	04422-20080	Kit	CALDINA CT19#,...ET196 ABS	85/5~99/8	Wheel Hub FRONT
03901 6637	04422-20080	Kit	CALDINA AT211,CT216,ST21#	97/8~	Wheel Hub FRONT
03901 7639	04422-21010	Kit	CALDINA ST215 GTT	97/8~	Wheel Hub FRONT
03901 1359	04445-20200		CALDINA CT196	92/11~96/1	Steering (P/S) R&P GASKET KIT
03901 4127	90311-38020	38 x 55 x 8.5	CALDINA AT191,CT190,196,197,ET196,ST19#	92/11~99/3	Mission & Differential (A/T) FRONT OIL PUMP
03901 3569	90311-52005	52 x 75 x 7.5 x 12	CALDINA CT216,ST215 (4WD)	97/8~	Wheel Hub REAR OUTER
03901 2739	90311-34012	34 x 54 x 9 x 15.5	CALDINA ET196 3FC	92/11~98/3	Mission & Differential (A/T) DIFF. SIDE
03901 1825	90311-25011	25 x 37 x 8	CALDINA AT191,211,ET196 5F	92/11~	Mission & Differential (M/T) INPUT SHAFT
03901 2297	90311-38064	38 x 55 x 8.7	CALDINA ET196	99/3~	Mission & Differential (A/T) FRONT OIL PUMP
03901 6965	90311-34012	34 x 54 x 9 x 15.5	CALDINA ET196 3FC	92/11~83/3	Mission & Differential (A/T) TRANSAXLE CASE
03901 5453	04445-20161		CALDINA AT191,CT190,198,199,ST19#...TOYODAKOKI	92/11~	Steering (P/S) R&P GASKET KIT
03901 6671	04445-20161		CALDINA AT211,CT216,ST215 TOYODAKOKI G/B	97/8~	Steering (P/S) R&P GASKET KIT
03901 7425	04445-20170		CALDINA ET196	92/11~96/1	Steering (P/S) R&P GASKET KIT
03901 4999	90311-38020	38 x 55 x 8.5	CALDINA AT211,CT216,ST21#	97/8~	Mission & Differential (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3967	90311-38020	38 x 55 x 8.5	CALDINA CT197,ST198	99/3~	Mission & Differential (A/T) FRONT OIL PUMP
03901 5393	04422-12060	Kit	CALDINA CT19#,ET196,ST19#...WITH OUT ABS	92/11~	Wheel Hub FRONT
03901 7771	90311-34022	34 x 56 x 9 x 15	CALDINA ET196 3FC	98/3~	Mission & Differential (A/T) DIFF.SIDE
03901 5631	04445-20170		CALDINA AT191,ST191 TOYOTA G/B	96/4~97/8	Steering (P/S) R&P GASKET KIT
03901 5313	90311-34012	34 x 54 x 915.5	CALDINA AT191,211 4FC	96/1~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4745	90311-34016	34 x 54 x 9 x 15.5	CALDINA ET196 3FC	83/3~	Mission & Differential (A/T) TRANSAXLE CASE
03901 2809	90311-34013	34 x 63 x 9 x 15	CALDINA AT191,211 4FC	96/1~97/8	Mission & Differential (A/T) TRANSAXLE CASE
03901 3295	90311-35020	35 x 63 x 9 x 15.5	CALDINA CT190,196,197,ST190,191 4FC	92/11~99/8	Mission & Differential (A/T) TRANSAXLE CASE
03901 1965	90311-50011	50 x 80 x 16.5 x 23	CALDINA ST215 4FC GTT	97/11~	Mission & Differential (A/T) DIFF.SIDE
03901 1421	90311-35020	35 x 63 x 9 x 15.5	CALDINA CT216,ST21#...4FC (E,G,GT)	97/8~	Mission & Differential (A/T) TRANSAXLE CASE
03901 2269	90311-62004	62 x 74 x 8.5	CALDINA ST215 4FC GTT	97/11~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1117	90311-35033	35 x 55 x 9 x 15.5	CALDINA CT190,196,197,ST190,191 4FC	92/11~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4605	90311-35033	35 x 55 x 9 x 15.5	CALDINA ST210	97/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1563	90311-49002	50 x 64 x 8	CALDINA CT216,ST215 4FC (E,G,GT)	97/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3323	04445-20170		CALDINA AT211,ST210 TOYOTA G/B	97/8~	Steering (P/S) R&P GASKET KIT
03901 4841	90311-35020	35 x 63 x 9 x 15.5	CALDINA CT197 4FC	99/8~	Mission & Differential (A/T) TRANSAXLE CASE
03901 2255	90043-11292-000	73.5 x 89 x 8.5	CAMI K3V#...J102,122	00/5~	Engine CRANK SHAFT REAR
03901 1001	90043-11310-000	34 x 55 x 12 x 18	CAMI J10#...EFI	99/5~	Final Drive PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2197	90048-12021-000		CAMI K3V#	00/5~	Engine VALVE STEM SEAL
03901 5137	90048-12011-000		CAMI HCEJ	99/5~	Engine VALVE STEM SEAL
03901 3047	90311-35040	35 x 49 x 6	CAMI K3V#...J102,122	00/5~	Engine TIMING GEAR COVER
03901 4895	90043-11345-000	32 x 48 x 5	CAMI HCEJ J100	99/5~	Engine CRANK SHAFT FRONT
03901 2651	90043-11342-000	40 x 65 x 11.5 x 18	CAMI J102 TURBO,J122	00/5~	Final Drive PINION
03901 7319	90043-11285-000	36 x 52 x 8	CAMI J122 5F	99/5~	Transmission EXTENTION
03901 3553	90043-10035-000	25 x 35 x 6	CAMI J10#,122 5F	99/5~	Transmission FRONT
03901 5859	90043-11291-000	40 x 56 x 8	CAMI J10#,122	99/5~	Wheel Hub REAR
03901 5067	90311-80003	80 x 100 x 8.5	CAMI HCEJ J100	99/5~	Engine CRANK SHAFT REAR
03901 1723	90043-11229-000	38 x 50 x 8	CAMI HCEJ J100	99/5~	Engine CAM SHAFT
03901 2749	90913-02101		CAMRY GRACIA 2MZFE (IN.)	96/12~	Engine VALVE STEM SEAL
03901 3311	15165-70010	18 x 30 x 7	CAMRY GRACIA 5SFE SXV2#	96/12~	Engine OIL PUMP
03901 3515	90311-42035	42 x 60 x 7	CAMRY GRACIA 5SFE SXV2#	96/12~	Engine CRANK SHAFT FRONT
03901 6687	90311-92008	92 x 110 x 9	CAMRY GRACIA 2MZFE MCV2#	96/12~	Engine CRANK SHAFT REAR
03901 3293	90311-85007	85 x 105 x 10	CAMRY GRACIA 5SFE SXV2#	96/12~	Engine CRANK SHAFT REAR
03901 1819	90311-35033	35 x 55 x 9 x 15.5	CAMRY GRACIA SXV20	96/12~	Mission & Differential (A/T) TRANSAXLE CASE
03901 4829	90913-02079		CAMRY GRACIA 5SFE (IN.)	96/12~	Engine VALVE STEM SEAL
03901 4869	90913-02062		CAMRY GRACIA 5SFE (EX.)	96/12~	Engine VALVE STEM SEAL
03901 3263	90913-02111		CAMRY GRACIA 2MZFE (EX.)	96/12~	Engine VALVE STEM SEAL
03901 5849	90311-40022	40 x 55 x 6	CAMRY GRACIA 2MZFE MCV2#	96/12~	Engine OIL PUMP
03901 7365	90311-52005	52 x 75 x 7.5 x 12	CAMRY GRACIA MCV25,SXV25 (4WD)	97/6~	Wheel Hub REAR OUTER
03901 6913	04445-32051		CAMRY GRACIA MCV21,SXV20 WAGON	96/12~	Steering (P/S) R&P GASKET KIT
03901 1249	90311-38036	38 x 50 x 8	CAMRY GRACIA 5SFE SXV2#	96/12~	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6373	90311-54005	55 x 70 x 10	CAMRY GRACIA MCV25,SXV25 (4WD)	97/6~	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 5425	90311-40010	40 x 56 x 9 x 15.5	CAMRY GRACIA MCV21	96/12~	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 7393	90311-56015	56 x 75 x 7 x 12	CAMRY GRACIA MCV25,SXV25 (4WD)	97/6~	Wheel Hub REAR INNER
03901 5765	90311-35033	35 x 55 x 9 x 15.5	CAMRY GRACIA SXV20	96/12~	Mission & Differential (A/T) DIFF. SIDE
03901 6107	90311-50011	50 x 80 x 16.5 x 23	CAMRY GRACIA MCV2#	96/12~	Mission & Differential (A/T) DIFF. SIDE
03901 3059	90311-38020	38 x 55 x 8.5	CAMRY GRACIA MCV2#,SXV2#	96/12~	Mission & Differential (A/T) FRONT OIL PUMP
03901 2341	90311-38034	38 x 50 x 10.5	CAMRY GRACIA 2MZFE MCV2#	96/12~	Engine CAM SHAFT
03901 3773	04445-33070		CAMRY GRACIA MCV21,SXV20 SEDAN	96/12~	Steering (P/S) R&P GASKET KIT
03901 2195	04445-33080		CAMRY GRACIA MCV25,SXV25	97/6~	Steering (P/S) R&P GASKET KIT
03901 5597	90311-26003	26 x 38 x 6.5	CAMRY GRACIA MCV2#,SXV2#	96/12~	Steering (P/S) CONTROL VALVE LOWER
03901 1363	90311-19010	19 x 32 x 6	CAMRY GRACIA MCV21,SXV20	96/12~	Steering (P/S) CONTROL VALVE UPPER
03901 4545	90311-50022	42 x 62 x 8.5 x 15.4	CAMRY GRACIA SXV25	97/6~	Mission & Differential (A/T) DIFF. SIDE
03901 6447	90311-38025	38 x 50 x 6	CAMRY, VISTA 1CT,2CT CV10,20,30	85/1~94/	Engine CAM SHAFT
03901 6091	90311-42003	42 x 60 x 7	CAMRY, VISTA 1S#,2S#,3S#,4S#...SV1#,2#	82/3~90/	Engine CRANK SHAFT FRONT
03901 4935	90311-38059	38 x 50 x 8	CAMRY, VISTA 1ZZFE ZZV50	98/6~	Engine TIMING GEAR COVER
03901 1565	90311-40022	40 x 55 x 6	CAMRY, VISTA 1VZFE,4VZFE VZV20,3#	87/4~94/	Engine OIL PUMP
03901 3951	90029-21022	22 x 34 x 6.5	CAMRY, VISTA 2CT,3CT CV20,30,4#	89/5~98/	Engine OIL PUMP
03901 2879	90029-21020	20325 x x	CAMRY, VISTA 1CT,2CT CV1#,20	85/5~89/5	Engine OIL PUMP
03901 4031	15165-64010	20 x 32 x 7	CAMRY, VISTA 1CT CV10	82/3~85/5	Engine OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7061	15165-70010	18 x 30 x 7	CAMRY, VISTA 1S#,2S#,3S#,4S#...SV1#,2#,3 #,4#,5#	82/3~	Engine OIL PUMP
03901 2099	90311-38067	38 x 50 x 8	CAMRY, VISTA 3SF#...SV5#	98/6~	Engine CAM SHAFT
03901 1575	90311-38044	38 x 50 x 6	CAMRY, VISTA 3CT CV4#	94/6~98/	Engine CAM SHAFT
03901 7371	90311-38036	38 x 50 x 8	CAMRY, VISTA 1CT CV10	82/3~85/1	Engine CAM SHAFT
03901 7219	90311-42026	42 x 60 x 7	CAMRY, VISTA 3S#,4S#...SV3#,4#	90/7~98/	Engine CRANK SHAFT FRONT
03901 5463	90311-90005	90 x 110 x 8.5 x 10	CAMRY, VISTA 2CT,3CT CV30,4#	90/7~98/	Engine CRANK SHAFT REAR
03901 2947	90310-25032	25 x 35 x 6	CAMRY, VISTA SV5#,ZZV50	98/6~	Steering (P/S) CONTROL VALVE LOWER
03901 6767	90311-38067	38 x 50 x 8	CAMRY, VISTA 3SFE,4SFE 4#	97/8~98/	Engine CAM SHAFT
03901 4633	90311-38036	38 x 50 x 8	CAMRY, VISTA 3SFE,4SFE SV2#,3#,4#	86/8~97/8	Engine CAM SHAFT
03901 1945	90311-38036	38 x 50 x 8	CAMRY, VISTA 1S#,2S#...SV1#,20	82/3~88/	Engine CAM SHAFT
03901 4689	90311-38034	38 x 50 x 10.5	CAMRY, VISTA 1VZFE,4VZFE VZ20,3#	87/4~94/	Engine CAM SHAFT
03901 2029	90913-02062		CAMRY, VISTA 3S#,4S# (EX.)	88/8~98/	Engine VALVE STEM SEAL
03901 1991	90913-02095		CAMRY, VISTA 4VZFE(IN.)	91/5~98/	Engine VALVE STEM SEAL
03901 7475	90913-02062		CAMRY, VISTA 4VZFE(EX.)	91/5~98/	Engine VALVE STEM SEAL
03901 4495	90913-02062		CAMRY, VISTA 1VZFE(IN. & EX.)	88/8~92/	Engine VALVE STEM SEAL
03901 2441	90913-02110		CAMRY, VISTA 1CT,2CT,3CT,(IN. & EX.)	82/3~98/	Engine VALVE STEM SEAL
03901 1207	90913-02111		CAMRY, VISTA 3SFSE(EX.) SV50,1ZZFE(EX.)	98/6~	Engine VALVE STEM SEAL
03901 6117	90913-02101		CAMRY, VISTA 3SFSE(IN.) SV50,1ZZFE(IN.)	98/6~	Engine VALVE STEM SEAL
03901 5161	90913-02079		CAMRY, VISTA 3SFE(IN.) SV55	98/6~	Engine VALVE STEM SEAL
03901 3607	90913-02079		CAMRY, VISTA 3S#,4S#(IN.)	90/7~98/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3947	90311-85007	85 x 105 x 10	CAMRY, VISTA 3SF#,4SFE SV3#,4#,5#	90/10~	Engine CRANK SHAFT REAR
03901 3685	90913-02062		CAMRY, VISTA 3SFE(EX.) SV55	98/6~	Engine VALVE STEM SEAL
03901 5221	90311-42035	42 x 60 x 7	CAMRY, VISTA 3SF#...SV5#	98/6~	Engine CRANK SHAFT FRONT
03901 1357	90913-02056		CAMRY, VISTA 1S#,2S# (IN. & EX.)	82/3~88/	Engine VALVE STEM SEAL
03901 4683	90311-76001	76 x 94 x 8.5	CAMRY, VISTA 1ZZFE ZZV50	98/6~	Engine CRANK SHAFT REAR
03901 6663	90311-89001	89 x 105 x 10	CAMRY, VISTA 3SGE SV21,32,33	89/7~92/	Engine CRANK SHAFT REAR
03901 7581	90311-92005	92 x 110 x 10	CAMRY, VISTA 1VZFE,4VZFE VZV20,3#	87/4~94/	Engine CRANK SHAFT REAR
03901 5733	90311-90003	90 x 110 x 8.5 x 10	CAMRY, VISTA 1CT,2CT CV10,20	82/3~90/	Engine CRANK SHAFT REAR
03901 3097	90311-85004	85 x 105 x 10	CAMRY, VISTA 1S#,2S#,3SFE,4SFE SV1#,2#,3#	82/3~90/1 0	Engine CRANK SHAFT REAR
03901 3135	90311-42026	42 x 60 x 7	CAMRY, VISTA 2CT,3CT CV30,4#	90/7~98/	Engine CRANK SHAFT FRONT
03901 5937	90311-42015	42 x 60 x 6	CAMRY, VISTA 1CT,2CT CV1#,20	85/5~90/	Engine CRANK SHAFT FRONT
03901 2397	90311-42003	42 x 60 x 7	CAMRY, VISTA 1CT CV10	82/3~85/5	Engine CRANK SHAFT FRONT
03901 7263	90913-02062		CAMRY, VISTA 3S#,4S#(IN.)	88/8~90/7	Engine VALVE STEM SEAL
03901 6407	90311-35033	35 x 55 x 9 x 15.5	CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4 0	82/3~98/	Mission & Differential (M/T) DIFF.SIDE
03901 5249	90311-40010	40 x 56 x 9 x 15.5	CAMRY, VISTA VZV3#	90/7~94/	Mission & Differential (A/T) DIFFERENTIAL
03901 2837	90311-49002	50 x 64 x 8	CAMRY, VISTA SV55	98/6~	Mission & Differential (A/T) DIFF.SIDE
03901 8099	90311-50011	50 x 80 x 16.5 x 23	CAMRY, VISTA VZV3#	90/7~94/	Mission & Differential (A/T) DIFF.SIDE
03901 1691	90311-44003	44 x 80 x 9 x 15.5	CAMRY, VISTA SV25,35,43,CV43 (4WD)	87/10~98	Mission & Differential (A/T) DIFF.SIDE
03901 3307	90311-35033	35 x 55 x 9 x 15.5	CAMRY, VISTA SV50,ZZV50	98/6~	Mission & Differential (A/T) DIFF.SIDE
03901 5619	90311-35033	35 x 55 x 9 x 15.5	CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4 0,VZV20 2WD	82/3~98/	Mission & Differential (A/T) DIFF.SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4041	90311-35033	35 x 55 x 9 x 15.5	CAMRY, VISTA SV5#,ZZV50	98/6~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1479	90311-40004	40 x 56 x 9 x 15.5	CAMRY, VISTA VZV20,30,31	87/4~94/	Mission & Differential (M/T) TRANSAXLE CASE COVER
03901 6921	90311-50010	50 x 80 x 16.5 x 23	CAMRY, VISTA VZV20,30,31	87/4~94/	Mission & Differential (M/T) TRANSMISSION CASE
03901 5103	90311-50010	50 x 80 x 16.5 x 23	CAMRY, VISTA SV25 ABS	87/10~90/	Mission & Differential (M/T) TRANSMISSION CASE
03901 6139	90311-38020	38 x 55 x 8.5	CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4 #,VZV20,3#	82/3~98/	Mission & Differential (A/T) FRONT OIL PUMP
03901 7293	90311-44003	44 x 80 x 9 x 15.5	CAMRY, VISTA SV25 WITHOUT ABS	87/10~90/	Mission & Differential (M/T) TRANSMISSION CASE
03901 7381	90311-35033	35 x 55 x 9 x 15.5	CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4 0,VZV20 2WD	82/3~98/	Mission & Differential (A/T) TRANSAXLE CASE
03901 6855	90311-35033	35 x 55 x 9 x 15.5	CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4 0	82/3~98/	Mission & Differential (M/T) TRANSAXLE CASE
03901 2509	90311-30006	30 x 42 x 7	CAMRY, VISTA SV1#,2#,3#,4#,CV10,20,30,4 0,VZV20	82/3~98/	Mission & Differential (M/T) INPUT SHAFT
03901 1481	90311-52005	52 x 75 x 7.5 x 12	CAMRY, VISTA SV25,35,43,CV43 (4WD)	87/10~98	Wheel Hub REAR OUTER
03901 6513	90311-56007	56 x 75 x 6.5 x 11	CAMRY, VISTA SV25,35,43,CV43 (4WD)	87/10~98	Wheel Hub REAR INNER
03901 7969	90311-42018	42 x 55 x 6	CAMRY, VISTA SV33,VZV33	92/6~94	Wheel Hub REAR
03901 2123	90311-42018	42 x 55 x 6	CAMRY, VISTA SV3#,CV30,VZV3#	90/7~92/6	Wheel Hub REAR
03901 6991	90311-42018	42 x 55 x 6	CAMRY, VISTA SV1#,20,21,22,CV10,20,VZ V20	82/3~90	Wheel Hub REAR
03901 7451	04422-32010	Kit	CAMRY, VISTA SV1#,2#,CV10,20,VZV20	82/3~90	Wheel Hub FRONT
03901 6235	90310-30013	30 x 41 x 6.5	CAMRY, VISTA SV32,VZV30,32 ZX,VX,PRO	90/7~94/	Steering (P/S) CONTROL VALVE LOWER
03901 8065	90311-35013	35 x 49 x 6	CAMRY, VISTA 3SGE SV21,32,33	86/8~94/	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5343	90311-44003	44 x 80 x 9 x 15.5	CAMRY, VISTA SV35,43	90/7~98/	Mission & Differential (M/T) TRANSMISSION CASE
03901 2481	90310-28003	28 x 41 x 6.5	CAMRY, VISTA SV1#,CV11	85/8~86/	Steering (P/S) CONTROL VALVE LOWER
03901 4997	90310-30013	30 x 41 x 6.5	CAMRY, VISTA SV21 ZX,GT,VX,VZV20	86/8~90/	Steering (P/S) CONTROL VALVE LOWER
03901 5945	90310-28003	28 x 41 x 6.5	CAMRY, VISTA CV30,4#,VZV31,33	90/7~98/	Steering (P/S) CONTROL VALVE LOWER
03901 5941	90310-28003	28 x 41 x 6.5	CAMRY, VISTA SV2#,CV20 XT,ZT,ZE,GT,VL,VE,VR	86/8~90/	Steering (P/S) CONTROL VALVE LOWER
03901 5127	90311-38020	38 x 55 x 8.5	CAMRY, VISTA SV5#,ZZV50	98/6~	Mission & Differential (A/T) FRONT OIL PUMP
03901 6979	90310-28003	28 x 41 x 6.5	CAMRY, VISTA SV11,12,CV10	82/8~85/8	Steering (P/S) CONTROL VALVE LOWER
03901 4835	90310-31001	31 x 44 x 6.5	CAMRY, VISTA SV10	82/7~85/	Steering (P/S) CONTROL VALVE LOWER
03901 7345	90311-20008	20 x 34 x 7	CAMRY, VISTA SV5#,ZZV50	98/6~	Steering (P/S) CONTROL VALVE UPPER
03901 7739	90311-19002	19 x 32 x 7 x 8	CAMRY, VISTA SV1#,2#,3#,4#,CV1#,20,30,4 #,VZV3#	82/3~98/	Steering (P/S) CONTROL VALVE UPPER
03901 2999	04445-32081		CAMRY, VISTA SV5#,ZZV50	98/6~	Steering (P/S) R&P GASKET KIT
03901 6289	04445-32070		CAMRY, VISTA SV42	94/6~98/	Steering (P/S) R&P GASKET KIT
03901 5035	04445-32070		CAMRY, VISTA SV33,VZV31,33	90/7~94/	Steering (P/S) R&P GASKET KIT
03901 1297	04445-32061/60		CAMRY, VISTA SV32,VZV30,32 ZX,VX,PRO	90/7~94/	Steering (P/S) R&P GASKET KIT
03901 6935	04445-32051		CAMRY, VISTA CV4#,SV40,41,43	94/6~98/	Steering (P/S) R&P GASKET KIT
03901 2407	04445-32041		CAMRY, VISTA SV21 ZX,GT,VX,VZV20	86/8~90/	Steering (P/S) R&P GASKET KIT
03901 7813	90311-15001	15 x 25 x 7	CAMRY, VISTA SV10,20 LT,VC	82/3~98/	Steering (M/S) RACK HOUSING
03901 5045	04445-32011/10		CAMRY, VISTA SV10	82/8~85/8	Steering (P/S) R&P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7191	04445-32051		CAMRY, VISTA SV30,32(LUM,GT,VE,ETO), 35,CV30	90/7~94/	Steering (P/S) R&P GASKET KIT
03901 6449	04445-32030		CAMRY, VISTA SV2#,CV20 XT,ZT,ZE,GT,VL,VE,VR	86/8~90/	Steering (P/S) R&P GASKET KIT
03901 6563	04445-32020		CAMRY, VISTA SV1#,CV11	85/8~86	Steering (P/S) R&P GASKET KIT
03901 3567	04445-32020		CAMRY, VISTA SV11,12,CV10	82/8~85/8	Steering (P/S) R&P GASKET KIT
03901 5983	90310-28003	28 x 41 x 6.5	CAMRY, VISTA SV30,329LUM,GT,VE,ETO) ,33,35,4#	90/7~98/	Steering (P/S) CONTROL VALVE LOWER
03901 1097	04422-20080	Kit	CARINA (FWD) SEDAN AT19#,ST19#,CT19#...WITH ABS	92/8~96/	Wheel Hub FRONT
03901 1525	90310-23005	23 x 34 x 6.5	CARINA (FWD) SEDAN AT15#,ST150,CT150 TOYOTA G/B	84/5~88/	Steering (P/S) CONTROL VALVE LOWER
03901 3937	90311-19002	19 x 32 x 7 x 8	CARINA (FWD) SEDAN ST17#,19#,215	87/12~	Steering (P/S) CONTROL VALVE UPPER
03901 7975	90311-19002	19 x 32 x 7 x 8	CARINA (FWD) SEDAN AT17#,19#,21#,CT17#,19#,2 1#	87/12~	Steering (P/S) CONTROL VALVE UPPER
03901 2925	90311-19002	19 x 32 x 7 x 8	CARINA (FWD) SEDAN AT15#,160,ST150,162,CT15 0 TOYODAKOKI	84/5~88/	Steering (P/S) CONTROL VALVE UPPER
03901 6983	04422-20010	Kit	CARINA (FWD) SEDAN AT15#,160,ST150,162,CT15 0	84/5~89/	Wheel Hub FRONT
03901 5649	04422-20010	Kit	CARINA (FWD) SEDAN AT17#,ST17#,CT17#,ET17#	88/5~92/	Wheel Hub FRONT
03901 3759	90311-42018	42 x 55 x 6	CARINA (FWD) SEDAN AT15#,160,ST150,16#,CT15 0	84/5~89/	Wheel Hub REAR
03901 4153	04422-12060	Kit	CARINA (FWD) SEDAN AT19#,ST19#,CT19#...WITH OUT ABS	92/8~96/	Wheel Hub FRONT
03901 2243	90311-48001	48 x 62 x 9	CARINA (FWD) SEDAN CT176,ET176	88/5~92/	Wheel Hub REAR
03901 1379	04422-20080	Kit	CARINA (FWD) SEDAN AT21#,ST215,CT21#	96/8~	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7809	90310-25004	25 x 38 x 7 x 8	CARINA (FWD) SEDAN AT15#,160,ST150,162,CT15 0 TOYODAKOKI	84/5~88/	Steering (P/S) CONTROL VALVE LOWER
03901 7551	90311-52005	52 x 75 x 7.5 x 12	CARINA (FWD) SEDAN AT175,ST195,CT195 (4WD)	88/8~96	Wheel Hub REAR OUTER
03901 1477	90310-28003	28 x 41 x 6.5	CARINA (FWD) SEDAN AT211(TOYOTA G/B0,212	96/8~	Steering (P/S) CONTROL VALVE LOWER
03901 4979	90311-56015	56 x 75 x 7 x 12	CARINA (FWD) SEDAN CT215,216,ST215 (4WD)	97/7~	Wheel Hub REAR INNER
03901 6287	90311-56007	56 x 75 x 6.5 x 11	CARINA (FWD) SEDAN CT215,ST215 (4WD)	96/8~97/7	Wheel Hub REAR INNER
03901 3919	90311-56007	56 x 75 x 6.5 x 11	CARINA (FWD) SEDAN AT175,ST195,CT195 (4WD)	88/8~96	Wheel Hub REAR INNER
03901 6277	90311-42018	42 x 55 x 6	CARINA (FWD) SEDAN AT170.171,CT170.ST170	88/5~92/	Wheel Hub REAR
03901 6977	90311-52005	52 x 75 x 7.5 x 12	CARINA (FWD) SEDAN CT215,216,ST215 (4WD)	96/8~	Wheel Hub REAR OUTER
03901 1475	90311-35003	35 x 49 x 6	CARINA (FWD) SEDAN 3E ET176	88/5~92/	Engine CAM SHAFT
03901 5627	90311-32020	32 x 46 x 6	CARINA (FWD) SEDAN 3A#,4A#,5A#,7A#...AT15#,1 60,17#,19#,21#	84/5~	Engine OIL PUMP
03901 1847	90311-38044	38 x 50 x	CARINA (FWD) SEDAN 2C,3CTE CT21#	96/8~	Engine CAM SHAFT
03901 3799	90311-38044	38 x 50 x	CARINA (FWD) SEDAN 2C CT170,19#	90/10~96/	Engine CAM SHAFT
03901 7237	90311-38025	38 x 50 x 6	CARINA (FWD) SEDAN 2C CT150,170	85/1~90/1 0	Engine CAM SHAFT
03901 6553	90311-38067	38 x 50 x 8	CARINA (FWD) SEDAN 3SFE ST215	97/8~	Engine CAM SHAFT
03901 5517	90311-38036	38 x 50 x 8	CARINA (FWD) SEDAN 2C CT150	84/5~85/1	Engine CAM SHAFT
03901 6525	90311-38036	38 x 50 x 8	CARINA (FWD) SEDAN 1S#,3SFE,4S#...ST150,170,1 9#,215	84/5~97/7	Engine CAM SHAFT
03901 2027	90310-25004	25 x 38 x 7 x 8	CARINA (FWD) SEDAN AT210,211(TOYODAKOKI G/B),CT21#,ST215	96/8~	Steering (P/S) CONTROL VALVE LOWER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5893	90311-35003	35 x 49 x 6	CARINA (FWD) SEDAN 3SGLU ST162	85/8~88/	Engine CAM SHAFT
03901 7851	90310-25004	25 x 38 x 7 x 8	CARINA (FWD) SEDAN AT17#,ST17#,CT17#,ET176	87/12~92/	Steering (P/S) CONTROL VALVE LOWER
03901 6313	90311-35003	35 x 49 x 6	CARINA (FWD) SEDAN 4AGE(NO.1) AT210	96/8~	Engine CAM SHAFT
03901 6689	90311-35003	35 x 49 x 6	CARINA (FWD) SEDAN 5AFE,7AFE AT211,212	96/8~	Engine CAM SHAFT
03901 5821	90311-35003	35 x 49 x 6	CARINA (FWD) SEDAN 4A#,5A#,7A#...AT15#,17#,1 9#	84/5~96/	Engine CAM SHAFT
03901 2417	90311-30006	30 x 42 x 7	CARINA (FWD) SEDAN ST150,162,170,19#,CT150,1 7#,19#,AT175	84/5~96/	Mission & Differential (M/T) INPUT SHAFT
03901 3385	90310-28003	28 x 41 x 6.5	CARINA (FWD) SEDAN AT193,ST190	92/8~96/	Steering (P/S) CONTROL VALVE LOWER
03901 8193	15165-70010	18 x 30 x 7	CARINA (FWD) SEDAN 1S#,3S#,4S#...ST150,162,170 ,19#,215	84/5~	Engine OIL PUMP
03901 1445	90310-25004	25 x 38 x 7 x 8	CARINA (FWD) SEDAN CT19#,ST195	92/8~96/	Steering (P/S) CONTROL VALVE LOWER
03901 3923	90311-40015	40 x 54.5 x 7	CARINA (FWD) SEDAN 4AGE(NO.) AT210	96/8~	Engine CAM SHAFT
03901 7637	04445-20080		CARINA (FWD) SEDAN AT175,ST171	87/12~92/	Steering (P/S) R&P GASKET KIT
03901 4469	90311-34012	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN AT159 3FC	84/5~88/	Mission & Differential (A/T) DIFF. SIDE
03901 6485	90311-34012	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN ET176	87/12~92/	Mission & Differential (A/T) DIFF. SIDE
03901 3921	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN ST162	85/8~88/	Mission & Differential (A/T) DIFF. SIDE
03901 2353	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN ST17#	87/12~92/	Mission & Differential (A/T) DIFF. SIDE
03901 4995	90311-44003	44 x 80 x 9 x 15.5	CARINA (FWD) SEDAN ST195,215	92/8~98/8	Mission & Differential (A/T) DIFF. SIDE
03901 1211	90311-38020	38 x 55 x 8.5	CARINA (FWD) SEDAN AT15#,160,17#,19#,21#,CT1 50,17#,19#,21#	84/5~	Mission & Differential (A/T) FRONT OIL PUMP
03901 6773	90311-38020	38 x 55 x 8.5	CARINA (FWD) SEDAN ST150,162,17#,19#,215	84/5~	Mission & Differential (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6521	90311-15001	15 x 25 x 7	CARINA (FWD) SEDAN AT150,170,CT176,ET176	84/5~92/	Steering (M/S) RACK HOUSING
03901 6441	04445-12020		CARINA (FWD) SEDAN AT15#,ST150,CT150 TOYOTA G/B	84/5~88/	Steering (P/S) R&P GASKET KIT
03901 7203	90311-25011	25 x 37 x 8	CARINA (FWD) SEDAN AT15#,160,170,171,19#,ET1 76	84/5~96/	Mission & Differential (M/T) INPUT SHAFT
03901 5949	04445-20070		CARINA (FWD) SEDAN AT170,CT17#,ST170,ET176	87/12~92/	Steering (P/S) R&P GASKET KIT
03901 7613	90311-34016	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN AT21#	99/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3277	04445-20140		CARINA (FWD) SEDAN CT190 SG	92/8~96/	Steering (P/S) R&P GASKET KIT
03901 2561	04445- 20160/1		CARINA (FWD) SEDAN CT190 SE,CT195,ST195	92/8~96/	Steering (P/S) R&P GASKET KIT
03901 2175	04445- 20160/1		CARINA (FWD) SEDAN AT210,211(TOYODAKOKI G/B),CT21#,ST215	96/8~	Steering (P/S) R&P GASKET KIT
03901 7847	04445-20170		CARINA (FWD) SEDAN AT19#,ST190	92/8~96/	Steering (P/S) R&P GASKET KIT
03901 3635	04445-20170		CARINA (FWD) SEDAN AT211(TOYOTA G/B)	98/8~	Steering (P/S) R&P GASKET KIT
03901 7721	04445-20210		CARINA (FWD) SEDAN AT211(TOYOTA G/B)	96/8~98/8	Steering (P/S) R&P GASKET KIT
03901 3903	04445-20210		CARINA (FWD) SEDAN AT212	96/8~	Steering (P/S) R&P GASKET KIT
03901 4275	04445-20240		CARINA (FWD) SEDAN CT210,211	96/8~	Steering (P/S) R&P GASKET KIT
03901 4823	04445-20250		CARINA (FWD) SEDAN AT210	96/8~	Steering (P/S) R&P GASKET KIT
03901 8171	04445- 20030/1		CARINA (FWD) SEDAN AT15#,160,ST,150,162,CT15 0 TOYODAKOKI	84/5~88/	Steering (P/S) R&P GASKET KIT
03901 5443	90311-34012	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN AT150 3FC	84/5~88/	Mission & Differential (A/T) TRANSAXLE CASE
03901 7977	90029-21022	22 x 34 x 6.5	CARINA (FWD) SEDAN 2C CT17#,19#	89/5~96/	Engine OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7255	90311-30006	30 x 42 x 7	CARINA (FWD) SEDAN CT210,211,215,ST215	96/8~	Mission & Differential (M/T) INPUT SHAFT
03901 6931	90311-34016	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN AT15#,160,170,171,19#,ET1 76	84/5~96/ 76	Mission & Differential (M/T) TRANSAXLE CASE
03901 5675	90311-34016	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN AT21#	96/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 5495	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN ST150,162,170,190,CT150,1 7#,190	84/5~96/ 76	Mission & Differential (M/T) TRANSAXLE CASE
03901 7941	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN CT210,211	96/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 1701	90311-49002	50 x 64 x 8	CARINA (FWD) SEDAN ST215	96/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 4271	90311-34017	34 x 63 x 9 x 16	CARINA (FWD) SEDAN AT15#,160,170,171,19#,ET1 76	84/5~	Mission & Differential (M/T) TRANSMISSION CASE
03901 1333	90311-34017	34 x 63 x 9 x 16	CARINA (FWD) SEDAN AT21#	96/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 1261	90311-49002	50 x 64 x 8	CARINA (FWD) SEDAN CT216,ST215	98/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 6177	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN CT210,211,ST215	96/8~	Mission & Differential (M/T) DIFF. SIDE
03901 1491	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN ST150,190,CT150,17#,190,2 10,211	84/5~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4923	90311-34012	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN ET176	87/12~92	Mission & Differential (A/T) TRANSAXLE CASE
03901 1031	90311-34013	34 x 63 x 9 x 15	CARINA (FWD) SEDAN AT150 4FC	84/5~88/ 76	Mission & Differential (A/T) TRANSAXLE CASE
03901 1891	90311-34013	34 x 63 x 9 x 15	CARINA (FWD) SEDAN AT151,160,170,171,19#,21#	84/5~	Mission & Differential (A/T) TRANSAXLE CASE
03901 4795	90311-35020	35 x 63 x 9 x 15.5	CARINA (FWD) SEDAN ST150,190,215	84/5~	Mission & Differential (A/T) TRANSAXLE CASE
03901 8177	90311-35020	35 x 63 x 9 x 15.5	CARINA (FWD) SEDAN CT150,17#,190,213	84/5~	Mission & Differential (A/T) TRANSAXLE CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7513	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN ST162	85/8~88/	Mission & Differential (A/T) TRANSAXLE CASE
03901 5145	90311-35033	35 x 55 x 9 x 15.5	CARINA (FWD) SEDAN ST17#	87/12~92/	Mission & Differential (A/T) TRANSAXLE CASE
03901 5749	90311-44003	44 x 80 x 9 x 15.5	CARINA (FWD) SEDAN AT175 (4WD0	88/8~92/	Mission & Differential (A/T) TRANSAXLE CASE
03901 5171	90311-34012	34 x 54 x 9 x 15.5	CARINA (FWD) SEDAN AT15#,(4FC),160,170,19#,21 #	84/5~99/8	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 6421	90311-25011	25 x 37 x 8	CARINA (FWD) SEDAN AT21#	96/8~	Mission & Differential (M/T) INPUT SHAFT
03901 2483	90311-44003	44 x 80 x 9 x 15.5	CARINA (FWD) SEDAN AT175,CT195,215,ST195,21 5 (4WD)	88/8~98/8	Mission & Differential (M/T) TRANSMISSION CASE
03901 8211	90913-02062		CARINA (FWD) SEDAN 4AGE(EX.) AT171	89/3~92/8	Engine VALVE STEM SEAL
03901 1111	90311-85007	85 x 105 x 10	CARINA (FWD) SEDAN 3S#,4S#...ST170,19#,215	90/10~	Engine CRANK SHAFT REAR
03901 3273	90311-80003	80 x 100 x 8.5	CARINA (FWD) SEDAN 3E ET176	88/5~91/8	Engine CRANK SHAFT REAR
03901 3255	90311-80012	80 x 100 x 8.5	CARINA (FWD) SEDAN 3E ET176	91/8~92/	Engine CRANK SHAFT REAR
03901 3905	90311-90003	90 x 110 x 8.5 x 10	CARINA (FWD) SEDAN 2C CT150,170	84/5~90/2	Engine CRANK SHAFT REAR
03901 6529	90311-90005	90 x 110 x 8.5 x 10	CARINA (FWD) SEDAN 2C CT170,19#,21#	90/2~96/1 2	Engine CRANK SHAFT REAR
03901 3549	90311-90008	90 x 110 x 9.8 x 11.5	CARINA (FWD) SEDAN 2C,3C CT21#	96/12~	Engine CRANK SHAFT REAR
03901 3343	90913-02038		CARINA (FWD) SEDAN 3ALU,4AELU AT15#	84/5~88/4	Engine VALVE STEM SEAL
03901 7271	90913-02062		CARINA (FWD) SEDAN 4AFE,5A#(IN. &EX.) AT17#	88/5~90/1 0	Engine VALVE STEM SEAL
03901 4327	90311-85004	85 x 105 x 10	CARINA (FWD) SEDAN 1S#,3S#,4S#...ST150,162,170	84/5~90/1 0	Engine CRANK SHAFT REAR
03901 5831	90913-02062		CARINA (FWD) SEDAN 4AGE AT171	88/5~89/3	Engine VALVE STEM SEAL
03901 4787	90913-02062		CARINA (FWD) SEDAN 4F#,5AFE,7AFE(EX.) AT17#,19#,21#	90/10~	Engine VALVE STEM SEAL
03901 3529	90913-02079		CARINA (FWD) SEDAN 4AGE(IN.) AT171	89/3~92/8	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3619	90913-02093		CARINA (FWD) SEDAN 4AGE(IN. & EX.) AT210	96/8~	Engine VALVE STEM SEAL
03901 1355	90913-02056		CARINA (FWD) SEDAN 1SILU ST150	84/5~87/9	Engine VALVE STEM SEAL
03901 5537	90913-02094		CARINA (FWD) SEDAN 1SILU ST150	87/9~88/	Engine VALVE STEM SEAL
03901 5091	90913-02062		CARINA (FWD) SEDAN 3SGELU(IN. & EX.) ST162	85/8~88/	Engine VALVE STEM SEAL
03901 6049	90913-02062		CARINA (FWD) SEDAN ASF(IN. & EX.) ST170	88/5~90/3	Engine VALVE STEM SEAL
03901 1595	15165-64010	20 x 32 x 7	CARINA (FWD) SEDAN 2CL CT150	84/5~85/5	Engine OIL PUMP
03901 2207	90029-21020	20 x 32 x 5	CARINA (FWD) SEDAN 2C CT150,17#	85/5~89/5	Engine OIL PUMP
03901 2109	90913-02079		CARINA (FWD) SEDAN 4F#,5AFE,7AFE(IN.) AT17#,19#,21#	90/10~	Engine VALVE STEM SEAL
03901 4035	90913-02094		CARINA (FWD) SEDAN 2C CT17#,19#	90/11~96/	Engine VALVE STEM SEAL
03901 6639	90029-21020	20 x 32 x 5	CARINA (FWD) SEDAN 3E ET176	88/5~92/	Engine OIL PUMP
03901 4297	90913-02062		CARINA (FWD) SEDAN 4AGELU AT160	85/8~88/4	Engine VALVE STEM SEAL
03901 3753	90311-70007	70 x 92 x 8.5	CARINA (FWD) SEDAN 4A#,5A#,7A#...AT17#,19#,21#	91/6~	Engine CRANK SHAFT REAR
03901 5933	90311-42026	42 x 60 x 7	CARINA (FWD) SEDAN 3S#,4S#...ST170,19#,215	89/9~96/9	Engine CRANK SHAFT FRONT
03901 5195	90311-42035	42 x 60 x 7	CARINA (FWD) SEDAN 3SFE ST215	96/9~	Engine CRANK SHAFT FRONT
03901 6077	90311-42003	42 x 60 x 7	CARINA (FWD) SEDAN 2C CT150	84/5~85/1	Engine CRANK SHAFT FRONT
03901 6291	90913-02117		CARINA (FWD) SEDAN 2C,3C CT21#	97/4~	Engine VALVE STEM SEAL
03901 4673	90311-42003	42 x 60 x 7	CARINA (FWD) SEDAN 1S#,3S#,4S#...ST150,162,170	84/5~89/9	Engine CRANK SHAFT FRONT
03901 3795	90913-02110		CARINA (FWD) SEDAN 2C CT21#	96/8~97/4	Engine VALVE STEM SEAL
03901 5927	90913-02079		CARINA (FWD) SEDAN 3SFE,4SF#(IN.) ST170,19#,215	90/3~	Engine VALVE STEM SEAL
03901 8059	90913-02062		CARINA (FWD) SEDAN 3SFE,4SF#(EX.) ST170,19#,215	90/3~	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2699	90311-70004	70 x 92 x 8.5	CARINA (FWD) SEDAN 3A#,4A#,5A#...AT15#,17#	84/5~91/6	Engine CRANK SHAFT REAR
03901 7605	90311-19007	19 x 38 x 7	CARINA (FWD) SEDAN AT15#,ST150,CT150 TOYOTA G/B	84/5~88/	Steering (P/S) CONTROL VALVE UPPER
03901 1463	90913-02110		CARINA (FWD) SEDAN 2C CT150,17#	84/5~90/1 1	Engine VALVE STEM SEAL
03901 3831	90311-42015	42 x 60 x 6	CARINA (FWD) SEDAN 2C CT150,170	85/1~90/5	Engine CRANK SHAFT FRONT
03901 7253	90311-42026	42 x 60 x 7	CARINA (FWD) SEDAN 2C,3C CT170,19#,21#	90/5~	Engine CRANK SHAFT FRONT
03901 1613	90311-45002	45 x 68 x 12	CARINA (RWD) 18RGEU RA63	81/9~82/	Engine TIMING GEAR COVER
03901 2543	90311-32020	32 x 46 x 6	CARINA (RWD) 3AU,4AGEU AA6#	81/9~88/	Engine OIL PUMP
03901 4145	15165-70010	18 x 30 x 7	CARINA (RWD) 1SU SA60	81/9~88/	Engine OIL PUMP
03901 5929	90029-21020	20 x 32 x 5	CARINA (RWD) 1C CA67	85/5~88/	Engine OIL PUMP
03901 3401	15165-64010	20 x 32 x 7	CARINA (RWD) 1C CA60,67	82/2~85/5	Engine OIL PUMP
03901 2005	90311-38022	38.5 x 58 x 8.5	CARINA (RWD) 12TJ TA67V	82/3~88/	Engine TIMING GEAR COVER
03901 7659	90311-38036	38 x 50 x 8	CARINA (RWD) 1SU SA60	81/9~88/	Engine CAM SHAFT
03901 1151	90311-42003	42 x 60 x 7	CARINA (RWD) 1SU SA60	81/9~88/	Engine CRANK SHAFT FRONT
03901 4429	90311-38036	38 x 50 x 8	CARINA (RWD) 1C CA60,67	82/2~85/1	Engine CAM SHAFT
03901 1311	90311-38025	38 x 50 x 6	CARINA (RWD) 1C CA67	85/1~88/	Engine CAM SHAFT
03901 3167	90311-35013	35 x 49 x 6	CARINA (RWD) 3AU,4AGEU AA60,63	81/9~87/	Engine CAM SHAFT
03901 1371	90311-42003	42 x 60 x 7	CARINA (RWD) 1C CA60,67	82/2~85/5	Engine CRANK SHAFT FRONT
03901 6073	90311-42015	42 x 60 x 6	CARINA (RWD) 1C CA67	85/5~88/	Engine CRANK SHAFT FRONT
03901 2957	90311-75114	75 x 100 x 13	CARINA (RWD) 3T,12T TA63,67V	81/9~85/	Engine CRANK SHAFT REAR
03901 5865	90311-80001	80 x 100 x 12	CARINA (RWD) 18RGEU RA63	81/9~82/	Engine CRANK SHAFT REAR
03901 3779	90311-70004	70 x 92 x 8.5	CARINA (RWD) 3AU,4AGEU AA6#	81/9~88/	Engine CRANK SHAFT REAR
03901 2781	90311-70004	70 x 92 x 8.5	CARINA (RWD) 5KJ KA67	83/8~88/	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7921	90311-85004	85 x 105 x 10	CARINA (RWD) 1SU SA60	81/9~88/	Engine CRANK SHAFT REAR
03901 1671	90311-38013	38.5 x 58 x 11	CARINA (RWD) 12TJ TA67V	81/9~82/3	Engine TIMING GEAR COVER
03901 3473	90311-48001	48 x 62 x 9	CARINA (RWD) AA63,TA61,63,RA63	81/9~85/	Wheel Hub FRONT
03901 1589	90913-02058		CARINA (RWD) 3T,13T EX.	81/9~83/	Engine VALVE STEM SEAL
03901 7503	90913-02024		CARINA (RWD) 3T,12T IN.	81/9~83/	Engine VALVE STEM SEAL
03901 4501	90311-90003	90 x 110 x 8.5 x 10	CARINA (RWD) 1C CA6#	82/2~88/	Engine CRANK SHAFT REAR
03901 5639	90913-02056		CARINA (RWD) 1SU	81/9~88/	Engine VALVE STEM SEAL
03901 6895	90311-38020	38 x 55 x 8.5	CARINA (RWD) AA60,TA63,67,SA60,KA67, CA60	81/9~88/	Transmission (A/T) FRONT OIL PUMP
03901 4071	90913-02056		CARINA (RWD) 5KJ	81/11~88/	Engine VALVE STEM SEAL
03901 7419	90913-02110		CARINA (RWD) 1C	82/2~88/	Engine VALVE STEM SEAL
03901 3051	90913-02038		CARINA (RWD) 3AU	81/9~88/	Engine VALVE STEM SEAL
03901 6621	90311-41123	41 x 53 x 7	CARINA (RWD) AA60,TA67,SA60,KA67,CA 6#	81/9~88/	Wheel Hub FRONT
03901 2425	90311-52059	52 x 65 x 9	CARINA (RWD) AA60,TA67,SA60,KA67,CA 6#	81/9~88/	Wheel Hub REAR
03901 7741	90311-48122	48 x 62 x 7	CARINA (RWD) TA61,63,RA63	81/9~83/5	Wheel Hub REAR OUTER
03901 5209	90311-48001	48 x 62 x 9	CARINA (RWD) AA63,TA63	83/5~85/	Wheel Hub REAR OUTER
03901 3519	90311-25003	25 x 38 x 7	CARINA (RWD) AA6#,TA6#,SA60,KA67	81/9~88/	Transmission (M/T) FRONT COVER
03901 2719	90311-30115	30 x 45 x 8	CARINA (RWD) RA63,CA6#,TA63(GTT)	81/9~88/	Transmission (M/T) FRONT COVER
03901 4735	90311-38009	38 x 58 x 8	CARINA (RWD) AA63,TA61,63,RA63	81/9~85/	Wheel Hub REAR INNER
03901 5287	90311-38043	38 x 58 x 11	CARINA (RWD) RA63,CA6#,TA63(GTT)	81/9~88/	Transmission (M/T) REAR
03901 4063	90311-38013	38.5 x 58 x 11	CARINA (RWD) 3TGTEU TA63	82/10~85/	Engine TIMING GEAR COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3571	04332-30020	Kit	CARINA (RWD) AA60,TA63,67,SA60,KA67, CA60	81/9~88/	Transmission (A/T) EXTENTION HOUSING
03901 1415	90311-11128	11 x 22 x 7	CARINA (RWD) AA60,TA63,67,SA60,KA67, CA60	81/9~88/	Transmission (A/T) LEVER SHAFT
03901 7359	90311-38015	38 x 65 x 12 x 19	CARINA (RWD) AA60,TA67,SA60,KA67,CA 6#	81/9~88/	Final Drive PINION
03901 1085	90311-38133	38 x 74 x 11	CARINA (RWD) TA63,RA63 GT,GTT	81/9~85/	Final Drive PINION
03901 6263	90311-38019	38 x 65 x 10 x 17	CARINA (RWD) AA63,TA61,63 ST,SE,GT	81/9~88/	Final Drive PINION
03901 4531	90311-38011	38 x 65 x 10 x 17	CARINA (RWD) AA63,TA61,63,RA63	81/9~85/	Final Drive DIFF. SIDE
03901 4585	90310-28027	28 x 40 x 8	CARINA (RWD) TA67,KA67,CA67	81/9~88/	Steering (M/S) SECTOR SHAFT
03901 4803	90311-19001	19 x 32 x 8	CARINA (RWD) TA67,KA67,CA67	81/9~88/	Steering (M/S) WORM GEAR
03901 7455	90311-15001	15 x 25 x 7	CARINA (RWD) AA6#,TA61,63,SA60,CA60, RA63	81/9~88/	Steering (M/S) RACK HOUSING
03901 1621	90311-19002	19 x 32 x 7 x 8	CARINA (RWD) AA6#,TA63,SA60,CA60,RA 63	81/9~88/	Steering (P/S) ADJUSTER PLUG
03901 7489	90311-32074	32 x 52 x 11	CARINA (RWD) AA6#,TA6#,SA60,KA67	81/9~88/	Transmission (M/T) REAR
03901 4873	9031135033	35 x 55 x 9 x 15.5	CARINA ED ST16#,18#	87/8~93/	Mission & Differential (M/T) TRANSAXLE CASE
03901 2379	15165-70010	18 x 30 x 7	CARINA ED 1S#,3S#,4S#	87/8~98/	Engine OIL PUMP
03901 7041	04422-20010	Kit	CARINA ED ST200,201,202,203 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 6835	04422-20010	Kit	CARINA ED ST18#...WITHOUT ABS	89/9~93/	Wheel Hub FRONT (RH)
03901 4323	04422-20010	Kit	CARINA ED ST16#	87/8~89/	Wheel Hub FRONT (RH)
03901 4511	04445-20103		CARINA ED ST181,183,201,203	89/9~98/	Steering (P/S) R&P GASKET KIT
03901 1679	04445-20040		CARINA ED ST180	89/9~91/8	Steering (P/S) R&P GASKET KIT
03901 7075	04445-20060		CARINA ED ST16#	87/8~89/	Steering (P/S) R&P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2525	04445-20110		CARINA ED ST182	89/9~93/	Steering (P/S) R&P GASKET KIT
03901 4419	9031135033	35 x 55 x 9 x 15.5	CARINA ED ST16#,18#	87/8~93/	Mission & Differential (M/T) DIFF.SIDE
03901 2731	90311-19002	19 x 32 x 7 x 8	CARINA ED ST16#,18#,20#	87/8~98/	Steering (P/S) CONTROL VALVE UPPER
03901 4477	90310-28003	28 x 41 x 6.5	CARINA ED ST16#,181,183,201,203	87/8~98/	Steering (P/S) CONTROL VALVE LOWER
03901 1715	90310-31001	31 x 44 x 6.5	CARINA ED ST180,182,200,202,205	89/9~98/	Steering (P/S) CONTROL VALVE LOWER
03901 3873	04422-20080	Kit	CARINA ED ST18#...ABS	89/9~93/	Wheel Hub FRONT (RH)
03901 6387	90311-35013	35 x 49 x 6	CARINA ED 3SGE#	87/8~98/	Engine CAM SHAFT
03901 8097	04445-20120		CARINA ED ST180	91/8~93/	Steering (P/S) R&P GASKET KIT
03901 8239	90311-42003	42 x 60 x 7	CARINA ED 1S#,3S#,4S#	87/8~89/	Engine CRANK SHAFT FRONT
03901 1089	90311-42026	42 x 60 x 7	CARINA ED 3S#,4S#	89/9~98/	Engine CRANK SHAFT FRONT
03901 5917	90311-85004	85 x 105 x 10	CARINA ED 1S#,3S#,4SFE	87/8~90/10	Engine CRANK SHAFT REAR
03901 3767	90311-85004	85 x 105 x 10	CARINA ED 3SGE#...ST162	87/8~89/	Engine CRANK SHAFT REAR
03901 5743	90311-85007	85 x 105 x 10	CARINA ED 3SFE,4SFE	90/10~98/	Engine CRANK SHAFT REAR
03901 7831	90311-89002	89 x 105 x 10	CARINA ED 3SGE	89/9~98/	Engine CRANK SHAFT REAR
03901 4813	90913-02056		CARINA ED 1S#	87/8~88/	Engine VALVE STEM SEAL
03901 4097	90913-02062		CARINA ED 3S#,4S#	87/8~90/3	Engine VALVE STEM SEAL
03901 4685	90913-02062		CARINA ED 3S#,4S#(IN.)	90/3~98/	Engine VALVE STEM SEAL
03901 4045	90913-02079		CARINA ED 3S#,4S#(EX.)	90/3~93/	Engine VALVE STEM SEAL
03901 6275	90913-02079		CARINA ED 3SFE,4SFE(EX.)	93/9~98/	Engine VALVE STEM SEAL
03901 5797	90913-02104		CARINA ED 3SGE	93/9~98/	Engine VALVE STEM SEAL
03901 2103	90311-38036	38 x 50 x 8	CARINA ED 1S#,3SFE,4SFE	87/8~98/	Engine CAM SHAFT
03901 6947	90311-44003	44 x 80 x 9 x 15.5	CARINA ED ST205 (4WD)	94/5~98/	Mission & Differential (M/T) TRANSMISSION CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4089	90311-38020	38 x 55 x 8.5	CARINA ED ST16#,18#,20#	87/8~98/	Mission & Differential (A/T) FRONT OIL PUMP
03901 3377	90311-44003	44 x 80 x 9 x 15.5	CARINA ED ST205 (4WD)	94/5~98/	Mission & Differential (A/T) DIFF.SIDE
03901 7375	90311-35033	35 x 55 x 9 x 15.5	CARINA ED ST20#...F,X,SLIM,GLIM	93/9~98/	Mission & Differential (A/T) DIFF.SIDE
03901 1483	90311-35033	35 x 55 x 9 x 15.5	CARINA ED ST16#,18#	87/8~93/	Mission & Differential (A/T) DIFF.SIDE
03901 5877	04445-20180		CARINA ED ST200,202,205	93/9~98/	Steering (P/S) R&P GASKET KIT
03901 6209	90311-35033	35 x 55 x 9 x 15.5	CARINA ED ST16#,18#	87/8~93/	Mission & Differential (A/T) TRANSAXLE CASE
03901 5423	04422-20080	Kit	CARINA ED ST200,201,202,203 ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 5169	90311-50010	50 x 80 x 16.5 x 23	CARINA ED ST202 GLIM	93/9~98/	Mission & Differential (M/T) TRANSMISSION CASE
03901 3601	90311-40004	40 x 56 x 9 x 15.5	CARINA ED ST202 GLIM	93/9~98/	Mission & Differential (M/T) TRANSAXLE CASE COVER
03901 6257	9031135033	35 x 55 x 9 x 15.5	CARINA ED ST20#...F,X,SLIM,GLIM	93/9~98/	Mission & Differential (M/T) DIFF.SIDE
03901 4695	9031135033	35 x 55 x 9 x 15.5	CARINA ED ST20#...F,X,SLIM,GLIM	93/9~98/	Mission & Differential (M/T) TRANSAXLE CASE
03901 4877	90311-30006	30 x 42 x 7	CARINA ED ST16#,18#,20#	87/8~98/	Mission & Differential (M/T) INPUT SHAFT
03901 1527	90311-52005	52 x 75 x 7.5 x 12	CARINA ED ST205 (4WD)	94/5~98/	Wheel Hub REAR OUTER
03901 5695	04422-20010	Kit	CARINA ED ST16#	87/8~89/	Wheel Hub FRONT (LH)
03901 6061	90311-35033	35 x 55 x 9 x 15.5	CARINA ED ST20#...F,X,SLIM,GLIM	93/9~98/	Mission & Differential (A/T) TRANSAXLE CASE
03901 1951	90311-56015	56 x 75 x 7 x 12	CARINA ED ST205 (4WD)	94/5~98/	Wheel Hub REAR INNER
03901 4781	04422-20090	Kit	CARINA ED ST202 GLIM ABS,ST205 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 7601	04422-20100	Kit	CARINA ED ST202 GLIM ABS & SSS,ST205 ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 5285	04422-20010	Kit	CARINA ED ST180,182 WITHOUT ABS	89/9~93/	Wheel Hub FRONT (LH)

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8183	04422-20010	Kit	CARINA ED ST200,202 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 1361	04422-20080	Kit	CARINA ED ST180,182 ABS	89/9~93/	Wheel Hub FRONT (LH)
03901 3599	04422-20080	Kit	CARINA ED ST181,183	89/9~93/	Wheel Hub FRONT (LH)
03901 3839	04422-20080	Kit	CARINA ED ST200,202 ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 1971	04422-20080	Kit	CARINA ED ST201,203	93/9~98/	Wheel Hub FRONT (LH)
03901 5019	04422-20090	Kit	CARINA ED ST202 GLIM SSS,ST205 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 4055	04422-20100	Kit	CARINA ED ST202 GLIM ABS & SSS,ST205 ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 3107	90311-42018	42 x 55 x 6	CARINA ED ST16#,18#	87/8~93/	Wheel Hub REAR
03901 3893	04422-20080	Kit	CELICA (FWD) ST18#...ABS	89/9~93/	Wheel Hub FRONT
03901 5151	04422-12121	Kit	CELICA (FWD) ST202 SS2,3 ABS & SUPER STRUT SUS.	93/9~99/	Wheel Hub FRONT
03901 2045	90311-56015	56 x 75 x 7 x 12	CELICA (FWD) ST185,205 (4WD)	91/4~99/	Wheel Hub REAR INNER
03901 6005	90311-56007	56 x 75 x 6.5 x 11	CELICA (FWD) ST165,185 (4WD)	86/10~91/4	Wheel Hub REAR INNER
03901 8045	90311-42018	42 x 55 x 6	CELICA (FWD) ST182,183	85/9~93/	Wheel Hub REAR
03901 6781	90311-42018	42 x 55 x 6	CELICA (FWD) ST160,162,163,AT160	85/8~89/	Wheel Hub REAR
03901 3575	04422-12121	Kit	CELICA (FWD) ST205 (4WD)	94/2~99/	Wheel Hub FRONT
03901 1949	90311-52005	52 x 75 x 7.5 x 12	CELICA (FWD) ST165,185,205 (4WD)	86/10~99/	Wheel Hub REAR OUTER
03901 2171	04422-12111	Kit	CELICA (FWD) ST202 SS2,3 SUPER STRUT SUS.	93/9~96/	Wheel Hub FRONT
03901 3145	04422-20080	Kit	CELICA (FWD) ST203	93/9~97/	Wheel Hub FRONT
03901 4373	90311-85004	85 x 105 x 10	CELICA (FWD) 1S#,3SF#,4SF#...ST16#,18#	85/8~90/10	Engine CRANK SHAFT REAR
03901 1401	90311-25011	25 x 37 x 8	CELICA (FWD) AT160	85/8~87/	Mission & Differential (M/T) INPUT SHAFT
03901 7547	04422-20010	Kit	CELICA (FWD) ST18#...WITHOUT ABS	89/9~93/	Wheel Hub FRONT
03901 5979	04422-20010	Kit	CELICA (FWD) ST202 CV	96/6~97/	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4241	04422-20080	Kit	CELICA (FWD) ST202 CV,SS1,SS2 ABS	93/9~99/	Wheel Hub FRONT
03901 2271	04422-20010	Kit	CELICA (FWD) ST202 CV,SS1,SS2	93/9~96/6	Wheel Hub FRONT
03901 1461	90311-35013	35 x 49 x 6	CELICA (FWD) 3SGTE ST205	97/12~99/	Engine CAM SHAFT
03901 5887	04422-20010	Kit	CELICA (FWD) ST16#,AT160	85/~89/	Wheel Hub FRONT
03901 3399	90311-42026	42 x 60 x 7	CELICA (FWD) 3SG#...ST202,205	96/9~99/	Engine CRANK SHAFT FRONT
03901 3743	90311-42026	42 x 60 x 7	CELICA (FWD) 3S#...ST18#,20#	89/9~96/9	Engine CRANK SHAFT FRONT
03901 6327	90311-42003	42 x 60 x 7	CELICA (FWD) 1S#,3S#,4SF#...ST16#	85/8~89/	Engine CRANK SHAFT FRONT
03901 5897	90311-38059	38 x 50 x 8	CELICA (FWD) 1ZZFE,2ZZGE ZTZ23#	99/8~	Engine TIMING GEAR COVER
03901 5879	90311-32020	32 x 46 x 6	CELICA (FWD) 4A#...AT160	85/8~87/	Engine OIL PUMP
03901 2073	90311-38036	38 x 50 x 8	CELICA (FWD) 3SGTE ST202,203	93/9~97/8	Engine CAM SHAFT
03901 3555	90311-38036	38 x 50 x 8	CELICA (FWD) 1S#,3SF#,4SF#...ST16#,18#	85/8~93/	Engine CAM SHAFT
03901 5555	90311-42035	42 x 60 x 7	CELICA (FWD) 3SFE ST202,203	96/9~99/	Engine CRANK SHAFT FRONT
03901 4507	90311-35041	35 x 60 x 11	CELICA (FWD) 3SGTE ST202	97/12~99/	Engine CAM SHAFT (NO.1)
03901 1471	90311-85007	85 x 105 x 10	CELICA (FWD) 3SF#...ST18#,20#	90/10~99/	Engine CRANK SHAFT REAR
03901 2245	90311-35013	35 x 49 x 6	CELICA (FWD) 3SG#...ST202,205	93/9~97/1 2	Engine CAM SHAFT
03901 7915	90311-35013	35 x 49 x 6	CELICA (FWD) 3SG#...ST16#,18#	85/8~93/	Engine CAM SHAFT
03901 5801	90311-35013	35 x 49 x 6	CELICA (FWD) 4A#...AT160	85/8~87/	Engine CAM SHAFT
03901 3363	90310-25032	25 x 35 x 6	CELICA (FWD) ZTZ23#	99/8~	Steering (P/S) CONTROL VALVE LOWER
03901 2609	90310-31001	31 x 44 x 6.5	CELICA (FWD) ST182,185,202,205	89/9~99/	Steering (P/S) CONTROL VALVE LOWER
03901 6205	90310-31001	31 x 44 x 6.5	CELICA (FWD) ST162,163	89/3~89/	Steering (P/S) CONTROL VALVE LOWER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8037	90310-31001	31 x 44 x 6.5	CELICA (FWD) ST162(GT)	87/8~89/3	Steering (P/S) CONTROL VALVE LOWER
03901 7435	90310-31001	31 x 44 x 6.5	CELICA (FWD) AT160,ST162	86/2~87/8	Steering (P/S) CONTROL VALVE LOWER
03901 6517	90311-46004	46 x 60 x 6.5	CELICA (FWD) 3SGTE ST202	97/12~99/	Engine CAM SHAFT (NO.2)
03901 6701	90913-02079		CELICA (FWD) 3SFE (IN.)	93/8~99/	Engine VALVE STEM SEAL
03901 1243	90913-02111		CELICA (FWD) 1ZZFE (EX.)	99/8~	Engine VALVE STEM SEAL
03901 3077	90913-02101		CELICA (FWD) 1ZZFE (IN.)	99/8~	Engine VALVE STEM SEAL
03901 6993	90913-02115		CELICA (FWD) 2ZZGE (EX.)	99/8~	Engine VALVE STEM SEAL
03901 2259	90913-02115		CELICA (FWD) 3SGE (EX.)	97/12~99/	Engine VALVE STEM SEAL
03901 2613	90913-02104		CELICA (FWD) 3SGTE (EX.)	97/12~99/	Engine VALVE STEM SEAL
03901 4753	90913-02104		CELICA (FWD) 3SG# (EX.)	93/8~97/1 2	Engine VALVE STEM SEAL
03901 4849	90913-02114		CELICA (FWD) 2ZZGE (IN.)	99/8~	Engine VALVE STEM SEAL
03901 4863	90913-02114		CELICA (FWD) 3SGE (IN.)	97/12~99/	Engine VALVE STEM SEAL
03901 4377	90311-70004	70 x 92 x 8.5	CELICA (FWD) 4A#...AT160	85/8~87/	Engine CRANK SHAFT REAR
03901 2607	90913-02079		CELICA (FWD) 3SG# (IN.)	93/8~97/1 2	Engine VALVE STEM SEAL
03901 6003	90311-38067	38 x 50 x 8	CELICA (FWD) 3SGTE ST202,203	97/12~99/	Engine CAM SHAFT
03901 3439	90913-02062		CELICA (FWD) 3SFE (EX.)	93/8~99/	Engine VALVE STEM SEAL
03901 4061	90913-02062		CELICA (FWD) 3S#,4S# (EX.)	90/3~93/8	Engine VALVE STEM SEAL
03901 4537	90913-02062		CELICA (FWD) 3S#,4S# (IN. & EX.)	85/8~90/3	Engine VALVE STEM SEAL
03901 2591	90913-02056		CELICA (FWD)	85/8~88/	Engine VALVE STEM SEAL
03901 4563	90913-02062		CELICA (FWD) 4A#	85/8~87/	Engine VALVE STEM SEAL
03901 6997	90311-76001	76 x 94 x 8.5	CELICA (FWD) 1ZZFE ZZT230	99/8~	Engine CRANK SHAFT REAR
03901 7185	90311-89001	89 x 105 x 10	CELICA (FWD) 3SG#...ST18#,20#	89/9~99/	Engine CRANK SHAFT REAR
03901 3765	90311-85007	85 x 105 x 10	CELICA (FWD) 2ZZGE ZZT231	99/8~	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3249	90310-28003	28 x 41 x 6.5	CELICA (FWD) ST160,165	89/3	Steering (P/S) CONTROL VALVE LOWER
03901 2287	90913-02079		CELICA (FWD) 3SGTE (IN.)	97/12~99/	Engine VALVE STEM SEAL
03901 2203	90311-50010	50 x 80 x 16.5 x 23	CELICA (FWD) ST205 (4WD)	95/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 1617	90310-31001	31 x 44 x 6.5	CELICA (FWD) AT160,ST16#	85/8~86/2	Steering (P/S) CONTROL VALVE LOWER
03901 3357	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ST16#,18#,20#...2WD	85/8~99/	Mission & Differential (A/T) DIFF. SIDE
03901 3437	90311-35046	35 x 57 x 9 x 15.5	CELICA (FWD) ZTZ230	99/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 5373	90311-35020	35 x 63 x 9 x 15.5	CELICA (FWD) ST202 CV,SS2,SS3	97/12~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 2329	90311-35020	35 x 63 x 9 x 15.5	CELICA (FWD) ST182,183	89/9~93/	Mission & Differential (A/T) TRANSAXLE CASE
03901 6715	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ZTZ230	99/8~	Mission & Differential (A/T) TRANSAXLE CASE
03901 1241	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ST202 SS1	97/12~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 2687	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ST202,203	93/9~97/1 2	Mission & Differential (A/T) TRANSAXLE CASE
03901 1309	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ZTZ231	99/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 7587	90311-40004	40 x 56 x 9 x 15.5	CELICA (FWD) ST202 SS2	93/9~95/8	Mission & Differential (M/T) TRANSAXLE CASE COVER
03901 7285	90311-38020	38 x 55 x 8.5	CELICA (FWD) ST16#,18#,20#	85/8~99/	Mission & Differential (A/T) FRONT OIL PUMP
03901 6379	90311-50010	50 x 80 x 16.5 x 23	CELICA (FWD) ST202,205 GT4,SS2	93/9~95/8	Mission & Differential (M/T) TRANSMISSION CASE
03901 5993	90311-50010	50 x 80 x 16.5 x 23	CELICA (FWD) ST165,185 (4WD)	85/8~93/	Mission & Differential (M/T) TRANSMISSION CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2989	90311-35044	35 x 63 x 10 x 22	CELICA (FWD) ZZT23#	99/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 6817	90311-34017	34 x 63 x 9 x 16	CELICA (FWD) AT160	85/8~87/	Mission & Differential (M/T) TRANSMISSION CASE
03901 7049	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ST16#,18#,20#...2WD	85/8~99/	Mission & Differential (M/T) DIFF. SIDE
03901 3463	90311-35043	35 x 54 x 9 x 21.5	CELICA (FWD) ZZT23#	99/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 5307	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ST16#,18#,20#...2WD	85/8~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 5233	90311-34016	34 x 54 x 9 x 15.5	CELICA (FWD) AT160	85/8~87/	Mission & Differential (M/T) TRANSAXLE CASE
03901 3589	90311-30006	30 x 42 x 7	CELICA (FWD) ST16#,18#,20#	85/8~99/	Mission & Differential (M/T) INPUT SHAFT
03901 1739	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ST16#...2WD	85/8~89/	Mission & Differential (A/T) TRANSAXLE CASE
03901 8049	04445-20110		CELICA (FWD) ST182	91/8~93/	Steering (P/S) R & P GASKET KIT
03901 2179	90311-25011	25 x 37 x 8	CELICA (FWD) ZZT23#	99/8~	Mission & Differential (M/T) INPUT SHAFT
03901 4187	90310-28003	28 x 41 x 6.5	CELICA (FWD) ST160,162(ZR,CV),163,165	87/8~89/3	Steering (P/S) CONTROL VALVE LOWER
03901 4643	90310-28003	28 x 41 x 6.5	CELICA (FWD) ST160,165	86/2~87/8	Steering (P/S) CONTROL VALVE LOWER
03901 7395	90311-20008	20 x 34 x 7	CELICA (FWD) ZZT23#	99/8~	Steering (P/S) CONTROL VALVE UPPER
03901 1125	90311-19002	19 x 32 x 7 x 8	CELICA (FWD) AT160,ST16#	85/8~99/	Steering (P/S) CONTROL VALVE UPPER
03901 1189	04445-20261		CELICA (FWD) ZZT23#	99/8~	Steering (P/S) R & P GASKET KIT
03901 4739	04445-20180		CELICA (FWD) ST203,205	93/9~99/	Steering (P/S) R & P GASKET KIT
03901 5153	04445-20230		CELICA (FWD) ST203	96/2~97/	Steering (P/S) R & P GASKET KIT
03901 8013	90311-35033	35 x 55 x 9 x 15.5	CELICA (FWD) ZZT231	99/8~	Mission & Differential (A/T) DIFF. SIDE
03901 4519	04445-20130		CELICA (FWD) ST185	91/8~93/	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2377	90310-28003	28 x 41 x 6.5	CELICA (FWD) ST183,203	89/9~97/	Steering (P/S) CONTROL VALVE LOWER
03901 1129	04445-20110		CELICA (FWD) ST162,185	89/9~91/8	Steering (P/S) R & P GASKET KIT
03901 6731	04445-32030		CELICA (FWD) ST165	86/10~89/	Steering (P/S) R & P GASKET KIT
03901 4283	04445-20060		CELICA (FWD) ST160,162(ZR,CV),163	87/8~89/	Steering (P/S) R & P GASKET KIT
03901 3867	04445-20060		CELICA (FWD) ST160	86/2~87/8	Steering (P/S) R & P GASKET KIT
03901 4855	04445-20040		CELICA (FWD) ST162,163	89/3~89/	Steering (P/S) R & P GASKET KIT
03901 4077	04445-20040		CELICA (FWD) ST162(GT)	87/8~89/3	Steering (P/S) R & P GASKET KIT
03901 2131	04445-20040		CELICA (FWD) AT160,ST162	86/2~87/8	Steering (P/S) R & P GASKET KIT
03901 1881	04445-20040		CELICA (FWD) AT160,ST16#	85/8~86/2	Steering (P/S) R & P GASKET KIT
03901 5021	90311-38064	38 x 55 x 8.7	CELICA (FWD) ST23#	99/8~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4819	04445-20103		CELICA (FWD) ST183,203	89/9~96/2	Steering (P/S) R & P GASKET KIT
03901 4741	15165-70010	18 x 30 x 7	CELICA (FWD) 1S#,3S#,4SF#...ST16#,18#,20#	85/8~99/	Engine OIL PUMP
03901 1409	90311-32074	32 x 52 x 11	CELICA (RWD) AA63,TA61,SA60 ALL,TA63 SV,ST,SX	81/7~85/	Transmission (M/T) REAR EXTENTION
03901 4487	90311-19002	19 x 32 x 7 x 8	CELICA (RWD) AA63,TA63,RA63,GA61,M A6#,SA60	81/7~85/	Steering (P/S) ADJUSTER PLUG
03901 4621	90311-15001	15 x 25 x 7	CELICA (RWD) AA63,TA61,63,64,SA60,RA 63,GA61	81/7~85/	Steering (M/S) RACK HOUSING
03901 2865	90311-38018	38 x 50 x 8	CELICA (RWD) GA61 L,S,G	85/9~85/	Final Drive DUFF. SIDE
03901 1599	90311-38011	38 x 63 x 10 x 17	CELICA (RWD) GA61(GT),MA61(GT),MA6 3	85/9~85/	Final Drive DUFF. SIDE
03901 1135	90311-38011	38 x 63 x 10 x 17	CELICA (RWD) AA63,TA61,63,RA63,GA61, MA6#	81/7~85/9	Final Drive DUFF. SIDE
03901 4417	90311-38133	38 x 74 x 11	CELICA (RWD) TA64,MA63 ALL	81/7~85/	Final Drive PINION
03901 6093	90311-38015	38 x 65 x 12 x 19	CELICA (RWD) SA60	81/8~85/	Final Drive PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3151	90311-38015	38 x 65 x 12 x 19	CELICA (RWD) TA6#,SA60,GA61	81/7~81/8	Final Drive PINION
03901 2819	90311-38020	38 x 55 x 8.5	CELICA (RWD) TA64,SA60,GA61,MA6#	81/7~85/	Transmission (A/T) FRONT OIL PUMP
03901 1043	90311-11128	11 x 22 x 7	CELICA (RWD) TA64,SA60,GA61,MA6#	81/7~85/	Transmission (A/T) LEVER SHAFT
03901 5079	90311-38013	38.5 x 58 x 11	CELICA (RWD) 2TGTEU,3T#,4TGTEU TA6#	81/7~85/	Engine TIMING GEAR COVER
03901 5303	90311-38043	38 x 58 x 11	CELICA (RWD) TA63(GTT),64,RA63,GA61, MA61	81/7~85/	Transmission (M/T) REAR EXTENTION
03901 3207	90311-38019	38 x 65 x 10 x 17	CELICA (RWD) TA63,GA61 ST,SX,L,S,G, TA61 ALL	81/8~85/	Final Drive PINION
03901 7065	90311-30115	30 x 45 x 8	CELICA (RWD) TA63(GTT),64,RA63,GA61, MA61	81/7~85/	Transmission (M/T) FRONT COVER
03901 1791	90311-25003	25 x 38 x 7	CELICA (RWD) AA63,TA61,SA60 ALL,TA63 SV,ST,SX	81/7~85/	Transmission (M/T) FRONT COVER
03901 7331	90311-48001	48 x 62 x 9	CELICA (RWD) AA63,TA61,63,RA63,GA61, MA6#	83/5~85/	Wheel Hub REAR OUTER
03901 1987	90311-48122	48 x 62 x 7	CELICA (RWD) TA61,63,RA63,GA61,MA6#	81/7~83/5	Wheel Hub REAR OUTER
03901 2059	90311-38009	38 x 58 x 8	CELICA (RWD) AA63,TA61,63,RA63,GA61, MA6#	81/7~85/	Wheel Hub REAR INNER
03901 8119	90311-52059	52 x 65 x 9	CELICA (RWD) TA64,SA60	81/7~85/	Wheel Hub REAR
03901 3695	90311-48122	48 x 62 x 7	CELICA (RWD) AA63,TA6#,RA63,GA61,M A6#	81/7~85/	Wheel Hub FRONT
03901 8169	90311-41123	41 x 53 x 7	CELICA (RWD) SA60	81/7~85/	Wheel Hub FRONT
03901 6539	90311-45003	45 x 62 x 8	CELICA (RWD) 1G#...GA61	81/7~85/	Engine TIMING GEAR CASE
03901 5769	04332-30020	Kit	CELICA (RWD) TA64,SA60,GA61,MA6#	81/7~85/	Transmission (A/T) EXTENTION HOUSING
03901 3003	90311-42003	42 x 60 x 7	CELICA (RWD) 1SU SA60	81/7~85/	Engine CRANK SHAFT FRONT
03901 1887	90311-42003	42 x 60 x 7	CELICA (RWD) 5MGEU MA61	81/7~85/	Engine TIMING GEAR CASE
03901 3409	90311-38013	38.5 x 58 x 11	CELICA (RWD) 5MGEU MA61	81/7~85/	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6751	90311-35013	35 x 49 x 6	CELICA (RWD) 1GGEU GA61	81/7~85/	Engine CAM SHAFT
03901 6493	90311-35013	35 x 49 x 6	CELICA (RWD) 4AGEU AA63	83/8~85/	Engine CAM SHAFT
03901 5133	90311-38036	38 x 50 x 8	CELICA (RWD) 1SU SA60, 1GEU GA61	81/7~85/	Engine CAM SHAFT
03901 6271	90311-38133	38 x 74 x 11	CELICA (RWD) AA63,TA63,RA63,GA61,M A61 GT,GTT	81/7~85/	Final Drive PINION
03901 5295	90311-32020	32 x 46 x 6	CELICA (RWD) 4AGEU AA63	83/8~85/	Engine OIL PUMP
03901 5385	90311-45002	45 x 68 x 12	CELICA (RWD) 18RGEU RA63,MTEU MA63	81/7~85/	Engine TIMING GEAR COVER
03901 3543	90311-75114	75 x 100 x 13	CELICA (RWD) 2TGEU,3T#,4TGEU TA6#,1G#...GA61	81/7~85/	Engine CRANK SHAFT REAR
03901 7753	90311-80001	80 x 100 x 12	CELICA (RWD) 18RGEU RA63,MTEU,5MGEU MA6#	81/7~85/	Engine CRANK SHAFT REAR
03901 6125	90311-85004	85 x 105 x 10	CELICA (RWD) 1SU SA60	81/7~85/	Engine CRANK SHAFT REAR
03901 7357	90311-70004	70 x 92 x 8.5	CELICA (RWD) 4AGEU AA63	83/8~85/	Engine CRANK SHAFT REAR
03901 1403	90913-02024		CELICA (RWD) 3TEU(IN.) TA63	81/7~83/8	Engine VALVE STEM SEAL
03901 7123	90913-02038		CELICA (RWD) 1GEU GA61	81/7~85/	Engine VALVE STEM SEAL
03901 2997	15165-70010	18 x 30 x 7	CELICA (RWD) 1SU SA60, 1G#...GA61	81/7~85/	Engine OIL PUMP
03901 5785	90913-02058		CELICA (RWD) 3TEU(EX.) TA63	81/7~83/8	Engine VALVE STEM SEAL
03901 4261	90913-02056		CELICA (RWD) 1SU SA60	81/7~85/	Engine VALVE STEM SEAL
03901 4195	90913-02062		CELICA (RWD) 1GGEU GA61	82/8~85/	Engine VALVE STEM SEAL
03901 4845	90311-48004	48 x 70 x 12	CELICA (RWD) 5MGEU MA61	81/7~85/	Engine TIMING GEAR COVER
03901 1271	90913-02110		CELICA (RWD) 5MGEU MA61	81/7~85/	Engine VALVE STEM SEAL
03901 6851	90913-02015		CELICA (RWD) MTEU(EX.) MA63	82/2~85/	Engine VALVE STEM SEAL
03901 2889	90913-02022		CELICA (RWD) MTEU(IN.) MA63	82/2~85/	Engine VALVE STEM SEAL
03901 7505	90913-02060		CELICA (RWD) 3TGEU,4TGEU TA63,64	82/10~85/	Engine VALVE STEM SEAL
03901 2765	90072-72006		CELICA (RWD) 2TGEU TA61, 18RGEU RA63	81/7~83/8	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7351	90913-02062		CELICA (RWD) 4AGEU AA63	83/8~85/	Engine VALVE STEM SEAL
03901 2827	04445-50012		CELSIOR / LEXUS LS400 UCF1#	89/11~92/ 8	Steering (P/S) R &P GASKET KIT
03901 5489	04445-50013		CELSIOR / LEXUS LS401 UCF1#	92/8~94/	Steering (P/S) R &P GASKET KIT
03901 7117	90311-42024	42 x 55 x 10	CELSIOR / LEXUS LS402 UCF1#,2#	89/11~	Transmission (A/T) EXTENTION HOUSING
03901 1973	90311-47008	47 x 72 x 10 x 11	CELSIOR / LEXUS LS403 UCF2#,3#	97/7~	Final Drive DIFF. SIDE
03901 4217	90311-47003	47 x 84 x 11 x 17.5	CELSIOR / LEXUS LS404 UCF1#,2#	89/11~97/ 7	Final Drive DIFF. SIDE
03901 1245	90311-44005	44 x 74 x 11 x 16	CELSIOR / LEXUS LS405 UCF1#,2#,3#	89/11~	Final Drive PINION
03901 1943	90311-38029	38 x 55 x 7.5	CELSIOR / LEXUS LS406 UCF1#,2#	89/11~	Transmission (A/T) FRONT OIL PUMP
03901 7163	90311-57001	57 x 81 x 8 x 11	CELSIOR / LEXUS LS407 UCF2#	94/10~00/	Wheel Hub REAR OUTER
03901 3423	90311-57001	57 x 81 x 8 x 11	CELSIOR / LEXUS LS408 UCF1#	89/11~94/	Wheel Hub REAR OUTER
03901 4029	90311-63001	63 x 90 x 7 x 10	CELSIOR / LEXUS LS409 UCF2#	94/10~00/	Wheel Hub REAR INNER
03901 7883	90311-63001	63 x 90 x 7 x 10	CELSIOR / LEXUS LS410 UCF1#	89/11~94/	Wheel Hub REAR INNER
03901 2541	90311-50008	50 x 77.5 x 9 x 14	CELSIOR / LEXUS LS411 UCF1#	89/11~94/	Wheel Hub FRONT
03901 5269	90913-02112		CELSIOR / LEXUS LS412 1UZFE,3UZFE (EX.)	97/7~	Engine VALVE STEM SEAL
03901 6655	04445-50020		CELSIOR / LEXUS LS413 UCF2#	94/10~97/ 7	Steering (P/S) R &P GASKET KIT
03901 3609	90311-50008	50 x 77.5 x 9 x 14	CELSIOR / LEXUS LS414 UCF2#	94/10~00/	Wheel Hub FRONT
03901 2479	90913-02062		CELSIOR / LEXUS LS415 1UZFE (IN. &EX.)	89/11~94/	Engine VALVE STEM SEAL
03901 4587	90913-02106		CELSIOR / LEXUS LS416 1UZFE (IN. &EX.)	94/10~97/ 7	Engine VALVE STEM SEAL
03901 6495	04445-50030		CELSIOR / LEXUS LS417 UCF2#	97/7~00/	Steering (P/S) R &P GASKET KIT
03901 3459	90913-02113		CELSIOR / LEXUS LS418 1UZFE,3UZFE (IN.)	97/7~	Engine VALVE STEM SEAL
03901 8083	90311-95012	95 x 113 x 8.5	CELSIOR / LEXUS LS419 3UZFE UCF3#	00/8~	Engine CRANK SHAFT REAR
03901 3445	90311-95012	95 x 113 x 8.5	CELSIOR / LEXUS LS420 1UZFE UCF1#,2#	89/11~00/	Engine CRANK SHAFT REAR
03901 2465	90311-43006	43 x 60 x 7	CELSIOR / LEXUS LS421 3UZFE UCF3#	00/8~	Engine OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6609	90311-43006	43 x 60 x 7	CELSIOR / LEXUS LS422 1UZFE UCF2#	97/12~00/	Engine OIL PUMP
03901 6825	90311-19002	19 x 32 x 7 x 8	CELSIOR / LEXUS LS423 UCF1#,2#,3#	89/11~	Steering (P/S) CONTROL VALVE UPPER
03901 5187	90311-71001	71.5 x 85 x 10	CELSIOR / LEXUS LS424 3UZFE UCF3#	00/8~	Engine CAM SHAFT
03901 4779	90311-71001	71.5 x 85 x 10	CELSIOR / LEXUS LS425 1UZFE UCF2#	97/7~00/	Engine CAM SHAFT
03901 3545	90311-38036	38 x 50 x 8	CELSIOR / LEXUS LS426 1UZFE UCF1#,2#	89/11~97/7	Engine CAM SHAFT
03901 5231	90310-30013	30 x 41 x 6.5	CELSIOR / LEXUS LS427 UCF1#,2#,3#	89/11~	Steering (P/S) CONTROL VALVE LOWER
03901 4679	90311-43004	43 x 60 x 7	CELSIOR / LEXUS LS428 1UZFE UCF1#,2#	89/11~97/12	Engine OIL PUMP
03901 2263	04445-50040		CELSIOR / LEXUS LS429 UCF3#	00/8~	Steering (P/S) R & P GASKET KIT
03901 1743	9828-01228	100 x 135 x 15	COASTER J05C RX4JFAT#	96/6~	Engine CRANK SHAFT REAR
03901 3035	90311-95008	95 x 115 x 9.5 x 12	COASTER 1HZ,1HD#...HQB4#,5#,HDB5#	93/1~	Engine CRANK SHAFT REAR
03901 7307	90311-95008	95 x 115 x 9.5 x 12	COASTER 1HZ,1HDT HQB3#,HDB20,3#	90/1~93/	Engine CRANK SHAFT REAR
03901 5613	90311-95008	95 x 115 x 9.5 x 12	COASTER 15B#,1BZFPE,3B BB4#,5#,BQB40,50	93/1~	Engine CRANK SHAFT REAR
03901 6279	90311-95008	95 x 115 x 9.5 x 12	COASTER 3B,14B BB2#,31	88/8~93/	Engine CRANK SHAFT REAR
03901 7981	90311-95001	95 x 115 x 12	COASTER 2H,12HT HB3#	82/5~90/1	Engine CRANK SHAFT REAR
03901 4357	90311-80001	80 x 100 x 12	COASTER 20R,22R RB1#,2#	77/8~83/6	Engine CRANK SHAFT REAR
03901 3309	90311-95001	95 x 115 x 12	COASTER 2B,3B BB1#,2#,3#	77/8~88/8	Engine CRANK SHAFT REAR
03901 3119	90311-80010	80 x 100 x 10 x 11.5	COASTER 22R RB2#	83/6~93/	Engine CRANK SHAFT REAR
03901 7333	90913-02024		COASTER 20R,22R RB1#,2#	77/8~82/12	Engine VALVE STEM SEAL
03901 7301	90913-02094		COASTER 1HZ,1HDT HQB3#,HDB20,3#	90/11~93/	Engine VALVE STEM SEAL
03901 6087	04445-36120		COASTER BB5#	95/12~99/7	Steering (P/S) P/S GEAR GASKET KIT
03901 2069	90913-02110		COASTER 22R RB2#	82/12~93/	Engine VALVE STEM SEAL
03901 1785	90913-02028		COASTER 2B BB1#	77/8~80/8	Engine VALVE STEM SEAL
03901 7067	90913-02051		COASTER 2B,3B BB1#,2#,3#	80/8~88/8	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8261	90913-02076		COASTER 3B,14B BB2#,31,4#	88/8~99/7	Engine VALVE STEM SEAL
03901 1861	90913-02108		COASTER 15BF BB5#	95/12~99/3	Engine VALVE STEM SEAL
03901 5123	90913-02096		COASTER 15B#,1BZFPE BB58,BZB40,50	99/3~	Engine VALVE STEM SEAL
03901 3085	90913-02110		COASTER 1HZ,1HDT HZB3#,HDB20,3#	90/1~90/11	Engine VALVE STEM SEAL
03901 7267	90913-02094		COASTER 1HZ,1HDT HZB4#,5#,HDB5#	93/1~97/7	Engine VALVE STEM SEAL
03901 3055	90913-02096		COASTER 1HD#...HDB5#	95/5~	Engine VALVE STEM SEAL
03901 5559	90913-02056		COASTER 1HZ HZB4#,5#	97/7~	Engine VALVE STEM SEAL
03901 2055	90311-32020	32 x 46 x 6	COASTER 1HZ,1HD#...HZB4#,5#,HDB5#	93/1~	Engine CAM SHAFT
03901 2365	90913-02050		COASTER 2H,12HT HB3#	82/5~90/1	Engine VALVE STEM SEAL
03901 6665	90310-38033	38 x 44 x 18	COASTER RB2#,BB2#,3#,HB3#,HDB20,3#,HZB3#	82/5~93/	Wheel Hub REAR OUTER
03901 3475	90311-45007	45 x 62 x 8	COASTER HDB5#...6F	75/5~99/7	Transmission REAR OUTPUT
03901 1669	90311-48011	48 x 62 x 9	COASTER HDB5#...TDFI 6F	99/7~	Transmission REAR OUTPUT
03901 3721	90311-48011	48 x 62 x 9	COASTER BB4#,BZB40,50,HDB5#,HZB4#,5#...5F	93/1~	Transmission REAR OUTPUT
03901 6175	90311-48011	48 x 62 x 9	COASTER RB2#,BB2#,3#,HB3#,HDB3# #,HZB3#	85/10~93/	Transmission REAR OUTPUT
03901 5567	90311-45001	45 x 62 x 9	COASTER RB1#,2#,BB1#,2#,3#,HB3#	77/8~85/10	Transmission REAR OUTPUT
03901 5075	9828-43102	43 x 63 x 9	COASTER RX4JFAT#	96/6~	Transmission FRONT COVER
03901 1157	90311-32020	32 x 46 x 6	COASTER 1HZ,1HDZ HZB3#,HDB20,3#	90/1~93/	Engine CAM SHAFT
03901 5885	90311-32012	32 x 53 x 7	COASTER BB4#	93/1~99/7	Transmission FRONT COVER
03901 5889	90029-21010	24 x 36 x 7 x 7.5	COASTER BB4#,5#,HDB5#,HZB4#,5#	93/1~99/7	Steering (P/S) STEERING WORM
03901 4453	90311-28004	28.6 x 43.6.5 x	COASTER HB3#	82/5~85/10	Transmission FRONT COVER
03901 7675	90311-32106	32 x 48 x 8	COASTER RB1#,2#,BB1#,2#,3#	77/8~85/10	Transmission FRONT COVER
03901 1159	9828-55110	55 x 72 x 9 x 15	COASTER RX4JFAT#...AGF	96/6~	Transmission REAR OUTPUT
03901 3987	90310-38033	38 x 44 x 18	COASTER BB4#,5#,BZB40,50,HDB5#	93/1~	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
			HZB4#,5#		
03901 5493	90311-35023	35 x 48 x 6.5	COASTER BxB40,50,HDB5#,HZB4#,5#	93/1~	Transmission FRONT COVER
03901 4649	90311-35038	35 x 44 x 7	COASTER RB1#,BB1#	77/8~82/	Wheel Hub REAR OUTER
03901 6007	9828-01206	107 x 123 x 11	COASTER RX4JFAT#	96/6~	Wheel Hub REAR INNER
03901 7047	90311-78001	78 x 115 x 10 x 19	COASTER BB58,BZB40,50,HDB5#,HZB4#,5#	99/7~	Wheel Hub REAR INNER
03901 2467	90311-75003	75 x 108 x 10 x 20	COASTER BB4#,5#,BZB40,50,HDB5#,HZB4#,5#	93/1~99/7	Wheel Hub REAR INNER
03901 3735	90311-75003	75 x 108 x 10 x 20	COASTER RB2#,BB2#,3#,HB3#,HDB20,3#,HZB3#	84/8~93/	Wheel Hub REAR INNER
03901 7021	42404-36010	75 x 108 x 20	COASTER RB1#,2#,BB1#,2#,3#,HB3#	77/8~84/8	Wheel Hub REAR INNER
03901 7615	9828-85106	84 x 100 x 10	COASTER RX4JFAT#	96/6~	Wheel Hub FRONT
03901 4783	90311-68002	68 x 92 x 9.7	COASTER BZB40,50,HDB5#,HZB4#,5#	99/7~	Wheel Hub FRONT
03901 4001	90311-68001	68 x 90 x 10	COASTER BB4#,HDB5#,HZB4#,5#	93/1~99/7	Wheel Hub FRONT
03901 2115	90311-68001	68 x 90 x 10	COASTER RB2#,BB2#,3#,HB3#,HDB20,3#,HZB3#	82/5~93/	Wheel Hub FRONT
03901 2981	90311-68001	68 x 90 x 10	COASTER RB1#,BB1#	77/8~82/	Wheel Hub FRONT
03901 5483	9828-48112	48 x 109 x 13	COASTER RX4JFAT#	96/6~	Wheel Hub REAR OUTER
03901 7597	90311-65003	65 x 79 x 7	COASTER 1HDFTE HDB5#	99/7~	Engine TIMING GEAR COVER (NO.1)
03901 3907	9828-79103	79 x 114 x 17	COASTER J05C RX4JFAT#	96/6~	Engine TIMING GEAR COVER
03901 7173	90311-58007	58.5 x 75 x 9 x 14.5	COASTER 1HDFTE HDB5#	99/7~	Engine TIMING GEAR COVER (NO.2)
03901 4389	90311-58007	58.5 x 75 x 9 x 14.5	COASTER 1HZ,1HDEFT,1HDT HZB4#,5#,HDB5#	93/1~	Engine TIMING GEAR COVER (NO.2)
03901 1917	90311-32012	32 x 53 x 7	COASTER RB2#,BB2#,3#,HB3#,HDB3#,HZB3#	85/10~93/	Transmission FRONT COVER
03901 8029	S1371-91360		COASTER J05C RX4JFAT#	96/6~	Engine VALVE STEM SEAL
03901 3631	9828-60119	60 x 75 x 9 x 15	COASTER RX4JFAT#...KGB,KGC,KG D,KGE	96/6~	Transmission REAR OUTPUT
03901 1277	90311-58006	58 x 72 x 7	COASTER 1HZ,1HDEFT,1HDT HZB4#,5#,HDB5#	93/1~	Engine TIMING GEAR COVER (NO.1)

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1913	90311-58006	58 x 72 x 7	COASTER 1HZ,1HDZ HZB3#,HDB20,3#	90/1~93/	Engine TIMING GEAR COVER (NO.1)
03901 3877	90311-50013	50 x 72 x 9 x 14	COASTER 15B#,1BZFPE,3B BB4#,5#,BZB40,50	93/1~	Engine TIMING GEAR COVER
03901 4639	90311-50013	50 x 72 x 9 x 14	COASTER 3B,14B BB2#,31	88/8~93/	Engine TIMING GEAR COVER
03901 2449	90311-50006	50 x 72 x 12	COASTER 2H,12HT HB3#	82/5~90/1	Engine TIMING GEAR COVER
03901 5601	90311-50006	50 x 72 x 12	COASTER 2B,3B BB1#,2#,3#	77/8~88/8	Engine TIMING GEAR COVER
03901 5219	90311-45002	45 x 68 x 12	COASTER 1OR,22R RB1#,2#	77/8~93/	Engine TIMING GEAR COVER
03901 1487	90311-48019	48 x 82 x 10.2 x 17.8	COASTER BB4#,58,BZB40,50,HDB5#, HZB4#,5#	99/5~	Final Drive PINION
03901 8125	90311-58007	58.5 x 75 x 9 x 14.5	COASTER 1HZ,1HDZ HZB3#,HDB20,3#	90/1~93/	Engine TIMING GEAR COVER (NO.2)
03901 3319	90311-48135	48 x 82 x 12	COASTER RB1#,BB1#	77/8~82/	Final Drive PINION
03901 3597	90311-48135	48 x 82 x 12	COASTER BB4#,5#,HDB5#,HZB4#,5#	93/1~99/5	Final Drive PINION
03901 2839	9828-58109	58 x 102 x 8 x 22	COASTER RX4JFAT#	96/6~	Final Drive PINION
03901 1995	90311-36104	36 x 50 x 7	COASTER RB1#,2#,BB1#,2#,3#	77/8~90/1	Steering (M/S) SECTOR SHAFT
03901 3329	90311-22103	22 x 36 x 8	COASTER RB1#,2#,BB1#,2#,3#	77/8~90/1	Steering (M/S) WORM GEAR
03901 4497	04445-36040		COASTER RB2#,BB2#,3#,HB3#,HDB2 0,3#,HZB3#	85/10~93/	Steering (P/S) P/S GEAR GASKET KIT
03901 1997	04445-36100		COASTER BB4#,HDB5#,HZB4#,5#	93/1~99/7	Steering (P/S) P/S GEAR GASKET KIT
03901 7803	04445-37040		COASTER BB58,BZB40,50,HDB5#,HZ B4#,5#	99/7~	Steering (P/S) P/S GEAR GASKET KIT
03901 4437	90029-21010	24 x 36 x 7 x 7.5	COASTER RB2#,BB2#,3#,HB3#,HDB2 0,3#,HZB3#	82/5~93/	Steering (P/S) STEERING WORM
03901 3491	90311-48135	48 x 82 x 12	COASTER RB2#,BB2#,3#,HB3#,HDB2 0,3#,HZB3#	82/5~93/	Final Drive PINION
03901 1269	90913-02062		COMFORT 1GGPE (EX.)	95/12~01/ 12	Engine VALVE STEM SEAL
03901 4565	90311-80009	80 x 100 x 10	COMFORT 3YPE YXS1#	95/12~	Engine CRANK SHAFT REAR
03901 5991	90311-45015	45 x 62 x 9	COMFORT 1GGPE GXS12	01/8~	Engine TIMING GEAR CASE
03901 2695	90311-45010	45 x 62 x 8.5	COMFORT 1GGPE GXS10	95/12~	Engine TIMING GEAR CASE
03901 7315	90311-42026	42 x 60 x 7	COMFORT 4SFE SXS11	96/4~96/9	Engine CRANK SHAFT FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1391	90311-42035	42 x 60 x 7	COMFORT 3SFE,4SFE SXS1#	96/9~	Engine CRANK SHAFT FRONT
03901 8237	90311-85007	85 x 105 x 10	COMFORT 2LTE LXS11	95/12~99/	Engine CRANK SHAFT REAR
03901 2253	90311-85007	85 x 105 x 10	COMFORT 3SFE,4SFE SXS1#	95/12~	Engine CRANK SHAFT REAR
03901 4573	90311-75007	75 x 100 x 10	COMFORT 1G#...GXS1#	95/12~	Engine CRANK SHAFT REAR
03901 5989	90913-02110		COMFORT 2LTE	95/12~97/ 5	Engine VALVE STEM SEAL
03901 7611	90913-02117		COMFORT 2LTE	97/5~99/	Engine VALVE STEM SEAL
03901 6487	90913-02094		COMFORT 3YPE	95/12~	Engine VALVE STEM SEAL
03901 6339	90913-02079		COMFORT 3SFE,4SFE (IN.)	96/4~	Engine VALVE STEM SEAL
03901 6219	90913-02062		COMFORT 3SFE,4SFE (EX.)	96/4~	Engine VALVE STEM SEAL
03901 7291	90913-02123		COMFORT 1GGPE (IN.)	01/12~	Engine VALVE STEM SEAL
03901 7995	90311-42026	42 x 60 x 7	COMFORT 2LTE LXS11	95/12~99/	Engine TIMING GEAR CASE
03901 6531	90913-02122		COMFORT 1GGPE (EX.)	01/10~	Engine VALVE STEM SEAL
03901 4831	04332-30030	Kit	COMFORT GXS1#,LXS11,SXS1#,YXS1 #	95/12~	Transmission (A/T) REAR EXTENTON
03901 4843	90913-02106		COMFORT 1GGPE (IN.)	95/12~01/ 12	Engine VALVE STEM SEAL
03901 2511	90311-30014	30 x 45 x 8	COMFORT LXS11,SXS1#,YXS1#	95/12~	Transmission (M/T) FRONT COVER
03901 7845	04445-43010		COMFORT GXS1#,LXS11,SXS1#,YXS1 #	95/12~	Steering (P/S) R & P GASKET KIT
03901 7811	90311-52059	52 x 65 x 9	COMFORT GXS1#,LXS11,SXS1#,YXS1 #	95/12~	Wheel Hub REAR
03901 6809	15165-70040	18 x 30 x 7	COMFORT 1GGPE GXS10	95/12~01/ 2	Engine OIL PUMP
03901 2615	90311-38032	38 x 58 x 11	COMFORT LXS11,SXS1#,YXS1#	95/12~	Transmission (M/T) REAR EXTENTION
03901 6873	90311-38020	38 x 55 x 8.5	COMFORT GXS10,LXS11,SXS11,YXS1 #	95/12~96/ 10	Transmission (A/T) FRONT OIL PUMP
03901 6349	90311-38020	38 x 55 x 8.5	COMFORT SXS11	96/10~00/ 5	Transmission (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2241	90311-38058	38 x 55 x 8.5	COMFORT GXSI0,LXS11,YXS1#	96/10~	Transmission (A/T) FRONT OIL PUMP
03901 7631	90311-38064	38 x 55 x 8.7	COMFORT GXSI2,SXS1#	00/5~	Transmission (A/T) FRONT OIL PUMP
03901 1975	90311-38067	38 x 50 x 8	COMFORT 3SFE,4SFE SXS1#	97/8~	Engine CAM SHAFT
03901 6423	15165-70010	18 x 30 x 7	COMFORT 4SFE SXS11	96/4~01/8	Engine OIL PUMP
03901 3623	90311-48013	48 x 73 x 7	COMFORT GXSI#,LXS11,SXS1#,YXS1#	95/12~	Wheel Hub FRONT
03901 8249	90311-38047	38 x 74 x 11 x 18	COMFORT GXSI#,LXS11,SXS1#,YXS1#	95/12~	Final Drive PINION
03901 5647	90311-35040	35 x 49 x 6	COMFORT 1GGPE GXSI0	95/12~	Engine CAM SHAFT
03901 1425	90311-38036	38 x 50 x 8	COMFORT 4SFE SXS11	96/4~97/8	Engine CAM SHAFT
03901 1561	90311-32020	32 x 46 x 6	COMFORT 2LTE LXS11	95/12~99/	Engine CAM SHAFT
03901 4797	90310-25027	25 x 38 x 7	COMFORT GXSI#,LXS11,SXS1#,YXS1#	95/12~	Steering (P/S) CONTROL VALVE LOWER
03901 4623	90311-19002	19 x 32 x 7 x 8	COMFORT GXSI#,LXS11,SXS1#,YXS1#	95/12~	Steering (P/S) CONTROL VALVE UPPER
03901 2367	90311-34016	34 x 54 x 9 x 15.5	COROLLA (FWD) AE8#,9#,EE80,9#	83/5~92/	Mission & Differential (M/T) TRANSAXLE CASE
03901 4025	90311-25011	25 x 37 x 8	COROLLA (FWD) AE8#,9#,EE80,9#	83/5~92/	Mission & Differential (M/T) INPUT SHAFT
03901 2093	90311-52059	52 x 65 x 9	COROLLA (FWD) AE109,CE105,109 (4WD)	91/9~	Wheel Hub REAR
03901 4067	90311-56007	56 x 75 x 6.5 x 11	COROLLA (FWD) AE104,114,CE104,114 (4WD)	91/9~	Wheel Hub REAR INNER
03901 1579	90311-48001	48 x 62 x 9	COROLLA (FWD) EE102,103,104,106,107,108	91/9~	Wheel Hub REAR
03901 2411	90311-48001	48 x 62 x 9	COROLLA (FWD) CE102,106,107,108	91/9~	Wheel Hub REAR
03901 7947	90311-52010	52 x 65 x 7.5 x 12	COROLLA (FWD) AE104,114,CE104,114 (4WD)	91/9~	Wheel Hub REAR OUTER
03901 1583	90311-42055	42 x 55 x 7	COROLLA (FWD) AE95,CE95 (4WD)	87/10~91/	Wheel Hub REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5311	90311-25011	25 x 37 x 8	COROLLA (FWD) AE10#,11#,EE10#,111 2WD	91/6~	Mission & Differential (M/T) INPUT SHAFT
03901 6613	90311-25011	25 x 37 x 8	COROLLA (FWD) NZE12#,ZZE12#	00/8~	Mission & Differential (M/T) INPUT SHAFT
03901 7781	90311-30006	30 x 42 x 7	COROLLA (FWD) AE104,109,114 (4WD)	91/6~	Mission & Differential (M/T) INPUT SHAFT
03901 4491	90311-34016	34 x 54 x 9 x 15.5	COROLLA (FWD) AE10#,11#,EE10#,111 2WD	91/6~	Mission & Differential (M/T) TRANSAXLE CASE
03901 5491	90311-48001	48 x 62 x 9	COROLLA (FWD) CE96,97,EE96,97,98	87/8~91/	Wheel Hub REAR
03901 3709	90311-35033	35 x 55 x 9 x 15.5	COROLLA (FWD) CE80,9#,10#,11#...2WD	83/5~	Mission & Differential (M/T) TRANSAXLE CASE
03901 4425	90311-34016	34 x 54 x 9 x 15.5	COROLLA (FWD) NZE12#	00/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 3261	90311-30006	30 x 42 x 7	COROLLA (FWD) CE80,9#,10#,11#,12#	83/5~	Mission & Differential (M/T) INPUT SHAFT
03901 1863	90311-40025	40 x 64 x 8 x 14.5	COROLLA (FWD) CE121	00/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 1539	04422-12020	Kit	COROLLA (FWD) AE9#,CE9#,EE9#...WITHOUT ABS	87/5~91/	Wheel Hub FRONT
03901 6755	04422-12020	Kit	COROLLA (FWD) AE10#,CE10#,EE10#...WIT HOUT ABS	91/6~95/5	Wheel Hub FRONT
03901 2389	04422-12091	Kit	COROLLA (FWD) AE10#,CE10#,EE10#...WIT HOUT ABS	95/5~	Wheel Hub FRONT
03901 3739	04422-12091	Kit	COROLLA (FWD) AE11#,CE11#,EE111 WITHOUT ABS	95/5~	Wheel Hub FRONT
03901 6537	04422-12030	Kit	COROLLA (FWD) AE9#...WITH ABS	89/5~92/	Wheel Hub FRONT
03901 8145	04422-12030	Kit	COROLLA (FWD) AE10#,CE100,104,EE101 WITH ABS	91/6~	Wheel Hub FRONT
03901 2489	04422-20080	Kit	COROLLA (FWD) AE101GT,GTZ ABS,SSS	92/4~95/	Wheel Hub FRONT
03901 6133	04422-12030	Kit	COROLLA (FWD) AE11#,CE11#,EE111 WITH ABS	95/5~	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5167	90311-41004	41 x 55 x 7 x 12	COROLLA (FWD) AE91 (ABS),AE92	87/5~91/	Wheel Hub REAR
03901 2349	04422-12111	Kit	COROLLA (FWD) AE111BZV,BZG (SSS)	95/5~	Wheel Hub FRONT
03901 5445	04422-12121	Kit	COROLLA (FWD) AE111BZG (ABS & SSS),AE111BZV (ABS)	95/5~	Wheel Hub FRONT
03901 7101	90311-41003	41 x 55 x 6	COROLLA (FWD) AE80,81,CE80,EE80	83/5~87/	Wheel Hub REAR
03901 4993	90311-41003	41 x 55 x 6	COROLLA (FWD) AE82 (EXC. GT,FXT)	83/5~87/	Wheel Hub REAR
03901 2247	90311-41003	41 x 55 x 6	COROLLA (FWD) AE91 WITHOUT ABS,CE90,EE9#	87/5~91/	Wheel Hub REAR
03901 5107	90311-41004	41 x 55 x 7 x 12	COROLLA (FWD) AE82 (GT,FXT)	84/10~87/	Wheel Hub REAR
03901 7081	90311-34012	34 x 54 x 9 x 15.5	COROLLA (FWD) EE80,90,96,98,10#,111 3FC	83/5~98/3	Mission & Differential (A/T) TRANSAXLE CASE
03901 3737	90311-34012	34 x 54 x 9 x 15.5	COROLLA (FWD) EE80,90,96,98,10#,111 3FC	83/5~98/2	Mission & Differential (A/T) DIFFERENTIAL SIDE
03901 2843	90311-35033	35 x 55 x 9 x 15.5	COROLLA (FWD) CE80,9#,10#,11#...2WD	83/5~	Mission & Differential (M/T) DUFFERENTIAL SIDE
03901 4095	90311-34012	34 x 54 x 9 x 15.5	COROLLA (FWD) AE81,82,91,92,100,101,111 4FC	83/5~98/2	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3083	90311-34012	34 x 54 x 9 x 15.5	COROLLA (FWD) AE101,111 4FC	98/2~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 7057	90311-34016	34 x 54 x 9 x 15.5	COROLLA (FWD) AE100,110 4FC	98/2~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 6251	90311-35033	35 x 55 x 9 x 15.5	COROLLA (FWD) CE80,9#,10#,11#...2WD 4FC	84/1~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3523	90311-35033	35 x 55 x 9 x 15.5	COROLLA (FWD) ZZE123 4FC	00/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1077	90311-35046	35 x 57 x 9 x 15.5	COROLLA (FWD) CE121,ZZE122,124	00/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 4251	90311-34012	34 x 54 x 9 x 15.5	COROLLA (FWD) AE80,81,91,100 3FC	83/5~98/2	Mission & Differential (A/T) DIFFERENTIAL SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1503	90311-49002	50 x 64 x 8	COROLLA (FWD) ZZE124	00/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.1)
03901 7953	90311-34022	34 x 56 x 9 x 15	COROLLA (FWD) EE10#,111 3FC	98/2~	Mission & Differential (A/T) DIFFERENTIAL SIDE
03901 5305	90311-35033	35 x 55 x 9 x 15.5	COROLLA (FWD) ZZE123 4FC	00/8~	Mission & Differential (A/T) DIFFERENTIAL SIDE
03901 7373	90311-38020	38 x 55 x 8.5	COROLLA (FWD) AE8#,9#,10#,11#,CE8#,9#,10 #,110	83/5~	Mission & Differential (A/T) FRONT OIL PUMP
03901 6953	90311-38020	38 x 55 x 8.5	COROLLA (FWD) EE80,9#,10#,111	83/5~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4125	90311-15001	15 x 25 x 7	COROLLA (FWD) AE8#,9#,CE8#,9#,EE80,9#	83/5~89/5	Steering (M/S) RACK HOUSING
03901 4415	90311-15002	15 x 25 x 7	COROLLA (FWD) AE9#,100,110,CE9#,10#,110, EE9#,10#,111	89/5	Steering (M/S) RACK HOUSING
03901 5683	04445-12020		COROLLA (FWD) EE80,CE80,AE8#...TOYOT A GEAR BOX	83/5~87/	Steering (P/S) R & P GASKET KIT
03901 5315	90311-38075	38 x 55 x 7.8	COROLLA (FWD) NZE120 4FC	00/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4017	90311-19007	19 x 38 x 7	COROLLA (FWD) EE111,CE11#,AE11#(TOYO TA G/B)	95/5~00/	Steering (P/S) CONTROL VALVE UPPER
03901 3455	90311-34017	34 x 63 x 9 x 16	COROLLA (FWD) AE8#,9#,EE80,9#	83/5~92/	Mission & Differential (M/T) TRANSMISSION CASE
03901 6151	90311-34017	34 x 63 x 9 x 16	COROLLA (FWD) AE10#,11#,EE10#,111 2WD	91/6~	Mission & Differential (M/T) TRANSMISSION CASE
03901 4147	90311-34017	34 x 63 x 9 x 16	COROLLA (FWD) NZE120,121	00/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 7241	90311-44003	44 x 80 x 9 x 15.5	COROLLA (FWD) AE10#,114,CE10#,11#...4W D	91/9~	Mission & Differential (M/T) TRANSMISSION CASE
03901 4523	90311-35044	35 x 63 x 10 x 22	COROLLA (FWD) ZZE122,123	00/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 6559	90311-50024	50 x 80 x 11 x 17.5	COROLLA (FWD) CE121	00/8~	Mission & Differential (M/T) TRANSMISSION CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5643	90311-49002	50 x 64 x 8	COROLLA (FWD) NZE124	00/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 6069	90311-34012	34 x 54 x 9 x 15.5	COROLLA (FWD) AE80,91,100 3FC	83/5~98/3	Mission & Differential (A/T) TRANSAXLE CASE
03901 4375	90311-35051	35 x 54 x 9 x 21.5	COROLLA (FWD) ZZE122,123	00/8~	Mission & Differential (M/T) TRANSAXLE CASE
03901 3989	90311-34016	34 x 54 x 9 x 15.5	COROLLA (FWD) EE10#,111 3FC	98/3~	Mission & Differential (A/T) TRANSAXLE CASE
03901 5907	90311-34013	34 x 63 x 9 x 15	COROLLA (FWD) AE81,91,92,100,101,111 4FC	83/5~	Mission & Differential (A/T) TRANSAXLE CASE
03901 3417	90311-44003	44 x 80 x 9 x 15.5	COROLLA (FWD) AE104,109,114 (4WD) 4FC	91/9~	Mission & Differential (A/T) TRANSAXLE CASE
03901 1255	90311-35020	35 x 63 x 9 x 15.5	COROLLA (FWD) CE80,9#,10#,11#...2WD 4FC	84/1~	Mission & Differential (A/T) TRANSAXLE CASE
03901 6879	90311-34017	34 x 63 x 9 x 16	COROLLA (FWD) NZE120 4FC	00/8~	Mission & Differential (A/T) TRANSAXLE CASE
03901 1821	90311-34022	34 x 56 x 9 x 15	COROLLA (FWD) NZE121,124 4FC	00/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.1)
03901 6849	90311-35033	35 x 55 x 9 x 15.5	COROLLA (FWD) CE121,ZZE122 4FC	00/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.1)
03901 3833	04422-20010	Kit	COROLLA (FWD) AE8#,CE80,EE80	83/5~87	Wheel Hub FRONT
03901 2239	90311-70007	70 x 92 x 8.5	COROLLA (FWD) 4A,4A AE9#,10#,11#	91/6~	Engine CRANK SHAFT REAR
03901 5881	90311-38059	38 x 50 x 8	COROLLA (FWD) 1ZZ,2ZZ ZZE12#	00/8~	Engine TIMING GEAR COVER
03901 2393	90311-75016	75 x 107 x 8	COROLLA (FWD) 1NZ,2NZ NZE12#	00/8~	Engine CRANK SHAFT REAR
03901 4059	90311-90005	90 x 110 x 8.5 x 10	COROLLA (FWD) 1C,2C,3C CE9#,10#,11#,121	90/2~	Engine CRANK SHAFT REAR
03901 1007	90311-90003	90 x 110 x 8.5 x 10	COROLLA (FWD) 1C,2C CE80,9#	83/5~90/2	Engine CRANK SHAFT REAR
03901 2413	90311-80012	80 x 100 x 8.5	COROLLA (FWD) 3E,5E EE98,103,104,107,108	91/8	Engine CRANK SHAFT REAR
03901 4981	90311-80003	80 x 100-8.5 x	COROLLA (FWD) 3E EE98	87/8~91/8	Engine CRANK SHAFT REAR
03901 5953	90311-85007	85 x 105 x 10	COROLLA (FWD) 2ZZ ZZE123	00/8~	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7339	90311-75004	75 x 100 x 8.5	COROLLA (FWD) 2E EE80,9#	85/5~90/1 0	Engine CRANK SHAFT REAR
03901 3253	90913-02038		COROLLA (FWD) 2A- LU,3A-LU,4A-LU	83/5~87/4	Engine VALVE STEM SEAL
03901 4769	90311-70004	70 x 92 x 8.5	COROLLA (FWD) 2A,3A,4A,5A AE8#,9#	83/5~91/6	Engine CRANK SHAFT REAR
03901 6807	90311-35040	35 x 49 x 6	COROLLA (FWD) 4E,5E EE10#,111	96/4~	Engine CRANK SHAFT FRONT
03901 4917	90311-42026	42 x 60 x 7	COROLLA (FWD) 1C,2C,3C CE9#,10#,11#,121	90/10~	Engine CRANK SHAFT FRONT
03901 1033	90311-42015	42 x 60 x 6	COROLLA (FWD) 1C,2C CE9#	85/5~90/1 0	Engine CRANK SHAFT FRONT
03901 6841	90311-42003	42 x 60 x 7	COROLLA (FWD) 1C CE80,9#	83/5~85/5	Engine CRANK SHAFT FRONT
03901 6887	90311-19007	19 x 38 x 7	COROLLA (FWD) EE80,CE80,AE8# (TOYOTA G/B)	83/5~87/	Steering (P/S) CONTROL VALVE UPPER
03901 3383	90311-75009	75 x 100 x 8.5	COROLLA (FWD) 2E,4E EE9#,101,102,106,111	90/10~	Engine CRANK SHAFT REAR
03901 5469	90913-02110		COROLLA (FWD) 2C	95/11~97/ 4	Engine VALVE STEM SEAL
03901 4249	04445-12030		COROLLA (FWD) AE81,82 KOYO GEAR BOX	83/5~87/	Steering (P/S) R & P GASKET KIT
03901 2459	90913-02115		COROLLA (FWD) 2ZZGE (IN.)	00/8~	Engine VALVE STEM SEAL
03901 7945	90913-02114		COROLLA (FWD) 2ZZGE (EX.)	00/8~	Engine VALVE STEM SEAL
03901 7085	90913-02101		COROLLA (FWD) 1ZZFE (IN.)	00/8~	Engine VALVE STEM SEAL
03901 3581	90913-02111		COROLLA (FWD) 1ZZFE (EX.)	00/8~	Engine VALVE STEM SEAL
03901 5163	90913-02093		COROLLA (FWD) 1NZFE,2NZFE (IN. & EX.)	00/8~	Engine VALVE STEM SEAL
03901 7273	90311-76001	76 x 94 x 8.5	COROLLA (FWD) 1ZZ ZZE122,124	00/8~	Engine CRANK SHAFT REAR
03901 4703	90913-02117		COROLLA (FWD) 2C,3C	97/4~	Engine VALVE STEM SEAL
03901 8267	90311-25021	25.5 x 37.5 x 6	COROLLA (FWD) 1NZ,2NZ NZE12#	00/8~	Engine OIL PUMP
03901 4569	90913-02094		COROLLA (FWD) 1C,2C	90/1~95/1 1	Engine VALVE STEM SEAL
03901 7161	90913-02110		COROLLA (FWD) 1C,2C	83/5~90/1	Engine VALVE STEM SEAL
03901 7709	90913-02062		COROLLA (FWD) 2E,3E,4E,5E	83/5~	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7563	90913-02079		COROLLA (FWD) 4AFE,5AFE IN.	90/10~	Engine VALVE STEM SEAL
03901 7311	90913-02062		COROLLA (FWD) 4AFE,5AFE EX.	90/10~	Engine VALVE STEM SEAL
03901 7509	90913-02062		COROLLA (FWD) 4AFE,5AFE IN. & EX.	87/5~90/10	Engine VALVE STEM SEAL
03901 2453	90913-02093		COROLLA (FWD) 4AGE (IN. & EX.)	91/6~00/	Engine VALVE STEM SEAL
03901 5515	04445-12170		COROLLA (FWD) CE121,NZE124,ZZE12#	00/8~	Steering (P/S) R & P GASKET KIT
03901 6799	90311-35013	35 x 49 x 6	COROLLA (FWD) 2E,3E4E EE9#,10#	87/5~96/4	Engine CRANK SHAFT FRONT
03901 1061	90310-23005	23 x 34 x 6.5	COROLLA (FWD) EE10#,CE10#,AE10#(TOYOTA G/B)	91/6~	Steering (P/S) CONTROL VALVE LOWER
03901 5479	90310-23005	23 x 34 x 6.5	COROLLA (FWD) EE80,CE80,AE8# (TOYOTA G/B)	83/5~87/	Steering (P/S) CONTROL VALVE LOWER
03901 2727	90311-19010	19 x 32 x 6	COROLLA (FWD) EE111,CE11#,AE11#(KOYO G/B)	95/5~00/	Steering (P/S) CONTROL VALVE UPPER
03901 5547	90311-19010	19 x 32 x 6	COROLLA (FWD) EE10#,CE10#,AE10#(KOYO G/B)	91/6~	Steering (P/S) CONTROL VALVE UPPER
03901 1373	90311-19010	19 x 32 x 6	COROLLA (FWD) EE9#,CE9#,AE9#(KOYO G/B)	87/5~91/	Steering (P/S) CONTROL VALVE UPPER
03901 6545	90310-23004	23 x 35 x 6.5	COROLLA (FWD) AE8#(KOYO G/B)	83/5~87/	Steering (P/S) CONTROL VALVE LOWER
03901 3975	90311-19007	19 x 38 x 7	COROLLA (FWD) EE10#,CE10#,AE10#(TOYOTA G/B)	91/6~	Steering (P/S) CONTROL VALVE UPPER
03901 5585	90311-26003	26 x 38 x 6.5	COROLLA (FWD) EE9#,CE9#,AE9#(KOYO G/B)	87/5~91/	Steering (P/S) CONTROL VALVE LOWER
03901 2555	04445-12160		COROLLA (FWD) AE11#...KOYO GEAR BOX	95/5~00/	Steering (P/S) R & P GASKET KIT
03901 7221	04445-12160		COROLLA (FWD) AE10#...KOYO GEAR BOX	95/5~	Steering (P/S) R & P GASKET KIT
03901 2161	04445-12150		COROLLA (FWD) AE11#...TOYOTA GEAR BOX,CE 11#,EE11#	95/5~00/	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5519	04445-12150		COROLLA (FWD) AE10#...TOYOTA GEAR BOX,CE10#,EE10#	95/5~	Steering (P/S) R & P GASKET KIT
03901 1837	04445-12110		COROLLA (FWD) AE10#...TOYOTA GEAR BOX,CE10#,EE10#	91/6~95/5	Steering (P/S) R & P GASKET KIT
03901 3091	04445-12100		COROLLA (FWD) AE10#...KOYO GEAR BOX	91/6~95/5	Steering (P/S) R & P GASKET KIT
03901 2523	90311-19010	19 x 32 x 6	COROLLA (FWD) AE8#(KOYO G/B)	83/5~87/	Steering (P/S) CONTROL VALVE UPPER
03901 1301	90311-38025	38 x 50 x 6	COROLLA (FWD) 1C,2C CE80,9#	85/1~90/1 0	Engine CAM SHAFT
03901 8163	90029-21022	22 x 34 x 6.5	COROLLA (FWD) 2C,3C CE9#,10#,11#	89/5~	Engine OIL PUMP
03901 4481	90029-21020	20 x 32 x 5	COROLLA (FWD) 1C,2C CE80,9#	85/5~89/5	Engine OIL PUMP
03901 1099	15165-64010	20 x 32 x 7	COROLLA (FWD) 1C CE80	83/5~85/5	Engine OIL PUMP
03901 3347	90029-21020	20 x 32 x 5	COROLLA (FWD) 2E,3E,4E,5E EE9#,10#,111	87/5~	Engine OIL PUMP
03901 6247	90029-21020	20 x 32 x 5	COROLLA (FWD) 2E EE80	86/4~87/	Engine OIL PUMP
03901 2611	90029-21005	18 x 30 x 5	COROLLA (FWD) 2E EE80	85/5~86/4	Engine OIL PUMP
03901 2771	90310-23005	23 x 34 x 6.5	COROLLA (FWD) EE111,CE11#,AE11#(TOYO TA G/B)	95/5~00/	Steering (P/S) CONTROL VALVE LOWER
03901 5451	90311-38044	38 x 50 x 6	COROLLA (FWD) 1C,2C CE9#,10#,11#,121	90/1	Engine CAM SHAFT
03901 2755	04445-12051		COROLLA (FWD) EE9#,CE9#,AE9#...KOYO GEAR BOX	87/5~91/	Steering (P/S) R & P GASKET KIT
03901 6363	90311-38036	38 x 50 x 8	COROLLA (FWD) 1C CE80	83/5~85/1	Engine CAM SHAFT
03901 6653	90311-40015	40 x 54.5 x 7	COROLLA (FWD) 4AGE AE101,111(INTAKE)	91/6~00/	Engine CAM SHAFT
03901 3497	90311-35013	35 x 49 x 6	COROLLA (FWD) 2E,3E,4E,5E EE8#,9#,10#,11#	83/5~	Engine CAM SHAFT
03901 1697	90311-35013	35 x 49 x 6	COROLLA (FWD) 4AGE AE101,111(EXHAUST)	91/6~00/	Engine CAM SHAFT
03901 2681	90311-35013	35 x 49 x 6	COROLLA (FWD) 2A,3A,4A,5A AE8#,9#,10#,11#	83/5~	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4409	90311-26003	26 x 38 x 6.5	COROLLA (FWD) AE11#(KOYO G/B)	95/5~00/	Steering (P/S) CONTROL VALVE LOWER
03901 5193	90311-26003	26 x 38 x 6.5	COROLLA (FWD) AE10#(KOYO G/B)	91/6~95/	Steering (P/S) CONTROL VALVE LOWER
03901 4865	90311-32020	32 x 46 x 6	COROLLA (FWD) 4A,5A AE9#,10#,11#	87/5~	Engine OIL PUMP
03901 1143	90310-34003	34 x 46 x 8	COROLLA (RWD) TE71	81/8~87/	Steering (M/S) SECTOR SHAFT
03901 3103	90311-42083	42 x 65 x 12	COROLLA (RWD) KE7#	79/3~81/8	Transmission (A/T) FRONT OIL PUMP
03901 1177	90311-17092	17.4 x 30 x 7	COROLLA (RWD) KE72,74,TE7#	81/8~87/	Steering (M/S) WORM GEAR
03901 6919	90310-28027	28 x 40 x 8	COROLLA (RWD) KE72,74,TE74,CE7#	81/8~87/	Steering (M/S) SECTOR SHAFT
03901 1045	90310-28027	28 x 40 x 8	COROLLA (RWD) KE71,AE70,TE7#	79/3~81/8	Steering (M/S) SECTOR SHAFT
03901 1511	90311-38015	38 x 65 x 12 x 19	COROLLA (RWD) AE70.8#,TE7#,CE7#	79/3~87/	Final Drive PINION
03901 3579	90311-38015	38 x 65 x 12 x 19	COROLLA (RWD) KE7# (EXC.KE70)	79/3~87/	Final Drive PINION
03901 7621	90311-35131	35 x 55 x 11	COROLLA (RWD) KE70	79/3~83/	Final Drive PINION
03901 2409	90311-11128	11 x 22 x 7	COROLLA (RWD) AE70.8#,TE7#,CE7#	79/8~87/	Transmission (A/T) LEVER SHAFT
03901 3657	90311-11128	11 x 22 x 7	COROLLA (RWD) KE7#	81/8~87/	Transmission (A/T) LEVER SHAFT
03901 3461	04332-30020	Kit	COROLLA (RWD) AE70.8#,TE7#,CE7#	79/8~87/	Transmission (A/T) EXTENTION HOUSING
03901 4681	04332-30020	Kit	COROLLA (RWD) KE7#	81/8~87/	Transmission (A/T) EXTENTION HOUSING
03901 2217	90311-32074	32 x 52 x 11	COROLLA (RWD) KE7#	79/3~81/8	Transmission (A/T) EXTENTION HOUSING
03901 1175	90311-19001	19 x 32 x 8	COROLLA (RWD) CE7#	82/2~87/	Steering (M/S) WORM GEAR
03901 2181	90311-38020	38 x 55 x 8.5	COROLLA (RWD) KE7#	81/8~87/	Transmission (A/T) FRONT OIL PUMP
03901 6109	90311-17092	17.4 x 30 x 7	COROLLA (RWD) KE71,AE70,TE7#	79/3~81/8	Steering (M/S) WORM GEAR
03901 6015	90311-38043	38 x 58 x 11	COROLLA (RWD) CE7#	82/2~87/	Transmission (M/T) REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7095	90311-32074	32 x 52 x 11	COROLLA (RWD) KE7#,AE70,8#,TE7#	79/3~87/	Transmission (M/T) REAR
03901 7275	90311-30115	30 x 45 x 8	COROLLA (RWD) CE7#	82/2~87/	Transmission (M/T) FRONT COVER
03901 4553	90311-25003	25 x 38 x 7	COROLLA (RWD) KE7#,AE70,8#,TE7#	79/3~87/	Transmission (M/T) FRONT COVER
03901 5217	90311-52059	52 x 65 x 9	COROLLA (RWD) AE86	83/5~87/	Wheel Hub REAR
03901 4411	90311-52059	52 x 65 x 9	COROLLA (RWD) TE70,71	79/3~83/	Wheel Hub REAR
03901 2337	90311-42055	42 x 55 x 7	COROLLA (RWD) AE85	83/5~87/	Wheel Hub REAR
03901 1855	90311-42055	42 x 55 x 7	COROLLA (RWD) KE7#,AE70,TE73,74,CE7#	79/3~87/	Wheel Hub REAR
03901 1809	90311-41123	41 x 53 x 7	COROLLA (RWD) AE85,86	83/5~87/	Wheel Hub FRONT
03901 6941	90311-41123	41 x 53 x 7	COROLLA (RWD) KE7#,AE70,TE7#,CE7#	79/3~87/	Wheel Hub FRONT
03901 7979	90913-02110		COROLLA (RWD) 1C	82/2~87/	Engine VALVE STEM SEAL
03901 6775	90311-38020	38 x 55 x 8.5	COROLLA (RWD) AE70.8#,TE7#,CE7#	79/8~87/	Transmission (A/T) FRONT OIL PUMP
03901 4447	90311-42003	42 x 60 x 7	COROLLA (RWD) 1C CE7#	82/2~85/5	Engine CRANK SHAFT FRONT
03901 3807	90913-02056		COROLLA (RWD) 4A	83/5~87/	Engine VALVE STEM SEAL
03901 3997	90913-02038		COROLLA (RWD) 3A	79/3~87/	Engine VALVE STEM SEAL
03901 5561	90913-02058		COROLLA (RWD) 12T,13T (EX.)	81/1~83/	Engine VALVE STEM SEAL
03901 4191	90913-02024		COROLLA (RWD) 12T,13T (IN.)	81/1~83/	Engine VALVE STEM SEAL
03901 5259	90913-02024		COROLLA (RWD) 2T,12T,13T (IN. & EX.)	79/8~81/1	Engine VALVE STEM SEAL
03901 5727	90913-02056		COROLLA (RWD) 4K,5K	81/1~87/	Engine VALVE STEM SEAL
03901 5737	90913-02024		COROLLA (RWD) 4K	79/8~81/1	Engine VALVE STEM SEAL
03901 3025	90311-90003	90 x 110 x 8.5 x 10	COROLLA (RWD) 1C CE7#	82/2~87/	Engine CRANK SHAFT REAR
03901 2149	90311-75114	75 x 100 x 13	COROLLA (RWD) 2T,12T,13T TE7#	79/8~83/	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7775	90311-70004	70 x 92 x 8.5	COROLLA (RWD) 3A,4A AE70,85,86	79/3~87/	Engine CRANK SHAFT REAR
03901 7561	90311-42015	42 x 60 x 6	COROLLA (RWD) 1C CE7#	85/5~87/	Engine CRANK SHAFT FRONT
03901 7961	90311-15001	15 x 25 x 7	COROLLA (RWD) KE70	79/3~81/8	Steering (M/S) RACK HOUSING
03901 2913	90029-21020	20 x 32 x 5	COROLLA (RWD) 1C CE7#	85/5~87/	Engine OIL PUMP
03901 3675	90311-19002	19 x 32 x 7 x 8	COROLLA (RWD) AE70,85,86,TE70	81/8~87/	Steering (P/S) ADJUSTER PLUG
03901 5431	90311-15001	15 x 25 x 7	COROLLA (RWD) KE70,73,AE70,85,86	81/8~87/	Steering (M/S) RACK HOUSING
03901 4043	04445-12010		COROLLA (RWD) AE70	81/8~83/	Steering (P/S) R & P GASKET KIT
03901 6743	90311-70004	70 x 92 x 8.5	COROLLA (RWD) 4K,5K KE7#	79/8~87/	Engine CRANK SHAFT REAR
03901 2967	04445-12010		COROLLA (RWD) AE85,86	83/5~85/	Steering (P/S) R & P GASKET KIT
03901 6231	15165-64010	20 x 32 x 7	COROLLA (RWD) 1C CE7#	82/2~85/5	Engine OIL PUMP
03901 2125	90311-38013	38.5 x 58 x 11	COROLLA (RWD) 4K KE7#	79/8~82/4	Engine TIMING GEAR COVER
03901 6995	90311-38022	38.5 x 58 x 8.5	COROLLA (RWD) 4K,5K KE7#	82/5~87/	Engine TIMING GEAR COVER
03901 1507	90311-38013	38.5 x 58 x 11	COROLLA (RWD) 2T,12T,13T TE7#	79/8~83/	Engine TIMING GEAR COVER
03901 7835	90311-35013	35 x 49 x 6	COROLLA (RWD) 3A,4A AE70,85,86	79/3~87/	Engine CAM SHAFT
03901 7935	90311-38036	38 x 50 x 8	COROLLA (RWD) 1C CE7#	82/2~85/1	Engine CAM SHAFT
03901 2531	90311-38025	38 x 50 x 6	COROLLA (RWD) 1C CE7#	85/1~87/	Engine CAM SHAFT
03901 4403	90311-32020	32 x 46 x 6	COROLLA (RWD) 3A,4A AE70,85,86	79/3~87/	Engine OIL PUMP
03901 7767	04422-12030	Kit	COROLLA SPACIO AE11#	97/1~	Wheel Hub FRONT
03901 6505	90311-34013	34 x 63 x 9 x 15	COROLLA SPACIO AE111	97/1~	Mission & Differential (M/T) TRANSAXLE CASE
03901 1643	90311-52010	52 x 65 x 7.5 x 12	COROLLA SPACIO AE115 (4WD)	97/7~	Wheel Hub REAR OUTER
03901 6111	90311-44003	44 x 80 x 9 x 15.5	COROLLA SPACIO AE115 (4WD)	97/1~	Mission & Differential (M/T) TRANSAXLE CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8035	90311-34012	34 x 54 x 9 x 15.5	COROLLA SPACIO AE111	97/1~	Mission & Differential (M/T) TRANSAXLE HOUSING
03901 5475	90311-38020	38 x 55 x 8.5	COROLLA SPACIO AE11#	97/1~	Mission & Differential (M/T) FRONT OIL PUMP
03901 1419	04445-12150		COROLLA SPACIO AE11#	97/1~	Steering (P/S) R & P GASKET KIT
03901 1101	90310-23005	23 x 34 x 6.5	COROLLA SPACIO AE11#	97/1~	Steering (P/S) CONTROL VALVE LOWER
03901 3611	90311-35013	35 x 49 x 6	COROLLA SPACIO 4AFE,7AFE AE11#	97/1~	Engine CAM SHAFT
03901 4837	90311-32020	32 x 46 x 6	COROLLA SPACIO 4AFE,7AFE AE11#	97/1~	Engine OIL PUMP
03901 1849	90311-70007	70 x 92 x 8.5	COROLLA SPACIO 4AFE,7AFE AE11#	97/1~	Engine CRANK SHAFT REAR
03901 7997	90913-02062		COROLLA SPACIO 4AFE,7AFE	97/1~	Engine VALVE STEM SEAL
03901 5257	90913-02079		COROLLA SPACIO 4AFE,7AFE	97/1~	Engine VALVE STEM SEAL
03901 5673	90311-19007	19 x 38 x 7	COROLLA SPACIO AE11#	97/1~	Steering (P/S) CONTROL VALVE UPPER
03901 2221	90311-56007	56-75 x 6.5 x 11	COROLLA SPACIO AE115 (4WD)	97/7~	Wheel Hub REAR INNER
03901 2553	90311-35033	35 x 55 x 9 x 15.5	CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203	87/8~98/	Mission & Differential (A/T) TRANSAXLE CASE
03901 1181	90311-42018	42 x 55 x 6	CORONA (COUPE / EXIV) ST16#,18#	87/8~93/	Wheel Hub REAR
03901 3451	90311-56015	56 x 75 x 7 x 12	CORONA (COUPE / EXIV) ST205 (4WD)	94/5~98/	Wheel Hub REAR INNER
03901 5473	90311-52005	52 x 75 x 7.5 x 12	CORONA (COUPE / EXIV) ST205 (4WD)	94/5~98/	Wheel Hub REAR OUTER
03901 2703	90311-30006	30 x 42 x 7	CORONA (COUPE / EXIV) ST16#,18#,20#	87/8~98/	Mission & Differential (M/T) INPUT SHAFT
03901 1593	90311-35033	35 x 55 x 9 x 15.5	CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203	87/8~98/	Mission & Differential (M/T) TRANSAXLE CASE
03901 7045	90311-35033	35 x 55 x 9 x 15.5	CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203	87/8~98/	Mission & Differential (M/T) DIFF. SIDE
03901 7409	90311-50010	50 x 80 x 16.5 x 23	CORONA (COUPE / EXIV) ST205 (4WD)	94/5~98/	Mission & Differential (M/T) TRANSMISSION CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5595	04422-20100	Kit	CORONA (COUPE / EXIV) ST202 TRG ABS & SSS,ST205 ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 1459	90311-40004	40 x 56 x 9 x 15.5	CORONA (COUPE / EXIV) ST202 TRG	93/9~98/	Mission & Differential (M/T) TRANSAXLE CASE COVER
03901 8121	04422-20080	Kit	CORONA (COUPE / EXIV) ST180,182 ABS	89/9~93/	Wheel Hub FRONT (LH)
03901 1963	90311-44003	44 x 80 x 9 x 15.5	CORONA (COUPE / EXIV) ST205 (4WD)	94/5~98/	Mission & Differential (A/T) DIFF. SIDE
03901 8061	90311-44003	44 x 80 x 9 x 15.5	CORONA (COUPE / EXIV) ST202 TRG	93/9~98/	Mission & Differential (M/T) TRANSMISSION CASE
03901 1205	04422-20090	Kit	CORONA (COUPE / EXIV) ST202 TRG SSS,ST205 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 5853	04422-20080	Kit	CORONA (COUPE / EXIV) ST201,203	93/9~98/	Wheel Hub FRONT (LH)
03901 4661	04422-20080	Kit	CORONA (COUPE / EXIV) ST181,183	89/9~93/	Wheel Hub FRONT (LH)
03901 2067	90311-38020	38 x 55 x 8.5	CORONA (COUPE / EXIV) ST16#,18#,20#	87/8~98/	Mission & Differential (A/T) FRONT OIL PUMP
03901 2701	04422-20010	Kit	CORONA (COUPE / EXIV) ST200,202 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 5527	04422-20010	Kit	CORONA (COUPE / EXIV) ST180,182 WITHOUT ABS	89/9~93/	Wheel Hub FRONT (LH)
03901 3379	04422-20010	Kit	CORONA (COUPE / EXIV) ST16#	87/8~89/	Wheel Hub FRONT (LH)
03901 3531	04422-20100	Kit	CORONA (COUPE / EXIV) ST202 TRG ABS & SSS,ST205 ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 7999	04422-20090	Kit	CORONA (COUPE / EXIV) ST202 TRG SSS,ST205 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 6583	04422-20080	Kit	CORONA (COUPE / EXIV) ST200,201,202,203 ABS	93/9~98/	Wheel Hub FRONT (RH)
03901 2001	04422-20080	Kit	CORONA (COUPE / EXIV) ST18#... ABS	89/9~93/	Wheel Hub FRONT (RH)
03901 7367	04422-20010	Kit	CORONA (COUPE / EXIV) ST200,201,202,203 WITHOUT ABS	93/9~98/	Wheel Hub FRONT (RH)

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2211	04422-20010	Kit	CORONA (COUPE / EXIV) ST18#...WITHOUT ABS	89/9~93/	Wheel Hub FRONT (RH)
03901 2235	04422-20010	Kit	CORONA (COUPE / EXIV) ST16#	87/8~89/	Wheel Hub FRONT (RH)
03901 7353	04422-20080	Kit	CORONA (COUPE / EXIV) ST200,202 ABS	93/9~98/	Wheel Hub FRONT (LH)
03901 1227	15165-70010	18 x 30 x 7	CORONA (COUPE / EXIV) 1S#,3S#,4S#...ST16#,18#,20#	87/8~98/	Engine OIL PUMP
03901 7153	90913-02062		CORONA (COUPE / EXIV) 3S#,4S# (EX.) ST18#,20#	90/3~98/	Engine VALVE STEM SEAL
03901 1807	90913-02062		CORONA (COUPE / EXIV) 3S#,4S#...ST162,163,18#	87/8~90/3	Engine VALVE STEM SEAL
03901 3861	90913-02094		CORONA (COUPE / EXIV) 1SILU ST160	87/8~88/5	Engine VALVE STEM SEAL
03901 7289	90311-89001	89 x 105 x 10	CORONA (COUPE / EXIV) 3SGE ST18#,20#	89/9~98/	Engine CRANK SHAFT REAR
03901 4947	90311-85007	85 x 105 x 10	CORONA (COUPE / EXIV) 3SFE,4SFE ST18#,20#	90/10~98/	Engine CRANK SHAFT REAR
03901 7131	90311-85004	85 x 105 x 10	CORONA (COUPE / EXIV) 3SFE,4S#...ST18#	89/9~90/10	Engine CRANK SHAFT REAR
03901 6509	90311-85004	85 x 105 x 10	CORONA (COUPE / EXIV) 1S#,3S#,4S#...ST16#	87/8~89/	Engine CRANK SHAFT REAR
03901 1517	90311-35033	35 x 55 x 9 x 15.5	CORONA (COUPE / EXIV) ST16#,18#,200,201,202,203	87/8~98/	Mission & Differential (A/T) DIFF. SIDE
03901 3559	90311-42003	42 x 60 x 7	CORONA (COUPE / EXIV) 1S#,3S#,4S#...ST16#	87/8~89/	Engine CRANK SHAFT FRONT
03901 5773	04445-20040		CORONA (COUPE / EXIV) ST162 GT	87/8~89/3	Steering (P/S) R & P GASKET KIT
03901 4833	90311-35013	35 x 49 x 6	CORONA (COUPE / EXIV) 3SGE ST162,18#,20#	87/8~98/	Engine CAM SHAFT
03901 2335	90311-38036	38 x 50 x 8	CORONA (COUPE / EXIV) 1S#,3SFE,4S#...ST16#,18#,20#	87/8~98/	Engine CAM SHAFT
03901 8007	90310-31001	31 x 44 x 6.5	CORONA (COUPE / EXIV) ST162,163,180,182,200,202,205	89/3~98/	Steering (P/S) CONTROL VALVE LOWER
03901 1347	04445-20060		CORONA (COUPE / EXIV) ST16#,,EX,VX,GX	87/8~89/3	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4221	90311-42026	42 x 60 x 7	CORONA (COUPE / EXIV) 3S#,4S#...ST18#,20#	89/9~98/	Engine CRANK SHAFT FRONT
03901 4421	04445-20040		CORONA (COUPE / EXIV) ST180	89/9~91/	Steering (P/S) R & P GASKET KIT
03901 4701	90310-31001	31 x 44 x 6.5	CORONA (COUPE / EXIV) ST162 GT	87/8~89/3	Steering (P/S) CONTROL VALVE LOWER
03901 7229	04445-20210		CORONA (COUPE / EXIV) ST180	91/8~93	Steering (P/S) R & P GASKET KIT
03901 6155	04445-20110		CORONA (COUPE / EXIV) ST182	89/9~93/	Steering (P/S) R & P GASKET KIT
03901 2873	90913-02079		CORONA (COUPE / EXIV) 3S#,4S# (IN.) ST18#,20#	90/3~98/	Engine VALVE STEM SEAL
03901 7507	04445-20103		CORONA (COUPE / EXIV) ST201,203	93/9~98/	Steering (P/S) R & P GASKET KIT
03901 1667	04445-20180		CORONA (COUPE / EXIV) ST200,202,205	93/9~98/	Steering (P/S) R & P GASKET KIT
03901 1689	90311-19002	19 x 32 x 7 x 8	CORONA (COUPE / EXIV) ST16#,18#,20#	87/8~96/	Steering (P/S) CONTROL VALVE UPPER
03901 5397	90310-28003	28 x 41 x 6.5	CORONA (COUPE / EXIV) ST16#...EX,VX,GX	87/8~89/3	Steering (P/S) CONTROL VALVE LOWER
03901 7401	90310-28003	28 x 41 x 6.5	CORONA (COUPE / EXIV) ST181,183,201,203	89/9~98/	Steering (P/S) CONTROL VALVE LOWER
03901 7035	04445-20103		CORONA (COUPE / EXIV) ST181,183	89/9~93/	Steering (P/S) R & P GASKET KIT
03901 6611	04445-20040		CORONA (COUPE / EXIV) ST162,163	89/3~89/	Steering (P/S) R & P GASKET KIT
03901 5155	90311-38020	38 x 55 x 8.5	CORONA (RWD) KT147,TT14#,AT140,ST140	82/1~87/	Transmission (A/T) FRONT OIL PUMP
03901 4859	90913-02058		CORONA (RWD) 3TEU (EX.) TT142	82/1~83/	Engine VALVE STEM SEAL
03901 1823	90913-02060		CORONA (RWD) STGTEU TT142	82/10~85/	Engine VALVE STEM SEAL
03901 7855	90913-02056		CORONA (RWD) 1SU ST140	82/1~87/	Engine VALVE STEM SEAL
03901 7029	90913-02056		CORONA (RWD) 5KJ KT147	83/10~87/	Engine VALVE STEM SEAL
03901 2589	90913-02038		CORONA (RWD) 3AU AT140	82/1~87/	Engine VALVE STEM SEAL
03901 1549	90913-02062		CORONA (RWD) 4AGEU AT141	83/10~85/	Engine VALVE STEM SEAL
03901 5759	90913-02110		CORONA (RWD) 1C,2C CT14#	82/1~91/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6619	90913-02024		CORONA (RWD) 3TEU (IN.) TT142	82/1~83/	Engine VALVE STEM SEAL
03901 6071	90913-02094		CORONA (RWD) 2YPU YT140	82/9~	Engine VALVE STEM SEAL
03901 7235	90311-42026	42 x 60 x 7	CORONA (RWD) 2YPU YT140	86/5~	Engine TIMING GEAR COVER
03901 3183	90311-42026	42 x 60 x 7	CORONA (RWD) 2C CT141	90/10~91/	Engine CRANK SHAFT FRONT
03901 3603	90311-34001	34 x 44 x 8	CORONA (RWD) YT140	86/12~	Steering (M/S) SECTOR SHAFT
03901 6063	90311-19001	19 x 32 x 8	CORONA (RWD) KT147,TT147,CT140(STD),141,147	82/1~91/	Steering (M/S) WORM GEAR
03901 6451	90311-19001	19 x 32 x 8	CORONA (RWD) YT140	82/9~	Steering (M/S) WORM GEAR
03901 4263	90311-15001	15 x 25 x 7	CORONA (RWD) TT142,AT14#,ST140,CT140(GX)	82/1~87/	Steering (M/S) RACK HOUSING
03901 2075	90311-19002	19 x 32 x 7 x 8	CORONA (RWD) TT142,AT14#,ST140,CT140,RT141	82/1~87/	Steering (P/S) ADJUSTER PLUG
03901 6791	90311-19002	19 x 32 x 7 x 8	CORONA (RWD) YT140	82/9~	Steering (P/S) ADJUSTER PLUG
03901 1087	90312-30001	30 x 38 x 5	CORONA (RWD) YT140	82/9~	Steering (P/S) GEAR HOUSING
03901 2119	90310-25004	25 x 38 x 7 x 8	CORONA (RWD) AT140,ST140 GX	86/2~87/	Steering (P/S) BEARING GUIDE NUT
03901 2897	90311-38013	38.5 x 58 x 11	CORONA (RWD) 3T#...TT142	82/1~85/	Engine TIMING GEAR COVER
03901 1413	90311-38022	38.5 x 58 x 8.5	CORONA (RWD) 5KJ KT147	83/10~87/	Engine TIMING GEAR COVER
03901 2779	90310-28027	28 x 40 x 8	CORONA (RWD) KT147,CT147	86/12~87/ 12	Steering (M/S) SECTOR SHAFT
03901 3111	90311-42003	42 x 60 x 7	CORONA (RWD) 2YPU YT140	82/9~86/5	Engine TIMING GEAR COVER
03901 3939	90310-28027	28 x 40 x 8	CORONA (RWD) KT147,TT147,CT147,YT140	82/1~86/1 2	Steering (M/S) SECTOR SHAFT
03901 1705	90311-35013	35 x 49 x 6	CORONA (RWD) 3AU,4AGEU AT14#	82/1~87/	Engine CAM SHAFT
03901 4401	90311-38036	38 x 50 x 8	CORONA (RWD) 1SU ST140	82/1~87/	Engine CAM SHAFT
03901 5625	90311-38036	38 x 50 x 8	CORONA (RWD) 1C CT14#	82/1~85/1	Engine CAM SHAFT
03901 3749	90311-38025	38 x 50 x 6	CORONA (RWD) 1C,2C CT14#	85/1~91/	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3499	90311-32020	32 x 46 x 6	CORONA (RWD) 3AU,4AGEU AT14#	82/1~87/	Engine OIL PUMP
03901 5609	15165-70010	18 x 30 x 7	CORONA (RWD) 1SU ST140	82/1~87/	Engine OIL PUMP
03901 4601	15165-64010	20 x 32 x 7	CORONA (RWD) 1C CT14#	82/1~85/5	Engine OIL PUMP
03901 1901	90029-21020	20 x 32 x 5	CORONA (RWD) 1C,2C CT14#	85/5~89/5	Engine OIL PUMP
03901 6915	90029-21022	22 x 34 x 6.5	CORONA (RWD) 2C CT141	89/5~91/	Engine OIL PUMP
03901 1041	90311-42003	42 x 60 x 7	CORONA (RWD) 1SU ST140	82/1~87/	Engine CRANK SHAFT FRONT
03901 6351	90311-42003	42 x 60 x 7	CORONA (RWD) 1C CT14#	82/1~85/5	Engine CRANK SHAFT FRONT
03901 8245	90311-42015	42 x 60 x 6	CORONA (RWD) 1C,2C CT14#	85/5~90/1 0	Engine CRANK SHAFT FRONT
03901 2887	90311-45002	45 x 68 x 12	CORONA (RWD) 18RGEU RT141	82/1~82/1 0	Engine TIMING GEAR COVER
03901 6723	90311-30115	30 x 45 x 8	CORONA (RWD) YT140	82/9~91/1 0	Transmission (M/T) FRONT COVER
03901 7295	04332-30020	Kit	CORONA (RWD) KT147,TT14#,AT140,ST140, YT140	82/1~87/	Transmission (A/T) REAR EXTENTION
03901 2439	90072-72006		CORONA (RWD) 18RGEU RT141	82/1~82/1 0	Engine VALVE STEM SEAL
03901 2375	90311-48122	48 x 62 x 7	CORONA (RWD) TT142,RT141,YT140	82/1~83/5	Wheel Hub FRONT
03901 5745	90311-48122	48 x 62 x 7	CORONA (RWD) CT140 STD	82/1~83/5	Wheel Hub FRONT
03901 6435	90311-48001	48 x 62 x 9	CORONA (RWD) TT142,AT141,CT141	83/5~91/	Wheel Hub FRONT
03901 6343	90311-48001	48 x 62 x 9	CORONA (RWD) YT140	83/5~	Wheel Hub FRONT
03901 5487	90311-48001	48 x 62 x 9	CORONA (RWD) CT140 STD	83/5~86/	Wheel Hub FRONT
03901 6533	90311-41123	41 x 53 x 7	CORONA (RWD) KT147,TT147,AT140,ST140, CT147	82/1~87/	Wheel Hub FRONT
03901 2165	90311-41123	41 x 53 x 7	CORONA (RWD) CT140 GX,EXS	82/1~83/	Wheel Hub FRONT
03901 7751	90311-52059	52 x 65 x 9	CORONA (RWD) KT147,TT147,AT140,ST140, CT14#	82/1~91/	Wheel Hub REAR
03901 4007	90311-38009	38 x 58 x 8	CORONA (RWD) TT142,AT141,RT141	82/1~85/	Wheel Hub REAR INNER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5943	90311-34001	34 x 44 x 8	CORONA (RWD) CT140(STD),CT141	82/1~91/	Steering (M/S) SECTOR SHAFT
03901 6223	90311-30115	30 x 45 x 8	CORONA (RWD) TT142(GTT),RT141,CT14#	82/1~91/	Transmission (M/T) FRONT COVER
03901 3707	90311-48122	48 x 62 x 7	CORONA (RWD) TT142,AT141,RT141	82/1~85/	Wheel Hub REAR OUTER
03901 3019	90311-30014	30 x 45 x 8	CORONA (RWD) YT140	91/10~	Transmission (M/T) FRONT COVER
03901 6321	90311-32074	32 x 52 x 11	CORONA (RWD) KT147,TT142(SX),147,AT14 #,ST140	82/1~87/	Transmission (M/T) REAR
03901 4915	90311-38043	38 x 58 x 11	CORONA (RWD) TT142(GTT),RT141,CT14#, YT140	82/1~97/	Transmission (M/T) REAR
03901 7129	90311-38043	38 x 58 x 11	CORONA (RWD) YT140	82/9~91/1 0	Transmission (M/T) REAR
03901 5689	90311-38032	38 x 58 x 11	CORONA (RWD) YT140	91/10~	Transmission (M/T) REAR
03901 3677	90311-38020	38 x 55 x 8.5	CORONA (RWD) YT140	82/9~	Transmission (A/T) FRONT OIL PUMP
03901 2747	90311-38015	38 x 65 x 12 x 19	CORONA (RWD) AT140,ST140,CT140,141	82/1'91/	Final Drive PINION
03901 6933	90311-38133	38 x 74 x 11	CORONA (RWD) KT147,TT147,CT147	82/1~87/	Final Drive PINION
03901 5583	90311-38133	38 x 74 x 11	CORONA (RWD) YT140	82/9~	Final Drive PINION
03901 7841	90311-38133	38 x 74 x 11	CORONA (RWD) TT142,RT141 GTT	82/1~85/8	Final Drive PINION
03901 1093	90311-38019	38 x 65 x 10 x 17	CORONA (RWD) TT142,AT141 SX	82/1~85/8	Final Drive PINION
03901 6445	90311-38011	38 x 63 x 10 x 17	CORONA (RWD) TT142,AT141,RT141	82/1~85/8	Final Drive DIFF. SIDE
03901 6375	90311-25003	25 x 38 x 7	CORONA (RWD) KT147,TT142(SX),147,AT14 #,ST140	82/1~87/	Transmission (M/T) FRONT COVER
03901 4657	90311-75114	75 x 100 x 13	CORONA (RWD) 3T#...TT142	82/1~85/	Engine CRANK SHAFT FRONT
03901 7791	90311-52059	52 x 65 x 9	CORONA (RWD) YT140	82/9~	Wheel Hub REAR
03901 6729	90311-90005	90 x 110 x 8.5 x 10	CORONA (RWD) 2C CT141	90/2~91/1 1	Engine CRANK SHAFT FRONT
03901 3617	90311-90003	90 x 110 x 8.5 x 10	CORONA (RWD) 1C,2C CT14#	82/1~90/2	Engine CRANK SHAFT FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6021	90311-85004	85 x 105 x 10	CORONA (RWD) 1SU ST140	82/1~87/	Engine CRANK SHAFT FRONT
03901 5667	90311-70004	70 x 92 x 8.5	CORONA (RWD) 5KJ,3AU,4AGEU KT147.AT14#	82/1~87/	Engine CRANK SHAFT FRONT
03901 6497	90311-80012	80 x 100 x 8.5	CORONA (RWD) 2YPU YT140	86/5~	Engine CRANK SHAFT FRONT
03901 1523	90311-80003	80 x 100 x 8.5	CORONA (RWD) 2YPU YT140	82/9~86/5	Engine CRANK SHAFT FRONT
03901 6471	90311-80001	80 x 100 x 12	CORONA (RWD) 18RGEU RT141	82/1~82/10	Engine CRANK SHAFT FRONT
03901 4885	90311-35033	35 x 55 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ST16#,17#,210	85/8~	Mission & Differential (A/T) DIFF.SIDE
03901 2825	90311-34012	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ET176	87/12~92/	Mission & Differential (A/T) DIFF.SIDE
03901 7755	90311-34012	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT150..3FC	84/5~88/	Mission & Differential (A/T) DIFF.SIDE
03901 3303	90311-49002	50 x 64 x 8	CORONA (SEDAN / 5 DOOR) CT216,ST215	97/12~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3413	90311-35033	35 x 55 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ST150,190,CT150,17#,190,210,211	83/1~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 6473	90311-34012	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT150(4FC),170,190,21#	83/10~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 7773	90311-44003	44 x 80 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT175	88/8~92/	Mission & Differential (A/T) TRANSAXLE CASE
03901 2713	90311-35033	35 x 55 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ST16#,17#	85/8~92/	Mission & Differential (A/T) TRANSAXLE CASE
03901 3313	90311-35020	35 x 63 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) CT150,17#,190,21#	83/10~	Mission & Differential (A/T) TRANSAXLE CASE
03901 1955	90311-44003	44 x 80 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ST195,215	92/2~97/12	Mission & Differential (A/T) DIFF.SIDE
03901 5723	90311-34013	34 x 63 x 9 x 15	CORONA (SEDAN / 5 DOOR) AT170,190,21#	87/12~	Mission & Differential (A/T) TRANSAXLE CASE
03901 5659	90913-02117		CORONA (SEDAN / 5 DOOR) 2CT,3CTE CT21#	97/4~	Engine VALVE STEM SEAL
03901 7477	90311-34013	34 x 63 x 9 x 15	CORONA (SEDAN / 5 DOOR) AT150 4FC	83/10~87/	Mission & Differential (A/T) TRANSAXLE CASE
03901 2289	90311-35020	35 x 63 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ST150,190,21#	83/1~	Mission & Differential (A/T) TRANSAXLE CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5969	90311-38020	38 x 55 x 8.5	CORONA (SEDAN / 5 DOOR) AT150,170,190,21#,CT150,17#,190,21#	83/10~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4789	90311-38020	38 x 55 x 8.5	CORONA (SEDAN / 5 DOOR) ST150,16#,17#,19#,215	83/1~	Mission & Differential (A/T) FRONT OIL PUMP
03901 8123	90311-15001	15 x 25 x 7	CORONA (SEDAN / 5 DOOR) AT150,170,CT176,ET176	83/10~92/	Steering (M/S) RACK HOUSING
03901 1907	90311-34012	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ET176	87/12~92/	Mission & Differential (A/T) TRANSAXLE CASE
03901 7017	04445-20030		CORONA (SEDAN / 5 DOOR) AT15#,160,ST150,162,CT150 TOYODAKOKI	83/1~87/	Steering (P/S) R & P GASKET KIT
03901 5729	90311-49002	50 x 64 x 8	CORONA (SEDAN / 5 DOOR) ST215	97/12~	Mission & Differential (M/T) TRANSAXLE CASE
03901 6481	90913-02110		CORONA (SEDAN / 5 DOOR) 2C CT21#	96/1~97/4	Engine VALVE STEM SEAL
03901 6059	90913-02094		CORONA (SEDAN / 5 DOOR) 2C CT17#,19#	90/11~96/	Engine VALVE STEM SEAL
03901 3747	90913-02110		CORONA (SEDAN / 5 DOOR) 2C CT150,17#	87/12~90/11	Engine VALVE STEM SEAL
03901 6981	90913-02062		CORONA (SEDAN / 5 DOOR) 3E ET176	87/12~92/	Engine VALVE STEM SEAL
03901 7499	90913-02079		CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE (IN.) AT17#,19#,21#	90/10~	Engine VALVE STEM SEAL
03901 1399	90913-02062		CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE (EX.) AT17#,19#,21#	90/10~	Engine VALVE STEM SEAL
03901 7429	90913-02062		CORONA (SEDAN / 5 DOOR) 4A#,5A#...AT17#	87/12~90/10	Engine VALVE STEM SEAL
03901 2753	04445-12020		CORONA (SEDAN / 5 DOOR) AT150,ST150,CT150 TOYOTA G/B	83/1~87/	Steering (P/S) R & P GASKET KIT
03901 2011	90311-52005	52 x 75 x 7.5 x 12	CORONA (SEDAN / 5 DOOR) AT175,CT195,ST195 (4WD)	88/8~95/	Wheel Hub REAR OUTER
03901 5615	04445-20070		CORONA (SEDAN / 5 DOOR) CT17#,ET176,ST170	87/12~92/	Steering (P/S) R & P GASKET KIT
03901 6759	04422-20010	Kit	CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150	83/1~87/	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6039	04422-20010	Kit	CORONA (SEDAN / 5 DOOR) AT17#,ST17#,CT17#,ET176	87/12~92/	Wheel Hub FRONT
03901 5341	04422-20080	Kit	CORONA (SEDAN / 5 DOOR) AT170,ST170,171 ABS	90/5~92/	Wheel Hub FRONT
03901 1353	04422-20080	Kit	CORONA (SEDAN / 5 DOOR) AT190,CT19#,ST19#...ABS	92/2~95/	Wheel Hub FRONT
03901 3095	04422-20080	Kit	CORONA (SEDAN / 5 DOOR) AT21#,CT21#,ST21#	96/1~	Wheel Hub FRONT
03901 2983	04422-12060	Kit	CORONA (SEDAN / 5 DOOR) AT190,CT19#,ST19#...WITH OUT ABS	92/2~95/	Wheel Hub FRONT
03901 3299	90311-42018	42 x 55 x 6	CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150	83/1~87/	Wheel Hub REAR
03901 6377	90311-42018	42 x 55 x 6	CORONA (SEDAN / 5 DOOR) AT170,ST17#,CT170	87/12~92/	Wheel Hub REAR
03901 8079	90311-48001	48 x 62 x 9	CORONA (SEDAN / 5 DOOR) CT176,ET176	87/12~92/	Wheel Hub REAR
03901 6115	90311-56007	56 x 75 x 6.5 x 11	CORONA (SEDAN / 5 DOOR) AT175,CT195,ST195 (4WD)	88/8~95/	Wheel Hub REAR INNER
03901 3217	90311-34017	34 x 63 x 9 x 16	CORONA (SEDAN / 5 DOOR) AT21#	96/1~	Mission & Differential (M/T) TRANSMISSION CASE
03901 6635	90311-56015	56 x 75 x 7 x 12	CORONA (SEDAN / 5 DOOR) CT215,216,ST215 (4WD)	97/7~	Wheel Hub REAR INNER
03901 4645	90311-34012	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT150 3FC	83/10~87/	Mission & Differential (A/T) TRANSAXLE CASE
03901 3971	90311-25011	25 x 37 x 8	CORONA (SEDAN / 5 DOOR) AT150,170,190,ET176	83/10~95/	Mission & Differential (M/T) INPUT SHAFT
03901 1495	90311-30006	30 x 42 x 7	CORONA (SEDAN / 5 DOOR) AT175,ST150,16#,17#,190,C T150,17#,190	83/1~95/	Mission & Differential (M/T) INPUT SHAFT
03901 6737	90311-30006	30 x 42 x 7	CORONA (SEDAN / 5 DOOR) CT210,211,215,ST215	96/1~	Mission & Differential (M/T) INPUT SHAFT
03901 7033	90311-34016	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT150,170,190,ET176	83/10~95/	Mission & Differential (M/T) TRANSAXLE CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5275	90311-34016	34 x 54 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT21#	96/1~	Mission & Differential (M/T) TRANSAXLE CASE
03901 2009	90311-35033	35 x 55 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) ST150,16#,17#,190,CT150,17#,190	83/1~95/	Mission & Differential (M/T) TRANSAXLE CASE
03901 7305	90311-35033	35 x 55 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) CT210,211	96/1~	Mission & Differential (M/T) TRANSAXLE CASE
03901 1707	90311-25011	25 x 37 x 8	CORONA (SEDAN / 5 DOOR) AT21#	96/1~	Mission & Differential (M/T) INPUT SHAFT
03901 4171	90311-34017	34 x 63 x 9 x 16	CORONA (SEDAN / 5 DOOR) AT150,170,190,ET176	83/10~95/	Mission & Differential (M/T) TRANSMISSION CASE
03901 4329	90913-02038		CORONA (SEDAN / 5 DOOR) 3ALU	83/10~87/	Engine VALVE STEM SEAL
03901 6319	90311-44003	44 x 80 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) AT175,CT195,215,ST195,215 (4WD)	88/8~	Mission & Differential (M/T) TRANSMISSION CASE
03901 4635	90311-35033	35 x 55 x 9 x 15.5	CORONA (SEDAN / 5 DOOR) CT210,211,ST215	96/1~	Mission & Differential (M/T) DIFF. SIDE
03901 6381	90311-56007	56 x 75 x 6.5 x 11	CORONA (SEDAN / 5 DOOR) CT215,ST215 (4WD)	96/1~97/	Wheel Hub REAR INNER
03901 5529	90311-38025	38 x 50 x 6	CORONA (SEDAN / 5 DOOR) 2C CT150,17#	85/1~90/10	Engine CAM SHAFT
03901 1431	90310-25004	25 x 38 x 7 x 8	CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150 TOYODAKOKI G/B	83/1~87/	Steering (P/S) CONTROL VALVE LOWER
03901 2815	90310-25004	25 x 38 x 7 x 8	CORONA (SEDAN / 5 DOOR) AT17#,ST17#,CT17#,ET176	87/12~92/	Steering (P/S) CONTROL VALVE LOWER
03901 6237	90310-25004	25 x 38 x 7 x 8	CORONA (SEDAN / 5 DOOR) CT19#,ST195	92/2~95/	Steering (P/S) CONTROL VALVE LOWER
03901 5763	90310-25004	25 x 38 x 7 x 8	CORONA (SEDAN / 5 DOOR) AT211,CT21#,ST21#...TOYODAKOKI G/B	96/1~	Steering (P/S) CONTROL VALVE LOWER
03901 1345	90310-28003	28 x 41 x 6.5	CORONA (SEDAN / 5 DOOR) AT19#,ST190	92/8~96/	Steering (P/S) CONTROL VALVE LOWER
03901 6595	90311-38036	38 x 50 x 8	CORONA (SEDAN / 5 DOOR) 1S#,3SFE,4S#...ST150,160,17#,19#,21#	83/1~97/8	Engine CAM SHAFT
03901 7355	90311-38036	38 x 50 x 8	CORONA (SEDAN / 5 DOOR) 2C CT150	83/1~85/1	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4729	90311-19002	19 x 32 x 7 x 8	CORONA (SEDAN / 5 DOOR) AT150,ST150,16#,CT150 TOYODAKOKI G/B	83/1~87/	Steering (P/S) CONTROL VALVE UPPER
03901 2537	90311-38044	38 x 50 x 6	CORONA (SEDAN / 5 DOOR) 2C CT17#,19#	90/10~96/	Engine CAM SHAFT
03901 4687	90311-38044	38 x 50 x 6	CORONA (SEDAN / 5 DOOR) 2CT,3CTE CT21#	96/1~	Engine CAM SHAFT
03901 4723	90311-35013	35 x 49 x 6	CORONA (SEDAN / 5 DOOR) 3A#,4A#,5A#...AT150,17#,190	83/10~96/	Engine CAM SHAFT
03901 3321	90311-35013	35 x 49 x 6	CORONA (SEDAN / 5 DOOR) 4AFE,7AFE AT21#	96/1~	Engine CAM SHAFT
03901 6239	90311-35013	35 x 49 x 6	CORONA (SEDAN / 5 DOOR) 3E ET176	87/12~92/	Engine CAM SHAFT
03901 5065	90311-35013	35 x 49 x 6	CORONA (SEDAN / 5 DOOR) 3SGE ST162,171	85/8~92/	Engine CAM SHAFT
03901 5501	90310-28003	28 x 41 x 6.5	CORONA (SEDAN / 5 DOOR) AT21#,ST210 TOYOTA G/B	96/1~	Steering (P/S) CONTROL VALVE LOWER
03901 5439	04445-20161		CORONA (SEDAN / 5 DOOR) CT216,ST215	96/4~	Steering (P/S) R & P GASKET KIT
03901 2301	04445-20070		CORONA (SEDAN / 5 DOOR) AT170	87/12~92/	Steering (P/S) R & P GASKET KIT
03901 5005	04445-20070		CORONA (SEDAN / 5 DOOR) AT175	89/11~92/	Steering (P/S) R & P GASKET KIT
03901 3901	90311-52005	52 x 75 x 7.5 x 12	CORONA (SEDAN / 5 DOOR) CT215,216,ST215 (4WD)	96/1~	Wheel Hub REAR OUTER
03901 8259	90913-02111		CORONA (SEDAN / 5 DOOR) 3SFSE (EX.) ST210	96/12~	Engine VALVE STEM SEAL
03901 1171	04445-20080		CORONA (SEDAN / 5 DOOR) AT175	87/12~89/11	Steering (P/S) R & P GASKET KIT
03901 5809	04445-20080		CORONA (SEDAN / 5 DOOR) ST171	87/12~92/	Steering (P/S) R & P GASKET KIT
03901 2273	90310-23005	23 x 34 x 6.5	CORONA (SEDAN / 5 DOOR) AT150,ST150,CT150 TOYOTA G/B	83/1~87/	Steering (P/S) CONTROL VALVE LOWER
03901 7891	04445-20161		CORONA (SEDAN / 5 DOOR) AT211,ST210 TOYODAKOKI G/B	96/4~	Steering (P/S) R & P GASKET KIT
03901 1191	90311-19002	19 x 32 x 7 x 8	CORONA (SEDAN / 5 DOOR) AT17#,19#,21#,CT17#,19#,21#	87/12~	Steering (P/S) CONTROL VALVE UPPER
03901 7417	04445-20210		CORONA (SEDAN / 5 DOOR) AT210	96/1~97/12	Steering (P/S) R & P GASKET KIT
03901 8153	04445-20170		CORONA (SEDAN / 5 DOOR) AT210	97/12	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8091	04445-20170		CORONA (SEDAN / 5 DOOR) AT211,ST210 TOYOTA G/B	96/4~	Steering (P/S) R & P GASKET KIT
03901 1921	04445-20240		CORONA (SEDAN / 5 DOOR) CT210,211	96/1~	Steering (P/S) R & P GASKET KIT
03901 3953	90311-19007	19 x 38 x 7	CORONA (SEDAN / 5 DOOR) AT150,ST150,CT150 TOYOTA G/B	83/1~87/	Steering (P/S) CONTROL VALVE UPPER
03901 5061	90311-19002	19 x 32 x 7 x 8	CORONA (SEDAN / 5 DOOR) ST17#,19#,215	87/12~	Steering (P/S) CONTROL VALVE UPPER
03901 2717	04445-20161		CORONA (SEDAN / 5 DOOR) AT211,CT215,ST21#	96/1~96/4	Steering (P/S) R & P GASKET KIT
03901 1957	90913-02062		CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#	87/12~90/3	Engine VALVE STEM SEAL
03901 3869	90311-70004	70 x 92 x 8.5	CORONA (SEDAN / 5 DOOR) 3A#,4A#,5A#...AT150,160,17#	83/10~91/6	Engine CRANK SHAFT REAR
03901 3271	90311-70007	70 x 92 x 8.5	CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE AT17#,19#,21#	91/6~	Engine CRANK SHAFT REAR
03901 3655	90311-85004	85 x 105 x 10	CORONA (SEDAN / 5 DOOR) 1S#,3S#,4S#...ST150,16#,17#	83/1~90/10	Engine CRANK SHAFT REAR
03901 7287	90311-90003	90 x 110 x 8.5 x 10	CORONA (SEDAN / 5 DOOR) 2C CT150,17#	83/10~92/	Engine CRANK SHAFT REAR
03901 2281	90311-90008	90 x 110 x 9.5 x 11.5	CORONA (SEDAN / 5 DOOR) 2CT,3CTE CT21#	96/1~	Engine CRANK SHAFT REAR
03901 1695	90311-80003	80 x 100 x 8.5	CORONA (SEDAN / 5 DOOR) 3E ET176	87/12~92/	Engine CRANK SHAFT REAR
03901 5421	90311-35013	35 x 49 x 6	CORONA (SEDAN / 5 DOOR) 3E ET176	87/12~90/	Engine CRANK SHAFT FRONT
03901 1335	90913-02062		CORONA (SEDAN / 5 DOOR) 3SGELU ST162	85/8~87/	Engine VALVE STEM SEAL
03901 1843	90311-85007	85 x 105 x 10	CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#,19#,21#	90/10~	Engine CRANK SHAFT REAR
03901 3931	90913-02062		CORONA (SEDAN / 5 DOOR) 3S#,4S#(EX.) ST17#,19#	90/3~96/	Engine VALVE STEM SEAL
03901 6045	90311-38067	38 x 50 x 8	CORONA (SEDAN / 5 DOOR) 3SFE ST21#	97/8~	Engine CAM SHAFT
03901 7633	90913-02062		CORONA (SEDAN / 5 DOOR) 3SFE (EX.) ST21#	96/1~	Engine VALVE STEM SEAL
03901 4211	90913-02079		CORONA (SEDAN / 5 DOOR) 3S#,4S# (IN.) ST17#,19#	90/3~96/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5215	90913-02079		CORONA (SEDAN / 5 DOOR) 3SFE (IN.) ST21#	96/1~	Engine VALVE STEM SEAL
03901 7707	90913-02101		CORONA (SEDAN / 5 DOOR) 3SFSE (IN.) ST210	96/12~	Engine VALVE STEM SEAL
03901 8031	90913-02056		CORONA (SEDAN / 5 DOOR) 1S#...ST150,160	83/1~87/	Engine VALVE STEM SEAL
03901 1831	15165-70010	18 x 30 x 7	CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#,19#,21#	87/12~	Engine OIL PUMP
03901 6587	90311-38067	38 x 50 x 8	CORONA (SEDAN / 5 DOOR) 3SFSE ST210	96/12~	Engine CAM SHAFT
03901 3471	90311-32020	32 x 46 x 6	CORONA (SEDAN / 5 DOOR) 4A#,5A#,7AFE AT17#,19#,21#	87/12~	Engine OIL PUMP
03901 6863	90029-21020	20 x 32 x 5	CORONA (SEDAN / 5 DOOR) 2C CT17#	87/12~89/5	Engine OIL PUMP
03901 1485	90029-21022	22 x 34 x 6.5	CORONA (SEDAN / 5 DOOR) 2C CT17#,19#	89/5~96/	Engine OIL PUMP
03901 5751	90311-90005	90 x 110 x 8.5 x 10	CORONA (SEDAN / 5 DOOR) 2C CT19#	92/2~96/	Engine CRANK SHAFT REAR
03901 3075	90029-21020	20 x 32 x 5	CORONA (SEDAN / 5 DOOR) 3E ET176	87/12~92/	Engine OIL PUMP
03901 6285	90311-42035	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 3SFG ST210	97/8~	Engine CRANK SHAFT FRONT
03901 1731	90311-42003	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 2C CT150	83/1~85/5	Engine CRANK SHAFT FRONT
03901 6711	90311-42015	42 x 60 x 6	CORONA (SEDAN / 5 DOOR) 2C CT150,17#	85/5~90/8	Engine CRANK SHAFT FRONT
03901 4711	90311-42026	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 2C#,3CTE CT17#,19#,21#	90/8~	Engine CRANK SHAFT FRONT
03901 1553	90311-42035	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 3SFE ST21#	96/9~	Engine CRANK SHAFT FRONT
03901 3963	90311-42003	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 1S#,3S#,4S#...ST150,16#,17#	83/1~89/10	Engine CRANK SHAFT FRONT
03901 8095	90311-42026	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 3S#,4S#...ST17#,19#	89/10~96/	Engine CRANK SHAFT FRONT
03901 3965	90311-42026	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 3SFE ST21#	96/1~96/9	Engine CRANK SHAFT FRONT
03901 6169	90311-42026	42 x 60 x 7	CORONA (SEDAN / 5 DOOR) 3SFG ST210	96/12~97/8	Engine CRANK SHAFT FRONT
03901 6797	90310-25004	25 x 38 x 7 x 8	CRESSIDA / MARK II GX7#...EXCEPT GX71,TWT	84/8~88/	Steering (P/S) CONTROL VALVE LOWER
03901 3809	04445-22270		CRESSIDA / MARK II GX105	98/8~00/	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6897	90311-30016	30 x 42 x 7 x 8	CRESSIDA / MARK II JZX10#	96/9~00/	Steering (P/S) CONTROL VALVE LOWER
03901 6581	04445-22280		CRESSIDA / MARK II GX110,JZX110	00/10~	Steering (P/S) R & P GASKET KIT
03901 4289	04445-22290		CRESSIDA / MARK II GX115,JZX115	00/10~	Steering (P/S) R & P GASKET KIT
03901 4515	90311-19002	19 x 32 x 7 x 8	CRESSIDA / MARK II SX70,YX7#,GX7#,MX71,LX 7#	84/8~88/	Steering (P/S) CONTROL VALVE UPPER
03901 3595	90311-19002	19 x 32 x 7 x 8	CRESSIDA / MARK II GX81,LX80,MX83,SX80,YX 80,JZX81	88/8~95/	Steering (P/S) CONTROL VALVE UPPER
03901 7261	90311-19002	19 x 32 x 7 x 8	CRESSIDA / MARK II GX90,JZX9#,LX90,SX90	92/10~96/	Steering (P/S) CONTROL VALVE UPPER
03901 4197	90311-19002	19 x 32 x 7 x 8	CRESSIDA / MARK II GX10#,JZX10#,LX100	96/9~00/	Steering (P/S) CONTROL VALVE UPPER
03901 5847	90310-25027	25 x 38 x 7	CRESSIDA / MARK II GX10#,LX100	96/9~00/	Steering (P/S) CONTROL VALVE LOWER
03901 5959	90311-30016	30 x 42 x 7 x 8	CRESSIDA / MARK II JZX9#	92/10~96/	Steering (P/S) CONTROL VALVE LOWER
03901 8135	04445-22260		CRESSIDA / MARK II JZX105	96/9~00/	Steering (P/S) R & P GASKET KIT
03901 2303	90310-25004	25 x 38 x 7 x 8	CRESSIDA / MARK II SX80,YX80,GX81 (EXC. TWC,TWT),LX80	88/8~95/	Steering (P/S) CONTROL VALVE LOWER
03901 6273	90310-25004	25 x 38 x 7 x 8	CRESSIDA / MARK II GX90,LX90,SX90	92/10~96/	Steering (P/S) CONTROL VALVE LOWER
03901 7317	90311-30016	30 x 42 x 7 x 8	CRESSIDA / MARK II GX81 (TWC,TWT),MX83,JZX81	88/8~93/	Steering (P/S) CONTROL VALVE LOWER
03901 5025	90311-19001	19 x 32 x 8	CRESSIDA / MARK II TX6#,RX6#,GX60,MX60,LX 6#	80/9~84/	Steering (M/S) WORM GEAR
03901 7093	90311-30016	30 x 42 x 7 x 8	CRESSIDA / MARK II GX71 TWT	86/8~88/	Steering (P/S) CONTROL VALVE LOWER
03901 1251	90311-38025	38 x 50 x 6	CRESSIDA / MARK II 1GEU GX7#	87/1~88/	Engine CAM SHAFT
03901 5245	90311-38036	38 x 50 x 8	CRESSIDA / MARK II 1GEU GX6#,7#	80/9~87/1	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6365	90310-25004	25 x 38 x 7 x 8	CRESSIDA / MARK II SX70,YX7#,MX71,LX7#	84/8~88/	Steering (P/S) CONTROL VALVE LOWER
03901 3121	04445-22081		CRESSIDA / MARK II GX71 TWC	87/1~88/	Steering (P/S) R & P GASKET KIT
03901 5535	90311-43001	43 x 70 x 9 x 15.5	CRESSIDA / MARK II GX81,JZX81,MX83,,TWC	88/8~93/	Final Drive DIFF. SIDE
03901 3483	90311-43001	43 x 70 x 9 x 15.5	CRESSIDA / MARK II JZX90 (TOUV),JZX91	92/10~96/	Final Drive DIFF. SIDE
03901 2805	90311-75007	75 x 100 x 10	CRESSIDA / MARK II 1G#...GX70,81,90,10#,11#	89/8~	Engine CRANK SHAFT REAR
03901 4975	90311-35013	35 x 49 x 6	CRESSIDA / MARK II 1GG#...GX61,71,81	88/8~95/	Engine CAM SHAFT
03901 6801	90311-43001	43 x 70 x 9 x 15.5	CRESSIDA / MARK II JZX110 GDGT,GDV,IRV	00/10~	Final Drive DIFF. SIDE
03901 1257	90311-35018	35 x 63 x 10 x 16.5	CRESSIDA / MARK II GX71 (EFI)	85/10~88/	Final Drive DIFF. SIDE
03901 6951	90310-28027	28 x 40 x 8	CRESSIDA / MARK II TX6#,RX6#,GX60,MX60,LX 6#	80/9~84/	Steering (M/S) SECTOR SHAFT
03901 1051	90311-15001	15 x 25 x 7	CRESSIDA / MARK II LX7#,SX70,YX7#	84/8~88/	Steering (M/S) RACK HOUSING
03901 3763	04445-22062		CRESSIDA / MARK II SX70,YX7#,MX71,LX7#	87/1~90/	Steering (P/S) R & P GASKET KIT
03901 5375	04445-22062		CRESSIDA / MARK II GX7#...EXCEPT GX71 TWC,TWT	87/1~88/	Steering (P/S) R & P GASKET KIT
03901 7527	04445-22250		CRESSIDA / MARK II GX100,LX100	96/9~00/	Steering (P/S) R & P GASKET KIT
03901 1751	04445- 22091/2		CRESSIDA / MARK II GX71 TWT	87/1~88/	Steering (P/S) R & P GASKET KIT
03901 4123	04445- 22100/1		CRESSIDA / MARK II SX80,YX80,GX81 (EXC. TWC,TWT),LX80	88/8~95/	Steering (P/S) R & P GASKET KIT
03901 5499	04445-22110		CRESSIDA / MARK II GX81 (TWC,TWT),MX83	88/8~90/8	Steering (P/S) R & P GASKET KIT
03901 4589	04445-22130		CRESSIDA / MARK II GX81 (TWC,TWT),MX83,JZX81	90/8~92/	Steering (P/S) R & P GASKET KIT
03901 7541	04445-22160		CRESSIDA / MARK II JZX90,91	92/10~96/	Steering (P/S) R & P GASKET KIT
03901 6763	04445-22170		CRESSIDA / MARK II GX90,LX90,SX90	92/10~96/	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4961	04445-22190		CRESSIDA / MARK II JZX93	93/10~96/	Steering (P/S) R & P GASKET KIT
03901 3251	04445-22240		CRESSIDA / MARK II JZX100,101	96/9~00/	Steering (P/S) R & P GASKET KIT
03901 7379	90311-43001	43 x 70 x 9 x 15.5	CRESSIDA / MARK II JZX100 5F,5FC,4FC-TOUV,JZX101	96/9~00/	Final Drive DIFF. SIDE
03901 7663	90311-80009	80 x 100 x 10	CRESSIDA / MARK II 2Y#,3Y#...YX7#,80	90/5~97/	Engine CRANK SHAFT REAR
03901 7091	90311-75114	75 x 100 x 13	CRESSIDA / MARK II 1G#...GX6#,7#	80/9~86/5	Engine CRANK SHAFT REAR
03901 7269	90311-42026	42 x 60 x 7	CRESSIDA / MARK II 2L LX7#,8#,9#	91/2~96/	Engine TIMING GEAR CASE
03901 3021	90311-42003	42 x 60 x 7	CRESSIDA / MARK II 1SU,4S#...SX70,80	84/8~89/9	Engine CRANK SHAFT FRONT
03901 7187	90311-42026	42 x 60 x 7	CRESSIDA / MARK II 4S#...SX80,90	89/9~96/	Engine CRANK SHAFT FRONT
03901 5271	90311-46001	46 x 63 x 6.5	CRESSIDA / MARK II 1JZ#,2JZGE JZX81,9#,10#,11#	90/8~	Engine CRANK SHAFT FRONT
03901 6633	90311-80001	80 x 100 x 12	CRESSIDA / MARK II 21R RX6#	80/9~84/	Engine CRANK SHAFT REAR
03901 2801	90311-80001	80 x 100 x 12	CRESSIDA / MARK II M,5M,7M MX6#,71,83	80/9~93/	Engine CRANK SHAFT REAR
03901 5621	90311-75114	75 x 100 x 13	CRESSIDA / MARK II 13T TX6#	80/9~84/	Engine CRANK SHAFT REAR
03901 4989	90311-42003	42 x 60 x 7	CRESSIDA / MARK II 7MGE MX83	89/8~93/	Engine TIMING GEAR CASE
03901 4109	90311-80003	80 x 100 x 8.5	CRESSIDA / MARK II 2Y#,3Y#...YX7#,80	84/11~90/4	Engine CRANK SHAFT REAR
03901 6961	90311-45015	45 x 62 x 9	CRESSIDA / MARK II 1GFE GX10#,11#	98/8~	Engine TIMING GEAR CASE
03901 7281	90311-85004	85 x 105 x 10	CRESSIDA / MARK II L,2L LX6#,7#,8#	80/9~91/2	Engine CRANK SHAFT REAR
03901 6323	90072-72006		CRESSIDA / MARK II 18RGEU RX63	80/9~82/8	Engine VALVE STEM SEAL
03901 7119	90311-85004	85 x 105 x 10	CRESSIDA / MARK II 1S#,4S#...SX60,70	80/9~91/2	Engine CRANK SHAFT REAR
03901 6241	90311-85007	85 x 105 x 10	CRESSIDA / MARK II 2L LX7#,8#,9#,100	91/2~99/	Engine CRANK SHAFT REAR
03901 3015	90311-85007	85 x 105 x 10	CRESSIDA / MARK II 4S#...SX80,90	91/2~96/	Engine CRANK SHAFT REAR
03901 3803	90311-90006	90 x 110 x 9.5	CRESSIDA / MARK II 1JZ#,2JZGE JZX81,9#,10#,11#	90/8~	Engine CRANK SHAFT REAR
03901 4861	90311-38071	38 x 63 x 10 x 16.5	CRESSIDA / MARK II GX11#,JZX11#...GD,GDG,G DG,IR,IRS	00/10~	Final Drive DIFF. SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6269	90913-02094		CRESSIDA / MARK II 1SU SX70	87/9~88/8	Engine VALVE STEM SEAL
03901 7051	90311-75004	75 x 100 x 8.5	CRESSIDA / MARK II 1G#...GX7#,81	86/5~89/8	Engine CRANK SHAFT REAR
03901 1385	15165-70010	18 x 30 x 7	CRESSIDA / MARK II 1GEU,1GGEU,1GG(Z)E GX7#,81	88/8~93/	Engine OIL PUMP
03901 8085	90311-38036	38 x 50 x 8	CRESSIDA / MARK II 1SU SX60,70	80/9~88/	Engine CAM SHAFT
03901 6501	90311-38036	38 x 50 x 8	CRESSIDA / MARK II 4S#...SX80,90	88/8~96/	Engine CAM SHAFT
03901 2053	90311-42003	42 x 60 x 7	CRESSIDA / MARK II 2L#...LX7#	84/8~88/	Engine CAM SHAFT
03901 2823	90311-32020	32 x 46 x 6	CRESSIDA / MARK II 2L#...LX76,80,90,100	88/8~99/	Engine CAM SHAFT
03901 3241	90311-38025	38 x 50 x 6	CRESSIDA / MARK II 1JZGTE JZX90	92/10~96/	Engine CAM SHAFT
03901 2835	90311-40020	40.5 x 52.5 x 6.5	CRESSIDA / MARK II 1JZGTE,2JZGE JZX9#,100,115	92/10~	Engine CAM SHAFT
03901 4493	90311-40020	40.5 x 52.5 x 6.5	CRESSIDA / MARK II 1JZGTE JZX100,110	96/9~	Engine CAM SHAFT (NO.1)
03901 1153	90311-38056	38 x 52.5 x 6	CRESSIDA / MARK II 1JZGTE JZX100,110	96/9~	Engine CAM SHAFT (NO.2)
03901 5633	90311-42003	42 x 60 x 7	CRESSIDA / MARK II L,2L LX6#,7#,8#	80/9~91/2	Engine TIMING GEAR CASE
03901 6335	90029-21005	18 x 30 x 5	CRESSIDA / MARK II 1GFE GX70,81,90,100	88/8~98/	Engine OIL PUMP
03901 6265	90311-35013	35 x 49 x 6	CRESSIDA / MARK II 1GFE GX70,81,90,100	88/8~98/8	Engine CAM SHAFT
03901 4871	15165-70010	18 x 30 x 7	CRESSIDA / MARK II 1SU,4S#...SX70,80,90	84/8~96/	Engine OIL PUMP
03901 5967	90311-45002	45 x 68 x 12	CRESSIDA / MARK II 21R RX6#	80/9~84/	Engine TIMING GEAR COVER
03901 4939	90311-45002	45 x 68 x 12	CRESSIDA / MARK II M,5M MX6#,71	80/9~85/	Engine TIMING GEAR COVER
03901 6161	90311-52003	52 x 70 x 8.5	CRESSIDA / MARK II 7MGE MX83	89/8~93/	Engine TIMING GEAR COVER
03901 2503	90311-38022	38.5 x 58 x 8.5	CRESSIDA / MARK II 13T TX6#	80/9~84/	Engine TIMING GEAR COVER
03901 2927	90311-42003	42 x 60 x 7	CRESSIDA / MARK II 2Y YX7#	84/11~86/ 5	Engine TIMING GEAR COVER
03901 1239	90311-42026	42 x 60 x 7	CRESSIDA / MARK II 2Y,3Y YX7#,80	86/5~97/	Engine TIMING GEAR COVER
03901 4875	90311-45003	45 x 62 x 8	CRESSIDA / MARK II 1G#...GX6#,7#,81,90,100	80/9~98/8	Engine TIMING GEAR CASE
03901 6157	90311-34027	34 x 56 x 6	CRESSIDA / MARK II 1JZGTE JZX110	00/10~	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6383	90311-52059	52 x 65 x 9	CRESSIDA / MARK II SX70,YX7#,GX70,LX7#	84/8~88/	Wheel Hub REAR
03901 6149	90913-02024		CRESSIDA / MARK II 13T TX6#	80/9~81/1	Engine VALVE STEM SEAL
03901 3769	90311-48001	48 x 62 x 9	CRESSIDA / MARK II SX60, TX6#,RX6#,GX6#,MX 6#,LX6#	80/9~84/	Wheel Hub FRONT
03901 1521	90311-48001	48 x 62 x 9	CRESSIDA / MARK II SX70,YX7#,GX7#,MX71,LX 7#	84/8~88/	Wheel Hub FRONT
03901 1889	90311-48001	48 x 62 x 9	CRESSIDA / MARK II GX70,LX76,YX76,78 (WAGON, VAN)	88/10~97/	Wheel Hub FRONT
03901 3679	90311-48013	48 x 73 x 7	CRESSIDA / MARK II SX80,YX80,GX81,MX83,JZ X81,LX80	88/8~95/	Wheel Hub FRONT
03901 3591	90311-48013	48 x 73 x 7	CRESSIDA / MARK II SX90,GX90,JZX9#,LX90	92/10~96/	Wheel Hub FRONT
03901 3563	90311-48013	48 x 73 x 7	CRESSIDA / MARK II GX100,JZX100,101,LX100	96/9~00/	Wheel Hub FRONT
03901 4737	90311-48001	48 x 62 x 9	CRESSIDA / MARK II GX71,MX71	84/8~88/	Wheel Hub REAR OUTER
03901 6681	90311-52059	52 x 65 x 9	CRESSIDA / MARK II SX60, TX6#,RX60,GX60,MX 60,LX60,67	80/9~84/	Wheel Hub REAR
03901 2551	90913-02022		CRESSIDA / MARK II M#,5M# (IN.) MX6#,71	80/9~85/1 0	Engine VALVE STEM SEAL
03901 1567	90311-52059	52 x 65 x 9	CRESSIDA / MARK II GX70,LX76,YX76,78 (WAGON, VAN)	88/10~97/	Wheel Hub REAR
03901 5857	90311-52059	52 x 65 x 9	CRESSIDA / MARK II SX80,LX80,YX80	88/8~95/	Wheel Hub REAR
03901 4219	90311-38009	38 x 58 x 8	CRESSIDA / MARK II RX63,GX61,MX61,63,LX65	80/9~84/	Wheel Hub REAR INNER
03901 5357	90311-38009	38 x 58 x 8	CRESSIDA / MARK II GX71,MX71	84/8~88/	Wheel Hub REAR INNER
03901 5015	90311-63001	63 x 90 x 7 x 10	CRESSIDA / MARK II GX81,MX83,JZX81	88/8~93/	Wheel Hub REAR INNER
03901 2057	90311-63001	63 x 90 x 7 x 10	CRESSIDA / MARK II SX90,GX90,JZX9#,LX90	92/10~96/	Wheel Hub REAR INNER
03901 4655	90311-63001	63 x 90 x 7 x 10	CRESSIDA / MARK II GX10#,JZX10#,LX100	96/9~00/	Wheel Hub REAR INNER
03901 1015	90913-02062		CRESSIDA / MARK II 7MGE MX83	89/8~93/2	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7179	90311-48013	48 x 73 x 7	CRESSIDA / MARK II GX110,JZX110	00/10~	Wheel Hub FRONT
03901 2919	90913-02117		CRESSIDA / MARK II 2LTE LX100	97/5~99/	Engine VALVE STEM SEAL
03901 6463	90913-02024		CRESSIDA / MARK II 21R RX60	80/9~82/8	Engine VALVE STEM SEAL
03901 7063	90913-02038		CRESSIDA / MARK II 1GEU GX6#,7#	80/9~88/8	Engine VALVE STEM SEAL
03901 6523	90913-02062		CRESSIDA / MARK II 1GG#...GX61,71,81	82/8~93/	Engine VALVE STEM SEAL
03901 6603	90913-02062		CRESSIDA / MARK II 1GFE GX70,81,90,100	88/10~98/ 8	Engine VALVE STEM SEAL
03901 1713	90913-02093		CRESSIDA / MARK II 1GFE (IN. & EX.) GX10#,11#	98/8~	Engine VALVE STEM SEAL
03901 5931	90913-02094		CRESSIDA / MARK II 2Y#,3Y#...YX60,7#,80	83/2~97/	Engine VALVE STEM SEAL
03901 6033	90913-02036		CRESSIDA / MARK II L LX6#	80/9~81/7	Engine VALVE STEM SEAL
03901 3781	90913-02060		CRESSIDA / MARK II L,2L LX6#,7#	81/7~88/8	Engine VALVE STEM SEAL
03901 1411	90913-02024		CRESSIDA / MARK II 13T# (IN.) TX6#	81/1~84/7	Engine VALVE STEM SEAL
03901 4715	90913-02110		CRESSIDA / MARK II 2LTE LX100	96/9~97/5	Engine VALVE STEM SEAL
03901 5861	90913-02058		CRESSIDA / MARK II 13T# (EX.) TX6#	81/1~84/7	Engine VALVE STEM SEAL
03901 1557	90913-02079		CRESSIDA / MARK II 1JZ#,2JZGE (IN.) JZX81,9#,10#,11#	90/8~	Engine VALVE STEM SEAL
03901 1305	90913-02062		CRESSIDA / MARK II 1JZ#,2JZGE (EX.) JZX81,9#,10#,11#	90/8~	Engine VALVE STEM SEAL
03901 1435	90913-02079		CRESSIDA / MARK II 4S# (IN.) SX80,90	90/3~96/	Engine VALVE STEM SEAL
03901 2743	90913-02062		CRESSIDA / MARK II 4S# (EX.) SX80,90	90/3~96/	Engine VALVE STEM SEAL
03901 6227	90913-02062		CRESSIDA / MARK II 4S# (IN. & EX.) SX80	88/8~90/3	Engine VALVE STEM SEAL
03901 4293	90913-02056		CRESSIDA / MARK II 1SU SX60,70	82/8~87/9	Engine VALVE STEM SEAL
03901 8019	90913-02015		CRESSIDA / MARK II M#,5M# (EX.) MX6#,71	80/9~85/1 0	Engine VALVE STEM SEAL
03901 4299	90311-57001	57 x 81 x 8 x 11	CRESSIDA / MARK II GX81,MX83,JZX81	88/8~93/	Wheel Hub REAR OUTER
03901 5545	90913-02110		CRESSIDA / MARK II 2L#...LX7#,80,90	88/8~96/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5641	90311-38019	38 x 65 x 10 x 17	CRESSIDA / MARK II GX61 (ATM-EFI),GX71 (EFI)	82/8~88/	Final Drive PINION
03901 2961	90311-48122	48 x 62 x 7	CRESSIDA / MARK II RX63,GX61,MX61,63,LX65	80/9~84/	Wheel Hub REAR OUTER
03901 4405	90311-38133	38 x 74 x 11	CRESSIDA / MARK II SX60,TX6#,RX6#,MX6#,LX 6#	80/9~84/	Final Drive PINION
03901 1577	90311-38133	38 x 74 x 11	CRESSIDA / MARK II GX6#...EXCEPT ATM-EFI	80/9~84/	Final Drive PINION
03901 3705	90311-38133	38 x 74 x 11	CRESSIDA / MARK II SX70,YX7#,GX7# (EXCEPT EFI), MX71,LX7#	84/8~97/	Final Drive PINION
03901 6561	90311-38133	38 x 74 x 11	CRESSIDA / MARK II SX80,YX80,GX81,MX83,JZ X81,LX80	88/8~95/	Final Drive PINION
03901 7461	90311-38133	38 x 74 x 11	CRESSIDA / MARK II SX90,GX90,JZX9#,LX90	92/10~96/	Final Drive PINION
03901 3485	90311-38133	38 x 74 x 11	CRESSIDA / MARK II GX100,JZX10#,LX100	96/9~98/8	Final Drive PINION
03901 8203	90311-40001	40 x 58 x 11	CRESSIDA / MARK II GX81,MX83,JZX81,9#...A34 0E,341E	88/8~96/	Transmission (A/T) EXTENTION HOUSING
03901 2891	90311-38070	38 x 74 x 11 x 19	CRESSIDA / MARK II GX11#,JZX11#	00/10~	Final Drive PINION
03901 4319	90311-38032	38 x 58 x 11	CRESSIDA / MARK II GX100,110,LX100	96/9~	Transmission (A/T) EXTENTION HOUSING
03901 5289	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II RX63,GX61,MX61,63	80/9~84/	Final Drive DIFF. SIDE
03901 4549	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II GX71,MX71	84/8~85/1 0	Final Drive DIFF. SIDE
03901 1813	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II GX71 (EXCEPT EFI,TWC)	85/10~88/	Final Drive DIFF. SIDE
03901 5301	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II GX81 (ATM-HTWC,MTM- LG,GD)	88/8~85/	Final Drive DIFF. SIDE
03901 3969	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II GX90,JZX90 (EXCEPT TOUV),93,LX90,SX90	92/10~96/	Final Drive DIFF. SIDE
03901 8075	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II GX100,JZX105,LX100	96/9~98/8	Final Drive DIFF. SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4485	90311-38011	38 x 63 x 10 x 17	CRESSIDA / MARK II JZX100 EXCEPT 5F,5FC,4FC-TOUV	96/9~98/8	Final Drive DIFF. SIDE
03901 7369	90311-38071	38 x 63 x 10 x 16.5	CRESSIDA / MARK II GX100,JZX105,LX100	98/8~00/	Final Drive DIFF. SIDE
03901 6987	90311-38070	38 x 74 x 11 x 19	CRESSIDA / MARK II GX100,JZX10#,LX100	98/8~00/	Final Drive PINION
03901 3187	90311-38032	38 x 58 x 11	CRESSIDA / MARK II GX70,LX76,80,YX76,78,80, SX80,GX81	91/10~97/	Transmission (M/T) REAR EXTENTION
03901 4641	90311-57001	57 x 81 x 8 x 11	CRESSIDA / MARK II SX90,GX90,JZX9#,LX90	92/10~96/	Wheel Hub REAR OUTER
03901 2251	90311-57001	57 x 81 x 8 x 11	CRESSIDA / MARK II GX10#,JZX10#,LX100	96/9~00/	Wheel Hub REAR OUTER
03901 3441	90311-30115	30 x 45 x 8	CRESSIDA / MARK II SX60,TX6#,RX6#,GX6#,MX 6#,LX6#	80/9~84/	Transmission (M/T) FRONT COVER
03901 3279	90311-30115	30 x 45 x 8	CRESSIDA / MARK II SX70,80,YX7#,80,GX7#,81, LX7#,80	84/8~91/1 0	Transmission (M/T) FRONT COVER
03901 7737	90311-30014	30 x 45 x 8	CRESSIDA / MARK II GX70,LX76,80,YX76,78,80, SX80,GX81	91/10~97/	Transmission (M/T) FRONT COVER
03901 7973	90311-30014	30 x 45 x 8	CRESSIDA / MARK II SX90,GX90,100,LX90	92/10~00/	Transmission (M/T) FRONT COVER
03901 1381	90311-32012	32 x 53 x 7	CRESSIDA / MARK II JZX90,100,110	92/10~	Transmission (M/T) FRONT COVER
03901 3443	90311-40001	40 x 58 x 11	CRESSIDA / MARK II JZX100,101,110	96/9~	Transmission (A/T) EXTENTION HOUSING
03901 3957	90311-38043	38 x 58 x 11	CRESSIDA / MARK II SX70,80,YX7#,80,GX7#,81, LX7#,80	84/8~91/1 0	Transmission (M/T) REAR EXTENTION
03901 6413	90311-38071	38 x 63 x 10 x 16.5	CRESSIDA / MARK II JZX100 EXCEPT 5F,5FC,4FC-TOUV	98/8~00/	Final Drive DIFF. SIDE
03901 7909	90311-38032	38 x 58 x 11	CRESSIDA / MARK II SX90,GX90,100,LX90	92/10~00/	Transmission (M/T) REAR EXTENTION
03901 5795	90311-40001	40 x 58 x 11	CRESSIDA / MARK II JZX90,100,110	92/10~	Transmission (M/T) REAR EXTENTION
03901 1287	90311-38020	38 x 55 x 8.5	CRESSIDA / MARK II SX,YX,GX,MX,LX A41,42D,43D	84/8~96/	Transmission (A/T) FRONT OIL PUMP
03901 8047	90311-38020	38 x 55 x 8.5	CRESSIDA / MARK II GX100,LX100	96/9~98/8	Transmission (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1449	90311-38020	38 x 55 x 8.5	CRESSIDA / MARK II LX100	98/8~99/	Transmission (A/T) FRONT OIL PUMP
03901 4965	90311-38029	38 x 55 x 7.5	CRESSIDA / MARK II GX81,MX83,JZX81,9#...A34 0E,341E	88/8~96/	Transmission (A/T) FRONT OIL PUMP
03901 2905	90311-38029	38 x 55 x 7.5	CRESSIDA / MARK II GX105,115,JZX10#,11#	96/9~	Transmission (A/T) FRONT OIL PUMP
03901 3913	90311-38064	38 x 55 x 8.7	CRESSIDA / MARK II GX100,110	98/8~	Transmission (A/T) FRONT OIL PUMP
03901 7901	04332-30020	Kit	CRESSIDA / MARK II SX,YX,GX,MX,LX A41,42D,43D	84/8~96/	Transmission (A/T) EXTENTION HOUSING
03901 5719	90311-38043	38 x 58 x 11	CRESSIDA / MARK II SX60,TX6#,RX6#,GX6#,MX 6#,LX6#	80/9~84/	Transmission (M/T) REAR EXTENTION
03901 1729	90311-56015	56 x 75 x 7 x 12	CRESSIDA / MARK II WAGON MCV25,SXV25	97/6~	Wheel Hub REAR INNER
03901 8233	90311-38034	38 x 50 x 10.5	CRESSIDA / MARK II WAGON 1MZFE,2MZFE MCV2#	97/4~	Engine CAM SHAFT
03901 2773	90311-52005	52 x 75 x 7.5 x 12	CRESSIDA / MARK II WAGON MCV25,SXV25	97/6~	Wheel Hub REAR OUTER
03901 5387	90311-54005	55 x 70 x 10	CRESSIDA / MARK II WAGON MCV25,SXV25	97/6~	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 6785	90311-35033	35 x 55 x 9 x 15.5	CRESSIDA / MARK II WAGON SXV20	97/4~	Mission & Differential (A/T) TRANSAXLE CASE
03901 1659	90311-35033	35 x 55 x 9 x 15.5	CRESSIDA / MARK II WAGON SXV20	97/4~	Mission & Differential (A/T) DIFF. SIDE
03901 3849	90311-50011	50 x 80 x 16.5 x 23	CRESSIDA / MARK II WAGON MCV2#	97/4~	Mission & Differential (A/T) DIFF. SIDE
03901 4793	90311-50022	42 x 62 x 8.5 x 15.4	CRESSIDA / MARK II WAGON SXV25	97/6~	Mission & Differential (A/T) DIFF. SIDE
03901 1225	90311-38020	38 x 55 x 8.5	CRESSIDA / MARK II WAGON MCV2#,SXV2#	97/4~	Mission & Differential (A/T) FRONT OIL PUMP
03901 3101	04445-32051		CRESSIDA / MARK II WAGON MCV20,21,SXV20	97/4~	Steering (P/S) R & P GASKET KIT
03901 1683	04445-33080		CRESSIDA / MARK II WAGON MCV25,SXV25	97/6~	Steering (P/S) R & P GASKET KIT
03901 2573	90311-40010	40 x 56 x 9 x 15.5	CRESSIDA / MARK II WAGON MCV20,21	97/4~	Mission & Differential (A/T) FRONT DIFFERENTIAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1393	90311-26003	26 x 38 x 6.5	CRESSIDA / MARK II WAGON MCV2#,SXV2#	97/4~	Steering (P/S) CONTROL VALVE LOWER
03901 5309	90311-38036	38 x 50 x 8	CRESSIDA / MARK II WAGON 5SFE SXV2#	97/4~	Engine CAM SHAFT
03901 1217	90311-40022	40 x 55 x 6	CRESSIDA / MARK II WAGON 1MZFE,2MZFE MCV2#	97/4~	Engine OIL PUMP
03901 2047	15165-70010	18 x 30 x 7	CRESSIDA / MARK II WAGON 5SFE SXV2#	97/4~	Engine OIL PUMP
03901 1865	90311-42035	42 x 60 x 7	CRESSIDA / MARK II WAGON 5SFE SXV2#	97/4~	Engine CRANK SHAFT FRONT
03901 2421	90311-92008	92 x 110 x 9	CRESSIDA / MARK II WAGON 1MZFE,2MZFE MCV2#	97/4~	Engine CRANK SHAFT REAR
03901 3731	90311-85007	85 x 105 x 10	CRESSIDA / MARK II WAGON 5SFE SXV2#	97/4~	Engine CRANK SHAFT REAR
03901 1451	90913-02079		CRESSIDA / MARK II WAGON 5SFE (IN.)	97/4~	Engine VALVE STEM SEAL
03901 5715	90913-02062		CRESSIDA / MARK II WAGON 5SFE (EX.)	97/4~	Engine VALVE STEM SEAL
03901 6385	90913-02101		CRESSIDA / MARK II WAGON 1MZFE,2MZFE (IN.)	97/4~	Engine VALVE STEM SEAL
03901 7283	90913-02111		CRESSIDA / MARK II WAGON 1MZFE,2MZFE (EX.)	97/4~	Engine VALVE STEM SEAL
03901 6727	90311-19010	19 x 32 x 6	CRESSIDA / MARK II WAGON MCV2#,SXV2#	97/4~	Steering (P/S) CONTROL VALVE UPPER
03901 4751	90311-43003	43 x 65 x 8	CROWN GS141,JZS141,143,145,LS14 1	91/10~95/	Wheel Hub REAR INNER
03901 7671	90311-35013	35 x 49 x 6	CROWN 1GFE GS13#,151,171	88/9~	Engine CAM SHAFT
03901 1285	04445-30120		CROWN GS141,JZS141,LS141 (SALEX)	91/10~95/	Steering (P/S) GEAR GASKET KIT
03901 5121	90311-30016	30 x 42 x 7 x 8	CROWN JZS153,155,157,UZS155 C,ROY#,SALEX	95/8~	Steering (P/S) CONTROL VALVE LOWER
03901 5033	90311-30016	30 x 42 x 7 x 8	CROWN UZS173	99/9~	Steering (P/S) CONTROL VALVE LOWER
03901 1439	90310-25004	25 x 38 x 7 x 8	CROWN GS151,JZS151,LS151	95/8~	Steering (P/S) CONTROL VALVE LOWER
03901 6171	90310-25004	25 x 38 x 7 x 8	CROWN GS272,JZS171,173,175,179	99/9~	Steering (P/S) CONTROL VALVE LOWER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4499	90311-42003	42 x 60 x 7	CROWN L,2L#...LS11#,12#,13#	79/9~89/8	Engine CAM SHAFT
03901 3069	90311-32020	32 x 46 x 6	CROWN 2L#...LS13#,141,151	89/8~	Engine CAM SHAFT
03901 5699	90311-38013	38.5 x 58 x 11	CROWN 5M#,6M#...MS112.123.125	83/8~87/	Engine CAM SHAFT
03901 8201	90311-35013	35 x 49 x 6	CROWN 7M#...MS13#	87/9~91/	Engine CAM SHAFT
03901 6101	90311-38036	38 x 50 x 8	CROWN 1GE#...GS120,126	83/8~87/1	Engine CAM SHAFT
03901 5321	90310-30013	30 x 41 x 6.5	CROWN JZS177,UZS171,175	99/9~	Steering (P/S) CONTROL VALVE LOWER
03901 1199	90311-35013	35 x 49 x 6	CROWN 1GGE,1GGZE GS121,13#	83/8~91/	Engine CAM SHAFT
03901 5049	90310-30013	30 x 41 x 6.5	CROWN JZS155,UZS151,157 (MAJESTA)	95/8~	Steering (P/S) CONTROL VALVE LOWER
03901 2451	90311-35040	35 x 49 x 6	CROWN 1GGPE GS130,151	89/8~	Engine CAM SHAFT
03901 7431	90311-40020	40.5 x 52.5 x 6.5	CROWN 1JZGE,2JZGE JZS13#,14#,15#	90/8~	Engine CAM SHAFT
03901 4949	90311-40020	40.5 x 52.5 x 6.5	CROWN 1JZGE,2JZGE JZS171,173,179	99/9~	Engine CAM SHAFT
03901 7207	90311-40020	40.5 x 52.5 x 6.5	CROWN 1JZGFE JZS171	99/9~	Engine CAM SHAFT (NO.1)
03901 6599	90311-38056	38 x 52.5 x 6	CROWN 1JZGFE JZS171	99/9~	Engine CAM SHAFT (NO.2)
03901 3331	90311-34027	34 x 56 x 6	CROWN 2JZFSE JZS175,177	99/9~	Engine CAM SHAFT
03901 5007	90311-38036	38 x 50 x 8	CROWN 1UZFE UZS131,14#,15#	89/8~97/7	Engine CAM SHAFT
03901 7887	90311-71001	71.5 x 85 x 10	CROWN 1UZFE UZS15#,17#	97/7	Engine CAM SHAFT
03901 6267	90311-45002	45 x 68 x 12	CROWN 5RU RU110	79/9~83/	Engine TIMING GEAR COVER
03901 7573	90311-45002	45 x 68 x 12	CROWN M#,5MEU MS11#,120,130	79/9~89/	Engine TIMING GEAR COVER
03901 2035	90311-38025	38 x 50 x 6	CROWN 1GE#...GS120,126,13#	87/1~89/	Engine CAM SHAFT
03901 6137	04445-51010		CROWN GS171,JZS171 HTWC,TWC	99/9~	Steering (P/S) R & P GASKET KIT
03901 6331	04445-30130		CROWN GS130/6,LS130/6,YS130 STD,DX,SDX	91/10~95/	Steering (P/S) GEAR GASKET KIT
03901 4033	04445-30130		CROWN GS13#,JZS130,LS130	95/12~99/	Steering (P/S) GEAR GASKET KIT
03901 4579	04445-30130		CROWN LS141 (SSL)	91/10~95/	Steering (P/S) GEAR GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7135	04445-30140		CROWN JZS147,149,UZS141,147	91/10~95/	Steering (P/S) R & P GASKET KIT
03901 4023	04445-30170		CROWN UZS143,145,155	92/10~	Steering (P/S) R & P GASKET KIT
03901 3225	04445-30180		CROWN JZS155,UZS151,157 (MAJESTA)	95/8~	Steering (P/S) R & P GASKET KIT
03901 6195	04445-30190		CROWN JZS155 ROY#	95/8~	Steering (P/S) R & P GASKET KIT
03901 8077	04445-30200		CROWN GS151,JZS151,LS151	95/8~	Steering (P/S) R & P GASKET KIT
03901 3053	04445-30220		CROWN JZS153,157	95/12~	Steering (P/S) R & P GASKET KIT
03901 7399	04445-30260		CROWN JZS171,175 D4,TWT	99/9~	Steering (P/S) R & P GASKET KIT
03901 5553	90311-30016	30 x 42 x 7 x 8	CROWN UZS143M145	92/10~95/	Steering (P/S) CONTROL VALVE LOWER
03901 3649	04445-30290		CROWN UZS173	99/9~	Steering (P/S) R & P GASKET KIT
03901 8241	90311-42003	42 x 60 x 7	CROWN 3Y#...YS120	83/8~87/	Engine TIMING GEAR COVER
03901 4181	90311-19002	19 x 32 x 7 x 8	CROWN YS120,GS12#,MS12#,LS12#	83/8~87/	Steering (P/S) ADJUSTER PLUG
03901 4451	90312-32002	32 x 40 x 5	CROWN RS110,GS11#,MS11#,LS11#	79/9~83/	Steering (P/S) GEAR HOUSING
03901 3237	90312-32002	32 x 40 x 5	CROWN YS120,GS12#,MS12#,LS12#	83/8~87/	Steering (P/S) GEAR HOUSING
03901 3941	90312-32002	32 x 40 x 5	CROWN YS130,GS13#,MS13#,UZS13 1,LS13#	87/9~91/1 0	Steering (P/S) GEAR HOUSING
03901 7857	90312-32002	32 x 40 x 5	CROWN YS130,GS13#,JZS13#,LS13#	91/10~99/	Steering (P/S) GEAR HOUSING
03901 3195	90312-32002	32 x 40 x 5	CROWN JZS141,143,145,LS141	91/10~95/	Steering (P/S) GEAR HOUSING
03901 1977	90311-19002	19 x 32 x 7 x 8	CROWN UZS14#,JZS147,149	91/10~95/	Steering (P/S) CONTROL VALVE UPPER
03901 6589	90311-19002	19 x 32 x 7 x 8	CROWN GS15#,JZS15#,UZS15#,LS15 1	95/8~	Steering (P/S) CONTROL VALVE UPPER
03901 7777	90311-19002	19 x 32 x 7 x 8	CROWN GS171,JZS17#,UZS17#	99/9~	Steering (P/S) CONTROL VALVE UPPER
03901 1783	90310-30013	30 x 41 x 6.5	CROWN JZS147,149,UZS141,147	91/10~95/	Steering (P/S) CONTROL VALVE LOWER
03901 6719	04445-30280		CROWN JZS173,179	99/9~	Steering (P/S) R & P GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3407	90913-02110		CROWN 2L#	89/8~97/5	Engine VALVE STEM SEAL
03901 2347	90311-95012	95 x 113 x 8.5	CROWN 1UZFE UZS131,14#,15#,17#	89/8~	Engine CRANK SHAFT REAR
03901 6489	90913-02042		CROWN 5RU RU110	79/9~83/	Engine VALVE STEM SEAL
03901 1829	90913-02015		CROWN M#,5MEU (EX.)	79/9~89/	Engine VALVE STEM SEAL
03901 3173	90913-02022		CROWN M#,5MEU (IN.)	79/9~89/	Engine VALVE STEM SEAL
03901 1717	90913-02110		CROWN 5MGEU,6MGEU	81/8~87/	Engine VALVE STEM SEAL
03901 5705	90913-02062		CROWN 7MGE	87/9~91/	Engine VALVE STEM SEAL
03901 3669	90913-02038		CROWN 1G#,1GE	81/8~89/	Engine VALVE STEM SEAL
03901 8213	90913-02062		CROWN 1GG#,1GFE	83/8~98/8	Engine VALVE STEM SEAL
03901 4957	90913-02093		CROWN 1GFE (IN. & EX.)	98/8~	Engine VALVE STEM SEAL
03901 6757	90913-02094		CROWN 3Y#	83/8~95/	Engine VALVE STEM SEAL
03901 7697	90311-48004	48 x 70 x 12	CROWN 5MGEU MS112,123	81/8~84/8	Engine TIMING GEAR COVER
03901 2595	90913-02060		CROWN L,2L#	81/7~89/8	Engine VALVE STEM SEAL
03901 1873	90311-80003	80 x 100 x 8.5	CROWN 3Y#...YS120	83/8~87/	Engine CRANK SHAFT REAR
03901 4597	90913-02117		CROWN 2L#	97/5~	Engine VALVE STEM SEAL
03901 2959	90913-02079		CROWN 1JZGE,2JZGE (IN. & EX.)	90/8~91/1 0	Engine VALVE STEM SEAL
03901 1817	90913-02079		CROWN 1JZGE,2JZGE (IN.)	91/10~	Engine VALVE STEM SEAL
03901 8089	90913-02062		CROWN 1JZGE,2JZGE (EX.)	91/10~	Engine VALVE STEM SEAL
03901 5905	90913-02079		CROWN 1UZFE (IN. & EX.)	90/8~96/8	Engine VALVE STEM SEAL
03901 3751	90913-02079		CROWN 1UZFE (IN.)	96/8~97/7	Engine VALVE STEM SEAL
03901 2529	90913-02113		CROWN 1UZFE (IN.)	97/7~	Engine VALVE STEM SEAL
03901 3243	90913-02106		CROWN 1UZFE (EX.)	96/8~97/7	Engine VALVE STEM SEAL
03901 7239	90913-02112		CROWN 1UZFE (EX.)	97/7~	Engine VALVE STEM SEAL
03901 2871	90311-43003	43 x 65 x 8	CROWN MS135,137,UZS131	87/9~91/	Wheel Hub REAR INNER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6299	90913-02036		CROWN L	79/9~81/7	Engine VALVE STEM SEAL
03901 6733	90311-43004	43 x 60 x 7	CROWN 1UZFE UZS131,14#,15#	89/8~97/1 2	Engine OIL PUMP
03901 2911	04445-30300		CROWN JZS177,UZS171,175	99/9~	Steering (P/S) R & P GASKET KIT
03901 5891	90311-42026	42 x 60 x 7	CROWN 3Y#...YS120	87/9~95/	Engine TIMING GEAR COVER
03901 7743	90311-42003	42 x 60 x 7	CROWN 7MGE MS135,137	87/9~91/	Engine TIMING GEAR CASE
03901 4505	90311-42003	42 x 60 x 7	CROWN L,2L#...LS11#,12#,13#	79/9~91/2	Engine TIMING GEAR CASE
03901 4807	90311-42026	42 x 60 x 7	CROWN 2L#...LS13#,141,151	91/2~	Engine TIMING GEAR CASE
03901 2371	90311-45003	45 x 62 x 8	CROWN 1G#,1GG#...GS11#,12#,13#, 141,151	81/8~98/8	Engine TIMING GEAR CASE
03901 2527	90311-45015	45 x 62 x 9	CROWN 1GFE GS151,171	98/8~	Engine TIMING GEAR CASE
03901 2723	90311-45010	45 x 62 x 8.5	CROWN 1GGPE GS130,151	89/8~	Engine TIMING GEAR CASE
03901 3239	15165-70010	18 x 30 x 7	CROWN 1GE,1GG#...GS13#	87/9~91/1 0	Engine OIL PUMP
03901 1639	90029-21005	18 x 30 x 5	CROWN 1GFE GS13#,141,151	88/9~98/8	Engine OIL PUMP
03901 7175	90311-90006	90 x 110 x 9.5	CROWN 1JZ#,2JZ#...JZS13#,14#,15#, 17#	90/8~	Engine CRANK SHAFT REAR
03901 4727	15165-70040	18 x 30 x 7	CROWN 1GGPE GS130,151	89/8~	Engine OIL PUMP
03901 2159	90311-80012	80 x 100 x 8.5	CROWN 3Y#...YS130	87/9~95/	Engine CRANK SHAFT REAR
03901 1395	90311-43006	43 x 60 x 7	CROWN 1UZFE UZS15#,17#	97/12~	Engine OIL PUMP
03901 4757	90311-46001	46 x 63 x 6.5	CROWN 1JZGE,2JZGE JZS13#,14#,15#,17#	90/8~	Engine CRANK SHAFT FRONT
03901 2285	90311-80001	80 x 100 x 12	CROWN 5RU RU110	79/9~83/	Engine CRANK SHAFT REAR
03901 4183	90311-80001	80 x 100 x 12	CROWN M#,5M#,6M#,7M#...MS11#, 12#,13#	79/9~91/	Engine CRANK SHAFT REAR
03901 6261	90311-85001	85 x 105 x 13	CROWN L,2L#...LS11#,12#	79/9~84/2	Engine CRANK SHAFT REAR
03901 5159	90311-85004	85 x 105 x 10	CROWN 2L#...LS12#,13#	84/2~91/2	Engine CRANK SHAFT REAR
03901 3013	90311-85007	85 x 105 x 10	CROWN 2L#...LS13#,141,151	91/2	Engine CRANK SHAFT REAR
03901 7937	90311-75114	75 x 100 x 13	CROWN 1G#...GS11#,12#	81/8~86/5	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5029	90311-75004	75 x 100 x 8.5	CROWN 1G#...GS12#,13#	86/5~89/8	Engine CRANK SHAFT REAR
03901 1417	90311-75007	75 x 100 x 10	CROWN 1G#...GS13#,141,151	89/8	Engine CRANK SHAFT REAR
03901 7197	90311-52003	52 x 70 x 8.5	CROWN 6MGEU,7MGE MS125,135,137	84/8~91/	Engine TIMING GEAR COVER
03901 1049	15165-70010	18 x 30 x 7	CROWN 1GFE GS151,171	98/8~	Engine OIL PUMP
03901 1133	04445-30120		CROWN GS130/1,JZS130/1,LS130/1 ROY,SALEX	91/10~95/	Steering (P/S) GEAR GASKET KIT
03901 4717	90311-38058	38 x 55 x 8.5	CROWN GS151 LPGTE	96/10~	Transmission (A/T) FRONT OIL PUMP
03901 4663	90311-30115	30 x 45 x 8	CROWN RS110,MS110,117 3H,4H	80/10~83/	Transmission (M/T) FRONT COVER
03901 5367	90311-30115	30 x 45 x 8	CROWN RS110,MS11#...4F,5F,GS11# ,LS11#	79/9~83/	Transmission (M/T) FRONT COVER
03901 3771	90311-30115	30 x 45 x 8	CROWN YS120,GS12#,MS120,LS12#	83/8~87/	Transmission (M/T) FRONT COVER
03901 5365	90311-30115	30 x 45 x 8	CROWN YS130,GS13#,MS13#,LS13#	87/9~91/1 0	Transmission (M/T) FRONT COVER
03901 8067	90311-30014	30 x 45 x 8	CROWN YS130,GS13#,LS13#	91/10~99/	Transmission (M/T) FRONT COVER
03901 1675	90311-30014	30 x 45 x 8	CROWN GS151	95/12~	Transmission (M/T) FRONT COVER
03901 5741	04332-30010	Kit	CROWN MS11#...4F,5F,LS11#	79/9~81/1	Transmission (M/T) REAR EAXTENTION
03901 6617	90311-38140	38 x 58 x 11	CROWN RS110,MS110,117 3H,4H	79/9~80/1 0	Transmission (M/T) REAR EAXTENTION
03901 5543	90311-38043	38 x 58 x 11	CROWN RS110,MS110,117 3H,4H	80/10~81/ 8	Transmission (M/T) REAR EAXTENTION
03901 4107	90311-57001	57 x 81 x 8 x 11	CROWN GS151,JZS15#,LS151,UZS15 #	95/8~	Wheel Hub REAR OUTER
03901 7501	90311-38043	38 x 58 x 11	CROWN RS110,GS11#,MS110,117,LS 11#	81/8~83/	Transmission (M/T) REAR EAXTENTION
03901 1967	90311-57001	57 x 81 x 8 x 11	CROWN JZS147,149,UZS14#	91/10~95/	Wheel Hub REAR OUTER
03901 6243	90311-38043	38 x 58 x 11	CROWN YS130,GS13#,LS13#...5F	87/9~91/1 0	Transmission (M/T) REAR EAXTENTION
03901 3067	90311-38043	38 x 58 x 11	CROWN YS130,GS13#,MS130,LS13# ...4H	87/9~88/8	Transmission (M/T) REAR EAXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6597	90311-38032	38 x 58 x 11	CROWN YS130,GS13#,MS130,LS13# ...4H	88/8~91/1 0	Transmission (M/T) REAR EAXTENTION
03901 6677	90311-38032	38 x 58 x 11	CROWN YS130,GS13#,LS136	91/10~99/	Transmission (M/T) REAR EAXTENTION
03901 3741	90311-38032	38 x 58 x 11	CROWN GS151	95/12~	Transmission (M/T) REAR EAXTENTION
03901 3133	90311-38020	38 x 55 x 8.5	CROWN YS130,MS130,LS13#,GS130 ,131 (EXC. SPC)	87/9~91/1 0	Transmission (A/T) FRONT OIL PUMP
03901 6329	90311-38020	38 x 55 x 8.5	CROWN GS13#,LS136,YS130	91/10~99/	Transmission (A/T) FRONT OIL PUMP
03901 6131	90311-38020	38 x 55 x 8.5	CROWN GS141,151	93/8~96/1 0	Transmission (A/T) FRONT OIL PUMP
03901 7493	90311-38020	38 x 55 x 8.5	CROWN GS151 HTWC	96/10~98/ 8	Transmission (A/T) FRONT OIL PUMP
03901 4243	90311-38064	38 x 55 x 8.7	CROWN GS151 HTWC	98/8~	Transmission (A/T) FRONT OIL PUMP
03901 4291	90311-38064	38 x 55 x 8.7	CROWN GS171	99/9~	Transmission (A/T) FRONT OIL PUMP
03901 4761	90311-19002	19 x 32 x 7 x 8	CROWN RS110,GS11#,MS11#,LS11#	79/9~83/	Steering (P/S) ADJUSTER PLUG
03901 3541	90311-58118	58 x 72 x 9	CROWN GS11#,MS11#,LS11#...WAG ON,VAN	79/9~83/	Wheel Hub REAR
03901 8087	90311-48001	48 x 62 x 9	CROWN YS120,GS12#,MS12#,LS12#	83/8~87/	Wheel Hub FRONT
03901 5419	90311-48001	48 x 62 x 9	CROWN MS13#,UZS13#	87/9~91/	Wheel Hub FRONT
03901 6403	90311-48001	48 x 62 x 9	CROWN YS130,GS13#,JZS13#,LS13#	87/9~99/	Wheel Hub FRONT
03901 2007	90311-48001	48 x 62 x 9	CROWN GS141,JZS141,143,145,LS14 1	91/10~95/	Wheel Hub FRONT
03901 5407	90311-48013	48 x 73 x 7	CROWN GS151,JZS151,155 (EXC. MAJESTA),LS151	95/8~	Wheel Hub FRONT
03901 1279	90311-48013	48 x 73 x 7	CROWN GS171,JZS171,175	99/9~	Wheel Hub FRONT
03901 1833	90311-50008	50 x 77.5 x 9 x 14	CROWN JZS147,149,UZS141,147	91/10~95/	Wheel Hub FRONT
03901 4345	90311-50008	50 x 77.5 x 9 x 14	CROWN JZS155,UZS151,157 (MAJESTA)	95/8~99/	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7089	90311-50008	50 x 77.5 x 9 x 14	CROWN JZS177,UZS171,175	99/9~	Wheel Hub FRONT
03901 2853	90311-52059	52 x 65 x 9	CROWN RS110,GS110,MS11#,LS11#. ..SEDAN,H/T	79/9~83/	Wheel Hub REAR
03901 7397	90311-32106	32 x 48 x 8	CROWN RS110,MS110,117 3H,4H	79/9~80/10	Transmission (M/T) FRONT COVER
03901 1867	90311-52059	52 x 65 x 9	CROWN YS130,GS130,MS130,LS130 SEDAN,H/T	87/9~95/	Wheel Hub REAR
03901 2627	90311-38043	38 x 58 x 11	CROWN YS120,GS12#,MS120,LS12#	83/8~87/	Transmission (M/T) REAR EAXTENTION
03901 7669	90311-58118	58 x 72 x 9	CROWN GS12#,LS12#...WAGON,VAN	83/8~87/	Wheel Hub REAR
03901 7949	90311-58118	58 x 72 x 9	CROWN GS13#,JZS130,LS13#...WAGON,VAN	87/9~99/	Wheel Hub REAR
03901 2951	90311-38009	38 x 58 x 8	CROWN GS121,MS123,125	83/8~87/	Wheel Hub REAR INNER
03901 3845	90311-43003	43 x 65 x 8	CROWN GS131,JZS131,133,135,LS131	87/9~95/	Wheel Hub REAR INNER
03901 6573	90311-48122	48 x 62 x 7	CROWN RS110,GS11#,MS11#,LS11#	79/9~83/	Wheel Hub FRONT
03901 6255	90311-63001	63 x 90 x 7 x 10	CROWN JZS147,149,UZS14#	91/10~95/	Wheel Hub REAR INNER
03901 4479	90311-63001	63 x 90 x 7 x 10	CROWN GS151,JZS15#,LS151,UZS15#	95/8~	Wheel Hub REAR INNER
03901 1387	90311-48001	48 x 62 x 9	CROWN GS121,MS123,125	83/8~87/	Wheel Hub REAR OUTER
03901 2455	90311-48001	48 x 62 x 9	CROWN MS135,137,UZS131	87/9~91/	Wheel Hub REAR OUTER
03901 7717	90311-48001	48 x 62 x 9	CROWN GS131,JZS131,133,135,LS131	87/9~95/	Wheel Hub REAR OUTER
03901 3017	90311-48001	48 x 62 x 9	CROWN GS141,JZS141,143,145,LS141	91/10~95/	Wheel Hub REAR OUTER
03901 5427	90311-52059	52 x 65 x 9	CROWN YS120,GS120,MS120,LS120 SEDAN,H/T	83/8~87/	Wheel Hub REAR
03901 4229	90311-38043	38 x 58 x 11	CROWN MS11#...4F,5F,LS11#	81/8~	Transmission (M/T) REAR EAXTENTION
03901 7087	90311-44005	44 x 74 x 11 x 16	CROWN JZS155,UZS15# (MAJESTA)	95/8~	Final Drive PINION
03901 7625	90311-44005	44 x 74 x 11 x 16	CROWN JZS177,UZS17#	99/9~	Final Drive PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1641	90311-38011	38 x 63 x 10 x 17	CROWN GS121,MS123,125	83/8~87/	Final Drive DIFF.SIDE
03901 1535	90311-38011	38 x 63 x 10 x 17	CROWN GS131 (EXC. SPC),LS131	87/9~91/1 0	Final Drive DIFF.SIDE
03901 5273	90311-38011	38 x 63 x 10 x 17	CROWN GS131,141,LS131,141	91/10~95/	Final Drive DIFF.SIDE
03901 4473	90311-38011	38 x 63 x 10 x 17	CROWN GS151,JZS151,153,LS151	95/8~98/8	Final Drive DIFF.SIDE
03901 4617	90311-38071	38 x 63 x 10 x 16.5	CROWN GS151,JZS151,153,LS151	98/8~	Final Drive DIFF.SIDE
03901 1893	90311-38071	38 x 63 x 10 x 16.5	CROWN GS171,JZS171,173,179 4FC HTWC,TWC	99/9~	Final Drive DIFF.SIDE
03901 4891	90311-43001	43 x 70 x 9 x 15.5	CROWN GS131 (SPC),MS135,137,JZS131,U ZS131	87/9~91/	Final Drive DIFF.SIDE
03901 3287	90311-43001	43 x 70 x 9 x 15.5	CROWN JZS131,133,135,141,143,145	91/10~95/	Final Drive DIFF.SIDE
03901 3783	90311-44005	44 x 74 x 11 x 16	CROWN JZS147,149,UZS14#	91/10~95/	Final Drive PINION
03901 3345	90311-43001	43 x 70 x 9 x 15.5	CROWN JZS171 (ATH,ATGV),175	99/9~	Final Drive DIFF.SIDE
03901 4561	90311-43001	43 x 70 x 9 x 15.5	CROWN JZS155 ROY,ROYG,ROYT	95/8~	Final Drive DIFF.SIDE
03901 4257	90311-47008	47 x 72 x 10 x 11	CROWN JZS155,UZS15# (MAJESTA)	95/8~	Final Drive DIFF.SIDE
03901 6181	90311-47008	47 x 72 x 10 x 11	CROWN JZS177,UZS17#	99/9~	Final Drive DIFF.SIDE
03901 5637	90311-19001	19 x 32 x 8	CROWN RS#,YS#,GS#,MS#,LS#	79/9~93/	Steering (M/S) WORM GEAR
03901 5097	90310-34006	34 x 48 x 8	CROWN RS#,YS#,GS#,MS#,LS#	79/9~93/	Steering (M/S) SECTOR SHAFT
03901 5223	04445-30070		CROWN RS110,GS11#,MS11#,LS11#	79/9~83/	Steering (P/S) GEAR GASKET KIT
03901 6541	04445-30080		CROWN YS120,GS12#,MS12#,LS12#	83/8~87/	Steering (P/S) GEAR GASKET KIT
03901 6593	04445-30101		CROWN YS130,GS13#,MS13# (EXC. 135,137),LS13#	87/9~91/	Steering (P/S) GEAR GASKET KIT
03901 6141	04445-30091		CROWN MS137	87/9~89/8	Steering (P/S) GEAR GASKET KIT
03901 2735	04445-30091		CROWN MS135,137,UZS131	89/8~91/	Steering (P/S) GEAR GASKET KIT
03901 5175	04445-30110		CROWN JZS133,135,143,145	91/10~95/	Steering (P/S) GEAR GASKET KIT
03901 2783	90311-38029	38 x 55 x 7.5	CROWN GS130,131 (SPC)	87/9~91/1 0	Transmission (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5139	04332-30030	Kit	CROWN GS141,151	93/8~97/7	Transmission (A/T) REAR EXTENTION
03901 5073	90311-47008	47 x 72 x 10 x 11	CROWN JZS147,149,UZS14#	91/10~95/	Final Drive DIFF.SIDE
03901 4927	90311-38070	38 x 74 x 11 x 19	CROWN GS171,JZS171,173,175,179	99/9~	Final Drive PINION
03901 5143	90311-38029	38 x 55 x 7.5	CROWN JZS13#,MS135,137,UZS131	87/9~91/10	Transmission (A/T) FRONT OIL PUMP
03901 6233	90311-38029	38 x 55 x 7.5	CROWN JZS130,131,133,135,LS130,131	91/10~99/	Transmission (A/T) FRONT OIL PUMP
03901 5455	90311-38029	38 x 55 x 7.5	CROWN JZS14#,LS141,UZS14#	91/10~95/	Transmission (A/T) FRONT OIL PUMP
03901 7641	90311-38029	38 x 55 x 7.5	CROWN JZS15#,LS151,UZS15#	95/8~	Transmission (A/T) FRONT OIL PUMP
03901 7655	90311-38029	38 x 55 x 7.5	CROWN JZS17#,UZS17#	99/9~	Transmission (A/T) FRONT OIL PUMP
03901 3991	04332-30030	Kit	CROWN GS13#,LS136,YS130	91/10~99/	Transmission (A/T) REAR EXTENTION
03901 3653	90311-38032	38 x 58 x 11	CROWN GS151,171	97/7~	Transmission (A/T) REAR EXTENTION
03901 1727	90311-40001	40 x 58 x 11	CROWN JZS13#,MS135,137,UZS131	87/9~91/10	Transmission (A/T) REAR EXTENTION
03901 1541	90311-40001	40 x 58 x 11	CROWN JZS130,131,133,135,LS130,131	91/10~	Transmission (A/T) REAR EXTENTION
03901 6667	90311-40001	40 x 58 x 11	CROWN JZS141,143,145LS141	91/10~95/	Transmission (A/T) REAR EXTENTION
03901 3189	90311-38133	38 x 74 x 11	CROWN GS141,JZS141,143,145,LS141	91/10~95/	Final Drive PINION
03901 5413	90311-38070	38 x 74 x 11 x 19	CROWN GS151,JZS15# (EXC. MAJESTA),LS151	98/8~	Final Drive PINION
03901 7531	04332-30030	Kit	CROWN YS130,GS13# (EXC. SPC),MS130,LS13#	87/9~91/10	Transmission (A/T) REAR EXTENTION
03901 5157	90311-38133	38 x 74 x 11	CROWN GS151,JZS15# (EXC. MAJESTA),LS151	95/8~98/8	Final Drive PINION
03901 2741	90311-40001	40 x 58 x 11	CROWN JZS151,155 (EXC. MAJESTA),LS151	95/8~	Transmission (A/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7459	90311-38133	38 x 74 x 11	CROWN YS130,GS13#,MS13#,JZS130,LS13#	87/9~99/	Final Drive PINION
03901 3647	90311-38133	38 x 74 x 11	CROWN YS120,GS12#,MS12#,LS12#	83/8~87/	Final Drive PINION
03901 4255	90311-38133	38 x 74 x 11	CROWN RS110,GS11#,MS11#,LS11#	79/9~83/	Final Drive PINION
03901 1473	90311-42024	42 x 55 x 10	CROWN JZS155,UZS151,157 (MAJESTA)	95/8~99/	Transmission (A/T) REAR EXTENTION
03901 2973	90311-42024	42 x 55 x 10	CROWN JZS147,149,UZS141,147	91/10~95/	Transmission (A/T) REAR EXTENTION
03901 5031	90311-40001	40 x 58 x 11	CROWN JZS171,175	99/9~	Transmission (A/T) REAR EXTENTION
03901 4755	90311-42024	42 x 55 x 10	CROWN JZS177,UZS171,175	99/9~	Transmission (A/T) REAR EXTENTION
03901 8015	90311-85007	85 x 105 x 10	CURREN 3SFE,4SFE ST20#	94/2~98/	Engine CRANK SHAFT REAR
03901 7479	90311-19002	19 x 32 x 7 x 8	CURREN ST20#	94/2~98/	Steering (P/S) CONTROL VALVE UPPER
03901 8017	90310-28003	28 x 41 x 6.5	CURREN ST207	94/2~98/	Steering (P/S) CONTROL VALVE LOWER
03901 3283	90310-31001	31 x 44 x 6.5	CURREN ST206,208	94/2~98/	Steering (P/S) CONTROL VALVE LOWER
03901 3733	90311-35013	35 x 49 x 6	CURREN 3SGE ST206	94/2~98/	Engine CAM SHAFT
03901 4867	90311-38036	38 x 50 x 8	CURREN 3SFE,4SFE ST20#	94/2~98/	Engine CAM SHAFT
03901 3911	90311-42026	42 x 60 x 7	CURREN 3S#,4SFE ST20#	94/2~96/9	Engine CRANK SHAFT FRONT
03901 3875	9031-89002	89 x 105 x 10	CURREN 3SGE ST206	94/2~98/	Engine CRANK SHAFT REAR
03901 2953	90311-42035	42 x 60 x 7	CURREN 3SFE,4SFE ST20#	96/9~98/	Engine CRANK SHAFT FRONT
03901 3613	90913-02062		CURREN 3SFE,4SFE(EX.)	94/2~98/	Engine VALVE STEM SEAL
03901 5961	90913-02104		CURREN 3SGE(EX.)	94/2~98/	Engine VALVE STEM SEAL
03901 5449	04422-20010	Kit	CURREN ST20#...WITHOUT ABS	94/2~96/6	Wheel Hub FRONT
03901 6605	04445-20230		CURREN ST207	94/2~98/	Steering (P/S) R & P GASKET KIT
03901 7469	90311-42026	42 x 60 x 7	CURREN 3SGE ST206	96/9~98/	Engine CRANK SHAFT FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5779	04445-20103		CURREN ST207	94/2~96/2	Steering (P/S) R & P GASKET KIT
03901 3157	04445-20180		CURREN ST206,208	94/2~98/	Steering (P/S) R & P GASKET KIT
03901 4581	90311-38020	38 x 55 x 8.5	CURREN ST20#	94/2~98/	Mission & Differential (A/T) FRONT OIL PUMP
03901 5955	90311-35033	35 x 55 x 9 x 15.5	CURREN ST20#	94/2~98/	Mission & Differential (A/T) DIFF. SIDE
03901 7539	90311-35033	35 x 55 x 9 x 15.5	CURREN ST20#	94/2~98/	Mission & Differential (A/T) TRANSAXLE CASE
03901 6253	90311-50010	50 x 80 x 16.5 x 23	CURREN ST206 ZS	94/2~95/9	Mission & Differential (M/T) TRANSMISSION CASE
03901 6859	90311-40004	40 x 56 x 9 x 15.5	CURREN ST206 ZS	94/2~95/9	Mission & Differential (M/T) TRANSAXLE CASECOVER
03901 5429	90311-35033	35 x 55 x 9 x 15.5	CURREN ST20#	94/2~98/	Mission & Differential (M/T) DIFF. SIDE
03901 7567	90311-35033	35 x 55 x 9 x 15.5	CURREN ST20#	94/2~98/	Mission & Differential (M/T) TRANSAXLE CASE
03901 7905	90311-30006	30 x 42 x 7	CURREN ST20#	94/2~98/	Mission & Differential (M/T) INPUT SHAFT
03901 7427	04422-12121	Kit	CURREN ST206 ZS ABS & SUPER STRUT SUS	94/2~98/	Wheel Hub FRONT
03901 1559	04422-20080	Kit	CURREN ST20#...WITH ABS	94/2~98/	Wheel Hub FRONT
03901 5105	90913-02079		CURREN 3S#,4SFE(IN.)	94/2~98/	Engine VALVE STEM SEAL
03901 2635	04422-12111	Kit	CURREN ST206 ZS SUPER STRUT SUS.	94/2~96/6	Wheel Hub FRONT
03901 1185	90311-56016	56 x 73 x 7.5 x 15	CYNOS EL44,52,54 WITHOUT ABS	91/1~96/	Wheel Hub FRONT INNER
03901 2063	04445-10030		CYNOS EL44 ALPHA	91/1~95/	Steering (P/S) R & P GASKET KIT
03901 7679	90311-75009	75 x 100 x 8.5	CYNOS 4E EL52	95/8~99/	Engine CRANK SHAFT REAR
03901 6955	90311-80012	80 x 100 x 8.5	CYNOS ,5E EL44,54	91/8~99/	Engine CRANK SHAFT REAR
03901 4539	90311-35040	35 x 49 x 6	CYNOS 4E,5E EL44,52,54	96/4~99/	Engine CRANK SHAFT FRONT
03901 7829	90311-54003	54 x 66 x 7.5 x 10	CYNOS EL44,52,54	91/1~99/	Wheel Hub FRONT OUTER
03901 5113	90029-21020	20 x 32 x 5	CYNOS 4E,5E EL44,52,54	91/1~99/	Engine OIL PUMP
03901 8033	90311-35013	35 x 49 x 6	CYNOS 4E,5E EL44,52,54	91/1~99/	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3643	90311-26003	26 x 38 x 6.5	CYNOS EL44,52,54	91/1~99/	Steering (P/S) CONTROL VALVE LOWER
03901 6503	90311-19010	19 x 32 x 6	CYNOS EL44,52,54	91/1~99/	Steering (P/S) CONTROL VALVE UPPER
03901 5947	04445-16110		CYNOS EL52,54	95/12~99/	Steering (P/S) R & P GASKET KIT
03901 1603	90913-02062		CYNOS 4E,5E (IN. & EX.)	91/1~99/	Engine VALVE STEM SEAL
03901 6325	04445-10040		CYNOS EL44 BETA	91/1~95/	Steering (P/S) R & P GASKET KIT
03901 2023	90311-80003	80 x 100 x 8.5	CYNOS 5E EL44	91/1~91/8	Engine CRANK SHAFT REAR
03901 1187	90311-38020	38 x 55 x 8.5	CYNOS EL44,52,54	91/1~99/	Mission & Differential (A/T) FRONT PUMP
03901 7925	90311-34012	34 x 54 x 9 x 15.5	CYNOS EL44,52,54	91/1~99/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 6647	90311-34012	34 x 54 x 9 x 15.5	CYNOS EL52	95/8~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 6341	90311-34013	34 x 63 x 9 x 15	CYNOS EL44,54	91/1~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 3973	90311-50015	50 x 68 x 9 x 14.5	CYNOS EL44,52,54 WITH LSD	91/1~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 2633	90311-34016	34 x 54 x 9 x 15.5	CYNOS EL44,52,54	91/1~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 6837	90311-34017	34 x 63 x 9 x 16	CYNOS EL44,52,54	91/1~99/	Mission & Differential (M/T) TRANSMISSION CASE
03901 5415	90311-25011	25 x 37 x 8	CYNOS EL44,52,54	91/1~99/	Mission & Differential (M/T) INPUT SHAFT
03901 1903	90311-38037	38 x 52 x 7	CYNOS EL44,52,54	91/1~99/	Wheel Hub REAR
03901 1405	90311-56017	56 x 73 x 88.5 x 21.5	CYNOS EL44,52,54 WITH ABS	91/1~99/	Wheel Hub FRONT INNER
03901 1493	04445-16090		CYNOS EL52,54	95/8~95/12	Steering (P/S) R & P GASKET KIT
03901 6875	90311-35013	35 x 49 x 6	CYNOS 4E,5E EL44,52,54	91/1~96/4	Engine CRANK SHAFT FRONT
03901 6989	90048-12021-000		DUET EJ#,K3VE M100,101,110,111	98/9~	Engine VALVE STEM SEAL
03901 2225	90043-11316-000	45 x 70 x 12 x 18.5	DUET M10#,11#	98/9~	Mission & Differential (A/T) TRANSAXLE CASE (LH)

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5593	90043-11317-000	45 x 62 x 11 x 18	DUET M10#	98/9~	Mission & Differential (A/T) TRANSAXLE CASE (RH)
03901 4449	90043-11337-000	38 x 52 x 6.2	DUET EJ#...M100,110	98/9~	Engine CAM SHAFT
03901 6549	90043-11284-000	32 x 46 x 6	DUET EJ#...M100,110	98/9~	Engine CRANK SHAFT FRONT
03901 6911	90311-35040	35 x 49 x 6	DUET K3VE M101,111	00/5~	Engine TIMING GEAR COVER
03901 8109	90043-11283-000	58 x 74 x 10	DUET EJ#...M100,110	98/9~00/6	Engine CRANK SHAFT REAR
03901 1795	90043-11292-000	73.5 x 89 x 8.5	DUET K3VE M101,111	00/5~	Engine CRANK SHAFT REAR
03901 7731	90043-11317-000	45 x 62 x 11 x 18	DUET M10#	98/9~	Mission & Differential (M/T) TRANSAXLE CASE
03901 4543	90043-11312-000	35 x 54 x 10.5	DUET M11# (4WD)	98/9~	Wheel Hub REAR
03901 3419	90043-10035-000	25 x 35 x 6	DUET M10#,11#	98/9~	Mission & Differential (M/T) INPUT SHAFT
03901 1265	90043-11316-000	45 x 70 x 12 x 18.5	DUET M10#,11#	98/9~	Mission & Differential (M/T) TRANSMISSION CASE
03901 5805	90043-11323-000	58 x 74 x 10	DUET EJ#...M100,110	00/6~	Engine CRANK SHAFT REAR
03901 3317	9828-79102	79 x 114 x 17	DYNA 350 J05C FB4J#	95/5~99/	Engine TIMING GEAR COVER
03901 6147	S1371-91470		DYNA 351 F05C	98/2~99/	Engine VALVE STEM SEAL
03901 7251	S1371-91360		DYNA 352 F05C	95/5~98/1	Engine VALVE STEM SEAL
03901 3521	90913-02096		DYNA 353 15B	99/3~99/5	Engine VALVE STEM SEAL
03901 2491	90913-02108		DYNA 354 15B	95/5~99/3	Engine VALVE STEM SEAL
03901 4265	90311-95008	95 x 115 x 9.5 x 12	DYNA 355 15B FB5#,FB4JEAT(DF3,EF3,UF3,VF3,XB,XB3)	95/5~99/	Engine CRANK SHAFT REAR
03901 1765	90311-50013	50 x 72 x 9 x 14	DYNA 356 15B FB5#,FB4JEAT(DF3,EF3,UF3,VF3,XB,XB3)	95/5~99/	Engine TIMING GEAR COVER
03901 2043	9828-58113	58 x 102 x 7.8 x 21.8	DYNA 357 FB4J#,FB5B#	98/8~99/	Final Drive REAR DIFF. PINION
03901 3219	9828-58109	58 x 102 x 8 x 22	DYNA 358 FB4J#,FB5B#	95/5~98/7	Final Drive REAR DIFF. PINION
03901 5141	90311-48011	48 x 62 x 9	DYNA 359 FB4J#,FB5BC#,FB5BEAT#,FB5BGAT#	95/5~99/	Transmission REAR OUTPUT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3371	90311-35023	35 x 48 x 6.5	DYNA 360 FB4J#,FB5BC#,FB5BEAT#, FB5BGAT#	95/5~99/	Transmission FRONT COVER
03901 5623	9828-57103	57 x 124 x 13	DYNA 361 FB4JC#,FB4JEAT(AB,AB3, AC4,AE4,BB,BB3,DF3,EF3, FB3,	95/5~99/	Wheel Hub REAR OUTER
03901 1533	9828-48112	48 x 109 x 13	DYNA 362 FB4JEAT,GAT(AA,AA3,BA ,BA3,RA,RA3,SA,SA3),FB5 BC#,	95/5~99/	Wheel Hub REAR OUTER
03901 3671	9828-01203	127 x 147 x 11	DYNA 363 FB4JC#,FB4JEAT(AB,AB3, AC4,AE4,BB,BB3,DF3,EF3, FB3,	95/5~99/	Wheel Hub REAR INNER
03901 1119	9828-01137	101 x 114 x 10	DYNA 364 FB4JEAT(DF3,EF3,UF3,VF3 ,FB4JGAK#	95/5~99/	Wheel Hub FRONT
03901 8221	9828-85106	84 x 100 x 10	DYNA 365 FB5B#	95/5~99/	Wheel Hub FRONT
03901 3275	9828-85106	84 x 100 x 10	DYNA 366 FB4J#...EXC. FB4JEAT(DF3,EF3,UF3,VF3 ,FB4JGAK	95/5~99/	Wheel Hub FRONT
03901 7863	9828-01206	107 x 123 x 11	DYNA 367 FB4JEAT,GAT(AA,AA3,BA ,BA3,RA,RA3,SA,SA3),FB5 BC#,	95/5~99/	Wheel Hub REAR INNER
03901 5521	9828-01228	100 x 135 x 15	DYNA 368 J05C FB4J#	95/5~99/	Engine CRANK SHAFT REAR
03901 7125	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU6#,7#,8#...EXCEPT DM1,DM4,275T,3T,TD,DTP	84/9~87/8	Wheel Hub REAR OUTER
03901 7151	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU100,105,107,112,12#,13#, 14#...(TR,V) (175T,20T)	95/5~99/	Wheel Hub REAR OUTER
03901 2385	90310-38033	38 x 44 x 18	DYNA, TOYO ACE WU85 T3 20T(10.5INCH DIFF)	89/10~95/	Wheel Hub REAR OUTER
03901 4175	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU88 (T2,T3,T4,DM2,DM5) (20T,175T)	88/8~95/	Wheel Hub REAR OUTER
03901 1073	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU87 VAN,20T	88/8~95/	Wheel Hub REAR OUTER
03901 8093	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU67 TRUCK, BU72 FULL JUST LOW	88/8~95/	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3547	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU66 EXCEPT D/CAB, STANDARD DMP	88/8~95/	Wheel Hub REAR OUTER
03901 7553	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU60,61,70,80,81,83,84	87/8~95/	Wheel Hub REAR OUTER
03901 7411	90311-19001	19 x 32 x 8	DYNA, TOYO ACE BU6#,7#,8#	84/9~95/	Steering (M/S) WORM GEAR
03901 3165	90310-38033	38 x 44 x 18	DYNA, TOYO ACE YU6#,70,80	84/9~95/	Wheel Hub REAR OUTER
03901 6823	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU2 0,HU30	77/8~84/	Wheel Hub REAR OUTER
03901 2861	9828-01203	127 x 147 x 11	DYNA, TOYO ACE BU410,420,430,XZU400,401 ,41#,42#,430 295T~40T	99/5~	Wheel Hub REAR INNER
03901 6017	9828-01203	127 x 147 x 11	DYNA, TOYO ACE XZU330,340,350 35T,40T	99/6~	Wheel Hub REAR INNER
03901 4709	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU62,82,85,93 20T DSL,BU64 T3	87/8~88/8	Wheel Hub REAR OUTER
03901 1013	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU202,212,222,RZU140 (TR,V) (175T,20T)	95/5~99/	Wheel Hub REAR OUTER
03901 6713	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU172,182 T4	95/5~	Wheel Hub REAR OUTER
03901 3775	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU30#,346,RZU300,340,XZ U302,307,322,337,351,352	99/5~	Wheel Hub REAR OUTER
03901 2343	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU100,102,112,162,XZU130 DM3,DM6,DM7,DM8,TW1	95/5~99/	Wheel Hub REAR OUTER
03901 3711	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU68,73,74,78,85,94,WU85, 93	88/8~95/	Wheel Hub REAR OUTER
03901 4743	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU67 DMP,BU72 DM3,DM4,T3	88/8~95/	Wheel Hub REAR OUTER
03901 7023	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU66 D/CAB, STANDARD DMP	88/8~95/	Wheel Hub REAR OUTER
03901 1055	90311-88102	88 x 115 x 13	DYNA, TOYO ACE BU90,91,95,96,WU75,90,95	84/9~95/	Wheel Hub REAR INNER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2017	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU66,87 275T,3T	88/8~95/	Wheel Hub REAR OUTER
03901 5909	90311-75008	75 x 95 x 9.5 x 14	DYNA, TOYO ACE XZU362,37#,382 (4WD)	99/5~	Wheel Hub FRONT
03901 5283	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU62,82,85,93,98 275T,3T,BU64 DMP	87/8~88/8	Wheel Hub REAR OUTER
03901 4459	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU62,64,82,85 DM1,DM4,275T,3T,TD,DTP	84/9~87/8	Wheel Hub REAR OUTER
03901 8057	90310-38033	38 x 44 x 18	DYNA, TOYO ACE XZU402,411 T2,XZU412 SCB (T2,T5)	99/5~	Wheel Hub REAR OUTER
03901 2691	90310-38033	38 x 44 x 18	DYNA, TOYO ACE XZU306 T4,XZU347 T2	99/5~	Wheel Hub REAR OUTER
03901 2495	90310-38033	38 x 44 x 18	DYNA, TOYO ACE BU102,162,RZU100 (DM1,DM5,T2,T3,TW1,TW4) 20T	95/5~99/	Wheel Hub REAR OUTER
03901 5087	9828-01137	101 x 114 x 10	DYNA, TOYO ACE BU90,91,95,96,WU75,90,95	84/9~95/	Wheel Hub FRONT
03901 7725	04445-36110		DYNA, TOYO ACE BU102 T4 30T	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 4955	04445-36110		DYNA, TOYO ACE BU142 T3 20T	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 4465	04445-36110		DYNA, TOYO ACE RZU100 DM6	95/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 7463	04445-36110		DYNA, TOYO ACE BU60 T3 WT,BU87 TW1,T3	94/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 3993	04445-36110		DYNA, TOYO ACE BU66 (DM1,DM2,DM3,TW1,T3) WT	94/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 1289	04445-36110		DYNA, TOYO ACE BU68,78,88,9#	94/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 7871	90311-68001	68 x 90 x 10	DYNA, TOYO ACE BU6#,70,78,8#,93,94,98,YU6 #,70,80,WU85,93	84/9~95/	Wheel Hub FRONT
03901 4015	90311-68001	68 x 90 x 10	DYNA, TOYO ACE BU10#,112,12#,13#,14#,202, 212,222,XZU130,140	95/5~99/	Wheel Hub FRONT
03901 4433	90311-68001	68 x 90 x 10	DYNA, TOYO ACE RZU100,140	95/5~	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1059	90311-68002	68 x 92 x 9.7	DYNA, TOYO ACE BU30#,346,RZU300,340,XZ U30#,31#,32#,33#,34#,35#	99/5~03/3	Wheel Hub FRONT
03901 2813	90311-68002	68 x 92 x 9.7	DYNA, TOYO ACE BU400,410,420,XZU402,411 ,412,421 20T	99/5~	Wheel Hub FRONT
03901 7931	90311-68002	68 x 92 x 9.7	DYNA, TOYO ACE BU301,RZU300,340,XZU30 0,301,302,31#,32#,330,331	03/3~	Wheel Hub FRONT
03901 1081	42404-36010	75 x 108 x 20	DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU2 0,HU30	77/8~84/	Wheel Hub REAR INNER
03901 4629	9828-01137	101 x 114 x 10	DYNA, TOYO ACE BU40,41,5#,HU26,40,50,WU 26,40,50	82/4~84/	Wheel Hub FRONT
03901 4149	90311-88102	88 x 115 x 13	DYNA, TOYO ACE BU40,41,5#,HU26,40,50,WU 26,40,50	82/4~84/	Wheel Hub REAR INNER
03901 2585	9828-01137	101 x 114 x 10	DYNA, TOYO ACE BU410,420,430,XZU400,401 ,41#,42#,430 195T~40T	95/5~	Wheel Hub FRONT
03901 5645	90311-75008	75 x 95 x 9.5 x 14	DYNA, TOYO ACE BU72,73,74 (4WD)	89/10~95/	Wheel Hub FRONT
03901 1529	90311-75008	75 x 95 x 9.5 x 14	DYNA, TOYO ACE BU162,172,182 (4WD)	95/5~99/	Wheel Hub FRONT
03901 8165	90311-45001	45 x 62 x 9	DYNA, TOYO ACE BU6#,7#,8#,9#	84/9~85/8	Transmission REAR EXTENTION
03901 4161	90311-37001	37 x 58 x 11	DYNA, TOYO ACE BU72,73,74,162,172,182,XZ U362,37#,382	89/10~	Wheel Hub FRONT AXLE HOUSING
03901 3493	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU102,132,142,212,RZU100, XZU140 275T,30T	95/5~	Wheel Hub REAR OUTER
03901 1571	90311-75003	75 x 108 x 10 x 20	DYNA, TOYO ACE BU6#,7#,8#,93,94,98,YU6#,7 0,80,WU85,93	84/9~95/	Wheel Hub REAR INNER
03901 2721	90311-75003	75 x 108 x 10 x 20	DYNA, TOYO ACE BU10#,112,12#,13#,14#,162, 172,182,202,212,222	95/5~99/	Wheel Hub REAR INNER
03901 3141	90311-75003	75 x 108 x 10 x 20	DYNA, TOYO ACE XZU130,140	95/5~99/	Wheel Hub REAR INNER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4775	90311-75003	75 x 108 x 10 x 20	DYNA, TOYO ACE RZU100,140	95/5~	Wheel Hub REAR INNER
03901 1069	90311-78001	78 x 115 x 10 x 19	DYNA, TOYO ACE BU30#,346,RZU300,340	99/5~	Wheel Hub REAR INNER
03901 3817	90311-78001	78 x 115 x 10 x 19	DYNA, TOYO ACE XZU30#,31#,32#,33#,34#,35 #,362,37#,382 175T~30T	95/5~	Wheel Hub REAR INNER
03901 5011	90311-78001	78 x 115 x 10 x 19	DYNA, TOYO ACE BU400,410,420,XZU402,411 ,412,421 20T	95/5~	Wheel Hub REAR INNER
03901 6695	90311-68003	68 x 92 x 10 x 13.5	DYNA, TOYO ACE BU306,346,XZU306,307,337 ,346,347	03/3~	Wheel Hub FRONT
03901 6145	90311-28004	28.6 x 43 x 6.5	DYNA, TOYO ACE BU62,85,9#...TD,IV4	84/9~85/8	Transmission FRONT COVER
03901 6025	04445-36110		DYNA, TOYO ACE BU212,222,XZU140	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 7939	90311-35023	35 x 48 x 6.5	DYNA, TOYO ACE BU132,XZU130,140 (DM2,T3,TL4) 5F	99/5~99/	Transmission FRONT COVER
03901 3495	90311-35023	35 x 48 x 6.5	DYNA, TOYO ACE BU102,212,222 20T (LPG,TD) 5F	99/5~99/	Transmission FRONT COVER
03901 5117	90311-35023	35 x 48 x 6.5	DYNA, TOYO ACE BU102,112,142 275T,30T	99/5~99/	Transmission FRONT COVER
03901 2903	90310-40001	40 x 46 x 18	DYNA, TOYO ACE XZU301,341,342,346,347,36 2,372,382 DM3,DM5,DM6,DM7	99/5~	Wheel Hub REAR OUTER
03901 1281	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU301,346,XZU306,31#,320 ,321,330,371 (DM5,DM6,DM7,	99/5~	Wheel Hub REAR OUTER
03901 6283	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU400,410,420,XZU402,411 ,412,421 (T4,T5) 20T	99/5~	Wheel Hub REAR OUTER
03901 6477	90310-40001	40 x 46 x 18	DYNA, TOYO ACE XZU382	99/5~	Wheel Hub REAR OUTER
03901 8257	90310-41001	41 x 47 x 17	DYNA, TOYO ACE BU40,41,5#,HU26,40,50,WU 26,40,50	82/4~84/ 26,40,50	Wheel Hub REAR OUTER
03901 5149	90310-41001	41 x 47 x 17	DYNA, TOYO ACE BU90,91,95,96,WU75,90,95	84/9~95/	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6397	9828-57103	57 x 124 x 13	DYNA, TOYO ACE XZU330,340,350 35T,40T	99/6~	Wheel Hub REAR OUTER
03901 4203	9828-57103	57 x 124 x 13	DYNA, TOYO ACE BU410,420,430,XZU400,401 ,41#,42#,430 295T~40T	99/5~	Wheel Hub REAR OUTER
03901 5247	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU6#,70,8#,9#...(CBU,IV3)	85/9~88/8	Transmission REAR EXTENTION
03901 5441	90311-28004	28.6 x 43 x 6.5	DYNA, TOYO ACE RU2#,HU26,30,40,50,WU26, 40,50 H50	77/8~84/	Transmission FRONT COVER
03901 1327	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU6#...EXC. BU66 TW1	88/8~95/	Transmission REAR EXTENTION
03901 2021	90311-28004	28.6 x 43 x 6.5	DYNA, TOYO ACE BU62 IV4	85/8~87/8	Transmission FRONT COVER
03901 6623	90311-28004	28.6 x 43 x 6.5	DYNA, TOYO ACE BU62,66 TW1	87/8~95/	Transmission FRONT COVER
03901 1709	90311-28004	28.6 x 43 x 6.5	DYNA, TOYO ACE WU75,90,95	84/9~95/	Transmission FRONT COVER
03901 5477	90311-32106	32 x 48 x 8	DYNA, TOYO ACE BU20,22,30,33,35,RU2#,3#,J U20 M50,M51	77/8~84/	Transmission FRONT COVER
03901 3125	90311-32106	32 x 48 x 8	DYNA, TOYO ACE YU60,70,80	84/9~85/8	Transmission FRONT COVER
03901 3139	90311-32106	32 x 48 x 8	DYNA, TOYO ACE BU6#,70,8#...DSL (CBU,IV3)	84/9~85/8	Transmission FRONT COVER
03901 1631	90311-32012	32 x 53 x 7	DYNA, TOYO ACE YU6#,70,80	85/8~95/	Transmission FRONT COVER
03901 2777	90311-32012	32 x 53 x 7	DYNA, TOYO ACE BU6#,70,8#,9#...(CBU,IV3)	85/8~88/8	Transmission FRONT COVER
03901 7043	90311-32012	32 x 53 x 7	DYNA, TOYO ACE BU6#...EXC. BU66 TW1	88/8~95/	Transmission FRONT COVER
03901 6829	90311-32012	32 x 53 x 7	DYNA, TOYO ACE BU7#,8#,9#	88/8~95/	Transmission FRONT COVER
03901 3757	90311-32012	32 x 53 x 7	DYNA, TOYO ACE WU85,93	88/8~95/	Transmission FRONT COVER
03901 7521	90311-32012	32 x 53 x 7	DYNA, TOYO ACE BU10#,112,12#,13#,14#,162, 202,212,222,RZU140 (175T	95/5~	Transmission FRONT COVER
03901 5109	90311-32012	32 x 53 x 7	DYNA, TOYO ACE BU172,182,RZU100	95/5~	Transmission FRONT COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2643	90311-28004	28.6 x 43 x 6.5	DYNA, TOYO ACE BU2#,30,31,32,34,35,36,37 H50,H51	77/8~84/	Transmission FRONT COVER
03901 3645	90311-35023	35 x 48 x 6.5	DYNA, TOYO ACE XZU30#,31#,32#,33#,34#,35 #,362,37#,382	99/5~	Transmission FRONT COVER
03901 4353	90310-40001	40 x 46 x 18	DYNA, TOYO ACE RZU100 DM6	95/5~	Wheel Hub REAR OUTER
03901 5721	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU12,222 TD	95/5~99/	Wheel Hub REAR OUTER
03901 1179	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU212 (T3,T4,TW1,TW4) DSL ABS	95/5~99/	Wheel Hub REAR OUTER
03901 4133	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU172,182 T3,TW1	95/5~99/	Wheel Hub REAR OUTER
03901 5577	90310-40001	40 x 46 x 18	DYNA, TOYO ACE RZU300,XZU300,331,340 30T	99/5~	Wheel Hub REAR OUTER
03901 4163	90310-40001	40 x 46 x 18	DYNA, TOYO ACE XZU302 (T4,T5) (295T,30T)	99/5~	Wheel Hub REAR OUTER
03901 2769	90310-40001	40 x 46 x 18	DYNA, TOYO ACE XZU302,322 DM3,DM6,DM7,DM8,T3	99/5~	Wheel Hub REAR OUTER
03901 7247	90311-45001	45 x 62 x 9	DYNA, TOYO ACE BU62,66 TW1	87/8~95/	Transmission REAR EXTENTION
03901 3185	90311-45001	45 x 62 x 9	DYNA, TOYO ACE BU62 IV4	85/8~87/8	Transmission REAR EXTENTION
03901 5935	90311-32012	32 x 53 x 7	DYNA, TOYO ACE BU30#,346,RZU300,340	99/5~	Transmission FRONT COVER
03901 1339	90311-45001	45 x 62 x 9	DYNA, TOYO ACE YU60,70,80	84/9~85/8	Transmission REAR EXTENTION
03901 3389	90311-45001	45 x 62 x 9	DYNA, TOYO ACE HU26,30,40,50,WU26,40,50	77/8~84/	Transmission REAR EXTENTION
03901 7149	90311-48011	48 x 62 x 9	DYNA, TOYO ACE YU6#,70,80	85/8~95/	Transmission REAR EXTENTION
03901 4091	90311-35023	35 x 48 x 6.5	DYNA, TOYO ACE BU400,410,420,430,XZU382 ,40#,41#,42#,430	99/5~	Transmission FRONT COVER
03901 6905	90310-40001	40 x 46 x 18	DYNA, TOYO ACE BU142,147 T3 20T ABS	95/5~99/	Wheel Hub REAR OUTER
03901 1009	90311-45001	45 x 62 x 9	DYNA, TOYO ACE WU75,90,95	84/9~95/	Transmission REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5181	90311-48018	48 x 62 x 9	DYNA, TOYO ACE BU162,172,182,XZU362,37# ,382	96/5~	Transfer CASE
03901 2475	90311-48003	48 x 62 x 8	DYNA, TOYO ACE BU162,172,182	95/5~96/5	Transfer CASE
03901 3981	90311-48003	48 x 62 x 8	DYNA, TOYO ACE XZU362,37#,382 (4WD)	99/7~	Transmission REAR EXTENTION
03901 7559	90311-48003	48 x 62 x 8	DYNA, TOYO ACE BU162,172,182 (4WD)	95/5~99/	Transmission REAR EXTENTION
03901 5793	90311-48003	48 x 62 x 8	DYNA, TOYO ACE BU72,73,74	89/10~95/	Transmission REAR EXTENTION
03901 8207	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU400,410,420,430,XZU40# ,41#,42#,430	99/5~	Transmission REAR EXTENTION
03901 4313	90311-48011	48 x 62 x 9	DYNA, TOYO ACE XZU30#,31#,32#,33#,34#,35 #	99/5~	Transmission REAR EXTENTION
03901 4093	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU30#,346,RZU300,400	99/5~	Transmission REAR EXTENTION
03901 6051	90311-48011	48 x 62 x 9	DYNA, TOYO ACE RZU100,140,XZU130,140	95/5~	Transmission REAR EXTENTION
03901 4087	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU10#,112,12#,14#,202,212, 222 5F	95/5~99/	Transmission REAR EXTENTION
03901 1601	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU70,8#,9#	88/8~95/	Transmission REAR EXTENTION
03901 4231	90311-35023	35 x 48 x 6.5	DYNA, TOYO ACE BU212,222 6F	99/5~99/	Transmission FRONT COVER
03901 1745	90311-45001	45 x 62 x 9	DYNA, TOYO ACE BU2#,3#,4#,RU2#,3#,JU20	77/8~84/	Transmission REAR EXTENTION
03901 6405	90913-02028		DYNA, TOYO ACE 2J,H(IN.) JU20,HU30	77/8~78/1 2	Engine VALVE STEM SEAL
03901 5063	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU72 DM3,DM4,T3,BU87,88 275T,3T	88/8~89/8	Final Drive REAR DIFF. PINION
03901 5363	90033-11033	64 x 114 x 9 x 24.8	DYNA, TOYO ACE XZU400,410,420,430 40T	99/5~	Final Drive REAR DIFF. PINION
03901 6909	90311-18010	18 x 30 x 8	DYNA, TOYO ACE BU20,30,RU20,30,JU20 ST,T2,TW2	77/8~82/4	Steering (M/S) WORM GEAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3667	90311-22103	22 x 36 x 8	DYNA, TOYO ACE BU20,25,30,RU20,30,HU30 EXCEPT ST,T2	77/8~79/4	Steering (M/S) WORM GEAR
03901 4027	90311-22103	22 x 36 x 8	DYNA, TOYO ACE BU20 BTP,CTP,DTP,RU20 BTP	79/4~82/4	Steering (M/S) WORM GEAR
03901 3391	90311-22103	22 x 36 x 8	DYNA, TOYO ACE BU2#,3#,RU2#,3#,JU20 EXCEPT ST,T2	79/4~82/4	Steering (M/S) WORM GEAR
03901 2985	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE XZU410,420 4FC	99/5~	Final Drive REAR DIFF. PINION
03901 4513	90913-02096		DYNA, TOYO ACE 15BFTE BU400,410,420,430	99/8~	Engine VALVE STEM SEAL
03901 4953	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE BU420,430 T4,T5	99/5~	Final Drive REAR DIFF. PINION
03901 1197	90913-02044		DYNA, TOYO ACE 2J,H(EX.) JU20,HU30	77/8~78/1 2	Engine VALVE STEM SEAL
03901 6917	90913-02044		DYNA, TOYO ACE 2H(IN. & EX.) HU26,40,50	78/12~83/	Engine VALVE STEM SEAL
03901 1663	90913-02016		DYNA, TOYO ACE 1W WU75,85,9#	83/4~95/	Engine VALVE STEM SEAL
03901 2423	90038-12003		DYNA, TOYO ACE JO5C XZU130,140	95/10~98/ 2	Engine VALVE STEM SEAL
03901 8225	90038-12004		DYNA, TOYO ACE JO5C XZU130,140	98/2~99/	Engine VALVE STEM SEAL
03901 2485	90038-12004		DYNA, TOYO ACE JO5C,S05#,.XZU30#,31#,32 #,33#,341,342,346,347,35#	99/5~	Engine VALVE STEM SEAL
03901 5379	90311-68001	68 x 90 x 10	DYNA, TOYO ACE BU2#,3#,45,46,RU2#,3#,JU2 0,HU30	77/8~84/	Wheel Hub FRONT
03901 6417	90311-22103	22 x 36 x 8	DYNA, TOYO ACE BU36,37,45,46	82/4~84/	Steering (M/S) WORM GEAR
03901 6725	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU212 T3,T4,TW1,TW4,BU222 TD	95/5~99/	Final Drive REAR DIFF. PINION
03901 6367	90311-19001	19 x 32 x 8	DYNA, TOYO ACE BU2#,30,32,33,34,RU22,32	82/4~84/	Steering (M/S) WORM GEAR
03901 5027	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU88 T4,BU88 20T TD	89/8~95/	Final Drive REAR DIFF. PINION
03901 7911	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU66,87,88 275T	89/8~95/	Final Drive REAR DIFF. PINION
03901 4817	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU66,87,88 T3 30T	89/8~95/	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8147	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU102,132,142,212,RZU100, XZU140 275T,30T	95/5~	Final Drive REAR DIFF. PINION
03901 4551	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU100,102,112,162,XZU130 DM3,DM6,DM7,DM8,TW1	95/5~99/	Final Drive REAR DIFF. PINION
03901 7181	90033-11033	64 x 114 x 9 x 24.8	DYNA, TOYO ACE BU420,430 T3	99/5~	Final Drive REAR DIFF. PINION
03901 4205	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU172,182 T3,TW1	95/5~99/	Final Drive REAR DIFF. PINION
03901 4759	90311-19001	19 x 32 x 8	DYNA, TOYO ACE YU6#,70,80	84/9~95/	Steering (M/S) WORM GEAR
03901 8011	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE RZU300,XZU300,331,340 30T,35T,40T	99/5~	Final Drive REAR DIFF. PINION
03901 2231	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE XZU301,341,342,346,347,36 2,372,382 DM3,DM5,DM6,DM7	99/5~	Final Drive REAR DIFF. PINION
03901 5331	04445-36110		DYNA, TOYO ACE BU87 V	94/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 2395	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE BU301,346,XZU306,31#,320 ,321,330,350,371 (DM5,DM6,	99/5~	Final Drive REAR DIFF. PINION
03901 7919	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE XZU302 (T4,T5) (295T,30T)	99/5~	Final Drive REAR DIFF. PINION
03901 5803	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE XZU302,322 DM3,DM6,DM7,DM8,T3	99/5~	Final Drive REAR DIFF. PINION
03901 2883	90311-58010	58 x 102 x 11 x 19.5	DYNA, TOYO ACE BU400,410,XZU382,40#,41# ,42#,430 (T3,T4,T5) (20T,	99/5~	Final Drive REAR DIFF. PINION
03901 3007	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU142,147 T3 20T	95/5~99/	Final Drive REAR DIFF. PINION
03901 5939	04445-36070		DYNA, TOYO ACE BU67 DMP	88/8~94/2	Steering (P/S) P/S GEAR GASKET KIT
03901 5041	04445-36060		DYNA, TOYO ACE BU60,66 T2,T4,TW4,BU66 ST	90/1~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 2901	04445-36060		DYNA, TOYO ACE BU60,T3 ST	90/1~95/	Steering (P/S) P/S GEAR GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2845	04445-36060		DYNA, TOYO ACE YU60 TW1,TW2,T2,T3	93/5~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 6843	04445-36060		DYNA, TOYO ACE YU60 DYN T1 CBU	93/5~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 6281	04445-36060		DYNA, TOYO ACE BU100,102 T3 ST	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 2233	04445-36060		DYNA, TOYO ACE BU112,12#,132,RZU140 (TR,V) 20T	95/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 5825	90311-22103	22 x 36 x 8	DYNA, TOYO ACE BU77,85,93,98	84/9~87/	Steering (M/S) WORM GEAR
03901 2355	04445-36060		DYNA, TOYO ACE BU100,102,140,142 (DM5,T1,T2,T4,TW2,TW4) (175T,20T	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 1851	04445-36060		DYNA, TOYO ACE BU87 T2,T4,B67 TR	90/1~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 6053	04445-36070		DYNA, TOYO ACE WU75,85,9#,YU61	88/8~94/2	Steering (P/S) P/S GEAR GASKET KIT
03901 1993	04445-36070		DYNA, TOYO ACE BU87 V	88/8~94/2	Steering (P/S) P/S GEAR GASKET KIT
03901 4065	04445-36070		DYNA, TOYO ACE BU68,78,85,88,9#	88/8~94/2	Steering (P/S) P/S GEAR GASKET KIT
03901 5293	04445-36070		DYNA, TOYO ACE BU66 (DM1,DM2,DM3,TW1,T3) WT	88/8~94/2	Steering (P/S) P/S GEAR GASKET KIT
03901 1983	04445-36070		DYNA, TOYO ACE BU60 T3 WT,BU87 TW1,T3	88/8~94/2	Steering (P/S) P/S GEAR GASKET KIT
03901 6893	04445-36110		DYNA, TOYO ACE BU67 DMP	94/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 6075	04445-36110		DYNA, TOYO ACE WU75,85,9#	94/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 3073	04445-36060		DYNA, TOYO ACE RZU100 (DM5,T2,T3,T4,TW1,TW4) 20T	95/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 7593	90311-38033	38 x 52 x 9	DYNA, TOYO ACE BU85,88 (T2,T3) 5F 20T DSL	87/8~95/	Steering (M/S) SECTOR SHAFT
03901 7923	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU68,73,74,78,85,90,91,94,95,96	88/8~95/	Final Drive REAR DIFF. PINION
03901 7259	90311-18010	18 x 30 x 8	DYNA, TOYO ACE BU85 (T2,T3) 5F 20T DSL	87/8~95/	Steering (M/S) WORM GEAR
03901 5771	90311-32014	32 x 44 x 9	DYNA, TOYO ACE BU20,30,RU20,30,JU20 ST.T2.TW2	77/8~82/4	Steering (M/S) SECTOR SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6187	90311-36104	36 x 50 x 7	DYNA, TOYO ACE BU20,25,30,RU20,30,HU30 EXCEPT ST,T2	77/8~79/4	Steering (M/S) SECTOR SHAFT
03901 5359	90311-36104	36 x 50 x 7	DYNA, TOYO ACE BU20 BTP,CTP,DTP,RU20 BTP	79/4~82/4	Steering (M/S) SECTOR SHAFT
03901 5339	90311-36104	36 x 50 x 7	DYNA, TOYO ACE BU2#,3#,RU2#,3#,JU20 EXCEPT ST,T2	79/4~82/4	Steering (M/S) SECTOR SHAFT
03901 6211	90311-36104	36 x 50 x 7	DYNA, TOYO ACE BU2#,3#,45,46,RU22,32	82/4~84/	Steering (M/S) SECTOR SHAFT
03901 1629	04445-36060		DYNA, TOYO ACE BU66 DM5,BU60 T1,TW1,TW2	90/1~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 7787	90311-36104	36 x 50 x 7	DYNA, TOYO ACE BU6#,7#,8#	84/9~95/	Steering (M/S) SECTOR SHAFT
03901 4897	04445-36060		DYNA, TOYO ACE BU61,70,83,84	90/1~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 2373	04445-36060		DYNA, TOYO ACE BU61,67,83,84 TR	88/8~90/1	Steering (P/S) P/S GEAR GASKET KIT
03901 7727	04445-36060		DYNA, TOYO ACE YU60,70 T1,T2,T3,TW2,SRF	88/8~90/1	Steering (P/S) P/S GEAR GASKET KIT
03901 7013	04445-36060		DYNA, TOYO ACE BU60,87 T1,T2,T4,TW2,TW4	88/8~90/1	Steering (P/S) P/S GEAR GASKET KIT
03901 1655	04445-36060		DYNA, TOYO ACE BU66 T2,T4,DMS	88/8~90/1	Steering (P/S) P/S GEAR GASKET KIT
03901 3089	04445-36060		DYNA, TOYO ACE BU60,66,70 (T3,SRF) (03S,06S) ST	88/8~90/1	Steering (P/S) P/S GEAR GASKET KIT
03901 3397	04445-36060		DYNA, TOYO ACE YU60,70	90/1~93/5	Steering (P/S) P/S GEAR GASKET KIT
03901 2693	90311-50014	50 x 70 x 10 x 16	DYNA, TOYO ACE BU162,172,182,XZU362,37# ,382	95/5~	Transfer FRONT OUTPUT
03901 7341	90311-36104	36 x 50 x 7	DYNA, TOYO ACE YU6#,70,80	84/9~95/	Steering (M/S) SECTOR SHAFT
03901 4037	90311-95001	95 x 115 x 12	DYNA, TOYO ACE 2J,H,2H JU20,HU26,30,40,50	77/8~83/	Engine CRANK SHAFT REAR
03901 7875	9828-79103	79 x 114 x 17	DYNA, TOYO ACE JO5C XZU130,140	95/10~99/	Engine TIMING GEAR COVER
03901 1121	9828-79103	79 x 114 x 17	DYNA, TOYO ACE JO5C,SO5#...XZU30#,31#,32 #,33#,341,342,346,347,35#	99/5~	Engine TIMING GEAR COVER
03901 8129	90311-48020	48 x 68 x 7	DYNA, TOYO ACE 3RZ RZU100,140	95/5~	Engine TIMING GEAR CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2567	90311-80001	80 x 100 x 12	DYNA, TOYO ACE 5R RU2#,3#	77/8~84/	Engine CRANK SHAFT REAR
03901 6095	90311-80003	80 x 100 x 8.5	DYNA, TOYO ACE 3Y YU6#,70,8#	84/9~90/4	Engine CRANK SHAFT REAR
03901 2785	90311-80009	80 x 100 x 10	DYNA, TOYO ACE 3Y YU6#,70	90/4~95/	Engine CRANK SHAFT REAR
03901 3355	90311-95008	95 x 115 x 9.5 x 12	DYNA, TOYO ACE 15B#...XZU301,302,341	00/5~	Engine CRANK SHAFT REAR
03901 6453	90311-88005	88 x 106 x 8.5	DYNA, TOYO ACE 3RZ RZU300,340	99/5~	Engine CRANK SHAFT REAR
03901 5255	90311-50013	50 x 72 x 9 x 14	DYNA, TOYO ACE 15BFTE BU400,410,420,430	99/5~	Engine TIMING GEAR COVER
03901 4267	90311-95001	95 x 115 x 12	DYNA, TOYO ACE B,2B,3B BU2#,3#,4#,5#	77/8~84/	Engine CRANK SHAFT REAR
03901 2667	90311-95001	95 x 115 x 12	DYNA, TOYO ACE B,3B,11B,13B#,14B#...BU6# ,7#,8#,9#	84/9~90/1	Engine CRANK SHAFT REAR
03901 1677	90311-95008	95 x 115 x 9.5 x 12	DYNA, TOYO ACE B,3B,11B,14B#...BU6#,7#,8# ,9#	90/1~95/	Engine CRANK SHAFT REAR
03901 5541	90311-95008	95 x 115 x 9.5 x 12	DYNA, TOYO ACE 15B,3B BU10#,112,12#,13#,14#,162, 172,182,202,212,	95/5~99/	Engine CRANK SHAFT REAR
03901 2229	90311-95008	95 x 115 x 9.5 x 12	DYNA, TOYO ACE 4B BU30#,346	99/5~	Engine CRANK SHAFT REAR
03901 4053	90311-95008	95 x 115 x 9.5 x 12	DYNA, TOYO ACE 15BFTE BU400,410,420,430	99/5~	Engine CRANK SHAFT REAR
03901 2949	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU67 DMP,BU66 TW1,DM1,275T,3T	88/8~95/	Final Drive REAR DIFF. PINION
03901 1349	90311-88005	88 x 106 x 8.5	DYNA, TOYO ACE 3RZ RZU100,140	95/5~	Engine CRANK SHAFT REAR
03901 7685	90311-42026	42 x 60 x 7	DYNA, TOYO ACE 3Y YU6#,70	87/8~95/	Engine TIMING GEAR COVER
03901 3561	04445-36110		DYNA, TOYO ACE BU112,202,XZU130 DM7,DM8,T4	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 2955	04445-36110		DYNA, TOYO ACE BU100,102,132,140 (DM2,DM3,DM6,T3,T5,TW 1) WT	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2907	04445-36090		DYNA, TOYO ACE BU72,73,74	89/10~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 3081	04445-36090		DYNA, TOYO ACE BU162,172,182	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 2881	04445-37040		DYNA, TOYO ACE BU301,RZU300,340,XZU30 0,301,302,31#,32#,330,331,	99/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 7491	04445-37040		DYNA, TOYO ACE BU400,410,420,430,XZU382 ,40#,41#,42#,430	99/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 6245	04445-37030		DYNA, TOYO ACE BU306,346,XZU306,307,337 ,346,347	99/5~	Steering (P/S) R & P GASKET KIT
03901 3403	9828-58104	58 x 75 x 9 x 14.5	DYNA, TOYO ACE 1W WU75,85,9#	83/4~95/	Engine TIMING GEAR COVER
03901 7749	90311-42003	42 x 60 x 7	DYNA, TOYO ACE 3Y YU6#,70,8#	84/9~87/8	Engine TIMING GEAR COVER
03901 2655	90311-50013	50 x 72 x 9 x 14	DYNA, TOYO ACE 15B#...XZU301,302,341	00/5~	Engine TIMING GEAR COVER
03901 3023	90311-50006	50 x 72 x 12	DYNA, TOYO ACE 2J,H,2H JU20,HU26,30,40,50	77/8~83/	Engine TIMING GEAR COVER
03901 5815	90311-50006	50 x 72 x 12	DYNA, TOYO ACE B,2B,3B BU2#,3#,4#,5#	77/8~84/	Engine TIMING GEAR COVER
03901 1437	90311-50006	50 x 72 x 12	DYNA, TOYO ACE B,11B,13B BU6#,7#,8#,9#	84/9~88/8	Engine TIMING GEAR COVER
03901 6353	90311-50013	50 x 72 x 9 x 14	DYNA, TOYO ACE B,3B,11B,13BT,14B#...BU6# ,7#,8#,9#	88/8~95/	Engine TIMING GEAR COVER
03901 8137	90311-50013	50 x 72 x 9 x 14	DYNA, TOYO ACE 15B,3B BU10#,112,12#,13#,14#,162, 172,182,202,212,	95/5~99/	Engine TIMING GEAR COVER
03901 4075	90311-50013	50 x 72 x 9 x 14	DYNA, TOYO ACE 4B BU30#,346	99/5~	Engine TIMING GEAR COVER
03901 5725	9828-00109	100 x 120 x 13 x 18	DYNA, TOYO ACE 1W WU75,85,9#	83/4~95/	Engine CRANK SHAFT REAR
03901 3955	90311-45002	45 x 68 x 12	DYNA, TOYO ACE 5R RU2#,3#	77/8~84/	Engine TIMING GEAR COVER
03901 1911	90311-48019	48 x 82 x 10.2 x 17.8	DYNA, TOYO ACE BU30#,346,RZU300,340,XZ U302,307,322,337,351,352	99/5~	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1797	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU62,82,85,93 20T DSL,BU64 T3	87/8~88/8	Final Drive REAR DIFF. PINION
03901 4547	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU73 TW1,BU74,84 20T	88/8~95/	Final Drive REAR DIFF. PINION
03901 2935	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU67 TR, BU87 VAN	88/8~95/	Final Drive REAR DIFF. PINION
03901 7569	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU66 (DM2,DM3,DM5,TW4,T2,T 3,T4) (175T,20T)	88/8~95/	Final Drive REAR DIFF. PINION
03901 2081	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU88 (TW1,T2,T3) 20T DSL	88/8~95/	Final Drive REAR DIFF. PINION
03901 4443	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU100,105,107,112,12#,13#, 14#.202,212,222,RZU140..	95/5~	Final Drive REAR DIFF. PINION
03901 5369	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU6#,7#,8#...EXCEPT DM1,DM4,275T,3T,TD,DTP	84/9~87/8	Final Drive REAR DIFF. PINION
03901 5895	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU172,182 T4	95/5~99/	Final Drive REAR DIFF. PINION
03901 8155	90311-48135	48 x 82 x 12	DYNA, TOYO ACE YU6#,70,80	84/9~95/	Final Drive REAR DIFF. PINION
03901 2933	90311-48019	48 x 82 x 10.2 x 17.8	DYNA, TOYO ACE XZU306 T4,XZU347 T2	99/5~	Final Drive REAR DIFF. PINION
03901 4991	90311-48019	48 x 82 x 10.2 x 17.8	DYNA, TOYO ACE XZU402,411 T2,XZU412 SCB (T2,T5)	99/5~	Final Drive REAR DIFF. PINION
03901 4929	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU40,41,5#HU26,40,50,WU 26,40,50	82/4~84/	Final Drive REAR DIFF. PINION
03901 5281	90311-58002	58 x 102 x 12	DYNA, TOYO ACE WU75,85,9#	84/9~95/	Final Drive REAR DIFF. PINION
03901 7449	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU62,64,82,85,9#...DM1,DM 4,275T,3T,TD,DTP	87/8~88/8	Final Drive REAR DIFF. PINION
03901 1065	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU62,82,85,92,98 (275T,3T) DSL	87/8~88/8	Final Drive REAR DIFF. PINION
03901 6515	90311-58002	58 x 102 x 12	DYNA, TOYO ACE BU64 DMP,BU85,90,95 TD	87/8~88/8	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7011	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU102,162,RZU100 (DM2,DM5,T2,T3,T4,TW1,T W4) 20T	95/5~	Final Drive REAR DIFF. PINION
03901 1665	90913-02076		DYNA, TOYO ACE B,3B,11B,13B,14B BU6#,7#,8#,9#	88/8~95/	Engine VALVE STEM SEAL
03901 4287	9828-01228	100 x 135 x 17	DYNA, TOYO ACE JO5C XZU130,140	95/10~	Engine CRANK SHAFT REAR
03901 2237	9828-01228	100 x 135 x 17	DYNA, TOYO ACE JO5C,S05#...XZU30#,31#,32 #,33#,341,342,346,347,35#	99/5~	Engine CRANK SHAFT REAR
03901 2223	90913-02042		DYNA, TOYO ACE 5R RU2#,3#	78/5~84/	Engine VALVE STEM SEAL
03901 5101	90913-02094		DYNA, TOYO ACE 3Y#...YU6#,70,80	84/9~95/	Engine VALVE STEM SEAL
03901 2521	90913-02079		DYNA, TOYO ACE 3RZ(IN.) RZU100,140,300,340	95/5~	Engine VALVE STEM SEAL
03901 3479	90913-02062		DYNA, TOYO ACE 3RZ(EX.) RZU100,140,300,340	95/5~	Engine VALVE STEM SEAL
03901 7007	90913-02028		DYNA, TOYO ACE B,2B BU2#,3#	77/8~80/8	Engine VALVE STEM SEAL
03901 3045	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU60,61,70,80,81,83,84	87/8~95/	Final Drive REAR DIFF. PINION
03901 6891	90913-02051		DYNA, TOYO ACE B,11B,13B BU6#,7#,8#,9#	84/9~88/8	Engine VALVE STEM SEAL
03901 4615	04445-36110		DYNA, TOYO ACE BU142,RZU100 30T	95/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 7189	90913-02076		DYNA, TOYO ACE 3B BU100,105,120,140,145	95/5~99/	Engine VALVE STEM SEAL
03901 6557	90913-02076		DYNA, TOYO ACE 4B BU30#,346	99/5~	Engine VALVE STEM SEAL
03901 3823	90913-02108		DYNA, TOYO ACE 15B BU102,107,112,122,13#,142, 147,162,172,182,202,	95/5~99/	Engine VALVE STEM SEAL
03901 3327	90913-02096		DYNA, TOYO ACE 15B#...XZU301,302,341	99/5~	Engine VALVE STEM SEAL
03901 3365	90311-48011	48 x 62 x 9	DYNA, TOYO ACE BU162,172,182,XZU362,37# ,382	95/5~	Transfer REAR OUTPUT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3785	90311-48135	48 x 82 x 12	DYNA, TOYO ACE BU2#,3#,45,46, RU2#,3#,JU2 0,HU30	77/8~84/	Final Drive REAR DIFF. PINION
03901 7313	90913-02051		DYNA, TOYO ACE B,3B BU2#,3#	80/8~84/	Engine VALVE STEM SEAL
03901 6221	04332-30030	Kit	ESTIMA CXR1#,TCR1# (EFI)	90/5~00/	Transmission (A/T) REAR EXTENTION
03901 5791	90311-38029	38 x 55 x 7.5	ESTIMA TCR1#,2# (SPC)	94/8~00/	Transmission (A/T) FRONT OIL PUMP
03901 6857	04445-28030		ESTIMA CXR1#,2#,TCR1#,2# (EFI)	90/5~00/	Steering (P/S) R & P GASKET KIT
03901 5919	90311-38011	38 x 63 x 10 x 17	ESTIMA CXR11,21,TCR11,21	90/5~00/	Final Drive DIFF. SIDE
03901 6459	90311-38047	38 x 74 x 11 x 18	ESTIMA CXR10,20,TCR10,20	95/12~00/	Final Drive PINION
03901 2745	90311-38133	38 x 74 x 11	ESTIMA CXR10,20,TCR10,20	92/1~95/1 2	Final Drive PINION
03901 3395	90311-38133	38 x 74 x 11	ESTIMA CXR11,21,TCR11,21	90/5~00/	Final Drive PINION
03901 6543	90311-50026	50 x 68 x 9 x 15.5	ESTIMA ACR30	00/2~	Differential DIFF. SIDE
03901 1879	90311-50011	50 x 80 x 16.5 x 23	ESTIMA ACR40,MCR30,40	99/12~	Differential DIFF. SIDE
03901 4213	90311-40026	40 x 64 x 9 x 15.5	ESTIMA ACR30	00/2~	Differential TRANSAXLE HOUSING
03901 6089	90311-55003	55 x 74 x 10	ESTIMA ACR40,MCR40	99/12~	Differential TRANSAXLE HOUSING
03901 5317	04445-28060		ESTIMA TCR1#,2# (SPC)	94/8~00/	Steering (P/S) R & P GASKET KIT
03901 6163	90311-38064	38 x 55 x 8.7	ESTIMA ACR30,40,MCR30,40	99/12~	Transmission (A/T) FRONT OIL PUMP
03901 7991	90311-35002	35 x 40 x 49 x 11	ESTIMA CXR10,20,TCR10,20	92/1~00/	Wheel Hub REAR OUTER
03901 3943	90311-38020	38 x 55 x 8.5	ESTIMA CXR1#,2#,TCR1#,2# (EFI)	90/5~00/	Transmission (A/T) FRONT OIL PUMP
03901 1315	90311-38032	38 x 58 x 11	ESTIMA CXR1#,TCR10	92/1~00/	Transmission (M/T) REAR EXTENTION
03901 3467	90311-30014	30 x 45 x 8	ESTIMA CXR1#,2#,TCR1#,2#	92/1~00/	Transmission (M/T) FRONT COVER
03901 5197	90311-59002	59 x 78 x 7	ESTIMA CXR11,21,TCR11,21	90/5~00/	Wheel Hub REAR OUTER
03901 8223	90913-02111		ESTIMA 2AZFE,1MZFE (EX.)	99/12~	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5997	90311-63001	63 x 90 x 7 x 10	ESTIMA CXR11,21,TCR11,21	90/5~00/	Wheel Hub REAR INNER
03901 6461	90311-40010	40 x 56 x 9 x 15.5	ESTIMA MCR30	99/12~	Differential TRANSAXLE HOUSING
03901 5329	90311-56014	56 x 78 x 7.5 x 13	ESTIMA CXR2#,TCR2# (4WD)	90/5~00/	Wheel Hub FRONT DRIVE SHAFT
03901 1147	90311-61001	61 x 76 x 7 x 10	ESTIMA CXR1#,2#,TCR1#,2#	90/5~00/	Wheel Hub FRONT
03901 7585	90311-40001	40 x 58 x 11	ESTIMA TCR1# (SPC)	94/8~00/	Transmission (A/T) REAR EXTENTION
03901 3857	90913-02094		ESTIMA 3CT#	92/1~95/1 1	Engine VALVE STEM SEAL
03901 4671	90311-52059	52 x 65 x 9	ESTIMA CXR10,20,TCR10,20	92/1~00/	Wheel Hub REAR INNER
03901 3959	04445-28090		ESTIMA ACR30,40,MCR30,40	99/12~	Steering (P/S) R & P GASKET KIT
03901 4557	90913-02101		ESTIMA 2AZFE,1MZFE (IN.)	99/12~	Engine VALVE STEM SEAL
03901 7519	90913-02110		ESTIMA 3CT#	95/11~97/4	Engine VALVE STEM SEAL
03901 7825	90913-02079		ESTIMA 2TZFE (IN.)	92/6~00/	Engine VALVE STEM SEAL
03901 3979	90913-02062		ESTIMA 2TZFE (IN.)	90/5~92/6	Engine VALVE STEM SEAL
03901 5901	90913-02062		ESTIMA 2TZFE (EX.)	90/5~00/	Engine VALVE STEM SEAL
03901 5023	90311-89003	89 x 105 x 10	ESTIMA 2AZFE ACR30,40	00/2~	Engine CRANK SHAFT REAR
03901 3065	90311-92008	92 x 110 x 9	ESTIMA 1MZFE MCR30,40	99/12~	Engine CRANK SHAFT REAR
03901 8111	90311-88005	88 x 106 x 8.5	ESTIMA 2TZFE TCR1#,2#	90/5~00/	Engine CRANK SHAFT REAR
03901 6189	90311-90008	90 x 110 x 9.5 x 11.5	ESTIMA 3CT#...CXR1#,2#	93/8~00/	Engine CRANK SHAFT REAR
03901 2943	90310-25027	25 x 38 x 7	ESTIMA ACR30,40,MCR30,40	99/12~	Steering (P/S) CONTROL VALVE LOWER
03901 2019	90311-90005	90 x 110 x 8.5 x 10	ESTIMA 3CT#...CXR1#,2#	92/1~93/8	Engine CRANK SHAFT REAR
03901 3663	90311-42026	42 x 60 x 7	ESTIMA 3CT#...CXR1#,2#	92/1~00/	Engine CRANK SHAFT FRONT
03901 3113	90311-40022	40 x 55 x 6	ESTIMA 1MZFE MCR30,40	99/12~	Engine OIL PUMP
03901 2151	90311-38059	38 x 50 x 8	ESTIMA 2AZFE ACR30,40	00/2~	Engine TIMING GEAR CASE
03901 2849	90311-48020	48 x 68 x 7	ESTIMA 2TZFE TCR1#,2#	90/5~00/	Engine TIMING GEAR COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7821	90311-38034	38 x 50 x 10.5	ESTIMA 1MZFE MCR30,40	99/12~	Engine CAM SHAFT
03901 7677	90311-38044	38 x 50 x 6	ESTIMA 3CT#...CXR1#,2#	92/1~00/	Engine CAM SHAFT
03901 4899	90913-02117		ESTIMA 3CT#	94/4~	Engine VALVE STEM SEAL
03901 4369	90311-19002	19 x 32 x 7 x 8	ESTIMA ACR30,40,MCR30,40	99/12~	Steering (P/S) CONTROL VALVE UPPER
03901 7817	90310-25004	25 x 38 x 7 x 8	ESTIMA CXR1#,2#,TCR1#,2#	90/5~00/	Steering (P/S) CONTROL VALVE LOWER
03901 7039	90311-19002	19 x 32 x 7 x 8	ESTIMA CXR1#,2#,TCR1#,2#	90/5~00/	Steering (P/S) CONTROL VALVE UPPER
03901 7723	90311-38020	38 x 55 x 8.5	FUN CARGO NCP21,25	99/8~	Mission & Differential (A/T) FRONT OIL PUMP
03901 5465	04445-52020		FUN CARGO NCP20,21	99/8~	Steering (P/S) R & P GASKET KIT
03901 4887	04445-52010		FUN CARGO NCP25 (4WD)	99/8~	Steering (P/S) R & P GASKET KIT
03901 6191	90311-25021	25.5 x 37.5 x 6	FUN CARGO 1NZFE,2NZFE NCP2#	99/8~	Engine OIL PUMP
03901 4517	90913-02093		FUN CARGO 1NZFE,2NZFE (IN. & EX.)	99/8~	Engine VALVE STEM SEAL
03901 2293	90311-34016	34 x 54 x 9 x 15.5	FUN CARGO NCP20,21	99/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 6889	90311-75016	75 x 107 x 8	FUN CARGO 1NZFE,2NZFE NCP2#	99/8~	Engine CRANK SHAFT REAR
03901 4933	90311-38075	38 x 55 x 7.8	FUN CARGO NCP20	99/8~	Mission & Differential (A/T) FRONT OIL PUMP
03901 2917	90311-49002	50 x 64 x 8	FUN CARGO NCP25 (4WD)	99/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 2363	90311-42055	42 x 55 x 7	FUN CARGO NCP25 (4WD)	99/8~	Wheel Hub REAR
03901 7525	90311-34022	34 x 56 x 9 x 15	FUN CARGO NCP21,25	99/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.1)
03901 6429	90311-34017	34 x 63 x 9 x 16	FUN CARGO NCP20	99/8~	Mission & Differential (A/T) TRANSAXLE CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4771	90311-38075	38 x 55 x 7.8	FUN CARGO NCP20	99/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1545	04332-30030	Kit	GRANVIA, GRAND HIACE RCH11	95/8~98/	Transmission (A/T) REAR EXTENTION
03901 4763	90311-92006	92 x 110 x 9.5	GRANVIA, GRAND HIACE 5VZFE VZH1#,2#	97/8~	Engine CRANK SHAFT REAR
03901 8023	90311-50136	50 x 68 x 9	GRANVIA, GRAND HIACE KCH10,12,RCH11,VCH10,22	95/8~	Wheel Hub FRONT
03901 1407	90311-66001	66 x 85 x 8 x 10	GRANVIA, GRAND HIACE KCH16,VCH16,28 (4WD)	95/10~	Wheel Hub FRONT
03901 8081	90311-38020	38 x 55 x 8.5	GRANVIA, GRAND HIACE RCH11	95/8~98/	Transmission (A/T) FRONT OIL PUMP
03901 6707	90311-38029	38 x 55 x 7.5	GRANVIA, GRAND HIACE KCH1#,VCH1#,2#	95/8~	Transmission (A/T) FRONT OIL PUMP
03901 4235	90311-38051	38 x 50 x 10	GRANVIA, GRAND HIACE 5VZFE VZH1#,2#	97/8~	Engine CAM SHAFT
03901 4073	90913-02062		GRANVIA, GRAND HIACE 5VZFE (EX.)	97/8~	Engine VALVE STEM SEAL
03901 1107	90913-02095		GRANVIA, GRAND HIACE 5VZFE (IN.)	97/8~	Engine VALVE STEM SEAL
03901 5503	90913-02062		GRANVIA, GRAND HIACE 3RZFE (EX.)	95/8~98/4	Engine VALVE STEM SEAL
03901 5351	90913-02079		GRANVIA, GRAND HIACE 3RZFE (IN.)	95/8~98/4	Engine VALVE STEM SEAL
03901 3129	90913-02117		GRANVIA, GRAND HIACE 1KZTE	97/8~	Engine VALVE STEM SEAL
03901 3855	90913-02110		GRANVIA, GRAND HIACE 1KZTE	95/8~97/8	Engine VALVE STEM SEAL
03901 3689	90311-95008	95 x 115 x 9.5 x 12	GRANVIA, GRAND HIACE 1KZTE KCH1#	95/8~	Engine CRANK SHAFT REAR
03901 5731	90311-40022	40 x 55 x 6	GRANVIA, GRAND HIACE 5VZFE VZH1#,2#	97/8~	Engine OIL PUMP
03901 2991	90311-40001	40 x 58 x 11	GRANVIA, GRAND HIACE KCH10,12,VCH10,22	95/8~	Transmission (A/T) REAR EXTENTION
03901 6185	90311-32020	32 x 46 x 6	GRANVIA, GRAND HIACE 1KZTE KCH1#	95/8~	Engine CAM SHAFT
03901 5817	90311-58006	58 x 72 x 7	GRANVIA, GRAND HIACE 1KZTE KCH1#	95/8~	Engine TIMING GEAR COVER
03901 2291	90311-50017	50 x 68 x 9 x 14.5	GRANVIA, GRAND HIACE 1KZTE KCH1#	95/8~	Engine TIMING GEAR CASE
03901 5165	90311-48020	48 x 68 x 7	GRANVIA, GRAND HIACE 3RZFE RCH11	95/8~98/	Engine TIMING GEAR CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2581	90310-25004	25 x 38 x 7 x 8	GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2#	95/8~	Steering (P/S) CONTROL VALVE LOWER
03901 5411	90311-19002	19 x 32 x 7 x 8	GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2#	95/8~	Steering (P/S) CONTROL VALVE UPPER
03901 3583	04445-26050		GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2#	95/8~	Steering (P/S) R & P GASKET KIT
03901 5747	90311-38133	38 x 74 x 11	GRANVIA, GRAND HIACE KCH1#,RCH11,VCH1#,2#	95/8~	Final Drive REAR DIFF. PINION
03901 4431	90311-88005	88 x 106 x 8.5	GRANVIA, GRAND HIACE 3RZFE RCH11	95/8~98/	Engine CRANK SHAFT REAR
03901 4881	90311-40010	40 x 56 x 9 x 15.5	HARRIER MCU10,SXU10 (2WD)	97/12~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3199	15165-70010	18 x 30 x 7	HARRIER 5SFE SXU1#	97/12~	Engine OIL PUMP
03901 2863	90311-62004	62 x 74 x 8.5	HARRIER MCU15,SXU15 (4WD)	97/12~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 8069	90311-38020	38 x 55 x 8.5	HARRIER MCU1#,SXU1#	97/12~	Mission & Differential (A/T) FRONT OIL PUMP
03901 2307	04445-33070		HARRIER MCU1#,SXU1#	97/12~	Steering (P/S) R & P GASKET KIT
03901 3245	90311-19010	19 x 32 x 6	HARRIER MCU1#,SXU1#	97/12~	Steering (P/S) CONTROL VALVE UPPER
03901 6333	90311-26003	26 x 38 x 6.5	HARRIER MCU1#,SXU1#	97/12~	Steering (P/S) CONTROL VALVE LOWER
03901 1501	90311-38034	38 x 50 x 10.5	HARRIER 1MZFE MCU1#	97/12~	Engine CAM SHAFT
03901 3393	90311-52005	52 x 75 x 7.5 x 12	HARRIER MCU15,SXU15 (4WD)	97/12~	Wheel Hub REAR OUTER
03901 5225	90311-40022	40 x 55 x 6	HARRIER 1MZFE MCU1#	97/12~	Engine OIL PUMP
03901 7025	90311-56015	56 x 75 x 7 x 12	HARRIER MCU15,SXU15 (4WD)	97/12~	Wheel Hub REAR INNER
03901 3825	90311-42035	42 x 60 x 7	HARRIER 5SFE SXU1#	97/12~	Engine CRANK SHAFT FRONT
03901 4665	90311-92008	92 x 110 x 9	HARRIER 1MZFE MCU1#	97/12~	Engine CRANK SHAFT REAR
03901 7199	90311-85007	85 x 105 x 10	HARRIER 5SFE SXU1#	97/12~	Engine CRANK SHAFT REAR
03901 1017	90913-02101		HARRIER 1MZFE (IN.)	97/12~	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7745	90913-02111		HARRIER 1MZFE (EX.)	97/12~	Engine VALVE STEM SEAL
03901 4269	90913-02079		HARRIER 5SFE (IN.)	97/12~	Engine VALVE STEM SEAL
03901 6567	90311-50011	50 x 80 x 16.5 x 23	HARRIER MCU1#,SXU1#	97/12~	Mission & Differential (A/T) DIFF. SIDE
03901 3863	90311-38067	38 x 50 x 8	HARRIER 5SFE SXU1#	97/12~	Engine CAM SHAFT
03901 7793	90913-02062		HARRIER 5SFE (EX.)	97/12~	Engine VALVE STEM SEAL
03901 1615	90311-38133	38 x 74 x 11	HIACE (TRUCK) LY101,111,151,161,YY101	95/5~95/11	Final Drive REAR DIFF. PINION
03901 7785	90311-32106	32 x 48 x 8	HIACE (TRUCK) RH24,YH80	82/11~87/	Transmission (M/T) FRONT COVER
03901 7415	90311-32012	32 x 53 x 7	HIACE (TRUCK) LH85,95	87/10~95/	Transmission (M/T) FRONT COVER
03901 5921	90311-32012	32 x 53 x 7	HIACE (TRUCK) LY151,161	95/5~99/	Transmission (M/T) FRONT COVER
03901 3427	90311-38043	38 x 58 x 11	HIACE (TRUCK) LH24,RH24	82/11~85/	Transmission (M/T) REAR EXTENTION
03901 4119	90311-38043	38 x 58 x 11	HIACE (TRUCK) LH80,YH80,81	85/8~88/8	Transmission (M/T) REAR EXTENTION
03901 7729	90311-38032	38 x 58 x 11	HIACE (TRUCK) LH80,90,YH81	88/8~95/	Transmission (M/T) REAR EXTENTION
03901 2309	90311-38032	38 x 58 x 11	HIACE (TRUCK) LY101,111,YY101	95/5~99/	Transmission (M/T) REAR EXTENTION
03901 4669	90311-38020	38 x 55 x 8.5	HIACE (TRUCK) LH80,90,LY101,111	85/8~99/	Transmission (A/T) FRONT OIL PUMP
03901 1935	04332-30030	Kit	HIACE (TRUCK) LH80,90,LY101,111	85/8~99/	Transmission (A/T) REAR EXTENTION
03901 2387	90311-38133	38 x 74 x 11	HIACE (TRUCK) LH8#,9#,YH8#	85/8~95/	Final Drive REAR DIFF. PINION
03901 7917	90311-38133	38 x 74 x 11	HIACE (TRUCK) LY101,111,YY101	95/11~96/1	Final Drive REAR DIFF. PINION
03901 8173	90311-38133	38 x 74 x 11	HIACE (TRUCK) LY151,161 SUPER SINGLE JUST LOW	95/11~96/1	Final Drive REAR DIFF. PINION
03901 7629	90311-38047	38 x 74 x 11 x 18	HIACE (TRUCK) LY151,161 W/CAB,SINGLE JUST LOW	95/11~96/1	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1321	90311-38047	38 x 74 x 11 x 18	HIACE (TRUCK) LY101,111,151,161,YY101	96/1~99/	Final Drive REAR DIFF. PINION
03901 6827	90311-50136	50 x 68 x 9	HIACE (TRUCK) LY101,111,YY101	95/5~99/	Wheel Hub FRONT
03901 2665	90311-30014	30 x 45 x 8	HIACE (TRUCK) LY101.111.YY101	95/5~99/	Transmission (M/T) FRONT COVER
03901 4011	90311-38133	38 x 74 x 11	HIACE (TRUCK) LH24,RH24	82/11~85/	Final Drive REAR DIFF. PINION
03901 5093	90311-62001	62 x 85 x 10	HIACE (TRUCK) LH8#,9#,YH81 DOUBLE TIRE	85/8~95/	Wheel Hub REAR INNER
03901 3001	90311-50136	50 x 68 x 9	HIACE (TRUCK) LH80,90,YH81	85/8~95/	Wheel Hub FRONT
03901 2433	90311-42026	42 x 60 x 7	HIACE (TRUCK) 2Y,3Y YH8#,YY101	87/8~99/	Engine TIMING GEAR COVER
03901 6645	90311-66001	68 x 85 x 8 x 10	HIACE (TRUCK) LH85,95	87/10~95/	Wheel Hub FRONT
03901 5829	90311-18010	18 x 30 x 8	HIACE (TRUCK) LH24,80,90,RH24,YH8#	82/11~95/	Steering (M/S) WORM GEAR
03901 7249	90310-50001	50 x 70 x 9	HIACE (TRUCK) LH24,RH24 SINGLE TIRE	82/11~85/	Wheel Hub REAR INNER
03901 4619	90310-50001	50 x 70 x 9	HIACE (TRUCK) LH8#,9#,YH81 SINGLE TIRE	85/8~95/	Wheel Hub REAR INNER
03901 3995	90311-66001	68 x 85 x 8 x 10	HIACE (TRUCK) LY151,161	95/5~99/	Wheel Hub FRONT
03901 1215	90311-62001	62 x 85 x 10	HIACE (TRUCK) LH24,RH24 DOUBLE TIRE	82/11~85/	Wheel Hub REAR INNER
03901 5835	90311-30014	30 x 45 x 8	HIACE (TRUCK) LH80,90,YH81	90/7~95/	Transmission (M/T) FRONT COVER
03901 2545	90313-48001	48 x 62 x 9 x 24	HIACE (TRUCK) LH24,RH24 SINGLE TIRE	82/11~85/	Wheel Hub REAR OUTER
03901 2471	90313-48001	48 x 62 x 9 x 24	HIACE (TRUCK) LH8#,9#,YH81 SINGLE TIRE	85/8~95/	Wheel Hub REAR OUTER
03901 1827	90313-48001	48 x 62 x 9 x 24	HIACE (TRUCK) LY101,111,151,161,YY101	95/5~99/	Wheel Hub REAR OUTER
03901 2833	90310-35001	35 x 41 x 5.5 x 9	HIACE (TRUCK) LH24,RH24 DOUBLE TIRE	82/11~85/	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3851	90310-35001	35 x 41 x 5.5 x 9	HIACE (TRUCK) LH8#,9#,YH81 DOUBLE TIRE	85/8~95/	Wheel Hub REAR OUTER
03901 3915	90311-30115	30 x 45 x 8	HIACE (TRUCK) LH24	82/11~85/	Transmission (M/T) FRONT COVER
03901 3339	90311-30115	30 x 45 x 8	HIACE (TRUCK) LH80,YH81	85/8~90/7	Transmission (M/T) FRONT COVER
03901 2381	90310-50001	50 x 70 x 9	HIACE (TRUCK) LY101,111,151,161,YY101	95/5~99/	Wheel Hub REAR INNER
03901 5111	90311-85007	85 x 105 x 10	HIACE (TRUCK) 3L LY101,111,151,161	95/5~99/	Engine CRANK SHAFT REAR
03901 7413	90311-42003	42 x 60 x 7	HIACE (TRUCK) 2L LH8#	85/8~88/8	Engine CAM SHAFT
03901 5037	90311-42003	42 x 60 x 7	HIACE (TRUCK) 2L LH85	88/8~89/1 0	Engine CAM SHAFT
03901 4363	90311-32020	32 x 46 x 6	HIACE (TRUCK) 2L LH80	88/8~89/1 0	Engine CAM SHAFT
03901 7971	90311-32020	32 x 46 x 6	HIACE (TRUCK) 2L LH8#,9#	89/10~95/	Engine CAM SHAFT
03901 6949	90311-32020	32 x 46 x 6	HIACE (TRUCK) 3L LY101,111,151,161	95/5~99/	Engine CAM SHAFT
03901 5851	90311-85001	85 x 105 x 13	HIACE (TRUCK) L LH24	82/11~84/ 2	Engine CRANK SHAFT REAR
03901 3259	90311-38013	38.5 x 58 x 11	HIACE (TRUCK) 12R RH24	82/11~85/	Engine TIMING GEAR COVER
03901 4937	90311-85007	85 x 105 x 10	HIACE (TRUCK) 2L LH8#,9#	91/2~95/	Engine CRANK SHAFT REAR
03901 7133	90311-42026	42 x 60 x 7	HIACE (TRUCK) 2L LH8#,9#	91/2~95/	Engine TIMING GEAR CASE
03901 5279	90311-80003	80 x 100 x 8.5	HIACE (TRUCK) 2Y YH8#	85/8~90/4	Engine CRANK SHAFT REAR
03901 7233	90311-80009	80 x 100 x 10	HIACE (TRUCK) 2Y,3Y YH8#,YY101	90/4~99/	Engine CRANK SHAFT REAR
03901 1115	90913-02060		HIACE (TRUCK) L,2L LH24,8#	82/11~88/ 8	Engine VALVE STEM SEAL
03901 7877	90913-02060		HIACE (TRUCK) 2L LH85	88/8~89/1 0	Engine VALVE STEM SEAL
03901 3457	90913-02110		HIACE (TRUCK) 2L LH80	88/8~89/1 0	Engine VALVE STEM SEAL
03901 5433	90913-02110		HIACE (TRUCK) 3L LY101,111,151,161	95/5~99/	Engine VALVE STEM SEAL
03901 7927	90913-02094		HIACE (TRUCK) 2Y,3Y YH8#,YY101	85/8~99/	Engine VALVE STEM SEAL
03901 1443	90311-85004	85 x 105 x 10	HIACE (TRUCK) L,2L LH24,8#	84/2~91/2	Engine CRANK SHAFT REAR
03901 7495	90312-32001	32 x 42 x 5	HIACE (TRUCK) LY101,111,YY101	95/5~99/	Steering (P/S) GEAR HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5973	04445-25030		HIACE (TRUCK) LH80,YH8#	85/8~89/2	Steering (P/S) P/S GEAR GASKET KIT
03901 5703	04445-26030		HIACE (TRUCK) LH80,90,YH81	89/2~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 7591	04445-25060		HIACE (TRUCK) LY101,111,YY101	95/5~99/	Steering (P/S) P/S GEAR GASKET KIT
03901 5471	04445-27010		HIACE (TRUCK) LH85	87/10~88/ 8	Steering (P/S) R & P GASKET KIT
03901 7735	04445-27011		HIACE (TRUCK) LH85	88/8~89/1 0	Steering (P/S) R & P GASKET KIT
03901 7589	04445-27013		HIACE (TRUCK) LH85,95	89/10~95/	Steering (P/S) R & P GASKET KIT
03901 4911	04445-27013		HIACE (TRUCK) LY151,161	95/5~99/	Steering (P/S) R & P GASKET KIT
03901 6969	90311-42003	42 x 60 x 7	HIACE (TRUCK) L LH24	82/11~85/	Engine CAM SHAFT
03901 1275	90312-32001	32 x 42 x 5	HIACE (TRUCK) LH80,90,YH8#	85/8~95/	Steering (P/S) GEAR HOUSING
03901 7823	90311-42026	42 x 60 x 7	HIACE (TRUCK) 3L LY101,111,151,161	95/5~99/	Engine TIMING GEAR CASE
03901 8039	90311-19002	19 x 32 x 7 x 8	HIACE (TRUCK) LH85,95,LY151,161	87/10~99/	Steering (P/S) CONTROL VALVE UPPER
03901 5239	90310-25004	25 x 38 x 7 x 8	HIACE (TRUCK) LH85,95,LY151,161	87/10~99/	Steering (P/S) CONTROL VALVE LOWER
03901 7009	90311-50136	50 x 68 x 9	HIACE (TRUCK) LH24,RH24	82/11~85/	Wheel Hub FRONT
03901 5243	90311-42003	42 x 60 x 7	HIACE (TRUCK) 2Y YH8#	85/8~87/8	Engine TIMING GEAR COVER
03901 5497	90913-02110		HIACE (TRUCK) 2L LH8#,9#	89/10~95/	Engine VALVE STEM SEAL
03901 6833	90311-42003	42 x 60 x 7	HIACE (TRUCK) L,2L LH24,8#	82/11~91/ 2	Engine TIMING GEAR CASE
03901 3353	90311-32014	32 x 44 x 9	HIACE (TRUCK) LH24,80,90,RH24,YH8#	82/11~95/	Steering (M/S) SECTOR SHAFT
03901 1079	90311-19002	19 x 32 x 7 x 8	HIACE (TRUCK) LH80,90,YH8#	85/8~95/	Steering (P/S) ADJUSTER PLUG
03901 5069	90913-02033		HIACE (TRUCK) 12R RH24	82/11~85/	Engine VALVE STEM SEAL
03901 7799	90311-38032	38 x 58 x 11	HIACE (VAN, WAGON) LH102,103,113,123,162,172, 182,184	89/8~	Transmission (A/T) REAR EXTENTION
03901 2821	90311-38032	38 x 58 x 11	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#	88/8~89/	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6805	90311-38032	38 x 58 x 11	HIACE (VAN, WAGON) LH10#,11#,12#,140,16#,17#, 18#...EXCEPT TD,TDE	89/8~	Transmission (M/T) REAR EXTENTION
03901 1585	90311-40001	40 x 58 x 11	HIACE (VAN, WAGON) LH100,120,KZH10#,11#,12#. ..TD,TDE	89/8~	Transmission (M/T) REAR EXTENTION
03901 2775	90311-38020	38 x 55 x 8.5	HIACE (VAN, WAGON) YH51,61,LH50,51,61	83/12~89/	Transmission (A/T) FRONT OIL PUMP
03901 3727	90311-38020	38 x 55 x 8.5	HIACE (VAN, WAGON) LH1##...EXCEPT 100,120	89/8~	Transmission (A/T) FRONT OIL PUMP
03901 7383	90311-38020	38 x 55 x 8.5	HIACE (VAN, WAGON) RZH10#,11#,12#,133	89/8~	Transmission (A/T) FRONT OIL PUMP
03901 7801	90311-38029	38 x 55 x 7.5	HIACE (VAN, WAGON) LH100,120,KZH10#,11#,120, 13#	90/10~	Transmission (A/T) FRONT OIL PUMP
03901 1871	90311-18010	18 x 30 x 8	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#	82/12~89/	Steering (M/S) WORM GEAR
03901 1253	90311-38032	38 x 58 x 11	HIACE (VAN, WAGON) LH100	89/8~90/1 0	Transmission (A/T) REAR EXTENTION
03901 6081	90311-32012	32 x 53 x 7	HIACE (VAN, WAGON) YH57,LH56,66	86/8~89/	Transmission (M/T) FRONT COVER
03901 6661	90311-40001	40 x 58 x 11	HIACE (VAN, WAGON) LH100,120,KZH100,110,120, 132	90/10~	Transmission (A/T) REAR EXTENTION
03901 5971	90311-38133	38 x 74 x 11	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#	82/12~89/	Final Drive REAR DIFF. PINION
03901 3447	90311-38133	38 x 74 x 11	HIACE (VAN, WAGON) LH10#,11#,12#,140,RZH10#, 11#,12#,133	89/8~95/1 1	Final Drive REAR DIFF. PINION
03901 3821	90311-38133	38 x 74 x 11	HIACE (VAN, WAGON) KZH10#,11#,12#,13#	93/8~95/1 1	Final Drive REAR DIFF. PINION
03901 3615	90311-38133	38 x 74 x 11	HIACE (VAN, WAGON) LH10#,11#,12#,RZH102,112, 124	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 6371	90311-38047	38 x 74 x 11 x 18	HIACE (VAN, WAGON) KZH106,116 5F,KZH100,110,12#,132	95/11~96/ 1	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2857	90311-38047	38 x 74 x 11 x 18	HIACE (VAN, WAGON) RZH10#,11#,12#,133,KZH10 #,11#,12#,13#	96/1~	Final Drive REAR DIFF. PINION
03901 1801	90311-38032	38 x 58 x 11	HIACE (VAN, WAGON) YH51,61,LH51,61	87/8~	Transmission (A/T) REAR EXTENTION
03901 3281	90310-50001	50 x 70 x 9	HIACE (VAN, WAGON) LH1##,KZH1##,RZH1##	89/8~	Wheel Hub REAR INNER
03901 3205	90311-42026	42 x 60 x 7	HIACE (VAN, WAGON) 2L,3L,5L LH10#,11#,16#,17#,18#	91/8~	Engine TIMING GEAR CASE
03901 1057	90311-50136	50 x 68 x 9	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD	82/12~89/	Wheel Hub FRONT
03901 6425	90311-50136	50 x 68 x 9	HIACE (VAN, WAGON) RZH10#,11#,12#,133 2WD	89/8~	Wheel Hub FRONT
03901 5873	90311-50136	50 x 68 x 9	HIACE (VAN, WAGON) LH10#,11#,12#,140,162,172, 18#...2WD	89/8~	Wheel Hub FRONT
03901 6067	90311-50136	50 x 68 x 9	HIACE (VAN, WAGON) KZH100,110,120,132 2WD	93/8~	Wheel Hub FRONT
03901 1941	90311-66001	66 x 85 x 8 x 10	HIACE (VAN, WAGON) YH57,LH56,66 4WD	86/8~89/	Wheel Hub FRONT
03901 7211	90311-66001	66 x 85 x 8 x 10	HIACE (VAN, WAGON) LH107,109,117,119,129,168, 178,186,188 4WD	89/8~	Wheel Hub FRONT
03901 4719	90311-38043	38 x 58 x 11	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#	82/12~88/ 8	Transmission (M/T) REAR EXTENTION
03901 4475	90310-50001	50 x 70 x 9	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...SI NGLE TIRE	82/12~89/	Wheel Hub REAR INNER
03901 4575	90311-32012	32 x 53 x 7	HIACE (VAN, WAGON) LH100,120,KZH10#,11#,12#. ..TD,TDE	89/8~99/	Transmission (M/T) FRONT COVER
03901 5131	90311-62001	62 x 85 x 10	HIACE (VAN, WAGON) YH61,LH6#...DOUBLE TIRE	82/12~89/	Wheel Hub REAR INNER
03901 6293	90313-48001	48 x 62 x 9 x 24	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...SI NGLE TIRE	82/12~89/	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6389	90313-48001	48 x 62 x 9 x 24	HIACE (VAN, WAGON) LH1##,KZH1##,RZH1##	89/8~	Wheel Hub REAR OUTER
03901 5869	90310-35001	35 x 41 x 5.5 x 9	HIACE (VAN, WAGON) YH61,LH6#...DOUBLE TIRE	82/12~89/	Wheel Hub REAR OUTER
03901 1761	90311-30115	30 x 45 x 8	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD	82/12~89/	Transmission (M/T) FRONT COVER
03901 2327	90311-30014	30 x 45 x 8	HIACE (VAN, WAGON) LH10#,11#,12#,140,16#,17#, 18#...EXCEPT TD,TDE	89/8~	Transmission (M/T) FRONT COVER
03901 5125	90311-30014	30 x 45 x 8	HIACE (VAN, WAGON) RZH10#,11#,12#	89/8~	Transmission (M/T) FRONT COVER
03901 8197	90311-38047	38 x 74 x 11 x 18	HIACE (VAN, WAGON) LH10#,11#,12#,16#,17#,18#	96/1~	Final Drive REAR DIFF. PINION
03901 4445	90311-66001	66 x 85 x 8 x 10	HIACE (VAN, WAGON) KZH106,116,12#,138 4WD	93/8~	Wheel Hub FRONT
03901 6741	90311-85007	85 x 105 x 10	HIACE (VAN, WAGON) 2L,3L,5L LH10#,11#,12#,140,16#,17#, 18#	91/2~	Engine CRANK SHAFT REAR
03901 5383	90311-36004	36 x 46 x 9	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#	82/12~89/	Steering (M/S) SECTOR SHAFT
03901 6923	90913-02110		HIACE (VAN, WAGON) 1RZ#,2RZE RZH10#,11#,12#,133	89/8~	Engine VALVE STEM SEAL
03901 2549	90311-38133	38 x 74 x 11	HIACE (VAN, WAGON) KZH106,116,138,RZH101,11 1,133 4FC	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 7465	90913-02110		HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13#	93/8~97/1 0	Engine VALVE STEM SEAL
03901 5349	90913-02117		HIACE (VAN, WAGON) 3L,5L LH10#,11#,12#,16#,17#,18#	97/4~	Engine VALVE STEM SEAL
03901 7703	90913-02110		HIACE (VAN, WAGON) 2L,3L LH10#,11#,12#,140	89/8~97/4	Engine VALVE STEM SEAL
03901 3411	90913-02060		HIACE (VAN, WAGON) L,2L LH5#,6#,7#	82/12~89/ 8	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7529	90913-02094		HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71	82/12~89/	Engine VALVE STEM SEAL
03901 3033	90311-58006	58 x 72 x 7	HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13#	93/8~	Engine TIMING GEAR COVER
03901 4395	90311-88005	88 x 106 x 8.5	HIACE (VAN, WAGON) 1RZ#,2RZE RZH10#,11#,12#,133	89/8~	Engine CRANK SHAFT REAR
03901 3265	90311-42003	42 x 60 x 7	HIACE (VAN, WAGON) L,2L,3L LH5#,6#,7#,10#,11#,12#,140	82/12~91/ 8	Engine TIMING GEAR CASE
03901 2841	90311-85004	85 x 105 x 10	HIACE (VAN, WAGON) L,2L,3L LH5#,6#,7#,10#,11#,12#,140	84/2~91/2	Engine CRANK SHAFT REAR
03901 5665	90311-85001	85 x 105 x 13	HIACE (VAN, WAGON) L,2L LH5#,6#,7#	82/12~84/ 2	Engine CRANK SHAFT REAR
03901 4137	90311-80003	80 x 100 x 8.5	HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71	82/12~89/	Engine CRANK SHAFT REAR
03901 7827	90311-32020	32 x 46 x 6	HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13#	93/8~	Engine CAM SHAFT
03901 2513	90311-32020	32 x 46 x 6	HIACE (VAN, WAGON) 2L,3L,5L LH10#,11#,140,16#,17#,18#	89/8~	Engine CAM SHAFT
03901 5655	90311-42003	42 x 60 x 7	HIACE (VAN, WAGON) L,2L LH5#,6#,7#	82/12~89/	Engine CAM SHAFT
03901 3789	90311-50017	50 x 68 x 9 x 14.5	HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13#	93/8~	Engine TIMING GEAR CASE
03901 6631	90311-48020	48 x 68 x 7	HIACE (VAN, WAGON) 1RZ#,2RZE RZH10#,11#,12#,133	89/8~	Engine TIMING GEAR CASE
03901 2969	90311-95008	95 x 115 x 9.5 x 12	HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13#	93/8~	Engine CRANK SHAFT REAR
03901 4193	04445-26060		HIACE (VAN, WAGON) RZH102,112,12#	95/8~	Steering (P/S) R & P GASKET KIT
03901 4207	90311-15001	15 x 25 x 7	HIACE (VAN, WAGON) LH10#,11#,RZH10#,11#	89/8~93/	Steering (M/S) RACK HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7115	04445-27013		HIACE (VAN, WAGON) LH11#,KZH1##,RZH1##...E XC. PROGRESSIVE P/S	89/8~95/8	Steering (P/S) R & P GASKET KIT
03901 1039	04445-26020		HIACE (VAN, WAGON) LH100,107,RZH10#...PROG RESSIVE P/S	89/8~93/8	Steering (P/S) R & P GASKET KIT
03901 5995	90913-02117		HIACE (VAN, WAGON) 1KZTE KZH10#,11#,12#,13#	97/10~	Engine VALVE STEM SEAL
03901 7687	04445-26060		HIACE (VAN, WAGON) LH103,113,123,125,162,172, 182,184	95/8~	Steering (P/S) R & P GASKET KIT
03901 5767	90311-42026	42 x 60 x 7	HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71	87/8~89/	Engine TIMING GEAR COVER
03901 5735	04445-26070		HIACE (VAN, WAGON) LH109,119,129,168,178,186, 188	95/8~	Steering (P/S) R & P GASKET KIT
03901 7335	04445-26070		HIACE (VAN, WAGON) RZH101,111,133,KZH10#,11 #,12#,13#	95/8~	Steering (P/S) R & P GASKET KIT
03901 5531	90311-30016	30 x 42 x 7 x 8	HIACE (VAN, WAGON) LH100,KZH10#,RZH100,101 SCL	92/4~94/8	Steering (P/S) CONTROL VALVE LOWER
03901 3503	90312-32002	32 x 40 x 5	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD	82/12~89/	Steering (P/S) GEAR HOUSING
03901 7651	90311-19002	19 x 32 x 7 x 8	HIACE (VAN, WAGON) YH57,LH56,66 (4WD)	86/8~89/	Steering (P/S) CONTROL VALVE UPPER
03901 6871	90311-19002	19 x 32 x 7 x 8	HIACE (VAN, WAGON) LH1##,KZH1##,RZH1##	89/8~	Steering (P/S) CONTROL VALVE UPPER
03901 3213	90310-25004	25 x 38 x 7 x 8	HIACE (VAN, WAGON) YH57,LH56,66 (4WD)	86/8~89/	Steering (P/S) CONTROL VALVE LOWER
03901 7485	90310-25004	25 x 38 x 7 x 8	HIACE (VAN, WAGON) LH1##,KZH1##,RZH1##...E XC. PROGRESSIVE P/S	89/8~	Steering (P/S) CONTROL VALVE LOWER
03901 1607	90311-30016	30 x 42 x 7 x 8	HIACE (VAN, WAGON) LH100,107,RZH10#...PROG RESSIVE P/S	89/8~94/8	Steering (P/S) CONTROL VALVE LOWER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4503	90311-19002	19 x 32 x 7 x 8	HIACE (VAN, WAGON) YH5#,6#,71,LH5#,6#,7#...2 WD	82/12~89/ 8	Steering (P/S) ADJUSTER PLUG
03901 1753	04445-28051		HIACE (VAN, WAGON) KZH10#,RZH101 SUPER CUSTOM LIMITED	93/8~94/8	Steering (P/S) R & P GASKET KIT
03901 6437	90311-42003	42 x 60 x 7	HIACE (VAN, WAGON) 2Y,3Y YH5#,6#,71	82/12~87/ 8	Engine TIMING GEAR COVER
03901 8103	90311-32020	32 x 46 x 6	HIACE REGIUS 5L LXH4#	97/6~	Engine CAM SHAFT
03901 4799	90311-48020	48 x 68 x 7	HIACE REGIUS 1RZE,3RZFE RCH4#	97/4~	Engine TIMING GEAR CASE
03901 8041	90311-32020	32 x 46 x 6	HIACE REGIUS 1KZTE KCH4#	97/4~	Engine CAM SHAFT
03901 4767	90311-42026	42 x 60 x 7	HIACE REGIUS 5L LXH4#	97/6~	Engine TIMING GEAR CASE
03901 4387	90311-58006	58 x 72 x 7	HIACE REGIUS 1KZTE KCH4#	97/4~	Engine TIMING GEAR COVER
03901 1537	90311-95008	95 x 115 x 9.5 x 12	HIACE REGIUS 1KZTE KCH4#	97/4~	Engine CRANK SHAFT REAR
03901 3301	90913-02079		HIACE REGIUS 3RZFE(IN.) RCH41,47	97/4~	Engine VALVE STEM SEAL
03901 6043	90311-85007	85 x 105 x 10	HIACE REGIUS 5L LXH4#	97/6~	Engine CRANK SHAFT REAR
03901 6427	90913-02110		HIACE REGIUS 1KZTE KCH4#	97/4~97/1 0	Engine VALVE STEM SEAL
03901 6601	90913-02110		HIACE REGIUS 1RZE RCH42	97/6~	Engine VALVE STEM SEAL
03901 2331	90311-88005	88 x 106 x 8.5	HIACE REGIUS 1RZE,3RZFE RCH4#	97/4~	Engine CRANK SHAFT REAR
03901 7907	90913-02117		HIACE REGIUS 5L LXH4#	97/6~	Engine VALVE STEM SEAL
03901 3723	90913-02062		HIACE REGIUS 3RZFE(EX.) RCH41,47	97/4~	Engine VALVE STEM SEAL
03901 6659	90913-02117		HIACE REGIUS 1KZTE KCH4#	97/10~	Engine VALVE STEM SEAL
03901 3469	90311-50136	50 x 68 x 9	HIACE REGIUS KCH40,LXH43,RCH41,42	97/4~	Wheel Hub FRONT
03901 1165	90311-38029	38 x 55 x 7.5	HIACE REGIUS KCH4#	97/4~99/7	Transmission (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3537	90311-50017	50 x 68 x 9 x 14.5	HIACE REGIUS 1KZTE KCH4#	97/4~	Engine TIMING GEAR CASE
03901 1803	90311-38029	38 x 55 x 7.5	HIACE REGIUS KCH4#,RCH41,47	99/7~	Transmission (A/T) FRONT OIL PUMP
03901 7681	90311-38064	38 x 55 x 8.7	HIACE REGIUS LXH4#,RCH42	00/5~	Transmission (A/T) FRONT OIL PUMP
03901 3633	90311-38020	38 x 55 x 8.5	HIACE REGIUS LXH4#,RCH42	99/7~00/5	Transmission (A/T) FRONT OIL PUMP
03901 1295	90311-38020	38 x 55 x 8.5	HIACE REGIUS LXH4#,RCH41,47	97/4~99/7	Transmission (A/T) FRONT OIL PUMP
03901 2577	90311-38032	38 x 58 x 11	HIACE REGIUS LXH4#,RCH42	97/6~	Transmission (M/T) REAR EXTENTION
03901 7423	04332-30030	Kit	HIACE REGIUS LXH43,RCH41	97/4~99/7	Transmission (A/T) REAR EXTENTION
03901 4285	90311-66001	66 x 85 x 8 x 10	HIACE REGIUS KCH46,LXH49,RCH47 (4WD)	97/4~	Wheel Hub FRONT
03901 5903	90310-25004	25 x 38 x 7 x 8	HIACE REGIUS KCH4#,LXH4#,RCH4#	97/4~	Steering (P/S) CONTROL VALVE LOWER
03901 7653	90311-19002	19 x 32 x 7 x 8	HIACE REGIUS KCH4#,LXH4#,RCH4#	97/4~	Steering (P/S) CONTROL VALVE UPPER
03901 2645	04445-26050		HIACE REGIUS KCH4#,LXH4#,RCH4#	97/4~	Steering (P/S) R & P GASKET KIT
03901 7757	90311-38133	38 x 74 x 11	HIACE REGIUS KCH4#,LXH4#,RCH4#	97/4~	Final Drive REAR DIFF. PINION
03901 1653	90311-40001	40 x 58 x 11	HIACE REGIUS KCH40,RCH41	99/7~	Transmission (A/T) REAR EXTENTION
03901 7343	90311-40001	40 x 58 x 11	HIACE REGIUS KCH40	97/4~99/7	Transmission (A/T) REAR EXTENTION
03901 5999	90311-38032	38 x 58 x 11	HIACE REGIUS LXH43,RCH42	99/7~	Transmission (A/T) REAR EXTENTION
03901 3193	90311-30014	30 x 45 x 8	HIACE REGIUS LXH4#,RCH42	97/6~	Transmission (M/T) FRONT COVER
03901 3651	90311-45002	45 x 68 x 12	HILUX 18RJ RN36,39	79/10~83/	Engine TIMING GEAR COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2565	90311-32015	32 x 42 x 5	HILUX YN60,65,YN100,105,LN60,6 5,100,106	88/1~97/	Steering (P/S) GEAR HOUSING
03901 8161	90311-32016	32 x 40 x 5	HILUX YN8#,LN8#	90/8~97/	Steering (P/S) GEAR HOUSING
03901 3815	90311-32016	32 x 40 x 5	HILUX RZN147,152,LN147	97/8~	Steering (P/S) GEAR HOUSING
03901 7869	90311-36005	36 x 44 x 5	HILUX LN107,108,109,112,13#,KZN 130,YN107,130,VZN130	89/4~97/	Steering (P/S) GEAR HOUSING
03901 1637	90311-36005	36 x 44 x 5	HILUX LN16#,173,RZN16#,174	97/8~	Steering (P/S) GEAR HOUSING
03901 4151	90311-19002	19 x 32 x 7 x 8	HILUX KZN185,RZN183,VZN18#	95/11~	Steering (P/S) CONTROL VALVE UPPER
03901 7055	90311-38013	38.5 x 58 x 11	HILUX 12RJ RN30,33,35,4#	78/8~88/	Engine TIMING GEAR COVER
03901 6975	04445-35110		HILUX LN13#,VZN130,YN130	89/4~91/8	Steering (P/S) P/S GEAR GASKET KIT
03901 3369	90311-42003	42 x 60 x 7	HILUX 2Y#,3Y#...YN5#,6#	83/11~87/ 6	Engine TIMING GEAR COVER
03901 7575	90311-42026	42 x 60 x 7	HILUX 2Y#,3Y#...YN5#,6#,8#,10#,1 30	87/6~97/	Engine TIMING GEAR COVER
03901 6967	90311-58006	58 x 72 x 7	HILUX 1KZTE KZN130,185	93/8~	Engine TIMING GEAR COVER
03901 5915	90311-42003	42 x 60 x 7	HILUX L,2L,3L LN3#,4#,5#,6#,8#,10#,13#	79/12~91/ 2	Engine TIMING GEAR CASE
03901 7963	90311-42026	42 x 60 x 7	HILUX 2L,3L LN8#,10#,11#,13#	91/2~97/	Engine TIMING GEAR CASE
03901 6433	90310-25004	25 x 38 x 7 x 8	HILUX KZN185,RZN183,VZN18#	95/11~	Steering (P/S) CONTROL VALVE LOWER
03901 1071	90311-32014	32 x 44 x 9	HILUX YN8#,LN8#	91/8~94/	Steering (M/S) SECTOR SHAFT
03901 2661	90311-38047	38 x 74 x 11 x 18	HILUX LN8#,10#,112,YN8#,107	95/11~97/	Final Drive REAR DIFF. PINION
03901 7543	90311-38047	38 x 74 x 11 x 18	HILUX LN147,16#,17#,RZN147,152, 16#,174	97/8~	Final Drive REAR DIFF. PINION
03901 7665	90311-38047	38 x 74 x 11 x 18	HILUX KZN185,RZN18#,VZN18#	95/11~	Final Drive REAR DIFF. PINION
03901 5819	90311-19001	19 x 32 x 8	HILUX RN30,33,35,4#,YN5#,8#,LN 30,4#,5#,8#	78/8~94/	Steering (M/S) WORM GEAR
03901 1441	90311-18010	18 x 30 x 8	HILUX RN36,39,YN6#,LN36,46,6#	79/10~89/	Steering (M/S) WORM GEAR
03901 3433	90311-18010	18 x 30 x 8	HILUX LN106	88/9~94/	Steering (M/S) WORM GEAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7473	90310-28027	28 x 40 x 8	HILUX RN30,33,35,4#,YN5#,8#,LN 30,4#,5#,8#	78/8~91/8	Steering (M/S) SECTOR SHAFT
03901 4471	04445-35180		HILUX LN16#,17#,RZN163,174	97/8~	Steering (P/S) P/S GEAR GASKET KIT
03901 6565	90311-32014	32 x 44 x 9	HILUX LN106	88/9~94/	Steering (M/S) SECTOR SHAFT
03901 6099	04445-35160		HILUX KZN185,RZN18#,VZN183	95/11~	Steering (P/S) R & P GASKET KIT
03901 3665	90311-36004	36 x 46 x 9	HILUX YN61,LN61	85/8~88/	Steering (M/S) SECTOR SHAFT
03901 4631	04445-35090		HILUX YN8#,LN83	90/8'91/8	Steering (P/S) P/S GEAR GASKET KIT
03901 4555	04445-35120		HILUX YN8#,LN8#	91/8~97/	Steering (P/S) P/S GEAR GASKET KIT
03901 2867	04445-35120		HILUX RZN147,152,LN147	97/8~	Steering (P/S) P/S GEAR GASKET KIT
03901 7759	04445-35100		HILUX YN100,105,LN100,106	88/9~97/	Steering (P/S) P/S GEAR GASKET KIT
03901 1019	90311-42003	42 x 60 x 7	HILUX L,2L LN3#,4#,5#,6#	79/12~89/	Engine CAM SHAFT
03901 2763	04445-35130		HILUX LN107,108,109,112,13#,KZN 130,YN107,VZN130	91/8~97/	Steering (P/S) P/S GEAR GASKET KIT
03901 6907	90311-32014	32 x 44 x 9	HILUX RN36,39,YN60,65,LN36,46, 60,65	79/10~89/	Steering (M/S) SECTOR SHAFT
03901 4593	90913-02110		HILUX 5VZFE(IN.) VZN18#	95/11~	Engine VALVE STEM SEAL
03901 7217	90913-02094		HILUX 2Y#,3Y#...YN8#,10#,130	88/9~97/	Engine VALVE STEM SEAL
03901 6839	90913-02036		HILUX L LN30,40	79/12~81/ 7	Engine VALVE STEM SEAL
03901 5789	90913-02060		HILUX L,2L LN3#,4#	81/7~88/9	Engine VALVE STEM SEAL
03901 2391	90913-02110		HILUX 2L,3L LN8#,10#,11#,13#	88/9~97/5	Engine VALVE STEM SEAL
03901 3057	90913-02117		HILUX 2L,3L,5L LN8#,10#,11#,13#,147,16#,1 7#	97/5~	Engine VALVE STEM SEAL
03901 1573	90913-02110		HILUX 1KZTE KZN130,185	93/8~97/1 0	Engine VALVE STEM SEAL
03901 3169	90311-50017	50 x 68 x 9 x 14.5	HILUX 1KZTE KZN130,185	93/8~	Engine TIMING GEAR CASE
03901 5701	90913-02110		HILUX 3VZE VZN130	90/8~95/	Engine VALVE STEM SEAL
03901 6037	90311-88005	88 x 106 x 8.5	HILUX 1RZFE,3ZFE RZN147,152,16#,174,18#	95/11~	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6119	90913-02062		HILUX 5VZFE(EX.) VZN18#	95/11~	Engine VALVE STEM SEAL
03901 3079	90913-02110		HILUX 3RZFE(IN.) RZN169,174,18#	95/11~	Engine VALVE STEM SEAL
03901 6311	90913-02062		HILUX 3RZFE(EX.) RZN169,174,18#	95/11~	Engine VALVE STEM SEAL
03901 5611	90913-02117		HILUX 1RZE RZN147,167	97/8~	Engine VALVE STEM SEAL
03901 7537	90913-02110		HILUX 1RZE RZN152	99/8~	Engine VALVE STEM SEAL
03901 6519	90311-38140	38 x 58 x 11	HILUX RN36,39,YN6#,LN36,46,6#	79/10~88/	Transfer FRONT OUTPUT
03901 7583	90311-38047	38 x 74 x 11 x 18	HILUX LN8#,100,106,107,109,13#,Y N8#,10#,130	88/9~96/1	Final Drive REAR DIFF. PINION
03901 4177	90913-02117		HILUX 1KZTE KZN185	97/10~	Engine VALVE STEM SEAL
03901 6899	90311-80009	80 x 100 x 10	HILUX 2Y#,3Y#...YN8#,10#,130	90/4~97/	Engine CRANK SHAFT REAR
03901 7143	90311-48020	48 x 68 x 7	HILUX 1RZFE,3RZFE RZN147,152,16#,174,18#	95/11~	Engine TIMING GEAR CASE
03901 1933	90311-32020	32 x 46 x 6	HILUX 2L,3L LN8#,10#,11#,13#	88/9~97/	Engine CAM SHAFT
03901 4509	90311-32020	32 x 46 x 6	HILUX 2LTE,5L LN147,16#,17#	97/8~	Engine CAM SHAFT
03901 7265	90311-32020	32 x 46 x 6	HILUX 1KZTE KZN130,185	93/8~	Engine CAM SHAFT
03901 6315	90311-42027	742 x 55 x 8	HILUX 3VZE VZN130	90/8'95/	Engine CAM SHAFT
03901 3605	90311-38051	38 x 50 x 10	HILUX 5VZFE VZN18#	95/11~	Engine CAM SHAFT
03901 8151	90311-40022	40 x 55 x 6	HILUX 3VZE,5VZFE VZN130,18#	90/8~	Engine OIL PUMP
03901 5753	90913-02016		HILUX 18RJ RN36,39	79/10~83/	Engine VALVE STEM SEAL
03901 8053	90311-80003	80 x 100 x 8.5	HILUX 2Y#,3Y#...YN5#,6#,8#,10#,1 30	83/11~90/ 4	Engine CRANK SHAFT REAR
03901 7171	90913-02033		HILUX 12RJ RN30,33,35,\$	78/8'88/	Engine VALVE STEM SEAL
03901 7467	90311-85001	85 x 105 x 13	HILUX L,2L LN3#,4#,5#,6#	79/12~84/ 2	Engine CRANK SHAFT REAR
03901 8263	90311-85004	85 x 105 x 10	HILUX L,2L,3L LN4#,5#,6#,8#,10#,13#	84/2~91/2	Engine CRANK SHAFT REAR
03901 1025	90311-85007	85 x 105 x 10	HILUX 2L,3L LN8#,10#,11#,13#	91/2~97/	Engine CRANK SHAFT REAR
03901 3285	90311-85007	85 x 105 x 10	HILUX 2LTE,5L LN147,16#,17#	97/8~	Engine CRANK SHAFT REAR
03901 5399	90311-95008	95 x 115 x 9.5 x 12	HILUX 1KZTE KZN130,185	93/8~	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4691	90311-92006	92 x 110 x 9.5	HILUX 3VZE,5VZFE VZN130,18#	90/8~	Engine CRANK SHAFT REAR
03901 7323	90311-42026	42 x 60 x 7	HILUX 2LTE,5L LN147,16#,17#	97/8~	Engine TIMING GEAR CASE
03901 3513	90311-80001	80 x 100 x 12	HILUX 18RJ RN36,39	79/10~83/	Engine CRANK SHAFT REAR
03901 3477	90311-30014	30 x 45 x 8	HILUX YN8#,10#,130,LN8#,10#,131	88/9~97/	Transmission (M/T) FRONT COVER
03901 5617	90311-38020	38 x 55 x 8.5	HILUX LN56,85,YN86,RZN147,152	83/11~	Transmission (A/T) FRONT OIL PUMP
03901 5923	90313-48001	48 x 62 x 9 x 24	HILUX LN147,16#,17#,RZN147,167	97/8~98/5	Wheel Hub REAR OUTER
03901 3641	90313-48001	48 x 62 x 9 x 24	HILUX LN147,RZN147,152	98/5~	Wheel Hub REAR OUTER
03901 1925	90313-54001	54 x 64 x 9 x 24	HILUX LN16#,17#,RZN16#,174	98/5~	Wheel Hub REAR OUTER
03901 2183	90311-32106	32 x 48 x 8	HILUX RN3#,4#	78/8~85/	Transmission (M/T) FRONT COVER
03901 2193	90311-32106	32 x 48 x 8	HILUX YN5#...4H	83/11~85/	Transmission (M/T) FRONT COVER
03901 4399	90313-48001	48 x 62 x 9 x 24	HILUX LN30,4#,5#,6#,8#,10#	78/8~97/	Wheel Hub REAR OUTER
03901 1649	90311-30115	30 x 45 x 8	HILUX YN5#,6#,LN5#,6#...5H,5F	83/11~89/	Transmission (M/T) FRONT COVER
03901 5481	90313-48001	48 x 62 x 9 x 24	HILUX RN#,YN#,KZN#,VZN#	78/8~97/	Wheel Hub REAR OUTER
03901 6123	90311-30014	30 x 45 x 8	HILUX RZN147,167,LN147,167,172	97/8~	Transmission (M/T) FRONT COVER
03901 3257	90311-30014	30 x 45 x 8	HILUX RZN185	95/11~	Transmission (M/T) FRONT COVER
03901 1231	90311-32012	32 x 53 x 7	HILUX LN130,KZN130,VZN130	89/4~95/	Transmission (M/T) FRONT COVER
03901 1383	90311-32012	32 x 53 x 7	HILUX KZN185	95/11~	Transmission (M/T) FRONT COVER
03901 5685	90311-38043	38 x 58 x 11	HILUX RN3#,4#,YN5#,LN30,4#,5#	78/8~88/	Transmission (M/T) REAR EXTENTION
03901 2113	90311-38032	38 x 58 x 11	HILUX YN8#,LN8#	88/9~97/	Transmission (M/T) REAR EXTENTION
03901 7983	90311-38032	38 x 58 x 11	HILUX LN147,RZN147	97/8~	Transmission (M/T) REAR EXTENTION
03901 4311	90311-30115	30 x 45 x 8	HILUX LN3#,4#	79/12~88/	Transmission (M/T) FRONT COVER
03901 1799	90311-66001	66 x 85 x 8 x 10	HILUX YN107,LN107,108,109,112 (4WD)	91/8~97/	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8209	90311-50136	50 x 68 x 9	HILUX RN3#,4#,LN30,4#...2WD	78/8~88/	Wheel Hub FRONT
03901 3801	90311-50136	50 x 68 x 9	HILUX YN5#,LN5#	83/11~88/	Wheel Hub FRONT
03901 4611	90311-50136	50 x 68 x 9	HILUX YN8#,LN8#	88/9~97/	Wheel Hub FRONT
03901 4435	90311-50136	50 x 68 x 9	HILUX RZN147,152,LN147	97/8~	Wheel Hub FRONT
03901 6945	90311-62001	62 x 85 x 10	HILUX RN36,39,LN36,46 (4WD)	79/10~83/	Wheel Hub FRONT
03901 3625	90311-62001	62 x 85 x 10	HILUX YN60,65,LN60,65 (4WD)	83/11~88/	Wheel Hub FRONT
03901 4277	90313-48001	48 x 62 x 9 x 24	HILUX KZN185,RZN18#,VZN18#	95/11~	Wheel Hub REAR OUTER
03901 7137	90311-66001	66 x 85 x 8 x 10	HILUX YN61,LN61 (4WD)	85/8~89/	Wheel Hub FRONT
03901 6041	90311-33085	33 x 44 x 8	HILUX RN36,39,YN36,46,60,65 (4WD)	79/10~88/	Wheel Hub FRONT DRIVE SHAFT
03901 1469	90311-66001	66 x 85 x 8 x 10	HILUX YN130,VZN130,LN13#,KZN 130 (4WD)	89/4~95/	Wheel Hub FRONT
03901 6013	90311-66001	66 x 85 x 8 x 10	HILUX RZN16#,174,LN16#,17# (4WD)	97/8~	Wheel Hub FRONT
03901 6577	90311-41008	41 x 59 x 10 x 15	HILUX LN106,109,112,13#,KZN130, YN130,VZN130	89/4~97/	Transfer FRONT OUTPUT
03901 4343	90312-95001	90 x 108 x 10 x 12	HILUX KZN185,RZN18#,VZN18#	95/11~	Wheel Hub FRONT OUTER
03901 5691	90311-38133	38 x 74 x 11	HILUX KZN130,LN108,112,130,VZ N130	90/8~95/1 1	Final Drive REAR DIFF. PINION
03901 7987	90311-33085	33 x 44 x 8	HILUX YN100,105,LN100,106 (4WD)	88/9~97/	Wheel Hub FRONT DRIVE SHAFT
03901 8195	90310-50001	50 x 70 x 9	HILUX RN#,YN#,RZN#,LN#,KZN#, VZN#	78/8~	Wheel Hub REAR INNER
03901 1953	90311-62001	62 x 85 x 10	HILUX YN100,105,LN100,106 (4WD)	88/9~97/	Wheel Hub FRONT
03901 5783	90311-40021	40 x 58 x 7.8	HILUX KZN185,RZN185,VZN185	95/11~	Transfer TRANSFER COVER
03901 1597	90311-41007	41 x 61 x 8 x 13	HILUX LN107,YN107 SSR	91/8~97/	Transfer REAR OUTPUT
03901 2675	90311-41007	41 x 61 x 8 x 13	HILUX LN16#,17#,RZN16#,174	97/8~	Transfer REAR OUTPUT
03901 6035	90311-41007	41 x 61 x 8 x 13	HILUX KZN185,RZN185,VZN185	95/11~	Transfer REAR OUTPUT
03901 2415	90311-40007	40.5 x 58 x 8	HILUX LN108,109,112,13#,KZN130, YN130,VZN130	89/4~95/6	Transfer TRANSFER COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4625	90311-40007	40.5 x 58 x 8	HILUX LN107,YN107 SSR	91/8~95/6	Transfer TRANSFER COVER
03901 8175	90311-40021	40 x 58 x 7.8	HILUX LN108,109,112,13#,KZN130, YN130,VZN130	95/6~97/	Transfer TRANSFER COVER
03901 5787	90311-41007	41 x 61 x 8 x 13	HILUX LN108,109,112,13#,KZN130, YN130,VZN130	89/4~97/	Transfer REAR OUTPUT
03901 7705	90311-40021	40 x 58 x 7.8	HILUX LN16#,173,RZN16#,174	97/8~	Transfer TRANSFER COVER
03901 1427	90311-38134	38 x 74 x 11	HILUX RN36,39,YN6#,LN36,46,6#	79/10~89/	Final Drive FRONT DIFF. PINION
03901 5409	90311-38134	38 x 74 x 11	HILUX LN107,108,109,112,13#,KZN 130,YN107,130,VZN130	89/4~96/1	Final Drive FRONT DIFF. PINION
03901 2795	90311-38047	38 x 74 x 11 x 18	HILUX LN10#,112,YN107	96/1~97/	Final Drive FRONT DIFF. PINION
03901 4321	90311-38047	38 x 74 x 11 x 18	HILUX LN16#,17#,RZN16#,174	97/8~	Final Drive FRONT DIFF. PINION
03901 4379	90311-38049	38 x 74 x 11 x 17.5	HILUX KZN185,RZN185,VZN185	95/11~	Final Drive FRONT DIFF. PINION
03901 3267	90311-38133	38 x 74 x 11	HILUX RN3#,4#,YN5#,6#,LN3#,4#, 5#,6#	78/8~88/	Final Drive REAR DIFF. PINION
03901 4941	90311-38029	38 x 55 x 7.5	HILUX YN61,130,LN108,112,130,V ZN130,KZN130	86/8~97/	Transmission (A/T) FRONT OIL PUMP
03901 2205	90316-69001	69 x 86 x 7 x 15	HILUX KZN185,RZN185,VZN185	95/11~	Wheel Hub FRONT INNER
03901 2279	90311-40021	40 x 58 x 7.8	HILUX LN107,YN107 SSR	95/6~97/	Transfer TRANSFER COVER
03901 2507	90311-32009	32 x 52 x 8	HILUX RN36,39,YN6#,LN36,46,6#	79/10~88/	Transfer INPUT
03901 2829	90311-38029	38 x 55 x 7.5	HILUX LN165,170,RZN169,174	97/8~	Transmission (A/T) FRONT OIL PUMP
03901 1919	90311-38047	38 x 74 x 11 x 18	HILUX LN100,106,YN100,105	88/9~96/1	Final Drive FRONT DIFF. PINION
03901 2111	90311-38140	38 x 58 x 11	HILUX YN10#,LN100,106,107	88/9~97/	Transfer REAR OUTPUT
03901 3557	04332-30020	Kit	HILUX LN56	83/11~88/	Transmission (A/T) REAR EXTENTION
03901 4747	90311-40001	40 x 58 x 11	HILUX RZN180,VZN180	98/7~	Transmission (A/T) REAR EXTENTION
03901 4931	90311-38029	38 x 55 x 7.5	HILUX KZN185,RZN18#,VZN18#	95/11~	Transmission (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3681	90311-32009	32 x 52 x 8	HILUX YN10#,LN100,106,107	88/9~97/	Transfer INPUT
03901 1447	90311-40007	40.5 x 58 x 8	HILUX LN108,109,112,13#,KZN130, YN130,VZN130	89/4~97/	Transfer INPUT
03901 1203	90311-41008	41 x 59 x 10 x 15	HILUX LN16#,17#,RZN16#,174	97/8~	Transfer FRONT OUTPUT
03901 4227	90311-40007	40.5 x 58 x 8	HILUX LN16#,17#,RZN16#,174	97/8~	Transfer INPUT
03901 6055	90311-40007	40.5 x 58 x 8	HILUX KZN185,RZN185,VZN185	95/11~	Transfer INPUT
03901 5977	90311-38140	38 x 58 x 11	HILUX YN10#,LN100,106,107	88/9~97/	Transfer FRONT OUTPUT
03901 2729	90311-41008	41 x 59 x 10 x 15	HILUX LN107,YN107 SSR	91/8~97/	Transfer FRONT OUTPUT
03901 7733	90311-40007	40.5 x 58 x 8	HILUX LN107,YN107 SSR	91/8~97/	Transfer INPUT
03901 6011	90311-38140	38 x 58 x 11	HILUX RN36,39,YN6#,LN36,46,6#	79/10~88/	Transfer REAR OUTPUT
03901 7893	04332-30030	Kit	HILUX YN86,LN85,RZN147,152	88/9~	Transmission (A/T) REAR EXTENTION
03901 4529	90311-41008	41 x 59 x 10 x 15	HILUX KZN185,RZN185,VZN185	95/11~	Transfer FRONT OUTPUT
03901 2405	90311-35033	35 x 55 x 9 x 15.5	IPSUM / GAIA CXM10,SXM10	96/5~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 5235	90311-85007	85 x 105 x 10	IPSUM / GAIA 3SFE SXM1#	96/5~	Engine CRANK SHAFT REAR
03901 7227	90913-02117		IPSUM / GAIA 3CTE	97/9~	Engine VALVE STEM SEAL
03901 7483	90913-02062		IPSUM / GAIA 3SFE(EX.)	96/5~	Engine VALVE STEM SEAL
03901 5589	90311-35020	35 x 63 x 9 x 15.5	IPSUM / GAIA CXM10,SXM1#	96/5~	Mission & Differential (A/T) TRANSAXLE CASE
03901 1693	90311-90008	90 x 110 x 9.5 x 11.5	IPSUM / GAIA 3CTE CXM10	97/9~	Engine CRANK SHAFT REAR
03901 5003	90311-42026	42 x 60 x 7	IPSUM / GAIA 3CTE CXM10	97/9~	Engine CRANK SHAFT FRONT
03901 4951	90311-42035	42 x 60 x 7	IPSUM / GAIA 3SFE SXM1#	96/9~	Engine CRANK SHAFT FRONT
03901 4973	90311-42026	42 x 60 x 7	IPSUM / GAIA 3SFE SXM1#	96/5~96/9	Engine CRANK SHAFT FRONT
03901 5587	15165-70010	18 x 30 x 7	IPSUM / GAIA 3SFE SXM1#	96/5~	Engine OIL PUMP
03901 3985	90311-38067	38 x 50 x 8	IPSUM / GAIA 3SFE SXM1#	97/8~	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5333	90311-38036	38 x 50 x 8	IPSUM / GAIA 3SFE SXM1#	96/5~97/8	Engine CAM SHAFT
03901 3429	04445-20161		IPSUM / GAIA SXM15	98/4~	Steering (P/S) R & PGASKET KIT
03901 8217	90913-02079		IPSUM / GAIA 3SFE(IN.)	96/5~	Engine VALVE STEM SEAL
03901 7209	90311-38044	38 x 50 x 6	IPSUM / GAIA 3CTE CXM10	97/9~	Engine CAM SHAFT
03901 6097	90311-49002	50 x 64 x 8	IPSUM / GAIA SXM15	98/4~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1777	04445-20210		IPSUM / GAIA CXM10,SXM10	96/5~	Steering (P/S) R & PGASKET KIT
03901 2141	04445-20161		IPSUM / GAIA SXM10 FRIEND MATIC	97/8~	Steering (P/S) R & PGASKET KIT
03901 2579	90311-19002	19 x 32 x 7 x 8	IPSUM / GAIA CXM10,SXM1#	96/5~	Steering (P/S) CONTROL VALVE UPPER
03901 2135	90310-25004	25 x 38 x 7 x 8	IPSUM / GAIA SXM15	96/5~	Steering (P/S) CONTROL VALVE LOWER
03901 6065	90310-25004	25 x 38 x 7 x 8	IPSUM / GAIA SXM10 FRIEND MATIC	97/8~	Steering (P/S) CONTROL VALVE LOWER
03901 5523	90310-28003	28 x 41 x 6.5	IPSUM / GAIA CXM10,SXM10	96/5~	Steering (P/S) CONTROL VALVE LOWER
03901 3929	90311-38020	38 x 55 x 8.5	IPSUM / GAIA CXM10,SXM1#	96/5~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4359	90913-02101		KLUGER-V 1MZFE,2AZFE (IN.)	00/11~	Engine VALVE STEM SEAL
03901 5677	90311-89003	89 x 105 x 10	KLUGER-V 2AZFE ACU2#	00/11~	Engine CRANK SHAFT REAR
03901 3291	90311-52005	52 x 75 x 7.5 x 12	KLUGER-V ACU25,MCU25 (4WD)	00/11~	Wheel Hub REAR OUTER
03901 2663	04445-48010		KLUGER-V ACU2#,MCU2#	00/11~	Steering (P/S) R & P GASKET KIT
03901 6685	90311-92008	92 x 110 x 9	KLUGER-V 1MZFE MCU2#	00/11~	Engine CRANK SHAFT REAR
03901 7843	90311-38059	38 x 50 x 8	KLUGER-V 2AZFE ACU2#	00/11~	Engine TIMING GEAR CASE
03901 2083	90311-40022	40 x 55 x 6	KLUGER-V 1MZFE MCU2#	00/11~	Engine OIL PUMP
03901 1519	90311-38034	38 x 50 x 10.5	KLUGER-V 1MZFE MCU2#	00/11~	Engine CAM SHAFT
03901 1149	90311-38064	38 x 8.7 x	KLUGER-V ACU2#,MCU2#	00/11~	Mission & Differential (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7387	90311-50026	50 x 68 x 9 x 15.5	KLUGER-V ACU20	00/11~	Mission & Differential (A/T) DIFF. SIDE
03901 2427	90311-50011	50 x 80 x 16.5 x 23	KLUGER-V ACU25,MCU2#	00/11~	Mission & Differential (A/T) DIFF. SIDE
03901 2653	90311-62004	62 x 74 x 8.5	KLUGER-V ACU25,MCU25 (4WD)	00/11~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3453	90311-40010	40 x 56 x 9 x 15.5	KLUGER-V MCU20	00/11~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 8157	90311-56015	56 x 75 x 7 x 12	KLUGER-V ACU25,MCU25 (4WD)	00/11~	Wheel Hub REAR INNER
03901 6203	90913-02111		KLUGER-V 1MZFE,2AZFE (	00/11~	Engine VALVE STEM SEAL
03901 5361	90311-40026	40 x 64 x 9 x 15.5	KLUGER-V ACU20	00/11~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1775	04445-35160		LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Steering (P/S) R & P GASKET KIT
03901 1771	04445-60030		LAND CRUISER BJ61,HJ6#,FJ62	84/11~87/	Steering (P/S) P/S GEAR GASKET KIT
03901 3269	90311-18010	18 x 30 x 8	LAND CRUISER FJ6#,BJ6#,7#,HJ6#	84/11~90/	Steering (M/S) WORM GEAR
03901 3203	90311-18010	18 x 30 x 8	LAND CRUISER FJ75,HZJ75	90/6~99/	Steering (M/S) WORM GEAR
03901 1173	90311-19001	19 x 32 x 8	LAND CRUISER FJ6#,BJ6#	80/8~84/1	Steering (M/S) WORM GEAR
03901 5325	90311-32014	32 x 44 x 9	LAND CRUISER FJ4#,5#,BJ4#	69/3~84/	Steering (M/S) SECTOR SHAFT
03901 7453	90311-36104	36 x 50 x 7	LAND CRUISER FJ6#,BJ6#	80/8~84/1	Steering (M/S) SECTOR SHAFT
03901 7079	90311-36004	36 x 46 x 9	LAND CRUISER FJ6#,BJ6#,7#,HJ6#	84/11~90/	Steering (M/S) SECTOR SHAFT
03901 4825	90311-36005	36 x 44 x 5	LAND CRUISER HZJ7#,KZJ7#,LJ7#,PZJ7#	90/1~	Steering (P/S) GEAR HOUSING
03901 5053	04445-60020		LAND CRUISER BJ6#,HJ60,FJ6#	80/8~84/1	Steering (P/S) P/S GEAR GASKET KIT
03901 7277	90311-38066	38 x 74 x 11 x 48	LAND CRUISER HDJ101,UZJ100	98/1~	Final Drive REAR DIFF. PINION
03901 2631	04445-60030		LAND CRUISER LJ71,BJ7#	84/11~90/	Steering (P/S) P/S GEAR GASKET KIT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2101	04445-60040		LAND CRUISER HZJ7#,LJ7#,PZJ7#	90/1~92/8	Steering (P/S) P/S GEAR GASKET KIT
03901 6207	04445-60070		LAND CRUISER HZJ7#,LJ7#,PZJ7#,KZJ7#	92/8~	Steering (P/S) P/S GEAR GASKET KIT
03901 5345	04445-60050		LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Steering (P/S) P/S GEAR GASKET KIT
03901 4157	04445-60080		LAND CRUISER HDJ101,UZJ100	98/1~	Steering (P/S) R & P GASKET KIT
03901 1005	90311-19002	19 x 32 x 7 x 8	LAND CRUISER FJ4#,6#,BJ4#,6#,7#,HJ6#,LJ7 #	80/8~90/	Steering (P/S) ADJUSTER PLUG
03901 2031	90311-50014	50 x 70 x 10 x 16	LAND CRUISER HDJ101,UZJ100	98/1~	Transfer FRONT OUTPUT
03901 6305	90311-36004	36 x 46 x 9	LAND CRUISER FJ75,HZJ75	90/6~99/	Steering (M/S) SECTOR SHAFT
03901 1959	90311-38133	38 x 74 x 11	LAND CRUISER KZJ7#,LJ7#	90/4~95/1 1	Final Drive REAR DIFF. PINION
03901 7329	90311-95008	95 x 115 x 9.5 x 12	LAND CRUISER 1PZ PZJ7#	90/1~94/	Engine CRANK SHAFT REAR
03901 4005	90311-35004	35 x 55 x 11	LAND CRUISER FJ4#,5#,BJ4#,6#,7#,HJ6#	69/3~90/	P.T.O. BEARING RETAINER
03901 4259	90311-35004	35 x 55 x 11	LAND CRUISER HZJ70,PZJ70	90/1~99/	P.T.O. BEARING RETAINER
03901 4705	90311-38134	38 x 74 x 11	LAND CRUISER FJ4#,5#,BJ4#,6#,7#,HJ6#,LJ7 #	69/3~90/	Final Drive FRONT DIFF. PINION
03901 4627	90311-38047	38 x 74 x 11 x 18	LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#,PZJ 7#	90/1~	Final Drive FRONT DIFF. PINION
03901 6467	90311-38047	38 x 74 x 11 x 18	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Final Drive FRONT DIFF. PINION
03901 3827	90311-38049	38 x 74 x 11 x 17.5	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Final Drive FRONT DIFF. PINION
03901 2369	90311-18010	18 x 30 x 8	LAND CRUISER FJ4#,5#,BJ4#	72/4~84/	Steering (M/S) WORM GEAR
03901 1219	90311-38133	38 x 74 x 11	LAND CRUISER FJ4#,5#,BJ4#,6#,7#,HJ6#,LJ7 #	69/3~90/	Final Drive REAR DIFF. PINION
03901 1369	90311-18021	18 x 32 x 7	LAND CRUISER FJ55	69/3~72/4	Steering (M/S) WORM GEAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1029	90311-38047	38 x 74 x 11 x 18	LAND CRUISER KZJ7#,LJ7#...WITH DIFF. LOCK	90/4~95/12	Final Drive REAR DIFF. PINION
03901 4103	90311-38047	38 x 74 x 11 x 18	LAND CRUISER KZJ7#	95/11~96/	Final Drive REAR DIFF. PINION
03901 3755	90311-38047	38 x 74 x 11 x 18	LAND CRUISER FJ75,HZJ7#,PZJ7#	90/1~98/1	Final Drive REAR DIFF. PINION
03901 1127	90311-38047	38 x 74 x 11 x 18	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Final Drive REAR DIFF. PINION
03901 7673	90311-38047	38 x 74 x 11 x 18	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Final Drive REAR DIFF. PINION
03901 3551	90311-38066	38 x 74 x 11 x 48	LAND CRUISER HZJ7#	98/1~	Final Drive REAR DIFF. PINION
03901 2625	90311-36005	36 x 44 x 5	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Steering (P/S) GEAR HOUSING
03901 4971	90311-38066	38 x 74 x 11 x 48	LAND CRUISER HDJ101,UZJ100	98/1~	Final Drive FRONT DIFF. PINION
03901 7881	90311-43006	43 x 60 x 7	LAND CRUISER 2UZFE UZJ100	98/1~	Engine OIL PUMP
03901 5811	90311-48020	48 x 68 x 7	LAND CRUISER 3RZFE RZJ9#	97/4~	Engine TIMING GEAR CASE
03901 6735	90312-32001	32 x 42 x 5	LAND CRUISER FJ4#,BJ4#	81/10~84/	Steering (P/S) GEAR HOUSING
03901 1979	90311-32020	32 x 46 x 6	LAND CRUISER 2L LJ7#	90/4~93/	Engine CAM SHAFT
03901 1609	90311-32020	32 x 46 x 6	LAND CRUISER 1K#...KZJ7#,9#,KDJ9#	93/5~	Engine CAM SHAFT
03901 7167	90311-32020	32 x 46 x 6	LAND CRUISER 1H#...HZJ7#,81,HDJ81,101	90/1~	Engine CAM SHAFT
03901 2709	90311-38051	38 x 50 x 10	LAND CRUISER 5VZFE VZJ9#	96/4~	Engine CAM SHAFT
03901 4721	90312-32002	32 x 40 x 5	LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7#	80/8~90/	Steering (P/S) GEAR HOUSING
03901 1931	90311-40022	40 x 55 x 6	LAND CRUISER 5VZFE VZJ9#	96/4~	Engine OIL PUMP
03901 1899	90311-58007	58.5 x 75 x 9 x 14.5	LAND CRUISER 1PZ PZJ7#	90/1~94/	Engine TIMING GEAR COVER (NO.2)
03901 3147	90311-99065	100 x 120 x 11	LAND CRUISER F,2F,3F FJ4#,5#,6#	69/3~85/6	Engine CRANK SHAFT REAR
03901 1605	90311-99005	105 x 120 x 11	LAND CRUISER 3F FJ6#,75,80	85/6~92/	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6699	90311-99009	99 x 119 x 9.5	LAND CRUISER 1FZFE FZJ80	92/8~98/	Engine CRANK SHAFT REAR
03901 5267	90311-95001	95 x 115 x 12	LAND CRUISER B,2B,3B,13B BJ4#,6#,7#	74/2~88/8	Engine CRANK SHAFT REAR
03901 4367	90311-95001	95 x 115 x 12	LAND CRUISER 2H,12H HJ6#	82/10~90/	Engine CRANK SHAFT REAR
03901 5505	90311-95008	95 x 115 x 9.5 x 12	LAND CRUISER 3B,13B BJ7#	88/8~90/	Engine CRANK SHAFT REAR
03901 4613	90311-95008	95 x 115 x 9.5 x 12	LAND CRUISER 1H#...HZJ7#,81,HDJ81,101	90/1~	Engine CRANK SHAFT REAR
03901 7405	90311-38065	38 x 85 x 10	LAND CRUISER 2UZFE UZJ100	98/1~	Engine CAM SHAFT
03901 6643	90311-50013	50 x 72 x 9 x 14	LAND CRUISER 3B,13B BJ7#	88/8~90/	Engine TIMING GEAR COVER
03901 4785	90311-19002	19 x 32 x 7 x 8	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Steering (P/S) CONTROL VALVE UPPER
03901 1291	90311-19002	19 x 32 x 7 x 8	LAND CRUISER HDJ101,UZJ100	98/1~	Steering (P/S) CONTROL VALVE UPPER
03901 1755	90310-25004	25 x 38 x 7 x 8	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Steering (P/S) CONTROL VALVE LOWER
03901 7873	90310-25004	25 x 38 x 7 x 8	LAND CRUISER HDJ101,UZJ100	98/1~	Steering (P/S) CONTROL VALVE LOWER
03901 3761	90311-45002	45 x 68 x 12	LAND CRUISER F,2F FJ4#,5#,6#	69/3~84/10	Engine TIMING GEAR COVER
03901 3777	90311-45008	45 x 68 x 8.5	LAND CRUISER 2F,3F FJ6#,75,80	84/10~92/	Engine TIMING GEAR COVER
03901 5389	90311-52013	52 x 70 x 8.5	LAND CRUISER 1FZFE FZJ80	92/8~98/	Engine TIMING GEAR COVER
03901 5043	90311-50017	50 x 68 x 9 x 14.5	LAND CRUISER 1K#...KZJ7#,9#,KDJ9#	93/5~	Engine TIMING GEAR CASE
03901 5173	90311-50006	50 x 72 x 12	LAND CRUISER 2H,12H HJ6#	82/10~90/	Engine TIMING GEAR COVER
03901 6507	90311-42003	42 x 60 x 7	LAND CRUISER 2L LJ7#	85/10~93/	Engine TIMING GEAR CASE
03901 1123	90311-58006	58 x 72 x 7	LAND CRUISER 1HZ,1HD#...HZJ7#,81,HDJ81	90/1~	Engine TIMING GEAR COVER (NO.1)
03901 2559	90311-58006	58 x 72 x 7	LAND CRUISER 1PZ PZJ7#	90/1~94/	Engine TIMING GEAR COVER (NO.1)
03901 2169	90311-65003	65 x 79 x 7	LAND CRUISER 1HDFTE HDJ101	98/1~	Engine TIMING GEAR COVER (NO.1)

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7595	90311-58006	58 x 72 x 7	LAND CRUISER 1KZTE KZJ7#,9#	93/5~00/	Engine TIMING GEAR COVER
03901 3539	90311-65003	65 x 79 x 7	LAND CRUISER 1KDFTV KDJ9#	00/8~	Engine TIMING GEAR COVER
03901 2167	90311-58007	58.5 x 75 x 9 x 14.5	LAND CRUISER 1HZ,1HD#...HZJ7#,81,HDJ8 1,101	90/1~	Engine TIMING GEAR COVER (NO.2)
03901 2061	90311-50014	50 x 70 x 10 x 16	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Transfer FRONT OUTPUT
03901 4467	90311-50006	50 x 72 x 12	LAND CRUISER B,2B,3B,13B BJ4#,6#,7#	74/2~88/8	Engine TIMING GEAR COVER
03901 5435	90313-62001	62 x 81 x 7.5 x 17.5	LAND CRUISER HDJ101,UZJ100	98/1~	Wheel Hub REAR OUTER
03901 5651	90310-35001	35 x 41 x 5.5 x 9	LAND CRUISER FZ56,BJ4#...FULL FLOATING AXLE	79/9~84/	Wheel Hub REAR OUTER
03901 5001	90310-35001	35 x 41 x 5.5 x 9	LAND CRUISER FJ6#,BJ6#,7#,HJ6# FULL FLOATING AXLE	80/8~90/	Wheel Hub REAR OUTER
03901 2143	90310-35001	35 x 41 x 5.5 x 9	LAND CRUISER FJ75,HZJ7#,PZJ7#...FULL FLOATING AXLE	90/1~97/1 2	Wheel Hub REAR OUTER
03901 2517	90310-35001	35 x 41 x 5.5 x 9	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81 FULL FLOATING AXLE	90/1~98/	Wheel Hub REAR OUTER
03901 6761	90310-36003	36 x 41 x 5.5 x 9	LAND CRUISER HZJ7#	97/12~	Wheel Hub REAR OUTER
03901 3209	90313-48001	48 x 62 x 9 x 24	LAND CRUISER LJ7#	85/10~90/ 4	Wheel Hub REAR OUTER
03901 4083	90310-50001	50 x 70 x 9	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Wheel Hub REAR INNER
03901 8251	90313-48004	48 x 75 x 83.7 x 18	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Wheel Hub REAR OUTER
03901 2657	90311-47001	47.5 x 70.6 x 9	LAND CRUISER FJ6#,BJ6#,7#,HJ6# SEMI FLOATING AXLE	80/8~90/	Wheel Hub REAR OUTER
03901 8179	90311-62001	62 x 85 x 10	LAND CRUISER FJ56,BJ4#...FULL FLOATING AXLE	79/9~84/	Wheel Hub REAR INNER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7147	90311-62001	62 x 85 x 10	LAND CRUISER FJ6#,BJ6#,7#,HJ6# FULL FLOATING AXLE	80/8~90/	Wheel Hub REAR INNER
03901 3917	90311-62001	62 x 85 x 10	LAND CRUISER FJ75,HZJ7#,PZJ7#...DRUM BRAKE	90/1~	Wheel Hub REAR INNER
03901 6415	90311-62001	62 x 85 x 10	LAND CRUISER HZJ81,FZJ80 DRUM BRAKE	90/1~98/	Wheel Hub REAR INNER
03901 3505	90311-62002	62 x 85 x 8 x 17	LAND CRUISER HZJ7#...DISC BRAKE	90/1~	Wheel Hub REAR INNER
03901 1137	90311-62002	62 x 85 x 8 x 17	LAND CRUISER FJ80,FZJ80,HZJ81 DISC BRAKE	90/1~98/	Wheel Hub REAR INNER
03901 1905	90311-41008	41 x 59 x 10 x 15	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Transfer FRONT OUTPUT
03901 7885	90313-48004	48 x 75 x 83.7 x 18	LAND CRUISER KZJ7#,LJ7#	90/4~96/	Wheel Hub REAR OUTER
03901 2937	90311-33085	33 x 44 x 8	LAND CRUISER FJ4#,5#,BJ4#	69/3~84/	Wheel Hub FRONT DRIVE SHAFT
03901 4117	90312-55010	55 x 82 x 10	LAND CRUISER FJ4#,5#,BJ4#	69/3~75/9	Wheel Hub FRONT INNER
03901 5147	90311-62001	62 x 85 x 10	LAND CRUISER FJ4#,5#,BJ4#	75/9~84/	Wheel Hub FRONT INNER
03901 1981	90311-62001	62 x 85 x 10	LAND CRUISER FJ6#,BJ6#,HJ6#	80/8~90/	Wheel Hub FRONT INNER
03901 6853	90311-62001	62 x 85 x 10	LAND CRUISER BJ7#,LJ7#,FJ75,HZJ7#,KZJ7 #,PZJ7#	84/11~	Wheel Hub FRONT INNER
03901 2599	90311-62001	62 x 85 x 10	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Wheel Hub FRONT INNER
03901 6047	90316-69001	69 x 86 x 7 x 15	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Wheel Hub FRONT INNER
03901 3687	90311-70011	70 x 94 x 8 x 10.5	LAND CRUISER HD101,UZJ100	98/1~	Wheel Hub FRONT INNER
03901 5653	90311-47001	47.5 x 70.6 x 9	LAND CRUISER FZJ80,HZJ81 SEMI FLOATING AXLE	90/1~98/	Wheel Hub REAR OUTER
03901 7689	90312-95001	90 x 108 x 10 x 12	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Wheel Hub FRONT OUTER
03901 2603	90311-47001	47.5 x 70.6 x 9	LAND CRUISER HZJ7#,PZJ7#...SEMI FLOATING AXLE	90/1~99/	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5551	90311-33085	33 x 44 x 8	LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7#	80/8~90/1	Wheel Hub FRONT DRIVE SHAFT
03901 5883	90310-35005	35 x 50 x 9.5	LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#,PZJ7#	90/1~	Wheel Hub FRONT DRIVE SHAFT
03901 4057	90310-35005	35 x 50 x 9.5	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Wheel Hub FRONT DRIVE SHAFT
03901 7443	90311-47029	47.6 x 70.6 x 13.5	LAND CRUISER FJ4#,5#	69/3~73/8	Wheel Hub REAR OUTER
03901 2797	90311-47001	47.5 x 70.6 x 9	LAND CRUISER FJ4#,5#,BJ4#	73/8~74/11	Wheel Hub REAR OUTER
03901 6985	90311-47001	47.5 x 70.6 x 9	LAND CRUISER FJ4#,5#,BJ4#...SEMI FLOATING AXLE	74/11~84/	Wheel Hub REAR OUTER
03901 2705	90310-58002	58 x 70 x 7	LAND CRUISER KZJ7#,LJ7#	90/1~96/	Wheel Hub REAR INNER
03901 4361	90311-62003	62 x 74 x 8	LAND CRUISER HZJ7#,PZJ7#,KZJ7#,LZJ7#... POWER LOCKING HUB	90/1~99/	Wheel Hub FRONT OUTER
03901 2851	90311-48010	48 x 62 x 8 x 13	LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#.PZJ7#	90/1~	Transfer REAR OUTPUT
03901 7865	90316-48003	48 x 72 x 11	LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#,PZJ7#	90/1~	Transfer INPUT
03901 7765	90311-48003	48 x 62 x 8	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~96/5	Transfer INPUT
03901 3683	90311-48018	48 x 62 x 9	LAND CRUISER FZJ80,HDJ81,HZJ81	96/5~98/	Transfer INPUT
03901 6657	90311-48018	48 x 62 x 9	LAND CRUISER HDJ101,UZJ100	98/1~	Transfer INPUT
03901 4883	90311-40021	40 x 58 x 7.8	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Transfer INPUT
03901 8219	90311-45001	45 x 62 x 9	LAND CRUISER FJ4#,5#,BJ4#	69/3~80/7	Transfer REAR OUTPUT
03901 6717	90310-50001	50 x 70 x 9	LAND CRUISER LJ7#	85/10~90/4	Wheel Hub REAR INNER
03901 6249	90311-48010	48 x 62 x 8 x 13	LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7#	84/11~90/	Transfer REAR OUTPUT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2799	90311-48002	48 x 74 x 10	LAND CRUISER FJ4#,5#,BJ4#,6#	80/8~82/1 0	Transfer INPUT
03901 3425	90311-58008	50 x 70 x 16	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Transfer REAR OUTPUT
03901 7903	90311-58008	50 x 70 x 16	LAND CRUISER HDJ101,UZJ100	98/1~	Transfer REAR OUTPUT
03901 8063	90311-40007	40.5 x 58 x 8	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Transfer REAR OUTPUT
03901 1161	90311-45001	45 x 62 x 9	LAND CRUISER FJ4#,5#,BJ4#	69/3~80/7	Transfer FRONT OUTPUT
03901 4559	90311-48002	48 x 74 x 10	LAND CRUISER FJ4#,5#,BJ4#,6#,HJ6#	80/8~84/1 1	Transfer FRONT OUTPUT
03901 2807	90311-48009	48 x 74 x 10 x 15	LAND CRUISER FJ6#,BJ6#,7#,HJ6#,LJ7#	84/11~90/	Transfer FRONT OUTPUT
03901 7113	90311-48009	48 x 74 x 10 x 15	LAND CRUISER FJ75,HZJ7#,KZJ7#,LJ7#.PZJ 7#	90/1~	Transfer FRONT OUTPUT
03901 4901	90311-48003	48 x 62 x 8	LAND CRUISER FJ4#,5#,BJ4#,6#,HJ6#	80/8~84/1 1	Transfer REAR OUTPUT
03901 3337	90311-35023	35 x 48 x 6.5	LAND CRUISER HDJ101	98/1~	Transmission (M/T) FRONT COVER
03901 7059	90310-58002	58 x 70 x 7	LAND CRUISER HDJ101,UZJ100	98/1~	Wheel Hub REAR INNER
03901 5807	90311-28004	28.6 x 43 x 6.5	LAND CRUISER FJ4#,5#,BJ4#	69/3~84/	Transmission (M/T) FRONT COVER
03901 1195	90311-28004	28.6 x 43 x 6.5	LAND CRUISER FJ6#,BJ6#,7#,HJ6#	80/8~85/1 0	Transmission (M/T) FRONT COVER
03901 3489	90311-32013	32 x 48 x 7	LAND CRUISER FJ6#,BJ6#,7#,HJ6#	85/10~90/	Transmission (M/T) FRONT COVER
03901 2893	90311-32013	32 x 48 x 7	LAND CRUISER FJ75,HZJ7#	90/1~99/8	Transmission (M/T) FRONT COVER
03901 2995	90311-32012	32 x 53 x 7	LAND CRUISER LJ7#,KZJ7#,PZJ7#	85/10~99/	Transmission (M/T) FRONT COVER
03901 1047	90311-32012	32 x 53 x 7	LAND CRUISER HZJ71,74,76,79	99/8~	Transmission (M/T) FRONT COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2087	90316-48003	48 x 72 x 11	LAND CRUISER FJ62,HJ6#,BJ7#,LJ7#	88/1~90/	Transfer INPUT
03901 1423	90311-35023	35 x 48 x 6.5	LAND CRUISER FZJ80,HZJ81,HDJ81	90/1~98/	Transmission (M/T) FRONT COVER
03901 1299	90311-48012	48 x 72 x 8.5	LAND CRUISER FJ4#,5#,BJ4#,6#,7#,HJ6#,LJ7 #	82/10~88/ 1	Transfer INPUT
03901 2767	90311-38029	38 x 55 x 7.5	LAND CRUISER KZJ7#,LJ7#	90/4~96/	Transmission (A/T) FRONT OIL PUMP
03901 2071	90311-38029	38 x 55 x 7.5	LAND CRUISER KDJ9#,KZJ9#,RZJ9#,VZJ9#	96/4~	Transmission (A/T) FRONT OIL PUMP
03901 4085	90311-42010	42 x 60 x 8.5	LAND CRUISER HZJ7#	90/1~	Transmission (A/T) FRONT OIL PUMP
03901 5707	90311-42010	42 x 60 x 8.5	LAND CRUISER FJ80,FZJ80,HDJ81,HZJ81	90/1~98/	Transmission (A/T) FRONT OIL PUMP
03901 6153	90311-42010	42 x 60 x 8.5	LAND CRUISER HDJ101,UZJ100	98/1~	Transmission (A/T) FRONT OIL PUMP
03901 3629	90311-42014	42 x 60 x 9	LAND CRUISER FJ4#,5#,BJ4#	69/3~80/7	Transfer INPUT
03901 1927	90311-32020	32 x 46 x 6	LAND CRUISER 1PZ PZJ7#	90/1~94/	Engine CAM SHAFT
03901 2963	90311-32012	32 x 53 x 7	LAND CRUISER KDJ9#,KZJ9#,VZJ90	96/4~	Transmission (M/T) FRONT COVER
03901 6795	90913-02096		LAND CRUISER 1HDFTE HDJ81,101	95/1~	Engine VALVE STEM SEAL
03901 2569	90913-02110		LAND CRUISER 2L LJ7#	90/4~93/	Engine VALVE STEM SEAL
03901 3881	90913-02110		LAND CRUISER 1KZTE KZJ7#,9#	93/5~97/1 0	Engine VALVE STEM SEAL
03901 7457	90913-02117		LAND CRUISER 1KZTE KZJ9#	97/10~00/	Engine VALVE STEM SEAL
03901 5875	90913-02121		LAND CRUISER 1KDFTV KDJ9#	00/8~	Engine VALVE STEM SEAL
03901 5277	90913-02094		LAND CRUISER 1PZ PZJ7#	90/1~94/	Engine VALVE STEM SEAL
03901 1787	90913-02094		LAND CRUISER 1HZ HZJ7#,81	90/1~97/7	Engine VALVE STEM SEAL
03901 6777	90913-02060		LAND CRUISER 2L LJ7#	85/10~90/ 3	Engine VALVE STEM SEAL
03901 4049	90913-02094		LAND CRUISER 1HDT HDJ81	90/1~95/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4305	90913-02095		LAND CRUISER 5VZFE (IN.) VZJ9#	96/4~	Engine VALVE STEM SEAL
03901 3885	90913-02079		LAND CRUISER 3RZFE (IN.) RZJ9#	97/4~	Engine VALVE STEM SEAL
03901 2725	90913-02062		LAND CRUISER 3RZFE (EX.) RZJ9#	97/4~	Engine VALVE STEM SEAL
03901 3841	90913-02062		LAND CRUISER 5VZFE (EX.) VZJ9#	96/4~	Engine VALVE STEM SEAL
03901 6307	90913-02112		LAND CRUISER 2UZFE (EX.) UZJ100	98/1~	Engine VALVE STEM SEAL
03901 2587	90311-42003	42 x 60 x 7	LAND CRUISER 2L LJ7#	85/10~90/4	Engine CAM SHAFT
03901 2519	90311-95008	95 x 115 x 9.5 x 12	LAND CRUISER 1K#...KZJ7#,9#,KDJ9#	93/5~	Engine CRANK SHAFT REAR
03901 3719	90913-02094		LAND CRUISER 1HZ HZJ7#,81	97/7~	Engine VALVE STEM SEAL
03901 4827	90311-92006	92 x 110 x 9.5	LAND CRUISER 5VZFE VZJ9#	96/4~	Engine CRANK SHAFT REAR
03901 7201	90311-85007	85 x 105 x 10	LAND CRUISER 2L LJ7#	91/2~93/	Engine CRANK SHAFT REAR
03901 4765	90913-02113		LAND CRUISER 2UZFE (IN.) UZJ100	98/1~	Engine VALVE STEM SEAL
03901 3155	90913-02050		LAND CRUISER 2H,12H HJ6#	82/10~90/	Engine VALVE STEM SEAL
03901 3715	90311-85004	85 x 105 x 10	LAND CRUISER 2L LJ7#	85/10~91/2	Engine CRANK SHAFT REAR
03901 6391	90311-88005	88 x 106 x 8.5	LAND CRUISER 3RZFE RZJ9#	97/4~	Engine CRANK SHAFT REAR
03901 7545	90311-95012	95 x 113 x 8.5	LAND CRUISER 2UZFE UZJ100	98/1~	Engine CRANK SHAFT REAR
03901 5957	90913-02017		LAND CRUISER F,2F FJ4#,5#	69/3~76/8	Engine VALVE STEM SEAL
03901 6771	90913-02033		LAND CRUISER 2F FJ5#	76/8~80/7	Engine VALVE STEM SEAL
03901 1229	90913-02096		LAND CRUISER 1FZFE (IN.) FZJ80	92/8~98/	Engine VALVE STEM SEAL
03901 1365	90913-02105		LAND CRUISER 1FZFE (EX.) FZJ80	92/8~98/	Engine VALVE STEM SEAL
03901 2583	90913-02044		LAND CRUISER B (EX.) BJ4#	74/2~76/1	Engine VALVE STEM SEAL
03901 3043	90913-02076		LAND CRUISER 3B,13B BJ7#	88/8~90/	Engine VALVE STEM SEAL
03901 8107	90913-02028		LAND CRUISER B (IN.) BJ4#	74/2~76/1	Engine VALVE STEM SEAL
03901 7437	90913-02028		LAND CRUISER B (IN. & EX.) BJ4#	76/1~80/7	Engine VALVE STEM SEAL
03901 5871	90913-02042		LAND CRUISER 2F,3F FJ6#,75,80	80/8~92/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2177	90913-02051		LAND CRUISER 2B,3B,13B BJ4#,6#,7#	80/7~88/8	Engine VALVE STEM SEAL
03901 6815	90311-38032	38 x 58 x 11	LITE ACE KM51,YM55,CM5#,...5H,5F	88/8~96/	Transmission (M/T) REAR EXTENTION
03901 2187	90311-42003	42 x 60 x 7	LITE ACE 1YU,2Y#...YM2#,3#,40,55,6 0	82/10~87/ 6	Engine TIMING GEAR COVER
03901 2751	90311-38032	38 x 58 x 11	LITE ACE KM3#,YM3#,CM3#,...5H,5F	88/8~92/	Transmission (M/T) REAR EXTENTION
03901 1083	90311-19001	19 x 32 x 8	LITE ACE KM2#,TM20,YM2#,CM2#	79/10~85/	Steering (M/S) WORM GEAR
03901 1929	90311-38043	38 x 58 x 11	LITE ACE KM5#,YM55 4H	88/8~89/1 0	Transmission (M/T) REAR EXTENTION
03901 3005	90311-38043	38 x 58 x 11	LITE ACE KM3#,YM30,CM3#,...5H,5F	85/9~88/8	Transmission (M/T) REAR EXTENTION
03901 8143	90311-38032	38 x 58 x 11	LITE ACE KM5#,YM55 4H	89/10~90/	Transmission (M/T) REAR EXTENTION
03901 4301	90311-38043	38 x 58 x 11	LITE ACE KM30,35,36 4H	85/9~90/8	Transmission (M/T) REAR EXTENTION
03901 3889	90311-38043	38 x 58 x 11	LITE ACE KM2#,TM20,YM2#,CM2#	79/10~85/	Transmission (M/T) REAR EXTENTION
03901 5089	90311-38043	38 x 58 x 11	LITE ACE KM55,YM55,CM50,55	86/10~88/ 8	Transmission (M/T) REAR EXTENTION
03901 5485	90311-38032	38 x 58 x 11	LITE ACE KM7#,CM7#	99/6~	Transmission (M/T) REAR EXTENTION
03901 4637	90311-38020	38 x 55 x 8.5	LITE ACE KM3#,51,7#,YM3#,40,55,C M3#,40,5#,7#,85	85/9~	Transmission (A/T) FRONT OIL PUMP
03901 6225	04332-30020	Kit	LITE ACE KM3#,51,YM3#,55,CM3#,51 ,55	85/9~87/1 1	Transmission (A/T) REAR EXTENTION
03901 1429	04332-30030	Kit	LITE ACE KM3#,51,YM3#,55,CM3#,51 ,55	87/11~99/	Transmission (A/T) REAR EXTENTION
03901 6309	90311-38133	38 x 74 x 11	LITE ACE KM2#,3#,TM20,YM2#,3#,40 ,CM2#,3#,4#	79/10~92/	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2137	90311-38133	38 x 74 x 11	LITE ACE KM5#,YM55,6#,CM5#,6#	86/10~95/ 12	Final Drive REAR DIFF. PINION
03901 3333	90311-38133	38 x 74 x 11	LITE ACE KM7#,CM7#	99/6~	Final Drive REAR DIFF. PINION
03901 4893	90311-38047	38 x 74 x 11 x 18	LITE ACE CM52,6#,YM6#	95/12~99/	Final Drive REAR DIFF. PINION
03901 2877	90311-38047	38 x 74 x 11 x 18	LITE ACE KM8#,CM8#	99/6~	Final Drive REAR DIFF. PINION
03901 1351	90311-30014	30 x 45 x 8	LITE ACE KM73,8#,CM7#,8#	99/6~	Transmission (M/T) FRONT COVER
03901 2619	90311-48001	48 x 62 x 9	LITE ACE KM7#,CM7#	99/6~	Wheel Hub FRONT
03901 1627	90311-38133	38 x 74 x 11	LITE ACE KM51,YM55,CM51,55	95/12~99/	Final Drive REAR DIFF. PINION
03901 4307	90311-62001	62 x 85 x 10	LITE ACE CM52,61	91/10~99/	Wheel Hub REAR
03901 7647	90311-48122	48 x 62 x 7	LITE ACE KM2#,TM2#,YM2#,CM2#	79/10~83/ 5	Wheel Hub FRONT
03901 7713	90311-48001	48 x 62 x 9	LITE ACE KM21,YM2#,CM2#	83/5~85/	Wheel Hub FRONT
03901 7815	90311-48001	48 x 62 x 9	LITE ACE KM3#,YM3#,CM3#	85/9~92/	Wheel Hub FRONT
03901 7571	90311-48001	48 x 62 x 9	LITE ACE KM5#,YM55,CM50,51,55	86/10~99/	Wheel Hub FRONT
03901 4155	90311-66002	66 x 80 x 9	LITE ACE YM40,CM4# (4WD)	85/10~92/	Wheel Hub FRONT
03901 8101	90311-61001	61 x 76 x 7 x 10	LITE ACE KM8#,CM8# (4WD)	99/6~	Wheel Hub FRONT OUTER
03901 6963	90311-56014	56 x 78 x 7.5 x 13	LITE ACE KM8#,CM8# (4WD)	99/6~	Wheel Hub FRONT INNER
03901 5335	90311-52059	52 x 65 x 9	LITE ACE KM2#,TM20,YM20,21,CM2 0 SINGLE TIRE	79/10~85/	Wheel Hub REAR
03901 2715	90311-52059	52 x 65 x 9	LITE ACE KM3#,YM3#,40,CM3#,4#	85/9~92/	Wheel Hub REAR
03901 3049	90311-66002	66 x 80 x 9	LITE ACE YM6#,CM52,6# (4WD)	86/10~99/	Wheel Hub FRONT
03901 7481	90311-52059	52 x 65 x 9	LITE ACE KM7#,8#,CM7#,8#	99/6~	Wheel Hub REAR
03901 5761	90311-30014	30 x 45 x 8	LITE ACE KM51,YM55,6#,CM5#,63	90/7~99/	Transmission (M/T) FRONT COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5777	90311-58001	58 x 78 x 8	LITE ACE KM2#,YM20,25,CM2#...DO UBLE TIRE	79/10~85/	Wheel Hub REAR INNER
03901 3565	90310-29001	29 x 38 x 7 x 12	LITE ACE KM2#,YM20,25,CM2#...DO UBLE TIRE	79/10~85/	Wheel Hub REAR OUTER
03901 4773	90311-32106	32 x 48 x 8	LITE ACE KM2#,TM20,YM25 4H,4F	79/10~85/	Transmission (M/T) FRONT COVER
03901 3093	90311-32106	32 x 48 x 8	LITE ACE KM30,35,36 4H	85/9~90/8	Transmission (M/T) FRONT COVER
03901 4341	90311-32106	32 x 48 x 8	LITE ACE KM5#,YM55 4H	86/10~90/ 8	Transmission (M/T) FRONT COVER
03901 4603	90311-30115	30 x 45 x 8	LITE ACE TM20,YM20,21,CM2#...5H,5 F	81/1~85/	Transmission (M/T) FRONT COVER
03901 4921	90311-30115	30 x 45 x 8	LITE ACE KM30,36 5F,CM3#,4#,KM31,YM30,40	85/9~90/7	Transmission (M/T) FRONT COVER
03901 5539	90311-30115	30 x 45 x 8	LITE ACE KM51,CM5#,6#...5F,5H,YM 60	86/10~90/ 7	Transmission (M/T) FRONT COVER
03901 8113	90311-30014	30 x 45 x 8	LITE ACE KM3#,YM3#,40,CM33,4#...5 H,5F	90/7~92/	Transmission (M/T) FRONT COVER
03901 6821	90311-52059	52 x 65 x 9	LITE ACE KM5#,YM55,6#,CM50,51,55 ,60,65	86/10~99/	Wheel Hub REAR
03901 1319	90913-02056		LITE ACE 4KJ,5K#...KM2#,3#,5#	81/2~95/8	Engine VALVE STEM SEAL
03901 6585	90311-42015	42 x 60 x 6	LITE ACE 1C,2C#...CM3#,4#,5#,6#	85/5~90/1 0	Engine CRANK SHAFT FRONT
03901 2711	90311-42026	42 x 60 x 7	LITE ACE 2C#,3CE CM5#,6#,7#,8#	90/10~	Engine CRANK SHAFT FRONT
03901 7645	90311-70004	70 x 92 x 8.5	LITE ACE 4KJ,5K#...KM2#,3#,5#	79/10~97/ 5	Engine CRANK SHAFT REAR
03901 1853	90311-70007	70 x 92 x 8.5	LITE ACE 5K,7KE KM51,7#,8#	97/5~	Engine CRANK SHAFT REAR
03901 7005	90311-75114	75 x 100 x 13	LITE ACE 13TU TM20	79/10~82/	Engine CRANK SHAFT REAR
03901 2429	90311-80003	80 x 100 x 8.5	LITE ACE 1YU,2Y#...YM2#,3#,40,55,6 0	82/10~90/ 4	Engine CRANK SHAFT REAR
03901 6745	90311-80009	80 x 100 x 10	LITE ACE 2Y#,3YU YM3#,40,55,6#	90/4~99/	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5253	90311-90003	90 x 110 x 8.5 x 10	LITE ACE 1C,2C#...CM2#,3#,4#,5#,6#	82/10~90/ 2	Engine CRANK SHAFT REAR
03901 1687	90311-42003	42 x 60 x 7	LITE ACE 1C CM2#	82/10~85/ 5	Engine CRANK SHAFT FRONT
03901 4455	90311-90008	90 x 110 x 9.5 x 11.5	LITE ACE 2C#,3CE CM5#,6#,7#,8#	90/11~	Engine CRANK SHAFT REAR
03901 7635	90913-02024		LITE ACE 4KJ	79/10~81/ 2	Engine VALVE STEM SEAL
03901 4483	90913-02024		LITE ACE 13TU(IN. & EX.)	79/10~81/ 1	Engine VALVE STEM SEAL
03901 1209	90913-02024		LITE ACE 13TU(IN.)	81/1~82/	Engine VALVE STEM SEAL
03901 3977	90913-02058		LITE ACE 13TU(EX.)	81/1~82/	Engine VALVE STEM SEAL
03901 2601	90913-02094		LITE ACE 1Y,2Y,3Y YM2#,30,40,55,6#	82/10~99/	Engine VALVE STEM SEAL
03901 4339	90913-02110		LITE ACE 1C,2C#...CM2#,3#,4#,5#,6#	82/10~97/ 4	Engine VALVE STEM SEAL
03901 2215	90913-02117		LITE ACE 2C,3CE CM53,6#,7#,8#	97/4~	Engine VALVE STEM SEAL
03901 6193	90311-38086	38 x 58 x 7.5	LITE ACE 5K KM51	97/5~99/	Engine TIMING GEAR COVER
03901 7599	90310-28027	28 x 40 x 8	LITE ACE KM2#,TM20,YM2#,CM2#	79/10~85/	Steering (M/S) SECTOR SHAFT
03901 2499	90311-90005	90 x 110 x 8.5 x 10	LITE ACE 2C#...CM5#,6#	90/2~90/1 1	Engine CRANK SHAFT REAR
03901 3639	90311-19002	19 x 32 x 7 x 8	LITE ACE CM7#,8#,KM7#,8#	99/6~	Steering (P/S) CONTROL VALVE UPPER
03901 4335	90913-02094		LITE ACE 5K,7KE KM51,7#,8#	95/8~	Engine VALVE STEM SEAL
03901 2085	90029-21022	22 x 34 x 6.5	LITE ACE 2C#...CM5#,6#	89/5~93/8	Engine OIL PUMP
03901 1747	04445-27020		LITE ACE CM50,51,55,60,65,KM51,Y M55,6#	88/7~99/	Steering (P/S) R & P GASKET KIT
03901 5823	04445-27060		LITE ACE CM7#,8#,KM7#,8#	99/6~	Steering (P/S) R & P GASKET KIT
03901 4371	90311-19002	19 x 32 x 7 x 8	LITE ACE YM2#,CM2#	82/10~85/	Steering (P/S) ADJUSTER PLUG
03901 7523	90311-19002	19 x 32 x 7 x 8	LITE ACE CM3#,4#,5#,6#,KM3#,51,Y M30,40,55,6#	85/9~99/	Steering (P/S) CONTROL VALVE UPPER
03901 5047	90311-15001	15 x 25 x 7	LITE ACE KM3#,5#,CM3#,5#,YM55	85/9~99/	Steering (M/S) RACK HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1737	90310-25004	25 x 38 x 7 x 8	LITE ACE CM3#,4#,5#,6#,KM3#,51,Y M30,40,55,6#	85/9~99/	Steering (P/S) CONTROL VALVE LOWER
03901 6113	90310-25004	25 x 38 x 7 x 8	LITE ACE CM7#,8#,KM7#,8#	99/6~	Steering (P/S) CONTROL VALVE LOWER
03901 6575	90311-38013	38.5 x 58 x 11	LITE ACE 13TU TM20	79/10~82/	Engine TIMING GEAR COVER
03901 2277	90311-38044	38 x 50 x 6	LITE ACE 3CE CE7#,8#	99/6~	Engine CAM SHAFT
03901 3909	90029-21020	20 x 32 x 5	LITE ACE 1C,2C#...CM2#,3#,4#,5#,6#	85/5~89/5	Engine OIL PUMP
03901 3305	90312-30001	30 x 38 x 5	LITE ACE YM2#,CM2#	82/10~85/	Steering (P/S) GEAR HOUSING
03901 5863	15165-64010	20 x 32 x 7	LITE ACE 1C CM2#	82/10~85/ 5	Engine OIL PUMP
03901 7073	90311-38013	38.5 x 58 x 11	LITE ACE 4KJ KM2#	79/10~82/ 5	Engine TIMING GEAR COVER
03901 7627	90311-38044	38 x 50 x 6	LITE ACE 2C#...CM5#,6#	90/10~99/	Engine CAM SHAFT
03901 6683	90311-38025	38 x 50 x 6	LITE ACE 1C,2C#...CM2#,3#,4#,5#,6#	85/1~90/1 0	Engine CAM SHAFT
03901 6901	90311-38036	38 x 50 x 8	LITE ACE 1C CM2#	82/10~85/ 1	Engine CAM SHAFT
03901 4427	90311-42026	42 x 60 x 7	LITE ACE 2Y#,3YU YM3#,40,55,6#	87/6~99/	Engine TIMING GEAR COVER
03901 6499	90311-38086	38 x 58 x 7.5	LITE ACE 7KE KM7#,8#	99/6~	Engine TIMING GEAR COVER
03901 2153	90311-38022	38.5 x 58 x 8.5	LITE ACE 4KJ,5K#...KM2#,3#,5#	82/5~97/5	Engine TIMING GEAR COVER
03901 3235	90311-35033	35 x 55 x 9 x 15.5	MARK II QUALIS (WAGON) SXV20	97/4~	Mission & Differential (A/T) DIFF. SIDE
03901 6831	90311-38034	38 x 50 x 10.5	MARK II QUALIS (WAGON) 1MZFE,2MZFE NCV2#	97/4~	Engine CAM SHAFT
03901 4919	90311-26003	26 x 38 x 6.5	MARK II QUALIS (WAGON) MCV2#,SXV2#	97/4~	Steering (P/S) CONTROL VALVE LOWER
03901 6753	90311-56015	56 x 75 x 7 x 12	MARK II QUALIS (WAGON) MCV25,SXV25	97/6~	Wheel Hub REAR INNER
03901 7693	90311-52005	52 x 75 x 7.5 x 12	MARK II QUALIS (WAGON) MCV25,SXV25	97/6~	Wheel Hub REAR OUTER
03901 1719	04445-33080		MARK II QUALIS (WAGON) MCV25,SXV25	97/6~	Steering (P/S) R & P GASKET KIT
03901 8139	90311-40010	40 x 56 x 9 x 15.5	MARK II QUALIS (WAGON) MCV20,21	97/4~	Mission & Differential (A/T) FRONT DIFFERENTIAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8189	90311-38020	38 x 55 x 8.5	MARK II QUALIS (WAGON) MCV2#,SXV2#	97/4~	Mission & Differential (A/T) FRONT OIL PUMP
03901 3181	90311-35033	35 x 55 x 9 x 15.5	MARK II QUALIS (WAGON) SXV20	97/4~	Mission & Differential (A/T) TRANSAXLE CASE
03901 7205	90311-50011	50 x 80 x 16.5 x 23	MARK II QUALIS (WAGON) MCV2#	97/4~	Mission & Differential (A/T) DIFF. SIDE
03901 7127	90311-50022	42 x 62 x 8.5 x 15.4	MARK II QUALIS (WAGON) SXV25	97/6~	Mission & Differential (A/T) DIFF. SIDE
03901 1999	90913-02062		MARK II QUALIS (WAGON) 5SFE (EX.)	97/4~	Engine VALVE STEM SEAL
03901 6143	04445-32051		MARK II QUALIS (WAGON) MCV20,21,SXV20	97/4~	Steering (P/S) R & P GASKET KIT
03901 7795	90311-54005	55 x 70 x 10	MARK II QUALIS (WAGON) MCV25,SXV25	97/6~	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 3717	90311-38036	38 x 50 x 8	MARK II QUALIS (WAGON) 5SFE SXV2#	97/4~	Engine CAM SHAFT
03901 6475	90311-40022	40 x 55 x 6	MARK II QUALIS (WAGON) 1MZFE,2MZFE NCV2#	97/4~	Engine OIL PUMP
03901 1105	15165-70010	18 x 30 x 7	MARK II QUALIS (WAGON) 5SFE SXV2#	97/4~	Engine OIL PUMP
03901 8043	90311-42035	42 x 60 x 7	MARK II QUALIS (WAGON) 5SFE SXV2#	97/4~	Engine CRANK SHAFT FRONT
03901 6345	90311-92008	92 x 110 x 9	MARK II QUALIS (WAGON) 1MZFE,2MZFE NCV2#	97/4~	Engine CRANK SHAFT REAR
03901 3387	90913-02079		MARK II QUALIS (WAGON) 5SFE (IN.)	97/4~	Engine VALVE STEM SEAL
03901 6779	90913-02101		MARK II QUALIS (WAGON) 1MZFE,2MZFE (IN.)	97/4~	Engine VALVE STEM SEAL
03901 4129	90913-02111		MARK II QUALIS (WAGON) 1MZFE,2MZFE (EX.)	97/4~	Engine VALVE STEM SEAL
03901 5237	90311-19010	19 x 32 x 6	MARK II QUALIS (WAGON) MCV2#,SXV2#	97/4~	Steering (P/S) CONTROL VALVE UPPER
03901 6869	90311-85007	85 x 105 x 10	MARK II QUALIS (WAGON) 5SFE SXV2#	97/4~	Engine CRANK SHAFT REAR
03901 1223	90311-40004	40 x 56 x 9 x 15.5	MR2 SW20 GT	89/12~99/	Mission & Differential (M/T) MISSION CASE COVER
03901 6401	90311-50010	50 x 80 x 16.5 x 23	MR3 SW20 GT	89/12~99/	Mission & Differential (M/T) TRANSMISSION CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1377	90311-50010	50 x 80 x 16.5 x 23	MR4 AW1#... SUPER CHARGER	86/8~89/	Mission & Differential (M/T) TRANSMISSION CASE
03901 2107	90311-89002	89 x 105 x 10	MR5 3S#...SW20	93/11~99/	Engine CRANK SHAFT REAR
03901 2915	90311-34017	34 x 63 x 9 x 16	MR6 AW1#...EXCEPT SUPER CHARGER	84/6~89/	Mission & Differential (M/T) TRANSMISSION CASE
03901 3793	90311-30006	30 x 42 x 7	MR7 SW20	89/7~99/	Mission & Differential (M/T) INPUT SHAFT
03901 2761	90913-02079		MR8 3S# (IN.)	90/6~99/	Engine VALVE STEM SEAL
03901 4281	90913-02104		MR9 3S# (EX.)	93/11~99/	Engine VALVE STEM SEAL
03901 6721	90913-02062		MR10 3S# (EX.)	90/6~93/11	Engine VALVE STEM SEAL
03901 2325	90913-02062		MR11 3S# (IN. & EX.)	89/12~90/6	Engine VALVE STEM SEAL
03901 5461	90913-02062		MR12 4A#...AW11	84/6~89/	Engine VALVE STEM SEAL
03901 3593	90913-02038		MR13 3ALU AW10	84/6~89/	Engine VALVE STEM SEAL
03901 6215	90311-89001	89 x 105 x 10	MR14 3SGE SW20	90/12~93/11	Engine CRANK SHAFT REAR
03901 5291	90311-89002	89 x 105 x 10	MR15 3SGTE SW20	90/12~93/11	Engine CRANK SHAFT REAR
03901 5951	90311-34016	34 x 54 x 9 x 15.5	MR16 AW1#...EXCEPT SUPER CHARGER	84/6~89/	Mission & Differential (M/T) DIFF. SIDE
03901 5657	90311-89001	89 x 105 x 10	MR17 3S#...SW20	89/12~90/12	Engine CRANK SHAFT REAR
03901 3421	90311-70004	70 x 92 x 8.5	MR18 3A#,4A#...AW1#	84/6~89/	Engine CRANK SHAFT REAR
03901 7001	90311-42026	42 x 60 x 7	MR19 3S#...SW20	89/12~99/	Engine CRANK SHAFT FRONT
03901 5437	90311-35013	35 x 49 x 6	MR20 3A#,4A#...AW1#	84/6~89/	Engine CAM SHAFT
03901 6673	90311-35020	35 x 63 x 9 x 15.5	MR21 SW20	89/12~99/	Mission & Differential (A/T) TRANSMISSION CASE
03901 1845	90311-35033	35 x 55 x 9 x 15.5	MR22 SW20 G	89/12~99/	Mission & Differential (M/T) DIFF. SIDE
03901 3373	90311-35033	35 x 55 x 9 x 15.5	MR23 SW20	89/12~99/	Mission & Differential (A/T) DIFF. SIDE
03901 3701	90311-35013	35 x 49 x 6	MR24 3S#...SW20	89/12~99/	Engine CAM SHAFT
03901 5839	90311-30006	30 x 42 x 7	MR25 AW1#... SUPER CHARGER	86/8~89/	Mission & Differential (M/T) INPUT SHAFT
03901 7223	90311-41004	41 x 55 x 7 x 12	MR26 AW1#	84/6~89/	Wheel Hub FRONT
03901 4905	90311-42018	42 x 55 x 6	MR27 SW20	89/12~99/	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7535	90311-25011	25 x 37 x 8	MR28 AW1#...EXCEPT SUPER CHARGER	84/6~89/	Mission & Differential (M/T) INPUT SHAFT
03901 5201	04422-32010	Kit	MR29 AW1#	86/8~89/	Wheel Hub REAR
03901 1341	04422-17010	Kit	MR30 AW1#	84/6~86/8	Wheel Hub REAR
03901 7225	90311-35051	35 x 54 x 9 x 21.5	MR-S ZZW30	99/10~	Mission & Differential (A/T) DIFF. SIDE
03901 2185	90311-35044	35 x 63 x 10 x 22	MR-S ZZW30	99/10~	Mission & Differential (A/T) MISSION CASE
03901 2939	90311-25011	25 x 37 x 8	MR-S ZZW30	99/10~	Mission & Differential (A/T) INPUT SHAFT
03901 6625	04445-17020		MR-S ZZW30	99/10~	Steering (P/S) R & P GASKET KIT
03901 1213	90311-19010	19 x 32 x 6	MR-S ZZW30	99/10~	Steering (P/S) CONTROL VALVE UPPER
03901 3191	90311-26003	26 x 38 x 6.5	MR-S ZZW30	99/10~	Steering (P/S) CONTROL VALVE LOWER
03901 2399	90311-38067	38 x 50 x 8	MR-S 1ZZFE ZZW30	99/10~	Engine TIMING GEAR COVER
03901 5987	90311-76001	76 x 94 x 8.5	MR-S 1ZZFE ZZW30	99/10~	Engine CRANK SHAFT REAR
03901 7327	90913-02101		MR-S 1ZZFE (IN.)	99/10~	Engine VALVE STEM SEAL
03901 2283	90913-02111		MR-S 1ZZFE (EX.)	99/10~	Engine VALVE STEM SEAL
03901 7779	90311-38067	38 x 50 x 8	NADIA 3SF#...SXN1#	98/7~	Engine CAM SHAFT
03901 1923	90311-19002	19 x 32 x 7 x 8	NADIA SXN1#	98/7~	Steering (P/S) CONTROL VALVE UPPER
03901 7243	90310-25004	25 x 38 x 7 x 8	NADIA SXN15	98/7~	Steering (P/S) CONTROL VALVE LOWER
03901 1673	90310-25004	25 x 38 x 7 x 8	NADIA SXN10 FRIEND MATIC	98/7~	Steering (P/S) CONTROL VALVE LOWER
03901 1757	90310-28003	28 x 41 x 6.5	NADIA SXN10	98/7~	Steering (P/S) CONTROL VALVE LOWER
03901 1313	15165-70010	18 x 30 x 7	NADIA 3SF#...SXN1#	98/7~	Engine OIL PUMP
03901 7391	90311-42035	42 x 60 x 7	NADIA 3SF#...SXN1#	98/7~	Engine CRANK SHAFT FRONT
03901 2155	90311-85007	85 x 105 x 10	NADIA 3SF#...SXN1#	98/7~	Engine CRANK SHAFT REAR
03901 6591	90913-02079		NADIA 3SF# (IN.)	98/7~	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4365	04445-20161		NADIA SXN15	98/7~	Steering (P/S) R & P GASKET KIT
03901 6551	04445-20210		NADIA SXN10	98/7~	Steering (P/S) R & P GASKET KIT
03901 1909	90913-02062		NADIA 3SF# (EX.)	98/7~	Engine VALVE STEM SEAL
03901 1877	90311-38020	38 x 55 x 8.5	NADIA SXN1#	98/7~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4239	90311-49002	50 x 64 x 8	NADIA SXN15	98/7~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 5629	90311-35033	35 x 55 x 9 x 15.5	NADIA SXN10	98/7~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 8235	90311-35033	35 x 55 x 9 x 15.5	NADIA SXN1#...WITHOUT EFI	98/7~	Mission & Differential (A/T) DIFF. SIDE
03901 5837	90311-35020	35 x 63 x 9 x 15.5	NADIA SXN1#...EFI	98/7~	Mission & Differential (A/T) TRANSAXLE CASE
03901 5757	04445-20161		NADIA SXN10 FRIEND MATIC	98/7~	Steering (P/S) R & P GASKET KIT
03901 7617	90311-35033	35 x 55 x 9 x 15.5	OPA ACT10	00/8~	Mission & Differential (A/T) CVT NO.1
03901 6317	90310-25032	25 x 35 x 6	OPA ACT10,ZCT1#	00/4~	Steering (P/S) CONTROL VALVE LOWER
03901 3233	04445-32081		OPA ACT10,ZCT1#	00/4~	Steering (P/S) R & P GASKET KIT
03901 2219	90311-38059	38 x 50 x 8	OPA 1AZFSE ACT10	00/8~	Engine TIMING GEAR CASE
03901 5057	90311-38059	38 x 50 x 8	OPA 1ZZFE ZCT1#	00/4~	Engine TIMING GEAR COVER
03901 4013	90311-76001	76 x 94 x 8.5	OPA 1ZZFE ZCT1#	00/4~	Engine CRANK SHAFT REAR
03901 8167	90311-89003	89 x 105-10 x	OPA 1AZFSE ACT10	00/8~	Engine CRANK SHAFT REAR
03901 3415	90913-02101		OPA 1ZZFE,1AZFSE IN.	00/4~	Engine VALVE STEM SEAL
03901 7019	90311-20008	20 x 34 x 7	OPA ACT10,ZCT1#	00/4~	Steering (P/S) CONTROL VALVE UPPER
03901 5099	90311-35046	35 x 57 x 9 x 15.5	OPA ACT10	00/8~	Mission & Differential (A/T) CVT NO.2
03901 1109	90311-35046	35 x 57 x 9 x 15.5	OPA ZCT1#	00/4~	Mission & Differential (A/T) TRANSAXLE CASE NO.2

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2515	90311-49002	50 x 64 x 8	OPA ZCT15	00/4~	Mission & Differential (A/T) TRANSAXLE CASE NO.1
03901 3315	90311-35033	35 x 55 x 9 x 15.5	OPA ZCT10	00/4~	Mission & Differential (A/T) TRANSAXLE CASE NO.1
03901 6079	90913-02111		OPA 1ZZFE,1AZFSE EX.	00/4~	Engine VALVE STEM SEAL
03901 7619	90311-38064	38 x 55 x 8.7	OPA ZCT1#	00/4~	Mission & Differential (A/T) FRONT OIL PUMP
03901 5713	90311-35046	35 x 57 x 9 x 15.5	PRIUS NHW11	00/5~	Transaxle Assy TRANSAXLE (L)
03901 3999	90311-24024	25 x 39.5 x 8	PRIUS NHW11	00/5~	Transaxle Assy Input Shaft
03901 4347	90311-25022	25 x 39.5 x 8.2	PRIUS NHW10	97/12~00/5	Transaxle Assy Input Shaft
03901 3587	90913-02093		PRIUS 1NZFXE(IN. & EX.)	97/12~	Engine VALVE STEM SEAL
03901 2361	90311-75016	75 x 107 x 8	PRIUS 1NZFXE NHW11	00/5~	Engine CRANK SHAFT REAR
03901 4141	90311-25021	25.5 x 37.5 x 6	PRIUS 1NZFXE NHW10,11	97/12~	Engine OIL PUMP
03901 7169	90311-35033	35 x 55 x 9 x 15.5	PRIUS NHW11	00/5~	Transaxle Assy TRANSAXLE
03901 5297	90311-35033	35 x 55 x 9 x 15.5	PRIUS NHW10	97/12~00/5	Transaxle Assy TRANSAXLE (R & L)
03901 7959	90311-75013	75 x 114 x 8	PRIUS 1NZFXE NHW10	97/12~00/5	Engine CRANK SHAFT REAR
03901 4199	90311-19002	19 x 32 x 7 x 8	PROGRES JCG1#	98/5~	Steering (P/S) CONTROL VALVE UPPER
03901 7183	04445-51010		PROGRES JCG1#	98/5~	Steering (P/S) R & P GASKET KIT
03901 6127	90311-40020	40.5 x 52.5 x 6.5	PROGRES 1JZGE,2JZGE JCG1#	98/5~	Engine CAM SHAFT
03901 3797	90913-02062		PROGRES 1JZGE,2JZGE(EX.)	98/5~	Engine VALVE STEM SEAL
03901 1433	90913-02079		PROGRES 1JZGE,2JZGE(IN.)	98/5~	Engine VALVE STEM SEAL
03901 3725	90311-90006	90 x 110 x 9.5	PROGRES 1JZGE,2JZGE JCG1#	98/5~	Engine CRANK SHAFT REAR
03901 1647	90310-25027	25 x 38 x 7	PROGRES JCG1#	98/5~	Steering (P/S) CONTROL VALVE LOWER
03901 5459	90311-43001	43 x 70 x 9 x 15.5	PROGRES JCG11	98/5~	Final Drive DIFF. SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5319	90311-38011	38 x 63 x 10 x 17	PROGRES JCG10	98/5~	Final Drive DIFF. SIDE
03901 1397	90311-38133	38 x 74 x 11	PROGRES JCG1#	98/5~	Final Drive PINION
03901 6883	90311-40001	40 x 58 x 11	PROGRES JCG1#	98/5~	Transmission (A/T) EXTENTION HOUSING
03901 6001	90311-38029	38 x 55 x 7.5	PROGRES JCG1#	98/5~	Transmission (A/T) FRONT OIL PUMP
03901 4223	90311-48013	48 x 73 x 7	PROGRES JCG1#	98/5~	Wheel Hub FRONT
03901 8215	90311-46001	46 x 63 x 6.5	PROGRES 1JZGE,2JZGE JCG1#	98/5~	Engine CRANK SHAFT FRONT
03901 5211	90311-50011	50 x 80 x 16.5 x 23	PRONARD MCX20	00/2~	Mission & Differential (A/T) DIFF. SIDE
03901 2803	90311-19010	19 x 32 x 6	PRONARD MCX20	00/2~	Steering (P/S) CONTROL VALVE UPPER
03901 6679	90311-40010	40 x 56 x 9 x 15.5	PRONARD MCX20	00/2~	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 8009	90311-38020	38 x 55 x 8.5	PRONARD MCX20	00/2~	Mission & Differential (A/T) FRONT OIL PUMP
03901 3227	90311-38034	38 x 50 x 10.5	PRONARD 1MZFE MCX20	00/2~	Engine CAM SHAFT
03901 3171	90311-40022	40 x 55 x 6	PRONARD 1MZFE MCX20	00/2~	Engine OIL PUMP
03901 7279	90311-92008	92 x 110 x 9	PRONARD 1MZFE MCX20	00/2~	Engine CRANK SHAFT REAR
03901 3431	90913-02101		PRONARD 1MZFE(IN.)	00/2~	Engine VALVE STEM SEAL
03901 2437	90913-02111		PRONARD 1MZFE(EX.)	00/2~	Engine VALVE STEM SEAL
03901 2621	90311-26003	26 x 38 x 6.5	PRONARD MCX20	00/2~	Steering (P/S) CONTROL VALVE LOWER
03901 4777	90311-80012	80 x 100 x 8.5	RAUM 5E EXZ1#	97/5~	Engine CRANK SHAFT REAR
03901 3027	90913-02062		RAUM 5E (IN. & EX.)	97/5~	Engine VALVE STEM SEAL
03901 2977	90311-34016	34 x 54 x 9 x 15.5	RAUM EXZ10	97/5~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 2683	90311-54004	54 x 68 x 8.5	RAUM EXZ15 (4WD)	97/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 5669	90311-38020	38 x 55 x 8.5	RAUM EXZ1#	97/5~	Mission & Differential (A/T) FRONT OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2091	04445-16110		RAUM EXZ1#	97/5~	Steering (P/S) R & P GASKET KIT
03901 1455	90311-19010	19 x 32 x 6	RAUM EXZ1#	97/5~	Steering (P/S) CONTROL VALVE UPPER
03901 1053	90311-26003	26 x 38 x 6.5	RAUM EXZ1#	97/5~	Steering (P/S) CONTROL VALVE LOWER
03901 3847	90311-35013	35 x 49 x 6	RAUM 5E EXZ1#	97/5~	Engine CAM SHAFT
03901 7245	90311-42055	42 x 55 x 7	RAUM EXZ15 (4WD)	97/8~	Wheel Hub REAR
03901 7471	90311-35040	35 x 49 x 6	RAUM 5E EXZ1#	97/5~	Engine CRANK SHAFT FRONT
03901 4393	90311-56017	56 x 73 x 88.5 x 21.5	RAUM EXZ1#	97/5~	Wheel Hub FRONT INNER
03901 3859	90311-54003	54 x 66 x 7.5 x 10	RAUM EXZ1#	97/5~	Wheel Hub FRONT OUTER
03901 2855	90311-38037	38 x 52 x 7	RAUM EXZ10	97/5~	Wheel Hub REAR
03901 2117	90311-34013	34 x 63 x 9 x 15	RAUM EXZ1#	97/5~	Mission & Differential (A/T) TRANSAXLE CASE
03901 7577	90029-21020	20 x 32 x 5	RAUM 5E EXZ1#	97/5~	Engine OIL PUMP
03901 4913	04422-20080	Kit	RAV4 SXA1#...ABS	94/4~96/8	Wheel Hub FRONT
03901 8149	90311-76001	76 x 94 x 8.5	RAV5 1ZZFE ZCA2#	00/5~	Engine CRANK SHAFT REAR
03901 3367	90311-35041	35 x 60 x 11	RAV6 3SGE SXA10,11	98/8~00/	Engine CAM SHAFT (NO.1)
03901 5571	90311-46004	46 x 60 x 6.5	RAV7 3SGE SXA10,11	98/8~00/	Engine CAM SHAFT (NO.2)
03901 2637	90311-38067	38 x 50 x 8	RAV8 3SGE SXA1#	97/8~	Engine CAM SHAFT
03901 3533	90311-38059	38 x 50 x 8	RAV9 1AZESE ACA2#	00/5~	Engine TIMING GEAR CASE
03901 5985	90311-38059	38 x 50 x 8	RAV10 1ZZFE ZCA2#	00/5~	Engine TIMING GEAR COVER
03901 5263	90311-42026	42 x 60 x 7	RAV11 3S#...SXA1#	94/4~96/9	Engine CRANK SHAFT FRONT
03901 7071	90311-42026	42 x 60 x 7	RAV12 3SGE SXA10,11	96/9~00/	Engine CRANK SHAFT FRONT
03901 1937	90311-42035	42 x 60 x 7	RAV13 3SFE SXA1#	96/9~00/	Engine CRANK SHAFT FRONT
03901 1139	90311-85007	85 x 105 x 10	RAV14 3SFE SXA1#	94/4~00/	Engine CRANK SHAFT REAR
03901 2831	90311-35013	35 x 49 x 6	RAV15 3SGE SXA1#	96/8~98/8	Engine CAM SHAFT
03901 1329	90311-89003	89 x 105 x 10	RAV16 1AZESE ACA2#	00/5~	Engine CRANK SHAFT REAR
03901 6259	90311-38036	38 x 50 x 8	RAV17 3SGE SXA1#	94/4~97/8	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3349	90913-02079		RAV18 3S#(IN.)	94/4~98/8	Engine VALVE STEM SEAL
03901 8131	90913-02079		RAV19 3SFE (IN.)	98/8~00/	Engine VALVE STEM SEAL
03901 4461	90913-02062		RAV20 3SFE (EX.)	94/4~00/	Engine VALVE STEM SEAL
03901 8243	90913-02101		RAV21 1AZ,1ZZ (IN.)	00/5~	Engine VALVE STEM SEAL
03901 6703	90913-02111		RAV22 1AZ,1ZZ (EX.)	00/5~	Engine VALVE STEM SEAL
03901 4959	90913-02104		RAV23 3SGE (EX.)	96/8~98/8	Engine VALVE STEM SEAL
03901 3935	90913-02115		RAV24 3SGE (EX.)	98/8~00/	Engine VALVE STEM SEAL
03901 2049	90913-02114		RAV25 3SGE (IN.)	98/8~00/	Engine VALVE STEM SEAL
03901 7441	90311-30006	30 x 42 x 7	RAV26 SXA1#	94/4~00/	Mission & Differential (M/T) INPUT SHAFT
03901 2435	90311-89001	89 x 105 x 10	RAV27 3SGE SXA1#	96/8~00/	Engine CRANK SHAFT REAR
03901 6491	90311-35020	35 x 63 x 9 x 15.5	RAV28 SXA15,16	97/9~00/	Mission & Differential (A/T) TRANSAXLE CASE
03901 2339	04422-12060	Kit	RAV29 SXA1#...WITHOUT ABS	94/4~96/8	Wheel Hub FRONT
03901 6845	04422-20080	Kit	RAV30 SXA1#...EXCEPT G TYPE	96/8~00/	Wheel Hub FRONT
03901 2065	90311-30006	30 x 42 x 7	RAV31 ACA2#	00/5~	Mission & Differential (M/T) INPUT SHAFT
03901 4079	90311-44003	44 x 80 x 9 x 15.5	RAV32 SXA10,11	94/4~00/	Mission & Differential (M/T) TRANSMISSION CASE
03901 1023	90311-50010	50 x 80 x 16.5 x 23	RAV33 SXA15,16	97/9~99/11	Mission & Differential (M/T) TRANSMISSION CASE
03901 7649	90311-50011	50 x 80 x 16.5 x 23	RAV34 SXA15,16	99/11~00/	Mission & Differential (M/T) TRANSMISSION CASE
03901 4101	90311-50011	50 x 80 x 16.5 x 23	RAV35 ACA2#	00/5~	Mission & Differential (M/T) TRANSMISSION CASE
03901 1193	15165-70010	18 x 30 x 7	RAV36 3SGE,3SFE SXA1#	96/8~00/	Engine OIL PUMP
03901 1303	90311-62005	62 x 74 x 7.5	RAV37 ACA2#	00/5~	Mission & Differential (M/T) TRANSAXLE CASE COVER
03901 1337	90310-23005	23 x 34 x 6.5	RAV38 SXA1#,ACA2#,ZCA2#	94/4~	Steering (P/S) CONTROL VALVE LOWER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3853	90311-35033	35 x 55 x 9 x 15.5	RAV39 ZCA2#	00/5~	Mission & Differential (A/T) TRANSAXLE CASE (NO.1)
03901 6641	90311-35046	35 x 57 x 9 x 15.5	RAV40 ZCA2#	00/5~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 8133	04445-42020		RAV41 SXA1#	95/1~00/	Steering (P/S) R & P GASKET KIT
03901 5377	90311-40004	40 x 56 x 9 x 15.5	RAV42 SXA15,16	92/9~00/	Mission & Differential (M/T) TRANSAXLE CASE COVER
03901 5207	04445-42030		RAV43 ACA2#,ZCA2#	00/5~	Steering (P/S) R & P GASKET KIT
03901 2869	90311-35033	35 x 55 x 9 x 15.5	RAV44 SXA15,16	97/9~00/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4667	04445-42010		RAV45 SXA10	94/4~95/1	Steering (P/S) R & P GASKET KIT
03901 5525	90311-38064	38 x 55 x 8.7	RAV46 ACA2#,ZCA2#	00/5~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4725	90311-38020	38 x 55 x 8.5	RAV47 SXA1#	94/4~00/	Mission & Differential (A/T) FRONT OIL PUMP
03901 4857	90311-50011	50 x 80 x 16.5 x 23	RAV48 ACA2#	00/5~	Mission & Differential (A/T) DIFF. SIDE
03901 4839	90311-44003	44 x 80 x 9 x 15.5	RAV49 SXA10,11	94/4~00/	Mission & Differential (A/T) DIFF. SIDE
03901 2473	90311-62004	62 x 74 x 8.5	RAV50 ACA2#	00/5~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4131	90311-19007	19 x 38 x 7	RAV51 SXA1#,ACA2#,ZCA2#	94/4~	Steering (P/S) CONTROL VALVE UPPER
03901 7215	15165-70010	18 x 30 x 7	SCEPTER 5SFE SXV1#	92/11~96/	Engine OIL PUMP
03901 4651	90311-38034	38 x 50 x 10.5	SCEPTER 3VZFE VCV1#	92/7~96/	Engine CAM SHAFT
03901 2173	90913-02062		SCEPTER 3VZFE(EX.)	92/7~96/	Engine VALVE STEM SEAL
03901 2383	90913-02095		SCEPTER 3VZFE(IN.)	92/7~96/	Engine VALVE STEM SEAL
03901 7103	90913-02062		SCEPTER 5SFE(EX.)	92/11~96/	Engine VALVE STEM SEAL
03901 6627	90913-02079		SCEPTER 5SFE(IN.)	92/11~96/	Engine VALVE STEM SEAL
03901 7797	90311-92005	92 x 110 x 10	SCEPTER 3VZFE VCV1#	92/7~96/	Engine CRANK SHAFT REAR
03901 4749	90311-85007	85 x 105 x 10	SCEPTER 5SFE SXV1#	92/11~96/	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3131	90311-42026	42 x 60 x 7	SCEPTER 5SFE SXV1#	92/11~96/	Engine CRANK SHAFT FRONT
03901 1389	90311-50010	50 x 80 x 16.5 x 23	SCEPTER VCV1#	92/7~96/	Mission & Differential (A/T) DIFF. SIDE
03901 3037	90311-40022	40 x 55 x 6	SCEPTER 3VZFE VCV1#	92/7~96/	Engine OIL PUMP
03901 1505	90311-38036	38 x 50 x 8	SCEPTER 5SFE SXV1#	92/11~96/	Engine CAM SHAFT
03901 1489	90311-26003	26 x 38 x 6.5	SCEPTER SXV1#,VCV1#	92/7~96/	Steering (P/S) CONTROL VALVE LOWER
03901 2571	90311-19010	19 x 32 x 6	SCEPTER SXV1#,VCV1#	92/7~96/	Steering (P/S) CONTROL VALVE UPPER
03901 7849	90311-38020	38 x 55 x 8.5	SCEPTER SXV1#,VCV1#	92/7~96/	Mission & Differential (A/T) FRONT OIL PUMP
03901 7913	90311-40010	40 x 56 x 9 x 15.5	SCEPTER VCV1#	92/7~96/	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 4571	90311-35033	35 x 55 x 9 x 15.5	SCEPTER SXV1#	92/11~96/	Mission & Differential (A/T) TRANSAXLE CASE
03901 8073	90311-35033	35 x 55 x 9 x 15.5	SCEPTER SXV1#	92/11~96/	Mission & Differential (A/T) DIFF. SIDE
03901 7623	90311-26003	26 x 38 x 6.5	SERA EXY10	90/3~95/	Steering (P/S) CONTROL VALVE
03901 7439	90311-35013	35 x 49 x 6	SERA 5E EXY10	90/3~95/	Engine CAM SHAFT
03901 5975	90029-21020	20 x 32 x 5	SERA 5E EXY10	90/3~95/	Engine OIL PUMP
03901 6295	90311-35013	35 x 49 x 6	SERA 5E EXY10	90/3~95/	Engine CRANK SHAFT FRONT
03901 3071	90311-80003	80 x 100 x 8.5	SERA 5E EXY10	90/3~91/8	Engine CRANK SHAFT REAR
03901 6229	90311-80012	80 x 100 x 8.5	SERA 5E EXY10	91/8~95/	Engine CRANK SHAFT REAR
03901 1551	04445-10030		SERA EXY10	90/3~95/	Steering (P/S) R & P GASKET KIT
03901 2257	90913-02062		SERA 5E (EX.)	90/3~95/	Engine VALVE STEM SEAL
03901 5095	90913-02062		SERA 5E (IN.)	90/3~95/	Engine VALVE STEM SEAL
03901 7069	90311-38037	38 x 52 x 7	SERA EXY10	90/3~95/	Wheel Hub REAR
03901 1703	90311-38020	38 x 55 x 8.5	SERA EXY10	90/3~95/	Mission & Differential (A/T) FRONT OIL PUMP
03901 2357	04422-10030	Kit	SERA EXY10 WITHOUT ABS	90/3~95/	Wheel Hub FRONT
03901 4317	04422-10040	Kit	SERA EXY10 WITH ABS	90/3~95/	Wheel Hub FRONT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6431	90311-25011	25 x 37 x 8	SERA EXY10	90/3~95/	Mission & Differential (M/T) INPUT SHAFT
03901 4295	90311-34017	34 x 63 x 9 x 16	SERA EXY10	90/3~95/	Mission & Differential (M/T) TRANSMISSION CASE
03901 3231	90311-34016	34 x 54 x 9 x 15.5	SERA EXY10	90/3~95/	Mission & Differential (M/T) TRANSAXLE CASE
03901 1465	90311-50015	50 x 68 x 9 x 14.5	SERA EXY10 WITH LSD	92/12~95/	Mission & Differential (M/T) TRANSAXLE CASE
03901 1233	90311-34013	34 x 63 x 9 x 15	SERA EXY10	90/3~95/	Mission & Differential (A/T) TRANSAXLE CASE
03901 7377	90311-34012	34 x 54 x 9 x 15.5	SERA EXY10	90/3~95/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 4577	04445-30251		SOARER UZZ40	01/4~	Steering (P/S) R & P GASKET KIT
03901 7555	90311-40020	40.5 x 52.5 x 6.5	SOARER 2JZGE JZZ31	94/1~01/	Engine CAM SHAFT
03901 7407	90311-43004	43 x 60 x 7	SOARER 1UZFE UZZ3#	91/5~01/	Engine OIL PUMP
03901 3115	90311-71001	71.5 x 85 x 10	SOARER 3UZFE UZZ40	01/4~	Engine CAM SHAFT
03901 6393	90311-38036	38 x 50 x 8	SOARER 1UZFE UZZ3#	91/5~01/	Engine CAM SHAFT
03901 5965	90311-43006	43 x 60 x 7	SOARER 3UZFE UZZ40	01/4~	Engine OIL PUMP
03901 3535	90311-38056	38 x 52.5 x 6	SOARER 1JZGTE JZZ30	96/8~01/	Engine CAM SHAFT (NO.2)
03901 6669	90311-40020	40.5 x 52.5 x 6.5	SOARER 1JZGTE JZZ30	96/8~01/	Engine CAM SHAFT (NO.1)
03901 7657	90311-38025	38 x 50 x 6	SOARER 1JZGTE JZZ30	91/5~96/8	Engine CAM SHAFT
03901 6789	90311-46001	46 x 63 x 6.5	SOARER 1JZGTE,2JZGE JZZ3#	91/5~01/	Engine CRANK SHAFT FRONT
03901 4325	90311-19002	19 x 32 x 7 x 8	SOARER JZZ3#,UZZ3#	91/5~01/	Steering (P/S) CONTROL VALVE UPPER
03901 1103	90913-02079		SOARER 1UZFE (IN.)	96/8~01/	Engine VALVE STEM SEAL
03901 2295	04445-24051		SOARER JZZ3#,UZZ3#	91/5~01/	Steering (P/S) R & P GASKET KIT
03901 1095	90310-30013	30 x 41 x 6.5	SOARER JZZ3#,UZZ3#	91/5~01/	Steering (P/S) CONTROL VALVE LOWER
03901 1711	90311-95012	95 x 113 x 8.5	SOARER 1UZFE UZZ3#	91/5~01/	Engine CRANK SHAFT REAR
03901 7303	90311-95012	95 x 113 x 8.5	SOARER 3UZFE UZZ40	01/4~	Engine CRANK SHAFT REAR
03901 4385	90311-90006	90 x 110 x 9.5	SOARER 1JZGTE,2JZGE JZZ3#	91/5~01/	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5261	90913-02062		SOARER 1JZGTE,2JZGE (EX.)	95/1~	Engine VALVE STEM SEAL
03901 1897	90913-02079		SOARER 1UZFE (IN. & EX.)	94/8~96/8	Engine VALVE STEM SEAL
03901 6649	90913-02106		SOARER 1UZFE (EX.)	96/8~01/	Engine VALVE STEM SEAL
03901 3713	90913-02113		SOARER 3UZFE (IN.)	01/4~	Engine VALVE STEM SEAL
03901 1623	90913-02112		SOARER 3UZFE (EX.)	01/4~	Engine VALVE STEM SEAL
03901 2787	90913-02079		SOARER 1JZGTE (IN.)	91/5~01/	Engine VALVE STEM SEAL
03901 2249	90913-02106		SOARER 2JZGE (IN.)	94/1~95/1	Engine VALVE STEM SEAL
03901 6303	90913-02079		SOARER 2JZGE (IN.)	95/1~01/	Engine VALVE STEM SEAL
03901 1811	90311-47008	47 x 72 x 10 x 11	SOARER JZZ3#,UZZ3#,40	91/5~	Final Drive DIFF. SIDE
03901 2227	90311-50008	50 x 77.5 x 9 x 14	SOARER UZZ40	01/4~	Wheel Hub FRONT
03901 3673	90913-02062		SOARER 1UZFE (IN. & EX.)	91/5~94/8	Engine VALVE STEM SEAL
03901 3029	90311-48001	48 x 62 x 9	SOARER GZ10,MZ1#	81/2~85/	Wheel Hub REAR OUTER
03901 3949	90311-63001	63 x 90 x 7 x 10	SOARER GZ20,MZ2#,JZZ3#,UZZ3#,40	86/1~	Wheel Hub REAR INNER
03901 1793	90311-43001	43 x 70 x 9 x 15.5	SOARER GX20 GT (ATM)	89/1~91/	Final Drive DIFF. SIDE
03901 2419	90311-48001	48 x 62 x 9	SOARER GZ10,MZ1#	81/2~85/	Wheel Hub FRONT
03901 1885	90311-50008	50 x 77.5 x 9 x 14	SOARER GZ20,MZ2#	86/1~91/	Wheel Hub FRONT
03901 3137	90311-50008	50 x 77.5 x 9 x 14	SOARER JZZ3#,UZZ3#	91/5~01/	Wheel Hub FRONT
03901 5009	90311-38009	38 x 58 x 8	SOARER GZ10,MZ1#	81/2~85/	Wheel Hub REAR INNER
03901 7099	90311-57001	57 x 81 x 8 x 11	SOARER GZ20,MZ2#,JZZ3#,UZZ3#,40	86/1~	Wheel Hub REAR OUTER
03901 5511	90311-30115	30 x 45 x 8	SOARER GZ10,20,MZ1#	81/2~91/	Transmission (M/T) FRONT COVER
03901 5507	90311-32012	32 x 53 x 7	SOARER MZ2#,JZZ3#	86/1~01/	Transmission (M/T) FRONT COVER
03901 5017	90311-38043	38 x 58 x 11	SOARER GZ10,20,MZ1#	81/2~91/	Transmission (M/T) REAR EXTENTION
03901 6217	90311-40001	40 x 58 x 11	SOARER MZ2#,JZZ3#	91/5~01/	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1247	90311-38029	38 x 55 x 7.5	SOARER GZ20,MZ2#,JZZ3#,UZZ3#,40	86/1~	Transmission (A/T) FRONT OIL PUMP
03901 7139	90311-40001	40 x 58 x 11	SOARER JZZ3#	91/5~01/	Transmission (A/T) REAR EXTENTION
03901 1839	90311-38011	38 x 63 x 10 x 17	SOARER GZ20 VZ,VX,GT	86/1~89/1	Final Drive DIFF. SIDE
03901 6861	90311-38015	38 x 65 x 12 x 19	SOARER GZ10	81/2~81/8	Final Drive PINION
03901 6009	90311-38019	38 x 65 x 10 x 17	SOARER GZ10 V1,V2,VR,VX	81/8~85/	Final Drive PINION
03901 1167	90311-38133	38 x 74 x 11	SOARER GZ10 GT	83/2~85/	Final Drive PINION
03901 4457	90311-38133	38 x 74 x 11	SOARER GZ20,MX1#,2#	81/2~91/	Final Drive PINION
03901 6787	90311-44005	44 x 74 x 11 x 16	SOARER JZZ30,UZZ3#,40	91/5~	Final Drive PINION
03901 6693	90311-38011	38 x 63 x 10 x 17	SOARER GZ10,MZ10,11,12 ATM	81/2~85/9	Final Drive DIFF. SIDE
03901 6511	90311-43001	43 x 70 x 9 x 15.5	SOARER MZ2#,GZ20 GTT,GTL	86/1~91/	Final Drive DIFF. SIDE
03901 5381	90311-38011	38 x 63 x 10 x 17	SOARER GZ10 GT, MZ1#...ATM	85/9~85/12	Final Drive DIFF. SIDE
03901 7193	90311-35018	35 x 63 x 10 x 16.5	SOARER GZ10 V2,VR,VX	85/9~85/12	Final Drive DIFF. SIDE
03901 1721	90311-43001	43 x 70 x 9 x 15.5	SOARER MZ12 MTM	85/1~85/12	Final Drive DIFF. SIDE
03901 7321	90311-38011	38 x 63 x 10 x 17	SOARER GZ20 VX,GT(MTM)	89/1~91/	Final Drive DIFF. SIDE
03901 7195	90311-42024	42 x 55 x 10	SOARER UZZ3#,UZZ40	91/5~	Transmission (A/T) REAR EXTENTION
03901 2213	90311-38025	38 x 50 x 6	STARLET (FWD) 1N NP7#,80,90	86/12~92/8	Engine CAM SHAFT
03901 8141	90311-35013	35 x 49 x 6	STARLET (FWD) 2E#,4E#...EP7#,8#,9#	84/10~99/	Engine CAM SHAFT
03901 1155	90311-26003	26 x 38 x 6.5	STARLET (FWD) EP8#,9#,NP80,90	89/12~99/	Steering (P/S) CONTROL VALVE LOWER
03901 1681	90311-19010	19 x 32 x 6	STARLET (FWD) EP8#,9#,NP80,90	89/12~99/	Steering (P/S) CONTROL VALVE UPPER
03901 3405	90029-21005	18 x 30 x 5	STARLET (FWD) 2E#...EP7#	84/10~86/4	Engine OIL PUMP
03901 4463	04445-10030		STARLET (FWD) EP8#,NP80	89/12~96/	Steering (P/S) R & P GASKET KIT
03901 3837	90311-15002	15 x 25 x 7	STARLET (FWD) EP82,91,NP80,90	89/12~99/	Steering (M/S) RACK HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2033	04445-16110		STARLET (FWD) EP9#,NP90	96/1~99/	Steering (P/S) R & P GASKET KIT
03901 7715	90029-21020	20 x 32 x 5	STARLET (FWD) 2E#,4E#...EP7#,8#,9#	86/4~99/	Engine OIL PUMP
03901 4391	90311-35013	35 x 49 x 6	STARLET (FWD) 2E#,4E#...EP7#,8#,9#	84/10~96/ 4	Engine CRANK SHAFT FRONT
03901 2623	90311-35013	35 x 49 x 6	STARLET (FWD) 1N NP7#,80	86/12~92/ 8	Engine CRANK SHAFT FRONT
03901 7511	90913-02062		STARLET (FWD) 2E#,4E#	84/10~99/	Engine VALVE STEM SEAL
03901 5845	90311-75009	75 x 100 x 8.5	STARLET (FWD) 4E#...EP9#	96/1~99/	Engine CRANK SHAFT REAR
03901 3883	90311-80003	80 x 100 x 8.5	STARLET (FWD) 1N NP7#	86/12~89/	Engine CRANK SHAFT REAR
03901 3843	90311-80009	80 x 100 x 10	STARLET (FWD) 1N NP80,90	89/12~99/	Engine CRANK SHAFT REAR
03901 4247	90311-15001	15 x 25 x 7	STARLET (FWD) EP7#,NP7#	84/10~89/	Steering (M/S) RACK HOUSING
03901 6999	04422-10040	Kit	STARLET (FWD) EP9#,NP90 WITH ABS	96/1~99/	Wheel Hub FRONT
03901 7761	90311-35031	35 x 49 x 6	STARLET (FWD) 1N NP80,90	92/8~99/	Engine CRANK SHAFT FRONT
03901 7899	90311-34017	34 x 63 x 9 x 16	STARLET (FWD) EP7#,8#,9#,NP7#,80,90	84/10~99/	Mission & Differential (M/T) TRANSMISSION CASE
03901 4349	90913-02062		STARLET (FWD) 1N	86/12~99/	Engine VALVE STEM SEAL
03901 2037	90311-75004	75 x 100 x 8.5	STARLET (FWD) 2E#,4E#...EP7#,8#	84/10~95/	Engine CRANK SHAFT REAR
03901 3105	04422-10020	Kit	STARLET (FWD) EP7#,NP7#	84/10~89/	Wheel Hub FRONT
03901 8001	04422-10030	Kit	STARLET (FWD) EP8#,NP80 WITHOUT ABS	89/12~95/	Wheel Hub FRONT
03901 3891	04422-10030	Kit	STARLET (FWD) EP9#,NP90 WITHOUT ABS	96/1~99/	Wheel Hub FRONT
03901 6547	04422-10040	Kit	STARLET (FWD) EP8#,NP80 WITH ABS	89/12~95/	Wheel Hub FRONT
03901 1325	90311-36001	36 x 50 x 7	STARLET (FWD) EP7#,NP7#	84/10~89/	Wheel Hub REAR
03901 6793	90311-38037	38 x 52 x 7	STARLET (FWD) EP82,91,NP80,90	89/12~99/	Wheel Hub REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2733	90311-25011	25 x 37 x 8	STARLET (FWD) EP7#,8#,9#,NP7#,80,90	84/10~99/	Mission & Differential (M/T) INPUT SHAFT
03901 5573	90311-34012	34 x 54 x 9 x 15.5	STARLET (FWD) EP7#,82,91 3FC	84/10~99/	Mission & Differential (A/T) DIFFERENTIAL SIDE
03901 4805	90311-34016	34 x 54 x 9 x 15.5	STARLET (FWD) EP7#,82,91 (EXC. GRZV),NP7#,80,90	84/10~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 4903	90311-54004	54 x 68 x 8.5	STARLET (FWD) EP85,95 (4WD)	90/8~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 2401	90311-50015	50 x 68 x 9 x 14.5	STARLET (FWD) EP91 (GRZV)	96/1~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 6023	90311-34012	34 x 54 x 9 x 15.5	STARLET (FWD) EP7#,82,91 3FC	84/10~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 4847	90311-34013	34 x 63 x 9 x 15	STARLET (FWD) EP7#,8#,9#,NP7#,80,90 4FC	84/10~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 1497	90311-34012	34 x 54 x 9 x 15.5	STARLET (FWD) EP7#,82,91,NP70,80,90 4FC	84/10~99/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1841	90311-54004	54 x 68 x 8.5	STARLET (FWD) EP85,95 (4WD)	90/8~99/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 7661	90311-42055	42 x 55 x 7	STARLET (FWD) EP85,95 (4WD)	90/8~99/	Wheel Hub REAR
03901 6027	90311-35040	35 x 49 x 6	STARLET (FWD) 4E#...EP9#	96/4~99/	Engine CRANK SHAFT FRONT
03901 1547	90913-02056		STARLET (RWD) 3K#,4K#	81/2~84/	Engine VALVE STEM SEAL
03901 1235	90311-40108	40 x 52 x 7	STARLET (RWD) KP4#,51,6#	73/4~84/	Wheel Hub FRONT
03901 7807	90311-42055	42 x 55 x 7	STARLET (RWD) KP4#,51,6#	73/4~84/	Wheel Hub REAR
03901 6197	90311-25003	25 x 38 x 7	STARLET (RWD) KP4#,51,6#	73/4~84/	Transmission FRONT COVER
03901 7989	90311-32074	32 x 52 x 11	STARLET (RWD) KP4#,51,6#	73/4~84/	Transmission REAR
03901 2321	90311-35131	35 x 55 x 11	STARLET (RWD) KP4#,51,6#	73/4~84/	Final Drive PINION
03901 1075	90310-28038	28 x 37 x 7	STARLET (RWD) KP4#,51	73/4~78/1	Steering SECTOR SHAFT
03901 5533	90310-30035	30 x 40 x 7	STARLET (RWD) KP4#,51	73/4~78/1	Steering WORM GEAR
03901 5177	90311-15001	15 x 25 x 7	STARLET (RWD) KP6#	78/2~84/	Steering RACK HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5781	90311-38013	38.5 x 58 x 11	STARLET (RWD) 2K,3K#,4K#...KP4#,51,6#	73/4~82/5	Engine TIMING GEAR COVER
03901 5135	90311-38022	38.5 x 58 x 8.5	STARLET (RWD) 4K#...KP61	82/5~84/	Engine TIMING GEAR COVER
03901 2673	90311-70003	70 x 92 x 12	STARLET (RWD) 2K,3K#,4K#...KP4#,51,6#	73/4~82/5	Engine CRANK SHAFT REAR
03901 5563	90913-02024		STARLET (RWD) 2K,3K#,4K#	74/10~81/2	Engine VALVE STEM SEAL
03901 4019	90311-70004	70 x 92 x 8.5	STARLET (RWD) 4K#...KP61	82/5~84/	Engine CRANK SHAFT REAR
03901 2505	90080-31031	35 x 52 x 7	SUPRA JZA80 6F	93/5~	Transmission (M/T) FRONT COVER (NO.2)
03901 5799	90311-42003	42 x 60 x 7	SUPRA 7MGTEU MA70	86/2~90/	Engine TIMING GEAR CASE
03901 7037	90311-45003	45 x 62 x 8	SUPRA 1G#...GA70	86/2~93/	Engine TIMING GEAR CASE
03901 2443	90311-52003	52 x 70 x 8.5	SUPRA 7MGTEU MA70	86/2~90/	Engine TIMING GEAR COVER
03901 2313	90311-46001	46 x 63 x 6.5	SUPRA 1JZGTE JZA70	90/8~93/	Engine CRANK SHAFT FRONT
03901 6167	90311-46001	46 x 63 x 6.5	SUPRA 2JZ#...JZA80	93/5~	Engine CRANK SHAFT FRONT
03901 2139	90311-75004	75 x 100 x 8.5	SUPRA 1G#...GA70	86/2~89/10	Engine CRANK SHAFT REAR
03901 1003	90311-75007	75 x 100 x 10	SUPRA 1G#...GA70	89/10~93/	Engine CRANK SHAFT REAR
03901 4315	90311-80001	80 x 100 x 12	SUPRA 7MGTEU MA70	86/2~90/	Engine CRANK SHAFT REAR
03901 8115	90311-90006	90 x 110 x 9.5	SUPRA 1JZGTE JZA70	90/8~93/	Engine CRANK SHAFT REAR
03901 5323	90311-90006	90 x 110 x 9.5	SUPRA 2JZ#...JZA80	93/5~	Engine CRANK SHAFT REAR
03901 6019	90913-02062		SUPRA 1G# (IN. & EX.)	86/2~93/	Engine VALVE STEM SEAL
03901 5265	90913-02062		SUPRA 7MGTEU (IN. & EX.)	86/2~90/	Engine VALVE STEM SEAL
03901 6813	90029-21020	20 x 32 x 5	SUPRA 1GGEU GA70	86/2~92/	Engine OIL PUMP
03901 4595	90913-02079		SUPRA 1JZGTE,2JZ# (IN.)	90/8~	Engine VALVE STEM SEAL
03901 5391	90311-50008	50 x 77.5 x 9 x 14	SUPRA JZA80	93/5~	Wheel Hub FRONT
03901 2493	90311-38032	38 x 58 x 11	SUPRA JZA80 5F	93/5~	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4963	90311-40001	40 x 58 x 11	SUPRA MA70,JZA70	86/2~93/	Transmission (M/T) REAR EXTENTION
03901 8199	90311-38043	38 x 58 x 11	SUPRA GA70	86/2~93/	Transmission (M/T) REAR EXTENTION
03901 3375	90311-50008	50 x 77.5 x 9 x 14	SUPRA GA70	86/2~93/	Wheel Hub FRONT
03901 2305	90311-50008	50 x 77.5 x 9 x 14	SUPRA MA70	86/2~90/	Wheel Hub FRONT
03901 4527	90311-50008	50 x 77.5 x 9 x 14	SUPRA JZA70	90/8~93/	Wheel Hub FRONT
03901 2697	90080-31029	52 x 68 x 8	SUPRA JZA80 6F	93/5~	Transmission (M/T) REAR EXTENTION
03901 4809	90311-63001	63 x 90 x 7 x 10	SUPRA GA70,MA70,JZA70,80	86/2~	Wheel Hub REAR INNER
03901 2041	90311-30115	30 x 45 x 8	SUPRA GA70	86/2~93/	Transmission (M/T) FRONT COVER
03901 5115	90311-32012	32 x 53 x 7	SUPRA MA70,JZA70	86/2~93/	Transmission (M/T) FRONT COVER
03901 6359	90311-30014	30 x 45 x 8	SUPRA JZA80 5F	93/5~	Transmission (M/T) FRONT COVER
03901 1915	90069-08001	52.3 x 73 x 4.5 x 5.5	SUPRA JZA80 6F	93/5~	Transmission (M/T) FRONT COVER (NO.1)
03901 3925	90913-02062		SUPRA 1JZGTE,2JZ# (EX.)	90/8~	Engine VALVE STEM SEAL
03901 1457	90311-57001	57 x 81 x 8 x 11	SUPRA GA70,MA70,JZA70,80	86/2~	Wheel Hub REAR OUTER
03901 7579	90311-38029	38 x 55 x 7.5	SUPRA GA70,MA70,JZA70,80	86/2~	Transmission (A/T) FRONT OIL PUMP
03901 7447	90311-47008	47 x 72 x 10 x 11	SUPRA JZA80	96/5~	Final Drive DIFF. SIDE
03901 4121	90311-47008	47 x 72 x 10 x 11	SUPRA JZA80 4FC,5F	93/5~96/5	Final Drive DIFF. SIDE
03901 3627	90311-43001	43 x 70 x 9 x 15.5	SUPRA GA70,MA70,JZA70 GT,GTT,GTL,GTTR/L	86/2~93/	Final Drive DIFF. SIDE
03901 6419	90311-38011	38 x 63 x 10 x 17	SUPRA GA70 G	86/2~90/	Final Drive DIFF. SIDE
03901 7107	90311-50018	50 x 87 x 11 x 18	SUPRA JZA80 6F	93/5~96/5	Final Drive PINION
03901 3819	90311-44005	44 x 74 x 11 x 16	SUPRA JZA80	96/5~	Final Drive PINION
03901 4943	90311-44005	44 x 74 x 11 x 16	SUPRA JZA80 4FC,5F	93/5~96/5	Final Drive PINION
03901 3063	90311-38133	38 x 74 x 11	SUPRA GA70,MA70,JZA70	86/2~	Final Drive PINION
03901 4047	90311-42024	42 x 55 x 10	SUPRA JZA80 2JZGTE	93/5~	Transmission (A/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7889	90311-40001	40 x 58 x 11	SUPRA JZA80 2JZGE	93/5~	Transmission (A/T) REAR EXTENTION
03901 2189	90311-40001	40 x 58 x 11	SUPRA GA70,MA70,JZA70 GT,GTT,GTL,GTR	86/2~93/	Transmission (A/T) REAR EXTENTION
03901 4945	90311-38032	38 x 58 x 11	SUPRA GA70 G	88/8~90/	Transmission (A/T) REAR EXTENTION
03901 1835	90029-21005	18 x 30 x 5	SUPRA 1GFE GA70	88/8~90/	Engine OIL PUMP
03901 2199	90311-35013	35 x 49 x 6	SUPRA 1GF#,1GG#...GA70	86/2~93/	Engine CAM SHAFT
03901 1263	04445-14030		SUPRA GA70 GTT	88/8~93/	Steering (P/S) R & P GASKET KIT
03901 6057	04445-20040		SUPRA GA70 G,GT	88/8~93/	Steering (P/S) R & P GASKET KIT
03901 4143	04445-14040		SUPRA JZA80	93/5~	Steering (P/S) R & P GASKET KIT
03901 7763	90311-45013	45 x 98 x 10.5 x 15.5	SUPRA JZA80 6F	93/5~96/5	Final Drive DIFF. SIDE
03901 4801	90311-19002	19 x 32 x 7 x 8	SUPRA GA70,MA70,JZA70,80	88/8~	Steering (P/S) CONTROL VALVE UPPER
03901 7433	90311-38036	38 x 50 x 8	SUPRA 1GEU GA70	86/2~87/1	Engine CAM SHAFT
03901 7957	04445-14020		SUPRA MA70,JZA70	88/8~93/	Steering (P/S) R & P GASKET KIT
03901 6675	90311-35013	35 x 49 x 6	SUPRA 7MGTEU MA70	86/2~90/	Engine CAM SHAFT
03901 1875	90311-38025	38 x 50 x 6	SUPRA 1GEU GA70	97/1~90/	Engine CAM SHAFT
03901 5827	90311-38025	38 x 50 x 6	SUPRA 1JZGTE JZA70	90/8~93/	Engine CAM SHAFT
03901 2971	90311-40020	40.5 x 52.5 x 6.5	SUPRA 2JZ#...JZA80	93/5~	Engine CAM SHAFT
03901 6877	15165-70010	18 x 30 x 7	SUPRA 1GEU,1GGEU GA70	86/2~93/	Engine OIL PUMP
03901 6105	90310-30013	30 x 41 x 6.5	SUPRA GA70,MA70,JZA70,80	88/8~	Steering (P/S) CONTROL VALVE LOWER
03901 5071	90311-35013	35 x 49 x 6	TERCEL, CORSA 2E,3E,4E,5E EL3#,4#,5#	86/5~99/	Engine CAM SHAFT
03901 6749	90913-02062		TERCEL, CORSA 1N	86/5~99/	Engine VALVE STEM SEAL
03901 5447	90311-35040	35 x 49 x 6	TERCEL, CORSA 4E,5E EL5#	96/4~99/	Engine CRANK SHAFT FRONT
03901 3435	90311-70004	70 x 92 x 8.5	TERCEL, CORSA 1A,2A,3A AL1#,2#	78/8~90/	Engine CRANK SHAFT REAR
03901 3481	90913-02038		TERCEL, CORSA 1A,2A,3A	78/8~90/	Engine VALVE STEM SEAL

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4351	90311-80009	80 x 100 x 10	TERCEL, CORSA 1N NL30,40,50	86/5~99/	Engine CRANK SHAFT REAR
03901 6179	90311-80012	80 x 100 x 8.5	TERCEL, CORSA 5E EL43,45,53,55	90/9~99/	Engine CRANK SHAFT REAR
03901 3865	90311-80003	80 x 100 x 8.5	TERCEL, CORSA 3E EL31	86/5~90/	Engine CRANK SHAFT REAR
03901 2089	90311-35013	35 x 49 x 6	TERCEL, CORSA 1A,2A,3A AL1#,2#	78/8~90/	Engine CAM SHAFT
03901 3325	90311-75004	75 x 100 x 8.5	TERCEL, CORSA 2E EL30	86/5~90/	Engine CRANK SHAFT REAR
03901 7309	90913-02062		TERCEL, CORSA 2E,3E,4E,5E	86/5~99/	Engine VALVE STEM SEAL
03901 5299	90311-35040	35 x 49 x 6	TERCEL, CORSA 1N NL40,50	92/8~99/	Engine CRANK SHAFT FRONT
03901 5059	90311-35013	35 x 49 x 6	TERCEL, CORSA 1N NL30,40	86/5~92/8	Engine CRANK SHAFT FRONT
03901 1869	90311-35013	35 x 49 x 6	TERCEL, CORSA 2E,3E,4E,5E EL3#,4#,5#	86/5~96/4	Engine CRANK SHAFT FRONT
03901 5395	90029-21020	20 x 32 x 5	TERCEL, CORSA 2E,3E,4E,5E EL3#,4#,5#	86/5~99/	Engine OIL PUMP
03901 2127	90311-32020	32 x 46 x 6	TERCEL, CORSA 3A AL2#	82/5~90/	Engine OIL PUMP
03901 4113	90311-38025	38 x 50 x 6	TERCEL, CORSA 1N NL30,40,50	86/5~99/	Engine CAM SHAFT
03901 3465	90311-75009	75 x 100 x 8.5	TERCEL, CORSA 4E EL41,51	90/9~99/	Engine CRANK SHAFT REAR
03901 4977	04445- 16040/43		TERCEL, CORSA, COROLLA II EL31GP	86/5~90/	Steering (P/S) R & P GASKET KIT
03901 2265	90311-19009	19 x 37 x 6.5 x 9	TERCEL, CORSA, COROLLA II EL3#,NL30	86/5~90/	Steering (P/S) CONTROL VALVE UPPER
03901 1591	90311-26003	26 x 38 x 6.5	TERCEL, CORSA, COROLLA II EL4#,5#,NL40,50	90/9~99/	Steering (P/S) CONTROL VALVE LOWER
03901 5679	90310-23004	23 x 35 x 6.5	TERCEL, CORSA, COROLLA II AL2#,EL3#NL30	82/5~90/	Steering (P/S) CONTROL VALVE LOWER
03901 1183	90311-19010	19 x 32 x 6	TERCEL, CORSA, COROLLA II EL4#,5#,NL40,50	90/9~99/	Steering (P/S) CONTROL VALVE UPPER
03901 3221	90311-25011	25 x 37 x 8	TERCEL, CORSA, COROLLA II EL3#,4#,5#,NL30,40,50	86/5~99/	Mission & Differential (M/T) INPUT SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3699	90311-56017	56 x 73 x 88.5 x 21.5	TERCEL, CORSA, COROLLA II EL4#,NL40 WITH ABS	90/9~94/	Wheel Hub FRONT INNER
03901 5579	90311-19010	19 x 32 x 6	TERCEL, CORSA, COROLLA II AL2#	82/5~90/	Steering (P/S) CONTROL VALVE UPPER
03901 4699	90311-56016	56 x 73 x 7.5 x 15	TERCEL, CORSA, COROLLA II EL5#,NL50 WITHOUT ABS	94/9~99/	Wheel Hub FRONT INNER
03901 2677	04445-10040		TERCEL, CORSA, COROLLA II EL43 SZ, VITZ, VZ	90/9~94/	Steering (P/S) R & P GASKET KIT
03901 1221	90311-54004	54 x 68 x 8.5	TERCEL, CORSA, COROLLA II EL45,55 (4WD)	90/9~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 5077	90311-34016	34 x 54 x 9 x 15.5	TERCEL, CORSA, COROLLA II EL3#,4# (EXC.45),5# (EXC.55),NL30,40,50	86/5~99/	Mission & Differential (M/T) TRANSAXLE CASE
03901 2191	90311-32006	32 x 48 x 9 x 15.5	TERCEL, CORSA, COROLLA II AL1#,2#	78/8~90/	Mission & Differential (M/T) TRANSAXLE CASE
03901 4355	90311-34012	34 x 54 x 9 x 15.5	TERCEL, CORSA, COROLLA II EL41,51 3FC	90/9~98/3	Mission & Differential (A/T) TRANSAXLE CASE
03901 5205	90311-32006	32 x 48 x 9 x 15.5	TERCEL, CORSA, COROLLA II AL1#,2#	78/8~90/	Mission & Differential (M/T) TRANSMISSION CASE
03901 7867	90311-34016	34 x 54 x 9 x 15.5	TERCEL, CORSA, COROLLA II EL51 3FC	98/3~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 2557	90311-26001	26 x 48 x 7	TERCEL, CORSA, COROLLA II AL1#,2#	78/8~90/	Mission & Differential (M/T) INPUT SHAFT
03901 5241	90311-42055	42 x 55 x 7	TERCEL, CORSA, COROLLA II AL25,EL45,55 (4WD)	82/8~99/	Wheel Hub REAR
03901 4733	90311-38037	38 x 52 x 7	TERCEL, CORSA, COROLLA II EL4# (EXC.45),5# (EXC.55),NL40,50	90/9~99/	Wheel Hub REAR
03901 4541	90311-36001	36 x 50 x 7	TERCEL, CORSA, COROLLA II EL3#,NL30	86/5~90/	Wheel Hub REAR
03901 7929	90311-36001	36 x 50 x 7	TERCEL, CORSA, COROLLA II AL1#,2# (EXC.25)	78/8~90/	Wheel Hub REAR
03901 5347	90311-54003	54 x 66 x 7.5 x 10	TERCEL, CORSA, COROLLA II EL3#,4#,5#,NL30,40,50	86/5~99/	Wheel Hub FRONT OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3247	90311-56017	56 x 73 x 88.5 x 21.5	TERCEL, CORSA, COROLLA II EL5#,NL50 WITH ABS	94/9~99/	Wheel Hub FRONT INNER
03901 6465	90311-34017	34 x 63 x 9 x 16	TERCEL, CORSA, COROLLA II EL3#,4#,5#,NL30,40,50	86/5~99/	Mission & Differential (M/T) TRANSMISSION CASE
03901 3511	90311-15001	15 x 25 x 7	TERCEL, CORSA, COROLLA II AL1#,2#	78/8~90/	Steering (M/S) RACK HOUSING
03901 1773	04445-16110		TERCEL, CORSA, COROLLA II EL5#,NL50	95/12~99/	Steering (P/S) R & P GASKET KIT
03901 1141	04445-16090		TERCEL, CORSA, COROLLA II EL5#,NL50	94/9~95/1 2	Steering (P/S) R & P GASKET KIT
03901 6885	04445-10030		TERCEL, CORSA, COROLLA II EL4# (EXC.43SZ,VTIZ,VZ),NL40	90/9~94/	Steering (P/S) R & P GASKET KIT
03901 5085	04445-16030/33		TERCEL, CORSA, COROLLA II EL3# (EXC.31GP),NL30	86/5~90/	Steering (P/S) R & P GASKET KIT
03901 6709	04422-16010	Kit	TERCEL, CORSA, COROLLA II AL1#	78/8~82/	Wheel Hub FRONT
03901 6173	04422-16020	Kit	TERCEL, CORSA, COROLLA II AL2#	82/5~90/	Wheel Hub FRONT
03901 2649	90311-56006	56 x 73 x 77.7 x 14	TERCEL, CORSA, COROLLA II EL3#,NL30	86/5~90/	Wheel Hub FRONT INNER
03901 6769	90311-56016	56 x 73 x 7.5 x 15	TERCEL, CORSA, COROLLA II EL4#,NL40 WITHOUT ABS	90/9~94/	Wheel Hub FRONT INNER
03901 1763	90311-15001	15 x 25 x 7	TERCEL, CORSA, COROLLA II EL3#,NL30	86/5~90/	Steering (M/S) RACK HOUSING
03901 2039	90311-38020	38 x 55 x 8.5	TERCEL, CORSA, COROLLA II EL4#,5#,NL40,50	90/9~99/	Mission & Differential (A/T) FRONT OIL PUMP
03901 7347	90311-34022	34 x 56 x 9 x 15	TERCEL, CORSA, COROLLA II EL51 3FC	98/3~99/	Mission & Differential (A/T) DIFFERENTIAL SIDE
03901 1859	90311-34012	34 x 54 x 9 x 15.5	TERCEL, CORSA, COROLLA II EL41,51 3FC	90/9~98/3	Mission & Differential (A/T) DIFFERENTIAL SIDE
03901 8025	90311-54004	54 x 68 x 8.5	TERCEL, CORSA, COROLLA II EL45,55 (4WD)	90/9~99/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 1635	90311-34016	34 x 54 x 9 x 15.5	TERCEL, CORSA, COROLLA II EL53,NL50 4FC	98/2~99/	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3871	90311-34012	34 x 54 x 9 x 15.5	TERCEL, CORSA, COROLLA II EL43,53,NL40,50 4FC	90/9~98/2	Mission & Differential (A/T) TRANSAXLE HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3501	90311-34013	34 x 63 x 9 x 15	TERCEL, CORSA, COROLLA II EL43,45,53,55,NL40,50 4FC	90/9~99/	Mission & Differential (A/T) TRANSAXLE CASE
03901 3811	04445-16020		TERCEL, CORSA, COROLLA II AL2#	83/6~86/	Steering (P/S) R & P GASKET KIT
03901 1781	90311-38044	38 x 50 x 6	TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5#	90/10~	Engine CAM SHAFT
03901 5843	90311-38022	38.5 x 58 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) 5K KR41	96/11~97/ 5	Engine TIMING GEAR COVER
03901 2201	90311-38086	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) 7K KR42	96/11~97/ 5	Engine TIMING GEAR COVER
03901 7603	90311-38086	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) 5K,7K KR4#	97/5~	Engine TIMING GEAR COVER
03901 4653	90311-42003	42 x 60 x 7	TOWN ACE, LITE ACE (VAN, WAGON) 1YJ,2YU,3YEU YR2#,3#	82/11~87/ 6	Engine TIMING GEAR COVER
03901 3449	90311-42026	42 x 60 x 7	TOWN ACE, LITE ACE (VAN, WAGON) 1YJ,2Y#,3YEU YR2#,3#	87/6~96/	Engine TIMING GEAR COVER
03901 2923	90311-38036	38 x 50 x 8	TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50	96/10~97/ 8	Engine CAM SHAFT
03901 2669	90311-38025	38 x 50 x 6	TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C#...CR2#,3#	85/1~90/1 0	Engine CAM SHAFT
03901 7053	90311-38022	38.5 x 58 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) 4KJ,5KJ KR12,2#	82/5~96/	Engine TIMING GEAR COVER
03901 8071	90029-21020	20 x 32 x 5	TOWN ACE, LITE ACE (VAN, WAGON) 2C#...CR2#,3#	88/8~89/5	Engine OIL PUMP
03901 1969	90311-38067	38 x 50 x 8	TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50	97/8~	Engine CAM SHAFT
03901 4851	90311-38036	38 x 50 x 8	TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C CR2#	82/11~85/ 1	Engine CAM SHAFT
03901 5775	90311-38013	38.5 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) 3KJ,4KJ KR1#	78/8~82/5	Engine TIMING GEAR COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1283	90311-38013	38.5 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) 12RJ RR1#,2#	78/8~82/	Engine TIMING GEAR COVER
03901 1027	90311-38013	38.5 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) 2TJ,12T,13TU TR1#	76/10~82/	Engine TIMING GEAR COVER
03901 6357	90311-30016	30 x 42 x 7 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR21,22,30,31,YR21,30 FXV LIMITED	92/1~94/	Steering (P/S) CONTROL VALVE LOWER
03901 8185	90310-25004	25 x 38 x 7 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,4#,5#,KR2#,4#,YR2 #,30,SR30,	85/8~	Steering (P/S) CONTROL VALVE LOWER
03901 6555	90311-19002	19 x 32 x 7 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,4#,5#,KR2#,4#,YR2 #,30,SR30,	85/8~	Steering (P/S) CONTROL VALVE UPPER
03901 7015	90312-30001	30 x 38 x 5	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,YR2#	82/11~85/ 8	Steering (P/S) GEAR HOUSING
03901 7145	90311-19002	19 x 32 x 7 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,YR2#	82/11~85/ 8	Steering (P/S) ADJUSTER PLUG
03901 2105	04445-28070		TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50	96/10~	Steering (P/S) R & P GASKET KIT
03901 3175	04445-28041		TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR27,YR2#,3#	92/1~96/	Steering (P/S) R & P GASKET KIT
03901 7859	90029-21022	22 x 34 x 6.5	TOWN ACE, LITE ACE (VAN, WAGON) 2C#...CR2#,3#	89/5~93/8	Engine OIL PUMP
03901 4599	90913-02110		TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5#	95/11~97/ 4	Engine VALVE STEM SEAL
03901 6369	04445-28051		TOWN ACE, LITE ACE (VAN, WAGON) CR1,22,30,31,YR21,30 FXV LIMITED	92/1~94/	Steering (P/S) R & P GASKET KIT
03901 1735	90311-85007	85 x 105 x 10	TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50	96/10~	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 3887	90913-02117		TOWN ACE, LITE ACE (VAN, WAGON) 2C,3C#...CR4#,5#	97/4~	Engine VALVE STEM SEAL
03901 7695	90311-70004	70 x 92 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) 3KJ,4KJ,5KJ KR1#,2#	76/10~96/	Engine CRANK SHAFT REAR
03901 8021	90913-02094		TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#	90/11~95/ 11	Engine VALVE STEM SEAL
03901 3041	90311-15001	15 x 25 x 7	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR2#,YR2#	85/8~96/	Steering (M/S) RACK HOUSING
03901 1661	90913-02094		TOWN ACE, LITE ACE (VAN, WAGON) 1Y,2Y,3Y YR2#,3#	82/11~96/	Engine VALVE STEM SEAL
03901 6615	90913-02058		TOWN ACE, LITE ACE (VAN, WAGON) 2T,13T(EX.) TR1#	81/1~82/	Engine VALVE STEM SEAL
03901 1569	90913-02024		TOWN ACE, LITE ACE (VAN, WAGON) 2T,13T(IN.) TR1#	81/1~82/	Engine VALVE STEM SEAL
03901 4273	90913-02024		TOWN ACE, LITE ACE (VAN, WAGON) 2T,12T,13T TR1#	76/10~81/ 1	Engine VALVE STEM SEAL
03901 4381	90913-02033		TOWN ACE, LITE ACE (VAN, WAGON) 12RJ RR1#,2#	78/8~82/	Engine VALVE STEM SEAL
03901 4791	90913-02094		TOWN ACE, LITE ACE (VAN, WAGON) 5K#,7K KR2#,4#	95/8~	Engine VALVE STEM SEAL
03901 6607	90913-02110		TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C CR2#,3#	82/11~90/ 11	Engine VALVE STEM SEAL
03901 2457	90913-02024		TOWN ACE, LITE ACE (VAN, WAGON) 3KJ,4KJ KR1#	76/10~81/ 2	Engine VALVE STEM SEAL
03901 4707	15165-70010	18 x 30 x 7	TOWN ACE, LITE ACE (VAN, WAGON) 3SFE SR40,50	96/10~	Engine OIL PUMP

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7421	90311-90008	90 x 110 x 9.5 x 11.5	TOWN ACE, LITE ACE (VAN, WAGON) 2C,3C#...CR4#,5#	96/12~	Engine CRANK SHAFT REAR
03901 5405	90311-90005	90 x 110 x 8.5 x 10	TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5#	90/2~96/12	Engine CRANK SHAFT REAR
03901 7719	90311-90003	90 x 110 x 8.5 x 10	TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C#...CR2#,3#	82/11~90/2	Engine CRANK SHAFT REAR
03901 7955	90311-80009	80 x 100 x 10	TOWN ACE, LITE ACE (VAN, WAGON) 2Y#,3YEU YR2#,3#	90/4~96/	Engine CRANK SHAFT REAR
03901 2431	90311-80003	80 x 100 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) 1YJ,2Y#,3YEU YR2#,3#	82/11~90/4	Engine CRANK SHAFT REAR
03901 4201	90311-70007	70 x 92 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) 5K,7K KR4#	96/11~	Engine CRANK SHAFT REAR
03901 2847	90311-42035	42 x 60 x 7	TOWN ACE, LITE ACE (VAN, WAGON) 2SFE SR40,50	96/10~	Engine CRANK SHAFT FRONT
03901 1895	90311-42026	42 x 60 x 7	TOWN ACE, LITE ACE (VAN, WAGON) 2C#,3C#...CR2#,3#,4#,5#	90/10~	Engine CRANK SHAFT FRONT
03901 3637	90311-42015	42 x 60 x 6	TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C#...CR2#,3#	85/5~90/10	Engine CRANK SHAFT FRONT
03901 5189	90311-42003	42 x 60 x 7	TOWN ACE, LITE ACE (VAN, WAGON) 1C,2C CR2#	82/11~85/5	Engine CRANK SHAFT FRONT
03901 5599	90913-02056		TOWN ACE, LITE ACE (VAN, WAGON) 4KJ,5KJ KR12,2#	92/1~95/8	Engine VALVE STEM SEAL
03901 3031	90310-50001	50 x 70 x 9	TOWN ACE, LITE ACE (VAN, WAGON) RR10,20	78/8~79/11	Wheel Hub REAR INNER
03901 3659	90311-38043	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) KR12,TR1#,RR11,21	79/10~82/	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4139	04332-30010	Kit	TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR10,20	76/10~79/ 10	Transmission (M/T) REAR EXTENTION
03901 6867	90311-30014	30 x 45 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40	96/10~	Transmission (M/T) FRONT COVER
03901 1331	90311-30014	30 x 45 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR27,YR2#,3#	90/7~96/ 7	Transmission (M/T) FRONT COVER
03901 2965	90311-30115	30 x 45 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,YR2#,3#...5F,5H	82/11~90/ 7	Transmission (M/T) FRONT COVER
03901 7747	90311-30115	30 x 45 x 8	TOWN ACE, LITE ACE (VAN, WAGON) TR1#...5F	81/1~82/ 7	Transmission (M/T) FRONT COVER
03901 4693	90311-32106	32 x 48 x 8	TOWN ACE, LITE ACE (VAN, WAGON) KR26,YR2#...4H	82/11~90/ 8	Transmission (M/T) FRONT COVER
03901 7839	90311-32106	32 x 48 x 8	TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR1#,2#...4H	76/10~82/ 7	Transmission (M/T) FRONT COVER
03901 4225	90313-48001	48 x 62 x 9 x 24	TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 EXCEPT JUST LOW	79/11~82/ 7	Wheel Hub REAR OUTER
03901 1555	90312-35002	35 x 49 x 5.5 x 11.5	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50 ABS	96/10~	Wheel Hub REAR INNER
03901 6337	90311-38043	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) KR26,CR2#,YR2#	82/11~88/ 8	Transmission (M/T) REAR EXTENTION
03901 3351	90310-50001	50 x 70 x 9	TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 EXCEPT JUST LOW	79/11~82/ 7	Wheel Hub REAR INNER
03901 7853	90310-29001	29 x 38 x 7 x 12	TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 JUST LOW	79/11~82/ 7	Wheel Hub REAR OUTER
03901 5513	90311-52059	52 x 65 x 9	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50	96/10~	Wheel Hub REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1947	90311-52059	52 x 65 x 9	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR2#,YR2#,3#	82/11~96/	Wheel Hub REAR
03901 3961	90311-52059	52 x 65 x 9	TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#	76/10~82/	Wheel Hub REAR
03901 2811	90311-56014	56 x 78 x 7.5 x 13	TOWN ACE, LITE ACE (VAN, WAGON) CR5#,SR50 (4WD)	96/10~	Wheel Hub FRONT
03901 8265	90311-61001	61 x 76 x 7 x 10	TOWN ACE, LITE ACE (VAN, WAGON) CR5#,SR50 (4WD)	96/10~	Wheel Hub FRONT OUTER
03901 2899	90311-66002	66 x 80 x 9	TOWN ACE, LITE ACE (VAN, WAGON) CR3#,YR3# (4WD)	85/10~96/	Wheel Hub FRONT
03901 4009	90311-48001	48 x 62 x 9	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,KR4#,SR40	96/10~	Wheel Hub FRONT
03901 4169	90311-48122	48 x 62 x 7	TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR1#,2#	76/10~82/	Wheel Hub FRONT
03901 2133	90311-48001	48 x 62 x 9	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR2#,YR2#	82/11~96/	Wheel Hub FRONT
03901 3161	90311-75114	75 x 100 x 13	TOWN ACE, LITE ACE (VAN, WAGON) 2TJ,12T,13TU TR1#	76/10~82/ 10	Engine CRANK SHAFT REAR
03901 4179	90311-19008	19 x 38 x 7	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR26,YR2#	82/11~85/ 8	Steering (M/S) SECTOR SHAFT
03901 7159	90311-58001	58 x 78 x 8	TOWN ACE, LITE ACE (VAN, WAGON) RR11,21 JUST LOW	79/11~82/	Wheel Hub REAR INNER
03901 4647	90311-38133	38 x 74 x 11	TOWN ACE, LITE ACE (VAN, WAGON) CR27,KR27,YR25	95/12~96/	Final Drive REAR DIFF. PINION
03901 2299	90311-18010	18 x 30 x 8	TOWN ACE, LITE ACE (VAN, WAGON) RR1#,2#	78/8~82/	Steering (M/S) WORM GEAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 2129	90311-34001	34 x 44 x 8	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR26,YR2#	82/11~85/ 8	Steering (M/S) WORM GEAR
03901 7879	90313-48001	48 x 62 x 9 x 24	TOWN ACE, LITE ACE (VAN, WAGON) RR10,20	78/8~79/1 1	Wheel Hub REAR OUTER
03901 2461	90311-38043	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) KR26,YR25 4H	88/8~90/8	Transmission (M/T) REAR EXTENTION
03901 4233	90311-38047	38 x 74 x 11 x 18	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50	96/10~	Final Drive REAR DIFF. PINION
03901 5739	90311-38047	38 x 74 x 11 x 18	TOWN ACE, LITE ACE (VAN, WAGON) YR21 MTM E ABS	95/12~96/	Final Drive REAR DIFF. PINION
03901 3621	90311-38047	38 x 74 x 11 x 18	TOWN ACE, LITE ACE (VAN, WAGON) CR3#,YR30	95/12~96/	Final Drive REAR DIFF. PINION
03901 6395	90311-38047	38 x 74 x 11 x 18	TOWN ACE, LITE ACE (VAN, WAGON) CR22,YR21 ATM ABS	95/12~96/	Final Drive REAR DIFF. PINION
03901 2147	90311-38047	38 x 74 x 11 x 18	TOWN ACE, LITE ACE (VAN, WAGON) CR22,29 MTM	95/12~96/	Final Drive REAR DIFF. PINION
03901 1581	90311-38133	38 x 74 x 11	TOWN ACE, LITE ACE (VAN, WAGON) CR22,29,YR21 ATM	95/12~96/	Final Drive REAR DIFF. PINION
03901 2095	90311-19001	19 x 32 x 8	TOWN ACE, LITE ACE (VAN, WAGON) KR12,TR1#	81/1~82/	Steering (M/S) WORM GEAR
03901 2497	90311-38133	38 x 74 x 11	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR2#,YR2#,3#	82/11~95/ 12	Final Drive REAR DIFF. PINION
03901 5661	90311-38133	38 x 74 x 11	TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#,RR1#,2#	76/10~82/	Final Drive REAR DIFF. PINION
03901 4535	90311-38020	38 x 55 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,5#,KR4#,SR40,50	96/10~98/ 12	Transmission (A/T) FRONT OIL PUMP
03901 5603	90311-38032	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR27,YR2#...5F,5H	88/8~96/	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8027	90311-38032	38 x 58 x 11	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,KR4#,SR40	96/10~	Transmission (M/T) REAR EXTENTION
03901 6811	90311-38020	38 x 55 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,3#,KR27,YR2#,3#	82/11~96/	Transmission (A/T) FRONT OIL PUMP
03901 7701	90311-38133	38 x 74 x 11	TOWN ACE, LITE ACE (VAN, WAGON) YR21 MTM (D,E)	95/12~96/	Final Drive REAR DIFF. PINION
03901 4069	90311-32014	32 x 44 x 9	TOWN ACE, LITE ACE (VAN, WAGON) RR1#,2#	78/8~82/	Steering (M/S) SECTOR SHAFT
03901 7683	90311-38020	38 x 55 x 8.5	TOWN ACE, LITE ACE (VAN, WAGON) CR42,52,KR42	98/12~	Transmission (A/T) FRONT OIL PUMP
03901 7077	90311-38064	38 x 55 x 8.7	TOWN ACE, LITE ACE (VAN, WAGON) CR40,50,SR40,50	98/12~	Transmission (A/T) FRONT OIL PUMP
03901 7337	04332-30020	Kit	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,YR2#	82/11~88/ 8	Transmission (A/T) REAR EXTENTION
03901 4821	04332-30030	Kit	TOWN ACE, LITE ACE (VAN, WAGON) CR2#,KR27,YR2#	88/8~96/	Transmission (A/T) REAR EXTENTION
03901 2605	90310-28027	28 x 40 x 8	TOWN ACE, LITE ACE (VAN, WAGON) KR1#,TR1#	76/10~82/	Steering (M/S) SECTOR SHAFT
03901 7165	04332-30030	Kit	TOWN ACE, LITE ACE (VAN, WAGON) CR4#,KR4#,SR40	96/10~	Transmission (A/T) REAR EXTENTION
03901 3585	90311-48135	48 x 82 x 12	TOYO ACE, DYNA LY211,212,YY211 FULL JUST LOW (T4)	95/5~	Final Drive REAR DIFF. PINION
03901 4303	90311-48135	48 x 82 x 12	TOYO ACE, DYNA LY220,230,240,280,290,RZY 220,230 T4,TW4,VAN	01/7~	Final Drive REAR DIFF. PINION
03901 3381	90311-18010	18 x 30 x 8	TOYO ACE, DYNA LY5#,6#,YY5#,61	85/8~95/	Steering (M/S) WORM GEAR
03901 5899	90311-38066	38 x 74 x 11 x 48	TOYO ACE, DYNA LY12#,13#,20#,21#,YY121,1 31,201,211 ST	98/1~	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4815	90311-38066	38 x 74 x 11 x 48	TOYO ACE, DYNA LY230,RZY230 TW1	01/7~	Final Drive REAR DIFF. PINION
03901 2121	90311-38066	38 x 74 x 11 x 48	TOYO ACE, DYNA LY230,280,RZY230 (125T,15T) ST	01/7~	Final Drive REAR DIFF. PINION
03901 2311	90311-18010	18 x 30 x 8	TOYO ACE, DYNA LY2#,3#,RY2#,3#	79/3~85/	Steering (M/S) WORM GEAR
03901 2157	90311-18010	18 x 30 x 8	TOYO ACE, DYNA BY3#...TRUCK	79/3~85/	Steering (M/S) WORM GEAR
03901 2563	90311-38066	38 x 74 x 11 x 48	TOYO ACE, DYNA LY16#...TW2.LY16#...ST 15T	98/1~	Final Drive REAR DIFF. PINION
03901 5841	90311-19001	19 x 32 x 8	TOYO ACE, DYNA BY31 DUMP	83/8~85/	Steering (M/S) WORM GEAR
03901 6569	90311-32014	32 x 44 x 9	TOYO ACE, DYNA LY2#,3#,RY2#,3#	79/3~85/	Steering (M/S) SECTOR SHAFT
03901 4967	90311-32014	32 x 44 x 9	TOYO ACE, DYNA BY3#...TRUCK	79/3~85/	Steering (M/S) SECTOR SHAFT
03901 3297	90311-32014	32 x 44 x 9	TOYO ACE, DYNA LY5#,6#,YY5#,6#	85/8~95/	Steering (M/S) SECTOR SHAFT
03901 3703	90311-36104	36 x 50 x 7	TOYO ACE, DYNA BY31 DUMP	83/8~85/	Steering (M/S) SECTOR SHAFT
03901 5557	04445-25030		TOYO ACE, DYNA LY21,31	83/8~85/	Steering (P/S) P/S GEAR GASKET KIT
03901 6031	04445-25040		TOYO ACE, DYNA LY5#,6#,YY5#,61	85/8~95/	Steering (P/S) P/S GEAR GASKET KIT
03901 2979	04445-25060		TOYO ACE, DYNA LY10#,11#,20#,21#,YY101,2 01,211	95/5~	Steering (P/S) P/S GEAR GASKET KIT
03901 5591	04445-27013		TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,1 31	96/10~	Steering (P/S) R & P GASKET KIT
03901 5081	90311-19002	19 x 32 x 7 x 8	TOYO ACE, DYNA LY21,31,5#,6#,YY5#,61	83/8~95/	Steering (P/S) ADJUSTER PLUG
03901 1513	90311-48135	48 x 82 x 12	TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4)	85/8~95/	Final Drive REAR DIFF. PINION
03901 3341	90311-38133	38 x 74 x 11	TOYO ACE, DYNA LY5#,6#,YY5#,6#...EXCEPT FULL JUST LOW	85/8~95/	Final Drive REAR DIFF. PINION
03901 5083	90312-32001	32 x 42 x 5	TOYO ACE, DYNA LY21,31,5#,6#,YY5#,61	83/8~95/	Steering (P/S) GEAR HOUSING
03901 6399	90312-32001	32 x 42 x 5	TOYO ACE, DYNA LY10#,11#,20#,21#,YY101,2 01,211	95/5~	Steering (P/S) GEAR HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 8231	04445-25080		TOYO ACE, DYNA LY220,230,240,270,280,290, RZY220,230	01/7~	Steering (P/S) R & P GASKET KIT
03901 2013	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY201,211 (T2,TW2) WT	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 2975	90311-46005	46 x 63 x 7.8	TOYO ACE, DYNA LY230 TB	01/7~	Transmission (A/T) EXTENTION HOUSING
03901 7083	90311-38133	38 x 74 x 11	TOYO ACE, DYNA LY2#,3#,RY2#,3#	79/3~85/ 1	Final Drive REAR DIFF. PINION
03901 2015	90311-80009	80 x 100 x 10	TOYO ACE, DYNA 3Y#...YY101,121,131,161,20 1,211	95/5~	Engine CRANK SHAFT REAR
03901 5635	90311-38133	38 x 74 x 11	TOYO ACE, DYNA LY201,YY201 T1,T2,TW2	95/5~95/1 1	Final Drive REAR DIFF. PINION
03901 2593	90311-19002	19 x 32 x 7 x 8	TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,1 31	96/10~	Steering (M/S) CONTROL VALVE UPPER
03901 3177	90311-38133	38 x 74 x 11	TOYO ACE, DYNA LY201 T2 ST	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 3879	90311-38133	38 x 74 x 11	TOYO ACE, DYNA LY211 T2 ATM	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 6747	90311-38133	38 x 74 x 11	TOYO ACE, DYNA YY201 T1,T2,TW2	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 6301	90311-38133	38 x 74 x 11	TOYO ACE, DYNA YY211 (T2,TW2) WT	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 4697	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY51,61,YY61 ST,YY52 15T ST	89/11~95/ 1	Steering (P/S) REAR DIFF. PINION
03901 2535	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY201,YY201 ST 15T	95/5~96/3	Final Drive REAR DIFF. PINION
03901 6903	90311-38133	38 x 74 x 11	TOYO ACE, DYNA LY211,YY211 (T2,TW2) WT	95/5~95/1 1	Final Drive REAR DIFF. PINION
03901 5693	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY201 T1,TW2	95/11~96/ 1	Final Drive REAR DIFF. PINION
03901 6579	90311-48135	48 x 82 x 12	TOYO ACE, DYNA JY30,BY3#	79/3~85/ 1	Final Drive REAR DIFF. PINION
03901 6939	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY201,YY201 T1,T2,TW2	96/1~96/3	Final Drive REAR DIFF. PINION
03901 5213	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY211,YY211 (T2,TW2) WT	96/1~96/3	Final Drive REAR DIFF. PINION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7389	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY101,111,121,131,151,161, 201,211 T1,T2,T3,TW1,TW2	96/3~98/1	Final Drive REAR DIFF. PINION
03901 1259	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA YY101,121,131,201,211 T1,T2,T3,TW1,TW2	96/3~98/1	Final Drive REAR DIFF. PINION
03901 7965	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY10#,11#,15#,YY101	98/1~	Final Drive REAR DIFF. PINION
03901 6443	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY16#...(T2,T3,TW1) TS	98/1~	Final Drive REAR DIFF. PINION
03901 1779	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY12#,13#,162,20#,21#...(T2 ,TW2) WT	98/1~	Final Drive REAR DIFF. PINION
03901 1961	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA YY121,131,201,211 (T2,TW2) WT	98/1~	Final Drive REAR DIFF. PINION
03901 2267	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY230 TB 125T ST	01/7~	Final Drive REAR DIFF. PINION
03901 2793	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY220,270,RZY220 T2,T3,TW1	01/7~	Final Drive REAR DIFF. PINION
03901 6927	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY230,RZY230 (T2,TW2) TB WT	01/7~	Final Drive REAR DIFF. PINION
03901 1021	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY230,280,RZY230 (T2,T3,TW3) TS	01/7~	Final Drive REAR DIFF. PINION
03901 2463	90311-38047	38 x 74 x 11 x 18	TOYO ACE, DYNA LY211,YY211 ST	95/5~96/3	Final Drive REAR DIFF. PINION
03901 6535	90913-02036		TOYO ACE, DYNA L LY20,30	79/3~81/7	Engine VALVE STEM SEAL
03901 3661	90311-80003	80 x 100 x 8.5	TOYO ACE, DYNA 1Y,2Y,3Y#...YY5#,61	85/8~90/4	Engine CRANK SHAFT REAR
03901 5199	90311-85007	85 x 105 x 10	TOYO ACE, DYNA 2L,3L LY5#,6#	91/2~95/	Engine CRANK SHAFT REAR
03901 6957	90311-85007	85 x 105 x 10	TOYO ACE, DYNA 3L,5L LY10#,11#,12#,13#,15#,16#, 20#,21#	95/5~	Engine CRANK SHAFT REAR
03901 7385	90311-85007	85 x 105 x 10	TOYO ACE, DYNA 5L LY220,230,240,270,280,290	01/7~	Engine CRANK SHAFT REAR
03901 3829	90311-88005	88 x 106 x 8.5	TOYO ACE, DYNA 1RZE RZY220,230	01/7~	Engine CRANK SHAFT REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4889	90311-88005	88 x 106 x 8.5	TOYO ACE, DYNA 3RZFPE LY230,280	01/7~	Engine CRANK SHAFT REAR
03901 3163	90913-02033		TOYO ACE, DYNA 12R RY2#	79/3~85/	Engine VALVE STEM SEAL
03901 2079	90913-02042		TOYO ACE, DYNA 5R RY3#	79/3~85/	Engine VALVE STEM SEAL
03901 3933	90913-02094		TOYO ACE, DYNA 1Y,2Y,3Y#...YY5#,61	85/8~95/	Engine VALVE STEM SEAL
03901 2941	90913-02094		TOYO ACE, DYNA 3Y#...YY101,121,131,161,201,211	95/5~	Engine VALVE STEM SEAL
03901 7299	90311-85004	85 x 105 x 10	TOYO ACE, DYNA L,2L LY2#,31	84/2~85/	Engine CRANK SHAFT REAR
03901 5981	90913-02051		TOYO ACE, DYNA B BY3#	80/9~85/	Engine VALVE STEM SEAL
03901 6959	90311-85001	85 x 105 x 13	TOYO ACE, DYNA L,2L LY2#,3#	79/3~84/2	Engine CRANK SHAFT REAR
03901 8159	90913-02060		TOYO ACE, DYNA L,2L LY2#,3#,50,60	81/7~88/8	Engine VALVE STEM SEAL
03901 1011	90913-02110		TOYO ACE, DYNA 2L,3L LY5#,6#	88/8~95/	Engine VALVE STEM SEAL
03901 7549	90913-02110		TOYO ACE, DYNA 3L LY201,211	95/5~96/1	Engine VALVE STEM SEAL
03901 7985	90913-02110		TOYO ACE, DYNA 3L LY101,111,121,131,151,161, 201,211	96/1~97/5	Engine VALVE STEM SEAL
03901 7565	90913-02117		TOYO ACE, DYNA 3L,5L LY10#,11#,12#,15#,16#,20#, 21#	97/5~	Engine VALVE STEM SEAL
03901 3223	90913-02117		TOYO ACE, DYNA 5L LY220,230,240,270,280,290	01/7~	Engine VALVE STEM SEAL
03901 4879	90913-02110		TOYO ACE, DYNA 1RZE RZY220,230	01/7~	Engine VALVE STEM SEAL
03901 4105	90913-02079		TOYO ACE, DYNA 3RZFPE (IN.) LY230,280	01/7~	Engine VALVE STEM SEAL
03901 3517	90913-02062		TOYO ACE, DYNA 3RZFPE (EX.) LY230,280	01/7~	Engine VALVE STEM SEAL
03901 7833	90311-46005	46 x 63 x 7.8	TOYO ACE, DYNA LY132,212	99/5~	Transmission (A/T) EXTENTION HOUSING
03901 8191	90310-58002	58 x 70 x 7	TOYO ACE, DYNA LY230,280,RZY230 (12T,15T) ST	01/7~	Wheel Hub REAR INNER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 7789	90913-02044		TOYO ACE, DYNA 2J JY30	79/3~83/	Engine VALVE STEM SEAL
03901 2759	90311-48020	48 x 68 x 7	TOYO ACE, DYNA 1RZE RZY220,230	01/7~	Engine TIMING GEAR CASE
03901 1063	90311-38013	38.5 x 58 x 11	TOYO ACE, DYNA 12R RY2#	79/3~85/	Engine TIMING GEAR COVER
03901 1131	90311-45002	45 x 68 x 12	TOYO ACE, DYNA 5R RY3#	79/3~85/	Engine TIMING GEAR COVER
03901 6297	90311-42003	42 x 60 x 7	TOYO ACE, DYNA 1Y,3Y#...YY5#,61	85/8~87/8	Engine TIMING GEAR COVER
03901 5467	90311-42026	42 x 60 x 7	TOYO ACE, DYNA 2Y,3Y#...YY5#,61	87/8~95/	Engine TIMING GEAR COVER
03901 4441	90311-42026	42 x 60 x 7	TOYO ACE, DYNA 3Y#...YY101,121,131,161,201,211	95/5~	Engine TIMING GEAR COVER
03901 2163	90311-50006	50 x 72 x 12	TOYO ACE, DYNA 2J JY30	79/3~83/	Engine TIMING GEAR COVER
03901 7097	90311-50006	50 x 72 x 12	TOYO ACE, DYNA B BY3#	79/3~85/	Engine TIMING GEAR COVER
03901 5183	90311-42003	42 x 60 x 7	TOYO ACE, DYNA L,2L LY2#,3#	79/3~85/	Engine TIMING GEAR CASE
03901 4111	90311-42003	42 x 60 x 7	TOYO ACE, DYNA 2L,3L LY5#,6#	85/8~91/2	Engine TIMING GEAR CASE
03901 1317	90311-42026	42 x 60 x 7	TOYO ACE, DYNA 2L,3L LY5#,6#	91/2~95/	Engine TIMING GEAR CASE
03901 1645	90311-85004	85 x 105 x 10	TOYO ACE, DYNA 2L,3L LY5#,6#	85/8~91/2	Engine CRANK SHAFT REAR
03901 3127	90311-42026	42 x 60 x 7	TOYO ACE, DYNA 5L LY220,230,240,270,280,290	01/7~	Engine TIMING GEAR CASE
03901 2445	90310-25004	25 x 38 x 7 x 8	TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,131	96/10~	Steering (P/S) CONTROL VALVE LOWER
03901 2333	90311-48020	48 x 68 x 7	TOYO ACE, DYNA 3RZFPE LY230,280	01/7~	Engine TIMING GEAR CASE
03901 6571	90311-42003	42 x 60 x 7	TOYO ACE, DYNA L,2L LY2#,3#	79/3~85/	Engine CAM SHAFT
03901 2895	90311-42003	42 x 60 x 7	TOYO ACE, DYNA 2L LY50,60	85/8~88/8	Engine CAM SHAFT
03901 5227	90311-32020	32 x 46 x 6	TOYO ACE, DYNA 2L,3L LY5#,6#	88/8~95/	Engine CAM SHAFT
03901 5251	90311-32020	32 x 46 x 6	TOYO ACE, DYNA 3L,5L LY10#,11#,12#,13#,15#,16#,20#,21#	95/5~	Engine CAM SHAFT
03901 5185	90311-32020	32 x 46 x 6	TOYO ACE, DYNA 5L LY220,230,240,270,280,290	01/7~	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6483	11551-31010		TOYO ACE, DYNA 12R RY2#	79/3~85/	Engine CRANK SHAFT REAR
03901 7003	90311-80001	80 x 100 x 12	TOYO ACE, DYNA 5R RY3#	79/3~85/	Engine CRANK SHAFT REAR
03901 4675	90311-80009	80 x 100 x 10	TOYO ACE, DYNA 2Y,3Y#...YY5#,61	90/4~95/	Engine CRANK SHAFT REAR
03901 4907	90311-95001	95 x 115 x 12	TOYO ACE, DYNA 2J JY30	79/3~83/	Engine CRANK SHAFT REAR
03901 5565	90311-95001	95 x 115 x 12	TOYO ACE, DYNA B BY3#	79/3~85/	Engine CRANK SHAFT REAR
03901 7951	90311-42026	42 x 60 x 7	TOYO ACE, DYNA 3L,5L LY10#,11#,12#,13#,15#,16#, 20#,21#	95/5~	Engine TIMING GEAR CASE
03901 5671	90310-35001	35 x 41 x 5.5 x 9	TOYO ACE, DYNA LY5#,6#,YY5#,61 WT EXC. FULL JUST LOW	85/8~95/	Wheel Hub REAR OUTER
03901 2817	90313-48001	48 x 62 x 9 x 24	TOYO ACE, DYNA LY50,YY50 125T (T1,T3)	85/8~87/8	Wheel Hub REAR OUTER
03901 3787	90311-62001	62 x 85 x 10	TOYO ACE, DYNA LY220,230,RZY220,230 (T2,TW2) WT	01/7~	Wheel Hub REAR INNER
03901 3009	42404-36010	75 x 108 x 20	TOYO ACE, DYNA JY30,BY3#	79/3~85/	Wheel Hub REAR INNER
03901 7557	90311-75003	75 x 108 x 10 x 20	TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4)	85/8~95/	Wheel Hub REAR INNER
03901 2477	90311-75003	75 x 108 x 10 x 20	TOYO ACE, DYNA LY21#,YY211 FULL JUST LOW (T4)	95/5~	Wheel Hub REAR INNER
03901 1091	90311-75003	75 x 108 x 10 x 20	TOYO ACE, DYNA LY220,230,240,280,290,RZY 220,230 T4,TW4,VAN	01/7~	Wheel Hub REAR INNER
03901 2315	90310-58002	58 x 70 x 7	TOYO ACE, DYNA LY230,RZY230 TW1	01/7~	Wheel Hub REAR INNER
03901 2993	90313-48001	48 x 62 x 9 x 24	TOYO ACE, DYNA LY50,YY51 (T1,T2,T3) TS ST	87/8~88/8	Wheel Hub REAR OUTER
03901 3149	90313-48001	48 x 62 x 9 x 24	TOYO ACE, DYNA LY50,YY5#...(T1,T2,T3,TW) TS ST	88/8~95/	Wheel Hub REAR OUTER
03901 1163	90313-48001	48 x 62 x 9 x 24	TOYO ACE, DYNA LY10#,11#,15#,201,YY101,2 01 ST (125T,1T)	95/5~	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4567	90311-62001	62 x 85 x 10	TOYO ACE, DYNA LY12#,13#,162,YY121,131 (T2,TW2) WT	96/10~	Wheel Hub REAR INNER
03901 6937	90310-35001	35 x 41 x 5.5 x 9	TOYO ACE, DYNA LY2#,3#,RY2#,3#...DOUBL E TIRE	79/3~85/	Wheel Hub REAR OUTER
03901 3697	90311-62001	62 x 85 x 10	TOYO ACE, DYNA LY5#,6#,YY5#,61 WT EXC.FULL JUST LOW	85/8~95/	Wheel Hub REAR INNER
03901 5569	90310-35001	35 x 41 x 5.5 x 9	TOYO ACE, DYNA LY121,131,201,211,YY121,1 31,201,211 (T2,TW2) WT	95/5~97/1 2	Wheel Hub REAR OUTER
03901 8105	90310-36003	36 x 41 x 5.5 x 9	TOYO ACE, DYNA LY123,13#,162,YY121,131 (T2,TW2) WT	97/12~	Wheel Hub REAR OUTER
03901 5549	90310-36003	36 x 41 x 5.5 x 9	TOYO ACE, DYNA LY20#,21#,YY201,211 (T2,TW2) WT	97/12~	Wheel Hub REAR OUTER
03901 7643	90310-36003	36 x 41 x 5.5 x 9	TOYO ACE, DYNA LY220,230,RZY220,230 (T2,TW2) WT	01/7~	Wheel Hub REAR OUTER
03901 1725	90310-38033	38 x 44 x 18	TOYO ACE, DYNA JY30,BY3#	79/3~85/	Wheel Hub REAR OUTER
03901 4713	90310-38033	38 x 44 x 18	TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4)	85/8~95/	Wheel Hub REAR OUTER
03901 7769	90310-38033	38 x 44 x 18	TOYO ACE, DYNA LY21#,YY211 FULL JUST LOW (T4)	95/5~	Wheel Hub REAR OUTER
03901 5867	90310-38033	38 x 44 x 18	TOYO ACE, DYNA LY220,230,240,280,290,RZY 220,230 T4,TW4,VAN	01/7~	Wheel Hub REAR OUTER
03901 2929	90313-54001	54 x 64 x 9 x 24	TOYO ACE, DYNA LY220,270,RZY220 ST	01/7~	Wheel Hub REAR OUTER
03901 2359	90313-54001	54 x 64 x 9 x 24	TOYO ACE, DYNA LY230,280,RZY230 9T2,T3,TW3) (125T,1T)	01/7~	Wheel Hub REAR OUTER
03901 6697	90313-62001	62 x 81 x 7.5 x 17.5	TOYO ACE, DYNA LY230,RZY230 TW1	01/7~	Wheel Hub REAR OUTER
03901 1453	90313-48001	48 x 62 x 9 x 24	TOYO ACE, DYNA LY16#...(T2,T3,TW1) TS	95/5~	Wheel Hub REAR OUTER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5119	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY50,YY51 TW,LY50 T3..TB	87/8~88/8	Wheel Hub REAR
03901 4407	90311-50003	50 x 73 x 9	TOYO ACE, DYNA LY2#,3#,RY2#,3#	79/3~85/	Wheel Hub FRONT
03901 1651	90311-50003	50 x 73 x 9	TOYO ACE, DYNA LY5#,6#,YY5#,61 EXC. FULL JUST LOW	85/8~95/	Wheel Hub FRONT
03901 4003	90311-50003	50 x 73 x 9	TOYO ACE, DYNA LY20#,21#,YY201,211 EXC. FULL JUST LOW	95/5~	Wheel Hub FRONT
03901 1625	90311-68001	68 x 90 x 10	TOYO ACE, DYNA JY30,BY3#	79/3~85/	Wheel Hub FRONT
03901 2987	90311-68001	68 x 90 x 10	TOYO ACE, DYNA LY60,61,YY61 FULL JUST LOW (T4)	85/5~95/	Wheel Hub FRONT
03901 5129	90311-68001	68 x 90 x 10	TOYO ACE, DYNA LY21#,YY211 FULL JUST LOW (T4)	95/5~	Wheel Hub FRONT
03901 1067	90311-50136	50 x 68 x 9	TOYO ACE, DYNA LY10#,11#,YY101	96/10~	Wheel Hub FRONT
03901 4337	90311-66001	66 x 85 x 8 x 10	TOYO ACE, DYNA LY12#,13#,15#,16#,YY121,1 31	96/10~	Wheel Hub FRONT
03901 3805	90311-66001	66 x 85 x 8 x 10	TOYO ACE, DYNA LY220,230,240,270,280,290, RZY220,230	01/7~	Wheel Hub FRONT
03901 3335	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY2#,3#,RY2#,3#...SINGLE TIRE	79/3~85/	Wheel Hub REAR
03901 6783	90311-62001	62 x 85 x 10	TOYO ACE, DYNA LY20#,21#,YY201,211 (T2,TW2) WT	95/5~	Wheel Hub REAR INNER
03901 2791	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY60,YY52,61 (T2,T3,TW) ST	87/8~88/8	Wheel Hub REAR
03901 7141	90311-28004	28.6 x 43 x 6.5	TOYO ACE, DYNA BY31 DUMP	83/5~85/	Transmission (M/T) FRONT COVER
03901 2025	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY51,61,YY61 ST,YY52 15T ST	88/8~95/	Wheel Hub REAR
03901 5687	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY12#,13#,202,21#,YY121,1 31,211 ST	95/5~	Wheel Hub REAR
03901 1531	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY16#...TW2,LY16#,201,Y Y201 ST 15T	95/5~	Wheel Hub REAR

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 5013	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY50,YY50 125T (T1,T3)	85/8~87/8	Wheel Hub REAR INNER
03901 3899	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY50,YY51 (T1,T2,T3) TS ST	87/8~88/8	Wheel Hub REAR INNER
03901 1035	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY50,YY5#...(T1,T2,T3,TW) TS ST	88/8~95/	Wheel Hub REAR INNER
03901 3835	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY10#,11#,15#,201,YY101,2 01 ST (125T,1T)	95/5~	Wheel Hub REAR INNER
03901 5457	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY16#...(T2,T3,TW1) TS	95/5~	Wheel Hub REAR INNER
03901 5355	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY220,270,RZY220 ST	01/7~	Wheel Hub REAR INNER
03901 6739	90310-50001	50 x 70 x 9	TOYO ACE, DYNA LY230,280,RZY230 (T2,T3,TW3) (125T,1T)	01/7~	Wheel Hub REAR INNER
03901 4245	90311-62001	62 x 85 x 10	TOYO ACE, DYNA LY2#,3#,RY2#,3#...DOUBL E TIRE	79/3~85/	Wheel Hub REAR INNER
03901 5337	90311-47001	47.5 x 70.6 x 9	TOYO ACE, DYNA LY50,60,YY5#...ST (TW1,15T)	85/8~87/8	Wheel Hub REAR
03901 2659	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY230,RZY230 125T,15T,175T	01/7~	Transmission (M/T) REAR EXTENTION
03901 3927	90311-38032	38 x 58 x 11	TOYO ACE, DYNA LY230,RZY230 (T2,TW3) (125T,1T)	01/7~	Transmission (M/T) REAR EXTENTION
03901 1759	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY2#,3#,RY2#,3#	79/3~85/	Transmission (M/T) REAR EXTENTION
03901 5203	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY50,60,YY5#,61 TW,15T	85/8~87/8	Transmission (M/T) REAR EXTENTION
03901 7711	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY50,51 TW,LY60,YY52	87/8~88/8	Transmission (M/T) REAR EXTENTION
03901 3729	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY50 (T2,T3) 15T,YY61 T2,T3,T4	87/8~88/8	Transmission (M/T) REAR EXTENTION
03901 3099	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY61 TW1,YY61 TW TB	87/8~88/8	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6129	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY51,61,YY61	88/8~95/	Transmission (M/T) REAR EXTENTION
03901 5039	90311-38093	38 x 65 x 9	TOYO ACE, DYNA YY52 15T	88/8~95/	Transmission (M/T) REAR EXTENTION
03901 2671	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY201,YY201 WT	95/5~	Transmission (M/T) REAR EXTENTION
03901 1375	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY201,YY201 ST 15T	95/5~	Transmission (M/T) REAR EXTENTION
03901 6409	90313-62001	62 x 81 x 7.5 x 17.5	TOYO ACE, DYNA LY230,280,RZY230 (125T,15T) ST	01/7~	Wheel Hub REAR OUTER
03901 6691	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY220,240,290,RZY220 WT	01/7~	Transmission (M/T) REAR EXTENTION
03901 5697	90311-38032	38 x 58 x 11	TOYO ACE, DYNA LY50,YY5#...125T,1T	88/8~95/	Transmission (M/T) REAR EXTENTION
03901 2469	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY230,RZY230 (TW1,TW2,TW4) 125T	01/7~	Transmission (M/T) REAR EXTENTION
03901 7155	90311-38020	38 x 55 x 8.5	TOYO ACE, DYNA YY61	94/6~95/	Transmission (A/T) FRONT OIL PUMP
03901 2679	90311-38020	38 x 55 x 8.5	TOYO ACE, DYNA YY211 125T LPG	95/5~96/6	Transmission (A/T) FRONT OIL PUMP
03901 7699	90311-38020	38 x 55 x 8.5	TOYO ACE, DYNA LY10#,11#,16#,YY211 CBR,DEL	96/10~	Transmission (A/T) FRONT OIL PUMP
03901 8255	90311-38058	38 x 55 x 8.5	TOYO ACE, DYNA YY211 125T LPG	96/6~	Transmission (A/T) FRONT OIL PUMP
03901 6165	90311-38029	38 x 55 x 7.5	TOYO ACE, DYNA LY13#,21#	95/5~	Transmission (A/T) FRONT OIL PUMP
03901 2447	90311-38029	38 x 55 x 7.5	TOYO ACE, DYNA LY230,280 TB	01/7~	Transmission (A/T) FRONT OIL PUMP
03901 5229	90311-38064	38 x 55 x 8.7	TOYO ACE, DYNA LY220,230,280,RZY220,230 TS	01/7~	Transmission (A/T) FRONT OIL PUMP
03901 6629	04332-30030	Kit	TOYO ACE, DYNA YY61	94/6~95/	Transmission (A/T) EXTENTION HOUSING

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4423	04332-30030	Kit	TOYO ACE, DYNA LY10#,11#YY211	95/5~	Transmission (A/T) EXTENTION HOUSING
03901 6183	04332-30030	Kit	TOYO ACE, DYNA LY220,230,RZY220,230 125T ST	01/7~	Transmission (A/T) EXTENTION HOUSING
03901 2707	90311-38093	38 x 65 x 9	TOYO ACE, DYNA LY12#,13#,202,213,YY121,1 31,211	95/5~	Transmission (M/T) REAR EXTENTION
03901 6865	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY51,61,YY61,YY52 15T	88/8~95/	Transmission (M/T) FRONT COVER
03901 3693	90311-45007	45 x 62 x 8	TOYO ACE, DYNA LY131,211	95/5~99/5	Transmission (A/T) EXTENTION HOUSING
03901 1343	90311-30115	30 x 45 x 8	TOYO ACE, DYNA LY50 125T (T1,T2,T3)	85/8~87/8	Transmission (M/T) FRONT COVER
03901 4331	90311-30115	30 x 45 x 8	TOYO ACE, DYNA LY50,YY51 125T	87/8~88/8	Transmission (M/T) FRONT COVER
03901 1293	90311-30115	30 x 45 x 8	TOYO ACE, DYNA LY50,YY51	88/8~90/7	Transmission (M/T) FRONT COVER
03901 5709	90311-300014	30 x 45 x 8	TOYO ACE, DYNA LY50,YY5#...125T,1T	90/7~95/	Transmission (M/T) FRONT COVER
03901 4383	90311-300014	30 x 45 x 8	TOYO ACE, DYNA LY10#,11#,201,YY101,201 ST (125T,1T)	95/5~	Transmission (M/T) FRONT COVER
03901 6705	90311-300014	30 x 45 x 8	TOYO ACE, DYNA LY220,RZY220 ST	01/7~	Transmission (M/T) FRONT COVER
03901 8005	90311-300014	30 x 45 x 8	TOYO ACE, DYNA LY230,RZY230 (T2,TW3) (125T,1T)	01/7~	Transmission (M/T) FRONT COVER
03901 1323	90311-32106	32 x 48 x 8	TOYO ACE, DYNA JY30,BY3# (TRUCK)	79/3~85/	Transmission (M/T) FRONT COVER
03901 2323	90311-32106	32 x 48 x 8	TOYO ACE, DYNA YY50 T1,T2,T3	85/8~87/8	Transmission (M/T) FRONT COVER
03901 3487	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY50,YY51 TW,LY60,YY52	87/8~88/8	Transmission (M/T) FRONT COVER
03901 2003	90311-38032	38 x 58 x 11	TOYO ACE, DYNA LY220,RZY220 ST	01/7~	Transmission (M/T) REAR EXTENTION
03901 2629	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY61 TW1,YY61 TW TB	87/8~88/8	Transmission (M/T) FRONT COVER
03901 4309	90311-38032	38 x 58 x 11	TOYO ACE, DYNA LY10#,11#,201,YY101,201 ST (125T,1T)	95/5~	Transmission (M/T) REAR EXTENTION

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1307	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY12#,13,15#,16#,201,21#,Y Y121,131,211	95/5~	Transmission (M/T) FRONT COVER
03901 4607	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY201,YY201 WT	95/5~	Transmission (M/T) FRONT COVER
03901 5717	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY201,YY211 ST 15T	95/5~	Transmission (M/T) FRONT COVER
03901 5663	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY220,240,290,RZY220 WT	01/7~	Transmission (M/T) FRONT COVER
03901 3813	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY230,RZY230 125T,15T,175T	01/7~	Transmission (M/T) FRONT COVER
03901 2051	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY230,RZY230 (TW1,TW2,TW4) 125T	01/7~	Transmission (M/T) FRONT COVER
03901 6439	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY270,280	01/7~	Transmission (M/T) FRONT COVER
03901 1367	90311-45001	45 x 62 x 9	TOYO ACE, DYNA JY30,BY3#	79/3~85/	Transmission (M/T) REAR EXTENTION
03901 2275	90311-38043	38 x 58 x 11	TOYO ACE, DYNA LY50,YY50 125T (T1,T2,T3)	85/8~87/8	Transmission (M/T) REAR EXTENTION
03901 4215	90311-38043	38 x 58 x 11	TOYO ACE, DYNA LY50,YY51	87/8~88/8	Transmission (M/T) REAR EXTENTION
03901 3197	90311-28004	28.6 x 43 x 6.5	TOYO ACE, DYNA LY2#,3#,RY2#,3#	79/3~85/	Transmission (M/T) FRONT COVER
03901 6085	90311-32012	32 x 53 x 7	TOYO ACE, DYNA LY50 (T2,T3) 15T,YY61 T2,T3,T4	87/8~88/8	Transmission (M/T) FRONT COVER
03901 1145	90311-40001	40 x 58 x 11	VEROSSA GX115,JZX110	01/6~	Transmission (A/T) REAR EXTENTION
03901 1857	90311-38064	38 x 55 x 8.7	VEROSSA GX110	01/6~	Transmission (A/T) FRONT OIL PUMP
03901 1985	90311-38032	38 x 58 x 11	VEROSSA GX110	01/6~	Transmission (A/T) REAR EXTENTION
03901 4659	90311-38070	38 x 74 x 11 x 19	VEROSSA GX11#,JZX110	01/6~	Final Drive PINION
03901 1815	90311-38071	38 x 63 x 10 x 16.5	VEROSSA GX11#,JZX110 9EXC.VR25)	01/6~	Final Drive DIFF. SIDE
03901 6455	90311-43001	43 x 70 x 9 x 15.5	VEROSSA JZX110 (VR25)	01/6~	Final Drive DIFF. SIDE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1273	90311-38029	38 x 55 x 7.5	VEROSSA GX115,JZX110	01/6~	Transmission (A/T) FRONT OIL PUMP
03901 2097	90311-40020	40.5 x 52.5 x 6.5	VEROSSA 1JZGTE JZX110	01/6~	Engine CAM SHAFT (NO.1)
03901 5855	90913-02079		VEROSSA 1JZ# (IN.)	01/6~	Engine VALVE STEM SEAL
03901 3507	90913-02093		VEROSSA 1GFE (IN. & EX.)	01/6~	Engine VALVE STEM SEAL
03901 5913	90311-90006	90 x 110 x 9.5	VEROSSA 1JZ#...JZX110	01/6~	Engine CRANK SHAFT REAR
03901 7349	90311-75007	75 x 100 x 10	VEROSSA 1GFE GX110	01/6~	Engine CRANK SHAFT REAR
03901 3143	90311-46001	46 x 63 x 6.5	VEROSSA 1JZ#...JZX110	01/6~	Engine CRANK SHAFT FRONT
03901 5963	90913-02062		VEROSSA 1JZ# (EX.)	01/6~	Engine VALVE STEM SEAL
03901 3123	90311-38056	38 x 52.5 x 6	VEROSSA 1JZGTE JZX110	01/6~	Engine CAM SHAFT (NO.2)
03901 5607	04445-22290		VEROSSA GX115	01/6~	Steering (P/S) R & P GASKET KIT
03901 4985	90311-34027	34 x 56 x 6	VEROSSA 1JZFSE JZX110	01/6~	Engine CAM SHAFT
03901 3691	04445-22280		VEROSSA GX110,JZX110	01/6~	Steering (P/S) R & P GASKET KIT
03901 6029	90311-35013	35 x 49 x 6	VEROSSA 1GFE GX110	01/6~	Engine CAM SHAFT
03901 1989	90311-40001	40 x 58 x 11	VEROSSA JZX110 5F	01/6~	Transmission (M/T) REAR EXTENTION
03901 3215	90311-32012	32 x 53 x 7	VEROSSA JZX110 5F	01/6~	Transmission (M/T) FRONT COVER
03901 5711	90311-48013	48 x 73 x 7	VEROSSA GX110,JZX110	01/6~	Wheel Hub FRONT
03901 6819	90311-45015	45 x 62 x 9	VEROSSA 1GFE GX110	01/6~	Engine TIMING GEAR CASE
03901 1805	90311-38075	38 x 55 x 7.8	VITZ, PLATZ NCP1#	99/8~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 3201	90311-75016	75 x 107 x 8	VITZ, PLATZ 1NZFE,2NZFE NCP1#	99/8~	Engine CRANK SHAFT REAR
03901 4853	90311-73001	73.5 x 89 x 8.5	VITZ, PLATZ 1SZFE SCP1#	99/1~	Engine CRANK SHAFT REAR
03901 1789	90311-25021	25.5 x 37.5 x 6	VITZ, PLATZ 1NZFE,2NZFE NCP1#	99/8~	Engine OIL PUMP
03901 5353	90311-35040	35 x 49 x 6	VITZ, PLATZ 1SZFE SCP1#	99/1~	Engine TIMING GEAR COVER

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 4677	04445-52010		VITZ, PLATZ NCP15,16 (4WD)	99/9~	Steering (P/S) R & P GASKET KIT
03901 7609	04445-52020		VITZ, PLATZ SCP1#,NCP10,12	99/1~	Steering (P/S) R & P GASKET KIT
03901 7213	90913-02093		VITZ, PLATZ 1NZFE,2NZFE(IN. & EX.)	99/8~	Engine VALVE STEM SEAL
03901 5681	90311-38075	38 x 55 x 7.8	VITZ, PLATZ SCP1#,NCP1#	99/6~	Mission & Differential (A/T) FRONT OIL PUMP
03901 2145	90311-49003	49 x 68 x 8.5	VITZ, PLATZ NCP15,16 (4WD)	99/9~	Mission & Differential (M/T) TRANSAXLE CASE
03901 1201	90311-38075	38 x 55 x 7.8	VITZ, PLATZ SCP1#	99/1~99/6	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 8051	90311-49002	50 x 64 x 8	VITZ, PLATZ NCP15,16 (4WD)	99/8~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 1587	90311-34016	34 x 54 x 9 x 15.5	VITZ, PLATZ NCP110,12	99/9~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 3061	90311-34017	34 x 63 x 9 x 16	VITZ, PLATZ NCP1#	99/9~	Mission & Differential (A/T) TRANSAXLE CASE
03901 7487	90311-34016	34 x 54 x 9 x 15.5	VITZ, PLATZ NCP110,12	99/9~	Mission & Differential (M/T) TRANSAXLE CASE
03901 2351	90311-38076	38 x 63 x 9 x 15.5	VITZ, PLATZ SCP1#	99/1~	Mission & Differential (A/T) TRANSAXLE CASE
03901 5179	90913-02120		VITZ, PLATZ 1SZFE	99/1~	Engine VALVE STEM SEAL
03901 1883	90311-42055	42 x 55 x 7	VITZ, PLATZ NCP15,16 (4WD)	99/8~	Wheel Hub REAR
03901 4533	90311-23004	23 x 37 x 7	VITZ, PLATZ SCP1#	99/1~	Mission & Differential (M/T) INPUT SHAFT
03901 4237	90311-38074	38 x 54 x 9 x 15.5	VITZ, PLATZ SCP1#	99/1~	Mission & Differential (M/T) TRANSAXLE CASE
03901 4969	90311-34017	34 x 63 x 9 x 16	VITZ, PLATZ NCP1#	99/9~	Mission & Differential (M/T) TRANSMISSION CASE
03901 4609	90311-38074	38 x 54 x 9 x 15.5	VITZ, PLATZ SCP1#	99/1~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 4039	90311-38073	38 x 56 x 9 x 15.5	VITZ, PLATZ SCP1#	99/1~	Mission & Differential (M/T) TRANSMISSION CASE

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 6201	90311-17009	17.5 x 32 x 6	VITZ, PLATZ SCP1#	99/1~	Steering (M/S) RACK HOUSING
03901 3153	90311-25011	25 x 37 x 8	VITZ, PLATZ NCP1#	99/9~	Mission & Differential (M/T) INPUT SHAFT
03901 6411	90311-25021	25.5 x 37.5 x 6	WILL VI 2NZFE NCP19	00/1~	Engine OIL PUMP
03901 4521	90311-34016	34 x 54 x 9 x 15.5	WILL VI NCP19	00/1~	Mission & Differential (A/T) TRANSAXLE CASE (NO.2)
03901 8117	90311-38075	38 x 55 x 7.8	WILL VI NCP19	00/1~	Mission & Differential (A/T) TRANSAXLE HOUSING
03901 5605	04445-52020		WILL VI NCP19	00/1~	Steering (P/S) R & P GASKET KIT
03901 5925	90311-75016	75 x 107 x 8	WILL VI 2NZFE NCP19	00/1~	Engine CRANK SHAFT REAR
03901 4439	90913-02093		WILL VI 2NZFE (IN. & EX.)	00/1~	Engine VALVE STEM SEAL
03901 6881	90311-34017	34 x 63 x 9 x 16	WILL VI NCP19	00/1~	Mission & Differential (A/T) TRANSAXLE CASE
03901 3159	90311-38075	38 x 55 x 7.8	WILL VI NCP19	00/1~	Mission & Differential (A/T) FRONT OIL PUMP
03901 2931	90311-38034	38 x 50 x 10.5	WINDOM 1MZFE,2MZFE MCV2#	96/8~	Engine CAM SHAFT
03901 1611	90311-19010	19 x 32 x 6	WINDOM VCV1#,MCV2#	91/10~	Steering (P/S) CONTROL VALVE UPPER
03901 2547	90913-02111		WINDOM 1MZFE,2MZFE(EX.)	96/8~	Engine VALVE STEM SEAL
03901 5833	90913-02101		WINDOM 1MZFE,2MZFE(IN.)	96/8~	Engine VALVE STEM SEAL
03901 7515	90913-02062		WINDOM 3VZFE,4VZFE(EX.)	91/10~96/	Engine VALVE STEM SEAL
03901 1633	90913-02095		WINDOM 3VZFE,4VZFE(IN.)	91/10~96/	Engine VALVE STEM SEAL
03901 3229	90311-92008	92 x 110 x 9	WINDOM 1MZFE,2MZFE MCV2#	96/8~	Engine CRANK SHAFT REAR
03901 7363	90311-92005	92 x 110 x 10	WINDOM 3VZFE,4VZFE VCV1#	91/10~96/	Engine CRANK SHAFT REAR
03901 5911	90311-40022	40 x 55 x 6	WINDOM 1MZFE,2MZFE MCV2#	96/8~	Engine OIL PUMP
03901 3011	90311-26003	26 x 38 x 6.5	WINDOM VCV1#,MCV2#	91/10~	Steering (P/S) CONTROL VALVE UPPER
03901 7231	90311-38034	38 x 50 x 10.5	WINDOM 3VZFE,4VZFE VCV1#	91/10~96/	Engine CAM SHAFT

5. Seals product list

5.1 TOYOTA

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03901 1939	90311-40010	40 x 56 x 9 x 15.5	WINDOM VCV1#	91/10~96/	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 2859	04445-33070		WINDOM MCV2#	96/8~	Steering (P/S) R & P GASKET KIT
03901 7105	04445-33030		WINDOM VCV11	94/9~96/	Steering (P/S) R & P GASKET KIT
03901 5813	04445-33012		WINDOM VCV11	93/8~94/9	Steering (P/S) R & P GASKET KIT
03901 6765	04445-33040		WINDOM VCV10	94/9~96/	Steering (P/S) R & P GASKET KIT
03901 2617	04445-33023		WINDOM VCV10	91/10~94/9	Steering (P/S) R & P GASKET KIT
03901 6083	90311-38020	38 x 55 x 8.5	WINDOM VCV,MCV2#	91/10~	Mission & Differential (A/T) FRONT OIL PUMP
03901 4925	90311-50011	50 x 80 x 16.5 x 23	WINDOM VCV,MCV2#	91/10~	Mission & Differential (A/T) DIFF. SIDE
03901 4583	90311-40010	40 x 56 x 9 x 15.5	WINDOM MCV2#	96/8~	Mission & Differential (A/T) FRONT DIFFERENTIAL
03901 2639	90311-40022	40 x 55 x 6	WINDOM 3VZFE,4VZFE VCV1#	91/10~96/	Engine OIL PUMP

SERVICE WORLDWIDE

For over 10 years, we have continuously strived to improve our business to efficiently meet every customer demand. Now, SNT is providing Worldwide Service that will help drive your business growth endlessly and sustainably.



SNT AUTOPART GROUP

HEADQUARTERS

SNT AUTOPART ENTERPRISE, LLC.

Empire State Building
350 Fifth Avenue, 59th Floor
New York, NY 10118 U.S.A.
Telephone: (+1)917-979-6883
Fax: (+1)917-979-6884
E-mail: info@sntautopart.com

ASIA-PACIFIC OFFICE

SNT AUTOPART INTERTRADE Co., Ltd.

All Seasons Place
36th Floor, CRC Tower,
87/2 Wireless Road, Pathumwan,
Bangkok 10330 Thailand
Telephone: (+66)2-105-6155
Fax: (+66)2-105-6155 Ext.4
E-mail: info@sntautopart.com

FACTORY

SNT MACHINE LIMITED PARTNERSHIP

18/3 Rama II Road,
Samaedam, Bangkhuntien,
Bangkok 10150 Thailand
Telephone: (+66)2-897-0968
Fax: (+66)2-897-0968
E-mail: info@sntautopart.com



www.sntautopart.com