

PICKUP



TRUCK



BUILT TOUGH



TRAILER



HEAVY-DUTY EQUIPMENT



Oil Seals

CATALOG



SNT AUTOPART GROUP
www.sntautopart.com



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

1. FOREWORD

Rubber parts are in our DNA. It's not marketing speak. SNT produce only the highest quality products. If you need something custom, our engineering and design team can help assist with your unique rubber part requirements with our warranty guarantee. **We are different and we want to show why that's good for you.**

We know that having the right part at the right time is crucial to your operation. Under the SNT brand, we carry more than 30,000 SKUs.

We believe the best method to get our products to the customer is through strategic alliances with our distribution partners. Our commitment to our distributors, and the ultimate user, is to constantly introduce new and innovative products at higher levels of quality with an emphasis on compressed lead times - products that will last longer and reduce overall maintenance costs. All of our employees have a "can do" attitude and take pride in helping customers. **You have a problem? We have a solution.** All we ask is the chance to prove ourselves; you won't be disappointed!

Content Remarks

All rubber parts in this catalogue are specially manufactured by SNT. The O.E.M. Part No., Interchange Part No., Auto maker name, and all other trademarks mentioned in this document are the property of their respective owners and are used for identification purposes only.



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

2. INTRODUCTION

SNT AUTOPART GROUP is a leading manufacturer of replacement parts. For over 30 years experience, SNT supplies the high quality rubber parts successfully. We win worldwide clients' trust based on **premium quality of products, excellent service and competitive price.**

Our top executive has more than 7 years of R&D experience at the top 3 automobile companies in the world, create a perfect knowledge of products. Moreover, SNT products are manufactured according to German standard (DIN) and ISO 9001 quality management system. So we guarantee to

“SNT products are the same characteristics of original spare parts with competitive price”

SNT AUTOPART GROUP is comprised of the following companies:

1. SNT AUTOPART ENTERPRISE, LLC. (New York, U.S.A.)
2. SNT AUTOPART INTERTRADE Co., Ltd. (Bangkok, Thailand)
3. SNT MACHINE Ltd., Part. (Bangkok, Thailand)



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

2.1 ISO 9001 CERTIFICATION

globalgroup
Management System Experts®

Certificate of Registration

This is to certify that the

QUALITY MANAGEMENT SYSTEM

of

S.N.T. MACHINE LTD., PART.

18/3 Soi Bangkradee19 Yeak6, RAMA II Road, Bangkhuntien, Bangkok, 10150, THAILAND

for

Design and Manufacture of Rubber Parts and Stamping Parts, Oil Seals, Rubber Bushings, Torque Rod Bushings, Engine Mounts for Automotives, Motorcycles and Industrial Machineries.

has been assessed and registered against the provisions of

ISO 9001:2008

International Standard

With

Registration Number:	44Q16937	Project:	11-16937-1-Q
Certification Date:	11 December 2015	Code:	DH 25.13
Recertification Due Date:	14 September 2018	Exclusions:	7.5.4, 7.5.2
Certification Approved By:		Alan Cherry	
		Chairman	

Registration is subject to the management system being continually maintained to the above standard under regular surveillance. Should surveillance not take place when required, registration shall be removed.

This certificate is the property of GlobalGROUP of Companies Limited
21 Lansdowne Crescent, Edinburgh, Midlothian, EH12 5EH, Scotland, United Kingdom


0039

Please validate the authenticity of the certificate at www.globalgroup.net


30002530


3. SNT WARRANTY

SNT, warrants that all products sold shall be free from defects in material and workmanship for period of one year from date of shipment. At our option, any products prove to be defective either in workmanship or material whereby it is not suitable under proper usage and service for the purpose for which designed shall be replaced free of charge including transportation charges, but not the cost of installation, providing that the products are not subject to negligence, accident, or damages beyond our control. We shall not be responsible for consequential damages.

4. MEMBERSHIPS

SNT AUTOPART GROUP is long standing members and supporter of the following associations.

- 1) THE FEDERATION OF THAI INDUSTRIES
- 2) THE THAI CHAMBER OF COMMERCE
- 3) THAILAND AUTOMOTIVE INSTITUTE
- 4) THAI AUTO PARTS MANUFACTURERS ASSOCIATION



THE FEDERATION OF THAI INDUSTRIES



5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6387	9828-55110	55 x 72 x 9 x 15	BUS RB145,1W,RH160,1W	85/2~	Transmission REAR COVER
03908 5683	9828-55110	55 x 72 x 9 x 15	BUS RJ170,172,RR170,172	80/10~83/11	Transmission REAR COVER
03908 5035	9828-55110	55 x 72 x 9 x 15	BUS RL30#.32#	75/~81/	Transmission REAR COVER
03908 5011	9828-55110	55 x 72 x 9 x 15	BUS AM,AC140 5 SPEED T/M	76/~89/	Transmission REAR COVER
03908 6891	9828-47101	47 x 65 x 9	BUS AB115,2W,RB115,2W	85/2~	Transmission REAR COVER
03908 5635	9828-55119	55 x 78 x 12	BUS HT23#,2M,HU23#,2M EE DRIVE	85/8~	Transmission FRONT COVER
03908 3915	9828-55113	55 x 72 x 9	BUS HT23#,2M,HU23#,2M EXCEPT EE DRIVE	85/8~	Transmission FRONT COVER
03908 7379	13719-1020		BUS W04C,H06C,H07C,H07D	89/11~95/6	Engine VALVE STEM SEAL
03908 2547	9828-55113	55 x 72 x 9	BUS RU1F,2F,3F	90/7~	Transmission FRONT COVER
03908 7867	9828-55113	55 x 72 x 9	BUS RT22#,RU22#,60#,63#	82/10~90/	Transmission FRONT COVER
03908 5155	9828-55113	55 x 72 x 9	BUS RC,RS,RV	78/~84/	Transmission FRONT COVER
03908 8379	9828-60119	60 x 75 x 9 x 15	BUS AC140 6 SPEED T/M	83/8~89/	Transmission REAR COVER
03908 5331	9828-55113	55 x 72 x 9	BUS HT27#,3K,HU27#,3K	83/12~	Transmission FRONT COVER
03908 7211	9828-60119	60 x 75 x 9 x 15	BUS RJ170,171,RR170,171,172 ,191,192	83/12~90/	Transmission REAR COVER
03908 6931	9828-60119	60 x 75 x 9 x 15	BUS RH1J,RJ3H,1J,RR2H,3H, 1J	90/9~	Transmission REAR COVER
03908 5843	9828-60119	60 x 75 x 9 x 15	BUS RJ172 6 SPEED T/M	83/12~90/	Transmission REAR COVER
03908 1523	9828-60119	60 x 75 x 9 x 15	BUS RT174,RU174,192,3H	86/8~	Transmission REAR COVER
03908 1507	9828-60119	60 x 75 x 9 x 15	BUS CH160,3H,1J	87/12~	Transmission REAR COVER
03908 6491	9828-65108	65 x 95 x 14 x 22	BUS RC,RE,RS	69/~79/12	Transmission REAR COVER
03908 2115	9828-70101	70 x 95 x 14 x 20.5	BUS RC,RE	80/1~84/	Transmission REAR COVER
03908 3379	9828-70101	70 x 95 x 14 x 20.5	BUS RS1#,3#...6 SPEED	80/1~82/	Transmission REAR COVER
03908 7075	9828-70101	70 x 95 x 14 x 20.5	BUS RV7#,5#...6 SPEED	78/5~82/	Transmission REAR COVER
03908 4451	9828-70101	70 x 95 x 14 x 20.5	BUS RU22#,RT22#	82/10~90/	Transmission REAR COVER
03908 2971	9828-48120	48 x 60 x 9	BUS RT174,RU174,192,3H,CH 1J	86/8~	Transmission FRONT COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6635	13719-1360		BUS J05C,J08C	95/7~98/1	Engine VALVE STEM SEAL
03908 4107	9828-57103	57 x 124 x 13	BUS RH,RJ,RR,CH,HR	84/~	Wheel Hub REAR OUTER
03908 3851	13719-1470		BUS J05C,J08C	98/2~	Engine VALVE STEM SEAL
03908 8243	9828-66106	66 x 134 x 16	BUS RK	84/~90/	Wheel Hub REAR OUTER
03908 4931	9828-70101	70 x 95 x 14 x 20.5	BUS HT#,HU#	83/12~	Transmission REAR COVER
03908 6971	9828-85106	84 x 100 x 10	BUS AB,AC,AM,RB	76/~	Wheel Hub FRONT
03908 5675	9828-01137	101 x 114 x 10	BUS RH,RJ,RL,RR,CH	75/~	Wheel Hub FRONT
03908 7387	9828-01207	138 x 152 x 12	BUS RC,RE,RK,RM,RS,RT,R U,RV,HR,HT,HU	69/~	Wheel Hub FRONT
03908 5747	9828-01136	116 x 132 x 11	BUS AC,AM	76/~89/	Wheel Hub REAR INNER
03908 7707	9828-01204	145 x 164 x 14	BUS RK	84/~90/	Wheel Hub REAR INNER
03908 3099	9828-01203	127 x 147 x 11	BUS RH,RJ,RR,CH,HR	84/~	Wheel Hub REAR INNER
03908 8171	9828-01130	146 x 170 x 18	BUS RC,RE,RS,RV	69/~84/	Wheel Hub REAR INNER
03908 3691	9828-01193	154 x 175 x 13	BUS RM,RT,RU,HT,HU	82/~	Wheel Hub REAR INNER
03908 8091	9828-40101	40 x 50 x 6.5	BUS AC,AM	76/~89/	Wheel Hub REAR OUTER
03908 2875	9828-48112	48 x 109 x 13	BUS AB,RB	85/~	Wheel Hub REAR OUTER
03908 8475	9828-60108	60 x 74 x 7.5	BUS RC,RE,RS,RV	69/~84/	Wheel Hub REAR OUTER
03908 3731	9828-01149	120 x 140 x 12	BUS RJ,RL,RR	75/~83/	Wheel Hub REAR INNER
03908 2587	9828-48120	48 x 60 x 9	BUS RJ172 5 SPEED T/M	83/12~90/	Transmission FRONT COVER
03908 5107	9828-01228	100 x 135 x 17	BUS J05C,J08C	95/7~	Engine CRANK SHAFT REAR
03908 1411	9828-76101	76 x 164 x 14	BUS RM,RT,RU,HT,HU	82/~	Wheel Hub REAR OUTER
03908 8155	9828-30101	30 x 42 x 8	BUS AB115,RB115	85/2~90/	Transmission FRONT COVER
03908 4939	9828-37103	37 x 50 x 6	BUS AC140,AM101 5 SPEED,RB14#	80/1~89/	Transmission FRONT COVER
03908 6979	9828-37103	37 x 50 x 6	BUS RJ170,172,RR170,172	80/10~83/11	Transmission FRONT COVER
03908 1619	9828-37103	37 x 50 x 6	BUS RL301,321	80/1~81/	Transmission FRONT COVER
03908 5651	9828-43102	43 x 63 x 9	BUS AC140 6 SPEED T/M	83/8~89/	Transmission FRONT COVER
03908 2067	9828-43102	43 x 63 x 9	BUS AB2W,RB1W,2W,CH#,RH#	87/12~	Transmission FRONT COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7683	9828-43102	43 x 63 x 9	BUS RJ170,RR170	83/12~88/	Transmission FRONT COVER
03908 8371	9828-43102	43 x 63 x 9	BUS RJ172,RR172 6 SPEED T/M	83/12~90/	Transmission FRONT COVER
03908 6907	9828-48120	48 x 60 x 9	BUS RJ171,3H,1J,RR171,191,192,2H,3H,1J	88/10~	Transmission FRONT COVER
03908 7507	9828-45104	45 x 55 x 7.5	BUS RJ,RL,RR	75/~83/	Wheel Hub REAR OUTER
03908 8443	9828-65113	65 x 114 x 10 x 25.5	BUS RJ#,RR#	88/10~98/6	Final Drive PINION
03908 6779	9828-58105	58 x 75 x 9	BUS EC100,EH100,300 RL,AM	70/~77/	Engine CRANK SHAFT FRONT
03908 3107	9828-80117	80 x 136 x 9 x 25.5	BUS HT#,HU#,RU1F,2F,3F,4F	00/4~	Final Drive PINION
03908 3019	9828-80114	80 x 136 x 9 x 25	BUS RU1F,2F,3F,4F	98/10~00/3	Final Drive PINION
03908 6715	9828-65130	65 x 105 x 9 x 25	BUS HR#	01/11~	Final Drive PINION
03908 6483	9828-65127	65 x 114 x 9 x 25	BUS HR#	99/1~01/10	Final Drive PINION
03908 2691	9828-65127	65 x 114 x 9 x 25	BUS RH#,RR#,CH#	98/7~	Final Drive PINION
03908 3843	9828-80110	80 x 136 x 20 x 26	BUS RU1F,2F,3F,4F	90/7~98/9	Final Drive PINION
03908 8427	9828-80110	80 x 136 x 20 x 26	BUS RU60#,63#	85/9~90/	Final Drive PINION
03908 8339	9828-80115	80 x 124 x 19 x 25	BUS HT#,HU#	83/12~00/3	Final Drive PINION
03908 6411	9828-80115	80 x 124 x 19 x 25	BUS RU60#,63#	82/6~85/8	Final Drive PINION
03908 1075	9828-75111	75 x 100 x 13 x 18	BUS RC,RE,RS,RV	69/~84/	Final Drive PINION
03908 1027	9828-65116	65 x 88 x 12 x 19	BUS EC100,EH100,300 RL,AM	78/~83/	Engine CRANK SHAFT FRONT
03908 4947	9828-65113	65 x 114 x 10 x 25.5	BUS RH#,CH#	87/12~98/6	Final Drive PINION
03908 2283	9828-80115	80 x 124 x 19 x 25	BUS RU3H,1J	90/6~	Final Drive PINION
03908 7739	9828-65113	65 x 114 x 10 x 25.5	BUS RJ17#,RR17#...REDUCTION RATIO 4.100	83/12~88/9	Final Drive PINION
03908 7107	9828-63104	63 x 100 x 12	BUS RJ17#,RR17#...REDUCTION RATIO 5.142,5.571	83/12~88/9	Final Drive PINION
03908 6803	9828-63104	63 x 100 x 12	BUS RJ#,RR#	80/10~83/11	Final Drive PINION
03908 4499	9828-63104	63 x 100 x 12	BUS RL	75/4~81/	Final Drive PINION
03908 4571	9828-58109	58 x 102 x 8 x 22	BUS AB,RB	85/2~	Final Drive PINION
03908 6435	9828-52111	52 x 100 x 15	BUS AC,AM	76/~89/	Final Drive PINION
03908 6603	9828-75119	75 x 100 x 13 x 19	BUS RU60#,63#,1F,2F,3F	82/6~	Transmission REAR COVER
03908 6683	9828-75119	75 x 100 x 13 x 19	BUS RV5#...5 SPEED T/M	78/5~82/	Transmission REAR COVER
03908 4883	9828-75119	75 x 100 x 13 x 19	BUS RS3#...5 SPEED T/M	80/1~82/	Transmission REAR COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7171	9828-01206	107 x 123 x 11	BUS AB,RB	85/~	Wheel Hub REAR INNER
03908 4643	9828-01226	125 x 177 x 17.5	BUS F17D,F20C,F21C	95/7~	Engine CRANK SHAFT REAR
03908 7459	9828-65113	65 x 114 x 10 x 25.5	BUS RT174,RU174,192	86/8~90/	Final Drive PINION
03908 4131	9828-01168	135 x 165 x 14 x 20.5	BUS EF3#,5#,7#	78/~90/	Engine CRANK SHAFT REAR
03908 1899	9828-01223	116 x 151 x 17	BUS P11C,M10U,K13U	95/4~	Engine CRANK SHAFT REAR
03908 4955	9828-01200	122 x 150 x 12 x 18	BUS EM100 RT22#,RU22#	82/10~90/	Engine CRANK SHAFT REAR
03908 8323	9828-80115	80 x 124 x 19 x 25	BUS RT22#,RU22#	82/10~89/	Final Drive PINION
03908 1691	9828-01168	135 x 165 x 14 x 20.5	BUS F17#,F20C	90/7~95/6	Engine CRANK SHAFT REAR
03908 5027	9828-65116	65 x 88 x 12 x 19	BUS EH700 RL,RJ,RR	80/~83/	Engine CRANK SHAFT FRONT
03908 3987	9828-01168	135 x 165 x 14 x 20.5	BUS ER200,EB200,400	78/~84/	Engine CRANK SHAFT REAR
03908 7907	9828-01158	130 x 161 x 14	BUS DK20	69/~78/	Engine CRANK SHAFT REAR
03908 2803	9828-00109	100 x 120 x 13 x 18	BUS W04#,W06#	83/~	Engine CRANK SHAFT REAR
03908 5587	9828-01167	106 x 126 x 12	BUS H06#,H07#	83/~	Engine CRANK SHAFT REAR
03908 7323	9828-01167	106 x 126 x 12	BUS EH300,500,700	74/~83/	Engine CRANK SHAFT REAR
03908 1435	9828-00107	100 x 120 x 13	BUS EC100,EH100	69/~83/	Engine CRANK SHAFT REAR
03908 8035	9828-79103	79 x 114 x 17	BUS J05C,J08C	95/7~	Engine CRANK SHAFT FRONT
03908 7395	9828-96109	96 x 131 x 17.5	BUS F17D,F20C,F21C	85/7~	Engine CRANK SHAFT FRONT
03908 3051	9828-83103	83 x 118 x 18	BUS M10U	95/4~	Engine CRANK SHAFT FRONT
03908 7811	9828-75111	75 x 100 x 13 x 18	BUS DK20 RC1#,3#,4#	69/~78/	Engine CRANK SHAFT FRONT
03908 7235	9828-65116	65 x 88 x 12 x 19	BUS H06#,H07#...RT174,RU174,192,3H,CH3H	86/8~	Engine CRANK SHAFT FRONT
03908 4331	9828-01201	125 x 155 x 14 x 23	BUS EK200	79/~	Engine CRANK SHAFT REAR
03908 8131	9828-65116	65 x 88 x 12 x 19	BUS H06#,H07#...RJ#,RR#	83/~	Engine CRANK SHAFT FRONT
03908 3667	9828-75145	75 x 114 x 17	BUS K13U	95/4~	Engine CRANK SHAFT FRONT
03908 7435	9828-58104	58 x 75 x 9 x 14.5	BUS W04#,W06#...AB#,AC#,RH#,RB#,CH160	83/~	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3643	9828-80102	80 x 105 x 13	BUS ER200,EB200,400 RC301,321,RE#	78/~84/	Engine CRANK SHAFT FRONT
03908 7971	9828-70102	70 x 95 x 13	BUS EK200 RC7#	79/~83/	Engine CRANK SHAFT FRONT
03908 2651	9828-70110	70 x 95 x 13 x 20	BUS EK200 HT27#,HU27#	84/~90/	Engine CRANK SHAFT FRONT
03908 6859	9828-96101	96 x 124 x 14 x 21	BUS EF3#,5#,7#...RS#,RV#,RU 60#,63#	78/~90/	Engine CRANK SHAFT FRONT
03908 4835	9828-96101	96 x 124 x 14 x 21	BUS F17#,F20C RU1F,2F,3F	90/7~95/6	Engine CRANK SHAFT FRONT
03908 5995	9828-75140	75 x 100 x 13 x 20	BUS EM100 RT22#,RU22#	82/10~90/	Engine CRANK SHAFT FRONT
03908 6051	9828-75140	75 x 100 x 13 x 20	BUS P11C	99/6~	Engine CRANK SHAFT FRONT
03908 3611	1-09625-444-0	78 x 163 x 16	BUS CRA,CSA,CQ,CH,CL,CJ, CP AIR BRAKE	79/10~84/	Wheel Hub REAR OUTER
03908 6251	1-12569-009-0		BUS 8P#,10P#,12P#	84/3~91/6	Engine VALVE STEM SEAL
03908 4787	1-09625-425-1	120 x 153 x 15	BUS LV 8PC	88/8~89/	Engine CRANK SHAFT REAR
03908 7715	1-09625-525-2	111 x 153 x 16.5	BUS LV 8P#,10P#,12P#	93/3~	Engine CRANK SHAFT REAR
03908 3707	1-09625-559-0	139-171-19 x x	BUS LV 8TD1	00/4~	Engine CRANK SHAFT REAR
03908 1723	5-12569-001-0		BUS 6BG1	84/3~90/6	Engine VALVE STEM SEAL
03908 2227	9-12569-058-0		BUS 6QA2,6QB2	84/3~95/	Engine VALVE STEM SEAL
03908 3011	1-09625-013-0		BUS 6RB2	84/3~95/	Engine VALVE STEM SEAL
03908 1267	9-09924-415-0	100 x 145 x 14.5 x 26	BUS BA	66/~79/	Wheel Hub REAR INNER
03908 6347	1-09625-444-0	78 x 163 x 16	BUS LT AIR SUS.	89/4~00/3	Wheel Hub REAR OUTER
03908 6851	1-09625-350-0	117 x 174 x 15.5 x 28	BUS LT ALL	00/4~	Wheel Hub REAR INNER
03908 3459	1-09625-350-0	117 x 174 x 15.5 x 28	BUS LT AIR SUS.	89/4~00/3	Wheel Hub REAR INNER
03908 1307	1-09625-350-0	117 x 174 x 15.5 x 28	BUS LV	84/3~	Wheel Hub REAR INNER
03908 6619	9-09924-393-0	123 x 184 x 15 x 28	BUS CRA,CSA,CQ,CH,CL,CJ, CP AIR BRAKE	79/10~84/	Wheel Hub REAR INNER
03908 4075	1-09625-351-0	115 x 156 x 15.5 x 31	BUS CRA,CSA,CQ,CH,CL,CJ, CP OIL BRAKE	76/~84/	Wheel Hub REAR INNER
03908 2723	1-09625-351-0	115 x 156 x 15.5 x 31	BUS BU	67/~79/	Wheel Hub REAR INNER
03908 1627	1-09625-569-0	95 x 132 x 12 x 21.5	BUS CDM	82/5~84/	Wheel Hub REAR INNER
03908 6459	9-09924-470-0	64 x 132.5 x 13	BUS BA	69/~79/	Wheel Hub REAR OUTER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4803	9-09924-415-0	100 x 145 x 14.5 x 26	BUS ECM,EDM	78/11~84/	Wheel Hub REAR INNER
03908 6611	9-09924-470-0	64 x 132.5 x 13	BUS ECM,EDM	78/11~82/	Wheel Hub REAR OUTER
03908 7667	1-09625-041-0	120 x 140 x 10.5	BUS LT ALL	95/7~	Wheel Hub FRONT
03908 2395	1-09625-041-0	120 x 140 x 10.5	BUS LT AIR SUS.	89/4~95/	Wheel Hub FRONT
03908 8491	1-09625-041-0	120 x 140 x 10.5	BUS LV	84/3~	Wheel Hub FRONT
03908 7011	1-09625-041-0	120 x 140 x 10.5	BUS CRA,CSA,CQ,CH,CL,CJ, CP	76/~84/	Wheel Hub FRONT
03908 2259	1-09625-041-0	120 x 140 x 10.5	BUS BU	73/7~79/	Wheel Hub FRONT
03908 2819	1-09625-129-0	85 x 128 x 11 x 21	BUS LT LEAF SUS.	84/3~95/	Wheel Hub FRONT
03908 4739	1-09625-129-0	85 x 128 x 11 x 21	BUS ECM,EDM	78/11~84/	Wheel Hub FRONT
03908 3899	1-09625-568-0	75 x 112 x 10 x 17.5	BUS CDM	82/5~84/	Wheel Hub FRONT
03908 5499	9-09924-407-0	76 x 115 x 13 x 21	BUS BA	66/~79/	Wheel Hub FRONT
03908 2451	9-09924-415-0	100 x 145 x 14.5 x 26	BUS LT LEAF SUS.	84/3~00/3	Wheel Hub REAR INNER
03908 1419	1-09625-502-0	40 x 55 x 9	BUS ECM,EDM,CDM	78/11~84/	Transmission FRONT COVER
03908 3603	1-12569-019-1		BUS 8TD1	00/4~	Engine VALVE STEM SEAL
03908 1667	8-94396-609-2		BUS 6HE1,6HH1	90/7~99/5	Engine VALVE STEM SEAL
03908 5067	8-97120-307-0		BUS 6HH1	99/6~	Engine VALVE STEM SEAL
03908 3475	1-09625-497-0	48 x 62 x 9	BUS LV7#	86/11~90/5	Transmission FRONT COVER
03908 4147	1-09625-497-0	48 x 62 x 9	BUS LV2#,3#	84/3~89/10	Transmission FRONT COVER
03908 7227	1-09625-497-0	48 x 62 x 9	BUS CQ,CH	81/11~84/	Transmission FRONT COVER
03908 4587	1-09625-497-0	48 x 62 x 9	BUS CRA,CSA	80/~84/	Transmission FRONT COVER
03908 6555	1-09625-502-0	40 x 55 x 9	BUS LT	84/3~93/6	Transmission FRONT COVER
03908 6811	9-09924-351-0	86 x 130 x 15	BUS BA	66/~68/	Wheel Hub REAR OUTER
03908 1699	1-09625-502-0	40 x 55 x 9	BUS CRA	77/8~79/	Transmission FRONT COVER
03908 3635	1-12569-019-1		BUS 8P#,10P#,12P#	91/6~	Engine VALVE STEM SEAL
03908 3123	1-09625-502-0	40 x 55 x 9	BUS BA,BU45KYZ	73/~79/	Transmission FRONT COVER
03908 2619	1-09625-444-0	78 x 163 x 16	BUS LT ALL	00/4~	Wheel Hub REAR OUTER
03908 3443	1-09625-444-0	78 x 163 x 16	BUS LV	84/3~	Wheel Hub REAR OUTER
03908 6443	1-09625-524-3	111 x 153 x 16.5	BUS LV 8TD1	00/4~	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7955	1-09625-379-0	74 x 142.9 x 17.5	BUS CRA,CSA,CQ,CH,CL,CJ, CP OIL BRAKE	79/10~84/	Wheel Hub REAR OUTER
03908 7611	9-09924-374-0	71 x 142 x 14	BUS CRA	76/~79/9	Wheel Hub REAR OUTER
03908 4691	9-09924-374-0	71 x 142 x 14	BUS BU	87/~79/	Wheel Hub REAR OUTER
03908 7475	1-09625-331-0	56 x 122 x 10.5	BUS CDM	82/5~84/	Wheel Hub REAR OUTER
03908 1019	9-09924-470-0	64 x 132.5 x 13	BUS LT LEAF SUS.	84/3~00/3	Wheel Hub REAR OUTER
03908 1931	1-09625-502-0	40 x 55 x 9	BUS CP	80/2~84/	Transmission FRONT COVER
03908 7483	1-09625-565-0	40 x 55 x 7	BUS LT	93/7~	Transmission FRONT COVER
03908 6827	1-09625-484-0	60 x 103 x 12 x 20	BUS BA	77/6~79/	Final Drive PINION
03908 3939	1-09625-173-0	60 x 77 x 12	BUS BA	66/~77/5	Final Drive PINION
03908 5235	1-09625-515-0	67 x 90 x 12	BUS LV MLH T/M	86/4~99/	Transmission REAR COVER
03908 1755	1-09625-578-1	78 x 97 x 13	BUS LV MAL,MAP T/M	95/4~	Transmission REAR COVER
03908 4619	1-09625-579-1	74 x 97 x 13	BUS LV MAF T/M	86/4~95/	Transmission REAR COVER
03908 2571	1-09625-579-1	74 x 97 x 13	BUS LV ALL	84/3~86/3	Transmission REAR COVER
03908 2755	1-09625-579-1	74 x 97 x 13	BUS CQ,CH MAB5	83/6~84/	Transmission REAR COVER
03908 4867	1-09625-207-0	73 x 96 x 12	BUS CQ,CH MAB5	82/1~83/5	Transmission REAR COVER
03908 7835	1-09625-207-0	73 x 96 x 12	BUS CQ,CH MAB6	82/1~84/	Transmission REAR COVER
03908 5003	1-09625-207-0	73 x 96 x 12	BUS CP	80/2~84/	Transmission REAR COVER
03908 5923	1-09625-207-0	73 x 96 x 12	BUS CRA,CSA	80/~84/	Transmission REAR COVER
03908 4019	1-09625-149-0	80 x 105 x 12	BUS CRA	77/8~79/	Transmission REAR COVER
03908 7035	1-09625-484-0	60 x 103 x 12 x 20	BUS EMC,EDM,CDM	78/11~84/	Final Drive PINION
03908 4875	1-09625-063-0	68 x 90 x 12	BUS CL,CJ	80/2~84/	Transmission REAR COVER
03908 4779	1-09625-201-0	120 x 153 x 15 x 18	BUS CRA,CSA	77/8~84/	Engine CRANK SHAFT REAR
03908 1811	1-09625-063-0	68 x 90 x 12	BUS BU EXCEPT 45KYZ	69/~79/	Transmission REAR COVER
03908 8059	1-09625-505-0	60 x 77 x 12	BUS LT	90/3~	Transmission REAR COVER
03908 7627	1-09625-173-0	60 x 77 x 12	BUS LT	84/3~90/2	Transmission REAR COVER
03908 4307	1-09625-173-0	60 x 77 x 12	BUS BA,ECM,EDM,CDM	66/~84/	Transmission REAR COVER
03908 5099	1-09625-562-0	54 x 69 x 9	BUS LV7#	90/6~	Transmission FRONT COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 1563	1-09625-562-0	54 x 69 x 9	BUS LV2#,3#	89/11~	Transmission FRONT COVER
03908 3171	1-09625-507-1	120 x 153 x 17	BUS LV 10PC,D	88/8~93/2	Engine CRANK SHAFT REAR
03908 2459	1-09625-507-1	120 x 153 x 17	BUS LV 8PC,10PC	84/3~88/7	Engine CRANK SHAFT REAR
03908 6939	1-09625-439-1	105 x 135 x 15	BUS LT 6B#	84/3~90/6	Engine CRANK SHAFT REAR
03908 6123	1-09625-441-0	128 x 148 x 14	BUS LV 6QA2,6QB2,6RB2	86/4~95/	Engine CRANK SHAFT REAR
03908 5043	9-09924-356-0	105 x 135 x 14	BUS BA	74/1~79/	Engine CRANK SHAFT REAR
03908 4179	1-09625-317-0	128 x 148 x 10	BUS CQ,CH,CL,CJ,CP	80/2~84/	Engine CRANK SHAFT REAR
03908 7299	1-09625-317-0	128 x 148 x 10	BUS BU	75/~79/	Engine CRANK SHAFT REAR
03908 2251	1-09625-149-0	80 x 105 x 12	BUS BU45KYZ	75/~79/	Transmission REAR COVER
03908 6563	1-09625-524-3	111 x 153 x 16.5	BUS LV 8P#,10P#,12P#	93/3~	Engine CRANK SHAFT FRONT
03908 3363	1-09625-317-0	128 x 148 x 10	BUS LV 6QA2,6RB2	84/3~87/	Engine CRANK SHAFT REAR
03908 8347	1-09625-484-0	60 x 103 x 12 x 20	BUS LT LEAF SUS.	84/3~00/3	Final Drive PINION
03908 6867	5-09625-052-0	100 x 135 x 15	BUS ECM,EDM,CDM	78/11~84/	Engine CRANK SHAFT REAR
03908 5443	1-09625-424-0	120 x 153 x 13 x 15	BUS LV 8PC	88/8~89/	Engine CRANK SHAFT FRONT
03908 3235	1-09625-506-0	120 x 153 x 15	BUS LV 10PC,D	88/8~93/2	Engine CRANK SHAFT FRONT
03908 5691	1-09625-506-0	120 x 153 x 15	BUS LV 8PC,10PC	84/3~88/7	Engine CRANK SHAFT FRONT
03908 5315	1-09625-200-0	120 x 153 x 15	BUS CRA,CSA	77/8~84/	Engine CRANK SHAFT FRONT
03908 4163	1-09625-442-0	70 x 92 x 12	BUS LV 6QA2,6QB2,6RB2	88/8~95/	Engine CRANK SHAFT FRONT
03908 1499	1-09625-316-0	70 x 92 x 10 x 16	BUS LV 6QA2,6RB2	84/3~88/7	Engine CRANK SHAFT FRONT
03908 5171	1-09625-316-0	70 x 92 x 10 x 16	BUS CQ,CH,CL,CJ,CP	80/2~84/	Engine CRANK SHAFT FRONT
03908 2843	1-09625-316-0	70 x 92 x 10 x 16	BUS BU	77/4~79/	Engine CRANK SHAFT FRONT
03908 3115	1-09625-316-0	70 x 92 x 10 x 16	BUS BA	76/6~79/	Engine CRANK SHAFT FRONT
03908 7019	1-09625-128-0	70 x 92 x 12	BUS BU	67/~77/3	Engine CRANK SHAFT FRONT
03908 6067	1-09625-128-0	70 x 92 x 12	BUS BA	66/~76/5	Engine CRANK SHAFT FRONT
03908 3243	1-09625-017-0	68 x 124 x 11.5 x 27	BUS LV7#	84/4~	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4811	1-09625-063-0	68 x 90 x 12	BUS BU	69/79/	Final Drive PINION
03908 6795	1-09625-063-0	68 x 90 x 12	BUS CRA	77/8~79/	Final Drive PINION
03908 7635	8-97602-378-0	104 x 137 x 13	BUS LT 6HE1,6HH1	90/7~	Engine CRANK SHAFT FRONT
03908 1243	1-09625-017-0	68 x 124 x 11.5 x 27	BUS LV2#,3#...15.5INCH,16.51 NCH DIFF..	84/3~	Final Drive PINION
03908 7619	1-09625-063-0	68 x 90 x 12	BUS CL,CJ,CP	80/2~84/	Final Drive PINION
03908 1115	1-09625-017-0	68 x 124 x 11.5 x 27	BUS LT AIR SUS.	89/4~00/3	Final Drive PINION
03908 2859	1-09625-017-0	68 x 124 x 11.5 x 27	BUS LT ALL	00/4~	Final Drive PINION
03908 7179	1-09625-322-0	86 x 143 x 10 x 38	BUS LV2#,3#...17.5INCH DIFF.	92/6~99/	Final Drive PINION
03908 6595	8-97602-379-0	104 x 139 x 13	BUS LT 6HE16HH1	90/7~	Engine CRANK SHAFT REAR
03908 3515	8-94373-765-0	60 x 82 x 12	BUS ECM,EDM,CDM	78/11~84/	Engine CRANK SHAFT FRONT
03908 5819	1-09625-319-0	60 x x 82 x 10	BUS LT 6BG1	84/3~87/12	Engine CRANK SHAFT FRONT
03908 7123	1-09625-438-0	60 x 82 x 12	BUS LT 6BG1	88/1~90/6	Engine CRANK SHAFT FRONT
03908 5211	1-09625-017-0	68 x 124 x 11.5 x 27	BUS CRA,CSA,CQ,CH	80/~84/	Final Drive PINION
03908 3091	90311-95008	95 x 115 x 9.5 x 12	RANGER (3.5T) FB4J EAA-XB J05C	97/11~00/	Engine CRANK SHAFT REAR
03908 5019	9828-79103	79 x 114 x 17	RANGER (3.5T) FB J05C	95/2~97/11	Engine CRANK SHAFT FRONT
03908 7651	9828-47101	47 x 65 x 9	RANGER (3.5T) FB	84/6~95/1	Transmission REAR COVER
03908 5915	90311-48011	48 x 62 x 9	RANGER (3.5T) FB	95/2~00/	Transmission REAR COVER
03908 8355	9828-52111	52 x 100 x 15	RANGER (3.5T) KM	65/~86/	Final Drive PINION
03908 4859	9828-58109	58 x 102 x 8 x 22	RANGER (3.5T) FB	84/6~98/7	Final Drive PINION
03908 4659	90311-35023	35 x 48 x 6.5	RANGER (3.5T) FB	95/2~00/	Transmission FRONT COVER
03908 5267	9828-55105	55 x 72 x 9	RANGER (3.5T) KM DM100,DQ100	71/~83/	Engine CRANK SHAFT FRONT
03908 3947	9828-30101	30 x 42 x 8	RANGER (3.5T) FB	84/6~90/4	Transmission FRONT COVER
03908 7787	9828-52112	52 x 70 x 9	RANGER (3.5T) KM	65/~86/	Transmission REAR COVER
03908 6739	9828-79103	79 x 114 x 17	RANGER (3.5T) EXCEPT FB4J EAA-XB J05C	97/11~00/	Engine CRANK SHAFT FRONT
03908 3195	90311-50013	50 x 72 x 9 x 14	RANGER (3.5T) FB4J EAA-XB J05C	97/11~00/	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 1995	9828-90108	90 x 110 x 13	RANGER (3.5T) KM DM100,DQ100	71/~83/	Engine CRANK SHAFT REAR
03908 8459	9828-00109	100 x 120 x 13 x 18	RANGER (3.5T) KM,FB W04D	83/~95/1	Engine CRANK SHAFT REAR
03908 7563	9828-01228	100 x 135 x 17	RANGER (3.5T) EXCEPT FB4J EAA-XB J05C	97/11~00/	Engine CRANK SHAFT REAR
03908 2595	13719-1020		RANGER (3.5T) W04D	83/~95/	Engine VALVE STEM SEAL
03908 7139	13719-1360		RANGER (3.5T) J05C	95/2~97/10	Engine VALVE STEM SEAL
03908 4203	13719-1360		RANGER (3.5T) EXCEPT FB4J EAA-XB J05C	97/11~98/1	Engine VALVE STEM SEAL
03908 5611	13719-1470		RANGER (3.5T) EXCEPT FB4J EAA-XB J05C	98/2~00/	Engine VALVE STEM SEAL
03908 2699	13719-1480		RANGER (3.5T) FB4J EAA-XB J05C	97/11~00/	Engine VALVE STEM SEAL
03908 8219	9828-58113	58 x 102 x 7.8 x 21.8	RANGER (3.5T) FB	98/8~00/	Final Drive PINION
03908 6547	9828-43102	43 x 63 x 9	RANGER (3.5T) FB	90/6~95/1	Transmission FRONT COVER
03908 3955	9828-01228	100 x 135 x 17	RANGER (3.5T) FB J05C	95/2~97/11	Engine CRANK SHAFT REAR
03908 2443	9828-01203	127 x 147 x 11	RANGER (3.5T) FB4J CAA-#	95/5~99/	Wheel Hub REAR INNER
03908 2355	9828-48112	48 x 109 x 13	RANGER (3.5T) FB5B EAA EXCEPT -TD	95/5~99/	Wheel Hub REAR OUTER
03908 6283	9828-58104	58 x 75 x 9 x 14.5	RANGER (3.5T) KM,FB W04D	83/~95/1	Engine CRANK SHAFT FRONT
03908 5987	9828-85106	84 x 100 x 10	RANGER (3.5T) KM	65/~86/	Wheel Hub FRONT
03908 2779	9828-01136	116 x 132 x 11	RANGER (3.5T) KM	65/~86/	Wheel Hub REAR INNER
03908 2715	9828-01203	127 x 147 x 11	RANGER (3.5T) FB4J EAA EXCEPT -AA,-BA,-RA,-SA	95/5~99/	Wheel Hub REAR INNER
03908 7771	9828-01203	127 x 147 x 11	RANGER (3.5T) FB4J GAA EXCEPT -AA,-BA,-RA,-SA	95/5~99/	Wheel Hub REAR INNER
03908 3835	9828-01203	127 x 147 x 11	RANGER (3.5T) FB5B EAA-TD	97/11~99/	Wheel Hub REAR INNER
03908 4403	9828-01203	127 x 147 x 11	RANGER (3.5T) FB5B GAV-#	95/5~99/	Wheel Hub REAR INNER
03908 3131	9828-01206	107 x 123 x 11	RANGER (3.5T) FB1#,2#	84/7~95/	Wheel Hub REAR INNER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6787	9828-01206	107 x 123 x 11	RANGER (3.5T) FB4J EAA -AA,-BA,-RA,-SA	95/5~99/	Wheel Hub REAR INNER
03908 1955	9828-01206	107 x 123 x 11	RANGER (3.5T) FB4J GAA -AA,-BA,-RA,-SA	95/5~99/	Wheel Hub REAR INNER
03908 3971	9828-48112	48 x 109 x 13	RANGER (3.5T) FB1#,2#	84/7~95/	Wheel Hub REAR OUTER
03908 8043	9828-48112	48 x 109 x 13	RANGER (3.5T) FB5B CAA-#,EAV-#,GAA-#	95/5~99/	Wheel Hub REAR OUTER
03908 2139	9828-85106	84 x 100 x 10	RANGER (3.5T) FB	84/7~00/	Wheel Hub FRONT
03908 1659	9828-01206	107 x 123 x 11	RANGER (3.5T) FB5B CAA-#,EAV-#,GAA-#	95/5~99/	Wheel Hub REAR INNER
03908 1035	9828-48112	48 x 109 x 13	RANGER (3.5T) FB4J GAA -AA,-BA,-RA,-SA	95/5~99/	Wheel Hub REAR OUTER
03908 3739	9828-48112	48 x 109 x 13	RANGER (3.5T) FB4J EAA -AA,-BA,-RA,-SA	95/5~99/	Wheel Hub REAR OUTER
03908 2315	9828-57103	57 x 124 x 13	RANGER (3.5T) FB5B GAV-#	95/5~99/	Wheel Hub REAR OUTER
03908 2419	9828-57103	57 x 124 x 13	RANGER (3.5T) FB5B EAA -TD	97/11~99/	Wheel Hub REAR OUTER
03908 3523	9828-57103	57 x 124 x 13	RANGER (3.5T) FB4J GAA EXCEPT -AA,- BA,-RA,-SA	95/5~99/	Wheel Hub REAR OUTER
03908 2835	9828-57103	57 x 124 x 13	RANGER (3.5T) FB4J EAA EXCEPT -AA,-BA,- RA,-SA	95/5~99/	Wheel Hub REAR OUTER
03908 6219	9828-57103	57 x 124 x 13	RANGER (3.5T) FB4J CAA-#	95/5~99/	Wheel Hub REAR OUTER
03908 1859	9828-40101	40 x 50 x 6.5	RANGER (3.5T) KM	65/~86/	Wheel Hub REAR OUTER
03908 4443	9828-01206	107 x 123 x 11	RANGER (3.5T) FB5B EAA EXCEPT -TD	95/5~99/	Wheel Hub REAR INNER
03908 6819	9828-65113	65 x 114 x 10 x 25.5	RANGER (4.5T~5T) FD#,GD#,KD	83/12~98/6	Final Drive PINION
03908 3323	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) FC 17#,2J	84/6~90/	Transmission REAR COVER
03908 1179	9828-63104	63 x 100 x 12	RANGER (4.5T~5T) FC..11#,14#	84/6~90/5	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2947	9828-63104	63 x 100 x 12	RANGER (4.5T~5T) FD,GD EC100,EH500,700	80/~83/11	Final Drive PINION
03908 7059	9828-63104	63 x 100 x 12	RANGER (4.5T~5T) KL	69/~80/	Final Drive PINION
03908 7043	9828-63108	63 x 78 x 9 x 15	RANGER (4.5T~5T) GD 1J(NA,NG)	94/10~98/9	Transmission REAR COVER
03908 4187	9828-63104	63 x 100 x 12	RANGER (4.5T~5T) FT	83/9~86/4	Final Drive PINION
03908 5867	9828-63108	63 x 78 x 9 x 15	RANGER (4.5T~5T) FD 1H,1J(DUMP)	89/10~94/	Transmission REAR COVER
03908 1971	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) GC	02/9~	Transmission REAR COVER
03908 5803	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) GD 1J,7J	98/10~	Transmission REAR COVER
03908 1539	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) FT 17#,3H,1J,7J	83/9~	Transmission REAR COVER
03908 5971	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) FC 3W(#-LC)	90/6~95/	Transmission REAR COVER
03908 7291	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) GD 1J(AA,AC,AG)	94/10~98/9	Transmission REAR COVER
03908 7163	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) GD 16#,17#,2H,3H	83/12~94/	Transmission REAR COVER
03908 7219	9828-65113	65 x 114 x 10 x 25.5	RANGER (4.5T~5T) FC17#	84/6~90/5	Final Drive PINION
03908 4035	9828-01167	106 x 126 x 12	RANGER (4.5T~5T) H06C,H07C,D	83/~	Engine CRANK SHAFT REAR
03908 1827	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) FC 1J,2J,3J,5J,6J,7J	95/1~	Transmission REAR COVER
03908 7267	9828-58104	58 x 75 x 9 x 14.5	RANGER (4.5T~5T) W04D,W06E	83/~	Engine CRANK SHAFT FRONT
03908 2019	13719-1360		RANGER (4.5T~5T) J05C,J07C,J08C	91/10~98/1	Engine VALVE STEM SEAL
03908 4299	13719-1020		RANGER (4.5T~5T) W04C	00/10~	Engine VALVE STEM SEAL
03908 5387	13719-1020		RANGER (4.5T~5T) H06C,H07C,D,W04D,W0 6D,E	83/6~95/	Engine VALVE STEM SEAL

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7315	9828-01228	100 x 135 x 17	RANGER (4.5T~5T) J05C,J07C,J08C	91/~	Engine CRANK SHAFT REAR
03908 4003	9828-00109	100 x 120 x 13 x 18	RANGER (4.5T~5T) W04C,D,W06E	83/~	Engine CRANK SHAFT REAR
03908 2995	9828-48120	48 x 60 x 9	RANGER (4.5T~5T) FD 1H,2H,1J,2J,7J	89/7~	Transmission FRONT COVER
03908 3355	9828-01167	106 x 126 x 12	RANGER (4.5T~5T) EH300,EH500,EH700	74/~83/	Engine CRANK SHAFT REAR
03908 6267	9828-00107	100 x 120 x 13	RANGER (4.5T~5T) EC100,EH100	69/~83/	Engine CRANK SHAFT REAR
03908 8275	9828-79103	79 x 114 x 17	RANGER (4.5T~5T) J05C,J07C,J08C	91/~	Engine CRANK SHAFT FRONT
03908 8291	9828-65113	65 x 114 x 10 x 25.5	RANGER (4.5T~5T) FC#	90/6~98/6	Final Drive PINION
03908 5795	9828-65116	65 x 88 x 12 x 19	RANGER (4.5T~5T) H06C,H07C,D	83/~	Engine CRANK SHAFT FRONT
03908 8299	9828-65116	65 x 88 x 12 x 19	RANGER (4.5T~5T) EH500,EH700	80/~83/	Engine CRANK SHAFT FRONT
03908 5571	9828-65116	65 x 88 x 12 x 19	RANGER (4.5T~5T) EC100,EH100,EH300	78/~83/	Engine CRANK SHAFT FRONT
03908 1651	9828-58105	58 x 75 x 9	RANGER (4.5T~5T) EC100,EH100,EH300	69/~77/	Engine CRANK SHAFT FRONT
03908 2603	9828-65130	65 x 105 x 9 x 25	RANGER (4.5T~5T) FC#,FD#,FT#,GC#,GD#	01/11~	Final Drive PINION
03908 8083	9828-65127	65 x 114 x 9 x 25	RANGER (4.5T~5T) FC#,FD#,FT#,GD#	98/7~01/10	Final Drive PINION
03908 5283	9828-65113	65 x 114 x 10 x 25.5	RANGER (4.5T~5T) FT	86/6~98/6	Final Drive PINION
03908 5243	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) FD 17#,2H,3H,1J(EXCEPT DUMP),2J,7J	83/12~	Transmission REAR COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7099	9828-01134	140 x 160 x 12	RANGER (4.5T~5T) FT1J EXCEPT EBA,ECA,GBA-A#,GBF-A#,GCA-A#,H#	95/1~99/3	Wheel Hub FRONT
03908 3435	9828-57103	57 x 124 x 13	RANGER (4.5T~5T) FC,FD,GC,GD,KD	83/12~	Wheel Hub REAR OUTER
03908 1171	9828-45104	45 x 55 x 7.5	RANGER (4.5T~5T) FD,GD	80/~83/11	Wheel Hub REAR OUTER
03908 4723	9828-45104	45 x 55 x 7.5	RANGER (4.5T~5T) KL	69/~80/	Wheel Hub REAR OUTER
03908 3043	9828-01146	122 x 138 x 12	RANGER (4.5T~5T) FT	80/~95/	Wheel Hub REAR INNER
03908 3963	9828-01203	127 x 147 x 11	RANGER (4.5T~5T) FC,FD,GC,GD,KD	83/12~	Wheel Hub REAR INNER
03908 6699	9828-01149	120 x 140 x 12	RANGER (4.5T~5T) FD,GD	80/~83/11	Wheel Hub REAR INNER
03908 5459	9828-48103	48 x 58 x 7	RANGER (4.5T~5T) FT 173A,175A	80/12~83/	Wheel Hub REAR OUTER
03908 8179	9828-01134	140 x 160 x 12	RANGER (4.5T~5T) FT1J ALL	99/3~	Wheel Hub FRONT
03908 5163	9828-37103	37 x 50 x 6	RANGER (4.5T~5T) FD,GD EC100,EH500,700	80/~83/11	Transmission FRONT COVER
03908 1843	9828-01134	140 x 160 x 12	RANGER (4.5T~5T) FT3H EAL,GAL,GAF- ADA	89/10~95/	Wheel Hub FRONT
03908 3931	9828-01192	116 x 132 x 12	RANGER (4.5T~5T) FT1J EBA,ECA,GBA- A#,GBF-4#,GCA-A#,H#	95/1~99/3	Wheel Hub FRONT
03908 1907	9828-01192	116 x 132 x 12	RANGER (4.5T~5T) FT3H EXCEPT EAL,GAL,GAF-ADA	89/10~95/	Wheel Hub FRONT
03908 2323	9828-01192	116 x 132 x 12	RANGER (4.5T~5T) FT17#	80/~90/	Wheel Hub FRONT
03908 5435	9828-01137	101 x 114 x 10	RANGER (4.5T~5T) FC,FD,GC,GD,KD	80/~	Wheel Hub FRONT
03908 7643	9828-01137	101 x 114 x 10	RANGER (4.5T~5T) KL	69/~80/	Wheel Hub FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3907	13719-1470		RANGER (4.5T~5T) J05C,D,J07C,E,J08C	98/2~	Engine VALVE STEM SEAL
03908 8523	9828-01149	120 x 140 x 12	RANGER (4.5T~5T) KL	69/~80/	Wheel Hub REAR INNER
03908 3203	9828-48120	48 x 60 x 9	RANGER (4.5T~5T) FC 1J,3J,5J,6J,7J	95/1~	Transmission FRONT COVER
03908 6275	9828-55110	55 x 72 x 9 x 15	RANGER (4.5T~5T) FC 3W(EXCEPT #-LC)	90/6~95/	Transmission REAR COVER
03908 4219	9828-55110	55 x 72 x 9 x 15	RANGER (4.5T~5T) FC 14#,4J,1W,2W	84/6~	Transmission REAR COVER
03908 8075	9828-55110	55 x 72 x 9 x 15	RANGER (4.5T~5T) FD 16#,3W 5 SPEED	83/12~94/	Transmission REAR COVER
03908 3715	9828-55110	55 x 72 x 9 x 15	RANGER (4.5T~5T) FD,GD EC100,EH500,700	80/~83/11	Transmission REAR COVER
03908 5979	9828-55110	55 x 72 x 9 x 15	RANGER (4.5T~5T) KD,KL	75/~89/	Transmission REAR COVER
03908 1875	9828-52112	52 x 70 x 9	RANGER (4.5T~5T) FC 11#	84/6~90/	Transmission REAR COVER
03908 5811	9828-52112	52 x 70 x 9	RANGER (4.5T~5T) KL	69/~74/	Transmission REAR COVER
03908 7331	9828-57103	57 x 124 x 13	RANGER (4.5T~5T) FT 173B,175B,3H,1J	80/12~	Wheel Hub REAR OUTER
03908 8067	9828-48120	48 x 60 x 9	RANGER (4.5T~5T) FT 1J	97/10~	Transmission FRONT COVER
03908 4027	9828-60119	60 x 75 x 9 x 15	RANGER (4.5T~5T) FD 16#,3W 6 SPEED	83/12~95/	Transmission REAR COVER
03908 3259	9828-48120	48 x 60 x 9	RANGER (4.5T~5T) GD 16#,2H,1J	83/12~	Transmission FRONT COVER
03908 4251	9828-43102	43 x 63 x 9	RANGER (4.5T~5T) KD	86/4~89/	Transmission FRONT COVER
03908 5059	9828-43102	43 x 63 x 9	RANGER (4.5T~5T) FC 14#,17#,3H,2J,4J,1W,2W, 3W	84/6~	Transmission FRONT COVER
03908 1531	9828-43102	43 x 63 x 9	RANGER (4.5T~5T) FT 17#,3H,1J	83/9~97/9	Transmission FRONT COVER
03908 3923	9828-43102	43 x 63 x 9	RANGER (4.5T~5T) GD 17#,3H	83/12~94/	Transmission FRONT COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6499	9828-43102	43 x 63 x 9	RANGER (4.5T~5T) FD 16#,17#,3H,3W	83/12~94/	Transmission FRONT COVER
03908 8051	9828-48120	48 x 60 x 9	RANGER (4.5T~5T) GC	02/9~	Transmission FRONT COVER
03908 2027	9828-65111	65 x 95 x 14 x 20.5	TRUCK (2-2XD) TC303M,TC9#	71/~79/8	Transmission REAR COVER
03908 4355	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN2P EA,EB,JA,JB	92/5~	Final Drive PINION
03908 5411	9828-01207	138 x 152 x 12	TRUCK (2-2XD) TC,FN,GN	71/~	Wheel Hub FRONT (FORWARD)
03908 8019	9828-75111	75 x 100 x 13 x 18	TRUCK (2-2XD) TC3#...EXCEPT 303D,TC7#,9#	71/~81/	Final Drive PINION
03908 6243	9828-95106	95 x 152 x 10 x 25	TRUCK (2-2XD) TC303D,5#	71/~81/	Final Drive PINION
03908 2827	9828-95106	95 x 152 x 10 x 25	TRUCK (2-2XD) FN270AD,AM,FN63#	81/5~83/	Final Drive PINION
03908 8211	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN27#...EXCEPT 270#	81/5~89/	Final Drive PINION
03908 5195	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN28#...RT,RTN,TT,VTS	82/7~89/	Final Drive PINION
03908 1043	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN60#,GN28#	81/9~89/	Final Drive PINION
03908 8419	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN2K,GN1F,1P,2P	89/12~95/3	Final Drive PINION
03908 8011	9828-78104	78 x 100 x 14 x 20	TRUCK (2-2XD) FN1K	99/9~	Transmission REAR COVER
03908 4459	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN1P RT,RW,TT,VTS	90/1~92/	Final Drive PINION
03908 8259	9828-78102	78 x 100 x 14 x 20	TRUCK (2-2XD) FN2P,GN2P HK06,07 T/M	92/5~99/8	Transmission REAR COVER
03908 3819	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2-2XD) EN270#,FN63#	83/~89/	Final Drive PINION
03908 5787	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2-2XD) FN28#...ST,UT,WTS	82/7~89/	Final Drive PINION
03908 6363	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2-2XD) FN1F,2F,1K	90/1~92/4	Final Drive PINION
03908 5603	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2-2XD) FN1P ST,SW,WTS,UT	90/1~92/	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4339	9828-80115	80 x 124 x 19 x 25	TRUCK (2-2XD) GN27#	81/5~90/	Final Drive PINION
03908 3403	9828-80115	80 x 124 x 19 x 25	TRUCK (2-2XD) GN2K	90/3~	Final Drive PINION
03908 2171	9828-85112	85 x 146 x 9 x 24	TRUCK (2-2XD) FN1K,1V,2F,3F,4F	92/5~	Final Drive PINION
03908 1219	9828-85112	85 x 146 x 9 x 24	TRUCK (2-2XD) FN2P FA,FB,MA,MB	92/5~	Final Drive PINION
03908 4243	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD) FN1F	92/5~95/3	Final Drive PINION
03908 4891	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) TC5#	71/~81/	Transmission REAR COVER
03908 1155	9828-01207	138 x 152 x 12	TRUCK (2-2XD) TC,FN,GN	71/~	Wheel Hub FRONT (REARWARD)
03908 6227	9828-01130	146 x 170 x 18	TRUCK (2-2XD) TC	71/~81/	Wheel Hub REAR INNER
03908 4899	9828-01193	154 x 175 x 13	TRUCK (2-2XD) FN,GN	81/5~	Wheel Hub REAR INNER
03908 7979	9828-60108	60 x 74 x 7.5	TRUCK (2-2XD) TC	71/~81/	Wheel Hub REAR OUTER
03908 7371	9828-55113	55 x 72 x 9	TRUCK (2-2XD) TC,FN,GN	71/~	Transmission FRONT COVER
03908 1795	9828-65111	65 x 95 x 14 x 20.5	TRUCK (2-2XD) TC942	79/9~81/	Transmission REAR COVER
03908 3779	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2-2XD) TC3#..EXCEPT 303M,TC7#	71/~79/8	Transmission REAR COVER
03908 4195	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2-2XD) TC3#,7#,922	79/9~81/	Transmission REAR COVER
03908 5355	9828-78104	78 x 100 x 14 x 20	TRUCK (2-2XD) FN2P,GN2P HK06,07 T/M	99/9~	Transmission REAR COVER
03908 4083	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2-2XD) FN28#	82/7~83/11	Transmission REAR COVER
03908 1603	9828-80114	80 x 136 x 9 x 25	TRUCK (2-2XD) FN2K,1F,GN2P	95/4~	Final Drive PINION
03908 2379	9828-76101	76 x 164 x 14	TRUCK (2-2XD) FN,GN	81/5~	Wheel Hub REAR OUTER
03908 6107	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) FN27#...7 SPEED T/M	81/5~89/	Transmission REAR COVER
03908 6587	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) FN28#	83/12~89/	Transmission REAR COVER
03908 2683	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) FN338,60#,63#,GN28#	81/9~89/	Transmission REAR COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2179	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) FN1F,1P,2K,GN1F,1P,2K	89/10~	Transmission REAR COVER
03908 1835	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) FN1K,2F	90/1~92/4	Transmission REAR COVER
03908 8107	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD) FN2P,GN2P MJ06,07 T/M	92/5~	Transmission REAR COVER
03908 1851	9828-78102	78 x 100 x 14 x 20	TRUCK (2-2XD) FN1K,1V,2F,3F	92/5~99/8	Transmission REAR COVER
03908 3083	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2-2XD) FN27#...6 SPEED T/M, GN27#	81/5~89/	Transmission REAR COVER
03908 1611	9-37529-003-0	65 x 113 x 26	TRUCK (2-2XD) SPG	73/~78/	Propeller Shaft CENTER BEARING (F)
03908 1587	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (2-2XD) SRG SINGLE SPEED DIFF.	75/~83/	Final Drive PINION
03908 6091	1-09625-359-0	80 x 100 x 12	TRUCK (2-2XD) CXG MJA,MJB,MJC T/M	83/8~94/6	Transmission REAR COVER
03908 6883	1-09625-577-1	80 x 100 x 13	TRUCK (2-2XD) CXG,CYG MJA,MJB,MJC,MJD,MJT T/M	94/7~	Transmission REAR COVER
03908 1059	1-09625-473-0	80 x 115 x 15	TRUCK (2-2XD) CXG MAB10 T/M	86/4~89/8	Transmission REAR COVER
03908 7259	1-09625-625-0	104 x 126 x 13	TRUCK (2-2XD) CXG,CYG MJX12 T/M	03/6~	Transmission REAR COVER
03908 2883	1-09625-578-1	78 x 97 x 13	TRUCK (2-2XD) CXG,CYG MAG,MAH,MAL T/M	83/8~	Transmission REAR COVER
03908 3283	9-37529-013-0	65 x 110 x 47	TRUCK (2-2XD) SPG	73/~78/	Propeller Shaft CENTER BEARING
03908 7523	1-09625-126-0	70 x 100 x 16	TRUCK (2-2XD) SRG,SSG571	80/1~83/	Propeller Shaft CENTER BEARING (F&R)
03908 4603	1-09625-126-0	70 x 100 x 16	TRUCK (2-2XD) CXG,CYG P60,90L PROPELLER SHAFT	83/8~	Propeller Shaft CENTER BEARING (F&R)
03908 1347	1-09625-127-0	75 x 105 x 16	TRUCK (2-2XD) CXG,CYG P85,90 PROPELLER SHAFT	83/8~00/	Propeller Shaft CENTER BEARING (F&R)

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 5139	1-09625-222-1	83 x 114 x 19	TRUCK (2-2XD) CXG,CYG P105,115 PROPELLER SHAFT	83/8~00/	Propeller Shaft CENTER BEARING (F&R)
03908 1475	1-09625-222-1	83 x 114 x 19	TRUCK (2-2XD) CXG,CYG P115 PROPELLER SHAFT	00/4~	Propeller Shaft CENTER BEARING (F)
03908 3787	1-09625-622-0	86 x 106 x 14	TRUCK (2-2XD) CXG,CYG P115 PROPELLER SHAFT	00/4~	Propeller Shaft CENTER BEARING
03908 1675	1-09625-149-0	80 x 105 x 12	TRUCK (2-2XD) SSG 2 SPEED DIFF.	80/1~83/	Final Drive PINION
03908 2627	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (2-2XD) SSG SINGLE SPEED DIFF.	80/1~83/	Final Drive PINION
03908 3659	1-09625-149-0	80 x 105 x 12	TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY	73/79/12	Final Drive PINION
03908 7827	1-09625-379-0	74 x 142.9 x 17.5	TRUCK (2-2XD) SMG MAB5 T/M	80/1~83/	Wheel Hub REAR OUTER
03908 3811	1-09625-041-0	120 x 140 x 10.5	TRUCK (2-2XD) CXG,CYG	83/8~	Wheel Hub FRONT (F&R)
03908 7283	9-09924-393-0	123 x 184 x 15 x 28	TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY	73/~79/	Wheel Hub REAR INNER
03908 5419	1-09625-317-0	128 x 148 x 10	TRUCK (2-2XD) SPG E120 (EXCEPT MIXER)	73/~83/	Engine CRANK SHAFT REAR
03908 8195	9-09924-393-0	123 x 184 x 15 x 28	TRUCK (2-2XD) SRG,SSG,SMG(EXCEPT MAB5 T/M)	75/~83/	Wheel Hub REAR INNER
03908 7723	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (2-2XD) SMG EXCEPT TANK LORRY,CINTAINER	80/1~83/	Final Drive PINION
03908 2403	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (2-2XD) SMG MAB5 T/M	80/1~83/	Wheel Hub REAR INNER
03908 6027	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2-2XD) CXG,CYG	83/8~	Wheel Hub REAR INNER
03908 6659	9-09924-392-0	78 x 162 x 16	TRUCK (2-2XD) SPG EXCEPT 540 TANK LORRY	73/~79/	Wheel Hub REAR OUTER
03908 1011	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (2-2XD) SPG 540 TANK LORRY	73/~79/	Wheel Hub REAR INNER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6291	9-09924-374-0	71 x 142 x 14	TRUCK (2-2XD) SPG 540 TANK LORRY	73/~79/	Wheel Hub REAR OUTER
03908 6307	1-09625-579-1	74 x 97 x 13	TRUCK (2-2XD) CXG MAB,MAF T/M	83/8~94/	Transmission REAR COVER
03908 7595	1-09625-444-0	78 x 163 x 16	TRUCK (2-2XD) SRG,SSG,SMG(EXCEPT MAB5 T/M)	80/1~83/	Wheel Hub REAR OUTER
03908 7067	1-09625-444-0	78 x 163 x 16	TRUCK (2-2XD) CXG,CYG	83/8~	Wheel Hub REAR OUTER
03908 5347	1-09625-502-0	40 x 55 x 9	TRUCK (2-2XD) SPG,SRG	73/~79/12	Transmission FRONT COVER
03908 6875	1-09625-497-0	48 x 62 x 9	TRUCK (2-2XD) SRG,SSG,SMG	80/1~83/	Transmission FRONT COVER
03908 8163	1-09625-497-0	48 x 62 x 9	TRUCK (2-2XD) CXG	83/8~89/8	Transmission FRONT COVER
03908 5251	1-09625-562-0	54 x 69 x 9	TRUCK (2-2XD) CXG,CYG	89/9~	Transmission FRONT COVER
03908 6995	1-09625-149-0	80 x 105 x 12	TRUCK (2-2XD) SPG,SRG	73/~79/12	Transmission REAR COVER
03908 4011	1-09625-207-0	73 x 96 x 12	TRUCK (2-2XD) SRG,SSG,SMG	80/1~83/	Transmission REAR COVER
03908 2923	9-09924-392-0	78 x 162 x 16	TRUCK (2-2XD) SRG	75/~79/12	Wheel Hub REAR OUTER
03908 4531	1-12569-009-0		TRUCK (2-2XD) 8P,10P,12P	75,~91/6	Engine VALVE STEM SEAL
03908 2667	1-09625-540-3	114 x 153 x 17.5	TRUCK (2-2XD) CXG,CYG 6SD1	94/12~	Engine CRANK SHAFT FRONT
03908 4491	1-09625-507-1	120 x 153 x 17	TRUCK (2-2XD) CXG 10P#,12P#	88/8~93/2	Engine CRANK SHAFT REAR
03908 3331	1-09625-425-1	120 x 153 x 15	TRUCK (2-2XD) CXG 8P#	88/8~93/2	Engine CRANK SHAFT REAR
03908 3995	1-09625-525-2	111 x 153 x 16.5	TRUCK (2-2XD) CXG,CYG 8P#,10P#,12P#	93/3~03/	Engine CRANK SHAFT REAR
03908 1123	1-09625-443-0	120 x 150 x 15	TRUCK (2-2XD) CXG 6SD1	83/8~94/	Engine CRANK SHAFT REAR
03908 3571	1-09625-541-2	114 x 150 x 17	TRUCK (2-2XD) CXG,CYG 6SD1	94/12~	Engine CRANK SHAFT REAR
03908 4067	1-09625-557-1	118 x 148 x 20	TRUCK (2-2XD) CXG,CYG 6WA1,6WG1,6WF1	92/4~	Engine CRANK SHAFT REAR
03908 1275	1-09625-504-0	125 x 155 x 10	TRUCK (2-2XD) SPG E120 (MIXER),CXG 6RB1 (MIXER)	73/~92/	Engine CRANK SHAFT REAR
03908 6155	1-12569-013-0		TRUCK (2-2XD) 6R	81/~92/	Engine VALVE STEM SEAL

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4275	1-09625-317-0	128 x 148 x 10	TRUCK (2-2XD) CXG 6RB1 (EXCEPT MIXER)	83/8~86/3	Engine CRANK SHAFT REAR
03908 1891	1-12569-009-0		TRUCK (2-2XD) 6SD1	83/~94/	Engine VALVE STEM SEAL
03908 6059	1-12569-019-1		TRUCK (2-2XD) 6SD1	94/12	Engine VALVE STEM SEAL
03908 1203	1-12569-019-1		TRUCK (2-2XD) 8P,10P,12P	91/7~	Engine VALVE STEM SEAL
03908 1579	1-12569-019-1		TRUCK (2-2XD) 6WA1,6WG1,6WF1	92/4~00/5	Engine VALVE STEM SEAL
03908 5523	1-12569-020-0		TRUCK (2-2XD) 6WG1,6WF1	00/6~	Engine VALVE STEM SEAL
03908 1747	1-09625-041-0	120 x 140 x 10.5	TRUCK (2-2XD) SPG,SRG,SSG,SMG	73/~83/	Wheel Hub FRONT (F&R)
03908 3163	1-09625-441-0	128 x 148 x 14	TRUCK (2-2XD) CXG 6RB1 (EXCEPT MIXER)	86/4~92/	Engine CRANK SHAFT REAR
03908 5259	9-12569-072-0		TRUCK (2-2XD) E120	71/~83/	Engine VALVE STEM SEAL
03908 3387	1-09625-442-0	70 x 92 x 12	TRUCK (2-2XD) CXG 6RB1	88/7~92/	Engine CRANK SHAFT FRONT
03908 1731	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (2-2XD) SPG 540 TANK LORRY	73/~79/12	Final Drive PINION
03908 1187	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (2-2XD) SMG TANK LORRY,CONTAINER	80/1~83/	Final Drive PINION
03908 3979	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (2-2XD) CXG,CYG 16.5 INCH FINAL	83/8~00/	Final Drive PINION
03908 5083	1-09625-322-0	86 x 143 x 10 x 38	TRUCK (2-2XD) CXG,CYG 17.5 INCH FINAL	89/9~00/	Final Drive PINION
03908 3867	1-09625-322-0	86 x 143 x 10 x 38	TRUCK (2-2XD) CXG,CYG 18.5 INCH FINAL	83/8~00/	Final Drive PINION
03908 6507	1-09625-322-0	86 x 143 x 10 x 38	TRUCK (2-2XD) CXG,CYG ALL	00/4~	Final Drive PINION
03908 2963	1-09625-128-0	70 x 92 x 12	TRUCK (2-2XD) SPG E120	73/~77/	Engine CRANK SHAFT FRONT
03908 1595	1-09625-507-1	120 x 153 x 17	TRUCK (2-2XD) CXG 8PC1,10PC1,12PC1	83/8~88/7	Engine CRANK SHAFT REAR
03908 8187	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (2-2XD) CXG 6RB1	83/8~88/7	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3155	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (2-2XD) CXG 17.5 INCH FINAL	83/8~89/8	Final Drive PINION
03908 6419	1-09625-200-0	120 x 153 x 15	TRUCK (2-2XD) SRG,SSG,SMG 8P,10P	75/~83/	Engine CRANK SHAFT FRONT
03908 2891	1-09625-506-0	120 x 153 x 15	TRUCK (2-2XD) CXG 6SD1,8PC1,10PC1,12PC1	83/8~88/7	Engine CRANK SHAFT FRONT
03908 5739	1-09625-506-0	120 x 153 x 15	TRUCK (2-2XD) CXG 10P#,12P#	88/8~93/2	Engine CRANK SHAFT FRONT
03908 4139	1-09625-424-0	120 x 153 x 13 x 15	TRUCK (2-2XD) CXG 8P#	88/8~93/2	Engine CRANK SHAFT FRONT
03908 5075	1-09625-524-3	111 x 153 x 16.5	TRUCK (2-2XD) CXG,CYG 8P#,10P#,12P#	93/3~03/	Engine CRANK SHAFT FRONT
03908 7963	1-09625-451-0	120 x 153 x 15	TRUCK (2-2XD) CXG 6SD1	88/8~94/	Engine CRANK SHAFT FRONT
03908 4971	1-09625-556-2	118 x 148 x 20	TRUCK (2-2XD) CXG,CYG 6WA1,6WG1,6WF1	92/4~	Engine CRANK SHAFT FRONT
03908 1459	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (2-2XD) SPG E120	77/~83/	Engine CRANK SHAFT FRONT
03908 4155	1-09625-201-0	120 x 153 x 15 x 18	TRUCK (2-2XD) SPG,SSG,SMG 8P,10P,12P	75/~83/	Engine CRANK SHAFT REAR
03908 8435	9828-90104	90 x 115 x 13 x 19	TRUCK (2-2XD-D) FW27#,28#,60#,1F,2K	83/11~94/6	Final Drive PINION (FRONT)
03908 2011	9828-76101	76 x 164 x 14	TRUCK (2-2XD-D) FY	88/9~	Wheel Hub REAR OUTER (F)
03908 6955	9828-45104	45 x 55 x 7.5	TRUCK (2-2XD-D) FW	81/6~83/11	Wheel Hub REAR OUTER
03908 3251	9828-57103	57 x 124 x 13	TRUCK (2-2XD-D) FW	83/12~	Wheel Hub REAR OUTER
03908 5931	9828-76101	76 x 164 x 14	TRUCK (2-2XD-D) FY	88/9~	Wheel Hub REAR OUTER
03908 5699	9828-55113	55 x 72 x 9	TRUCK (2-2XD-D) FW,FY	83/11~	Transmission FRONT COVER
03908 3227	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD-D) FW27#,28#,60#,1F,2K	83/11~00/	Transmission REAR COVER
03908 5475	9828-78102	78 x 100 x 14 x 20	TRUCK (2-2XD-D) FW1K,2P,2F,3F,4F	92/4~99/8	Transmission REAR COVER
03908 5219	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW,FY	81/6~	Wheel Hub FRONT (FORWARD)

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4363	9828-78104	78 x 100 x 14 x 20	TRUCK (2-2XD-D) FY	99/9~	Transmission REAR COVER
03908 7251	9828-01193	154 x 175 x 13	TRUCK (2-2XD-D) FY	88/9~	Wheel Hub REAR INNER
03908 3491	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD-D) FW1K,2F,3F	89/11~94/6	Final Drive PINION (FRONT)
03908 5323	9828-90115	90 x 125 x 10 x 17	TRUCK (2-2XD-D) FW1F,2F,3F,4F,1K,2P	94/7~	Final Drive PINION (FRONT)
03908 2523	9828-90115	90 x 125 x 10 x 17	TRUCK (2-2XD-D) FY	98/9~	Final Drive PINION (FRONT)
03908 6835	9828-63104	63 x 100 x 12	TRUCK (2-2XD-D) FW27#,60#	83/11~85/8	Final Drive PINION (REAR)
03908 8395	9828-80110	80 x 136 x 20 x 26	TRUCK (2-2XD-D) FW27#	85/9~90/	Final Drive PINION (REAR)
03908 2235	9828-65113	65 x 114 x 10 x 25.5	TRUCK (2-2XD-D) FW28#,60#,1F,2F,3F,4F,1K,2K,2P	85/9~98/6	Final Drive PINION (REAR)
03908 4395	9828-65127	65 x 114 x 9 x 25	TRUCK (2-2XD-D) FW1K,2P,4F	98/7~	Final Drive PINION (REAR)
03908 3059	9828-80114	80 x 136 x 9 x 25	TRUCK (2-2XD-D) FY	98/9~	Final Drive PINION (REAR)
03908 4051	9828-78104	78 x 100 x 14 x 20	TRUCK (2-2XD-D) FW1K,2P,3F,4F	99/9~	Transmission REAR COVER
03908 7187	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW3F ALL	98/4~	Wheel Hub FRONT (REARWARD)
03908 7467	9828-75119	75 x 100 x 13 x 19	TRUCK (2-2XD-D) FW1K,2F	89/11~92/3	Transmission REAR COVER
03908 2131	9828-01137	101 x 114 x 10	TRUCK (2-2XD-D) FW1K,3F ALL	90/1~94/12	Wheel Hub FRONT (REARWARD)
03908 6395	9828-01137	101 x 114 x 10	TRUCK (2-2XD-D) FW1K EXCEPT YDA,XDA,ZD#	94/12~98/5	Wheel Hub FRONT (REARWARD)
03908 5363	9828-01137	101 x 114 x 10	TRUCK (2-2XD-D) FW1K AG#,WC#	98/5~	Wheel Hub FRONT (REARWARD)
03908 3683	9828-01137	101 x 114 x 10	TRUCK (2-2XD-D) FW2P	96/12~98/3	Wheel Hub FRONT (REARWARD)
03908 5763	9828-01137	101 x 114 x 10	TRUCK (2-2XD-D) FW3F EXCEPT #D	96/12~98/3	Wheel Hub FRONT (REARWARD)
03908 2435	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW1K YDA,XDA,ZD#	94/12~98/5	Wheel Hub FRONT (REARWARD)
03908 3531	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW1K EXCEPT AG#,WC#	98/5~	Wheel Hub FRONT (REARWARD)
03908 6643	9828-57103	57 x 124 x 13	TRUCK (2-2XD-D) FW	83/12~	Wheel Hub REAR OUTER (F)

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4371	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW3F #D	94/12~98/3	Wheel Hub FRONT (REARWARD)
03908 2555	9828-45104	45 x 55 x 7.5	TRUCK (2-2XD-D) FW	81/6~83/11	Wheel Hub REAR OUTER (F)
03908 6723	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW4F	94/12~	Wheel Hub FRONT (REARWARD)
03908 1099	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FY	88/9~	Wheel Hub FRONT (REARWARD)
03908 6011	9828-01149	120 x 140 x 12	TRUCK (2-2XD-D) FW	81/6~83/11	Wheel Hub REAR INNER (F)
03908 4595	9828-01203	127 x 147 x 11	TRUCK (2-2XD-D) FW	83/12~	Wheel Hub REAR INNER (F)
03908 7499	9828-01193	154 x 175 x 13	TRUCK (2-2XD-D) FY	88/9~	Wheel Hub REAR INNER (F)
03908 8539	9828-01149	120 x 140 x 12	TRUCK (2-2XD-D) FW	81/6~83/11	Wheel Hub REAR INNER
03908 1363	9828-01203	127 x 147 x 11	TRUCK (2-2XD-D) FW	83/12~	Wheel Hub REAR INNER
03908 7571	9828-01137	101 x 114 x 10	TRUCK (2-2XD-D) FW27#,28#,60#,1F,2F,2K	81/6~	Wheel Hub FRONT (REARWARD)
03908 3875	9828-01207	138 x 152 x 12	TRUCK (2-2XD-D) FW2P	98/3~	Wheel Hub FRONT (REARWARD)
03908 1963	9828-78102	78 x 100 x 14 x 20	TRUCK (2-2XD-D) FY	98/9~99/8	Transmission REAR COVER
03908 3595	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2XD-4) FR1K#,FR2K#	90/1~92/4	Final Drive PINION
03908 4467	9828-01207	138 x 152 x 12	TRUCK (2XD-4) FR,FP	81/5~	Wheel Hub FRONT
03908 4651	9828-01207	138 x 152 x 12	TRUCK (2XD-4) KE	71/~81/	Wheel Hub FRONT
03908 2939	9828-95106	95 x 152 x 10 x 25	TRUCK (2XD-4) FR270B#	81/~83/	Final Drive PINION
03908 1259	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-4) FR27#...EXCEPT 270B,FP27#	81/~89/	Final Drive PINION
03908 7347	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-4) FR28#KP,LP,FP28#KP,LP	81/~89/	Final Drive PINION
03908 7859	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-4) FR60#...EXCEPT 600BD,BM,FP60#	81/~89/	Final Drive PINION
03908 3451	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-4) (FR1P,FP1P) KP,LP	89/10~92/	Final Drive PINION
03908 6075	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2XD-4) FR270B#,FR33#	83/~89/	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7155	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2XD-4) FR28#PP,QP,FP28#PP,QP	83/~89/	Final Drive PINION
03908 3803	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2XD-4) FR600BD,BM,FR63#,66#	83/~89/	Final Drive PINION
03908 4227	9828-01130	146 x 170 x 18	TRUCK (2XD-4) KF	71/~81/	Wheel Hub REAR INNER (F)
03908 3179	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2XD-4) (FR1P,FP1P) PP,PV,PW,QP	89/12~92/	Final Drive PINION
03908 7795	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-4) FR1F EXCEPT FK#,FP1F	89/12~95/3	Final Drive PINION
03908 5939	9828-85110	85 x 146 x 10 x 26	TRUCK (2XD-4) FR1FK#,FR2F#,FR3F#,FP 2F#	92/5~95/3	Final Drive PINION
03908 4979	9828-85110	85 x 146 x 10 x 26	TRUCK (2XD-4) (FR2P,FP2P) NA,NC,GA	92/5~94/11	Final Drive PINION
03908 7203	9828-85110	85 x 146 x 10 x 26	TRUCK (2XD-4) FR1K,FP1K	92/5~94/11	Final Drive PINION
03908 8499	9828-85110	85 x 146 x 10 x 26	TRUCK (2XD-4) FR2K KBD-BA,KBM-BE	92/5~95/	Final Drive PINION
03908 1163	9828-80114	80 x 136 x 9 x 25	TRUCK (2XD-4) FR2K EXCEPT KBD-BA,KBM- BE,FP2K	95/8~00/	Final Drive PINION
03908 7443	9828-80114	80 x 136 x 9 x 25	TRUCK (2XD-4) FR1F EXCEPT FK#, FP1F	95/4~	Final Drive PINION
03908 4683	9828-85112	85 x 146 x 9 x 24	TRUCK (2XD-4) (FR2P,FP2P) NA,NC,GA	94/12~	Final Drive PINION
03908 2339	9828-85112	85 x 146 x 9 x 24	TRUCK (2XD-4) FR1K,FP1K	94/12~	Final Drive PINION
03908 6731	9828-85112	85 x 146 x 9 x 24	TRUCK (2XD-4) FR1FK#,FR2F#,FR3F#,F R4F#,FP2F#	95/4~	Final Drive PINION
03908 4411	9828-65113	65 x 114 x 10 x 25.5	TRUCK (2XD-4) (FR2P,FP2P) FA,KA,KC	92/5~	Final Drive PINION
03908 6451	9828-95106	95 x 152 x 10 x 25	TRUCK (2XD-4) FR28#PP,QP,FP28#PP,QP	81/~83/	Final Drive PINION
03908 7195	9828-95112	95 x 156 x 17 x 23.5	TRUCK (2XD-4) FR1FK#,FR2F#,FR3F#	89/12~92/4	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7411	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-4) FR2P NA,NC,GA	92/5~99/8	Transmission REAR COVER
03908 1643	9828-95106	95 x 152 x 10 x 25	TRUCK (2XD-4) KF301D,704D,5#	71/~81/	Final Drive PINION
03908 8123	9828-75111	75 x 100 x 13 x 18	TRUCK (2XD-4) KF3#,7#...EXCEPT 301D,704D	71/~81/	Final Drive PINION
03908 2611	9828-78104	78 x 100 x 14 x 20	TRUCK (2XD-4) FR1K,3F,4F,2P,FP2P	99/9~	Transmission REAR COVER
03908 1195	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-4) FR2K EXCEPT KBD-BA,KBM- BE,FP2K	92/5~95/7	Final Drive PINION
03908 6355	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-4) FP1K,2F	92/5~	Transmission REAR COVER
03908 2467	9828-01193	154 x 175 x 13	TRUCK (2XD-4) FR,FP	81/5~	Wheel Hub REAR INNER (F)
03908 2059	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-4) FR2F,3F,4F,1K	92/5~99/8	Transmission REAR COVER
03908 3339	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-4) FR1F DUMP MIXER	92/5~	Transmission REAR COVER
03908 6467	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FP2P FA,KA,KC	92/5~99/8	Transmission REAR COVER
03908 7275	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FP1F,1P,2K	89/12~	Transmission REAR COVER
03908 3003	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FR2K	92/5~00/	Transmission REAR COVER
03908 7843	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FR2P FA,FF,FN,KA,KC	92/5~99/8	Transmission REAR COVER
03908 4731	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FR1F EXCEPT DUMP,MIXER	92/5~	Transmission REAR COVER
03908 6747	9828-60108	60 x 74 x 7.5	TRUCK (2XD-4) KF	71/~81/	Wheel Hub REAR OUTER (F)
03908 7987	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-4) FP2P NA,NC	92/5~99/8	Transmission REAR COVER
03908 4315	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FR1F,2F,3F,1P,1K,2K	89/9~92/4	Transmission REAR COVER
03908 3499	9828-01207	138 x 152 x 12	TRUCK (2XD-4) FR SELF STEERING	89/9~	Wheel Hub REAR INNER
03908 4507	9828-01130	146 x 170 x 18	TRUCK (2XD-4) KF	71/~81/	Wheel Hub REAR INNER
03908 5595	9828-76101	76 x 164 x 14	TRUCK (2XD-4) FR,FP	81/5~	Wheel Hub REAR OUTER (F)

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3147	9828-55113	55 x 72 x 9	TRUCK (2XD-4) KF,FR,FP	71/~	Transmission FRONT COVER
03908 2811	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-4) KF EXCEPT 500D,545,585,595	71/~81/	Transmission REAR COVER
03908 4267	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-4) FR27#,FP27#	81/5~83/11	Transmission REAR COVER
03908 7003	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) KF 500D,545,585,595	76/~81/	Transmission REAR COVER
03908 5755	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FR27#,33#,FP27#	83/12~90/	Transmission REAR COVER
03908 1299	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-4) FR28#,60#,63#,66#,FP28# ,60#	81/5~89/	Transmission REAR COVER
03908 7403	9828-01193	154 x 175 x 13	TRUCK (2XD-4) FR,FP	81/5~	Wheel Hub REAR INNER
03908 1883	9828-57103	57 x 124 x 13	TRUCK (2XD-D) KK,FQ,GK	83/12~	Wheel Hub REAR OUTER
03908 3187	9828-62104	62 x 76 x 9	TRUCK (2XD-D) WP	98/7~	Wheel Hub REAR OUTER
03908 5851	9828-01189	159 x 182 x 18	TRUCK (2XD-D) WP	98/7~	Wheel Hub REAR INNER
03908 5467	9828-76101	76 x 164 x 14	TRUCK (2XD-D) FS	81/5~	Wheel Hub REAR OUTER
03908 3307	9828-60108	60 x 74 x 7.5	TRUCK (2XD-D) ZM	71/~81/	Wheel Hub REAR OUTER
03908 6691	9828-62104	62 x 76 x 9	TRUCK (2XD-D) WP	98/7~	Wheel Hub REAR OUTER (F)
03908 1107	9828-57103	57 x 124 x 13	TRUCK (2XD-D) KK,FQ,GK	83/12~	Wheel Hub REAR OUTER (F)
03908 7675	9828-76101	76 x 164 x 14	TRUCK (2XD-D) FS	81/5~	Wheel Hub REAR OUTER (F)
03908 5547	9828-60108	60 x 74 x 7.5	TRUCK (2XD-D) ZM	71/~81/	Wheel Hub REAR OUTER (F)
03908 4059	9828-01203	127 x 147 x 11	TRUCK (2XD-D) KK,FQ,GK	83/12~	Wheel Hub REAR INNER
03908 4611	9828-01193	154 x 175 x 13	TRUCK (2XD-D) FS	81/5~	Wheel Hub REAR INNER
03908 5539	9828-01130	146 x 170 x 18	TRUCK (2XD-D) ZM	71/~81/	Wheel Hub REAR INNER
03908 3315	9828-01189	159 x 182 x 18	TRUCK (2XD-D) WP	98/7~	Wheel Hub REAR INNER (F)
03908 5451	9828-01193	154 x 175 x 13	TRUCK (2XD-D) FS	81/5~	Wheel Hub REAR INNER (F)
03908 2003	9828-01130	146 x 170 x 18	TRUCK (2XD-D) ZM	71/~81/	Wheel Hub REAR INNER (F)
03908 5875	9828-01207	138 x 152 x 12	TRUCK (2XD-D) ZM,KK,FQ,FS,GK,WP	71/~	Wheel Hub FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2675	9828-78101	78 x 100 x 14 x 20	TRUCK (2XD-D) FS60#,63#,66#... 9 SPEED T/M	81/5~89/	Transmission REAR COVER
03908 1915	9828-55113	55 x 72 x 9	TRUCK (2XD-D) ZM,FQ,FS,WP	71/~	Transmission FRONT COVER
03908 7339	9828-01203	127 x 147 x 11	TRUCK (2XD-D) KK,FQ,GK	83/12~	Wheel Hub REAR INNER (F)
03908 4995	9828-75111	75 x 100 x 13 x 18	TRUCK (2XD-D) ZM	71/~81/	Final Drive PINION (REAR)
03908 3579	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) FQ1F	90/2~95/4	Transmission REAR COVER
03908 4483	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-D) WP	98/7~99/8	Transmission REAR COVER
03908 3723	9828-78104	78 x 100 x 14 x 20	TRUCK (2XD-D) FS1F,3F,4F,1K,2P	99/9~	Transmission REAR COVER
03908 2787	9828-78104	78 x 100 x 14 x 20	TRUCK (2XD-D) FQ2P RFA#,TFA#,WFA#	99/9~	Transmission REAR COVER
03908 8387	9828-78104	78 x 100 x 14 x 20	TRUCK (2XD-D) FQ3F,4F,1K	99/9~	Transmission REAR COVER
03908 7939	9828-65127	65 x 114 x 9 x 25	TRUCK (2XD-D) FQ	00/3~	Final Drive PINION (REAR)
03908 4379	9828-78104	78 x 100 x 14 x 20	TRUCK (2XD-D) WP	99/9~	Transmission REAR COVER
03908 5771	9828-90104	90 x 115 x 13 x 19	TRUCK (2XD-D) ZM,KK,FQ,FS,GK	71/~92/3	Final Drive PINION (FRONT)
03908 5115	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-D) FQ1K	98/2~99/8	Transmission REAR COVER
03908 8003	9828-80115	80 x 124 x 19 x 25	TRUCK (2XD-D) WP	98/7~01/	Final Drive PINION (FRONT)
03908 7851	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-D) FQ2P RFA#,TFA#,WFA#	96/4~99/8	Transmission REAR COVER
03908 6403	9828-63104	63 x 100 x 12	TRUCK (2XD-D) KK	83/9~86/5	Final Drive PINION (REAR)
03908 8411	9828-65113	65 x 114 x 10 x 25.5	TRUCK (2XD-D) GK	89/7~98/6	Final Drive PINION (REAR)
03908 1979	9828-65113	65 x 114 x 10 x 25.5	TRUCK (2XD-D) FQ	90/2~00/2	Final Drive PINION (REAR)
03908 3539	9828-65113	65 x 114 x 10 x 25.5	TRUCK (2XD-D) KK	86/6~89/	Final Drive PINION (REAR)
03908 7931	9828-80110	80 x 136 x 20 x 26	TRUCK (2XD-D) FS	81/5~95/3	Final Drive PINION (REAR)
03908 6323	9828-70116	70 x 94.5 x 10 x 16.5	TRUCK (2XD-D) WP	98/7~01/	Final Drive PINION (REAR)
03908 5723	9828-80114	80 x 136 x 9 x 25	TRUCK (2XD-D) FS	95/4~	Final Drive PINION (REAR)
03908 7491	9828-65127	65 x 114 x 9 x 25	TRUCK (2XD-D) GK	98/7~	Final Drive PINION (REAR)
03908 6019	9828-90115	90 x 125 x 10 x 17	TRUCK (2XD-D) FQ,FS,GK	92/4~	Final Drive PINION (FRONT)

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4627	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) FS60#,63#,66#...EXCEPT 9 SPEED T/M	81/5~89/	Transmission REAR COVER
03908 6571	9828-50105	50 x 68 x 9	TRUCK (2XD-D) KK,GK	86/6~	Transmission FRONT COVER
03908 6371	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-D) ZM,303D,M REAR AXLE RATIO 6.428	77/~81/	Transmission REAR COVER
03908 2563	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-D) ZM706D,M 1ST GEAR RATIO 6.028	79/~81/	Transmission REAR COVER
03908 5963	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-D) ZM745,765,785	79/~81/	Transmission REAR COVER
03908 6195	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-D) FS27#	81/5~83/11	Transmission REAR COVER
03908 4915	9828-70101	70 x 95 x 14 x 20.5	TRUCK (2XD-D) KK,GK	83/9~	Transmission REAR COVER
03908 7579	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) ZM303D,M REAR AXLE RATIO 6.833	77/~81/	Transmission REAR COVER
03908 6627	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) ZM706F,M 1ST GEAR RATIO 7.028	79/~81/	Transmission REAR COVER
03908 5899	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-D) FQ2F,3F	92/5~99/8	Transmission REAR COVER
03908 3547	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) FS27#,33#...EXCEPT 9 SPEED T/M	83/12~89/	Transmission REAR COVER
03908 1339	9828-48120	48 x 60 x 9	TRUCK (2XD-D) KK	83/9~86/5	Transmission FRONT COVER
03908 2763	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) FS1F,2F,3F,1K,2K	89/8~92/4	Transmission REAR COVER
03908 5491	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) FS2K	92/5~	Transmission REAR COVER
03908 6963	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) FQ2P REA#,TEA#,WEA#	98/3~00/	Transmission REAR COVER
03908 5555	9828-78101	78 x 100 x 14 x 20	TRUCK (2XD-D) FS27#,33#...9 SPEED T/M	83/12~89/	Transmission REAR COVER
03908 8251	9828-78101	78 x 100 x 14 x 20	TRUCK (2XD-D) FS1V 10 SPEED T/M	92/5~	Transmission REAR COVER
03908 5859	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-D) FS1F,2F,3F,4F,1K	92/5~99/8	Transmission REAR COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 1939	9828-78102	78 x 100 x 14 x 20	TRUCK (2XD-D) FS1V EXCEPT 10 SPEED T/M	92/5~	Transmission REAR COVER
03908 4099	9828-75119	75 x 100 x 13 x 19	TRUCK (2XD-D) ZM500D,540,560,580,940	77/~81/	Transmission REAR COVER
03908 7891	1-09625-149-0	80 x 105 x 12	TRUCK (2XD-D) SPZ,SRZ,SSZ	73/~79/12	Final Drive PINION (FORWARD)
03908 2035	1-09625-127-0	75 x 105 x 16	TRUCK (2XD-D) SVZ581	82/9~83/	Propeller Shaft CENTER BEARING (F&R)
03908 1491	1-09625-127-0	75 x 105 x 16	TRUCK (2XD-D) CXZ,CYZ P85,P90 P/S	83/8~99/12	Propeller Shaft CENTER BEARING (F&R)
03908 2243	1-09625-127-0	75 x 105 x 16	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P90 P/S	00/1~	Propeller Shaft CENTER BEARING (F)
03908 6083	1-09625-126-0	70 x 100 x 16	TRUCK (2XD-D) SRZ,SSZ581,641,701	80/1~83/	Propeller Shaft CENTER BEARING (F&R)
03908 3411	1-09625-126-0	70 x 100 x 16	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P60,P90L P/S	83/8~03/	Propeller Shaft CENTER BEARING (F&R)
03908 3563	1-09625-621-0	81 x 103 x 16	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P90 P/S	00/1~	Propeller Shaft CENTER BEARING
03908 5507	1-09625-222-1	83 x 114 x 19	TRUCK (2XD-D) CXZ,CYZ P115 P/S	83/8~99/12	Propeller Shaft CENTER BEARING (F&R)
03908 4547	1-09625-622-0	86 x 106 x 14	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P115,P115L P/S	00/1~	Propeller Shaft CENTER BEARING
03908 8531	1-09625-119-0	80 x 127 x 16 x 24	TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ,T MK-Z,TMQ-Z	80/1~83/	Final Drive PINION (FORWARD)
03908 8403	1-09625-323-0	86 x 127 x 16 x 25	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY	83/8~	Final Drive PINION (FORWARD)
03908 1235	9-37529-013-0	65 x 110 x 47	TRUCK (2XD-D) SPZ,TMK-Z	73/~78/	Propeller Shaft CENTER BEARING
03908 4675	1-09625-624-0	60 x 75 x 9	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJX16	03/5~	Transmission FRONT COVER
03908 6211	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ,T MK-Z,TMQ-Z	73/~83/	Final Drive PINION (REARWARD)
03908 8315	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (2XD-D) CXZ	83/8~89/7	Final Drive PINION (REARWARD)

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3555	1-09625-222-1	83 x 114 x 19	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY P115,P115L P/S	00/1~	Propeller Shaft CENTER BEARING (F)
03908 1051	1-09625-562-0	54 x 69 x 9	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY	89/8~03/	Transmission FRONT COVER
03908 4563	1-09625-502-0	40 x 55 x 9	TRUCK (2XD-D) TMK- Z	73/~80/3	Transmission FRONT COVER
03908 2507	1-09625-502-0	40 x 55 x 9	TRUCK (2XD-D) SRZ,SSZ	75/~79/12	Transmission FRONT COVER
03908 7051	1-09625-525-2	111 x 153 x 16.5	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 8PE1,10PE1,12PE1	94/10~	Engine CRANK SHAFT REAR
03908 2043	1-09625-322-0	86 x 143 x 10 x 38	TRUCK (2XD-D) CXZ,CYZ	89/8~95/	Final Drive PINION (REARWARD)
03908 2099	1-09625-497-0	48 x 62 x 9	TRUCK (2XD-D) TMK- Z	80/4~83/	Transmission FRONT COVER
03908 8363	1-09625-497-0	48 x 62 x 9	TRUCK (2XD-D) SRZ,SSZ	80/1~83/	Transmission FRONT COVER
03908 5091	1-09625-207-0	73 x 96 x 12	TRUCK (2XD-D) SPZ,SRZ,SSZ,TMK- Z,SQZ,TMQ-Z,SVZ	80/1~83/	Transmission REAR COVER
03908 2851	1-09625-497-0	48 x 62 x 9	TRUCK (2XD-D) CXZ	83/8~89/7	Transmission FRONT COVER
03908 8267	9-37529-003-0	65 x 113 x 26	TRUCK (2XD-D) SPZ,TMK-Z	73/~78/	Propeller Shaft CENTER BEARING (F)
03908 1067	1-09625-562-0	54 x 69 x 9	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MAL6,MAP6,MJT7,MJX 12	03/5~	Transmission FRONT COVER
03908 7947	1-09625-149-0	80 x 105 x 12	TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ	73/~79/12	Transmission REAR COVER
03908 1227	1-09625-579-1	74 x 97 x 13	TRUCK (2XD-D) CXZ MAB,MAF T/M	83/8~94/	Transmission REAR COVER
03908 1379	1-09625-578-1	78 x 97 x 13	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MAG,MAH,MAL,MAP T/M	83/8~	Transmission REAR COVER
03908 8467	1-09625-359-0	80 x 100 x 12	TRUCK (2XD-D) CXZ MJA T/M	86/1~94/	Transmission REAR COVER
03908 8203	1-09625-577-1	80 x 100 x 13	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJA,MJD,MJT T/M	94/7~	Transmission REAR COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6843	1-09625-625-0	104 x 126 x 13	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY MJX12,16	0/3	Transmission REAR COVER
03908 2163	1-09625-497-0	48 x 62 x 9	TRUCK (2XD-D) SQZ,TMQ-Z	81/8~83/	Transmission FRONT COVER
03908 4635	1-09625-504-0	125 x 155 x 10	TRUCK (2XD-D) SPZ E120(MIXER),CXZ 6R(MIXER)	73/~89/	Engine CRANK SHAFT REAR
03908 4715	1-09625-425-1	120 x 153 x 15	TRUCK (2XD-D) CXZ 8PD1	89/8~93/2	Engine CRANK SHAFT REAR
03908 6763	1-09625-557-1	118 x 148 x 20	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6WA1,6WG1,6WF1	92/5~	Engine CRANK SHAFT REAR
03908 1331	1-09625-541-2	114 x 150 x 17	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6SD1	96/11~	Engine CRANK SHAFT REAR
03908 7899	1-09625-559-0	139 x 171 x 19	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6TE1,7TD1	00/1~	Engine CRANK SHAFT REAR
03908 5667	9-12569-072-0		TRUCK (2XD-D) E120	73/~83/	Engine VALVE STEM SEAL
03908 7147	1-12569-013-0		TRUCK (2XD-D) 6R	81/~89/	Engine VALVE STEM SEAL
03908 5707	1-09625-507-1	120 x 153 x 17	TRUCK (2XD-D) CXZ 10PD1,12PD1	89/8~93/2	Engine CRANK SHAFT REAR
03908 1371	1-12569-019-1		TRUCK (2XD-D) 8P#,10P#,12P#	91/7~	Engine VALVE STEM SEAL
03908 4515	1-09625-507-1	120 x 153 x 17	TRUCK (2XD-D) CXZ 8P,10P,12P	83/8~89/7	Engine CRANK SHAFT REAR
03908 6235	1-12569-019-1		TRUCK (2XD-D) 6SD1	96/11~	Engine VALVE STEM SEAL
03908 2363	1-12569-019-1		TRUCK (2XD-D) 6WA1,6WG1	92/5~00/5	Engine VALVE STEM SEAL
03908 1555	1-12569-020-0		TRUCK (2XD-D) 6WF1,6WG1	00/6~	Engine VALVE STEM SEAL
03908 6523	1-12569-019-1		TRUCK (2XD-D) 6TE1,8TD1	00/1~	Engine VALVE STEM SEAL
03908 5299	1-09625-502-0	40 x 55 x 9	TRUCK (2XD-D) SPZ	73/~83/	Transmission FRONT COVER
03908 2707	1-09625-128-0	70 x 92 x 12	TRUCK (2XD-D) SPZ,TMK-Z E120	73/~77/	Engine CRANK SHAFT FRONT
03908 2275	1-12569-009-0		TRUCK (2XD-D) 8P,10P,12P	75/~91/6	Engine VALVE STEM SEAL
03908 1515	1-09625-424-0	120 x 153 x 13 x 15	TRUCK (2XD-D) CXZ 8PD1	89/8~93/2	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3795	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 16.5 INCH DIFF.	95/5~	Final Drive PINION (REARWARD)
03908 8227	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (2XD-D) SPZ,TMK-Z E120	77/~83/	Engine CRANK SHAFT FRONT
03908 1987	1-09625-200-0	120 x 153 x 15	TRUCK (2XD-D) SRZ,SSZ,SVZ 10P,12P	75/~83/	Engine CRANK SHAFT FRONT
03908 4419	1-09625-506-0	120 x 153 x 15	TRUCK (2XD-D) CXZ 8P,10P,12P	83/8~89/7	Engine CRANK SHAFT FRONT
03908 6035	1-09625-506-0	120 x 153 x 15	TRUCK (2XD-D) XZ 10PD1,12PD1	89/8~93/2	Engine CRANK SHAFT FRONT
03908 8147	1-09625-524-3	111 x 153 x 16.5	TRUCK (2XD-D) CXZ 8PD1,10PD1,12PD1	93/3~94/	Engine CRANK SHAFT FRONT
03908 1571	1-09625-525-2	111 x 153 x 16.5	TRUCK (2XD-D) CXZ 8PD1,10PD1,12PD1	93/3~94/	Engine CRANK SHAFT REAR
03908 4667	1-09625-524-3	111 x 153 x 16.5	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6TE1,8TD1	00/1~	Engine CRANK SHAFT FRONT
03908 5955	1-09625-322-0	86 x 143 x 10 x 38	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 17.5 INCH DIFF.	94/9~	Final Drive PINION (REARWARD)
03908 2107	1-09625-556-2	118 x 148 x 20	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6WA1,6WG1,6WF1	92/5~	Engine CRANK SHAFT FRONT
03908 2747	1-09625-540-3	114 x 153 x 17.5	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 6SD1	96/11~	Engine CRANK SHAFT FRONT
03908 3699	1-09625-317-0	128 x 148 x 10	TRUCK (2XD-D) SPZ,TMK-Z E120(EXCEPT MIXER)	73/~83/	Engine CRANK SHAFT REAR
03908 5123	1-09625-317-0	128 x 148 x 10	TRUCK (2XD-D) SQZ TMQ-Z,CXZ 6R(EXCEPT MIXER)	81/8~85/12	Engine CRANK SHAFT REAR
03908 4755	1-09625-441-0	128 x 148 x 14	TRUCK (2XD-D) CXZ 6R (EXCEPT MIXER)	86/1~89/	Engine CRANK SHAFT REAR
03908 3347	1-09625-201-0	120 x 153 x 15 x 18	TRUCK (2XD-D) SRZ,SSZ,SVZ 10P,12P	75/~83/	Engine CRANK SHAFT REAR
03908 5891	1-09625-524-3	111 x 153 x 16.5	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY 8PE1,10PE1,12PE1	94/10~	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2731	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2XD-D) CYZ EXC. REAR BRAKE WITH 150MM	96/11~99/	Wheel Hub REAR INNER (F&R)
03908 7755	1-51389-005-0	155 x 185 x 13 x 16	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY	83/8~	Rear Suspension TRUNNION SHAFT
03908 8507	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (2XD-D) SQZ,CXZ 6R	81/8~89/	Engine CRANK SHAFT FRONT
03908 4115	1-09625-041-0	120 x 140 x 10.5	TRUCK (2XD-D) CXZ,CYZ,CXY,CYY	83/8~	Wheel Hub FRONT
03908 3763	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (2XD-D) SPZ,TMK- Z,SRZ,SSZ,SQZ,TMQ- Z,SVZ	73/~83/	Wheel Hub REAR INNER (F&R)
03908 1739	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2XD-D) CXZ ALL	83/8~96/10	Wheel Hub REAR INNER (F&R)
03908 3675	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2XD-D) CXZ EXC. REAR BRAKE WITH 150MM	96/11~99/	Wheel Hub REAR INNER (F&R)
03908 3859	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2XD-D) CYZ ALL	94/9~96/10	Wheel Hub REAR INNER (F&R)
03908 7547	1-09625-041-0	120 x 140 x 10.5	TRUCK (2XD-D) SPZ,TMK- Z,SRZ,SSZ,SQZ,TMQ- Z,SVZ	73/~83/	Wheel Hub FRONT
03908 6579	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2XD-D) CYZ,CYY 16.5,17.5 INCH FINAL	00/1~	Wheel Hub REAR INNER (F&R)
03908 2371	9-09924-415-0	100 x 145 x 14.5 x 26	TRUCK (2XD-D) CXZ,CYZ REAR BRAKE WITH 150MM	96/11~99/	Wheel Hub REAR INNER (F&R)
03908 2515	9-09924-415-0	100 x 145 x 14.5 x 26	TRUCK (2XD-D) CXY ALL	00/1~	Wheel Hub REAR INNER (F&R)
03908 2083	9-09924-415-0	100 x 145 x 14.5 x 26	TRUCK (2XD-D) CYZ,CYY 14.5 INCH FINAL	00/1~	Wheel Hub REAR INNER (F&R)
03908 1147	1-09625-444-0	78 x 163 x 16	TRUCK (2XD-D) CYZ EXC. REAR BRAKE WITH 150 MM	96/11~99/	Wheel Hub REAR OUTER (F&R)
03908 1291	1-51389-005-0	155 x 185 x 13 x 16	TRUCK (2XD-D) SPZ,SRZ,SSZ,SQZ,SVZ	73/~83/	Rear Suspension TRUNNION SHAFT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2387	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (2XD-D) CXZ ALL	00/1~	Wheel Hub REAR INNER (F&R)
03908 4747	9-09924-374-0	71 x 142 x 14	TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ	73/~79/12	Wheel Hub REAR OUTER (F&R)
03908 5427	9-09924-470-0	64 x 132.5 x 13	TRUCK (2XD-D) CXY ALL	00/1~	Wheel Hub REAR OUTER (F&R)
03908 1707	9-09924-470-0	64 x 132.5 x 13	TRUCK (2XD-D) CYZ,CYY 14.5 INCH FINAL	00/1~	Wheel Hub REAR OUTER (F&R)
03908 4387	1-09625-444-0	78 x 163 x 16	TRUCK (2XD-D) CYZ,CYY 16.5,17.5 INCH FINAL	00/1~	Wheel Hub REAR OUTER (F&R)
03908 2635	1-09625-444-0	78 x 163 x 16	TRUCK (2XD-D) CYZ ALL	94/9~96/10	Wheel Hub REAR OUTER (F&R)
03908 6899	1-09625-444-0	78 x 163 x 16	TRUCK (2XD-D) CXZ ALL	00/1~	Wheel Hub REAR OUTER (F&R)
03908 4907	1-09625-444-0	78 x 163 x 16	TRUCK (2XD-D) CXZ EXC. REAR BRAKE WITH 150MM	96/11~99/	Wheel Hub REAR OUTER (F&R)
03908 4323	1-09625-444-0	78 x 163 x 16	TRUCK (2XD-D) CXZ ALL	83/8~96/10	Wheel Hub REAR OUTER (F&R)
03908 3035	1-09625-379-0	74 x 142.9 x 17.5	TRUCK (2XD-D) SPZ,TMK-Z,SRZ,SSZ,SQZ,TMQ-Z,SVZ	80/1~83/	Wheel Hub REAR OUTER (F&R)
03908 5147	9-09924-470-0	64 x 132.5 x 13	TRUCK (2XD-D) CXZ,CYZ REAR BRAKE WITH 150MM	96/11~99/	Wheel Hub REAR OUTER (F&R)
03908 6099	9828-01130	146 x 170 x 18	TRUCK (6T~8T) KB	70/~81/	Wheel Hub REAR INNER
03908 4923	9828-90115	90 x 125 x 10 x 17	TRUCK (6T~8T) FZ 1F,4F	95/4~	Final Drive PINION
03908 7875	9828-75111	75 x 100 x 13 x 18	TRUCK (6T~8T) KB	70/~81/	Final Drive PINION
03908 4259	9828-70110	70 x 95 x 13 x 20	TRUCK (6T~8T) K13D	90/1~95/1	Engine CRANK SHAFT FRONT
03908 2411	9828-70110	70 x 95 x 13 x 20	TRUCK (6T~8T) EK100	83/~90/	Engine CRANK SHAFT FRONT
03908 2123	9828-96101	96 x 124 x 14 x 21	TRUCK (6T~8T) EF750,F17D	87/4~94/11	Engine CRANK SHAFT FRONT
03908 2051	9828-70102	70 x 95 x 13	TRUCK (6T~8T) EK100	70/~83/	Engine CRANK SHAFT FRONT
03908 6339	9828-80102	80 x 105 x 13	TRUCK (6T~8T) EB300	70/~81/	Engine CRANK SHAFT FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3219	9828-65116	65 x 88 x 12 x 19	TRUCK (6T~8T) H06C,H07C,D	83/7~94/	Engine CRANK SHAFT FRONT
03908 1091	9828-65116	65 x 88 x 12 x 19	TRUCK (6T~8T) EH500,700	76/~83/	Engine CRANK SHAFT FRONT
03908 4699	9828-79103	79 x 114 x 17	TRUCK (6T~8T) J08C	94/9~	Engine CRANK SHAFT FRONT
03908 7451	9828-58105	58 x 75 x 9	TRUCK (6T~8T) EH300 E/#~44626	74/~77/	Engine CRANK SHAFT FRONT
03908 7419	9828-75145	75 x 114 x 17	TRUCK (6T~8T) K13D	95/2~	Engine CRANK SHAFT FRONT
03908 2659	9828-90104	90 x 115 x 13 x 19	TRUCK (6T~8T) FZ 27#,63#,1F	83/11~95/3	Final Drive PINION
03908 2499	9828-01120	140 x 160 x 14	TRUCK (6T~8T) KG,KR,FF,FG	74/~83/11	Wheel Hub REAR INNER
03908 1283	9828-80114	80 x 136 x 9 x 25	TRUCK (6T~8T) FH 2K,2P	95/4~	Final Drive PINION
03908 1483	9828-01137	101 x 114 x 10	TRUCK (6T~8T) KR C/#~19999	74/~75/5	Wheel Hub FRONT
03908 8483	9828-80110	80 x 136 x 20 x 26	TRUCK (6T~8T) FH 220#,222BA- KA,222BF,270BD,272BA	83/12~90/2	Final Drive PINION
03908 5187	9828-80115	80 x 124 x 19 x 25	TRUCK (6T~8T) FH 221#,222BA- AA,224BA,226BA,228#,2 29#	83/12~90/2	Final Drive PINION
03908 2075	9828-80115	80 x 124 x 19 x 25	TRUCK (6T~8T) FF 2H,3H,1J	89/8~99/	Final Drive PINION
03908 7803	9828-80115	80 x 124 x 19 x 25	TRUCK (6T~8T) FG 19#,1H,1J	83/7~	Final Drive PINION
03908 2643	9828-75111	75 x 100 x 13 x 18	TRUCK (6T~8T) FG 18#	80/7~83/	Final Drive PINION
03908 7603	9828-65116	65 x 88 x 12 x 19	TRUCK (6T~8T) EH300 E/#44627~	78/~79/	Engine CRANK SHAFT FRONT
03908 6531	9828-01200	122 x 150 x 12 x 18	TRUCK (6T~8T) EM100	83/12~90/	Engine CRANK SHAFT REAR
03908 1467	13719-1470		TRUCK (6T~8T) J08C	98/1~	Engine VALVE STEM SEAL
03908 3267	13719-1360		TRUCK (6T~8T) H07C,D,J08C	94/9~97/12	Engine VALVE STEM SEAL
03908 6539	13719-1350		TRUCK (6T~8T) H06C WITH TURBO (EX.)	83/7~89/7	Engine VALVE STEM SEAL

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2427	13719-1020		TRUCK (6T~8T) H06C (IN. & EX.)	89/8~94/	Engine VALVE STEM SEAL
03908 5515	13719-1020		TRUCK (6T~8T) H06C WITH TURBO (IN.)	83/7~89/7	Engine VALVE STEM SEAL
03908 2483	13719-1020		TRUCK (6T~8T) H06C WITHOUT TURBO (IN. & EX.)	83/7~89/7	Engine VALVE STEM SEAL
03908 2475	13719-1020		TRUCK (6T~8T) H07C,D	83/7~94/8	Engine VALVE STEM SEAL
03908 1083	9828-01223	116 x 151 x 17	TRUCK (6T~8T) K13D,P11C	95/4~	Engine CRANK SHAFT REAR
03908 2211	9828-75140	75 x 100 x 13 x 20	TRUCK (6T~8T) EM100	83/12~90/	Engine CRANK SHAFT FRONT
03908 5731	9828-01228	100 x 135 x 17	TRUCK (6T~8T) J08C	94/9~	Engine CRANK SHAFT REAR
03908 3883	9828-80110	80 x 136 x 20 x 26	TRUCK (6T~8T) FH 2K	90/1~95/4	Final Drive PINION
03908 6203	9828-01201	125 x 155 x 14 x 23	TRUCK (6T~8T) K13D EXCEPT FH2KGAM-BA	90/1~95/4	Engine CRANK SHAFT REAR
03908 2579	9828-01201	125 x 155 x 14 x 23	TRUCK (6T~8T) EK100 EXCEPT MIXER	75/~90/	Engine CRANK SHAFT REAR
03908 2739	9828-01168	135 x 165 x 14 x 20.5	TRUCK (6T~8T) EF750,F17D	87/4~94/11	Engine CRANK SHAFT REAR
03908 4291	9828-01202	125 x 155 x 14	TRUCK (6T~8T) K13D FH2KGAM-BA	90/1~92/	Engine CRANK SHAFT REAR
03908 4771	9828-01202	125 x 155 x 14	TRUCK (6T~8T) EB300,EK100 MIXER	70/~87/	Engine CRANK SHAFT REAR
03908 4043	9828-01167	106 x 126 x 12	TRUCK (6T~8T) H06C,H07C,D	83/7~94/	Engine CRANK SHAFT REAR
03908 1635	9828-01167	106 x 126 x 12	TRUCK (6T~8T) EH300,500,700	74/~83/	Engine CRANK SHAFT REAR
03908 5531	9828-96109	96 x 131 x 17.5	TRUCK (6T~8T) P11C	00/3~	Engine CRANK SHAFT FRONT
03908 3075	9828-96109	96 x 131 x 17.5	TRUCK (6T~8T) F17D	94/12~02/	Engine CRANK SHAFT FRONT
03908 1443	9828-01226	125 x 177 x 17.5	TRUCK (6T~8T) F17D	94/12~02/	Engine CRANK SHAFT REAR
03908 7883	9828-65127	65 x 114 x 9 x 25	TRUCK (6T~8T) FE,FJ	98/7~	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 1403	9828-48120	48 x 60 x 9	TRUCK (6T~8T) FE 1J	96/8~	Transmission FRONT COVER
03908 7819	9828-48120	48 x 60 x 9	TRUCK (6T~8T) FG19#,FH22#,FF2H,1J	80/~99/	Transmission FRONT COVER
03908 7115	9828-43102	43 x 63 x 9	TRUCK (6T~8T) FF 17#,3H	83/7~94/	Transmission FRONT COVER
03908 5051	9828-37103	37 x 50 x 6	TRUCK (6T~8T) KR 6 SPEED,FF	76/~83/6	Transmission FRONT COVER
03908 2987	9828-57103	57 x 124 x 13	TRUCK (6T~8T) FE,FJ	96/8~	Wheel Hub REAR OUTER
03908 2203	9828-76101	76 x 164 x 14	TRUCK (6T~8T) CG,FH,FZ	81/1~	Wheel Hub REAR OUTER
03908 6379	9828-60108	60 x 74 x 7.5	TRUCK (6T~8T) KB	70/~81/	Wheel Hub REAR OUTER
03908 6179	9828-48120	48 x 60 x 9	TRUCK (6T~8T) FJ	99/3~	Transmission FRONT COVER
03908 5339	9828-52115	52 x 64 x 9	TRUCK (6T~8T) KG,FF,FG	80/~83/11	Wheel Hub REAR OUTER
03908 4555	9828-66106	66 x 134 x 16	TRUCK (6T~8T) KG,FF,FG	83/12~	Wheel Hub REAR OUTER
03908 5883	9828-52108	52 x 62 x 6 x 10	TRUCK (6T~8T) KR301,321,361	74/~77/	Wheel Hub REAR OUTER
03908 5403	9828-01203	127 x 147 x 11	TRUCK (6T~8T) FE,FJ	96/8~	Wheel Hub REAR INNER
03908 1131	9828-01193	154 x 175 x 13	TRUCK (6T~8T) CG,FH,FZ	81/1~	Wheel Hub REAR INNER
03908 6947	9828-01204	145 x 164 x 14	TRUCK (6T~8T) KG,FF,FG	83/12~	Wheel Hub REAR INNER
03908 7027	9828-01189	159 x 182 x 18	TRUCK (6T~8T) FZ	83/12~	Wheel Hub FRONT
03908 3827	9828-01207	138 x 152 x 12	TRUCK (6T~8T) CG,FE,FG,FH,FJ,KG	80/~	Wheel Hub FRONT
03908 7691	9828-01207	138 x 152 x 12	TRUCK (6T~8T) KB	70/~81/	Wheel Hub FRONT
03908 4523	9828-01207	138 x 152 x 12	TRUCK (6T~8T) KR C/#20000~	75/6~80/	Wheel Hub FRONT
03908 1427	9828-65113	65 x 114 x 10 x 25.5	TRUCK (6T~8T) FE	96/8~98/6	Final Drive PINION
03908 6675	9828-78101	78 x 100 x 14 x 20	TRUCK (6T~8T) FZ 1F	93/6~99/8	Transmission REAR COVER
03908 3299	9828-65113	65 x 114 x 10 x 25.5	TRUCK (6T~8T) FF 17#	83/7~89/	Final Drive PINION
03908 4827	9828-65108	65 x 95 x 14 x 22	TRUCK (6T~8T) KR,FF	74/~83/6	Final Drive PINION
03908 3771	9828-52115	52 x 64 x 9	TRUCK (6T~8T) KR305,325,365	77/~80/	Wheel Hub REAR OUTER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 2491	9828-78104	78 x 100 x 14 x 20	TRUCK (6T~8T) FZ 1F,4F	99/9~	Transmission REAR COVER
03908 6475	9828-50105	50 x 68 x 9	TRUCK (6T~8T) KB EXCEPT 501	72/~81/	Transmission FRONT COVER
03908 1803	9828-75119	75 x 100 x 13 x 19	TRUCK (6T~8T) FH	95/4~	Transmission REAR COVER
03908 1395	9828-75119	75 x 100 x 13 x 19	TRUCK (6T~8T) FZ 63#,1F	87/4~92/12	Transmission REAR COVER
03908 4843	9828-70101	70 x 95 x 14 x 20.5	TRUCK (6T~8T) FH,FZ27#	83/11~95/4	Transmission REAR COVER
03908 1819	9828-70101	70 x 95 x 14 x 20.5	TRUCK (6T~8T) FG	80/7~	Transmission REAR COVER
03908 3483	9828-55110	55 x 72 x 9 x 15	TRUCK (6T~8T) KR,FF	74/~83/6	Transmission REAR COVER
03908 4211	9828-70101	70 x 95 x 14 x 20.5	TRUCK (6T~8T) KB 6 SPEED	70/~81/	Transmission REAR COVER
03908 3891	9828-50105	50 x 68 x 9	TRUCK (6T~8T) FG 1H,1J	89/8~	Transmission FRONT COVER
03908 6755	9828-55113	55 x 72 x 9	TRUCK (6T~8T) FZ	83/11~	Transmission FRONT COVER
03908 1715	9828-55113	55 x 72 x 9	TRUCK (6T~8T) KB 501	77/9~81/	Transmission FRONT COVER
03908 7747	9828-60119	60 x 75 x 9 x 15	TRUCK (6T~8T) FF 17#,3H	83/7~94/	Transmission REAR COVER
03908 7515	9828-63108	63 x 78 x 9 x 15	TRUCK (6T~8T) FF 2H,1J	89/8~99/	Transmission REAR COVER
03908 3651	9828-63108	63 x 78 x 9 x 15	TRUCK (6T~8T) FE,FJ	96/8~	Transmission REAR COVER
03908 1451	9828-65111	65 x 95 x 14 x 20.5	TRUCK (6T~8T) KB 5 SPEED	70/~79/	Transmission REAR COVER
03908 5827	9828-55113	55 x 72 x 9	TRUCK (6T~8T) FH 27#,2K,2P	81/6~	Transmission FRONT COVER
03908 5483	1-09625-497-0	48 x 62 x 9	TRUCK (6T~8T) CVR	83/9~89/10	Transmission FRONT COVER
03908 2979	1-09625-085-0	55 x 72 x 15	TRUCK (6T~8T) TXD	80/5~84/	Propeller Shaft CENTER BEARING (F & R)
03908 5291	9-37529-013-0	65 x 110 x 47	TRUCK (6T~8T) TD,TP	71/~79/12	Propeller Shaft CENTER BEARING
03908 5275	1-09625-577-1	80 x 100 x 13	TRUCK (6T~8T) CVR MJT7 T/M	03/6~	Transmission REAR COVER
03908 7307	1-09625-579-1	74 x 97 x 13	TRUCK (6T~8T) CVR MAF5,MAF6 T/M	83/9~95/	Transmission REAR COVER
03908 5395	1-09625-207-0	73 x 96 x 12	TRUCK (6T~8T) TD,TP,SMR,SJR MAB T/M	80/1~83/	Transmission REAR COVER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3291	1-09625-149-0	80 x 105 x 12	TRUCK (6T~8T) SMR MAB T/M	78/4~79/12	Transmission REAR COVER
03908 1251	1-09625-063-0	68 x 90 x 12	TRUCK (6T~8T) TXD,TD,TP,SLR MLE T/M	71/~83/	Transmission REAR COVER
03908 4763	1-09625-562-0	54 x 69 x 9	TRUCK (6T~8T) CVR	89/11~	Transmission FRONT COVER
03908 5835	1-09625-130-0	65 x 90 x 16	TRUCK (6T~8T) TD,TDJ,TDK,TP	80/1~83/	Propeller Shaft CENTER BEARING (F & R)
03908 7587	1-09625-173-0	60 x 77 x 12	TRUCK (6T~8T) TXD MG,MB T/M	71/~84/	Transmission REAR COVER
03908 7659	1-09625-130-0	65 x 90 x 16	TRUCK (6T~8T) SMR EXCEPT TURBO	78/4~83/	Propeller Shaft CENTER BEARING (F & R)
03908 7427	1-09625-130-0	65 x 90 x 16	TRUCK (6T~8T) SLR,SJR	80/1~83/	Propeller Shaft CENTER BEARING (F & R)
03908 8331	1-09625-130-0	65 x 90 x 16	TRUCK (6T~8T) CVR 6QA1	83/9~89/10	Propeller Shaft CENTER BEARING (F & R)
03908 2307	1-09625-126-0	70 x 100 x 16	TRUCK (6T~8T) CVR 8PC1,8PD1,8PE1	83/9~03/	Propeller Shaft CENTER BEARING (F & R)
03908 3619	1-09625-127-0	75 x 105 x 16	TRUCK (6T~8T) CVR 6SD1,6WF1	03/6~	Propeller Shaft CENTER BEARING (F)
03908 7731	1-09625-621-0	81 x 103 x 16	TRUCK (6T~8T) CVR 6SD1,6WF1	03/6~	Propeller Shaft CENTER BEARING
03908 3427	1-09625-173-0	60 x 77 x 12	TRUCK (6T~8T) TXD	71/~77/	Final Drive PINION
03908 7915	1-09625-484-0	60 x 103 x 12 x 20	TRUCK (6T~8T) TXD	77/~84/	Final Drive PINION
03908 6987	1-09625-063-0	68 x 90 x 12	TRUCK (6T~8T) TD,TP SINGLE SPEED	71/~74/	Final Drive PINION
03908 7779	1-09625-063-0	68 x 90 x 12	TRUCK (6T~8T) SLR SINGLE SPEED	73/~83/	Final Drive PINION
03908 7699	1-09625-497-0	48 x 62 x 9	TRUCK (6T~8T) SMR,SJR	80/1~83/	Transmission FRONT COVER
03908 5307	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (6T~8T) TDJ	80/1~84/	Final Drive PINION
03908 1323	9-09924-374-0	71 x 142 x 14	TRUCK (6T~8T) TD,TP EXCEPT TD-U,TD-P (2 SPEED)	71/~79/12	Wheel Hub REAR OUTER

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3419	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (6T~8T) TP SINGLE SPEED	72/~84/	Final Drive PINION
03908 5779	9-37529-003-0	65 x 113 x 26	TRUCK (6T~8T) TD,TP	71/~79/12	Propeller Shaft CENTER BEARING(F)
03908 2331	9-09924-407-0	76 x 115 x 13 x 21	TRUCK (6T~8T) YXD	71/~84/	Wheel Hub FRONT
03908 4795	1-09625-041-0	120 x 140 x 10.5	TRUCK (6T~8T) TD,TP,SLR,SMR,SJR	73/~84/	Wheel Hub FRONT
03908 2267	1-09625-041-0	120 x 140 x 10.5	TRUCK (6T~8T) CVR	83/9~	Wheel Hub FRONT
03908 6171	9-09924-415-0	100 x 145 x 14.5 x 26	TRUCK (6T~8T) TXD	71/~84/	Wheel Hub REAR INNER
03908 6515	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (6T~8T) TD,TP EXCEPT TD-U,TD-P (2 SPEED)	71/~79/12	Wheel Hub REAR INNER
03908 3755	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (6T~8T) TDJ,TPJ78	80/1~84/	Wheel Hub REAR INNER
03908 4707	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (6T~8T) SLR,SMR(EXCEPT 360,361)	73/~83/	Wheel Hub REAR INNER
03908 2955	1-09625-351-0	115 x 156 x 15.5 x 31	TRUCK (6T~8T) SJR 461,531,601	81/8~83/	Wheel Hub REAR INNER
03908 6259	9-09924-393-0	123 x 184 x 15 x 28	TRUCK (6T~8T) TD,TP TD-U,TD-P (2 SPEED)	71/~79/12	Wheel Hub REAR INNER
03908 2219	9-09924-393-0	123 x 184 x 15 x 28	TRUCK (6T~8T) TDK,TP,TDJ (EXCEPT 78)	80/1~84/	Wheel Hub REAR INNER
03908 6163	9-09924-393-0	123 x 184 x 15 x 28	TRUCK (6T~8T) SMR360,361,SJR361	78/4~83/	Wheel Hub REAR INNER
03908 2155	9-09924-374-0	71 x 142 x 14	TRUCK (6T~8T) SMR450,520,600,670	78/3~79/12	Wheel Hub REAR OUTER
03908 7243	9-09924-470-0	64 x 132.5 x 13	TRUCK (6T~8T) TXD	71/~84/	Wheel Hub REAR OUTER
03908 1387	1-09625-502-0	40 x 55 x 9	TRUCK (6T~8T) SMR	78/4~79/12	Transmission FRONT COVER
03908 3467	9-09924-374-0	71 x 142 x 14	TRUCK (6T~8T) SLR350,360,400,450,520, 600,670,700	73/~79/12	Wheel Hub REAR OUTER
03908 8115	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (6T~8T) SMR EXCEPT 360,361	78/~83/	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 5563	1-09625-379-0	74 x 142.9 x 17.5	TRUCK (6T~8T) TD,TDJ	80/1~84/	Wheel Hub REAR OUTER
03908 7363	1-09625-379-0	74 x 142.9 x 17.5	TRUCK (6T~8T) SLR361,401,461,531	80/1~83/	Wheel Hub REAR OUTER
03908 3211	1-09625-379-0	74 x 142.9 x 17.5	TRUCK (6T~8T) SMR401,461,531,601,671	80/1~83/	Wheel Hub REAR OUTER
03908 4851	1-09625-379-0	74 x 142.9 x 17.5	TRUCK (6T~8T) SJR461,531,601	81/8~83/	Wheel Hub REAR OUTER
03908 8307	9-09924-392-0	78 x 162 x 16	TRUCK (6T~8T) TD,TP TD-U,TD-P (2 SPEED)	70/1~79/12	Wheel Hub REAR OUTER
03908 1211	9-09924-392-0	78 x 162 x 16	TRUCK (6T~8T) SMR360	78/4~79/12	Wheel Hub REAR OUTER
03908 2195	1-09625-444-0	78 x 163 x 16	TRUCK (6T~8T) SMR361,SJR361	80/1~83/	Wheel Hub REAR OUTER
03908 2531	1-09625-444-0	78 x 163 x 16	TRUCK (6T~8T) CVR	83/9~	Wheel Hub REAR OUTER
03908 7091	1-09625-502-0	40 x 55 x 9	TRUCK (6T~8T) TXD	73/~84/	Transmission FRONT COVER
03908 4963	1-09625-502-0	40 x 55 x 9	TRUCK (6T~8T) TD,TDJ,TP	80/1~84/	Transmission FRONT COVER
03908 5227	1-09625-350-0	117 x 174 x 15.5 x 28	TRUCK (6T~8T) CVR	83/9~	Wheel Hub REAR INNER
03908 6315	1-09625-441-0	128 x 148 x 14	TRUCK (6T~8T) CVR 6QA1(EXCEPT FLYWHEEL PTO)	86/4~89/10	Engine CRANK SHAFT REAR
03908 2187	1-09625-556-2	118 x 148 x 20	TRUCK (6T~8T) CVR 6WF1	03/6~	Engine CRANK SHAFT FRONT
03908 6187	9-12365-040-0	SPLIT SEAL x x	TRUCK (6T~8T) TXD DA120,640	71/~76/	Engine CRANK SHAFT REAR
03908 3371	9-09924-356-0	105 x 135 x 14	TRUCK (6T~8T) TXD 120,640	76/~84/	Engine CRANK SHAFT REAR
03908 4427	1-09625-317-0	128 x 148 x 10	TRUCK (6T~8T) TD,TP,SLR(EXCEPT MIXER) DH100	75/~84/	Engine CRANK SHAFT REAR
03908 7531	1-09625-317-0	128 x 148 x 10	TRUCK (6T~8T) TDK E120	80/1~84/	Engine CRANK SHAFT REAR
03908 1315	1-09625-317-0	128 x 148 x 10	TRUCK (6T~8T) TDJ,TPJ 6QA1	80/1~84/	Engine CRANK SHAFT REAR

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 3275	1-09625-541-2	114 x 150 x 17	TRUCK (6T~8T) CVR 6SD1	03/6~	Engine CRANK SHAFT REAR
03908 6003	1-09625-317-0	128 x 148 x 10	TRUCK (6T~8T) CVR 6QA1(EXCEPT FLYWHEEL PTO)	83/9~86/3	Engine CRANK SHAFT REAR
03908 6299	1-09625-424-0	120 x 153 x 13 x 15	TRUCK (6T~8T) CVR 8PC1,8PD1	88/8~95/	Engine CRANK SHAFT FRONT
03908 6771	1-09625-504-0	125 x 155 x 10	TRUCK (6T~8T) SLR DH100 (MIXER)	76/~83/	Engine CRANK SHAFT REAR
03908 5627	1-09625-504-0	125 x 155 x 10	TRUCK (6T~8T) CVR 6QA1 (MIXER)	83/9~89/	Engine CRANK SHAFT REAR
03908 5371	1-09625-201-0	120 x 153 x 15 x 18	TRUCK (6T~8T) SMR 8PB1	78/4~83/	Engine CRANK SHAFT REAR
03908 2907	1-09625-507-1	120 x 153 x 17	TRUCK (6T~8T) CVR 8PC1	83/9~88/7	Engine CRANK SHAFT REAR
03908 8235	1-09625-425-1	120 x 153 x 15	TRUCK (6T~8T) CVR 8PC1,8PD1	88/8~95/	Engine CRANK SHAFT REAR
03908 2347	1-09625-525-2	111 x 153 x 16.5	TRUCK (6T~8T) CVR 8PE1	95/3~03/	Engine CRANK SHAFT REAR
03908 2291	1-09625-317-0	128 x 148 x 10	TRUCK (6T~8T) SJR 6QA1(EXCEPT MIXER)	81/8~83/	Engine CRANK SHAFT REAR
03908 5643	1-09625-128-0	70 x 92 x 12	TRUCK (6T~8T) TD,TP,SLR DH100,D920	71/~77/	Engine CRANK SHAFT FRONT
03908 7355	1-09625-578-1	78 x 97 x 13	TRUCK (6T~8T) CVR MAL5,MAL6,MAP6 T/M	95/5~	Transmission REAR COVER
03908 2915	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (6T~8T) SJR461,531,601	81/8~83/	Final Drive PINION
03908 6427	1-09625-017-0	68 x 124 x 11.5 x 27	TRUCK (6T~8T) CVR 16.5 INCH FINAL	83/9~	Final Drive PINION
03908 4283	1-09625-149-0	80 x 105 x 12	TRUCK (6T~8T) TD,TP 2 SPEED	71/~84/	Final Drive PINION
03908 8283	1-09625-149-0	80 x 105 x 12	TRUCK (6T~8T) SLR 2 SPEED	73/~79/12	Final Drive PINION

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 6923	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (6T~8T) TDK SINGLE SPEED	80/1~84/	Final Drive PINION
03908 3627	1-09625-540-3	114 x 153 x 17.5	TRUCK (6T~8T) CVR 6SD1	03/???	Engine CRANK SHAFT FRONT
03908 4091	1-09625-128-0	70 x 92 x 12	TRUCK (6T~8T) TXD DA120,640	71/~84/	Engine CRANK SHAFT FRONT
03908 1787	1-09625-524-3	111 x 153 x 16.5	TRUCK (6T~8T) CVR..8PE1	95/3~03/	Engine CRANK SHAFT FRONT
03908 1923	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (6T~8T) TD,TP,SLR DH100	77/~84/	Engine CRANK SHAFT FRONT
03908 2771	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (6T~8T) TDK E120	80/1~84/	Engine CRANK SHAFT FRONT
03908 6331	1-09625-316-0	70 x 92 x 10 x 16	TRUCK (6T~8T) TDJ,TPJ,SJR,CVR 6QA1	80/1~88/7	Engine CRANK SHAFT FRONT
03908 3395	1-09625-442-0	70 x 92 x 12	TRUCK (6T~8T) CVR 6QA1	88/8~89/10	Engine CRANK SHAFT FRONT
03908 4171	1-09625-200-0	120 x 153 x 15	TRUCK (6T~8T) SMR 8PB1	78/4~83/	Engine CRANK SHAFT FRONT
03908 8451	1-09625-506-0	120 x 153 x 15	TRUCK (6T~8T) CVR 8PC1,8PD1	83/9~88/7	Engine CRANK SHAFT FRONT
03908 4819	1-09625-322-0	86 x 143 x 10 x 38	TRUCK (6T~8T) CVR 17.5 INCH FINAL	89/11~	Final Drive PINION
03908 1355	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (6T~8T) CVR 17.5 INCH FINAL	83/9~89/10	Final Drive PINION
03908 2795	1-09625-030-0	80 x 143 x 10 x 37	TRUCK (6T~8T) SMR360,361,SJR361	78/4~83/	Final Drive PINION
03908 4123	1-12569-009-0		TRUCK (6T~8T) DA120,640	71/~84/	Engine VALVE STEM SEAL
03908 3747	9-12569-072-0		TRUCK (6T~8T) E120	71/~83/	Engine VALVE STEM SEAL
03908 3027	9-12569-058-0		TRUCK (6T~8T) DA100,6QA1	75/~89/10	Engine VALVE STEM SEAL
03908 1867	1-12569-009-0		TRUCK (6T~8T) 8PC1,8PD1	83/9~91/6	Engine VALVE STEM SEAL
03908 5179	1-12569-019-1		TRUCK (6T~8T) 8PC1,8PD1,8PE1	91/7~03/	Engine VALVE STEM SEAL
03908 6707	1-12569-019-1		TRUCK (6T~8T) 6SD1	03/6~	Engine VALVE STEM SEAL

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 7083	1-12569-020-0		TRUCK (6T~8T) 6WF1	03/6~	Engine VALVE STEM SEAL
03908 1683	1-09625-557-1	118 x 148 x 20	TRUCK (6T~8T) CVR 6WF1	03/6~	Engine CRANK SHAFT REAR
03908 5947	9828-01201	125 x 155 x 14 x 23	TRUCK ENGINE K13C,D EXCEPT MIXER	89/11~95/3	Crank Shaft REAR
03908 2867	9828-01202	125 x 155 x 14	TRUCK ENGINE EK100 MIXER	75/~89/	Crank Shaft REAR
03908 4435	9828-01201	125 x 155 x 14 x 23	TRUCK ENGINE EK100 EXCEPT MIXER	75/~90/	Crank Shaft REAR
03908 6115	9828-01202	125 x 155 x 14	TRUCK ENGINE K13D MIXER	89/11~95/3	Crank Shaft REAR
03908 2299	9828-01158	130 x 161 x 14	TRUCK ENGINE EF300 E/?..30000		Crank Shaft REAR
03908 2147	9828-01103	135 x 165 x 14	TRUCK ENGINE EF300 E/?..30001~		Crank Shaft REAR
03908 8027	9828-01103	135 x 165 x 14	TRUCK ENGINE EF500,700 E/?..30100	~81/	Crank Shaft REAR
03908 4475	9828-01168	135 x 165 x 14 x 20.5	TRUCK ENGINE EF500,700 E/?..30101~	81/~82/	Crank Shaft REAR
03908 6667	9828-01168	135 x 165 x 14 x 20.5	TRUCK ENGINE EF350,550,750	81/~90/	Crank Shaft REAR
03908 6043	9828-01168	135 x 165 x 14 x 20.5	TRUCK ENGINE V22D	90/10~95/	Crank Shaft REAR
03908 5907	9828-01223	116 x 151 x 17	TRUCK ENGINE P11C	94/12~	Crank Shaft REAR
03908 1139	9828-01200	122 x 150 x 12 x 18	TRUCK ENGINE P09C,11C	89/10~94/11	Crank Shaft REAR
03908 1771	9828-01228	100 x 135 x 17	TRUCK ENGINE J08C	94/9~	Crank Shaft REAR
03908 7923	9828-01226	125 x 177 x 17.5	TRUCK ENGINE F17D,E,V,F20C,F21C	94/12~	Crank Shaft REAR
03908 6915	9828-96109	96 x 131 x 17.5	TRUCK ENGINE P11C	00/3~	Crank Shaft FRONT
03908 3587	9828-01223	116 x 151 x 17	TRUCK ENGINE K13C,D	95/4~	Crank Shaft REAR
03908 5131	9828-01168	135 x 165 x 14 x 20.5	TRUCK ENGINE F17C,D,E,F20C	87/7~94/11	Crank Shaft REAR

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 8099	9828-01200	122 x 150 x 12 x 18	TRUCK ENGINE EP100,EM100	81/1~90/	Crank Shaft REAR
03908 4987	9828-70110	70 x 95 x 13 x 20	TRUCK ENGINE K13D	89/11~94/12	Crank Shaft FRONT
03908 3507	9828-96109	96 x 131 x 17.5	TRUCK ENGINE K13C	98/2~	Crank Shaft FRONT
03908 7995	9828-01167	106 x 126 x 12	TRUCK ENGINE H06C,H07C,D	83/7~94/	Crank Shaft REAR
03908 7555	9828-70102	70 x 95 x 13	TRUCK ENGINE EK100 KF3#,ZM3#,TC3#	71/~81/	Crank Shaft FRONT
03908 5579	9828-70110	70 x 95 x 13 x 20	TRUCK ENGINE EK100	83/8~90/	Crank Shaft FRONT
03908 1779	9828-96101	96 x 124 x 14 x 21	TRUCK ENGINE EF300,350,500	77/~81/	Crank Shaft FRONT
03908 6147	9828-96101	96 x 124 x 14 x 21	TRUCK ENGINE EF550,750	81/5~90/	Crank Shaft FRONT
03908 2091	9828-96101	96 x 124 x 14 x 21	TRUCK ENGINE F17C,D,E,F20C	85/10~94/11	Crank Shaft FRONT
03908 8515	9828-96101	96 x 124 x 14 x 21	TRUCK ENGINE V22D	90/10~95/	Crank Shaft FRONT
03908 4347	9828-96109	96 x 131 x 17.5	TRUCK ENGINE F17D,E,V,F20C,F21C	94/12~	Crank Shaft FRONT
03908 5619	9828-75140	75 x 100 x 13 x 20	TRUCK ENGINE K13C	83/10~94/12	Crank Shaft FRONT
03908 7539	9828-75140	75 x 100 x 13 x 20	TRUCK ENGINE P09C	89/10~92/	Crank Shaft FRONT
03908 2931	9828-75140	75 x 100 x 13 x 20	TRUCK ENGINE P11C	92/4~00/2	Crank Shaft FRONT
03908 7763	9828-65116	65 x 88 x 12 x 19	TRUCK ENGINE H06C,H07C,D	83/7~94/	Crank Shaft FRONT
03908 7131	9828-79103	79 x 114 x 17	TRUCK ENGINE J08C	94/9~	Crank Shaft FRONT
03908 5715	9828-75145	75 x 114 x 17	TRUCK ENGINE K13C,D	95/1~98/1	Crank Shaft FRONT
03908 2539	9828-75145	75 x 114 x 17	TRUCK ENGINE K13D	98/2~	Crank Shaft FRONT
03908 8139	9828-75140	75 x 100 x 13 x 20	TRUCK ENGINE EP100,EM100	82/7~90/	Crank Shaft FRONT

5. Seals product list

5.8 HINO

SNT Part No.	OEM Part No.	Size	Body Model	Year/ Month	Part Description
03908 4539	9828-70102	70 x 95 x 13	TRUCK ENGINE EK100 FR27#,FP27#,FS27#,FN27#,GN27#	81/5~83/	Crank Shaft FRONT
03908 6139	13719-1080		TRUCK ENGINE K13D	89/11~00/	Valve Stem Seal
03908 1947	13719-1540		TRUCK ENGINE P11C	00/3~	Valve Stem Seal
03908 3067	13719-1500		TRUCK ENGINE F21C	02/3~	Valve Stem Seal
03908 5379	13719-1030		TRUCK ENGINE EM100, EP100	83/12~90/	Valve Stem Seal
03908 1547	13719-1030		TRUCK ENGINE F20C, 21C	89/11~00/2	Valve Stem Seal
03908 6651	13719-1080		TRUCK ENGINE K13C	86/1~92/3	Valve Stem Seal
03908 2899	13719-1370		TRUCK ENGINE P09C, 11C	89/10~00/2	Valve Stem Seal
03908 3139	13719-1470		TRUCK ENGINE J08C	98/1~	Valve Stem Seal
03908 5659	13719-1360		TRUCK ENGINE J08C	94/9~97/12	Valve Stem Seal
03908 4579	13719-1020		TRUCK ENGINE K13C	92/4~	Valve Stem Seal
03908 4235	13719-1020		TRUCK ENGINE H06C, H07C, D	83/7~94/10	Valve Stem Seal
03908 5203	13719-1080		TRUCK ENGINE V22D	90/10~95/	Valve Stem Seal
03908 1763	13719-1080		TRUCK ENGINE F17C, D, E, V	85/10~	Valve Stem Seal
03908 6131	13719-1080		TRUCK ENGINE EK100, EF550, 750	83/8~90/	Valve Stem Seal

SERVICE WORLDWIDE

For over 10 years, we have continuously strived to improve our business to efficiently meet every customer demand. Now, SNT is providing Worldwide Service that will help drive your business growth endlessly and sustainably.



SNT AUTOPART GROUP

HEADQUARTERS

SNT AUTOPART ENTERPRISE, LLC.

Empire State Building
350 Fifth Avenue, 59th Floor
New York, NY 10118 U.S.A.
Telephone: (+1)917-979-6883
Fax: (+1)917-979-6884
E-mail: info@sntautopart.com

ASIA-PACIFIC OFFICE

SNT AUTOPART INTERTRADE Co., Ltd.

All Seasons Place
36th Floor, CRC Tower,
87/2 Wireless Road, Pathumwan,
Bangkok 10330 Thailand
Telephone: (+66)2-105-6155
Fax: (+66)2-105-6155 Ext.4
E-mail: info@sntautopart.com

FACTORY

SNT MACHINE LIMITED PARTNERSHIP

18/3 Rama II Road,
Samaedam, Bangkhuntien,
Bangkok 10150 Thailand
Telephone: (+66)2-897-0968
Fax: (+66)2-897-0968
E-mail: info@sntautopart.com



www.sntautopart.com