

PICKUP



TRUCK



BUILT TOUGH



TRAILER



HEAVY-DUTY EQUIPMENT



Oil Seals

CATALOG



SNT AUTOPART GROUP
www.sntautopart.com



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

1. FOREWORD

Rubber parts are in our DNA. It's not marketing speak. SNT produce only the highest quality products. If you need something custom, our engineering and design team can help assist with your unique rubber part requirements with our warranty guarantee. **We are different and we want to show why that's good for you.**

We know that having the right part at the right time is crucial to your operation. Under the SNT brand, we carry more than 30,000 SKUs.

We believe the best method to get our products to the customer is through strategic alliances with our distribution partners. Our commitment to our distributors, and the ultimate user, is to constantly introduce new and innovative products at higher levels of quality with an emphasis on compressed lead times - products that will last longer and reduce overall maintenance costs. All of our employees have a "can do" attitude and take pride in helping customers. **You have a problem? We have a solution.** All we ask is the chance to prove ourselves; you won't be disappointed!

Content Remarks

All rubber parts in this catalogue are specially manufactured by SNT. The O.E.M. Part No., Interchange Part No., Auto maker name, and all other trademarks mentioned in this document are the property of their respective owners and are used for identification purposes only.



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

2. INTRODUCTION

SNT AUTOPART GROUP is a leading manufacturer of replacement parts. For over 30 years experience, SNT supplies the high quality rubber parts successfully. We win worldwide clients' trust based on **premium quality of products, excellent service and competitive price.**

Our top executive has more than 7 years of R&D experience at the top 3 automobile companies in the world, create a perfect knowledge of products. Moreover, SNT products are manufactured according to German standard (DIN) and ISO 9001 quality management system. So we guarantee to

“SNT products are the same characteristics of original spare parts with competitive price”

SNT AUTOPART GROUP is comprised of the following companies:

1. SNT AUTOPART ENTERPRISE, LLC. (New York, U.S.A.)
2. SNT AUTOPART INTERTRADE Co., Ltd. (Bangkok, Thailand)
3. SNT MACHINE Ltd., Part. (Bangkok, Thailand)



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

2.1 ISO 9001 CERTIFICATION

globalgroup
Management System Experts[®]

Certificate of Registration

This is to certify that the

QUALITY MANAGEMENT SYSTEM

of

S.N.T. MACHINE LTD., PART.

18/3 Soi Bangkradee19 Yeak6, RAMA II Road, Bangkhuntien, Bangkok, 10150, THAILAND

for

Design and Manufacture of Rubber Parts and Stamping Parts, Oil Seals, Rubber Bushings, Torque Rod Bushings, Engine Mounts for Automotives, Motorcycles and Industrial Machineries.

has been assessed and registered against the provisions of

ISO 9001:2008

International Standard

With

Registration Number:	44Q16937	Project:	11-16937-1-Q
Certification Date:	11 December 2015	Code:	DH 25.13
Recertification Due Date:	14 September 2018	Exclusions:	7.5.4, 7.5.2
Certification Approved By:		Alan Cherry	
		Chairman	

Registration is subject to the management system being continually maintained to the above standard under regular surveillance. Should surveillance not take place when required, registration shall be removed.

This certificate is the property of GlobalGROUP of Companies Limited
21 Lansdowne Crescent, Edinburgh, Midlothian, EH12 5EH, Scotland, United Kingdom


0039

Please validate the authenticity of the certificate at www.globalgroup.net


30002530


3. SNT WARRANTY

SNT, warrants that all products sold shall be free from defects in material and workmanship for period of one year from date of shipment. At our option, any products prove to be defective either in workmanship or material whereby it is not suitable under proper usage and service for the purpose for which designed shall be replaced free of charge including transportation charges, but not the cost of installation, providing that the products are not subject to negligence, accident, or damages beyond our control. We shall not be responsible for consequential damages.

4. MEMBERSHIPS

SNT AUTOPART GROUP is long standing members and supporter of the following associations.

- 1) THE FEDERATION OF THAI INDUSTRIES
- 2) THE THAI CHAMBER OF COMMERCE
- 3) THAILAND AUTOMOTIVE INSTITUTE
- 4) THAI AUTO PARTS MANUFACTURERS ASSOCIATION



THE FEDERATION OF THAI INDUSTRIES



5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4579	540727	80	110	10	-
03802 3806	543637	50	80	13	-
03802 1327	585208	30	40	7	10
03802 2972	595985	35	55	10	-
03802 2732	724579	30	55	10	-
03802 2732	734128	30	55	10	-
03802 3991	741605	55	90	10	-
03802 4255	741654	65	90	10	-
03802 2223	746389	17	28	7.3	-
03802 2739	751065	30	62	10	-
03802 2493	757174	25	52	8	-
03802 2309	759371	20	40	7	-
03802 2493	762113	25	52	8	-
03802 2459	767755	25	40	7	-
03802 2437	768343	25	35	7	-
03802 2437	772333	25	35	7	-
03802 2223	773254	17	28	7.3	-
03802 3388	815835	42	62	8	-
03802 4462	843075	75	100	10	-
03802 5128	843182	130	160	12	-
03802 4390	851101	70	100	12	-
03802 2223	860111	17	28	7.3	-
03802 3217	882509	40	56	8	-
03802 4684	886807	88	126	12	-
03802 4648	892532	85	110	12	-
03802 3991	989094	55	90	10	-
03802 2119	1122949	10	15	3	-
03802 3709	1161039	50	62	7	-
03802 2116	1167489	8	16	7	-
03802 2897	1268104	35	47	7	-
03802 2119	1273109	10	15	3	-
03802 2155	01273789	14	24	7	-
03802 3657	1274257	48	65	10	-
03802 2223	1288064	17	28	7.3	-
03802 3086	1290380	38	52	7	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 2129	1307739	11	17	4	-
03802 2711	1307817	30	47	7	-
03802 4841	1905085	95.3	114.29	11.88	-
03802 4881	2148905	100	120	15	-
03802 4244	2234133	65	85	13	-
03802 5040	2234134	115	140	16	-
03802 4955	2418366	105	130	15	-
03802 4881	2421819	100	120	15	-
03802 4955	2421820	105	130	15	-
03802 5239	2442744	150	170	15	-
03802 5067	2475845	120	140	13	-
03802 4994	2475900	110	130	13	-
03802 5053	2475977	117.48	152.36	22	-
03802 3707	2476049	50	62	5	-
03802 1978	2477558	110	130	18	50
03802 4650	2477868	85	110	12	-
03802 3882	2478478	54	68	12	-
03802 4801	2478619	95	115	13	-
03802 1814	2479497	65	80	8	10
03802 4080	2960684	60	74	10	-
03802 2439	2961557	25	35	7	-
03802 1304	2961558	25	35	7	10
03802 3390	2961985	42	62	10	-
03802 4358	2965403	70	90	10	-
03802 4354	2965404	70	90	10	-
03802 3657	2980071	48	65	10	-
03802 2459	2982310	25	40	7	-
03802 3540	3345907	45	65	10	-
03802 4153	3345918	60	90	13	-
03802 4153	3433912	60	90	13	-
03802 5279	4008972	160	185	10	-
03802 5052	4016447	117.47	142.87	12.7	-
03802 3864	4023144	52	76.2	10	-
03802 5165	4023392	135	162	13	-
03802 4407	4048022	72	100	10	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 3684	4051367	48	72	10	-
03802 3486	4117608	45	59.13	10	-
03802 4357	4279412	70	90	10	-
03802 4730	4279413	90	115	13	-
03802 5067	4459071	120	140	13	-
03802 4088	4459074	60	75	8	-
03802 1737	4459442	55	72	12	21
03802 1833	4459443	66.67	92.2	12.7	21
03802 4354	4460151	70	90	10	-
03802 4355	4460152	70	90	10	-
03802 3278	4503820	40	65	10	-
03802 4397	4545571	70	112	12	-
03802 4993	4551424	110	130	13	-
03802 5181	4560719	140	160	13	-
03802 4485	4562724	75	120	13	-
03802 5055	4566052	118	136	13	-
03802 5101	4566349	125	150	13	-
03802 4866	4567251	100	118	12	-
03802 5236	4573796	150	168	13	-
03802 5280	4580400	160	185	13	-
03802 4255	4580546	65	90	10	-
03802 2728	4587995	30	52	10	-
03802 2732	4587996	30	55	10	-
03802 3933	4589556	55	72	10	-
03802 3262	4590419	40	62	10	-
03802 3390	4594821	42	62	10	-
03802 4868	4597461	100	120	10	-
03802 4178	4597462	62	80	10	-
03802 2728	4597995	30	52	10	-
03802 3991	4655211	55	90	10	-
03802 3917	4716458	55	70	8	-
03802 4784	4833664	95	100	14	-
03802 4324	4833666	70	65	14	-
03802 1199	4862154	100	176.8	13.6	-
03802 1856	4890832	70	100	12.5	16

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 2023	4890833	130	155	12.5	16
03802 1043	7149488	63.5	108	15	17.9
03802 1543	7162447	41.27	49.5	4	6
03802 1695	7162448	50.8	59	4	6.2
03802 1356	7162882	34	41.2	3.5	5.7
03802 2537	7163000	27	33.7	4	-
03802 5325	7163592	180	200	15	-
03802 1313	7169664	27	33.7	3.5	5.7
03802 2537	7170630	27	33.7	4	-
03802 1544	7170631	42	49.2	3.5	5.7
03802 1695	7170632	50.8	59	4	6.2
03802 1695	7170633	50.8	59	4	6.2
03802 1543	7170634	41.27	49.5	4	6
03802 1695	7170962	50.8	59	4	6.2
03802 5151	7178936	133.35	180	17	-
03802 5151	7179838	133.35	180	17	-
03802 1614	7182982	45	75	13	14.5
03802 4833	7185250	95	130	16	-
03802 1614	7185355	45	75	13	14.5
03802 1798	7185870	60	90	14	16.3
03802 4841	7980661	95.3	114.29	11.88	-
03802 2711	7980955	30	47	7	-
03802 2944	7981262	35	52	7	-
03802 3823	7981329	50.8	65	8	-
03802 4751	7981666	90	125	12	-
03802 3948	7982064	55	75	8	-
03802 4949	7982082	105	130	12	-
03802 4355	7984238	70	90	10	-
03802 1907	7984287	82.61	139.7	16.5	19.4
03802 1043	7984661	63.5	108	15	17.9
03802 5099	8120972	125	150	10	-
03802 4499	8121803	76.2	101.6	11.5	-
03802 3487	8123520	45	60	7	-
03802 4956	8123893	105	130	16	-
03802 3658	8193021	48	65	10	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4796	8193189	95	115	10	-
03802 2435	08193597	25	35	7	-
03802 3658	8193659	48	65	10	-
03802 1155	8193809	82.6	155	19.4	-
03802 2674	8194329	30	42	7	-
03802 1329	8194388	30	42	6	6.5
03802 4939	8194731	105	125	12	-
03802 4947	8198823	105	130	12	-
03802 4446	8199344	75	95	10	-
03802 2242	8273910	17.46	28.58	6.3	-
03802 5244	8527970	150	180	13	-
03802 4352	8576283	70	90	10	-
03802 4473	8831405	75	100	17	-
03802 4545	8833200	80	100	10	-
03802 4468	8836666	75	100	13	-
03802 2279	8857563	20	26	4	-
03802 3412	8869681	42	76	10	-
03802 4081	8870828	60	74	10	-
03802 3412	8870829	42	76	10	-
03802 4723	8952035	90	110	13	-
03802 2598	9004030	28	42.5	8	-
03802 2119	9005065	10	15	3	-
03802 2494	9007270	25	52	10	-
03802 2363	9917920	22.2	34.9	6.35	-
03802 2613	9918512	28	47	7	-
03802 2675	9920169	30	42	7	-
03802 4841	9930128	95.3	114.29	11.88	-
03802 4499	9931099	76.2	101.6	11.5	-
03802 4629	9931649	85	105	10	-
03802 1304	9931659	25	35	7	10
03802 4629	9931790	85	105	10	-
03802 3692	9932368	48	75	8	-
03802 3657	9933015	48	65	10	-
03802 3677	9933054	48	69	10	-
03802 4203	9980750	63.6	88.9	11	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4315	9980981	69.8	101.6	11	-
03802 4351	9981309	70	90	10	-
03802 3692	9981327	48	75	8	-
03802 2598	9981723	28	42.5	8	-
03802 2220	9982785	17	28	7	-
03802 4499	9985197	76.2	101.6	11.5	-
03802 4869	9986969	100	120	10	-
03802 2613	9987536	28	47	7	-
03802 4355	9988105	70	90	10	-
03802 2363	9988597	22.2	34.9	6.35	-
03802 4204	9988946	63.6	90	11	-
03802 3823	9989094	50.8	65	8	-
03802 2162	10043190	14	35	7	-
03802 2234	10043290	17	40	7	-
03802 2490	10043490	25	52	7	-
03802 2313	25450612	20	42	7	-
03802 2494	29740382	25	52	10	-
03802 3721	29740892	50	65	8	-
03802 4587	29741132	80	120	13	-
03802 2311	30187487	20	40	10	-
03802 4301	30188213	68	90	10	-
03802 4544	38505699	80	100	10	-
03802 4462	38510549	75	100	10	-
03802 4579	38512262	80	110	10	-
03802 4390	38514100	70	100	12	-
03802 4949	38515091	105	130	12	-
03802 5280	38529750	160	185	13	-
03802 4473	38819123	75	100	17	-
03802 3401	40000010	42	65	12	-
03802 4353	40000040	70	90	10	-
03802 3211	40000050	40	56	7	-
03802 4545	40000070	80	100	10	-
03802 3872	40000160	53	68	10	-
03802 3872	40000161	53	68	10	-
03802 2615	40000180	28	47	8	-



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)
SNT AUTOPART INTERTRADE CO., LTD
SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 3211	40000220	40	56	7	-
03802 2845	40000240	32	56	11	-
03802 2615	40000260	28	47	8	-
03802 4178	40000280	62	80	10	-
03802 4178	40000283	62	80	10	-
03802 3539	40000370	45	65	10	-
03802 3932	40000400	55	72	10	-
03802 4391	40000410	70	100	12	-
03802 4428	40000420	75	90	7	-
03802 5209	40000480	145	170	13	-
03802 3939	40000490	55	72	12	-
03802 3977	40000520	55	80	10	-
03802 2485	40000560	25	47	10	-
03802 3390	40000580	42	62	10	-
03802 3390	40000583	42	62	10	-
03802 4477	40000610	75	105	12	-
03802 4581	40000620	80	110	13	-
03802 4463	40000630	75	100	10	-
03802 5325	40000690	180	200	15	-
03802 4826	40000720	95	120	13	-
03802 4370	40000730	70	90	15	-
03802 5189	40000740	140	165	15	-
03802 4397	40000750	70	112	12	-
03802 4868	40000760	100	120	10	-
03802 4868	40000763	100	120	10	-
03802 2601	40000800	28	43	10	-
03802 5032	40000850	115	140	13	-
03802 3989	40000860	55	90	10	-
03802 2217	40000880	17	28	7	-
03802 2217	40000881	17	28	7	-
03802 2710	40000930	30	47	7	-
03802 5236	40000950	150	168	13	-
03802 5033	40000960	115	140	13	-
03802 3575	40000990	45	75	10	-
03802 5052	40001010	117.47	142.87	12.7	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4866	40001020	100	118	12	-
03802 4993	40001030	110	130	13	-
03802 4188	40001040	62	100	12	-
03802 5165	40001050	135	162	13	-
03802 5055	40001060	118	136	13	-
03802 2847	40001120	32	65	13	-
03802 2847	40001124	32	65	13	-
03802 4153	40001260	60	90	13	-
03802 4684	40001300	88	126	12	-
03802 4684	40001304	88	126	12	-
03802 3804	40001320	50	80	10	-
03802 5059	40001440	118	148	15	-
03802 3804	40001580	50	80	10	-
03802 4580	40001590	80	110	12	-
03802 5280	40001650	160	185	13	-
03802 5280	40001653	160	185	13	-
03802 4581	40001670	80	110	13	-
03802 5155	40001790	134	152	13	-
03802 5000	40001800	110	135	13	-
03802 3073	40001820	38	50	7	-
03802 3073	40001821	38	50	7	-
03802 4468	40001880	75	100	13	-
03802 4468	40001883	75	100	13	-
03802 4723	40001900	90	110	13	-
03802 4723	40001903	90	110	13	-
03802 4908	40001910	100	130	13	-
03802 4908	40001913	100	130	13	-
03802 5052	40001920	117.47	142.87	12.7	-
03802 5102	40001930	125	150	13	-
03802 5102	40001933	125	150	13	-
03802 5193	40001940	140	170	13	-
03802 4138	40002020	60	85	10	-
03802 4485	40002050	75	120	13	-
03802 4581	40002160	80	110	13	-
03802 2485	40002280	25	47	10	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4976	40002310	108	135	15	-
03802 4473	40002440	75	100	17	-
03802 3262	40002540	40	62	10	-
03802 4844	40002600	96	135.7	12	-
03802 4363	40002630	70	90	12	-
03802 5103	40002650	125	150	13	-
03802 4418	40002740	74	90	10	-
03802 5000	40002810	110	135	13	-
03802 5000	40002811	110	135	13	-
03802 4966	40002850	105	136	13	-
03802 4966	40002851	105	136	13	-
03802 3978	40003260	55	80	10	-
03802 4485	40003360	75	120	13	-
03802 4152	40003400	60	90	13	-
03802 4801	40003510	95	115	13	-
03802 4485	40003620	75	120	13	-
03802 3771	40003630	50	70	10	-
03802 3771	40003640	50	70	10	-
03802 3917	40003650	55	70	8	-
03802 4357	40003660	70	90	10	-
03802 4730	40003670	90	115	13	-
03802 5033	40003700	115	140	13	-
03802 3810	40003710	50	81	13	-
03802 3810	40003713	50	81	13	-
03802 4418	40003760	74	90	10	-
03802 5022	40003800	114	135	13	-
03802 4357	40003840	70	90	10	-
03802 4730	40003850	90	115	13	-
03802 4911	40100040	100	130	14	-
03802 5194	40100060	140	170	14	-
03802 3917	40100070	55	70	8	-
03802 3771	40100080	50	70	10	-
03802 4803	40100090	95	115	14	-
03802 4803	40100093	95	115	14	-
03802 5185	40100100	140	160	14	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 5185	40100103	140	160	14	-
03802 4910	40100110	100	130	14	-
03802 4910	40100113	100	130	14	-
03802 4152	40100140	60	90	13	-
03802 5185	40100200	140	160	14	-
03802 4357	40100300	70	90	10	-
03802 4357	40100303	70	90	10	-
03802 4730	40100310	90	115	13	-
03802 4730	40100313	90	115	13	-
03802 3917	40100330	55	70	8	-
03802 3917	40100331	55	70	8	-
03802 5321	40100440	180	200	12	-
03802 4272	40100450	65	100	14	-
03802 4904	40100460	100	130	12	-
03802 4904	40100463	100	130	12	-
03802 4651	40100470	85	110	12	-
03802 4364	40100480	70	90	12	-
03802 4509	40100490	78	100	10	-
03802 4245	40100501	65	85	13	-
03802 4245	40100503	65	85	13	-
03802 3658	40100510	48	65	10	-
03802 3658	40100511	48	65	10	-
03802 3658	40100513	48	65	10	-
03802 5189	40100600	140	165	15	-
03802 4370	40100610	70	90	15	-
03802 5156	40100650	134	152	14	-
03802 5194	40100660	140	170	14	-
03802 5194	40100663	140	170	14	-
03802 5323	40100670	180	200	12	-
03802 5323	40100673	180	200	12	-
03802 2710	40100790	30	47	7	-
03802 2710	40100791	30	47	7	-
03802 4568	40100810	80	100	14	-
03802 4568	40100813	80	100	14	-
03802 4361	40100850	70	90	10	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4361	40100853	70	90	10	-
03802 3399	40100870	42	65	10	-
03802 5022	40100880	114	135	13	-
03802 4357	40100900	70	90	10	-
03802 3917	40100933	55	70	8	-
03802 4735	40100960	90	115	15	-
03802 5315	40101010	176	196	5.8	-
03802 5315	40101013	176	196	5.8	-
03802 4588	40101021	80	120	15	-
03802 4588	40101023	80	120	15	-
03802 2439	40101080	25	35	7	-
03802 5238	40101090	150	170	14	-
03802 5238	40101093	150	170	14	-
03802 5071	40101103	120	140	14	-
03802 5122	40101113	128	148	12	-
03802 1073	40101120	128	152.3	11	26
03802 4426	40101163	75	88	5.5	-
03802 5122	40101163	128	148	12	-
03802 3575	40101180	45	75	10	-
03802 5033	40101210	115	140	13	-
03802 5034	40101220	115	140	13	-
03802 5103	40101240	125	150	13	-
03802 5058	40101320	118	148	13	-
03802 3401	40101330	42	65	12	-
03802 5022	40101340	114	135	13	-
03802 3872	40101360	53	68	10	-
03802 4473	40101390	75	100	17	-
03802 5103	40101400	125	150	13	-
03802 3575	40101420	45	75	10	-
03802 5187	40101433	140	165	13	-
03802 2847	40101440	32	65	13	-
03802 2847	40101443	32	65	13	-
03802 2847	40101444	32	65	13	-
03802 4975	40101453	108	135	13	-
03802 5058	40101460	118	148	13	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 5034	40101470	115	140	13	-
03802 1789	40101600	60	77	12	14
03802 1789	40101603	60	77	12	14
03802 4277	40101610	66	92	19	-
03802 4757	40101623	90	130	14	-
03802 4967	40101643	105	136	13	-
03802 4154	40101693	60	90	13	-
03802 4392	40101700	70	100	13	-
03802 1089	40101720	25	49.5	14.5	-
03802 1089	40101723	25	49.5	14.5	-
03802 5326	40101730	180	200	17	-
03802 5190	40101770	140	167	13	-
03802 3659	40101843	48	65	10	-
03802 4240	40101973	65	85	12	-
03802 4128	40101983	60	80	12	-
03802 4365	40101993	70	90	12	-
03802 4229	40102033	65	80	14	-
03802 4483	40102043	75	110	14	-
03802 4618	40102053	85	100	14	-
03802 1789	40102090	60	77	12	14
03802 1789	40102093	60	77	12	14
03802 1073	40102100	128	152.3	11	26
03802 1073	40102103	128	152.3	11	26
03802 4272	40102130	65	100	14	-
03802 4272	40102133	65	100	14	-
03802 4833	40102140	95	130	16	-
03802 4833	40102140	95	130	16	-
03802 4833	40102143	95	130	16	-
03802 4797	40102163	95	115	12	-
03802 4559	40102173	80	100	12	-
03802 1929	40102213	87	105	6.5	11
03802 2036	40102223	137	164	4.5	6
03802 1797	40102263	60	90	14	16.3
03802 1849	40102270	70	90	13.5	14.5
03802 1849	40102273	70	90	13.5	14.5

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 1857	40102280	70	100	13.5	15
03802 1857	40102283	70	100	13.5	15
03802 1822	40102293	65	90	13	14.5
03802 1892	40102301	80	110	9	13
03802 1205	40102321	114.1	159.3	14	-
03802 2009	40102330	121	170	15.5	17
03802 2009	40102333	121	170	15.5	17
03802 5022	40102470	114	135	13	-
03802 4277	40102503	66	92	19	-
03802 3399	40102620	42	65	10	-
03802 4912	40102680	100	130	14	-
03802 4912	40102683	100	130	14	-
03802 5131	40102690	130	160	14	-
03802 5131	40102693	130	160	14	-
03802 2999	40102763	35	64	9	-
03802 3181	40102773	40	52	9	-
03802 2103	40102810	6	15	4	-
03802 1834	40102833	67	100	13	15
03802 1468	40102840	40	47	3.5	5.7
03802 1468	40102843	40	47	3.5	5.7
03802 1348	40102850	33	40	3.5	5.7
03802 1348	40102853	33	40	3.5	5.7
03802 2086	40102943	179	200	15.5	16.5
03802 4139	41487132	60	85	12	-
03802 4355	42003375	70	90	10	-
03802 4755	42003979	90	130	13	-
03802 5035	42031150	115	140	13	-
03802 5114	42031684	125	160	15	-
03802 2057	42043079	150	180	15	22
03802 5321	42127526	180	200	12	-
03802 5324	42127773	180	200	13.4	-
03802 4138	42480552	60	85	10	-
03802 3692	42480940	48	75	8	-
03802 3849	42484086	52	68	8	-
03802 3976	42484578	55	80	10	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4252	42485513	65	90	10	-
03802 3692	42485652	48	75	8	-
03802 4629	42485827	85	105	10	-
03802 4628	42486028	85	105	10	-
03802 4351	42486103	70	90	10	-
03802 4080	42486470	60	74	10	-
03802 2675	42486547	30	42	7	-
03802 3977	42486609	55	80	10	-
03802 4138	42487131	60	85	10	-
03802 3657	42487485	48	65	10	-
03802 3677	42487486	48	69	10	-
03802 4358	42487487	70	90	10	-
03802 1311	42488743	26	37	7	7.5
03802 4841	42490441	95.3	114.29	11.88	-
03802 4841	42490447	95.3	114.29	11.88	-
03802 4949	42492378	105	130	12	-
03802 4351	42493153	70	90	10	-
03802 4628	42493818	85	105	10	-
03802 4244	42520000	65	85	13	-
03802 5040	42520001	115	140	16	-
03802 3543	42521712	45	65	10	-
03802 5040	42523053	115	140	16	-
03802 2292	42530258	20	31	7.3	-
03802 2223	42530475	17	28	7.3	-
03802 3917	42531636	55	70	8	-
03802 1907	42531764	82.61	139.7	16.5	19.4
03802 3926	42531997	55	72	8	-
03802 2736	42532431	30	61.8	5	-
03802 3948	42533218	55	75	8	-
03802 1942	42534214	90	125	12	19
03802 4402	42534371	72	90	12	-
03802 2597	42534650	28	42	11	-
03802 1987	42534850	110.23	145	10	12
03802 3412	42534932	42	76	10	-
03802 2257	42534975	18	31	8	-



SNT AUTOPART ENTERPRISE, LLC. (U.S.A.)

SNT AUTOPART INTERTRADE CO., LTD

SNT MACHINE LTD., PART

WWW.SNTAUTOPART.COM

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4841	42535096	95.3	114.29	11.88	-
03802 5264	42535369	155	178	12	-
03802 4578	42536782	80	110	10	-
03802 4550	42536995	80	100	10	-
03802 5283	42537151	160	190	13	-
03802 4079	42538148	60	74	10	-
03802 3654	42538222	48	65	10	-
03802 4245	42538259	65	85	13	-
03802 2437	42538283	25	35	7	-
03802 4434	42540075	75	90	4.7	-
03802 4663	42541034	85	120	12	-
03802 3390	42541136	42	62	10	-
03802 1740	42545936	55	75	8	9.2
03802 2028	42548295	130	170	18	20
03802 4236	42549399	65	85	10	-
03802 3980	42549622	55	80	10	-
03802 4366	42550761	70	90	12	-
03802 2292	42551388	20	31	7.3	-
03802 2613	42551646	28	47	7	-
03802 1949	42554790	90	151	10	15
03802 5141	42554907	132	160	10	-
03802 1667	42557111	50	65	8	13.5
03802 3649	42557160	48	65	9	-
03802 3918	42557902	55	70	8	-
03802 1795	42558469	60	90	10	14.5
03802 3394	42558665	42	62	14	-
03802 4951	60188915	105	130	12	-
03802 5040	61581187	115	140	16	-
03802 4944	61581188	105	130	12	-
03802 4944	61586122	105	130	12	-
03802 5040	61586123	115	140	16	-
03802 3025	79019706	36	50	7	-
03802 2220	79023584	17	28	7	-
03802 2613	79043163	28	47	7	-
03802 2284	79045465	20	30	7	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 2284	79045965	20	30	7	-
03802 2289	79071380	20	31	7	-
03802 4528	86010588	80	95	8	-
03802 4786	86014686	95	110	10	-
03802 4655	86015484	85	110	13	-
03802 2307	86030036	20	37	6	-
03802 5069	93156558	120	140	13	-
03802 1309	93157023	26	34	4.5	7
03802 4080	93158332	60	74	10	-
03802 3390	93159257	42	62	10	-
03802 2289	93160144	20	31	7	-
03802 1056	93160191	76.33	122	14	16.9
03802 4667	93160765	85	140	17	-
03802 4290	93160829	68	85	10	-
03802 5115	93160832	125	160	17	-
03802 4579	93163157	80	110	10	-
03802 4579	93163158	80	110	10	-
03802 2028	93163213	130	170	18	20
03802 4402	93163220	72	90	12	-
03802 3798	93163800	50	80	8	-
03802 4549	93165539	80	100	10	-
03802 5069	93190312	120	140	13	-
03802 2654	93190507	30	37	4	-
03802 5166	93190679	135	165	12	-
03802 2898	93190736	35	47	7	-
03802 2468	93191207	25	40	15	-
03802 4796	93191591	95	115	10	-
03802 4506	93192322	78	93	4.7	-
03802 4550	93192567	80	100	10	-
03802 1056	93193136	76.33	122	14	16.9
03802 4939	93193253	105	125	12	-
03802 4192	93193359	63	55	9.4	-
03802 4841	93193398	95.3	114.29	11.88	-
03802 1545	93193760	42	55	4	8
03802 1155	93194335	82.6	155	19.4	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 4578	93194753	80	110	10	-
03802 3978	93804576	55	80	10	-
03802 1048	98427996	70	108	10	21.6
03802 3916	98427998	55	70	8	-
03802 4865	98436545	100	118	10	-
03802 3769	98451055	50	70	10	-
03802 3916	98454039	55	70	8	-
03802 3916	98454041	55	70	8	-
03802 3769	98454043	50	70	10	-
03802 3769	98454045	50	70	10	-
03802 1048	98454051	70	108	10	21.6
03802 1048	98454053	70	108	10	21.6
03802 4865	98454055	100	118	10	-
03802 4865	98454057	100	118	10	-
03802 1143	98461673	70	179	16	-
03802 3398	98461684	42	65	10	-
03802 5022	98461686	114	135	13	-
03802 4357	98467211	70	90	10	-
03802 1047	98467211	70	107	10	42
03802 5188	98467213	140	165	13	-
03802 3575	98467215	45	75	10	-
03802 4865	98486091	100	118	10	-
03802 3398	98488393	42	65	10	-
03802 5022	98488395	114	135	13	-
03802 4357	98494984	70	90	10	-
03802 1047	98494984	70	107	10	42
03802 5188	98494987	140	165	13	-
03802 3575	98494989	45	75	10	-
03802 5033	98499173	115	140	13	-
03802 1069	98499174	125	167	13	24.3
03802 4974	98499175	108	135	13	-
03802 5058	98499176	118	148	13	-
03802 1070	98499177	125	167	13	29.3
03802 4683	99447290	88	123	15	-
03802 5020	99447291	112	147	15	-

5. Seals product list

5.12 IVECO

SNT Part No.	Interchange Part No.	Size (mm)			
		Inner Diameter	Outer Diameter	Width 1	Width 2
03802 1204	99447458	114	177	13	-
03802 5022	99457401	114	135	13	-
03802 1204	99468744	114	177	13	-
03802 3398	99469265	42	65	10	-
03802 2031	500023256	132	172	12.5	14.5
03802 1143	500315684	70	179	16	-
03802 2880	500350049	34	60	10	-
03802 2031	503126456	132	172	12.5	14.5
03802 4509	503464835	78	100	10	-
03802 1156	504010779	83	13	12.2	-
03802 1183	504014232	90	13	12.5	-
03802 1143	504031409	70	179	16	-
03802 1143	504059359	70	179	16	-
03802 1204	504059361	114	177	13	-
03802 4912	504078251	100	130	14	-
03802 1156	504078511	83	13	12.2	-
03802 1143	504086312	70	179	16	-
03802 1143	504086313	70	179	16	-
03802 1204	504086314	114	177	13	-
03802 1204	504086315	114	177	13	-
03802 3805	504087648	50	80	11	-
03802 1156	504101720	83	13	12.2	-
03802 1156	504123771	83	13	12.2	-
03802 3807	504123772	50	80	14	-
03802 1211	504142000	130	14	13.5	-
03802 1183	504180969	90	13	12.5	-
03802 3805	504227240	50	80	11	-
03802 5131	504244493	130	160	14	-
03802 3774	504274032	50	70	11	-
03802 1083	504341691	18.85	27	11.8	-
03802 4738	5001861755	90	120	11	-
03802 1083	5801438487	18.85	27	11.8	-
03802 4913	5801625923	100	130	14	-
03802 1211	5801625924	130	14	13.5	-

SERVICE WORLDWIDE

For over 10 years, we have continuously strived to improve our business to efficiently meet every customer demand. Now, SNT is providing Worldwide Service that will help drive your business growth endlessly and sustainably.



SNT AUTOPART GROUP

HEADQUARTERS

SNT AUTOPART ENTERPRISE, LLC.

Empire State Building
350 Fifth Avenue, 59th Floor
New York, NY 10118 U.S.A.
Telephone: (+1)917-979-6883
Fax: (+1)917-979-6884
E-mail: info@sntautopart.com

ASIA-PACIFIC OFFICE

SNT AUTOPART INTERTRADE Co., Ltd.

All Seasons Place
36th Floor, CRC Tower,
87/2 Wireless Road, Pathumwan,
Bangkok 10330 Thailand
Telephone: (+66)2-105-6155
Fax: (+66)2-105-6155 Ext.4
E-mail: info@sntautopart.com

FACTORY

SNT MACHINE LIMITED PARTNERSHIP

18/3 Rama II Road,
Samaedam, Bangkhuntien,
Bangkok 10150 Thailand
Telephone: (+66)2-897-0968
Fax: (+66)2-897-0968
E-mail: info@sntautopart.com



www.sntautopart.com